

SR44 OPTIMIZING SOFT STARTERS

QUICK-START GUIDE:

INSTALLATION AND OPERATION OF THE SR44 SOFT STARTER

Guide To Contents

1 – Mechanical Outlines

Referring to the appropriate size of SR44, mount the SR44 ensuring that correct clearances are maintained for adequate ventilation and operation of the SR44.

2 – Wiring Diagrams

Referring to the appropriate Wiring Diagram, install the SR44 electrical connections ensuring that the correct control supply voltage is used and is within the specified operating limits as described on the product specification.




WARNING: Always replace the cover panel on the unit after gaining access to the electrical connections.

The unit requires two AC supplies:

- A three-phase balanced main power supply to provide the source of power for the controlled motor.
- A single-phase, 115/230V, 50/60Hz supply for the internal control circuit.

Control Voltage Selector Switch



WARNING: Ensure that the voltage selector switch position corresponds to the control supply before you apply the control supply voltage.



WARNING: The SR44 uses semiconductor devices in the main circuit, and is not designed to provide isolation. For this reason, isolation means must be installed in the supply circuit in accordance with the appropriate wiring and safety regulations.



*The Mains Supply and the Control Supply each require protection. Although all SR44 units have electronic overload protection, the installer should always place fuse protection **between** the unit and the Mains Supply; **NOT between** the unit and the motor. Semiconductor fuses can be supplied for short circuit protection of the semiconductors.*

3 – Keypad Operation and Basic Set-up

Refer to this section for familiarization with the keypad controls of the SR44. Use the illustration of the Basic Menu structure to find SR44 menu items on the display.



We highly recommend that you configure the SR44 by first selecting and setting an application from the “Applications” menu that is similar to your application. If necessary, you can then ‘fine-tune’ your configuration by changing the settings of other parameters and menu items.

4 – Set-up Examples

Set-up basic SR44 operating parameters, if necessary, by following one or all of the examples described in this section.

5 – Product Information

Refer to Product Information for details of Design Standards and Approvals, operating and storage limits, and other installation instructions.


Further Information

For further information about the SR44 soft starter motor controller, a detailed SR44 user manual is available on the AutomationDirect website:


<http://www.automationdirect.com/static/manuals/index.html>.

1 – Mechanical Outlines

Size 1: SR44-9 to SR44-146



Size 2: SR44-174 to SR44-370



Ventilation for Enclosures

When fitting an SR44 into an electrical enclosure, ventilation must be provided if the heat output of the unit is greater than the enclosure will dissipate.

If the enclosure cannot dissipate enough heat, use the following formula to determine the fan requirement. An allowance has been incorporated into the formula so that the figure for "Q" is the air delivery quoted in the fan supplier's data.

$$Q = (4 \times Wt) / (t_{max} - t_{amb})$$

- Q = required volume of air (cubic meters per hour; m³/h)
- Wt = heat produced by the unit and all other heat sources within the enclosure (Watts)
- t_{max} = maximum permissible temperature within the enclosure (40 °C for a fully rated SR44)
- t_{amb} = temperature of the air entering the enclosure (°C)

(If you prefer to work in CFM, substitute °F for °C. Q will then be in CFM, instead of m³/h.)

An approximation of the heat produced by the SR44 (in Watts) can be made by multiplying the Full Load Line Current by three. Exact figures for unit Full Load Current are available in the SR44 user manual.

2 – Wiring Diagrams

Fig 2.1 Control Circuit Wiring

Note: Contactor C3 is required for the 'Operation in Bypass Power Circuit', and is controlled by the programmable relay set as a 'Top of Ramp' relay.





Fig 2.2 Electronic Control Card

The electronic control card is located underneath the SR44 cover. Connections shown in the control circuit wiring diagram (Fig 2.1) are made to the electronic control card terminals as shown in Fig 2.2.



Connection for current transformer (CT):

J3 is factory prewired to SR44 internal CT. User-supplied external CT may be required for Bypass operation, depending upon other settings & parameters. If user-supplied external CT is required, remove the two pre-connected internal CT wires from J3 and short them together. Connect the two external CT wires to J3. Connection polarity is irrelevant.

Important: Be sure to set the Control Voltage Switch to the proper control voltage setting before applying voltage to the control circuit.

- 1) Power factor CORRECTION CAPACITORS must NOT be positioned on the output of the power circuit.
- 2) FUSE SELECTION: Where semiconductor type fuses are required, they should be selected from the table in Section 5.
- 3) The IN-LINE configuration shown in Fig 2.3 requires that the Firing Mode (Parameter 6) be set to '0' (Normal Motor).
- 4) The IN-DELTA configuration shown in Fig 2.4 requires that the Firing Mode (Parameter 6) be set to '1' (Delta).
[An in-line contactor controlled by the soft starter MUST be used with the In-Delta Firing Mode and motor connections.]

Use the control circuit with one of these power circuits:

The soft starter must be connected to a 3-phase power supply and a 3-phase load for proper operation. Attempted starts will result in a starter fault if either the 3-phase power or the 3-phase load is not connected.

Fig 2.3 Power Circuit for In-Line Motor Connections (SEE NOTE 3)




Fig 2.4 Power Circuit for In-Delta Motor Connections (SEE NOTE 4)
Mains Supply (V_e)





Fig 2.5 Power Circuit for Bypass Operation

NOTE: The "Auto Bypass" Auto Feature (P18/B2; P86/B2) should be ON for bypass operation. Using a bypass contactor with Auto Bypass in the OFF state can cause thyristor faults. ("ON" is the default "Auto Bypass" setting.)



3 – Keypad Operation and Basic Set-up



WARNING: ALWAYS ENSURE THAT THE KEYPAD CABLE IS PLUGGED IN BEFORE APPLYING POWER TO THE UNIT.


When wired as Fig 2.1, the SR44 display will indicate start up messages followed by 'Stopped and ready'.

At this point:


- The SR44 will start the motor when the keypad 'START/STOP' key is pressed, but not when the START switch (shown in Fig.2.1) is closed.
- The SR44 parameters are set to factory default, which may not be ideal for your required application.

The examples in the next section show how to set up some of the essential SR44 operating parameters using the keypad. Once these are understood, other SR44 settings, as indicated in the programming Menu Structure below, can be set in a similar manner. (The corresponding default settings are shown in brackets). For the full menu structure, refer to the SR44 User Manual.

Keypad controls



Menu Structure – typical keypad menu



Starter Enable/Disable

An additional safety feature has been added so that following certain actions of the starter, it will be disabled.



We strongly recommend that you disable the starter via the Basic Menu before making any changes to parameter values.

Once disabled, the starter remains unable to drive the load until it has been enabled via the Basic Menu, or until the control supply is removed and reapplied, or until the Down-arrow key is pressed when prompted.


4 – Set-up Examples



To keep Menu Item and Parameter setting changes, they must be permanently saved using the 'Permanent Store' menu, as shown below in Example 3.


Ex1: Setting the SR44 for Large Pump Application

- ① With 'Starter Disabled' shown on the display, press ENTER key.
- ② With 'Applications' shown on the top line of the display, press ENTER.
- ③ With 'Settings' shown at the top of the display, press ⇐ key until 'Large pump' is shown at top of display.
- ④ Press ENTER to select 'Large pump'. The display will indicate the parameters changing in short intervals.
- ⑤ With the display top line indicating 'Send to store?', press ENTER to save the settings for a large pump to permanent store. Display will flash the message 'Storing' twice to indicate this has been done.
- ⑥ At any of the above stages, pressing # will return the user to the previous menu. The SR44 will not start until the control display indicates 'Stopped and ready'.



Ex2: Setting the SR44 for Remote Starting and Stopping

- ① With 'Starter Disabled' shown on the display, press ENTER key.
- ② With 'Applications' shown on the top line of the display, press ⇐ key until 'Basic' is shown at the top of the display.
- ③ Press ENTER to select 'Basic' menu.
- ④ Press ⇐ key until 'Starting' is shown at top of the display. Then press ENTER to select starting option menu.
- ⑤ With display now indicating 'Starting' on top line, press ENTER to toggle from 'Keypad Starting' to 'Remote Starting' as shown on bottom line of display.
- ⑥ At any of the above stages pressing # will return the user to the previous menu.




The SR44 will now start and stop remotely from the START and STOP switches shown in Figure 2.1, but will return to keypad starting if the control supply is removed from terminals X1 and X2. Alternatively, to return to keypad starting and stopping, repeat the above procedure and select 'Keypad Starting' at step 5.

To keep the remote start/stop setting after removal of the control supply, the settings must be permanently saved (see Ex3 below).

Ex3: Permanently Saving Parameters Set by User

- ① With 'Starter Disabled' shown on the display, press ENTER key.
- ② With 'Applications' shown on the top line of the display, press ⇐ key until 'Permanent Store' is shown at top of display.
- ③ Press ENTER to select 'Permanent Store' menu.
- ④ With 'Save Param' shown at top of display, press ENTER to permanently save parameters. Display will flash twice to indicate that this has been done.
- ⑤ At any of the above stages pressing # will return the user to the previous menu.



5 – Product Information

5.1 – Design Standards and Approvals

- CE
- IEC 60947-4-2; EN 60947-4-2 – ‘AC Semiconductor Motor Controllers and Starters’
- RoHS
- UL* –  – Listed to U.S. and Canadian safety standards – E333109
* Options SR44-KPD & SR44-RS485 are not UL approved

5.2 – Basic Ratings

SR44 Basic Ratings			
	Connector/Terminal	SR44 Range	Rated Frequency
Rated Operational Voltage	L1, L2, L3	230–460 VAC (-15% +10%)	50/60 Hz (±2 Hz)
Control Supply Voltage (V _s)	X1, X2	115 or 230 VAC (-15% +10%)	
Control Input Voltage (V _c)	S0, S1	12/24 VDC or 115/230 VAC	
Output Relays	11,12,14 and 21,22,24	AC1 230V, 3A; 24 VDC, 3A	
Rated Operational Current (I _e)	see semiconductor fuse types table in section 5.4		
Form Designation	Form 1		

Index Ratings (per IEC 60947-4-2)


SR44 Index Ratings *			
Model #	I _e (A)	Standard Operation AC-53a; X-Tx; F-S	Bypassed Operation AC-53b; X-Tx; OFF-time
SR44-9 to SR44-105	9 to 105	AC-53a: 5-4; 99-10 AC-53a: 3-35; 99-10	AC-53b: 5-4; 120 AC-53b: 3-35; 120
SR44-146 to SR44-202	146 to 202	AC-53a: 4-6; 99-10 AC-53a: 3-35; 99-10	AC-53b: 4-6; 120 AC-53b: 3-35; 120
SR44-242 to SR44-370	242 to 370	AC-53a: 4-6; 60-3 AC-53a: 3-35; 60-3	AC-53b: 4-6; 420 AC-53b: 3-35; 420

* Index ratings AC-53a and AC-53b are specified by IEC standard # 60947-4-2


In line with the stated IEC starting duties, starters of 242 Amps and above have an enforced off period of seven minutes set as standard. During this period the display indicates “Stopped. Cooling”, and the starter will not respond to a start signal.

IEC Index Ratings are comprised of Rated Operational Current (I_e), Utilization Category, Overload Current Profile (X-Tx), and Duty Cycle (F-S) or OFF-time.


Index Rating Example - Standard Operation (AC-53a Utilization Category per IEC 60947-4-2)



Index Rating Example - Bypassed Operation (AC53b Utilization Category per IEC 60947-4-2)



5.3 – Overload



‘Current limit’, ‘Overload level’ and ‘Overload delay’ settings may be adjusted to limit overload currents in accordance with the trip curves shown here (see Menu Structure in Section 3 for default settings).

» For motors with FLCs lower than the rated current of the SR44, the ‘Overload level’ may be adjusted using the following formula:

$$\text{Overload Level} = \text{Motor FLC} \times 1.1(A)$$

Note:

The overload monitors only one of the phases, and the ‘Current Limit’ level is active only during motor starting.

IMPORTANT:

We recommend that the control supply is maintained between starts to ensure the integrity of the overload, which will reset on its removal.

5.4 – Safety and Installation

Rated Insulation Voltage (V_i)	690V
Ingress Protection	IP20
Pollution Degree	3
Short Circuit Coordination	Type 1

UL requires Recognized special purpose fuses (JFHR2) for the protection of semi-conductor devices, rated 700 VAC, as indicated in Table 5.4, be used to obtain the short circuit ratings required by UL.

Suitable for use on a circuit capable of delivering not more than the RMS Symmetrical Amperes indicated in Table 5.4 at maximum rated operational voltage, when protected by Semiconductor Fuse type, Manufactured by Company and Model Number indicated in Table 5.4. Fuse rated 700 VAC, Amps as indicated in Table 5.4.

These fuses are for short circuit protection of the semiconductors and must be mounted externally by the user between the unit and the mains supply; not between the unit and the motor.

Model Name	I _e (A)	Short Circuit Withstand (kA)	UL Recognized JFHR2 Fuses		
			Bussman Model #	Mersen (formerly Ferraz) Model #	Amps
SR44-9	9	5	170M3110	6.9 URD 30 D08A 0063	63
SR44-16	16		170M3112	6.9 URD 30 D08A 0100	100
SR44-23	23		170M3114	6.9 URD 30 D08A 0160	160
SR44-30	30		170M3115	6.9 URD 30 D08A 0200	200
SR44-44	44		170M3116	6.9 URD 30 D08A 0250	250
SR44-59	59	10	170M3119	6.9 URD 30 D08A 0400	400
SR44-72	72		170M3121	6.9 URD 30 D08A 0500	500
SR44-85	85		170M4114	6.9 URD 31 D08A 0500	500
SR44-105	105		170M4116	6.9 URD 31 D08A 0630	630
SR44-146	146		18		
SR44-174	174				
SR44-202	202				
SR44-242	242				
SR44-300	300				
SR44-370	370				

5.5 – Normal Service Conditions

SR44 Normal Service Conditions	
Ambient Temperature	0 to 40 °C [32 to 104 °F] – Above 40 °C derate linearly by 2% of unit FLC per °C to a maximum of 40% at 60 °C [140 °F]
Transport and Storage	-25 to +60 °C [-13 to +140] (continuous) – -25 to +75 °C [-13 to +167 °F] (not exceeding 24 hours).
Altitude	1000m [3281 ft] – Above 1000m derate linearly by 1% of unit FLC per 100m to a maximum altitude of 2000m [6562 ft]
Humidity	max. 85% non-condensing, not exceeding 50% at 40 °C [104 °F].

5.6 – EMC Emission and Immunity Levels

EMC compliance is in accordance with EN 60947-4-2, which refers to the following basic standards.

SR44 EMC Compliance (in accordance with EN 60947-4-2 *)		
	Basic Standard	Level
IMMUNITY Severity Level 3	IEC 61000-4-2	6kV contact or 8kV air discharge
	IEC 61000-4-6	140dBuV over 0.15–80 MHz
	IEC 61000-4-3	10V/m over 80–1000 MHz
	IEC 61000-4-4	2kV / 5kHz
	IEC 61000-4-5	2kV line to ground and 1kV line to line
EMISSION Equipment Class A (Industrial)	EN 55011	Class A
* EN 60947-4-2 is published as a harmonized standard under European Council Directive No. 2004/108/EC in relation to the electromagnetic compatibility.		

5.7 – Control, Power, and Ground Terminations; Cover & Gland Plate Screws

Control Terminal Specifications

SR44 Control Terminal Specifications							
Terminals	Terminal Type	Wire Type	Cable Cross Section				Tightening Torque
			AWG		mm ²		
			Min	Max	Min	Max	
X1, X2 S0, S1 11, 12, 14 21, 22, 24	screw clamp terminals (with captive screws)	solid or stranded	22	14	0.3	2.5	4.4 lb-in [0.5 N·m]

Power and Ground Terminal Specifications

SR44 Power and Ground Terminal Specifications								
Soft Starter Model	Terminals		Terminal Type **	Conductor Type	Cable Cross Section *		Busbar *	Tightening Torque
					AWG	mm ²	mm ²	
Size 1: SR44-9 to SR44-146	Power	L1, L2, L3 T1, T2, T3	M8 metric threaded studs	Use 75 °C copper (CU) conductor only, and the wire shall be fitted with close eyelet lug	1/0	50	n/a	106 lb-in [12 N·m]
	Ground	PE 	M8 metric threaded stud					
Size 2: SR44-174 to SR44-370	Power	L1, L2, L3 T1, T2, T3	M8 metric threaded studs	Use 75 °C copper (CU) conductor only, and the wire shall be fitted with close eyelet lug, or use busbar	2 x 250 MCM	2 x 120	20 x 6	
	Ground	PE 	M8 metric threaded stud					
* The indicated conductor sizes are the maximum allowed by UL for each chassis size. The actual conductors used must comply with local wiring regulations.								
** Power and Ground terminal studs include M8 nuts, flat washers, and lock washers. Termination requires ring lugs with hole diameter > 0.3075 in [7.81 mm].								

To maintain approvals for cable connections, the Wire Terminals should be UL Listed or Recognized Wire Connectors and Soldering Lugs, fitted to the wire with special Crimping Tools as indicated by the manufacturer.

 The owner, installer, and user are responsible for the correct installation and use of the SR44, and must ensure that only qualified personnel install the SR44, and that the installation, operation, and maintenance of the unit comply with the relevant Codes of Practice, Regulations and Statutory Requirements. The Manufacturer or his agent do not assume any liability, expressed or implied, for any consequence resulting from inappropriate, negligent or incorrect installation, application, use, or adjustment of the product or circuit design, or from the mismatch of the unit to a motor. To prevent an electrical shock hazard the SR44 must be connected to a safety ground. The unit is not designed for use in hazardous areas. Use in such an area may invalidate the hazardous area certification.

Cover & Gland Plate Screw Specifications

Cover and gland plate removal is required for access to electrical terminals.

SR44 Front Cover and Gland Plate Screw Specifications			
Soft Starter Model	Cover	Screw Type	Tightening Torque
Size 1: SR44-9 to SR44-146	Front Cover	(2) captive M5x20 POZI screws + spring & plain washers; held captive with M4 nylon 6/6 washers	30 lb-in [3N·m]
	Gland Plates (upper & lower)	(4) M5x10 POZI screws & shake-proof washers	
Size 2: SR44-174 to SR44-370	Front Cover	(2) captive M5x12 POZI screws + spring & plain washers; held captive with M4 nylon 6/6 washers	
	Gland Plates (upper & lower)	(4) M5x10 POZI screws & shake-proof washers	