



**Ferguson Beaugard iMonitoring iNodes**

**TLM<sub>e</sub>**

**Ultrasonic Tank Level Monitor**

**User Installation and Operating Manual**

## Table of Contents

<b>Introduction.....</b>	<b>4</b>
<b>What is an iMonitoring Tank Level Monitor (TLMe)? .....</b>	<b>4</b>
<b>Principal features of the TLMe .....</b>	<b>4</b>
<b>Additional support documentation .....</b>	<b>5</b>
<b>TLMe installation.....</b>	<b>6</b>
<b>Tank mounting.....</b>	<b>6</b>
<b>Solar panel lighting.....</b>	<b>8</b>
<b>Installation procedure .....</b>	<b>8</b>
<b>iNodeConfig .....</b>	<b>9</b>
<b>PDA version .....</b>	<b>10</b>
iNodeConfig PDA screen layout.....	10
<b>PC version .....</b>	<b>12</b>
iNodeConfig PC screen layout.....	12
<b>Device Selection screen.....</b>	<b>14</b>
Device Selection screen actions .....	14
Device Selection menus .....	15
CFR screens .....	17
<b>Data screen .....</b>	<b>20</b>
Data values and definitions .....	20
Data screen actions.....	21
Data screen menus .....	21
<b>Data log screen.....</b>	<b>25</b>
Data log screen actions.....	25
Data log menus.....	26
<b>Config screen.....</b>	<b>28</b>
Config screen actions .....	28
Config menus .....	29
Site calibration .....	31
Preparation for calibration.....	31
Calibration.....	32
<b>Thresholds screen .....</b>	<b>34</b>
Thresholds screen actions .....	34
Thresholds menus .....	35
<b>Alarms page .....</b>	<b>36</b>
Alarms page actions .....	36
Alarm menus .....	37
<b>Status screen.....</b>	<b>39</b>
Status screen actions .....	40
Status menus .....	40
<b>Firmware screen .....</b>	<b>43</b>
Firmware screen actions.....	43

Firmware menus.....	44
<b><i>TLMe Specifications</i></b> .....	<b>45</b>

## Introduction

### *What is an iMonitoring Tank Level Monitor (TLMe)?*



**Figure 1. The TLMe.**

The Ferguson Beauregard Tank Level Monitor (TLMe) is used to measure fluid levels ultrasonically in tanks and silos. Part of the iNodes suite of wireless sensors, it delivers data remotely over the Internet or locally to any Compact Flash Radio-enabled computer. The TLMe eliminates the need for daily tank gauging, providing 24-hour production data with consistent daily data collection times.

#### ***Principal features of the TLMe***

- Eliminates the need for manual daily tank gauging.
- Uses advanced ultrasonic sensing technology.
- Reports fluid depth or distance to fluid.
- Collects daily production data consistently.
- Provides consistent 24-hour production data with programmable data collection times.
- Includes power supply, data storage, processing and bidirectional radio communications in a small, integrated package.

- Certified intrinsically safe.
- Communicates with any Compact Flash Radio-enabled PC, including pen tablet PCs, PDAs and our Concentration & Communications Unit.
- Solar powered with backup battery.
- Rugged IP-65 rated enclosure.
- Field configurable and upgradeable.
- Low cost.
- Basic alarm capabilities (alarm service optional).

### ***Additional support documentation***

More detail on mounting options, calibration and other features can be found in the Ferguson Beauregard Installers' Guide, which presents in-depth information on all iNode devices. The Installers' Guide can be downloaded from the FB Customer Support website (<http://sw.fergusonbeauregard.com>) in the iNode Products section.

## TLMe installation

The TLMe measures tank fluid levels ultrasonically, using a technique similar to radar. It transmits a pulse which reflects off the liquid surface and returns to the TLMe. The TLMe measures the pulse “flight time”, then compensates for the effect of temperature on the speed of sound. It is important to mount and install the TLMe correctly to obtain the most accurate and reliable level measurements.

### Tank mounting

1. For best accuracy the TLMe must be mounted at right angles to the fluid surface  $\pm 2$  degrees. This maximizes the signal strength of the reflected signal for best measurement accuracy.
2. At 260 inches (about 21 feet), there must be at least 15 inches of clearance from the center of the beam to any obstacles such as internal tank braces. This minimizes any reflections or weakening of the signal, improving measurement accuracy.

Figure 1 below shows a properly installed TLMe. Figure 2 and Figure 3 show two TLMe field installations. Figure 2 is the preferred mounting method.





Figure 2. Proper TLMe mounting angle.



Typical beam clearance from any obstacles.



**Figure 3. Preferred mounting method on a 2" NPT non-vent pipe.**



**Figure 4 Mounting on a 2" NPT vent pipe.**

## **Solar panel lighting**

The TLMe power supply contains a solar panel, high-capacity rechargeable battery, charging circuit and regulator. When fully charged the TLMe will typically operate for at least two weeks without sunlight.

Manmade lighting such as fluorescent or incandescent lights will not generate sufficient power for continuous operation. The TLMe must be mounted so that the solar panel is exposed to ambient sunlight.

## **Installation procedure**

When the TLMe is installed, it must be provisioned in its intended configuration. The installation must comply with all regulatory and safety requirements. With the exception of those items listed in the **TLMe installation instructions**, the TLMe is shipped with factory default calibration and configuration settings.

1. If you are unfamiliar with iNodeConfig or TLMe installation, review the **Site Calibration** and **iNodeConfig** sections of this manual before beginning.
2. Remove the TLMe from its packing box.
3. Remove the Phillips head reset button access screw on the bottom of the unit (Figure 5). Using a non-metallic tool, press and hold the reset button briefly to bring the unit out of sleep mode, then replace the screw and lightly tighten it.



**Figure 5. Reset button access screw.**

4. Drop a gauging tape into the pipe fitting where the TLMe will be attached. Measure and record the distance from the bottom of the tank to the top of the fitting. This is the tank height.
5. Screw the TLMe temporarily into the pipe fitting (Figure 2 or Figure 3). Mark the last exposed thread on the TLMe bushing and remove the unit. Measure and record the distance from the thread to the sensor face. This is the head offset.
6. Permanently mount the TLMe to the tank fitting.
7. Install the antenna.
8. Configure the TLMe as instructed in the **iNodeConfig Configuration screen** section.
9. Calibrate the TLMe as instructed in the **iNodeConfig Site Calibration** section.



## iNodeConfig

Local communication with iNodes is necessary for setup and maintenance. The same radio system used to collect data from iNodes by the CCU also supports local communications. The local communications software, called **iNodeConfig**, allows you to configure iNodes, set controls and view or save data and configurations.

There are two versions of iNodeConfig: **iNodeConfig-PDA**, which runs on PDAs with the Windows CE operating system, and **iNodeConfig-PC**, which runs on laptops and PCs with Windows 2000, NT or XP. An iMonitoring Compact Flash Radio card (CFR) is required. The two versions are as similar as possible to minimize confusion when switching between a PDA and a laptop.

The following sections start with the leftmost user screen and move to the right, one screen at a time. Each user screen shown on the iNodeConfig screen toolbar is denoted by bold type, e.g. “**Data** screen”. Configuration or selection items within each screen are denoted by bold type, e.g. “**Configure**”.

In these sections you will often be instructed to “tap” a button or location on the screen. On the PDA, this means tapping the button or location with the PDA stylus. On PCs, this means moving the cursor over the button or location, then tapping on a mouse pad, or clicking with the left mouse button.

Whenever possible, iNodeConfig PDA and PC screen figures are shown side by side so that you can see the similarities and differences between them. In larger screens, the PDA screen are shown first and the PC screen are shown second.

The main differences between iNodeConfig for the PC and PDA are:

- The PDA version uses the Windows CE standard tools and features, particularly the keyboard icon and OK button at the top right of the screen. The PC version uses the Windows standard tools: Minimize – Maximize – Close buttons at the top right of the screen, sizeable windows, etc.
- The PC version has no keyboard icon.
- The PDA page tabs run across the bottom of the screen. The PC page tabs run across the top of the screen.

## PDA version

iNodeConfig requires about 800KB of storage space. There is no setup application; copy the iNodeConfig fileset into a folder on the PDA. Use File Explorer to browse to the iNodeConfig folder and tap the “iNodeConfig” icon to start iNodeConfig. See your PDA documentation for instructions on copying files to folders and creating start menu icons.

## iNodeConfig PDA screen layout




Figure 6. iNodeConfig-PDA firmware screen.

All iNodeConfig-PDA screens have similar views and tools. The Firmware page, which you can select after connecting to a TLMe, contains most of them, which will be referred to as follows:


- **OK button:** The white circle at the top right of the screen containing the letters “ok”. If you tap this button on this page, iNodeConfig will return to the Connection page (more on this later).
- **Upper window:** Some pages have only one window; others, like the Firmware page, have two. The upper window usually contains one or more items that can be selected.
- **Lower window:** This window usually contains information items.

- **Update Firmware box:** Most pages have one or more action boxes like this one. If you tap a box, the action described by the box text is performed.
- **Keyboard icon:** This is part of the PDA operating system. If you tap this icon, a keyboard will pop up to allow you to enter text and numbers. iNodeConfig usually will pop up the keyboard automatically if you tap an editable value.
- **Tab arrows:** There is a tab to select each page. In most cases, not all tabs can be displayed at the same time. You can tap the left (◀) and right (▶) tab arrows to slide the tab set so you can locate the tab you want to choose.
- **Firmware tab:** Eight pages can be chosen after you connect to a TLMe with iNodeConfig. These pages are chosen by tapping the tab of the page you want to see.
- **File menu:** Most pages have pull-up menus, located at the bottom left of the screen. If you tap a menu, one or more choices will pop up. File choices relate to importing and exporting types of files into iNodeConfig.

## PC version

iNodeConfig-PC uses about 6MB of disk space. A setup application is used to install iNodeConfig on your PC. After installation, use File Explorer to browse to the iNodeConfig folder and tap the “iNodeConfig.exe” icon to start iNodeConfig. (You may want to copy and paste the icon as a shortcut to your laptop’s desktop for quick access to the program.)

## iNodeConfig PC screen layout




## FIRMWARE PAGE

Figure 7. iNodeConfig-PC firmware screen.

All iNodeConfig PC screens have similar views and tools. The Firmware page, which you can select after connecting to a TLMe, contains most of them, referred to as follows:

- Windows buttons (Minimize, Maximize, Close): The standard Windows buttons. They behave as in other Windows programs.
- Upper window: Some pages have only one window; others, like the Firmware page, have two. The upper window usually contains one or more selectable items.
- Lower window: This window usually contains information items.
- **Update Firmware** box: Most pages have one or more action boxes like this one. If you tap a box, the action described by the box text is performed.
- **Firmware** tab: Eight pages can be chosen after you connect to a TLMe with iNodeConfig. These pages are chosen by tapping the tab of the page you want to see.
- **File** menu: Most pages have pull-down menus, located at the top left of the screen. If you tap a menu, one or more choices will be presented. File choices mainly relate to importing and exporting types of files into iNodeConfig.

## Device Selection screen



The first screen iNodeConfig displays is the Device Selection page.

### Device Selection screen actions

- Choose an iNode device from the ESN list.
- Find iNodes and automatically add their ESNs to the list.
- Clear ESNs from the list.
- Enter an iNode ESN manually.
- Configure the CFR.
- Create a Device Group and assign a Group ID to the Group.
- Enter the Setup and Help screens.

To choose an existing iNode device from the ESN list:

- Tap the ESN for the iNode.
  - If you double-tap, the ESN appears in the ESN box, or
  - Tap the > box and the selected ESN appears in the ESN box.
- Tap **Connect**.

To make iNodeConfig find iNodes and add them to the ESN list:

- Tap the **Find Devices** checkbox.
- The bar beneath **Find Devices** scrolls back and forth as iNodeConfig searches for iNodes.
- As iNode ESNs are found, they are added to the ESN list. Each added ESN will have an \* beside its ESN.
- Tap the checkbox again to stop finding iNodes.

To clear ESNs from the ESN list:

- Tap an ESN to highlight it.
- Tap **Clear**.

To manually enter an ESN:

- Tap the Keyboard icon at the bottom right of the PDA screen. The keyboard will pop up.
- Tap inside the ESN box.
- Use the keyboard to enter the ESN. Valid characters are numbers “0” through “9”, and letters “a” through “f”.
- If you want to save the ESN in the ESN list, tap the < box to the left of the ESN box. The ESN is copied to the ESN list.
- Tap **Connect**.

To configure a Device Group and assign a Group ID:


- Contact iMonitoring Customer Support if you want to learn more about this feature.

## Device Selection menus

- **Setup.**
- **Action.**
- **Help.**

**Setup** menu items:

- Options.
- Group IDs.
- Admin Privileges.
- Demo Mode.



The Options screen allows you to:

- Set behavior with contention and the number of retries.
- Show CFR status messages.

Change these settings as needed, then tap the **OK** box to enable the changes and return to the Device Selection screen, or tap the **Cancel** button to exit without making changes.

*Contention* takes place when another iNode, iNodeConfig or a SCADA radio system is transmitting as you try to communicate with a device - the signals interfere with each other. iNodeConfig will detect contention, display a Contention error and stop transmitting. If Ignore Contention is checked, iNodeConfig will continue to transmit even if there is contention and no error will be displayed. This is usually an undesirable setting, since it allows you to interfere with other device communications. The default setting is disabled (unchecked).

*Retries* sets the number of times iNodeConfig will try to establish communications with an iNode before quitting. In situations where there is more interference, more retries may be needed. You can choose 0 through 10 retries (default = 3).

*Show CFR status messages* allows you to watch the communications progress and messages between a CFR and an iNode. Expert users enable status messages when troubleshooting communications problems. Leave this feature disabled unless instructed by iMonitoring.

### Group IDs

Groups are used to prevent unauthorized access to iNode data. This feature is risky, as it is possible to lock users out of devices if the group code is lost or forgotten. Contact iMonitoring for instructions on the configuration and use of this feature.

### User Levels

Three user levels are defined in iNodeConfig: Pumper, Installer and Administrator. A Pumper can view data but not make configuration changes. An Installer can view data and fully configure the iNode. The Administrator can change an iNode's ESN, shut it down, etc. The default level is Installer. Administrator level requires a password.

### Demo Mode

Demo mode allows you to simulate viewing data and configuring an iNode without making connection to a real device. This option is used in training.

**Action** menu item selections:

- Clear Device List
- Find Devices
- Connect to Device...
- Configure CF Radio



Clear Device List clears all ESNs in the Device List. A caution box is displayed, asking if you're sure you want to clear the list. If you tap **Yes**, the list is cleared.

Find Devices performs the same action as the **Find Devices** checkbox.

Connect to Device ... is the same as the **Connect** button.

Configure CF Radio is the same as the **CF Radio** button.

The **Help - About** screen displays the iNodeConfig files and versions.

## CFR screens

Tap the **CF Radio** button to view the CFR screens. The **Config** screen displays CFR information: ESN, transmit cypher, power setting, firmware version and board revision. The **Firmware** screen is used to update the CFR firmware.




Figure 8. CFR screens on the PDA.

**CAUTION:** Do not update CFR firmware without direction from iMonitoring customer support.

To close the CFR screen, tap the **OK** circle button or the Windows Close (X) button. iNodeConfig returns to the Device Selection screen.




Figure 9. CFR screens on the PC.

The **Config** page displays the CFR's current device settings. Tap the **Refresh** button to refresh the information on this screen.

### *Config menus*

There is only one **Config** menu item selection: **Action** > Refresh, which is the same as the **Refresh** button.

The **Update** screen displays the CFR firmware revision and any available firmware updates.

To update CFR firmware:

- On the PDA, CFR firmware files must be stored in the iNodeConfig folder. On the PC, you can browse to other folders to find CFR firmware files. All CFR firmware files will be listed in the upper window of the Firmware page. To see available firmware, tap **File** > Refresh Available Updates.
- Tap the firmware (.hex) file you want to highlight it. Example: "CFRv3 3.03.02.hex" is Version 3.03.02.
- Tap **Update Firmware**. The selected file will be loaded into the CFR's flash memory.
- The new firmware version will be displayed on the **Update** screen.

### *Firmware menus*

- **File.**
- **Action.**

**File** menu item selections:


- Browse directories.
- Refresh available updates.

- Update firmware.
- Refresh version info.

### Browse Directories ...

PDA: Nonfunctional.

PC: You can browse to any directory, tap a folder, then tap **OK**. To see the update files, tap **File** > Refresh Available Updates.



Refresh Available Updates ... If you copied a new CFR firmware file into the iNodeConfig folder on your PDA, tap Refresh Available Updates to display the new file in the upper window without closing and restarting iNodeConfig.

Update Firmware is the same as the *Update Firmware* button.

Refresh Version Info. If the firmware has been updated, this will display the new firmware version.

## Data screen




Figure 10. Data screen.

After connecting to the TLMe, iNodeConfig displays the Data screen, containing data related to tank liquid depth and important operating information. You can choose from three data formats:

- Transducer data (the most current data),
- RTU data (the data sent to an RTU),
- SatCom data (the last data sent to the iCCU).

### Data values and definitions

Item	Definition
TLMe ESN	Electronic Serial Number (ESN) of the TLMe
Level	The fluid depth.
Range	The distance from the TLMe to the fluid surface.
RESERVED	Not used.
Temperature	The temperature at the TLMe head.
Energy level	The charge in the battery in percent.
RSSI margin (dB)	The Received Signal Strength Indicator value, a measure of the signal strength received by the TLMe.
Device status	Indicates alarm conditions. If an alarm is present, a code and a brief fault description are displayed, otherwise it displays "Normal".

Version	The TLMe firmware version.
Drop in top level, Drop time span	If the level drop alarm is enabled, these will display the level drop in feet and inches, and the drop time. See the <b>Alarms</b> section.

## Data screen actions

- View and refresh the current TLMe data.
- Export (save) the data to a file.
- Run a data loop test.

## Data screen menus

- **File.**
- **Action.**

## File menu item.

- Export...

To export the data displayed on the TLMe Data screen to a Comma Separated Variable (CSV) file, tap **File** > Export... iNodeConfig will display the Save As screens, shown in Figure 11.





Figure 11. File Export, Save As screens.

- On the PDA,
  - Enter a filename.
  - Choose a folder. Tap the ▼ arrow beside the Folder box to list all folders.
  - Choose a location. Tap the ▼ arrow beside the Location box for a list of memory locations: Main Memory, Built-In Storage, or SD Card. (The SD card is the most reliable, as it does not need a battery to retain its memory.)
  - Tap **OK**.

- On the PC,
  - Type a name for the file.
  - Browse to a folder.
  - Tap **Save**.

**Action** menu items.

- Refresh. Refreshes the data displayed on the screen.
- Data loop... When Data Loop is enabled, iNodeConfig will periodically collect data from the TLMe. After selecting Data Loop, the Frequency dialog box, which allows you to set the data collection rate, is displayed:



After choosing a Frequency, tap **OK**. The collected data is displayed, most recent data at the top of the page.

TLM1 - 0000 0362 4:06 ok

Time	Level	Range	RESERVED	Te
16:06:09	n/a	8' 0"	n/a	74
16:06:05	n/a	8' 0"	n/a	74
16:06:02	n/a	8' 0"	n/a	74
16:05:59	n/a	8' 0"	n/a	74
16:05:57	n/a	8' 0"	n/a	74
16:05:55	n/a	8' 0"	n/a	74
16:05:52	n/a	8' 0"	n/a	74
16:05:50	n/a	8' 0"	n/a	74
16:05:48	n/a	8' 0"	n/a	74
16:05:39	n/a	8' 0"	n/a	74
16:05:36	n/a	8' 0"	n/a	74
16:05:33	n/a	8' 0"	n/a	74
16:05:31	n/a	7' 11....	n/a	74
16:05:28	n/a	7' 11....	n/a	74
16:05:26	n/a	7' 11....	n/a	74
16:05:24	n/a	7' 11....	n/a	74
16:05:22	n/a	7' 11....	n/a	74

File Setup

Data Loop

File Setup

Time	Level	Range	RESERVED	Temperature	Energy level	RSSI margin (dB)	Device status	Version	Drop in level	Drop time span (min)
16:05:09	n/a	8' 0"	n/a	74.57°F	90 %	28.71	Normal	00.04.00.06	n/a	n/a
16:05:06	n/a	8' 0"	n/a	74.57°F	90 %	28.12	Normal	00.04.00.06	n/a	n/a
16:05:03	n/a	8' 0"	n/a	74.57°F	90 %	28.95	Normal	00.04.00.06	n/a	n/a
16:05:00	n/a	8' 0"	n/a	74.57°F	90 %	28.24	Normal	00.04.00.06	n/a	n/a
16:04:57	n/a	8' 0"	n/a	74.58°F	90 %	27.53	Normal	00.04.00.06	n/a	n/a
16:04:54	n/a	8' 0"	n/a	74.60°F	90 %	28.83	Normal	00.04.00.06	n/a	n/a
16:04:51	n/a	8' 0"	n/a	74.57°F	90 %	28.00	Normal	00.04.00.06	n/a	n/a
16:04:48	n/a	8' 0"	n/a	74.57°F	90 %	27.88	Normal	00.04.00.06	n/a	n/a
16:04:45	n/a	8' 0"	n/a	74.57°F	90 %	27.41	Normal	00.04.00.06	n/a	n/a
16:04:42	n/a	8' 0"	n/a	74.58°F	90 %	29.07	Normal	00.04.00.06	n/a	n/a
16:04:39	n/a	8' 0"	n/a	74.55°F	90 %	27.76	Normal	00.04.00.06	n/a	n/a
16:04:36	n/a	8' 0"	n/a	74.57°F	90 %	28.00	Normal	00.04.00.06	n/a	n/a
16:04:33	n/a	8' 0"	n/a	74.56°F	90 %	28.12	Normal	00.04.00.06	n/a	n/a
16:04:30	n/a	8' 0"	n/a	74.56°F	90 %	27.88	Normal	00.04.00.06	n/a	n/a
16:04:27	n/a	8' 0"	n/a	74.57°F	90 %	27.65	Normal	00.04.00.06	n/a	n/a
16:04:24	n/a	8' 0"	n/a	74.59°F	90 %	28.60	Normal	00.04.00.06	n/a	n/a
16:04:21	n/a	8' 0"	n/a	74.60°F	90 %	28.60	Normal	00.04.00.06	n/a	n/a
16:04:18	n/a	8' 0"	n/a	74.57°F	90 %	28.24	Normal	00.04.00.06	n/a	n/a

Figure 12. Data loop screens.

**Data Loop records:**

- Time of collection
- Level
- Range
- Temperature
- Energy level
- RSSI margin
- Device status
- Version
- Drop in level
- Drop time span

To save the data, you must enable data logging. **NOTE:** Any data displayed before data logging is started cannot be saved later. See **File** > Log Data below.


### *Data Loop menu selections*

- **File.**
- **Setup.**

**File** menu item.

- Log Data...

Log Data allows you to save Data Loop data to a CSV file. If you select this feature, the **Save As** dialog is displayed. (This is not the same as the **Data Log** screen, explained in the next section.)



To log data,

- Enter a file name.
- Choose a folder.
- Tap **OK** or **Save**.

PDA's cannot display CSV files directly. You must first move it to a laptop or desktop PC with ActiveSync, then open it with a spreadsheet program. Logging will continue until you exit the Data Loop page (tap **OK**). The PC can display the file contents if it has a spreadsheet program.

**Setup** menu item:

- Options redisplay the Frequency dialog.



## Data log screen.

The TLMe keeps a data log for later review. This log can be downloaded and saved from the Data log screen.

Date	Time	Range	Temp...
1/12/2000	19:45:00	-111' 11"	76.21°F
1/12/2000	20:45:00	2' 1.25"	76.94°F
1/12/2000	21:45:00	2' 1"	76.77°F
1/12/2000	22:45:00	8' 0"	76.09°F
1/12/2000	23:45:00	7' 11.75"	75.12°F
1/13/2000	0:45:00	8' 0"	74.74°F
1/13/2000	1:45:00	8' 0"	74.56°F
1/13/2000	2:45:00	8' 0"	74.42°F
1/13/2000	3:45:00	8' 0"	74.31°F
1/13/2000	4:45:00	8' 0"	74.14°F
1/13/2000	5:45:00	8' 0"	73.92°F
1/13/2000	6:45:00	8' 0"	73.70°F
1/13/2000	7:45:00	8' 0"	73.48°F


Date	Time	Range	Temp...	En...	Device status
1/12/2000	19:45:00	-111' 11"	76.21°F	88 %	Normal
1/12/2000	20:45:00	2' 1.25"	76.94°F	88 %	Normal
1/12/2000	21:45:00	2' 1"	76.77°F	88 %	Normal
1/12/2000	22:45:00	8' 0"	76.09°F	88 %	Normal
1/12/2000	23:45:00	7' 11.75"	75.12°F	88 %	Normal
1/13/2000	0:45:00	8' 0"	74.74°F	88 %	Normal
1/13/2000	1:45:00	8' 0"	74.56°F	88 %	Normal
1/13/2000	2:45:00	8' 0"	74.42°F	88 %	Normal
1/13/2000	3:45:00	8' 0"	74.31°F	88 %	Normal
1/13/2000	4:45:00	8' 0"	74.14°F	88 %	Normal
1/13/2000	5:45:00	8' 0"	73.92°F	88 %	Normal
1/13/2000	6:45:00	8' 0"	73.70°F	88 %	Normal
1/13/2000	7:45:00	8' 0"	73.48°F	88 %	Normal
1/13/2000	8:45:00	7' 11.75"	73.23°F	88 %	Normal
1/13/2000	9:45:00	7' 11.75"	73.02°F	88 %	Normal
1/13/2000	10:45:00	7' 11.75"	72.80°F	88 %	Normal
1/13/2000	11:45:00	7' 11.75"	72.57°F	88 %	Normal
1/13/2000	12:45:00	8' 0"	72.42°F	88 %	Normal
1/13/2000	13:45:00	8' 0"	72.26°F	88 %	Normal
1/13/2000	14:45:00	7' 11.75"	72.92°F	88 %	Normal
1/13/2000	15:45:00	8' 0"	73.67°F	88 %	Normal

Figure 13. Data log.

## Data log screen actions

- Set the log range.
- Download the data log.
- Save the data log.

When the Data log screen tab is tapped, the Log Range dialog box opens, shown in Figure 14. By default, the Start Date/Time and End Date/Times are set to the beginning and ending times in the log. Frequency sets the interval between downloaded log entries: Every 5 minutes, Every 15 minutes, Every Hour, Every 6 Hours, Every 12 Hours, and Every Day.



**Figure 14. Data log range screens.**

To download the data log,

- Choose a Start Date/Time. (A new date/time must be later than the default and earlier than the End Date/Time.)
- Choose an End Date/Time. (A new date/time must be earlier than the default and later than the Start Date/Time.)
- Choose an entry Frequency.
- Tap **OK**.

A downloaded log is displayed similar to those shown in Figure 13.

The data log contains the following data:

- Entry date and time.
- Range or Level, depending on the operating mode.
- Temperature.
- Energy level.
- Device status.

## Data log menus

- **File**
- **Action.**
- **Admin.** (Requires Administrator login.)

**File** menu items:

- Export...

The data log can be saved to a CSV file for later review. See the **Data** screen, **File** > Export. The save process and screens are the same.

**Action** menu items:

- Redraw.
- Refresh/Acquire.

Redraw redraws the existing data on the Data log screen.

Refresh/Acquire is the same as the **Refresh** button, displaying the Log Range dialog box so that other dates, times and frequencies can be chosen.

**Admin** menu items:

- Reset Data Log...
- Set Log Interval...

Reset Data Log clears the contents of the data log.

Set Log Interval allows you to choose either 1 minute or 5 minute logging. 1 minute entries record more data but the log range is reduced. The default setting is 5 minutes.

## Config screen.

Most TLMe configuration settings are located on the **Config** screen, shown in Figure 15.




Figure 15. Config screens.

## Config screen actions

- Name the TLMe for easier identification.
- Set the operating mode (Range or Level).
- In Level mode, set the Tank height and Head offset values.
- Set the Filter size and Hysteresis.
- Synchronize the real-time clock (RTC) to the PDA or PC clock.
- Import and export device configuration.
- Perform a site calibration.
- Change the RF frequency band.
- Change the ESN (admin only).
- Change the cypher (admin only).
- Shut the TLMe down (admin only).

To name the TLMe:

- Tap the **Name** value. On the PDA, the keyboard pops up.

- Enter a name (32 characters or less).
- Tap *Save*.

To set the operating mode:

- Tap the **Mode** value.
- Choose either **Range** or **Level**.
- Tap *Save*.

## Config menus

- **File**
- **Action.**


**File** menu items:

- Import Config...
- Export Config...

Import Config applies a saved configuration to the TLMe. This saves time if configuration settings are similar among several TLMe's, or if a TLMe previously in service must be replaced.

To import a saved configuration,

- Tap **File** > Import Config.... The File Open box will be displayed. Tap the configuration file you want to import. (On the PC, tap the *Open* button.)



An import options page will be displayed.




Figure 16. Import options selection boxes.

- Check both boxes.
- Tap **OK**. The configuration file is imported, and the device configuration is updated.

Export Config saves the TLMe configuration data to a CSV file. The export procedure is the same as described in the Data screen section.

**Action** menu items:

- Refresh.
- Save.
- Sync Clock.
- Site Calibration...
- Change Frequency Band...

Refresh is the same as the **Refresh** button.

Save is the same as the **Save** button.

To Sync Clock:

- Tap **Action** > Sync Clock.

Change Frequency Band allows you to configure iNode radios to minimize interference from some SCADA radios (e.g. FreeWave). Many SCADA radios, including FreeWave, can be set to use only a part of the 902 – 928MHz radio band. If the SCADA radios are configured to use the upper band and iNodes to use the lower band, the two radios will not interfere. Communications will be faster and more reliable.

To change the TLMe frequency band:

- Tap **Action** > Change Frequency Band... The Frequency Band window will open.

- The TLMe radio can be set to one of three modes: **Wide** (the entire 902 – 928MHz range), **A** (the lower band, 902 – 916MHz) or **B** (the upper band, 914 – 928MHz).
- Tap the desired mode to highlight it and tap **OK**.

Note that this requires a similar configuration of the SCADA radio system. Refer to the SCADA manufacturer's data for information on how to configure the SCADA system. Also the CFR must be set to use the same band as the iNodes.




Figure 17. Frequency band settings.


## Site calibration

### Preparation for calibration.

Before permanently mounting the TLMe to the tank, you must make two measurements so that the TLM can be properly calibrated after it is installed: (1) the distance from the bottom of the tank to the point where the TLM is threaded into the fitting (tank depth), and (2) the distance between where the fitting mates with the TLM thread and sensor head (head offset). The automated calibration procedure performed after installation subtracts head offset from tank depth and calculates the distance between the TLM sensor head and the bottom of the tank.

1. **Head offset.**
  - a. **Closed top tank.** Measure the distance from the last visible thread that is seen when the TLM is installed and the tip of the TLM sensor head.
  - b. **Open top tank.** With an open top tank enter this distance as '0', since the distance from the TLM sensor head to the tank bottom can be measured directly.
2. **Tank depth.**
  - a. **Closed top tank.** Using a gauge line, measure the distance from top of the fitting where the TLM will be mounted, to the bottom of the tank.

- b. **Open top tank.** Install the TLM and measure the distance from the sensor head to the tank bottom with a gauge line.



## Calibration

After the TLME is mounted to the tank, it must be calibrated.

- Select **Level Mode**.
- Enter the tank height and head offset values measured earlier.
- Tap **Save**.
- Select **Action** > Site Calibration... The Site Cal window will be displayed as shown in Figure 18.
- Measure and enter the fluid depth and the gas temperature.
- Tap **Calibrate**. The calibration process will run.
- If the calibration is successful, the Site Cal Successful window will be displayed as in Figure 19. Tap **OK** to close the window and complete the calibration.






Figure 18. Site Cal window.




Figure 19. Site cal successful window.

## Thresholds screen

For accurate distance measurement, the TLMe must find the first reflected signal. After the TLMe is installed and calibrated, its threshold (the signal levels the TLMe uses for distance calculations) settings can be adjusted for best performance.

The **Thresholds** screen is shown in Figure 20. If a signal pulse is above the red line, it will be used by the TLMe. If not, it will be ignored. The threshold levels can be changed by touching a line or point, then dragging it to a new position. (In the figure, the first blue “signal” is the transmitted pulse. The second signal is the reflection.) The default thresholds set the TLMe to ignore the transmitted pulse while using the reflected pulse. Threshold adjustment is more critical when the TLMe is measuring very short distances between the fluid and the sensor head, or it needs to ignore multiple reflections inside a tank.




Figure 20. Thresholds screens.

## Thresholds screen actions

- Import and export the TLMe configuration.
- Export a trace to a CSV file.
- Get a new trace.
- Restore threshold default settings.
- Refresh the display.

- Save threshold settings.

## Thresholds menus

- **File.**
- **Action.**

### **File** menu items:

- Import Config...
- Export Config...

These selections are identical to those on the **Config** screen. See the **Config** section for their use.


- Export trace saves the trace and threshold data values to a CSV file.

### **Action** menu items:

- Get trace causes the TLMe to acquire a new trace and display it on the Thresholds screen.
- Restore defaults resets the threshold levels and locations to their default values.
- Refresh refreshes the data displayed on the screen.
- Save saves any threshold level or location changes made on the screen.

## Alarms page

The TLMe can detect alarm conditions and send alarm messages to a CCU.



## Alarms page actions

- Enable and disable alarms.
- Set alarms for low and high fluid levels or temperatures.
- Configure a level drop alarm.
- Set the alarm holdoff time.

To enable an alarm:

- All alarms are disabled by default.
- Tap the **Disabled** value beside an alarm.
- Tap **Enabled**.
- Tap **Save**.

To set a level alarm value:

- Tap the level setpoint value you want to change. (PDA: The keyboard will pop up.)
- Enter the setpoint value in feet and inches.
- Tap **Save**.

To set a temperature alarm value:

- Tap the temperature setpoint value you want to change. (PDA: The keyboard will pop up.)

- Enter the setpoint value in degrees F.
- Tap *Save*.

To minimize nuisance alarms, **Alarm holdoff** sets the time that an alarm condition must be present before the TLMe will send an alarm. The longer the holdoff time, the longer the alarm condition must persist before an alarm is generated.

To set the Alarm holdoff:

- Tap the Alarm holdoff value. On the PDA, the keyboard will pop up.
- Enter the desired value in minutes.
- Tap the *Save* button.

The **level drop alarm** will send an alarm when the tank level drops during a selectable time span (for example, if oil is “thieved” at night when the tank is unattended). Level drop alarm configuration requires you to enter four values:

- Level drop (in feet and inches) sets the fluid level drop necessary to trigger an alarm.
- Drop time span (in minutes) sets the maximum time interval necessary to trigger an alarm.
- Drop window start and end (24 hour format, local time) sets a “window” during which a level drop alarm can be generated. This prevents sending an alarm during the normal workday.

To set the Level drop values:

- Tap the Alarm holdoff value. On the PDA, the keyboard will pop up.
- Enter the desired value in feet and inches.
- Tap *Save*.

For example, assume that you want to detect a level drop and send an alarm if the fluid level drops more than 1’ in 10 minutes, between 7PM and 5AM. In this case,

- Level drop = 1’ 0”.
- Drop time span = 10 minutes.
- Drop window start = 19 (PM values add 12, so 7PM = 12 + 7).
- Drop window end = 5 (AM values don’t add 12, so 5AM = 5).

## Alarm menus

- **File.**
- **Action.**

**File** menu items:

- Import Config.
- Export Config.

As previously explained in the **Configuration** section, Import Config and Export Config load and save TLMe configuration files.

**Action** menu items:

- Enable (not functional).
- Refresh.
- Save.

Refresh and Save refresh the Alarms values page and save your changes. They are the same as the *Refresh* and *Save* buttons.

## Status screen

The Status screen displays information about the TLMe.




Figure 21. Status screens.

The following status information is displayed:

- Firmware version.
- Board (hardware) revision.
- Self-test codes. When it is powered on or reset, the TLMe runs several self-tests. The test results display 'OK' if the test is passed, or a brief description of the failure if it fails.
  - Radio test.
  - Clock test.
  - FLASH (memory) test.
- Reset source. The typical reset source is 'Hardware reset pin & power-on' (The hardware reset pin is the reset button. There are several other reset sources. If another reset source is displayed, it may indicate a problem with the TLMe. Consult Ferguson Beauregard customer support if you have a problem.)
- Charge current. This represents the amount of charge current generated by the solar panel. In average sunlight this value is typically > 40. If the value is 0 in sunlight, there may be a failure in the solar panel or charging circuit.
- Auto-calibration status. After a successful site calibration, this will display **OK**.
- Auto-calibration passes. This should display "5".

- Auto-calibration error location. TBD.
- Background noise level. The average noise level seen by the TLMe sensor.
- Reflection peak level. The maximum level of the reflected signal.

### Status screen actions

- Refresh the displayed status information.
- Export the TLMe status.
- Run the RF Link Test.

To refresh status information:

- Tap the **Refresh** box. The status information is refreshed.

### Status menus

- **File.**
- **Action.**

There is only one **File** menu item, Export. To export the TLMe status information to a CSV file:

- Tap **File** > Export. The Save As dialog is displayed.
- Enter a filename.
- Choose a folder (or browse to a folder, on a PC) in which to save the file.
- On the PDA, choose the memory location (main memory, built-in storage, SD card).
- Tap **OK**.

**Action** menu items:

- Refresh.
- RF Link Test...

Refresh is the same as the **Refresh** button.

RF Link Test... When RF Link Test is enabled, iNodeConfig collects RF communications data from the TLMe. After selecting RF Link Test, the Frequency box, which allows you to set the data collection rate, is displayed. Choose a Frequency, tap the **OK** button, and collection will begin.






Figure 22. Data loop options boxes.

**RF Link Test** is similar to **Data Loop**, and the Frequency selection box is identical. However all collected information relates to the radio system used to communicate with all iNodes. See Figure 23 below.

Time	CFR RX Channel	CFR Rssi	CF
13:46:58	30	27.290039	30
13:46:56	3	22.069336	3
13:46:54	35	23.967773	35
13:46:53	44	24.323730	44
13:46:51	41	23.611816	41

Time	CFR RX Channel	CFR Rssi	CFR TX Channel	Dev RX Channel	Dev AbsRSSI	Dev thresh	Dev margin	Timing offs
13:54:01	35	27.883301	30	30	-48.347656	246	28.357910	865
13:53:59	44	28.476563	3	3	-48.822266	246	28.713867	865
13:53:57	41	25.510254	35	35	-48.347656	246	28.357910	865
13:53:55	47	25.866211	44	44	-48.347656	246	29.069824	865
13:53:53	27	28.239258	41	41	-48.347656	246	29.188477	865
13:53:51	37	25.154297	47	47	-48.347656	246	28.832520	865
13:53:49	5	26.459473	27	27	-48.822266	246	28.120605	865
13:53:47	14	26.934082	37	37	-47.873047	246	28.357910	865
13:53:45	52	28.120605	5	5	-48.347656	246	29.069824	865
13:53:43	8	27.527344	14	14	-48.822266	246	29.069824	865
13:53:41	39	23.255859	52	52	-47.873047	246	28.357910	865
13:53:39	32	28.239258	8	8	-48.347656	246	29.188477	865
13:53:37	18	28.120605	39	39	-48.347656	246	28.595215	865
13:53:35	23	21.238770	32	32	-48.822266	246	28.713867	864
13:53:33	34	27.645996	18	18	-48.822266	246	29.188477	864
13:53:31	29	28.120605	23	23	-48.347656	246	26.340820	864
13:53:29	10	26.459473	34	34	-48.347656	246	28.951172	864
13:53:27	2	27.883301	29	29	-48.822266	246	28.595215	864

Figure 23. RF link test data.

RF Link Test displays:


- Time of collection (24-hour format, local)
- CFR RX Channel (inbound channel number)
- CFR Rssi (inbound signal strength)
- CFR TX Channel (outbound channel number)
- Dev RX Channel (outbound
- Dev Abs RSSI (inbound signal strength, seen on the TLMe)
- Dev thresh (noise threshold of the received channel on the TLMe)
- Dev margin (noise margin of the received channel on the TLMe)
- Timing offset (timing alignment value synchronizing the TLMe and CFR radios)

After the link test is running, two menu items can be selected:

- ***File*** > Log data. The link test data can be logged to a CSV file. **NOTE:** Data logging must be selected after the link test is started. Data displayed on the screen before logging is enabled will not be saved to the log.
- ***Setup*** > Options. Displays the Frequency dialog box.

RF Link Test is usually only used by iMonitoring for system troubleshooting.

## Firmware screen



TLMe firmware can be updated on the Firmware screen. New firmware versions must be copied into the iNodeConfig folder on your PDA. All TLMe firmware versions in the iNodeConfig folder will be displayed in the top box on the screen. Firmware can be located in different folders on the PC, since you can browse folders to find the files.

### Firmware screen actions

- View the current firmware version, ESN and device type.
- Update the firmware on the TLMe.

To update firmware,

- Tap the version to be loaded to highlight it.
- Tap the **Update Firmware** box. If the version is older than the one presently loaded, a notification box will be displayed. Tap **OK** to proceed.
- A confirmation box will be displayed. Tap **Yes** if you want to proceed, or **No** to cancel.
- If you tapped **Yes**, the firmware will be updated.

**CAUTION:** This process takes several minutes. Don't use the PDA until the upload process is complete.

## Firmware menus

- **File.**
- **Action.**

File menu items:

- Browse Available Directories.
- Refresh Available Updates.

On the PDA, Browse available directories is nonfunctional. On the PC, you can browse to any directory on the PC to find firmware files.

If firmware files have been copied into the iNodeConfig folder on the PDA, or you have added firmware files on the PC, Refresh available updates will display the new files in the upper window.

Action menu items:

- Update Firmware.
- Refresh Version Info.

Update Firmware is the same as the *Update Firmware* button.

Refresh Version Info displays the current TLMe firmware version.

## TLMe Specifications

<b>Measurement</b>		
Fluid level range		18 to 240 inches (1.5 to 20 feet)
Accuracy		+/- 2"
<b>Electrical</b>		
Radio range: Sensor to CCU		1,500 feet typ. line of sight. > 5000 feet with optional high gain antenna.
Radio range: Sensor to CFR-enabled device		500 feet.
Radio technology		902-928 MHz spread spectrum frequency hopping.
Communications protocol		Proprietary iMECH protocol specifically designed for iNode wireless sensors
Security		Access to sensor data can be restricted by cypher
Data logging		Internally stored data logs, 30 day length
Power		1/4w solar panel, rechargeable Li-Ion battery and integrated charger/regulator
Data log		Level measurement data logs stored internally
<b>Mechanical</b>		
Mounting		3" NPT fitting
<b>Environmental</b>		
Operating temperature		-40°C to + 60°C (-40°F to 140°F)
Humidity		0 to 95% non-condensing
<b>Certifications</b>		
Safety listings		UL and c-UL Class I, Div. 1, Groups C and D (Intrinsically safe)
FCC approval		CFR 47 Part 15
<b>Reliability</b>		
Product life		≥ 5 years by design

## **The Ferguson Beauregard iNodes suite of products includes:**

- Tank Level Monitor (TLM1, TLMe, TLM-3)
- Wireless Data Switch (WDS)
- Electronic Flow Monitor (EFM)
- Compact Flash Radio (CFR)
- Wireless Pressure Monitor (WPM)
- Concentration & Communications Unit (CCU)
- CCU with RTU analog and digital input interface (CCU-RTU)
- Wireless Two Pen Pressure Recorder (WPM-2P)

## **Other Services compatible with our iNodes suite:**

FieldDIRECT® is an end-to-end service for collecting and storing production data and delivering it directly to your desktop via a Web-based interface. It operates seamlessly with our iNodes intelligent sensors and our handheld data entry system. That gives you data capture options that are economical even for mature fields with wells producing as little as five BOE per day.

For more details on iNodes and FieldDIRECT, call 1-903-561-4851, fax (903) 561-6567, visit our Web site at [www.FergusonBeauregard.com/products](http://www.FergusonBeauregard.com/products), or send an e-mail to: [automation@fergusonbeauregard.com](mailto:automation@fergusonbeauregard.com).