

Premium and Atrium using Unity Pro Weighing module User manual

June 2006 eng

35006238 03



Telemecanique

Table of Contents




	Safety Information	7
	About the Book	9
Part I	Hardware installation of the weighing module	11
	At a glance	11
Chapter 1	General introduction to the weighing module	13
	At a Glance	13
	Introduction to the weighing system	14
	General description of the weighing module	17
Chapter 2	General rules for implementation of the weighing module ..	19
	At a Glance	19
	Recommendations on how to install a measurement system	20
	Installation of the weighing module	22
	Cabling precautions on the weighing module	24
Chapter 3	Debugging of the weighing module	25
	At a Glance	25
	Weighing module fault display	26
	Weighing module diagnostics	28
Chapter 4	Description of the weighing module connections	29
	At a Glance	29
	Measurement connection	30
	Connection of discrete outputs of the weighing module	33
	Pins of the serial link for the display panel	35
	The TSX XBT N410 display panel	36
Chapter 5	Module TSX ISP Y101	39
	Overview of this Chapter	39
	Physical description of the weighing module	40
	General characteristics of the module TSX ISP Y101	41

Part II	Software installation of the weighing module	43
	At a glance	43
Chapter 6	General introduction to the weighing application-specific function	45
	At a glance	45
	Installation Phase Overview	46
	Operation of the weighing module	48
Chapter 7	Configuration of the Weighing application	51
	At a glance	51
7.1	Configuration of the weighing module : general	52
	Description of the weighing application function configuration screen	52
7.2	Parameters of the weighing module channels	54
	Weighing module configuration parameters	54
7.3	Configuration of the weighing module parameters	55
	At a glance	55
	How to modify the task parameter	56
	How to modify metrological information	57
	How to modify the zero	59
	How to modify the data format	60
	How to modify the stability	61
	How to modify measurement input Filter(s)	62
	How to modify the flow calculation	64
	How to modify the tare	65
	How to modify the threshold check	66
Chapter 8	Presentation of the weighing module language objects	69
	At a glance	69
8.1	General on the weighing programming	70
	At a glance	70
	Weighing application programming principle	71
	Addressing language objects associated with the weighing Module	73
	Description of the Main Objects Linked to the Weighing Function	74
8.2	Language objects and IODDT	76
	At a glance	76
	Presentation of language objects associated with the Weighing function	77
	Implicit exchange language objects associated with the application-specific function	78
	Explicit Exchange Language Objects Associated with the Application-Specific Function	79
	Management of Exchanges and Reports with Explicit Objects	81
8.3	The IODDTs of the weighing module	85
	At a glance	85
	Detail of the implicit exchange objects of the IODDT of type T_WEIGHTING_ISPY101	86

	Explicit exchange objects of the IODDT of type T_WEIGHING_ISPY101	89
	Explicit exchange objects of the IODDT of type T_WEIGHING_ISPY101	91
	Explicit exchange objects of the IODDT of type T_WEIGHING_ISPY101	92
	Details of the Language Objects of the IODDT of Type T_GEN_MOD.	94
8.4	Description of the commands conveyed by program	95
	At a glance	95
	Sending commands to the weighing module by program	96
	How to perform a tare mode by program	97
	How to reset the value of the weight to zero by program	100
	How to return to gross weight measurement via the program.	102
	How to display the manual tare via the program.	104
	How to enable or disable Thresholds by program.	105
8.5	Modifying the parameters by program.	107
	At a glance	107
	Modifying the parameters by program.	108
	Instructions used for adjustments	110
	Description of parameters adjustable by program.	112
	Reading configuration parameters.	113
Chapter 9	Debugging the weighing function.	117
	At a glance	117
	Introduction to the debug function of the weighing module.	118
	Description of the weighing application function debug screen.	119
	Description of the module zone of the debug screen	121
	Description of the display zone of the debugging screen	122
	Description of the parameter setting zone.	123
Chapter 10	Calibrating the measurement string	125
	At a glance	125
	Introduction to the Calibration Function.	126
	Description of the calibration screen.	128
	Calibrating the Analog Measurement System.	130
	Calibrating the Analog Measurement System by Program	132
	How to achieve a forced calibration	134
	Performing a Forced Calibration by Program	135
	How to achieve a software calibration.	136
Chapter 11	Protecting the adjustments	139
	At a glance	139
	Protection of the weighing parameter settings	140
	How to protect the adjustments.	142
	Legal metrology and regulations	143
Chapter 12	Operating a weighing application	145
	At a glance	145
	Ways of displaying weighing information	146

	Description of the display report	147
	Weighing module operating modes	150
Chapter 13	Diagnostics of the weighing application	151
	At a glance.	151
	How to access the Diagnostics function of the weighing module	152
	How to access the channel Diagnostics function of the weighing module.	153
Chapter 14	Examples of the weighing program	155
	At a glance.	155
	Example of a tare mode.	156
	Example of metering flow.	157
Glossary	161
Index	167

Safety Information



Important Information

NOTICE

Read these instructions carefully, and look at the equipment to become familiar with the device before trying to install, operate, or maintain it. The following special messages may appear throughout this documentation or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.



The addition of this symbol to a Danger or Warning safety label indicates that an electrical hazard exists, which will result in personal injury if the instructions are not followed.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

DANGER

DANGER indicates an imminently hazardous situation, which, if not avoided, **will result** in death, serious injury, or equipment damage.

WARNING

WARNING indicates a potentially hazardous situation, which, if not avoided, **can result** in death, serious injury, or equipment damage.

CAUTION


CAUTION indicates a potentially hazardous situation, which, if not avoided, **can result** in injury or equipment damage.

PLEASE NOTE

Electrical equipment should be serviced only by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this material. This document is not intended as an instruction manual for untrained persons.

© 2006 Schneider Electric. All Rights Reserved.

About the Book



At a Glance

Document Scope This manual describes the hardware and software implementation of the weighing module for Premium and Atrium PLCs.

Validity Note The data and illustrations found in this documentation are not binding. We reserve the right to modify our products in line with our policy of continuous product development.

The information in this document is subject to change without notice and should not be construed as a commitment by Schneider Electric.

Product Related Warnings

Schneider Electric assumes no responsibility for any errors that may appear in this document. If you have any suggestions for improvements or amendments or have found errors in this publication, please notify us.

No part of this document may be reproduced in any form or by any means, electronic or mechanical, including photocopying, without express written permission of Schneider Electric.

All pertinent state, regional, and local safety regulations must be observed when installing and using this product.

For reasons of safety and to ensure compliance with documented system data, only the manufacturer should perform repairs to components.


When controllers are used for applications with technical safety requirements, please follow the relevant instructions.

Failure to observe this product related warning can result in injury or equipment damage.

User Comments

We welcome your comments about this document. You can reach us by e-mail at techpub@schneider-electric.com.

Hardware installation of the weighing module



At a glance

In This Chapter

This part introduces the hardware installation of the weighing module of the Premium PLC range and its dedicated display accessory.

What's in this Part?

This part contains the following chapters:

Chapter	Chapter Name	Page
1	General introduction to the weighing module	13
2	General rules for implementation of the weighing module	19
3	Debugging of the weighing module	25
4	Description of the weighing module connections	29
5	Module TSX ISP Y101	39

General introduction to the weighing module

1

At a Glance

Aim of this Chapter

This chapter is a general introduction to the weighing module.

What's in this Chapter?


This chapter contains the following topics:

Topic	Page
Introduction to the weighing system	14
General description of the weighing module	17

Introduction to the weighing system

General

The following illustration presents the Premium weighing system range.




The various elements of the weighing system are described in the following table.

Number	Description
1	The TSX ISP Y101 weighing module.
2	The TSX XBT N410 display panel with weighing protocol.
3	Junction box.
4	Weighing sensors.

Note: the complete Premium weighing range also integrates the following process control applications:

- filling unit,
- multi-product metering,
- flow regulator,
- graded weighing unit,
- batch and continuous totalizer.

The following illustration presents the different elements that may make up a complete weighing system configuration.



General description of the weighing module

Introduction

The **TSX ISP Y101** weighing module comes with:

- one **measurement input** channel capable of receiving up to 8 constraint gauge sensors,
- **2 discrete callback outputs** for graded filling applications,
- one **sealable digital link** enabling the weight or manual tare to be displayed on a **TSX XBT N410** external display panel.

In order to ensure the integrity of the measurements made, the measurement input, weighing module and display panel can all be lead sealed to meet legal metrology requirements concerning weighing instruments used in commercial transactions.

Maximum number of TSX ISP Y101 modules per station

The maximum number of **TSX ISP Y101** modules in a PLC station depends on:

- the type of processor installed (see table below),
- of the number of specific-application channels already used.

Number of "application-specific" channels supported:

- Premium (See Premium and Atrium using Unity Pro Manual, Processors, racks and power supply modules, Catalog of TSX 57 Processors)
 - Atrium (See Premium and Atrium using Unity Pro Manual, Processors, racks and power supply modules, Catalog of Atrium Processors)
-

General rules for implementation of the weighing module

2

At a Glance

Aim of this Chapter

This chapter presents the general rules for implementation of the weighing module.

What's in this Chapter?

This chapter contains the following topics:

Topic	Page
Recommendations on how to install a measurement system	20
Installation of the weighing module	22
Cabling precautions on the weighing module	24

Recommendations on how to install a measurement system

General

The quality of the measurement provided by the module may be reduced considerably if the sensor set-up and installation precautions have not been observed. Thus in place of exhaustive information, these few lines should make you aware of some of the precautions which need to be taken.

Dividing up the loads

In a measurement system, the weighing sensors support the following weights :

- the maximum weight to be weighed,
 - the weight of the loading receiver and its structures (or metrological tare).
- This total weight is divided up between 1, 2, 3, 4, 6, even 8 sensors. The design of the mechanical structures, the shape of the loading receiver and the dividing of the load on or within the receiver, means that the total weight is not always equally divided between all the sensors (except of course in the case of a single sensor).

It is therefore a good idea to make sure that the dimensions of the weighing sensors are calculated in such a way as to be able to support the total weight (maximum weight + tare) to which they will be subjected

Inhibiting interference on the load receiver

As a weighing sensor deflection is very weak (a few tenths of a millimeter), all interference on the load receiver or any friction on the permanent framework will cause an invalid weight measurement and make correct adjustment of the module impossible.

Mechanical installation of the weighing sensors

The sensors in traction or compression must be used vertically respecting their action direction (traction or compression). The maximum admissible tolerance on the installation's verticality is in the region of the degree according to the installation and the required precision.

Protecting the sensors from interference currents

It is recommended that each sensor be provided with a mass flex which plays the role of the electric " shunt " with the aim of protecting sensors from currents capable of circulating in the metallic framework (ground currents, from the terminal to be connected, and electrostatic discharges...).

This flex will be of a sufficient length to not result in mechanical constraints and it will be placed directly next to the sensors, between the permanent framework and the load receiver.

Contact with water and corrosive products

Weighing sensors are manufactured as waterproof. It is recommended, however, that they be prevented from coming into contact with water, corrosive products and direct sunlight.

Preventive maintenance of the installation and accessories

The weighing module requires no special maintenance. The weighing sensors, however, should be cleaned periodically if used in a difficult environment. It is advisable to periodically test and service the mechanical state of the load receiver.

- Cleaning the receiver and its structures because of a product deposit or various material deposits may result in a noticeable variation of the tare.
- Checking the verticality of the weighing sensors.
- Checking the sensor and actuator states according to their period of use.
- Etc.

Note: Statistics show that 90% of breakdowns occurring on a weighing/dosing installation are not attributable to the electric command device, but to the installation itself (defective limit switches, mechanical faults...).

Installation of the weighing module

At a Glance

The method and precautions relating to the installation of the weighing module are detailed below:

Installation




The weighing module **TSX ISP Y101** is standard format and therefore occupies a single position in the **TSX RKY•••** racks. It can be installed in all positions on the rack except for the first two (PS and 00) which are reserved for the rack power supply module (**TSX PSY•••**) and processor module (**TSX 57•••**) respectively. They are powered by the rack back bus, and can be positioned either in the standard rack or in an extendable rack.

Installation precaution

The installation and removal of the weighing module can be done with the PLC **switched on** (without risk of damage to the module or disruption to the PLC).

Installing the module on the rack

Installation of the weighing module on the rack is carried out as follows:

Step	Action	
1	Position the two lugs at the rear of the module (the lower part of the module) in the centering holes located on the lower part of the rack.	
2	Pivot the module upwards so as to plug it into the rack's back connector.	
3	Fix the module to the rack by tightening the fixing screw located on the upper part of the module. Note: If this screw is not tightened, the module will not stay in the rack position.	

Cabling precautions on the weighing module

At a Glance	To protect the signal from external noises induced in serial mode and from noises in common mode, you are advised to take the following precautions.
Kind of conductors	Use shielded twisted pairs of a minimum section of 0.28 mm ² (AWG24 gage).
Cable shielding	The measurement cable shielding should only be connected to the ground on the module side. If problems arise, if the grounds on either side of the connection are of good quality, then both ends of the shield can be connected to the ground. On the Sub-D connectors connect the cable shield to the cover of the connector, the PLC ground being connected by the tightening screws of the Sub-D connector. For this reason, the male Sub-D connector must be screwed onto its female connection base.
Cable routing	Keep the measurement wires as far as possible from the discrete input/output cables (particularly relay outputs) and the cables which transmit "power" signals. Avoid : <ul style="list-style-type: none">• parallel routing (maintain a distance of at least 20 cm between the cables),• and cross them at right-angles.

Note: The measurement input is grounded via the module.

Debugging of the weighing module

3

At a Glance

Aim of this Chapter

This chapter presents the general rules for debugging the weighing module.

What's in this Chapter?

This chapter contains the following topics:

Topic	Page
Weighing module fault display	26
Weighing module diagnostics	28

Weighing module fault display


At a Glance

The weighing module is fitted with LEDs which display the status of the module and the status of the channels. We distinguish between :

- the module status LEDs : RUN, ERR and I/O,
 - the channel status LEDs : CH•.
-

Illustration

The following diagram shows the weighing module display screen :






Description

Three LEDs located on the display panel of each module indicate the operational status of the module (LED on, flashing and off) :

- The green LED RUN : indicates the module's operational status
- The red LED ERR : indicates an internal fault in the module or a fault between the module and the rest of the configuration
- The red LED I/O : indicates an external fault.

Note: The CH• status LEDs are not used in analog modules.
--

The various possible faults are grouped in the following table :

LED	On 	Flashing 	Off 
RUN (green)	Normal operation	-	Module faulty or switched off
ERR (red)	Internal error, module faulty	Communication error, missing, invalid or faulty application.	No internal error
I/O (red)	External errors: <ul style="list-style-type: none"> ● overload or underload error during calibration, ● range overshoot error, ● measurement error, ● sealed module (configuration refused). 	No connector to the weighing sensors.	No external error
CH•	No channel status LEDs		

Weighing module diagnostics

At a Glance

A faulty module is makes itself evident be means of lit or flashing RUN, ERR and I/O LEDs.

There are three groups of faults: external errors, internal errors and other faults.

Fault diagnostics

The following table can be used to diagnose faults relating to the three LEDs: RUN, ERR and I/O :

Module status	Status of LEDs		
	RUN	ERR	I/O
Normal operation	●	○	○
Module faulty or switched off	○	⊗	○
Internal errors (module broken down):			
● communication with CPU possible	●	●	○
● communication with CPU impossible	○	●	○
External errors :			
● overload or underload error during calibration,			
● range overshoot error,	●	○	●
● measurement error,			
● sealed module (configuration refused)			
Other faults :			
● communication error (absent, invalid or faulty application)	●	⊗	○
Key :			
○ LED unlit			
⊗ LED flashing			
● LED lit			

Description of the weighing module connections

4

At a Glance

Aim of this Chapter

This chapter introduces the weighing module connections.

What's in this Chapter?

This chapter contains the following topics:


Topic	Page
Measurement connection	30
Connection of discrete outputs of the weighing module	33
Pins of the serial link for the display panel	35
The TSX XBT N410 display panel	36

Measurement connection

General

The measurement sensors are connected using a 15 pin female Sub-D connector on the module side.


TSX ISP Y101



The module and the Sub-Ds can be plugged-in and unplugged with the power on.
The type of cable to be used is a 6 conductor cable with a 15 pin Sub-D connector.
Sensor supply is exclusively provided by the module.

**Sub-D
Connector 15**

Connection of the 15 pin Sub-D connector is shown in the following illustration:




Connection of discrete outputs of the weighing module

General

Weighing module discrete outputs are used to trigger actions on threshold crossings. This functionality is used in the "filling unit" application.

Discrete outputs are connected using a screw terminal block:



The common 2 and 3 are linked by the card.

Characteristics of the discrete outputs

The following table shows the characteristics of the discrete outputs of the module TSX ISP Y101:

Discrete output	Characteristics
Number of channels	2
Type	A transistors
Response time	1 ms discrimination. The threshold crossover point between two measurements is calculated by interpolation to the millisecond.
Nominal supply voltage	24 V
Insulation voltage	1500 Vrms
Maximum current	500 mA
Protection	Reverse polarity and short circuit. Install a fuse on the +24 V pre-actuator supply.

Protection

The outputs are galvanically protected by the ground.

Each of the two output channels is protected against:

- short-circuits and overloads,
- reverse polarities.


Note: In order to best protect against reverse polarities , it is essential **to place** a fast-acting **fuse** on the supply, upstream of the load (shown as Fu in the diagram above).

Pins of the serial link for the display panel

General

The serial link is used to carry over the weight to an external display panel.

The connection to the terminal is via a female 9 pin Sub-D connector on the module side, the link is RS485, the connections are described below :



The line on the module side is polarized using straps 6-5 and 8-9.

Characteristics

The following table shows the characteristics of output display panel :

Output display panel	Characteristics
Physical interface	non-isolated RS 485
Bit rate	9,6 Kbits/s
Format	1 start bit, 8 data bits and 1 stop bit
Remote distance	Maximum 30 m

The TSX XBT N410 display panel

General

The **TSX XBT N410** is designed to be connected to the weighing module, in order to act as the main display panel and display weight information.

The display panel should be connected to the module by a shielded cable with two conductors. It is equipped with a 15-pin female SUB-D connector.


Characteristics

The following table shows the electrical characteristics of the display panel:

Display	Green back-lit LCD (122x32 pixels)	
Display capacity	2 lines of 20 characters	
Refresh period	100 ms	
Serial link	RS 485	
Transmission speed	9.6 Kbits/s	
Connection	With 25-way SUB-D connector	
Power supply	Plug-in terminal block, 3 screw terminal (pitched at 5.08 mm [0.2 in]). Maximum clamping capacity: 1.5 mm (0.06 in).	
Voltage limits	18 to 30 V, DC	
Ripple	5% maximum	
Consumption	5 W maximum	
Ambient temperatures	for operation	0...55°C (32...130°F)
	for storage	-20...60°C (-4...140°F)
Degree of protection	front	IP65 and in compliance with IEC 60529 and Nema 4X ("outdoor use")
	rear	IP20, in compliance with IEC 60529
Compliant with standards	IEC 61131-2, IEC 60068-2-6, IEC 60068-2-27, UL 508 and CSA C22-2 No.14	

Display panel connections

The following diagram shows the link between the **TSX ISP Y101** weighing module and the **TSX XBT N410** display panel:



The cable, a **shielded twisted pair**, from the weighing module to the **TSX XBT N410** cannot exceed 100 meters (328 feet).

The shield on the module side should be connected to the metal part of the SUB-D connector.

Module TSX ISP Y101



5

Overview of this Chapter

Aim of this Chapter

This chapter introduces the general characteristics of the weighing module **TSX ISP Y101**.

What's in this Chapter?

This chapter contains the following topics:

Topic	Page
Physical description of the weighing module	40
General characteristics of the module TSX ISP Y101	41


Physical description of the weighing module

General

The following is a physical description of the weighing module **TSX ISP Y101**.

Illustration

The following illustration presents the module **TSX ISP Y101**.



Description

The following table describes the different elements of the weighing module:

Number	Description
1	A plastic case equipped with shielding plates protecting the electronic circuits and providing protection against radiant interference.
2	Display block
3	A 9 pin Sub-D female connector for connecting the remote display (TSX XBT N410).
4	A 5 pin screw terminal block for connecting discrete outputs.
5	A 15 pin Sub-D female connector for connecting weighing sensors.

General characteristics of the module TSX ISP Y101

At a Glance

This part introduces the general characteristics of the module **TSX ISP Y101**.

The measurement device

This following table provides the general characteristics of the module **TSX ISP Y101**.

Electrical range	0 to 25 mV
Minimum dynamic	4.5 mV
Maximum dynamic	25 mV
Converter resolution	20 bits (1 048 576 pulses)
Limitations of use	50 000 pts
Conversion speed	50 measurements/second
Zero drift	< 200 nV/°C
Gain drift	< 10 ppm/°C
Non linearity	< 20 ppm (FS)
50 Hz series mode rejection	> 120 dB
Maximum length of the measurement cable	100 m for cable at 0.4 mm ² 200 m for cable at 0.6 mm ² For 1 to 8 sensors

Consumption

The following table shows the consumption values of the module **TSX ISP Y101**:

		Typical	Maximum
Consumption	on 5 VDC	150 mA	330 mA
	on 24 VR (1)	7 mA + 17 mA x N	14 mA + 17 mA x N
Dissipated power		0.75 W	1.65 W
Key:			
(1)	Consumption depends on the number of sensors (N) present on the measurement input.		

Software installation of the weighing module



At a glance

In This Chapter

This part introduces the Weighing application-specific function on Premium PLC and describes its installation with Unity Pro software.

What's in this Part?

This part contains the following chapters:

Chapter	Chapter Name	Page
6	General introduction to the weighing application-specific function	45
7	Configuration of the Weighing application	51
8	Presentation of the weighing module language objects	69
9	Debugging the weighing function	117
10	Calibrating the measurement string	125
11	Protecting the adjustments	139
12	Operating a weighing application	145
13	Diagnostics of the weighing application	151
14	Examples of the weighing program	155

General introduction to the weighing application-specific function



6

At a glance

Aim of this section

This section introduces the weighing application-specific function on Premium PLCs.

What's in this Chapter?

This chapter contains the following topics:

Topic	Page
Installation Phase Overview	46
Operation of the weighing module	48

Installation Phase Overview

Introduction

The software installation of the application-specific modules is carried out from the various Unity Pro editors:

- in offline mode
- in online mode

If you do not have a processor to connect to, Unity Pro allows you to carry out an initial test using the simulator. In this case the installation (See *Implementation Phases with Simulator*, p. 47) is different.

The following order of installation phases is recommended but it is possible to change the order of certain phases (for example, starting with the configuration phase).

Installation Phases with Processor

The following table shows the various phases of installation with the processor:

Phase	Description	Mode
Declaration of variables	Declaration of IODDT-type variables for the application-specific modules and variables of the project.	Offline (1)
Programming	Project programming.	Offline (1)
Configuration	Declaration of modules.	Offline
	Module channel configuration.	
	Entry of configuration parameters.	
Association	Association of IODDTs with the channels configured (variable editor).	Offline (1)
Generation	Project generation (analysis and editing of links).	Offline
Transfer	Transfer project to PLC.	Online
Adjustment/ Debugging	Project debugging from debug screens, animation tables.	Online
	Modifying the program and adjustment parameters.	
Documentation	Building documentation file and printing miscellaneous information relating to the project.	Online (1)
Operation/ Diagnostic	Displaying miscellaneous information necessary for supervisory control of the project.	Online
	Diagnostic of project and modules.	
Key:		
(1)	These various phases can also be performed in the other mode.	

Implementation Phases with Simulator

The following table shows the various phases of installation with the simulator.

Phase	Description	Mode
Declaration of variables	Declaration of IODDT-type variables for the application-specific modules and variables of the project.	Offline (1)
Programming	Project programming.	Offline (1)
Configuration	Declaration of modules.	Offline
	Module channel configuration.	
	Entry of configuration parameters.	
Association	Association of IODDTs with the modules configured (variable editor).	Offline (1)
Generation	Project generation (analysis and editing of links).	Offline
Transfer	Transfer project to simulator.	Online
Simulation	Program simulation without inputs/outputs.	Online
Adjustment/ Debugging	Project debugging from debug screens, animation tables.	Online
	Modifying the program and adjustment parameters.	
Key:		
(1)	These various phases can also be performed in the other mode.	

Note: The simulator is only used for the discrete or analog modules.

Operation of the weighing module


General

In the PLC environment, the module uses, in the same way as the other modules, a set of data which are specific to it.

This information is used for the exchanges (report and commands) with the processor.

Structural diagram

The following operation diagram shows the processes executed by the module and gives all the elements to be configured.



Description of operation

The following table describes the various operating phases of the module.

Phase	Operation	Description
1	Measurement processing.	The signal from the weighing sensors is: <ul style="list-style-type: none"> ● converted, ● filtered according to the choice made in the configuration screen, ● scaled, the scaling characteristics are determined at the end of a calibration.
2	Measurement checking.	The measurement taken from the processing is subject to the following checks: <ul style="list-style-type: none"> ● a underload or overload check, ● a stability check defined by a stability range and a stability time, ● a check for presence in the zero zone.
3	Data exchanges with the processor.	The module receives and processes the commands from the processor (Set to zero, tare mode semi automatic, etc.). It also prepares the data in legal format for display on the TSX XBT N410 . It returns various information to the processor such as the gross weight, the net weight, the flow, the tare and the statuses.
4	Data display.	The TSX XBT N410 displays the weight or the manual tare, in the unit chosen in the configuration and 4 items of additional information: the net weight, the stability, the presence in the zero zone and the unit of weight.
5	Output management.	The card can directly manage 2 discrete outputs and control them according to thresholds transmitted to the module by the application program. The elements used for this management are: <ul style="list-style-type: none"> ● the switchover thresholds, ● the direction of movement of the weight (Weighing or Downweighing), ● the switchover logic of the outputs.

Configuration of the Weighing application



7

At a glance

Subject of this chapter

This chapter describes how to select and modify the parameters of the weighing module's configuration.

What's in this Chapter?

This chapter contains the following sections:

Section	Topic	Page
7.1	Configuration of the weighing module : general	52
7.2	Parameters of the weighing module channels	54
7.3	Configuration of the weighing module parameters	55

7.1 Configuration of the weighing module : general


Description of the weighing application function configuration screen

General

Configuration (See Unity Pro, Operating Modes Manual, Access to the module configuration editor) information is used to define the measuring characteristics and to adapt the operation of the module to the application for which it is intended.

Illustration

This screen allows you to display and modify parameters in offline mode, as well as to debug in online mode.



Description

The table below shows the various elements of the configuration screen and their functions.

Address	Element	Function
1	Tabs	The front tab indicates the current mode (Configuration in this example). Each mode may be selected by the corresponding tab. The Debug and Calibration modes are only accessible in online mode.
2	Module zone	Shows the abbreviated name of the module. In online mode, this zone also contains the three LEDs Run, Err and I/O .
3	Channel field	Is used: <ul style="list-style-type: none"> ● By clicking on the reference number, to display the tabs: <ul style="list-style-type: none"> ● Description which gives the characteristics of the device. ● I/O Objects (See Unity Pro, Operating Modes Manual, I/O Objects Tab for a Module) which is used to presymbolize the input/output objects. ● Fault which shows the device faults (in online mode). ● To select the channel, ● To display the Symbol, name of the channel defined by the user (using the variable editor).
4	General parameters zone	Comprises: <ul style="list-style-type: none"> ● the dropdown Function menu, ● the dropdown Task menu defining the task (MAST or FAST) in which the implicit exchange objects of the channels will be exchanged.
5	Configuration zone	Is used to configure the various channels' configuration parameters.

7.2 Parameters of the weighing module channels

Weighing module configuration parameters

List of parameters

The following table shows the parameters available for the weighing module.

Parameters	Possible choices	Unit of measurement
Task	Mast /Fast	-
Metrology/Unit	kg	kilogram
	g	gram
	t	tonne (metric)
	lb	pound (= 453 g)
	oz	ounce (= 28.35 g)
	<none>	-
Metrology/Max range	from 0 to 65535 (150)	in the weight unit chosen
Metrology / Scale division	1×10^n ($1 \times 10^{-2} = \mathbf{0.01}$)	in the weight unit chosen
	2×10^n	
	5×10^n	
Metrology / Overload threshold	+9 e	scale divisions
	+2 % PM	% of Max range
	+5 % PM	% of Max range
Zero / Zero tracking	Inactive /active	-
Zero / Extent of range	+/-2 % PM or +/-5 % PM	-
Data format	Legal /High resolution	-
Stability / Extent of range	2, 3 , 4, 6 or 8	1/4 of the scale division
Stability / Time	0.4, 0.5, 0.7 or 1	seconds
Filtering / Coefficients	F1	from 0 to 19 (4)
	F2, F3	from 0 to 19 (0)
Flow / Calculation	2, 4 , 8, 16, 32 or 64	measurements
Tare	Not predefined /predefined	in the weight unit chosen
Threshold check	Inactive /Active	-
LF mask time	0 to 1.5 s per 0.1 s step	seconds
Output logic	Weighing /Downweighing	-
Phase 1 active outputs	S0 or (S0 and S1)	-
Breaking points PD and GD	from 0 to Max Range	in 1/100ths of the unit

Note: the parameters in bold correspond to the parameters configured by default.

7.3 Configuration of the weighing module parameters

At a glance

Aim of this sub-section

This sub-section shows the implementation of the various weighing module configuration parameters.

What's in this Section?

This section contains the following topics:

Topic	Page
How to modify the task parameter	56
How to modify metrological information	57
How to modify the zero	59
How to modify the data format	60
How to modify the stability	61
How to modify measurement input Filter(s)	62
How to modify the flow calculation	64
How to modify the tare	65
How to modify the threshold check	66

How to modify the task parameter

At a glance

This parameter defines the processor task in which the input acquisition and the output update take place.


Possible choices are:

- The **MAST** task,
- The **FAST** task.

Note: It is only possible to modify this parameter in offline mode.

Procedure

The following table shows the procedure to define the type of task assigned to the module channels.

Step	Action
1	Access the weighing module configuration screen.
2	<p>Click on the button of the drop-down menu Task in the General parameters zone.</p> <p>Result: a drop-down list appears.</p> 
3	Select the required task.
4	Confirm the modification with the command Edit → Validate .

How to modify metrological information

At a glance

The configuration screen offers the following metrological information.

Designation	Description
Unit	<p>gives the choice for the weight measurement unit:</p> <ul style="list-style-type: none"> ● g: gram, ● kg: kilogram, ● t: tonne (metric), ● lb: pound (lb = 453 g), ● oz: ounce (oz = 28.35 g), ● without: any unit.
Max Range (MR)	<p>This is the maximum weight that it is possible to weigh with the instrument and without including the weight of the empty load receiver (in the legal format (See <i>How to modify the data format, p. 60</i>)).</p>
Scale Division	<p>The value of the scale division is in the form of 1, 2 or 5 multiplied by 10^n (n being a positive or negative integer or zero with its absolute value ≤ 3).</p> <p>Example: for a scale division of 0.002 (if the unit chosen is the kg), the measurement increases by 2 g at a time.</p>
Overload Threshold	<p>The threshold is the value of the weight above which the display panel no longer indicates the weight (the overload is then indicated with a > line on the display panel).</p> <p>It may take the values:</p> <ul style="list-style-type: none"> ● +9 scale divisions, ● +2 % of the maximum range, ● +5 % of the maximum range. <p>Example: the maximum range has been established at 150 kg, the scale division at 10 g, according to the choice of the user, the operating limit will be for:</p> <ul style="list-style-type: none"> ● 9 e: Max range + 9 scale divisions i.e. 150.09 kg, ● +2 %MR: 102 % of Max range i.e. 153 kg, ● +5 %MR: 105 % Max range i.e. 157.5 kg, <p>Note: The under-load threshold cannot be parameterized: it defines the permissible limit of the indication below zero. It is -2 % of the maximum range (the under-load is then indicated with a < line on the display panel).</p>

Note: In an industrial context, because of the environment of the weighing installation, choosing a resolution of more than 3000 points assumes that there are rigorous installation precautions.

At the level of the programming screen, it will not be possible to input a resolution greater than 50 000 points. In other words the following disparity should be observed: Maximum Range (MR) \leq 50000 x Scale division.

Procedure

The following table shows the procedure for defining the metrological information.

Step	Action
1	Access the weighing module configuration screen.
2	Select the parameter values Unit , Scale division or Threshold overload using the drop-down lists offered and enter the Maximum Range value.
3	Confirm the modification with the command Edit → Validate .

How to modify the zero

At a glance

The configuration screen offers the following information for zero setting.

Designation	Description
Extent of the recalibration range	Any deviation from zero can be corrected as long as it does not exceed this range. It is defined as a % of the maximum range. It may take the values: <ul style="list-style-type: none"> ● +/-2 % PM (+/- 2 % of the maximum range), ● +/-5 % PM (+/-5 % of the maximum range),
Zero Tracking	This optional function is used to compensate for slow deviations from zero in the extent of range (+/-2 % of the maximum range). You are not advised to choose this option in the automatic installations.

Note: The discrimination between a slow deviation and a true weight is based on the following rule: any variation in weight lower than the semi-scale division whose repetition frequency is sufficiently weak to preserve the stability of the measurement is considered to be a deviation. The correction engendered by the function is limited to +/-2 % of the maximum range of the flip-flop. When this limit is exceeded, there is no automatic correction.

Procedure

The following table shows the procedure for defining zero.

Step	Action
1	Access the weighing module configuration screen.
2	Select the extent of range by using the drop-down menu.
3	If necessary, check the Zero tracking box to confirm this function.
4	Confirm the modification with the command Edit → Validate .

How to modify the data format

At a glance

The configuration screen allows you to choose the measurement's display format. You may enter the weight value:

- either as a fixed point physical unit: **Legal** format,
- or as a hundredth of a fixed point physical unit: **High resolution**.

Note: A fixed point physical unit is called a whole number expressed as a unit of weight where a point can be put. The position of this is given by the power of ten of the scale division.

Example

Legal format: the value 3014 means 301.4 kg if the scale is $2 \cdot 10^{-1}$ kg.

High resolution format: the value 301403 means 301,403 kg if the scale is $2 \cdot 10^{-1}$ kg. This unit offers greater accuracy but it is not accepted by the Legal Metrology Department.

Procedure

The following table shows the procedure for modifying the data format.

Step	Action
1	Access the weighing module configuration screen.
2	Check the data format required.
3	Confirm the modification with the command Edit → Validate .

How to modify the stability

At a glance

The configuration screen offers the following parameters to define the stability.

Designation	Description
Extent of range	A weight cannot be measured immediately after receiving a load because the inevitable oscillations affect the mechanical part. The stability range shows the size below which the measurement is considered stable. It is parameterized on 2, 3, 4, 6 or 8 quarters of a scale.
Time	The stability time shows how long the measurement must stay in the stability range before it is considered stable. It is parameterized on 0.4, 0.5, 0.7 or 1 second.

Procedure

The following table shows the procedure for defining the stability.

Step	Action
1	Access the weighing module configuration screen.
2	Select the extent of range using the drop-down menu Extent of range in the Stability field.
3	Select the stability time using the drop-down menu Time in the Stability field.
4	Confirm the modification with the command Edit → Validate .

How to modify measurement input Filter(s)

At a glance

Filters concern the measurement input of the weighing sensors.

By default, a unique filter is offered which is defined for the total duration of the weighing action.

To increase the speed/precision performance of weighing, 3 different filters can be used for the same weighing action, as follows:

- filter **F1** associated with phase 1 (default phase),
- filter **F2** associated with phase 2,
- filter **F3** associated with phase 3.

Each filter can either have:

- a sliding average (filtering coefficients from 1 to 11), where the measurement is the average of the last n values,
 - or be of second order (filtering coefficients from 12 to 19), which are referenced by their cut-off frequencies.
-

Measurement Phases

The various phases of a continuous weighing action can be broken down into:

- a phase 1, where speed is the prime feature of control precision (High flow),
 - a measurement refining phase 2 (Low flow),
 - a final phase 3, where the measurement value differs very little and requires a high level of precision (Residual flow).
-

Filter Coefficients

The following list gives the meanings of the filter coefficients:

Value	Filter type	Characteristics
0	none	not filtered
1	sliding average	average of the last 2 measurements
2	sliding average	average of the last 3 measurements
3	sliding average	average of the last 4 measurements
4	sliding average	average of the last 5 measurements
5	sliding average	average of the last 8 measurements
6	sliding average	average of the last 16 measurements
7	sliding average	average of the last 25 measurements
8	sliding average	average of the last 32 measurements
9	sliding average	average of the last 40 measurements
10	sliding average	average of the last 50 measurements
11	sliding average	average of the last 64 measurements
12	second order filter	cut-off frequency at 15 Hz
13	second order filter	cut-off frequency at 10 Hz
14	second order filter	cut-off frequency at 8 Hz
15	second order filter	cut-off frequency at 6 Hz
16	second order filter	cut-off frequency at 4 Hz
17	second order filter	cut-off frequency at 2 Hz
18	second order filter	cut-off frequency at 1 Hz
19	second order filter	cut-off frequency at 0.8 Hz

Procedure

The following table shows the procedure for defining the filter:

Step	Action
1	Access the weighing module configuration screen.
2	If filters F2 et F3 are being used check the Active box in the Threshold check field.
3	Select for each phase, the filtering coefficient using the drop-down menus F1 , F2 and F3 in the Filtering field.
4	Confirm the modification with the command Edit → Validate .

How to modify the flow calculation

At a glance

You can choose the number of measurements for calculating the flow. (One measurement is taken every 20 milli-seconds).

The flow is a difference in the values of filtered weights for a number of configured measurements. The flow is calculated using the following formula:

$$\text{Flow } n = \text{Val}n - (\text{Val}n-b)$$

where:

- b = the number of measurements for calculating the flow,
- $\text{Val}n$ = the filtered weight value at the moment n ,
- $\text{Val}n-b$ = the filtered weight value at the moment $n-b$.

Operation

At each instant, the frequency is calculated and implicitly sent back to the processor as the weight measurement, in order to allow threshold corrections.


The flow is always calculated in high resolution format.

This calculation can be done on 2, 4, 8, 16, 32 or 64 measurements.

By default, the number of measurements is 4.

Example

The following figure illustrates a calculation on 4 measurements.



$$\text{flow } n+4 = \text{Val } n+4 - \text{Val } n$$

$$\text{flow } n+5 = \text{Val } n+5 - \text{Val } n+1$$

Procedure

The following table shows the procedure for defining flow calculation.

Step	Action
1	Access the weighing module configuration screen.
2	Select the number of measurements using the drop-down menu from the Flow field.
3	Confirm the modification with the command Edit → Validate .

How to modify the tare

At a glance

The tare is the weight measurement memorized during the last semi-automatic tare unit command.

However, if necessary, you can introduce a tare value manually. Therefore, this tare value is known as predefined or manual and can be transmitted to the module. It is expressed in legal format (physical unit with fixed decimal point).

The tare must be positive or zero and be lower than the Max. Range.

Once a device of this sort is used, the predefined tare (PT) indicator is positioned. It is disabled once a **Taring** order is executed.

Note: The entry range extends from 0 to 65535. If you want a greater tare, you must modify the scale and enter the tare accordingly.

Procedure

The following table shows the procedure for defining a predetermined tare and the tare value.

Step	Action
1	Access the weighing module configuration screen.
2	<p>If necessary check the Predetermined box in the Tare field to confirm this function.</p> <p>Note: If this box is already checked, you must first:</p> <ul style="list-style-type: none"> ● uncheck this box, ● enable the configuration screen, ● check the Predefined box again.
3	Enter the tare value in the Value entry field.
4	Confirm the modification with the command Edit → Validate .

How to modify the threshold check

At a glance

The threshold check manages the module's discrete outputs:

- the **High Flow cut-off point** is associated with output S0,
- the **Low Flow cut-off point** is associated with output S1.



The configuration screen gives the following threshold check information.

Designation	Description
Active	Discrete output management is operational if this box is checked. It is not checked by default.
Direction	The detection direction corresponds to the direction in which the thresholds are recognized i.e.: <ul style="list-style-type: none"> ● Weighing (filling), ● Downweighing (emptying). This is the concept of exceeding by a greater value, in the case of weighing, or by a lower value, in the case of downweighing. By default, Weighing is selected.
Phase 1 active outputs	The choice concerns the control of the S0 output on its own, or the S0 and S1 outputs at the same time. See the explanation that follows. By default, the module only activates S0 in the first phase.
Cut-off points	The measurement can be associated with 2 thresholds for the following dosages: A High Flow cut-off point and a Low Flow cut-off point . Depending on the logic defined, the S0 and S1 outputs go to zero when these thresholds are met. The threshold values allowed lie between 0 and the maximum range. They are expressed in high resolution (one hundredth of a physical unit with fixed decimal point).
LF (Low Flow) mask time	It defines the time after the high flow cut-off, during which the module no longer checks the Weight/Threshold; This is to mask the overshoot caused when the product has a drop in voltage. The values allowed lie between 0 and 1.5 seconds per 1/10th second step. See the explanation that follows. By default, this time is zero.



Activating Outputs

The following illustration describes the output operating differences between the choice of active phase 1 Outputs: S0 or S0 and S1.

Active output phase 1 (S0)




Active output phase 1 (S0 and S1)



Masking Time

The following illustration shows the role of the masking time, the aim of which is to mask the overshoot caused when the product has a drop in voltage.



Procedure

The following table shows the procedure for the threshold check.

Step	Action
1	Access the weighing module configuration screen.
2	If necessary check the Active box in the Threshold check field to activate this function.
3	Check the selection boxes corresponding to the detection direction (Weighing or Downweighing) and to the phase 1 active outputs (S0 or S0 and S1).
4	Enter the Low flow and High flow in the Breaking points field.
5	Using the drop-down menu in the Threshold check field, select the PD masking time .
6	Confirm the modification with the command Edit → Validate .

Presentation of the weighing module language objects



At a glance

Aim of this section

This section describes the language objects associated with the weighing module from the various IODDTs.

What's in this Chapter?

This chapter contains the following sections:

Section	Topic	Page
8.1	General on the weighing programming	70
8.2	Language objects and IODDT	76
8.3	The IODDTs of the weighing module	85
8.4	Description of the commands conveyed by program	95
8.5	Modifying the parameters by program	107

8.1 General on the weighing programming

At a glance

Subject of this section

This section describes the general principles of programming a weighing application.

What's in this Section?

This section contains the following topics:

Topic	Page
Weighing application programming principle	71
Addressing language objects associated with the weighing Module	73
Description of the Main Objects Linked to the Weighing Function	74

Weighing application programming principle

General

Once it is configured, the weighing module is fitted with sensors and linked to a TSX XBT display. The TSX ISPY101 can operate autonomously (without a program). These outputs may be controlled without the intervention of the PLC processor program.

Programming at the level of the PLC processor makes it possible to:

- make weighing information available in order to carry out other processes or to drive other control devices,
- to dynamically modify the weighing function parameters by means of explicit commands.

Access to measurements

The numerical values of the (GROSS or NET) weights and flow rate are stored in 2 double word input registers (%ID). They are completed by 1 measurement Status word (%W), 1 tare value double word (%ID) and 1 calibration memory double word (%ID) (offset from zero).

i.e. a variable `IODDT_VAR1 IODDT T_WEIGHING_ISPY101`.

The table below lists the weighing numerical values transmitted by the weighing function.

Symbol	Register address	Meaning of the register
IODDT_VAR1.WEIGHT	%IDr.m.0.0	Weight value (GROSS or NET)
IODDT_VAR1.FLOW_RATE	%IDr.m.0.2	Flow
IODDT_VAR1.MEASURE_DATA	%lWr.m.0.4	Measurement state: stability, zero ...
IODDT_VAR1.TARE	%IDr.m.0.5	Tare value
IODDT_VAR1.OFFSET_MEM_VAL	%IDr.m.0.7	Recalibration memory (zero offset)

These data are returned automatically to the processing unit at the start of the task associated with the channel, whether the task is in Run or in Stop mode. The data are directly accessible:

- by the application via an operator dialog (access to PLC memory image objects),
- by the terminal using the animation tables.

**Dynamic
modification of
the parameters**

The preset adjustment parameters may be modified automatically during the operation of the program with the explicit exchange instruction `WRITE_PARAM`.

Example: modification of the SO high flow and SI low flow cut-off-points.

Addressing language objects associated with the weighing Module

At a glance

This page introduces addressing specifics linked to weighing modules.

Illustration

Reminder of addressing principle:

%	I, Q, M, K	X, W, D, F	r	□	m	□	c	□	d
Symbol	Type of Object	Format	Rack		Module		Channel No.		Rank

Specific values


The table below gives the values that are specific to weighing module objects.

Element	Values	Comment
r	0 to 7	Rack address.
m	0 to 14	Position of the module in the rack.
c	0 or MOD	0 channel number. MOD: channel reserved for module management and parameters common to all channels.
d	0 to 16 or ERR	ERR: indicates a module or channel fault.

Description of the Main Objects Linked to the Weighing Function

Illustration

The illustration presents the formation of the different functions executed by the module, and the associated language objects.



Description The following table describes the main language objects. i.e. a WGH1 IODDT T_WEIGHTING_ISPY101variable.

Symbol	Address	Type of object to exchange	Role
WGH1.WEIGHT	%IDr.m.0.0	Implicit	Weight value (gross or net).
WGH1.FLOW_RATE	%IDr.m.0.2	Implicit	Flow.
WGH1.TARE	%IDr.m.0.5	Implicit	Tare value.
WGH1.OFFSET_MEM_VAL	%IDr.m.0.7	Implicit	Recalibration memory (zero offset).
WGH1.F1_FILTER	%MWr.m.0.6	Explicit	F1 filter coefficient.
WGH1.MANU_TARE	%MWr.m.c.0	Explicit	Manual tare.
WGH1.HF_CUT	%MDr.m.0.8	Explicit	S0 high flow cut-off point (dosage).
WGH1.LF_CUT	%MDr.m.0.10	Explicit	S1 high flow cut-off point (dosage).
WGH1.OUTPUTS_LOGIC	%MWr.m.0.12	Explicit	Logic of outputs S0 and S1 (dosage).
WGH1.MASK_TIME	%MWr.m.0.13	Explicit	PD mask time.
WGH1.FLOW_MEAS_NB	%MWr.m.0.14	Explicit	Number of measurements used to calculate flow rate.
WGH1.F2_FILTER	%MWr.m.0.15	Explicit	F2 filter coefficient.
WGH1.F3_FILTER	%MWr.m.0.16	Explicit	F3 filter coefficient.

8.2 Language objects and IODDT

At a glance

Aim of this sub-section

This sub-section shows the general features of the language objects and IODDT of the weighing module.

What's in this Section?

This section contains the following topics:

Topic	Page
Presentation of language objects associated with the Weighing function	77
Implicit exchange language objects associated with the application-specific function	78
Explicit Exchange Language Objects Associated with the Application-Specific Function	79
Management of Exchanges and Reports with Explicit Objects	81

Presentation of language objects associated with the Weighing function

General

The weighing module has various associated IODDTs.

The IODDTs are predefined by the manufacturer and contain output/input language objects belonging to the channel of an application-specific module.

The Weighing function IODDT is of the type `T_WEIGHING_ISPY101`.

Note: IODDT variables can be created in two different ways:

- Using the **I/O objects** (See Unity Pro, Operating Modes Manual, I/O Objects Tab for a Module) tab,
- Data Editor (See Unity Pro, Operating Modes Manual, Creation of an IODDT type data instance).

Language object types

In each of the IODDTs there is a set of language objects enabling them to be controlled and check their operation.

There are two types of language objects:

- **implicit exchange objects**, which are automatically changed on each task cycle associated with the module,
- **explicit exchange objects**, which are changed at the request of the application, using explicit exchange instructions.

Implicit exchanges concern the inputs/outputs of the module: measuring results, information and commands.

Explicit exchanges are used to parameterize the module and to diagnose it.

Implicit exchange language objects associated with the application-specific function

At a Glance

An integrated application-specific interface or the addition of a module automatically enhances the language objects application used to program this interface or module.

These objects correspond to the input/output images and software data of the module or integrated application-specific interface.

Reminders

The module inputs (%I et %IW) are updated in the PLC memory at the start of the task, the PLC being in RUN or STOP mode.


The outputs (%Q et %QW) are updated at the end of the task, only when the PLC is in RUN mode.

Note: When the task occurs in STOP mode, either of the following are possible, depending on the configuration selected:

- Outputs are set to fallback position (fallback mode),
 - Outputs are maintained at their last value (maintain mode).
-

Figure

The following diagram shows the operating cycle of a PLC task (cyclical execution).



Explicit Exchange Language Objects Associated with the Application-Specific Function

Introduction

Explicit exchanges are exchanges performed at the user program's request, and using instructions:

- READ_STS (See Unity Pro, I/O Management Manual, RESTORE_PARAM) (read status words),
- WRITE_CMD (See Unity Pro, I/O Management Manual, WRITE_CMD) (write command words),
- WRITE_PARAM (See Unity Pro, I/O Management Manual, WRITE_PARAM) (write adjustment parameters),
- READ_PARAM (See Unity Pro, I/O Management Manual, READ_PARAM) (read adjustment parameters),
- SAVE_PARAM (See Unity Pro, I/O Management Manual, SAVE_PARAM) (save adjustment parameters),
- RESTORE_PARAM (See Unity Pro, I/O Management Manual, READ_STS) (restore adjustment parameters).

These exchanges apply to a set of %MW objects of the same type (status, commands or parameters) that belong to a channel.


Note:

These objects can:

- provide information about the module (for example, type of channel fault)
- have command control of the module (for example, switch command)
- define the module's operating modes (save and restore adjustment parameters in the process of application)

General Principle for Using Explicit Instructions

The diagram below shows the different types of explicit exchanges that can be made between the processor and module.



(1) Only with `READ_STS` and `WRITE_CMD` instructions.


Managing Exchanges

During an explicit exchange, it is necessary to check its performance in order that data is only taken into account when the exchange has been correctly executed.

To do this, two types of information is available:

- information concerning the exchange in progress (See *Execution Indicators for an Explicit Exchange: EXCH_STS*, p. 84),
- the exchange report (See *Explicit Exchange Report: EXCH_RPT*, p. 84).

The following diagram describes the management principle for an exchange



Management of Exchanges and Reports with Explicit Objects


At a Glance

When data is exchanged between the PCL memory and the module, the module may require several task cycles to acknowledge this information. All IODDTs use two words to manage exchanges:

- EXCH_STS (%MW_{r.m.c.}0): exchange in progress,
- EXCH_RPT (%MW_{r.m.c.}1): report.

Illustration

The illustration below shows the different significant bits for managing exchanges:



Description of Significant Bits

Each bit of the words `EXCH_STS` (%MWr.m.c.0) and `EXCH_RPT` (%MWr.m.c.1) is associated with a type of parameter:


- Rank 0 bits are associated with the status parameters:
 - the `STS_IN_PROGR` bit (%MWr.m.c.0.0) indicates whether a read request for the status words is in progress,
 - the `STS_ERR` bit (%MWr.m.c.1.0) specifies whether a read request for the status words is accepted by the module channel.
- Rank 1 bits are associated with the command parameters:
 - the `CMD_IN_PROGR` bit (%MWr.m.c.0.1) indicates whether command parameters are being sent to the module channel,
 - the `CMD_ERR` bit (%MWr.m.c.1.1) specifies whether the command parameters are accepted by the module channel.
- Rank 2 bits are associated with the adjustment parameters:
 - the `ADJ_IN_PROGR` bit (%MWr.m.c.0.2) indicates whether the adjustment parameters are being exchanged with the module channel (via `WRITE_PARAM`, `READ_PARAM`, `SAVE_PARAM`, `RESTORE_PARAM`),
 - the `ADJ_ERR` bit (%MWr.m.c.1.2) specifies whether the adjustment parameters are accepted by the module. If the exchange is correctly executed, the bit is set to 0.
- rank 15 bits indicate a reconfiguration on channel `c` of the module from the console (modification of the configuration parameters + cold start-up of the channel).

Note: `r` represents the rack number and `m` the position of the module in the rack, while `c` represents the channel number in the module.

Note: Exchange and report words also exist at module level `EXCH_STS` (%MWr.m.MOD) and `EXCH_RPT` (%MWr.m.MOD.1) as per IODDT type `T_GEN_MOD`.


Example

Phase 1: Sending data by using the `WRITE_PARAM` instruction.



When the instruction is scanned by the PLC processor, the **Exchange in progress** bit is set to 1 in `%MWr.m.c`.

Phase 2: Analysis of the data by the I/O module and report.



When the data is exchanged between the PLC memory and the module, acknowledgement by the module is managed by the `ADJ_ERR` bit (`%MWr.m.c.1.2`): Report (0 = correct exchange, 1 = faulty exchange).

Note: There is no adjustment parameter at module level.

Execution Indicators for an Explicit Exchange: EXCH_STS

The table below shows the control bits of the explicit exchanges : EXCH_STS (%MWr.m.c.0).

Standard symbol	Type	Access	Meaning	Address
STS_IN_PROGR	BOOL	R	Reading of channel status words in progress	%MWr.m.c.0.0
CMD_IN_PROGR	BOOL	R	Command parameters exchange in progress	%MWr.m.c.0.1
ADJ_IN_PROGR	BOOL	R	Adjust parameters exchange in progress	%MWr.m.c.0.2
RECONF_IN_PROGR	BOOL	R	Reconfiguration of the module in progress	%MWr.m.c.0.15

Note: If the module is not present or is disconnected, explicit exchange objects (READ_STS for example) are not sent to the module (STS_IN_PROG (%MWr.m.c.0.0) = 0), but the words are refreshed.

Explicit Exchange Report: EXCH_RPT

The table below shows the report bits: EXCH_RPT (%MWr.m.c.1).

Standard symbol	Type	Access	Meaning	Address
STS_ERR	BOOL	R	Error reading channel status words (1 = failure)	%MWr.m.c.1.0
CMD_ERR	BOOL	R	Error during a command parameter exchange (1 = failure)	%MWr.m.c.1.1
ADJ_ERR	BOOL	R	Error during an adjust parameter exchange (1 = failure)	%MWr.m.c.1.2
RECONF_ERR	BOOL	R	Error during reconfiguration of the channel (1 = failure)	%MWr.m.c.1.15

8.3 The IODDTs of the weighing module

At a glance

Aim of this sub-section

This sub-section shows the various IODDTs and language objects associated with the weighing module.

What's in this Section?

This section contains the following topics:

Topic	Page
Detail of the implicit exchange objects of the IODDT of type T_WEIGHING_ISPY101	86
Explicit exchange objects of the IODDT of type T_WEIGHING_ISPY101	89
Explicit exchange objects of the IODDT of type T_WEIGHING_ISPY101	91
Explicit exchange objects of the IODDT of type T_WEIGHING_ISPY101	92
Details of the Language Objects of the IODDT of Type T_GEN_MOD	94

Detail of the implicit exchange objects of the IODDT of type T_WEIGHTING_ISPY101

At a glance The table below shows the implicit exchange objects of the IODDT of type T_WEIGHTING_ISPY101 which applies to the module TSX ISPY 101.

Error bit %lr.m.c.ERR The table below shows the meaning of the error bit CH_ERROR (%lr.m.c.ERR):

Standard symbol	Type	Access	Meaning	Address
CH_ERROR	BOOL	R	Error bit of the weighing channel.	%lr.m.c.ERR

Word objects The table below shows the various implicit exchange word objects:

Standard symbol	Type	Access	Meaning	Address
WEIGHT	DINT	R	<p>Weight value (gross or net). By default, if no taring command has been executed, the weight value is expressed as a GROSS weight. It changes to NET weight as soon as the taring command is executed or a tare has been manually introduced. The measurement is expressed in legal format or high resolution according to the choice created at configuration.</p>	%IDr.m.0.0
FLOW_RATE	DINT	R	<p>Flow. Example: %IDxy.0.2 = 450 000 means that, if the scale division is equal to 1.10^{-2} kg, a weight difference of 45 kg has been measured between n measurements (sampling every 20 ms). The n number of measurements is defined at configuration.</p>	%IDr.m.0.2
TARE	DINT	R	<p>Tare value. This word allows the current tare value to be visualized in the same format as the weight. It is memorized by the module. It is reset to 0 at each calibration.</p>	%IDr.m.0.5
OFFSET_MEM_VAL	DINT	R	<p>Recalibration memory (zero offset) This word allows the offset to be visualized currently in high resolution format. This value is memorized by the module. It is reset to 0 at each calibration.</p>	%IDr.m.0.7

**Measurement
state word
objects**

The table below shows the various status word bits `MEASURE_DATA` (%IW.r.m.0.4):

Standard symbol	Type	Access	Meaning	Address
Q0_OUT	BOOL	R	Image of output S0.	%IW.r.m.0.4.0
Q1_OUT	BOOL	R	Image of output S1.	%IW.r.m.0.4.1
UNDERLOAD	BOOL	R	Indicator that voltage is too low. The measurement is deviating. There is a strong possibility of an error on a sensor or in the wiring.	%IW.r.m.0.4.2
OVERLOAD	BOOL	R	Voltage too high on module input.	%IW.r.m.0.4.3
SEALED_ON	BOOL	R	Sealed module.	%IW.r.m.0.4.4
IN_PROGR	BOOL	R	Processing in progress (Taring, Reset, etc.).	%IW.r.m.0.4.5
CAL_IN_PROGR	BOOL	R	Calibration during processing.	%IW.r.m.0.4.6
CMD_FLT	BOOL	R	Fault during command.	%IW.r.m.0.4.7
NET	BOOL	R	NET weight measurement.	%IW.r.m.0.4.8
STABILITY	BOOL	R	Measurement instability. This is set when the measurement is outside the stability range during the defined time. The extent of the stability range and the time are defined during configuration.	%IW.r.m.0.4.9
ZERO	BOOL	R	Zero indicator. This is set when the deviation from zero is no greater than +/- 1/4 of the scale division.	%IW.r.m.0.4.10
ZERO_TRACK	BOOL	R	Zero tracking indicator active.	%IW.r.m.0.4.11
PREDEF_TARE	BOOL	R	Predefined or manual tare indicator (language element specific to module, accessible in read only). This is set when the tare is not the result of a taring command but rather an entry by the user.	%IW.r.m.0.4.12

Explicit exchange objects of the IODDT of type T_WEIGHTING_ISPY101

At a glance

This part shows the explicit exchange objects of the IODDT of type T_WEIGHTING_ISPY101 which apply to the TSX ISPY101 module. It groups together the word objects, the bits of which have a particular meaning. These objects are shown in detail below.

Example of declaration of a variable: IODDT_VAR1 T_WEIGHTING_ISPY101.

Notes

- Generally speaking the meaning of the bits is given for the state 1 of this bit. In specific cases each bit state is explained.
- Not all the bits are used.

Managing exchanges: EXCH_STS

The table below shows the meaning of the exchange control bits of the channel EXCH_STS (%MWr.m.0.0).

Standard symbol	Type	Access	Meaning	Address
STS_IN_PROGR	BOOL	R	Exchange of the status parameters (STATUS) in progress.	%MWr.m.0.0.0
CMD_IN_PROGR	BOOL	R	Command parameters exchange in progress	%MWr.m.0.0.1
ADJ_IN_PROGR	BOOL	R	Adjustment parameters exchange in progress	%MWr.m.0.0.2
RECONF_IN_PROGR	BOOL	R	Reconfiguring the module.	%MWr.m.0.0.15

Exchange report: EXCH_RPT

The table below shows the meaning of the report bits EXCH_RPT (%MWr.m.0.1).

Standard symbol	Type	Access	Meaning	Address
STS_ERR	BOOL	R	exchange report of the status parameters (STATUS).	%MWr.m.0.1.0
CMD_ERR	BOOL	R	Exchange report of the command parameters.	%MWr.m.0.1.1
ADJ_ERR	BOOL	R	Exchange report of the adjustment parameters.	%MWr.m.0.1.2
RECONF_ERR	BOOL	R	Configuration fault.	%MWr.m.0.1.15

Operating state of the channel: CH_FLT

The table below shows the meaning of the bits of the status word CH_FLT (%MWr.m.0.2), read is carried out by a READ_STS (IODDT_VAR1).

Standard symbol	Type	Access	Meaning	Address
CAL_OVERLOAD_FLT	BOOL	R	External error: Overload or underload during calibration	%MWr.m.0.2.0
OVER_RANGE_FLT	BOOL	R	Range (2) overshoot fault or dynamics lower than 4.5mV at calibration.	%MWr.m.0.2.1
SAT_FLT	BOOL	R	External error: saturation of the measurement circuit.	%MWr.m.0.2.2
SEALED_FLT	BOOL	R	External error: sealed module, configuration refused.	%MWr.m.0.2.3
INTERNAL_FLT	BOOL	R	Internal error: module failure.	%MWr.m.0.2.4
CONF_FLT	BOOL	R	Configuration fault: the current module is not the one declared on configuration.	%MWr.m.0.2.5
COM_FLT	BOOL	R	Communication fault with the processor.	%MWr.m.0.2.6
APPLI_FLT	BOOL	R	Application fault.	%MWr.m.0.2.7
PROTECT_FLT	BOOL	R	Protected module error, parameter refused: the module refuses the parameter if it influences the current value.	%MWr.m.c.2.8
NON_CAL_FLT	BOOL	R	Module not calibrated.	%MWr.m.0.2.9
OVERLOAD_FLT	BOOL	R	Overload error.	%MWr.m.0.2.10
UNDERLOAD_FLT	BOOL	R	Underload error.	%MWr.m.0.2.11
TARE_MODE	BOOL	R	Taring mode.	%MWr.m.0.2.12
ZERO_MODE	BOOL	R	Zero mode.	%MWr.m.0.2.13
CAL_MODE	BOOL	R	Calibration mode.	%MWr.m.0.2.14
FORCED_CAL_MODE	BOOL	R	Forced calibration mode.	%MWr.m.0.2.15

Explicit exchange objects of the IODDT of type T_WEIGHTING_ISPY101

At a glance

This word type object allows commands to be sent to the weighing module by explicit exchange (WRITE_CMD instruction).

Managing exchanges: CMD_TYPE

The table below shows the meaning of the word bits CMD_TYPE (%MWr.m.0.3).

Standard symbol	Type	Access	Meaning	Address
MOD_CAL_SAVE_CMD	BOOL	R/W	Save calibration coefficients in module.	%MWr.m.0.3.0
ZERO_LOAD_CAL_CMD	BOOL	R/W	Zero Load calibration.	%MWr.m.0.3.1
STD_LOAD_CAL_CMD	BOOL	R/W	Calibration Weight Calibration (Normal condition).	%MWr.m.0.3.2
CANCEL_CMD	BOOL	R/W	Cancellation of command (calibration, setting to zero, taring).	%MWr.m.0.3.3
TARE_CMD	BOOL	R/W	Taring order.	%MWr.m.0.3.4
ZERO_CMD	BOOL	R/W	Reset order.	%MWr.m.0.3.5
GROSS_CMD	BOOL	R/W	Return to GROSS weight order.	%MWr.m.0.3.6
MANU_TARE_DISP_CMD	BOOL	R/W	3 second display of manual tare.	%MWr.m.0.3.7
TH_EN_CMD	BOOL	R/W	Enable thresholds.	%MWr.m.0.3.8
TH_DIS_CMD	BOOL	R/W	Disable thresholds.	%MWr.m.0.3.9
FORCED_CAL_CMD	BOOL	R/W	Forced calibration (CPU -> Module).	%MWr.m.0.3.10
CPU_CAL_SAVE_CMD	BOOL	R/W	Save calibration coefficients in processor.	%MWr.m.0.3.11
DG_CAL_CMD	BOOL	R/W	Standard load calibration in degraded condition (Standard load < 70 % of maximum weight).	%MWr.m.0.3.12

Explicit exchange objects of the IODDT of type T_WEIGHTING_ISPY101

At a glance

This part shows the explicit exchange objects of the IODDT of type T_WEIGHTING_ISPY101 which apply to the TSX ISPY101 module. It groups together word objects. These objects are shown in detail below.

Example of declaration of a variable: IODDT_VAR1 of type T_WEIGHTING_ISPY101.

Word objects

The table below shows the meaning of the words. The requests used are those associated with the parameters (READ_PARAM, WRITE_PARAM, SAVE_PARAM, RESTORE_PARAM).

Standard symbol	Type	Access	Meaning	Address
STD_LOAD	DINT	R/W	Standard load weight for the calibration command.	%MDr.m.0.4
F1_FILTER	INT	R/W	F1 filter coefficient.	%MWr.m.0.6
MANU_TARE	INT	R/W	Manual tare value.	%MWr.m.0.7
HF_CUT	DINT	R/W	S0 high flow cut-off point (dosage).	%MDr.m.0.8
LF_CUT	DINT	R/W	S1 high flow cut-off point (dosage).	%MDr.m.0.10

Output logic

The table below shows the meaning of the word bits OUTPUTS_LOGIC (%MWr.m.0.12). The requests used are those associated with the parameters (READ_PARAM, WRITE_PARAM, SAVE_PARAM, RESTORE_PARAM).

Standard symbol	Type	Access	Meaning	Address
WEIGH_UNWEIGH	BOOL	R/W	Low Flow mask time.	%MWr.m.0.12.0
Q0_OR_QOQ1	BOOL	R/W	Number of measurements used to calculate flow rate.	%MWr.m.0.12.1

Word objects

The table below shows the meaning of the words. The requests used are those associated with the parameters (READ_PARAM, WRITE_PARAM, SAVE_PARAM, RESTORE_PARAM).

Standard symbol	Type	Access	Meaning	Address
MASK_TIME	INT	R/W	Low Flow mask time.	%MWr.m.0.13
FLOW_MEAS_NB	INT	R/W	Number of measurements used to calculate flow rate.	%MWr.m.0.14
F2_FILTER	INT	R/W	F2 filter coefficient.	%MWr.m.0.15
F3_FILTER	INT	R/W	F3 filter coefficient.	%MWr.m.0.16

Details of the Language Objects of the IODDT of Type T_GEN_MOD

At a Glance All the modules of Premium PLCs have an associated IODDT of type T_GEN_MOD.

Observations

- In general, the meaning of the bits is given for bit status 1. In specific cases an explanation is given for each status of the bit.
- Not all bits are used.

List of Objects The table below presents the objects of the IODDT:

Standard symbol	Type	Access	Meaning	Address
MOD_ERROR	BOOL	R	Module error bit	%I.r.m.MOD.ERR
EXCH_STS	INT	R	Module exchange control word.	%MWr.m.MOD.0
STS_IN_PROGR	BOOL	R	Reading of status words of the module in progress.	%MWr.m.MOD.0.0
EXCH_RPT	INT	R	Exchange report word.	%MWr.m.MOD.1
STS_ERR	BOOL	R	Fault when reading module status words.	%MWr.m.MOD.1.0
MOD_FLT	INT	R	Internal error word of the module.	%MWr.m.MOD.2
MOD_FAIL	BOOL	R	Internal error, module failure.	%MWr.m.MOD.2.0
CH_FLT	BOOL	R	Faulty channel(s).	%MWr.m.MOD.2.1
BLK	BOOL	R	Terminal block fault.	%MWr.m.MOD.2.2
CONF_FLT	BOOL	R	Hardware or software configuration fault.	%MWr.m.MOD.2.5
NO_MOD	BOOL	R	Module missing or inoperative.	%MWr.m.MOD.2.6
EXT_MOD_FLT	BOOL	R	Internal error word of the module (Fipio extension only).	%MWr.m.MOD.2.7
MOD_FAIL_EXT	BOOL	R	Internal fault, module unserviceable (Fipio extension only).	%MWr.m.MOD.2.8
CH_FLT_EXT	BOOL	R	Faulty channel(s) (Fipio extension only).	%MWr.m.MOD.2.9
BLK_EXT	BOOL	R	Terminal block fault (Fipio extension only).	%MWr.m.MOD.2.10
CONF_FLT_EXT	BOOL	R	Hardware or software configuration fault (Fipio extension only).	%MWr.m.MOD.2.13
NO_MOD_EXT	BOOL	R	Module missing or inoperative (Fipio extension only).	%MWr.m.MOD.2.14

8.4 Description of the commands conveyed by program

At a glance

Subject of this section

This section describes the different commands that can be executed by program.

What's in this Section?

This section contains the following topics:

Topic	Page
Sending commands to the weighing module by program	96
How to perform a tare mode by program	97
How to reset the value of the weight to zero by program	100
How to return to gross weight measurement via the program	102
How to display the manual tare via the program	104
How to enable or disable Thresholds by program	105

Sending commands to the weighing module by program

General

Commands are sent to the module using the `WRITE_CMD` instruction with the following syntax: `WRITE_CMD (%CHR.m.0)`

This instruction sends the order to the module and awaits its acknowledgement. This wait may require several task cycles.

Note: The module only interprets one command at a time. If a command is requested while the previous command is being processed, the new command is refused. There should never be more than one bit at 1 in the command word.

Monitoring parameter recognition

As the module may require several task cycles to recognize commands, two memory words are standardized to control the `%MWr.m.0.0` and `%MWr.m.0.1` exchanges

The first word `%MWr.m.0.0` indicates a current exchange.

The second word `%MWr.m.0.1` gives the exchange report.

The following table describes the objects used for controlling the sending of commands to the module.

Address	Meaning (for the bit at state 1)
<code>%MWr.m.0.0.1</code>	Indicates that the command has been sent to the module.
<code>%MWr.m.0.1.1</code>	Shows if the command is accepted by the module.
<code>%MWr.m.0.2.7</code>	Signals that a command or parameter has been refused (application fault).

How to perform a tare mode by program

At a glance

This function involves bringing the value of the measured net weight to zero when a load, or tare, is placed on the load holder.

It therefore supports movement of the measurement with an offset value, in order to make it conform to the user's expected value.

When no tare mode operation has been carried out, the net weight is the same as the gross weight.

Note:

- When changing configuration, all tares are deleted. Any Tare mode command cancels all tares entered in manual mode and resets the "manual" tare indicator to zero,
- Similarly, an return to gross weight order allows you to delete all tare modes. It does not need any acceptance condition.

Execution conditions for the tare mode

The acceptance conditions for performing the Tare mode command are the following:

- the measurement is stable,
 - the measurement is below the maximum range,
 - the measurement is strictly positive.
-

Procedure

The following table describes the procedure for executing a tare mode operation.

Step	Action	Behavior of the module
1	Input the <code>WRITE_CMD</code> instruction while positioning the tare mode order (%MWr.m.0.3.4 = 1).	-
2	Confirm the execution, with the application in RUN mode.	The module switches to tare mode and sends the %lwr.m.0.4.5 = 1 Processing_in_progress report. Acquires the tare. Note: The value of the weight is measured and stored in the associated %IDr.m.0.5. It will be deducted from all further gross weight measurements to determine the net weight. End of acquisition: Processing_in_progress = 0
3	Monitor the command's smooth execution: State of Processing_in_progress : %lWr.m.0.4.5	The module stays in the Processing_in_progress state for as long as the acceptance conditions are not met or until it receives an order to cancel the command.

Summary of the data used

The table below provides a table of the data used for a tare mode.

Type	Role	Associated data
Command	Tare mode order	%MWr.m.0.3.4
Display	Tare value	%IDr.m.0.5
	Tare mode in progress	%lWr.m.0.4.5

Example

The following example in instruction list language describes a tare mode order being sent to the weighing module in slot 2, rack 0.

```
LD TRUE
S  %MW 2.0.3.4
[WRITE_CMD  (%CH2.0) ]
```

Executing the program involves:

Phase	Description
1	Sending the command.
2	Setting the %MW2.0.0.1 bit to 1, showing that the command is being sent.
3	This bit remains at 1 until the module sends a report. The bit then goes back to 0. The exchange report bit is then relevant.
4	The exchange report bit %MW2.0.1.1 rises to 1 if there is a problem during the exchange. The 0 value shows that the command has been accepted by the module.

Note:

%IW2.0.4.5 stays at 1 (Processing in progress) for as long as the acceptance conditions are not met (waiting for measurement stability, for example). The status channel's application fault bit is at 1 (module executing command). As for all commands, the order can be cancelled by sending the "cancel command in progress" command.

How to reset the value of the weight to zero by program

At a glance

This function consists in moving the measured weight value to zero. The zero indicator is then put into position.

It is controlled by the command bit **Set to Zero**. The correction carried out on the measurement is stored in the word %IDr.m.0.7, in a high resolution format. It can be saved by the application. This parameter is reset to zero on each calibration.

Note: On changing configuration, any setting to zero is deleted.

Conditions for carrying out zero setting

The acceptance conditions for performing the zero setting command are the following:

- the measurement is in gross weight,
- the measurement is stable,
- the measurement is included in the preset zero range extent.

Procedure

The following table describes the procedure for executing a tare mode operation.

Step	Action	Behavior of the module
1	Input the <code>WRITE_CMD</code> while setting the order Set to zero (%MWr.m.0.3.5 = 1).	-
2	Confirm the execution, with the application in RUN mode.	The module switches to set to zero and sends the Processing_in_progress report %IWr.m.0.4.5 = 1. The module proceeds to the acquisition of the measurement and memorizes the new value in the recalibration memory %IDr.m.0.7. Processing_in_progress = 0 signifies the end of the procedure.
3	Monitor the command's smooth execution: State of Processing_in_progress : %IWr.m.0.4.5	The module stays in the Processing_in_progress state for as long as the acceptance conditions are not met or until it receives an order to cancel the command.

Summary of the data used

The table below provides the data used for resetting to zero.

Type	Role	Associated data
Command	Reset order.	%MWr.m.0.3.5
Display	Recalibration memory	%IDr.m.0.7
Exchange	Processing in progress	%IW2.m.0.4.5

Example

The following example in instruction list language describes a **Reset order** being sent to the weighing module in slot 2, rack 0.

```
LD TRUE
S %MW 2.0.30.5
[WRITE_CMD (%CH2.0)]
```

Executing this order involves:

Phase	Description
1	Sending the command.
2	Setting the %MW2.0.0.1 bit to 1, showing that the command is being sent.
3	This bit remains at 1 until the module sends a report. The bit then goes back to 0. The exchange report bit is then relevant.
4	The exchange report bit %MW2.0.1.1 rises to 1 if there is a problem during the exchange. The 0 value shows that the command has been accepted by the module.

Note:

%IW2.0.4.5 stays at 1 (Processing in progress) for as long as the acceptance conditions are not met (waiting for measurement stability, for example). The status channel's application fault bit is at 1 (module executing command). As for all commands, the order can be cancelled by sending the **cancel command in progress** command.

How to return to gross weight measurement via the program

At a glance

This function cancels the tare value so that the current weight value is in gross weight.

The current weight is stored in the word %ldr.m..0.0, in the format set in configuration.

Execution conditions for the tare mode

This command does not require any particular execution conditions.

Procedure

The following table describes the procedure for executing a return to measurement in gross weight.

Step	Action	Behavior of the module
1	Input the <code>WRITE_CMD</code> while programming the tare mode order (%MWr.m.0.3.6 = 1).	-
2	Confirm the execution, with the application in RUN.	The module switches to "return to gross weight" mode. The module then sets the tare to zero. The NET = 0 (%lwr.m..0.4.8=0) flag shows the end of the procedure.
3	Check that the command has been performed correctly: State of the NET flag: %lWr.m.0.4.8	-

Summary of the data used

The table below provides the data used for resetting to zero.

Type	Role	Associated data
Command	Return to gross weight order	%MWr.m.0.3.6
Display	Measured weight	%IDr.m.0.0
	Value of the Tare in progress	%IDr.m.0.5
Exchange	Processing in progress	%IWr.m.0.4.5
	Gross Weight	%IWr.m.0.4.8 = 0

How to display the manual tare via the program

At a glance

This function supports display of the manual tare on the display panel for 3 seconds.

Execution conditions for the tare mode

For this command, a manual tare must have already been configured.

Procedure

The following table describes the procedure for displaying the manual tare.

Step	Action	Behavior of the module
1	Input <code>WRITE_CMD</code> while positioning the display order (%MWr.m.0.3.7 = 1).	-
2	Confirm the execution, with the application in RUN mode.	The module manages its data normally. The values displayed on the TSX XBT N410 display panel show the manual tare value.
3	After the 3 second delay, the display panel reverts to its current values.	-

Summary of the data used

The table below provides the data used for resetting to zero.

Type	Role	Associated data
Command	Tare display order	%MWr.m.0.3.7
Display	Manual tare	The data on the display panel show the manual tare.

How to enable or disable Thresholds by program

At a Glance

These functions are primarily used to coordinate the output command in relation to the processor-managed mechanism.

The threshold check option must first be enabled in the configuration screen.

Operating Principle

Action on outputs is performed from the command **Enabling of thresholds**. Once this command has been executed, the threshold check cycle starts.

A disable command is used to stop the threshold check cycle in progress and authorize a new threshold enabling command.

If need be, this command will also reset outputs S0 and S1 to 0.

Enabling Procedure

The following table describes the procedure for validating thresholds.

Step	Action	Behavior of the module
1	Make the necessary changes to the threshold values, output logic and mask time.	-
2	Set the threshold enabling order (%MWr.m.0.3.8 = 1).	-
3	Launch enable thresholds using the <code>WRITE_CMD</code> instruction.	The module interprets the request, sets the S0 and S1 outputs and ensures the conformity of the image bits: <ul style="list-style-type: none"> ● %IWrr.m.0.4.0 current position of S0. ● %IWrr.m.0.4.1 current position of S1.

Disabling Procedure

The following table describes the procedure for disabling thresholds.

Step	Action	Behavior of the module
1	Set the disable thresholds (%MWr.m.0.3.9 = 1).	-
2	Launch threshold disabling using the <code>WRITE_CMD</code> instruction.	The module sets outputs to idle and image bits to 0.

Summary of the data used

The table below provides the data used for enabling and disabling thresholds.

Type	Role	Associated data
Command	Threshold enabling order	%MWr.m.0.3.8
	Threshold disabling order	%MWr.m.0.3.9
Display	Current flow	%IDr.m.0.2
	High flow threshold	%MDr.m.0.8
	Low flow threshold	%MDr.m.0.10
	Output logic	%MWr.m.0.12
	LF mask time	%MWr.m.0.13
	S0 current position	%IWr.m.0.4.0
S1 current position	%IWr.m.0.4.1	

8.5 Modifying the parameters by program

At a glance

Subject of this section

This section describes how to dynamically modify the application's parameters by program.

What's in this Section?

This section contains the following topics:

Topic	Page
Modifying the parameters by program	108
Instructions used for adjustments	110
Description of parameters adjustable by program	112
Reading configuration parameters.	113

Modifying the parameters by program

Principle

You can command the modification of certain parameters by program, in order to automatically adapt the measurements to the processing applications.

Example: modifying the tare value by program if several types of product are to be weighed with different packagings.

List of adjustable parameters

The following parameters may be modified by program:

Adjustable parameters	Corresponding data
F1 filter coefficient	%MWr.m.0.6
"Manual" tare value	%MWr.m.0.7
Cut-off points (thresholds)	%MDr.m.0.8 and %MDr.m.0.10
Logic of S0 and S1 outputs	%MWr.m.0.12
LF mask time	%MWr.m.0.13
Number of measurements used to calculate flow rate	%MWr.m.0.14
F2 filter coefficient	%MWr.m.0.15
F3 filter coefficient	%MWr.m.0.16

Possible Actions

You can:

- modify an adjustment parameter by program,
 - send adjustment parameters to the module,
 - control the module's parameter recognition,
 - read the adjustment parameter value in the module and thereby update the PLC memory,
 - save the adjustment parameters,
 - restore the value of saved parameters to the PLC memory.
-

**Instructions
Used**

The instructions used to do these operations are as follows:

Instruction	Function carried out
WRITE_PARAM (%CH r.m.0)	Send the parameter contents of the previous table to the weighing module.
READ_PARAM (%CH r.m.0)	Reads the adjustment parameters in the module and updates the above table.
SAVE_PARAM (%CH r.m.0)	Saves the adjustment parameter values in the memory zone of the processor. These parameter values will be the ones used when the PLC is started from cold.
RESTORE_PARAM (%CH r.m.0)	Allows the adjustment parameters to be reloaded with the values entered at module configuration or at the last SAVE_PARAM.

The module can process several adjustments simultaneously.

Instructions used for adjustments

General

To be able to carry out adjustment operations, you must be able to access the module's own data.

Access is gained using the following instructions.

Sending adjustment parameters to the module

Parameters are sent from the module channel using the `WRITE_PARAM` instruction, with the following syntax:

```
WRITE_PARAM (%CH r.m.0)
```

This instruction sends the contents of the parameters to the module and waits for its acknowledgement. This may necessitate several task cycles.

Monitoring parameter recognition

As the module can take several task cycles to acknowledge values, two memory words are used to monitor the exchanges: `%MWr.m.0.0` and `%MWr.m.0.1`

- The first word `%MWr.m.0.0` shows that there is an exchange in progress,
 - The second word `%MWr.m.0.1` gives the exchange report,
 - rank 2 bits are associated with the adjustment parameters:
 - the `%MWr.m.0.0.2` bit shows that the adjustment parameters are sent to the module,
 - the `%MWr.m.0.1.2` bit specifies whether the adjustment parameters are accepted by the module.
-

Example

Writing the module's parameters in slot 2 of rack 0,

```
WRITE_PARAM (%CH2.0) involves:
```

- sending the adjustment parameters,
 - setting the `%MW2.0.0.2` bit to 1, showing that the adjustment parameters are being sent. This bit remains at 1 until the module sends a report. The bit then goes back to 0. The exchange report bit is then relevant,
 - the `%MW2.0.1.2` exchange report bit is set at 1 if there is a problem during the exchange. The 0 value shows that the data has been accepted by the module.
-

Reading the adjustment parameters

The `READ_PARAM` instruction is used to read the module's adjustment parameters and to update the PLC's memory. It is particularly useful after a `WRITE_PARAM` that the module has not accepted. Reading the adjustment parameters can take several task cycles.

The adjustment parameters are read from the module's channel using the `READ_PARAM` instruction, with the following syntax:

```
READ_PARAM (%CH r.m.0)
```

Saving the adjustment parameters

The `SAVE_PARAM` Instruction allows you to copy the current values of the module's adjustment parameters in the backup zone defined in the processor memory. The backup zone is not accessible from the language.

This instruction can take several task cycles to be executed. The module's adjustment parameters are saved using the `SAVE_PARAM` instruction, with the following syntax:

```
SAVE_PARAM (%CH r.m.0)
```

Restoring the saved adjustment parameters

The `RESTORE_PARAM` instruction supports restoring of the saved adjustment parameter values in the processor's memory and in the module.

The adjustment parameters are restored from the module using the `RESTORE_PARAM` instruction, with the following syntax:

```
RESTORE_PARAM (%CH r.m.0)
```

Description of parameters adjustable by program

Description

The following table describes the parameters that can be adjusted by program, using the `WRITE_PARAM` instruction.

Word	Role	Description
%MWr.m.0.6 %MWr.m.0.15 %MWr.m.0.16	Filter Coefficients,	The admissible filter coefficient values are between 0 and 19.
%MWr.m.0.7	"Manual" tare value.	The admissible "manual" tare values are between 0 and 65535. They cannot exceed the maximum range.
%MD r.m.0.8 %MD r.m.0.10	Cut-off points (thresholds).	S0 high flow cut-off point. S1 low flow cut-off point. The threshold values allowed lie between 0 and the maximum range in high resolution format.. If a threshold check has not been defined at configuration, no detection processing is done. The value of these threshold is zero by default. Note: <ul style="list-style-type: none"> ● when weighing: $GD < MW < \text{Maximum weight}$, ● in downweighing: $MW < GD < \text{Maximum weight}$ The module carries out a consistency check of the threshold values. If this logic is not respected, the thresholds will be refused.
%MWr.m.0.12	Output logic.	<ul style="list-style-type: none"> ● %MWr.m.0.12.0: <ul style="list-style-type: none"> ● 0: Weighing, ● 1: Downweighing. ● %MWr.m.0.12.1: <ul style="list-style-type: none"> ● 0: S0 then S1, ● 1: S0 then S1 then S1.
%MWr.m.0.13	PD mask time.	The admissible values are between 0 and 15 per 1/10 second step (0 = 0 s, 1 = 0.1 s, 2 = 0.2 s, ...).
%MWr.m.0.14	Number of measurements for flow.	Admissible values are values 2, 4, 8, 16, 32 or 64.

Reading configuration parameters.

General

The set of parameters entered during the configuration of the module is accessible by program in read only.

These parameters are coded in 3 words of the %KW constant area.

Coding of the maximum weight


The maximum weight reading, configured for the measuring channel, may be accessed with the word %KWr.m.0.0.

Coding the measurement unit

Reading the unit and the scale division, configured for the measuring channel, is accessible with the word %KWr.m.0.1.

The measurement unit is coded on 3 bits of the least significant byte.

%KWr.m.0.1: Least significant byte



The table below describes the coding of the measurement unit.

Bits 0 to 2	Corresponding unit	Role
0	g	gram
1	kg	kilogram
2	t	tonne (metric)
3	lb	pound (=453g)
4	oz	once (=28.35g)
5	<none>	no unit


Scale division coding

The reading of the unit and the scale division configured for the measuring channel, is accessible with the word %KW_r.m.0.1.

Note: The scale division is always defined in the same unit as that of the measurement.

The measurement unit is coded on 5 bits of the most significant byte.

%KW_r.m.0.1 of the most significant byte



The following table describes the coding of the scale division.

Bits 8 to 12	Scale division value	Bits 8 to 12	Scale division value
0	0.001	11	5
1	0.002	12	10
2	0.005	13	20
3	0.01	14	50
4	0.02	15	100
5	0.05	16	200
6	0.1	17	500
7	0.2	18	1000
8	0.5	19	2000
9	1	20	5000
10	2		

Coding of the stability, of zero, thresholds, outputs and format

The reading of the extent of range and the stability time and the extent of range from zero and the activity of zero tracking, of the overload threshold, the utilization of the outputs and the format of the weight values, configured for the channel measurement are accessible with the memory word %KWr.m.0.2.

Coding of the word %KWr.m.0.2.

%KWr.m.0.2 : Least significant byte

bit 7	bit 6	bit 5	bit 4	bit 3	bit 2	bit 1	bit 0
Stability time				Extent of stability			

%KWr.m.0.2 of the most significant byte

bit 15	bit 14	bit 13	bit 12	bit 11	bit 10	bit 9	bit 8
Format	Outputs	Zero Tracking	Manual tare.	Extent. Zero	Supply sensor	Overload	

The following table describes the coding of the extent of stability (bits 0 to 2).

Value read	Equivalence in 1/4 of the scale division
0	2
1	3
2	4
3	6
4	8

The following table describes the coding of the stability time (bits 4 to 5).

Value read	Equivalence in seconds
0	0.4
1	0.5
2	0.7
3	1

The following table describes the coding of the overload (bits 8 to 9).

Value read	Type of overload selected
0	Maximum weight + 9 scale divisions
1	Maximum weight + 2% of the maximum weight
2	Maximum weight +5% of the maximum weight

The following table describes the coding of the other parameters. These parameters are each coded on one bit of the word %KWr.m.0.2.

Bit no.	Parameter	bit at 0	bit at 1
11	Recalibration range	+/-2% of the maximum weight	+/-5% of the maximum weight
12	Tare predefined	No predetermined tare	Tare predefined
13	Activity of the zero tracker	Inactive	Active
14	Utilization of the outputs	Not used	Used
15	Format	Legal (physical unit with fixed point)	High resolution (hundredth of a fixed point physical unit)

Debugging the weighing function

9

At a glance

Subject of this chapter

This chapter introduces the debugging screen and describes the functions available for debugging the application.

What's in this Chapter?

This chapter contains the following topics:

Topic	Page
Introduction to the debug function of the weighing module	118
Description of the weighing application function debug screen	119
Description of the module zone of the debug screen	121
Description of the display zone of the debugging screen	122
Description of the parameter setting zone	123

Introduction to the debug function of the weighing module

Introduction

The Debug function makes it possible for the weighing module of the application to display the parameters of each of its channels (channel status etc.), to access the diagnostic and the adjustment of the selected channel.

The function also gives access to the module diagnostics in the case of a fault.

Note: This function is only accessible in online mode.


Description of the weighing application function debug screen

At a glance

The debug screen (See Unity Pro, Operating Modes Manual, Access to the module configuration editor) can be used to display weighing information and adjust certain parameters.

Illustration

This screen can be only accessed in online mode.



Description The following table shows the various parts of the debug screen and their functions.

Address	Element	Function
1	Tab	The tab in the foreground indicates the current mode (Debug for this example). Each mode may be selected by the corresponding tab.
2	Module zone	Shows the abbreviated name of the module. In online mode, this zone also contains the three LEDs Run , Err and IO .
3	Channel field	Is used: <ul style="list-style-type: none"> ● By clicking on the reference number, to display the tabs: <ul style="list-style-type: none"> ● Description which gives the characteristics of the device. ● I/O Objects (See Unity Pro, Operating Modes Manual, I/O Objects Tab for a Module) which is used to presymbolize the input/output objects. ● Fault which shows the device faults (in online mode). ● To select the channel, ● To display the Symbol, name of the channel defined by the user (using the variable editor).
4	General parameters zone	Comprises: <ul style="list-style-type: none"> ● the dropdown Function menu, ● the dropdown Task menu defining the task (MAST or FAST) in which the implicit exchange objects of the channels will be exchanged. ● the Adjustments check box: allows you to access the adjustment functions. When this box is ticked, an extra zone is added to the debug screen giving access to the parameters.
5	Display and adjustment zones	Display weighing information and adjust certain module parameters.

Description of the module zone of the debug screen

At a glance

This zone displays general information on the module status.



Illustration

This zone on the screen informs you about the state of the module.



Description


The following table describes the different elements of the module screen zone and channel state.

Address	Description
 or 	Indicates whether the module is closed (locked padlock) or not.
Run	Indicator lit: normal operation Indicator unlit: module error or switched off
Err	Indicator lit: internal error, module broken down Indicator blinking: communication error, absent, invalid or faulty application Indicator unlit: no error
I/O	Indicator lit: External error: <ul style="list-style-type: none"> • overload or underload fault during calibration, • range overshoot error, • measurement error • Closed module: configuration refused Indicator blinking: loss of communication with the processor Indicator unlit: no error

Description of the display zone of the debugging screen



Illustration

This zone is the dynamic display zone containing important information connected to weighing.



Description

The following table describes the different elements belonging to the weighing debugging screen's display zone.

Zone	Field	Description
Weight	No. Converter Points	By default, the screen displays the current weight value. Clicking the No. Converter Points button will allow you to switch to points mode during the next disconnection of the PLC. The display weight will be reapplied when the PLC next runs.
	Value	The current weight value in a defined unit. If there is a fault on the measurement circuit detected by the module or when it is in calibration mode, the ERR note is displayed on the screen.
	NET	The net weight indicator is positioned if the module returns NET weight information, otherwise this relates to gross weight.
		The "stable measurement" flag specifies that the measurement is in the defined stability range.
		The zero zone indicator is activated when the measured weight is in zero format (+/- 1/4 of the scale indicator).
Outputs		The supplied indications correspond to the physical state of outputs S0 and S1.
Measurement Information		This zone displays: <ul style="list-style-type: none"> the flow value, it is indicated by the unit measurement, the current tare value, the memory zero value corresponding to zero shift from the last calibration, the PT indicator specifies the tare value which has been manually introduced and not measured, the Zero Tracking indicator shows that the function has been parameterized.

Description of the parameter setting zone

Illustration

This zone allows you to modify the adjustment parameters.

The screenshot displays a software interface for parameter setting, divided into several sections:

- Threshold Check:** Contains 'Activate' and 'Deactivate' buttons, 'LF Mask Time: 0 s', 'Direction: Weighing (selected) / Downweighing', and 'Outputs Active Phase 1: S0 (selected) / S0 and S1'.
- Flow:** 'Calculate on 4 measurements'.
- Tare:** 'Predefined Value: 0.1 Kg'.
- Cut-off points:** 'Low Flow (LF) 0.0000 Kg' and 'High Flow (HF) 0.0000 Kg'.
- Filtering:** 'F1: 4', a graph showing a curve with points LF, HF, F1, F2, and F3, and 'F2: 0', 'F3: 0'.

Description

It gives access to the modification and display of the following parameters:

Address	Description
Filtering (See <i>How to modify measurement input Filter(s)</i> , p. 62)	You have the possibility to modify for each phase the filter coefficient value of the measurement input. You can choose a value from 0 to 19. Note: The stronger the filter (value from 1 to 11), the longer the response time.
Flow (See <i>How to modify the flow calculation</i> , p. 64)	You have the possibility to modify the number of measurements for the flow calculation. The listed choices carry the values 2, 4, 8 16, 32 and 64.
Tare (See <i>How to modify the tare</i> , p. 65)	You have the possibility to introduce a predetermined tare by checking the corresponding box and filling in this tare value in the defined unit.
Threshold Check (See <i>How to modify the threshold check</i> , p. 66)	
The following parameters are displayed only if the Threshold monitoring option has been activated during configuration. Recognition of all parameters is effected from the confirmation command in the Edit menu.	
Activate	This key activates the threshold check monitoring cycle.
Deactivate	This key deactivates the threshold check monitoring cycle and positions outputs S0 and S1 into fallback mode.
LF mask time	Lets the user modify the mask time during switch to low flow.
Weighing/ Downweighing direction	Lets you modify the threshold recognition.
Phase 1 active outputs	Lets you choose the active outputs during the first dosage phase.
Low flow (PD) and high flow (GD) cut off points	Lets you modify the threshold values.

Calibrating the measurement string

10

At a glance

Subject of this chapter

This chapter describes how to calibrate the measurement string.

What's in this Chapter?

This chapter contains the following topics:

Topic	Page
Introduction to the Calibration Function	126
Description of the calibration screen	128
Calibrating the Analog Measurement System	130
Calibrating the Analog Measurement System by Program	132
How to achieve a forced calibration	134
Performing a Forced Calibration by Program	135
How to achieve a software calibration	136

Introduction to the Calibration Function

General

The calibration of the analog measurement system consists in making a weight value correspond to an electrical signal transmitted by sensors.

This adaptation is made on site when the product is set up. It is necessary to ensure the measurement's validity.

Note: The calibration function, forced or not, is only accessible in offline mode with the PLC in Run mode.

Calibration rules

Any non-calibrated module is in channel fault (can be seen in the debug screen or on the module, by the flashing of channel 0).

The first calibration must be complete:

1. Zero Load
2. Standard Load
3. Save

otherwise the information returned means nothing.

It is not possible to carry out a calibration if the PLC processor is fitted with A Flash-Eprom memory card (**TSX MFP P 128K** or **TSX MFP P 224K** or **TSX MFP P 384K**).

Calibration can be redone throughout the module's life. The electronics characteristics do not require regular recalibration. However, legal constraints or the application's mechanical characteristics may require calibration, particularly for commercial transactions.

Note: Calibration is independent of the configured filter, but acknowledges Metrological and Stability Information parameters.


Calibration Type You can choose one of the following 4 calibration types:

- normal calibration (The calibration function must be performed with a standard load calibration that is greater than or equal to 70% of the maximum weight),
 - graded calibration (if for various reasons calibration cannot be performed under the conditions previously described),
 - forced calibration :
 - CPU -> Module: being able to restore adjustments made to a different module in the event of a maintenance concern or duplication
 - Module -> CPU: being able to make the processor parameters conform with the parameters of a calibrated module that is connected to a new slot.
 - The software calibration requires:
 - the version of the weighing module is ≥ 2.1 ,
 - not to use the standard load,
 - to modify the module configuration.
-

Description of the calibration screen

At a glance The adjustment screen provides access to the calibration commands.

Illustration This screen can be only accessed in online mode.



**General
Description**

The following table shows the different elements of the calibration screen and their functions.

Address	Element	Function
1	Tab	The front tab indicates the current mode (Calibration in this example). Each mode may be selected by the corresponding tab.
2	Module zone	Shows the abbreviated name of the module. In online mode, this zone also contains the three LEDs Run , Err and IO .
3	Channel field	Is used: <ul style="list-style-type: none"> ● by clicking on the module reference, to display the Description tab, which contains the technical specifications and the Fault tab, which contains the module's faults, ● to select the channels you wish to configure.
4	General parameters zone	Comprises: <ul style="list-style-type: none"> ● the dropdown Function menu, ● the dropdown Task menu defining the task (MAST or FAST) in which the implicit exchange objects of the channels will be exchanged.
5	Display and calibration zones	Display weighing information (See <i>Description of the display zone of the debugging screen, p. 122</i>) and the calibration commands (See <i>Calibrating the Analog Measurement System, p. 130</i>).

Calibrating the Analog Measurement System

At a glance

Calibration can be carried out on a Unity Pro station connected to the PLC using the calibration screen.

It can also be done using an operator dialog, which uses Unity Pro language instructions.

Note: The procedure can be stopped at any time by pressing **Cancel**. The module reverts to the previous parameters. The current calibration parameters are therefore lost.

The procedure is only enabled if the module has been calibrated correctly.

If there is a measurement saturation problem, the new parameters cannot be saved. Either the error must be corrected or the procedure be cancelled, using **Cancel**.

Procedure This table describes the procedure for calibrating the analog measurement system.

Step	Action	Result
1	Switch the rack on.	The product is initialized, carries out self-tests and receives its configuration.
2	Access the calibration screen: <ol style="list-style-type: none"> 1. select Configuration in the project browser. 2. click on the module's slot 3. select the Calibration tab. <p>Note: The processor must be in RUN and the terminal in online mode.</p>	-
3	Check that the counter output is empty.	-
4	Click the Zero Load button to carry out zero load calibration (recognized by the load receiver).	This phase requires around 20 seconds. The Zero Load button switches to reverse image during this phase and an hour glass appears. The module switches to channel fault and all measurements are invalid. The status of the flag %lwr.m.0.4.6 Calibration_in_progress changes. The module indicates the acquisition of the zero weight reference and processes the reports.
5	Place calibration weight.	-
6	Enter the calibration weight value in the "Standard Load" field (this value is equal to the maximum weight) and click on the Standard Load button. If the command is disabled, an error message indicates the type of problem encountered.	This phase requires around 20 seconds. The module checks the standard load weight against the maximum weight. The status of the flag %lwr.m.0.4.6 Calibration_in_progress changes. The module acquires the standard load weight reference, processes and positions the report.
7	Click the Save button to recognize the parameters resulting from calibration.	The module and the processor recognize and save the parameters resulting from calibration. During the write phase, the measurement remains in channel fault. This fault disappears as soon as writing is finished (current channels faults and calibration in progress disappear). The measurement is valid.

Calibrating the Analog Measurement System by Program

General

Several language elements are used to implement and supervise the calibration mechanism.

The calibration screen facilitates the procedure, but it can also be performed by program using reserved data.

Procedure

Program the following operations to perform a calibration by program.

Step	Action	Result	
1	Zero weight	Enter <code>WRITE_CMD</code> while setting the calibration order of the channel using the zero weight (<code>%MWr.m.0.3.1=1</code>).	The status of the <code>%IWr.m.0.4.6</code> Calibration in progress indicator changes. This operation enables you to determine the Offset parameter.
2	Standard Load	Load the standard load weight value in the <code>%MDr.m.0.4</code> word	-
3		Enter <code>WRITE_CMD</code> while setting the calibration order of the channel using the standard load weight (<code>%MWr.m.0.3.2=1</code> , or <code>%MWr.m.0.3.12=1</code> for a graded calibration).	The <code>%IWr.m.0.4.6</code> Calibration in progress indicator changes status. This operation is used to determine the Gain parameter.
4	Save the parameters in the module	Enter <code>WRITE_CMD</code> while setting the save order of the calibration in the module (<code>%MWr.m.0.3.0=1</code>).	-
5	Copy the module parameters in the CPU	Enter <code>WRITE_CMD</code> while setting the save order of the calibration in the processor (<code>%MWr.m.0.3.11=1</code>).	-

Summary of the data used

The table below shows the data involved in a calibration.

Type	Role	Associated data
Command type	Save calibration in the module	%MWr.m.0.3.0
	Zero weight	%MWr.m.0.3.1
	Standard load weight (Normal)	%MWr.m.0.3.2
	Forced calibration (CPU -> Module)	%MWr.m.0.3.10
	Save calibration in the processor	%MWr.m.0.3.11
	Standard load weight (Graded)	%MWr.m.0.3.12
Command parameter	Value of standard load weight	%MDr.m.0.4
Report	Calibration in progress (Normal)	%IWr.m.0.4.6
	Instability	%IWr.m.0.4.9
	Overload or underload during calibration	%%MWr.m.0.2.0
	Non-calibrated module	%MWr.m.0.2.9
	Calibration mode	%MWr.m.0.2.14
	Forced calibration mode	%MWr.m.0.2.15

How to achieve a forced calibration

At a glance

This function responds to the needs of speedy maintenance.

Forced calibration allows calibration values from a weighing module to be transferred to the central unit, and vice versa.

Note: This action cannot be reversed. Once the transfer has occurred, it is not possible to cancel the command.

Note: This function is only accessible in online mode, with the PLC in Run.

Operating Mode

Transferring the CPU to the weighing module is always authorized once the CPU has the requisite calibration parameters for the desired slot.

Transferring the weighing module to the central unit requires the module to be calibrated (not forced calibration).

Procedure

This table describes the procedure for achieving forced calibration.

Step	Action
1	Switch the rack on.
2	Access the calibration screen: <ol style="list-style-type: none"> 1. Select Configuration 2. Click on the module's slot 3. Select the Calibration tab.
3	In the Forced Calibration field, click either CPU -->Module or Module -->CPU , according to the desired transfer direction.

Note: The procedure is not enabled unless the transfer is performed correctly. If there is a problem, click the **Cancel** button in the **Forced Calibration** field.

Performing a Forced Calibration by Program

General

Several language elements are used to implement and supervise the calibration mechanism.

The calibration screen facilitates the procedure, but it can also be performed by program using reserved data.

Procedure

Carry out the following operations to perform a forced calibration by program.

Direction of copy	Action	Result
CPU -> Module	Enter <code>WRITE_CMD</code> while positioning the save order of the calibration in the module (<code>%MWr.m.0.3.10=1</code>).	This operation is used for example when replacing a module. It enables you to automatically restore the calibration parameters in the module (gain, offset and converter configuration).
Module -> CPU	Enter <code>WRITE_CMD</code> while positioning the save order of the calibration in the processor (<code>%MWr.m.0.3.11=1</code>).	This operation enables you to automatically restore the calibration parameters in the processor when, for example, you are using a module that is placed in a new slot. This operation is only possible if the module is calibrated.

How to achieve a software calibration

At a glance

Calibration can be carried out on a Unity Pro station connected to the PLC using the calibration screen.

Note: Software calibration cannot be used for regulated weighing applications.

Procedure This table describes the procedure for calibrating the analog measurement system.

Step	Action	Result
1	Switch the rack on.	The product is initialized, carries out self-tests and receives its configuration.
2	<p>Access the calibration screen:</p> <ol style="list-style-type: none"> 1. click on the module's slot, 2. select the Configuration tab: <ul style="list-style-type: none"> • Set the Maximum Range (MR) to a value higher than the sum of the sensors' weight ratings, • Set the Low Flow (LF) to a value equal to the average of the sensors' sensitivities, • If needed, set the Scale Division (e) to less than 1. 3. validate, 4. select the Calibration tab. <p>Note: The processor must be in RUN and the terminal in online mode.</p>	-
3	Check that the counter output is empty.	-
4	Press the Zero Load button.	<p>The Zero Load button switches to reverse image during this phase.</p> <p>The module switches to channel fault and all measurements are invalid.</p> <p>The status of the flag %lwr.m.0.4.6 Calibration_in_progress changes.</p> <p>The module acquires the standard load weight reference, processes and positions the report.</p>
5	<p>In the Standard Load field, enter the value PN.xx where PN corresponds to the sensors' weight ratings and xx differs by 0.</p> <p>If the command is disabled, an error message indicates the type of problem encountered</p>	<p>The status of the flag %lwr.m.0.4.6 Calibration_in_progress changes.</p> <p>The module calculates the theoretical calibration coefficients.</p>
6	Click the Save button to recognize the parameters resulting from calibration.	<p>The module and the processor recognize and save the parameters resulting from calibration.</p> <p>During the write phase, the measurement remains in channel fault. This fault disappears as soon as writing is finished (current channels faults and calibration in progress disappear). The measurement is valid.</p>
7	Select Configuration tab, reset (MR), (LF) and (e) to their initial configuration values and validate .	

Protecting the adjustments

11

At a glance

Subject of this chapter

This chapter describes how to protect the adjustments done during the previous phases.

What's in this Chapter?

This chapter contains the following topics:

Topic	Page
Protection of the weighing parameter settings	140
How to protect the adjustments	142
Legal metrology and regulations	143

Protection of the weighing parameter settings

General

Any weighing instrument which can be used for commercial transactions must be approved. The parameters associated with the measurement must therefore be protected. It should not be possible to introduce into an instrument, via the interface, instructions or data likely to:

- falsify the weighing results displayed,
- change an adjustment factor.

Note: protection by sealing aims to guarantee measurement conformity, so that the parameters accessible only apply to the exploitation aspects of the module information by the mechanism.

Effect of Protecting the Configuration Parameters

There are two types of information. Information, which can be protected (if a module is sealed, this type of information will be available in read only) and information with free access (Read and Write)

The table below identifies the characteristics of this information according to the protection put in place.

Functions	Without sealing	With sealing
Task	Modifiable	Modifiable
Flow/ Calculation on n measurements	Modifiable	Modifiable
Tare/ Predefined	Modifiable	Modifiable
Threshold checking/ Active	Modifiable	Modifiable
Threshold checking/ Direction	Modifiable	Modifiable
Threshold checking/ Active outputs	Modifiable	Modifiable
Threshold Checking/ Cut-off points	Modifiable	Modifiable
Threshold checking/ LV Mask Time	Modifiable	Modifiable
Unit	Modifiable	Non modifiable
Max Range (MR)	Modifiable	Non modifiable
Scale Division	Modifiable	Non modifiable
Overload Threshold	Modifiable	Non modifiable
Filtering/ Coefficient	Modifiable	Modifiable
Data format	Modifiable	Non modifiable
Stability/Extent of Range	Modifiable	Non modifiable
Stability/Time	Modifiable	Non modifiable
Zero/Zero tracking	Modifiable	Non modifiable
Zero/Recalibration range	Modifiable	Non modifiable

The information word %lwr.m.0.4.4 (to 1) tells you if the measurement is protected.

Consequences of Protection

- A sealed module that receives a different configuration to the one memorized (before being switched off prior to the movement of the rider) is refused.
- In this case the module is seen as missing in the PLC diagnostics, but sends a weight to the display.
- A sealed module will not accept a new calibration request

Note: using the file allows you to keep a paper record of the configuration


How to protect the adjustments

Necessary conditions

The calibration and adjustment operations must be completed.

Illustration

The following illustration shows how to position the riders in order to protect the adjustments.



Procedure

The following table describes the operation of protecting the adjustments (leading).

Step	Action
1	Take the module out of the PLC rack (the rack can remain switched on).
2	Remove the module's casing (use a TORX type screwdriver for this).
3	Place the rider in position 2-3 as shown in the illustration.
4	Put the module back into its casing.
5	Replace the module in the rack in its previous position.

Legal metrology and regulations

EU approval

The set consisting of: load holder + sensors + module can be considered as an IPFNA (non automatic weighing instrument).

As such, and to be able to use it for commercial transitions, it has been approved by the EU.

If it is only used for internal processes, the display must have an identification plate mentioning:

Trademark	Max =
Type of instrument	e =
Serial number	
'All transitions prohibited'	

If it is used for regulated uses (e.g. commercial transitions), the display must have a identification plate, showing:

Trademark	Max =
Type of instrument	Min =
Serial Number	e=
Number and date of EU approval of type	Number 97.00.620.016.0
	29th September 1997

Moreover, it must receive a first check on leaving the factory, as well as regular on-site monitoring by a licensed body. Generally, monitoring takes place once a year, and this is the responsibility of the owner.

Approval of the model

Measurement and control device for filling machine and a discontinuous counter

This IPFNA can be supplemented by the specific software applications 'Filling Machine' or 'Discontinuous counter'. As such, it has passed national approvals, as a measurement and automatic control device for filling machines and discontinuous counters.

It is therefore up to the manufacturer of the measurer or discontinuous counter to get a complete approval of any automatic weighing instruments made up in this way, in the most straightforward conditions possible.

It is also up to the manufacturer of the machine to install the identification plate and to present the machine for its first check, when necessary.

Approval of a continuous counter model

Associated with a weighing table, it is authorized as a continuous counter device.

Except for when used for commercial transitions, the identification plate shows:

- Mark	QMax =
- Type	dt =
- Serial number	
'All transitions prohibited'	

When used for commercial transitions, the identification plate shows:

- Mark	QMax =
- Type	dt =
- Serial number	
Weighed products:	
- Max=	L =
- v=	d =

It must be checked. The first phase of the first check is done in the factory on the complete instrument uncoupled from its conveyor, by means of a movement simulator; the other phases are carried out on the complete instrument.

Class of appliance

With average precision, the appliance covers the range from the minimum (500 scale divisions) up to 6000 scale divisions. These instruments can be authorized or unauthorized to carry out commercial transitions. If it is unauthorized, 'PROHIBITED FOR ALL TRANSACTIONS' must be written on the appliance's front panel.

Operating a weighing application

12

At a glance

Subject of this chapter

This chapter describes the tools that allow you to operate a weighing application.

What's in this Chapter?

This chapter contains the following topics:

Topic	Page
Ways of displaying weighing information	146
Description of the display report	147
Weighing module operating modes	150

Ways of displaying weighing information

Description

The following table describes the different ways of displaying weighing information.

Ways	Description
Module display panel TSX XBT N410 (See <i>Description of the display report, p. 147</i>)	Automatically displays the weight measurement without any prior programming.
Debugging screen (See <i>Description of the display zone of the debugging screen, p. 122</i>)	Displays all information relevant to the weighing and allows the modification of certain parameters.
Animation tables	All information about the measurement can be accessed as PLC variables and can be displayed in the animation tables.
Operation screen	It is possible to create runtime screens using the weighing language objects in order to display the information required to run the application.
Supervision	The weighing language objects can be conveyed and operated by a supervision system.

Language Objects

The following language objects are used for operating the weighing application.

Displayed data	Object address
Protected module	%MWr.m.0.2.8 (Explicit Exchange Object)
Non-calibrated module	%MWr.m.0.2.9 (Explicit Exchange Object)
Weight value	%IDr.m.0.0
Net weight flag	%IWr.m.0.4.8
Stability flag	%IWr.m.0.4.9
Zero indicator	%IWr.m.0.4.10
Discrete S0 output status	%IWr.m.0.4.0
Discrete S1 output status	%IWr.m.0.4.1
Flow	%IDr.m.0.2
Tare value	%IDr.m.0.5
Recalibration memory	%IDr.m.0.7
Zero indicator follower	%IWr.m.0.4.11
Predetermined tare flag	%IWr.m.0.4.12

Description of the display report


General

The **TSX XBT N410** display module provides measurement indications (see **TSX XBT N410** installation documentation).

This display appears automatically without prior programming.

Illustration

The following illustration shows **TSX XBT N410** display.



Note: On the **TSX XBT N410**, space is left available for the punched identification plate to meet metrological legal requirements.

Description of the display

All valid measurements are transmitted to the display in physical units with a fixed number of decimal places, every 100 ms.

The following table describes the indications that may appear on the display in normal operation.

Address	Indication	Description
1	=	The measurement is stable.
	none	The measurement is not stable (the stability criteria are defined in the configuration).
2	Net	The measurement indicates a Net weight.
	none	The measurement indicates a gross weight.
3	+	The measurement is positive.
	0	The measurement is approximately 0 (between -1/4 et +1/4 scale division).
	-	The measurement is negative: <ul style="list-style-type: none"> ● if the associated numerical value blinks: the measurement is between -9 scale divisions and -1/4 scale division, ● if no associated numerical value is displayed: the measurement is below -9 scale divisions.
4	141.25	Numerical value of the weight.
5	kg	Symbol of measurement mass unit: g for gram, kg for kilogram, lb for pound, oz for ounces and t for metric tonne.

Note: The serial link test is carried out when the weighing module is powered up. For this the **TSX XBT N410** display module must be connected to the **TSX ISP Y101** when the PLC is powered up.

Error messages


The following table describes the error indications which may appear on the display.

Indication	Description
-----	The measurement is not valid, a channel fault is detected.
>>>>	An overload is detected.
<<<<	An underload is detected.
Time out	The display no longer receives data from the weighing module.
Checksum error	A problem was detected during the power-up. At power-up, the TSX XBT N410 performs a test on its resources. In operation, all the information received is checked. In the event of a problem, the <i>Checksum error</i> is displayed.

Weighing module operating modes

Operation

The following illustration describes the operation of the module.



Behavior on encountering an error

During power-up, the module carries out its own self-tests (REPROM , RAM, Link display, etc.).

If an error is detected at the end of these tests, the module switches to fall back mode, the outputs are at 0.

Similarly, if, when operating normally, an internal malfunction (error in RAM, CDG, etc.) is detected in the module, the outputs are positioned to 0 and the display shows dashes on the screen (----).

Behavior on power outage

On power outage the machine parameters are saved (Tare mode, Zero offset, etc.) whereas the operating parameters are lost (Thresholds, number of measurements used to calculate flow rate, etc.).

Diagnostics of the weighing application

13

At a glance

Subject of this chapter

This chapter allows you to diagnose the errors detected in the weighing application.

What's in this Chapter?

This chapter contains the following topics:

Topic	Page
How to access the Diagnostics function of the weighing module	152
How to access the channel Diagnostics function of the weighing module	153

How to access the Diagnostics function of the weighing module

At a glance

The Module diagnostics function displays errors when they occur, classified according to category:


- internal errors (module breakdown, running self-test),
- external errors (terminal block fault),
- other errors (configuration error, module missing or switched off, faulty channel(s) (details in channel diagnostics)).

A module error is indicated by certain LEDs changing to red, such as:

- in the rack-level configuration editor:
 - the module position LED,
- in the module-level configuration editor:
 - the **Err** and **I/O** LEDs, depending on the type of error,
 - the **Fault** tab LED.

Procedure

The table below shows the procedure for accessing the Module diagnostics screen.

Step	Action
1	Access the module configuration screen.
2	<p>Click on the module reference in the channel zone and select the Fault tab. Result: The list of module errors appears.</p>  <p>Note: It is not possible to access the module diagnostics screen if a configuration error, major breakdown error or module missing error occurs. The following message appears on the screen: The module is missing or different from that configured for this position.</p>

How to access the channel Diagnostics function of the weighing module

At a glance


The Channel diagnostics function displays errors when they occur, classified according to category:

- internal errors (breakdown of channel),
- external errors (link or sensor link power supply error),
- other errors (terminal block error, configuration error, communication error).

A faulty channel is indicated when the **Fault LED**, situated on the **Fault** tab of the configuration editor, switches to red.

Procedure

The table below shows the procedure for accessing the Channel diagnostics screen.

Step	Action
1	Access the weighing module configuration screen.
2	<p>Select the Fault tab.</p> <p>Result: The list of channel faults appears.</p>  <p>Note: Access to the channel diagnostics information is also possible by program (instruction READ_STS).</p>

Examples of the weighing program

14

At a glance

Subject of this chapter

This chapter provides programming examples for a weighing application.

What's in this Chapter?

This chapter contains the following topics:

Topic	Page
Example of a tare mode	156
Example of metering flow	157

Example of a tare mode

Description of the example

This example emphasizes the running of a weighing process by focusing on the essential operations to be carried out: it deals with carrying out a switch into NET weight (tare mode).

Program

The %M101 bit is used for this action. Its positioning causes the gross weight, which is currently measured as the weighed tare, to be acknowledged, then it causes the display to be switched to NET mode.


The WEIGHT_1 variable of type WEIGHING_ISPY101 is associated with channel 0 of the weighing module situated in rack 6.

```
(* Closed weighing module, slot 6 *)
! (* waiting for tare mode conditions *)
IF %M100 THEN
  IF NOT WEIGHT_1.STS_ERR AND NOT WEIGHT_1.CMD_ERR
  THEN
    SET (%M101);
    RESET (%M100);
  ELSE
    RETURN;
  END_IF;
END_IF;
! (* Tare mode *)
IF %M101 THEN
  (* send tare mode order *)
  IF NOT WEIGHT_1.STS_ERR AND NOT WEIGHT_1.CMD_ERR AND NOT %M102
THEN
  WEIGHT_1.MOD_CAL_SAVE_CMD:=0;
  SET (TARE_CMD);
  WRITE_CMD (WEIGHT_1);
  SET %M102;
END_IF;
  (* tare mode ended and OK *)
  IF NOT WEIGHT_1.STS_ERR AND NOT WEIGHT_1.CMD_ERR THEN
  WEIGHT_1.MOD_CAL_SAVE_CMD:=0;
  RESET (%M101);
  RESET (%M102);
  SET (%M103);
  ELSE
  (* tare mode refused => error *)
  IF NOT WEIGHT_1.STS_ERR AND WEIGHT_1.CMD_ERR THEN
  SET (%M200);
  WEIGHT_1.MOD_CAL_SAVE_CMD:=0;
  RESET (%M101);
  RESET (%M102);
  RESET (WEIGHT_1.CMD_ERR);
  SET %M100;
  END_IF;
END_IF;
END_IF;
```

Example of metering flow

Description of the example

The following example uses a weighing module in slot 2 of the PLC. It describes a metering flow cut up in stages as on the diagram below.



Program

The program is processed in structured text. The WEIGHT_1 variable of type WEIGHING_ISPY101 is associated with channel 0 of the weighing module situated in rack 6.

Main Program

```
(* //////////// Send thresholds //////////// *)
L100:
  IF NOT %M99 THEN
    JUMP L120;
  END_IF;

(*Loading and sending thresholds *)
  IF RE (%M99) THEN
    WEIGHT_1.HF_CUT:=%MD230; (* S0 High Flow cut-off point*)
    WEIGHT_1.LF_CUT:=%MD232; (* S1 Low Flow cut-off point*)
    WRITE_PARAM (WEIGHT_1);JUMP L120;
  END_IF;

(*Transmission in progress*)
  IF WEIGHT_1.ADJ_IN_PROGR THEN
    JUMP L120;
  END_IF;

(*command accepted*)
  IF NOT WEIGHT_1.ADJ_ERR THEN
    RESET (%M99);
  END_IF;

(*FIN INIT CYCLE*)
  L120:

(* //////////// TARE MODE PHASE      (%MW100 =4) //////////// *)

L260:
  IF %MW100<>4 THEN
    JUMP L300;
  END_IF;

(*Tare mode request *)
  IF %M72 THEN
    RESET (%M72);
    %MW270:2:=4;
  END_IF;

(*Management of commands *)
SR8; (* %MW270 informs you of the type of tare mode command 4 *)

(*Waiting for tare mode return*)
  IF %MW270=-1 AND %MW271=-1 THEN
    %MW100:=5;
    SET (%M72);
    JUMP L800;
  END_IF;
```

Program (continued)

```

(* ////////////////////////////////// DOSAGE PHASE (%MW100 = 5) ////////////////////////////////// *)
L300:
    IF %MW100<>5 THEN
        JUMP L340;
    END_IF;

    (*Enable thresholds *)
    IF %M72 THEN
        RESET (%M72);
        %MW270:2:=8;
    END_IF;

    (*Management of commands *)
    SR8();(* %MW270 = type of threshold enable command 8 *)

    (*Waiting for command mode return*)
    IF %MW270>=0 OR %MW271>=0 THEN
        JUMP L800;
    END_IF;

    (*Checking outputs to skip one after the other*)
    IF NOT WEIGHT_1.Q0_OUT AND NOT WEIGHT_1.Q1_OUT THEN
        %MW100:=6;
        SET (%M72);
        JUMP L800;
    END_IF;

    (*PHASE 6 continued *)
L340:
    IF %MW100<>6 THEN
        JUMP L380;
    END_IF;

L800:
SUBROUTINE SR8 :


    (* Send request for the module*)
    IF %MW270>=0 THEN (* %MW270 informs you of the order to carry out
*)
        %M0:16:=0;
        SET (%M0[%MW270]);
        WEIGHT_1.MOD_CAL_SAVE_CMD:=%M0:16;
        %MW271:=%MW270;
        %MW270:=-1;
        WRITE_CMD (WEIGHT_1);
        RETURN;
    END_IF;

    (*Command in progress? *)
    IF WEIGHT_1.CMD_IN_PROGR OR WEIGHT_1.IN_PROGR THEN
        RETURN;
    END_IF;

    (*command accepted? *)
    IF NOT WEIGHT_1.CMD_ERR AND NOT WEIGHT_1.APPLI_FLT THEN
        %MW270:2:=-1;
    ELSE
        %MW270:=%MW271;
    END_IF;

```

Glossary



!

(Weighing Instrument) Indicator Device

Part of load measuring device from which direct reading of result is obtained (TSX XBT N410).

C

Calibration Graduates a piece of measuring apparatus.

Configuration The configuration gathers together the data which characterizes the machine (invariant) and which is necessary for the module to operate. All this information is stored in the constant PLC %KW zone. The PLC application cannot modify them.

CPU Central Processing Unit: generic name used for Schneider Electric processors

D

Debug Debugging is a Unity Pro service which is used to check the module directly when it is online.

Discrete Discrete I/Os

E

Explicit exchanges Exchanges between the CPU and the specific application modules carried out by the Unity Pro program in order to update data specific to the module.

G

Gross Weight Indication of the load weight on an instrument when no tare or predefining device has been used.

I

I/O Inputs/Outputs.

IODDT Input/Output Derived Data Type.

L

Lead Sealing Sealing a piece of apparatus with lead. The positioning of a rider in the weighing module ensures this function.
The objective of this device is to guarantee measurement conformity. The accessible parameters only have influence on the aspects of the mechanism's exploitation of module information. (the unit, weight, scale division, etc, are read only).

Limit Load (Lim) The maximum static load that can be supported by the instrument, without permanently altering its meteorological qualities.

Load Receiver Device Part of instrument that will receive the load.

M

Maximum Weight (Max)	Maximum weighing capacity, not taking account of the additive capacity of the tare.
Metrology	The science of weights and measures.
Minimum Weight (Min)	Load value under which weighing results can be marred by a relative error that is too large.

N

Net Weight (Net)	Weight indication of a load placed on an instrument after a tare device has been used. Net weight = Gross weight - Tare weight
Non-Automatic Functioning Weighing Instruments	Weighing instruments that require the intervention of the operator during the weighing process, in order to deposit loads on the load receiver device and retrieve loads from it, for example, as well as to obtain the result. These instruments allow the weighing result to be directly observed, either displayed or printed out. The two possibilities are covered by the word "indication".

O

Operating Mode	These are all the rules governing the behavior of the module during the transitional phases or on the appearance of a fault.
-----------------------	--

P

Predefined Tare Value (PT)	Numerical value, representing a weight, which is entered into the instrument at configuration or by adjustment or program.
-----------------------------------	--

Premium Families of Schneider Electric hardware products.

S

Scale Division Value in mass units, expressing the difference between two consecutive indications for one numerical indication.

Set to Zero Device Device allowing the indicator to be "recalibrated" in the event of a deviation from zero (due to dirt accumulation, for example). This operation can only be carried out in the extent of zero range (+/-2 % or +/-5 % of the maximum range according to the weighing instrument).

T

Tare Load placed on the load receiver along with the product to be weighed. For example: product packaging or container.

Tare Device Device allowing the instrument indication to be moved to zero when a load is positioned on the load receiver:

- without encroaching on the weighing range of net loads (tare additive device),
- or reducing the weighing range of net loads (tare subtracting device, such as **TSX ISP Y100**).

Tare Predefining Device Device allowing a predefined tare value to be subtracted from a gross weight value and indicating the result of the calculation. The weighing range is consequently reduced.

Tare Value (T) Weight value of a load, determined by a tare weighing device.

Taring Action allowing the instrument indication to be moved to zero when a load is positioned on the load receiver.

U

Unity Pro Programming software of Schneider Electric PLCs.

W**Weighing Instruments**

Measuring instruments, which determine the mass of a body using the force of gravity. These instruments can also be used to determine other sizes, quantities, parameters or characteristics linked to the mass. According to the way they function, weighing instruments are either classified as automatic or non-automatic functioning instruments.

Weighing Range

Interval between maximum and minimum weight.


Z**Zero Load**

Tare weight of load receiver when equipped with its mechanical accessories (vibratory extractor, screw, trap, screw jack, etc.). It does not appear in the weight indication but must be taken into account when calculating the maximum load of the sensors.

Zero Tracking

Device allowing slow derivations from zero to be made up, within the limits of the extent of the zero range.

Index



A

- Addressing
 - Weighing, 73
- Application-specific function
 - Weighing, 45

C

- Calibration
 - Weighing application, 126
- Calibration screen
 - Weighing function, 128
- Channel diagnostics
 - Weighing application, 153
- Channel fault
 - Weighing module, 153
- Channel parameters
 - Weighing application, 54
- Characteristics
 - TSX ISP Y101, 41
- Command objects
 - Weighing, 91
- Configuration
 - Weighing application, 52
- Configuration screen
 - Weighing application, 52
- Connection of discrete outputs
 - Specific-application weighing module, 33

D

- Data format
 - Weighing application, 60
- Debug
 - Weighing application, 118
- Debug screen
 - Weighing application, 119
- Display
 - Weighing application, 147

E

- Ethernet module
 - software installation, 46
- Explicit Exchange Objects
 - Weighing Function, 77
- Explicit exchanges
 - Weighing, 89

F

- Filtering
 - Weighing application, 62
- Flow
 - Weighing application, 64
- Forced calibration
 - Weighing application, 134

I

- Implicit Exchange Objects
 - Weighing Function, 77

- Implicit exchanges
 - Weighing, 86
- Installation
 - Specific-application weighing module, 22
- installation phase
 - implementation, 47
 - overview, 46
 - with processor, 46

L

- Language Objects
 - Implicit Exchange, 78
- Language objects
 - Explicit exchanges, 89, 91, 92
 - Implicit exchanges, 86
 - Management of exchanges, 81
- language objects
 - explicit exchange, 79
- Leading
 - Weighing, 142

M

- Maximum range
 - Weighing application, 57
- Measurement connection
 - Specific-application weighing module, 30
- Measurement stability
 - Weighing application, 61
- Metrological information
 - Weighing application, 57
- Module diagnostics
 - Weighing application, 152
- Module fault
 - Weighing application, 152

O

- Operating mode
 - Weighing, 150
- Operation
 - Weighing application, 48
- Overload threshold
 - Weighing application, 57

P

- Programming
 - Weighing, 71
- Protection of the settings
 - Weighing application, 140

R

- READ_PARAM
 - Weighing, 110
- RESTORE_PARAM
 - Weighing, 110

S

- SAVE_PARAM
 - Weighing, 110
- Scale
 - Weighing application, 57
- Set to zero
 - Weighing, 100
- simulator
 - overview, 46
 - Specific-application weighing module, 14

T

- T_GEN_MOD, 94
- T_WEIGHING_ISPY101, 86, 89, 91, 92
- Tare
 - Weighing application, 65
- Tare mode, 97
- Task
 - Weighing application, 56
- Threshold
 - Weighing, 105
 - Weighing application, 66
- TSX ISP Y101, 39
- TSX XBT N410, 36

W

- Weight unit
 - Weighing application, 57

WRITE_CMD
 Weighing, 96
WRITE_PARAM
 Weighing, 110

Z

Zero
 Weighing application, 59
Zero tracker
 Weighing application, 59

