

Gear Meter System

312744B

ENG

*For continuous bead dispense control. For professional use only.
Not approved for explosive atmospheres.*


- 970175, Bottom Inlet Gear Meter
- 970176, Top Inlet Gear Meter
- 970177, Horizontal Inlet Gear Meter
- 970194, Heated Hose Horizontal Inlet Gear Meter
- 918465, 918473, 918477 Gear Pump
- 617517, Electrical Control

5000 psi (34.47 MPa, 344 bar) Maximum Working Pressure




Important Safety Instructions

Read all warnings and instructions in this manual.
Save these instructions.



ti11243a







ti11239a





Contents

| | | | |
|---------------------------------------|-----------|--------------------------------------|-----------|
| Warnings | 3 | Maintenance | 18 |
| Component Identification | 5 | Troubleshooting | 19 |
| Gear Meter System | 5 | Repair | 20 |
| Electrical Control Unit | 6 | Remove Gear Pump | 20 |
| Gear Meter Junction Box | 7 | Install Gear Pump | 21 |
| Buttons | 8 | Remove Electric Motor | 21 |
| Lights | 8 | Install Electric Motor | 22 |
| Switches | 8 | Remove Brake Clutch | 22 |
| Displays | 8 | Install Brake Clutch | 22 |
| Communications Diagram | 9 | Parts | 23 |
| Setup | 10 | Wiring Schematics | 35 |
| Connections | 10 | Accessories | 44 |
| | 14 | Windshield Nozzles | 44 |
| Set Pressure Display | 15 | Fluid Filters | 44 |
| Potentiometer Settings | 16 | Repair Kits | 44 |
| Adjust Gear Motor Speed | 16 | Gear Pump Repair Kits | 44 |
| Calibrate Flowrate | 16 | Dimensions | 45 |
| Pressure Relief | 16 | Technical Data | 46 |
| Flushing | 16 | Graco Standard Warranty | 48 |
| Operation | 17 | Graco Information | 48 |
| Startup | 17 | | |
| Dispense | 17 | | |
| Shutdown | 17 | | |

Warnings

The following warnings are for the setup, use, grounding, maintenance, and repair of this equipment. The exclamation point symbol alerts you to a general warning and the hazard symbol refers to procedure-specific risk. Refer back to these warnings. Additional, product-specific warnings may be found throughout the body of this manual where applicable.


|  WARNING | |
|--|---|
|  | <p>ELECTRIC SHOCK HAZARD</p> <p>Improper grounding, setup, or usage of the system can cause electric shock.</p> <ul style="list-style-type: none"> • Turn off and disconnect power at main switch before disconnecting any cables and before servicing equipment. • Connect only to grounded power source. • All electrical wiring must be done by a qualified electrician and comply with all local codes and regulations. |
|  | <p>EQUIPMENT MISUSE HAZARD</p> <p>Misuse can cause death or serious injury.</p> <ul style="list-style-type: none"> • Do not operate the unit when fatigued or under the influence of drugs or alcohol. • Do not exceed the maximum working pressure or temperature rating of the lowest rated system component. See Technical Data in all equipment manuals. • Use fluids and solvents that are compatible with equipment wetted parts. See Technical Data in all equipment manuals. Read fluid and solvent manufacturer's warnings. For complete information about your material, request MSDS forms from distributor or retailer. • Check equipment daily. Repair or replace worn or damaged parts immediately with genuine manufacturer's replacement parts only. • Do not alter or modify equipment. • Use equipment only for its intended purpose. Call your distributor for information. • Route hoses and cables away from traffic areas, sharp edges, moving parts, and hot surfaces. • Do not kink or over bend hoses or use hoses to pull equipment. • Keep children and animals away from work area. • Comply with all applicable safety regulations. |
|  | <p>FIRE AND EXPLOSION HAZARD</p> <p>Flammable fumes, such as solvent and paint fumes, in work area can ignite or explode. To help prevent fire and explosion:</p> <ul style="list-style-type: none"> • Use and clean equipment only in well ventilated area. • Eliminate all ignition sources; such as pilot lights, cigarettes, portable electric lamps, and plastic drop cloths (potential static arc). • Keep work area free of debris, including solvent, rags and gasoline. • Do not plug or unplug power cords or turn lights on or off when flammable fumes are present. • Ground equipment, personnel, object being sprayed, and conductive objects in work area. See Grounding instructions. • Use only Graco grounded hoses. • Check gun resistance daily. • If there is static sparking or you feel a shock, stop operation immediately. Do not use equipment until you identify and correct the problem. • Do not flush with gun electrostatics on. Do not turn on electrostatics until all solvent is removed from system. • Keep a working fire extinguisher in the work area. |

|  WARNING | |
|--|---|
|  | <p>SKIN INJECTION HAZARD</p> <p>High-pressure fluid from dispense valve, hose leaks, or ruptured components will pierce skin. This may look like just a cut, but it is a serious injury that can result in amputation. Get immediate surgical treatment.</p> <ul style="list-style-type: none"> • Do not point dispense valve at anyone or at any part of the body. • Do not put your hand over the end of the dispense nozzle. • Do not stop or deflect leaks with your hand, body, glove, or rag. • Follow Pressure Relief Procedure in this manual, when you stop spraying and before cleaning, checking, or servicing equipment. |
|  | <p>PRESSURIZED EQUIPMENT HAZARD</p> <p>Fluid from the gun/dispense valve, leaks, or ruptured components can splash in the eyes or on skin and cause serious injury.</p> <ul style="list-style-type: none"> • Follow Pressure Relief Procedure in this manual, when you stop spraying and before cleaning, checking, or servicing equipment. • Tighten all fluid connections before operating the equipment. • Check hoses, tubes, and couplings daily. Replace worn or damaged parts immediately. |
|  | <p>MOVING PARTS HAZARD</p> <p>Moving parts can pinch or amputate fingers and other body parts.</p> <ul style="list-style-type: none"> • Keep clear of moving parts. • Do not operate equipment with protective guards or covers removed. • Pressurized equipment can start without warning. Before checking, moving, or servicing equipment, follow the Pressure Relief Procedure in this manual. Disconnect power or air supply. |

Component Identification


Gear Meter System

970175, Bottom Inlet Service Meter



ti11238a

970177, Horizontal Inlet Service Meter



ti11236a

FIG. 1

- | | | | |
|---|--------------------------|---|----------------|
| A | Gear Meter Control Panel | H | Gear Pump |
| B | Gear Meter Junction Box | J | Electric Motor |
| C | Material Inlet | K | Gear Reducer |
| D | Material Outlet | L | Breather |
| E | Applicator | M | Fill Port |
| F | Air Valve | N | Drain Port |
| G | Gear Meter | | |

Electrical Control Unit




FIG. 2

- AA Emergency Stop Button
- AB Start Button
- AC Fault Reset Button
- AD Manual Mode Dispense Button
- AE Power Indicator Light
- AF Control Active Light
- AH Motor Active Light
- AJ Over Pressure Fault Light
- AK Material Outlet Pressure Below Minimum Light
- AL Motor On/Off Switch
- AM Speed Signal Input (POT / ANALOG) Switch
- AN Dispense (MANUAL / ROBOT)
- AP Tachometer Display
- AQ Pressure Display
- AR Main Sealer Disconnect Lever
- AS Transformer
- AT R53 - Analog Robot Interface Connector
- AU P50 - Meter Interface Cable
- AV P176 - Transducer Cable

Gear Meter Junction Box




FIG. 3

Key:

- BA R176 Connector
- BB R50 Connector
- BC Motor Speed Sensor Connector
- BD XDR Cable

- BE SOL 206 Cable
- BF SOL 202 Cable

Buttons

PB1132 and PB1133 - Emergency Stop Buttons

(AA): Engage either of these buttons to stop system operation. PB1132 is located on the Gear Meter Control Panel, while PB1133 is located on the Gear Meter Junction Box.

PB1131 - Start Button (AB): Engage button to put the system into an “ON” state when both emergency stop buttons (PB1132 & PB1133) are disengaged and the Main Sealer Disconnect Lever is on. The green Control Active Indicator light LT117 (AF) will illuminate.

PB158 - Fault Reset Button (AC): Engage button when the system has faulted due to an overpressure condition. The system will resume normal operation as long as the pressure has gone back down to an acceptable level. See **Dispense** on page 17 for more information.

PB169 - Manual Mode Dispense Button (AD): Engage button to open the dispense gun when selector switch SS169 is set to “MANUAL”.

Lights

LT111 - Power Indicator Light (AE): This white indicator light is illuminated when there is power to the system and the Main Sealer Disconnect Lever (AR) is on. The states of the emergency stop buttons (PB1132 and PB1133) do not affect this light.

LT117 - Control Active (AF): This green indicator light illuminates after the Start Button (PB1131) has successfully put the system into the “on” state and remains lit until either of the emergency stop buttons (PB1132 and PB1133) have been pressed or the Main Sealer Disconnect Lever (AR) has been turned off.

LT131 AND LT129 - Motor Active (AH): These amber indicator lights illuminate when the motor is on (SS125 is set to “On”). LT131 is located on the Gear Meter Control Panel, while LT129 is located on the Gear Meter Junction Box.

LT160 - Over Pressure Fault (AJ): This red indicator light is illuminated when the outlet pressure transducer detects that the pressure is above a maximum limit. When this condition occurs the motor disconnects from the gear pump via a clutch. To program the over pressure set point see **Set Pressure Display** on page 15.

LT154 - Material Outlet Pressure Below Minimum

(AK): This red indicator light is illuminated when the pressure transducer detects that the pressure is below a set point. To program the minimum pressure set point see **Set Pressure Display** on page 15.

Switches

SS125 - Motor ON/OFF (AL): In the “off” state, the motor and the supply pump will be off. In the “on” state, the motor will turn on. The system will not dispense, however, until a dispense signal is present and the pressure is within an acceptable range.

SS135 - Speed Signal Input (POT / ANALOG) (AM):

This selector switch determines how the motor speed is set.

- “POT” Mode: the motor speed is determined by the settings on the potentiometers POT 1 – POT4.
- “ANALOG” Mode: the voltage present on wires 3131 and 3105 (pins A and B of connector R53) determines the motor speed.

See **Potentiometer Settings** on page 16 for descriptions of each potentiometer.

SS169 - Dispense (MANUAL / ROBOT) (AN):

This selector switch determines how the dispense signal is issued to the system.

- “MANUAL: the dispense push button (PB169) controls the dispense signal.
- “ROBOT”: the robot dispense signal on wires 1711 and 1083 (pins A and B of connector R52) control the dispense state.
- The output control signals “Sealer in Cycle”, “Sealer Ready”, and “Sealer Maintenance Required” are only valid when SS169 is set to “ROBOT”.

Displays

TD321 - Tachometer Display (AP): This digital display shows the current speed (RPM) of the gear motor.

PD166 - Pressure Display (AQ): This digital display shows the current output pressure as measured by the pressure sensor near the material outlet port. This module controls the system’s minimum and maximum pressure limits. To program see **Set Pressure Display** on page 15.

Communications Diagram




FIG. 4

Cables

R52 – Discrete Robot Interface Connector

This connector provides a means to connect a cable between the Gear Meter Control Panel and a robot controller that carries discrete signals. This cable carries the following signals:

- Robot Dispense Signal
- Sealer Ready
- Sealer in Cycle
- Sealer Maintenance Required
- Select Speed 2
- Select Speed 3
- Select Speed 4
- Power

R53 – Analog Robot Interface Connector

This connector provides a means to connect a cable between the Gear Meter Control Panel and a robot controller that carries an analog speed signal.

P50 – Meter Interface Cable

This cable runs between the Gear Meter Control Panel and the Gear Meter Junction Box.

P176 – Transducer Cable

This cable runs between Gear Meter Control Panel and Gear Meter Junction Box.

4CL3 – Supply Pumps Interface Cable

This cable runs between the Main Electrical Control Panel and the Supply Pump Junction Box.

SOL 206– Solenoid Cable

This cable runs between the Gear Meter Junction Box and the Dispense Gun (SOL206).


SOL 202– Solenoid Cable

This cable runs between the Gear Meter Junction Box and the Brake/Clutch (SOL202).

XDR – Transducer Cable

This cable runs between the Gear Meter Junction Box and the Pressure Transducer.

Setup



Supply hoses are not included with the Gear Meter. We recommend 1-1.5 in. ID hose with nylon or PTFE core and SST overbraid for 5000 psi (34.47 MPa, 344 bar).

High pressure fluid filters should be used between the supply unit and the gear meter inlet. See **Fluid Filters** on page 44.

Connections


Power

The system requires 480 VAC, 3-phase, 60 Hz line voltage with ground. The system is not approved for use with 50 Hz line voltage. All electrical wiring must be performed by a qualified electrician and comply with all local codes and regulations.

1. Wire each phase to a separate terminal on Main Sealer Disconnect DISC100 (AR).
2. You must connect ground to the Gear Meter Control Panel (A). The ground wire must be connected to the ground bar above DISC100.

System Cables

1. Connect P50 cable from the Gear Meter Control Panel (A) to the Gear Meter Junction Box (B). Cable P50 provides ground to the gear meter. See page 41 for a detailed pin out.

 Use only cables supplied by Graco or cables that meet the requirements shown in the wiring schematic on page 41.

2. Verify that there is a good connection between the ground in the Gear Meter Junction Box (B) and the ground of the Gear Meter Control Panel (A).
3. Connect cable P176 from the Gear Meter Control Panel (A) to the Gear Meter Junction Box (B).
4. Connect cable 4CL3 from the Gear Meter Control Panel (A) to the Supply Pump Junction Box.

Robot Connections

Two connectors are available for external robot controller I/O signals. The R52 connector is available for discrete communication signals, while the R53 connector is available for an analog speed input. See **R53 Connector** on page 14.

R52 Connector

The input and output signals on R52 use a 120 VAC interface. Three types of signals are available from this connector:

Output – Output signals are driven by the Gear Meter Control Panel and provide feedback to the robot controller. An output signal is a 120 VAC signal as referenced between the wire corresponding to the desired output and wire 1083.

Input – Input signals originate from an external robot controller and can command the Gear Meter to dispense or change speeds. Input signals must be of the dry-contact type between wire 1711 and the wire corresponding to the desired input.

Power – 120 VAC power signals are provided on R52.

Table 1: R52 Signals on page 11 identifies available R52 signals and provides a brief description of each signal. The Pin ID correlates to that shown in FIG. 5 on page 13.

Table 1: R52 Signals

| Pin ID | Wire ID | Color | Pin Type | Usage: Description |
|--------|---------|-------|----------|---|
| A | 1711 | Red | Power | Power for Sealant Interface: Power is connected to this wire when the Dispense Mode Switch SS169 (AN) is set to robot mode. |
| B | 1083 | White | Power | Power for Sealant Interface (Common): This wire is not affected by the state of the Dispense Mode Switch SS169 (AN). This common power line is also connected to ground. |
| C | GND | Green | Power | Ground |
| D | R52-D | Red | - | - |
| E | R52-E | Red | - | - |
| F | 1832 | Red | Output | <p>Sealer in Cycle:</p> <p>An active signal is put on this wire when all of the following conditions are true:</p> <ul style="list-style-type: none"> • The Dispense Mode Switch SS169 (AN) is set to "Robot". • The Motor Selector Switch SS125 (AL) is set to "On". • Outlet pressure is above the minimum pressure set point. • Outlet pressure is not above the maximum pressure. • The Robot Dispense Signal is active on R52-Y. |
| G | R52-G | Red | - | - |
| H | R52-H | Red | - | - |
| J | R52-J | Red | - | - |
| K | 2261 | Red | Input | Engage POT #2* (Select Speed #2): This signal is activated by closing a dry contact between wire 1711 and wire 2261 at the robot controller. An active signal on this wire will set the speed of the motor according to the mechanical setting of POT2. |
| L | 2281 | Red | Input | Engage POT #3* (Select Speed #3): This signal is activated by closing a dry contact between wire 1711 and wire 2281 at the robot controller. An active signal on this wire will set the speed of the motor according to the mechanical setting of POT3. |
| M | 2301 | Red | Input | Engage POT #4* (Select Speed #4): This signal is activated by closing a dry contact between wire 1711 and wire 2301 at the robot controller. An active signal on this wire will set the speed of the motor according to the mechanical setting of POT4. |
| N | R52-N | Red | - | - |

| Pin ID | Wire ID | Color | Pin Type | Usage: Description |
|--------|---------|-------|----------|---|
| P | R52-P | Red | - | - |
| Q | R52-Q | Red | - | - |
| R | R52-R | Red | - | - |
| S | R52-S | Red | - | - |
| T | 1831 | Red | Output | <p>Sealer Maintenance Required:</p> <p>An active signal is put on this wire when the Dispense Mode Switch SS169 (AN) is set to "ROBOT" and one or more of the following conditions is true:</p> <ul style="list-style-type: none"> The Motor Selector Switch SS125 (AL) is set to "Off". Outlet pressure is not above the minimum pressure of set point. Outlet pressure is above the maximum pressure. |
| U | 1831 | Red | Output | <p>Sealer Ready:</p> <p>An active signal is put on this wire when all of the following conditions are true:</p> <ul style="list-style-type: none"> The Dispense Mode Switch SS169 (AN) is set to "ROBOT". The Motor Selector Switch SS125 (AL) is set to "On" Outlet pressure is above the minimum pressure set point. Outlet pressure is not above the maximum pressure. |
| V | R52-V | Red | - | - |
| W | R52-W | Red | - | - |
| X | R52-X | Red | - | - |
| Y | 1712 | Red | Input | <p>Robot Dispense Signal:</p> <p>This signal is activated by closing a dry contact between wire 1711 and wire 1712 at the robot controller. Asserting a signal on this line will do the following:</p> <ul style="list-style-type: none"> Open dispense gun. If the Motor Selector Switch SS125 (AL) is set to "on", the supply pumps on will be activated. If the motor is on and the supply pressure is below the maximum limit, the brake will be disengaged and the clutch will be engaged. |
| Z | R52-Z | Red | - | - |
| a | R52-a | Red | - | - |

| Pin ID | Wire ID | Color | Pin Type | Usage: Description |
|--------|---------|-------|----------|--------------------|
| b | R52-b | Red | - | - |
| c | R52-c | Red | - | - |
| d | R52-d | Red | - | - |
| e | R52-e | Red | - | - |
| f | R52-f | Red | - | - |
| g | R52-g | Red | - | - |


 By default, POT 1 is engaged only if POT 2, POT 3, and POT 4 are disengaged.

FIG. 5 depicts the pin-out of the R52 receptacle (Amphenol SINE type A431-2P04-E5).




FIG. 5: R52 Pin-Out Receptacle

R53 Connector


The R53 connector is available as an analog speed input from a robot controller. An acceptable signal from a robot controller is a 0 – 10 VDC signal.

Table 2: R53 Signals identifies the available R53 signals and provides a brief description of each signal. The Pin ID correlates to the pins identified in FIG. 6.

Table 2: R53 Signals

| Pin ID | Wire ID | Color | Usage: Description |
|--------|-------------|-------|--|
| A | 3131 | Blue | Analog Speed Command Input 0 - 10 VDC From Robot (+): Connect to the (+) wire of a 0-10 VDC analog controller. The speed of the motor directly correlates to this voltage, where 0 volts commands the slowest possible speed and 10 volts commands the fastest possible speed. |
| B | 3105 | Blue | Analog Speed Command Input 0 - 10 VDC From Robot (-): Connected to the (-) wire of a 0-10 VDC analog controller. |
| C | Do Not Wire | - | Do Not Connect |
| D | GND | Green | Ground |
| E | Do Not Wire | - | Do Not Connect |

FIG. 6 depicts the pin-out of the R53 receptacle (Amphe-nol type 97-3102A-14S-5P).



ti11388a

FIG. 6: R53 Pin-Out Receptacle

Set Pressure Display

Pressure Display PD166 (AQ) shows the outlet pressure. The pressure display is factory programmed with default over pressure and minimum outlet pressure values.

1. Press the “Down” arrow key on PD166 (AQ) and verify that the display is set to “Input” and not “Totalized.” This will display the outlet pressure value, not a totalized sum.



The optimum values vary from system to system based on variables such as hose length and material viscosity. The best settings for a particular application may be found empirically.

Graco Set Values

Programming of the pressure display is divided into modular steps. Use the up and down arrows beneath the display to navigate the set-up menu and change the function values. The “P” button is used to select a programming module or function and to save the function values.

1. Press “P” to enter programming mode. The message “Pro”, followed by a number, should appear. The number identified is the selected Program Module.
2. Press the “Up” or “Down” arrow keys to scroll the functions in the current program module.
3. Press “P” to select the highlighted function. Use the “Up” or “Down” arrows to change the value.
4. Press “P” to save the function value.

The following tables show the functions and Graco set values used. Program Modules 1, 4, 5, 7, 8, 9 are not used. See the **Red Lion Controls Model IMP Instruction Manual** (not provided by Graco) for all of the default programming values and description of all the Program Modules.

The over pressure set point is controlled by Alarm 2 (AL-2) and has a factory default setting of 5000 psi (34.47 MPa, 344 bar).

The under pressure set point is controlled by Alarm 1 (AL-1) and has a factory default setting of 1000 psi (6.89 MPa, 68.94 bar).

| Program Module #2 Scaled by Signal Method | |
|--|-------|
| Function | Value |
| dECPNt | 0 |
| round | 1 |
| SCALE | yes |
| dSP 1 | 0 |
| INP 1 | 4.00 |
| dSP | 1000 |
| INP 2 | 7.19 |

| Program Module #3 Front Panel Lockout | |
|--|-------|
| Function | Value |
| dSP AL | yes |
| Ent AL | yes |
| dSPHYS | yes |
| ENthYS | yes |
| rSt AL | yes |
| dSPbUF | no |
| rStbUF | no |
| SELdSP | no |
| RSttOt | no |
| tArE | no |

| Program Module #6 Alarms | |
|-----------------------------|-------|
| Function | Value |
| trAC | no |
| dISP | no |
| LAtC-1 | no |
| ASN-1 | input |
| AL-1 | 1000 |
| HyS-1 | 1 |
| Act-1 | hi |
| LAtC-2 | no |
| ASN-2 | input |
| AL-2 | 5000 |
| HyS-2 | 1 |
| Act-2 | hi |

Potentiometer Settings

The Speed Signal Input Selector Switch SS135 (AM) determines how the gear motor speed is set. SS135 can be set to “POT” or “ANALOG.”

“**POT**” - The speed is based on the physical settings of one of the potentiometers.

Each potentiometer, POT 1 – POT 4, can scale the motor speed between the minimum and maximum motor speed. Therefore, each potentiometer can be set to a unique “speed” and can be called upon by activating the corresponding pin on connector R52. Only one signal (pin K, L, or M of connector R52) should be activated at a time.

“**ANALOG**” - The speed of the gear motor is determined by the analog voltage signal that is supplied by the robot controller and the setting on the “ANALOG SPAN” potentiometer.

POT 1

The POT 1 potentiometer can be used to set the speed of the Gear Meter motor while in “MANUAL” or “ROBOT” dispense mode. This is the only potentiometer that can control the gear meter speed when the Dispense Mode Switch SS169 (AN) is set to “MANUAL”.

When Dispense Mode Switch SS169 (AN) is set to “ROBOT”, POT 1 is the default potentiometer if no other active signals are detected on pins K-M of connector R52.

POT 2 - 4

In addition to POT 1, potentiometers POT 2 – POT4 can be used to set the speed of the Gear Meter motor when a robot controller is connected. Each potentiometer represents a speed setting that can be saved and called upon by the robot controller. These settings can only be accessed via an external signal from a robot controller on pins K-M of connector R52.

ANALOG SPAN

This potentiometer can be used to scale the analog input voltage from the robot controller. This potentiometer should be set to 500 when programming the robot.

Adjust Gear Motor Speed

1. Turn Main Sealer Disconnect Lever (AR) off.
2. Open the Gear Meter Control Panel (A) door and locate the potentiometers. See **Part No. 617517, Electrical Control** on page 35.
3. Slide the lever beneath the potentiometer to the left and adjust the value.
4. Turn each potentiometer knob to increase or decrease the motor speed.
5. Slide the lever to the right to lock the potentiometer.

Calibrate Flowrate

1. See **Startup** on page 17.
2. Chart the flowrate for each analog VDC set point and determine the desired flowrate.
3. VDC setpoints need to be programmed into the robot if dispensing in “ROBOT” mode.

Pressure Relief



1. Turn off air supply to supply unit.
2. Turn off gear pump at gear meter control panel (A) using Motor On/Off switch SS125 (AL).
3. Set Dispense Mode Switch SS169 (AN) to “MANUAL” and push Manual Mode Dispense Button PB169 (AD).


Flushing

Refer to material manufacturer for recommended flushing compound.

CAUTION

Urethane material should not be exposed to atmosphere. Use grease or petroleum jelly to seal off urethane material in components from atmosphere.

Operation



Startup

1. Turn Main Sealer Disconnect Lever (AR) on. The Power Indicator Light LT111 (AE) should illuminate, indicating that power is on and that ground is connected.
2. Depress Start button PB1131 (AB). The Control Active Light LT117 (AF) should illuminate.
3. Turn Motor Selector Switch SS125 (AL) on. The Motor Active Lights LT129 and LT131 (AH) should illuminate.
4. Set the Dispense Mode Switch SS169 (AN) to “MANUAL” or “ROBOT” dispense mode.
5. Select speed with the Speed Signal Input Selector Switch SS135 (AM).
 - a. *POT Mode:* See **Potentiometer Settings** on page 16.
 - b. *Analog Mode:* the motor speed is controlled by a 0-10 VDC signal applied to wires 3131 (+) and 3105 (common). It is suggested that ANALOG SPAN potentiometer be set to 500 to allow easier adjustment when reprogramming the robot output speed signal.

Dispense

Once the system has been setup, the system is ready to dispense.

Pump activation is controlled by a pushbutton or a robotic dispense signal. The supply pump is only activated when dispensing occurs in order to prevent large pressure increases downstream of the gear meter. This helps prevent stall pressure build up in the gear meter that can result in downstream pressure creep depending on the material viscosity.

MANUAL Dispense Mode

1. Set SS169 (AN) to “MANUAL.”

2. Depress Manual Mode Dispense Button PB169 (AD) to dispense material. This button must be held down to maintain a flow of material.

ROBOT Dispense Mode

1. Set Dispense Mode Switch SS169 (AN) to “ROBOT.”
2. Close dry contacts in the robot control panel between wires 1711 and 1712 to dispense.
 - The sealer ready signal (wire 1813) will be on if the following conditions are present:
 - Motor is on.
 - Pressure is greater than the allowable minimum
 - Pressure is less than the allowable maximum.
 - The sealer in cycle signal (wire 1832) will be on if the following conditions are present:
 - Sealer ready is true.
 - Robotic dispense signal is present.
 - The sealer maintenance required signal will be on if the following conditions are present:
 - Motor is not on.
 - Material pressure is below minimum.
 - Material pressure is above maximum.

Overpressure Fault

The Overpressure Fault Light LT160 (AJ) illuminates when the pressure transducer detects that the pressure is above a maximum limit. An overpressure condition will turn the supply pumps off.


1. Open the dispense gun and disengage the drive system.
2. Depress the Fault Reset Button PB158 (AC) to reset the system after the cause for the fault is rectified.

Shutdown

At any time, Emergency Stop Buttons PB1132 or PB1133 (AA) may be pushed to stop dispensing operations.

1. Turn Motor Selector Switch SS125 (AL) off. The Motor Active Lights LT129 and LT131 (AH) will turn off indicating that the motor is inactive.
2. Turn Main Sealer Disconnect Lever (AR) off. The Power Indicator Light LT111 (AE) will turn off.

Maintenance



CAUTION

Urethane material should not be exposed to atmosphere. Use grease or petroleum jelly to seal off urethane material in components from atmosphere.

Reference the following manuals for detailed maintenance and repair procedures of the Gear Meter components listed below. These manuals are not provided by Graco.

| Part | Manual |
|---------------------|--|
| Gear Pump (35) | Kawasaki Gear Pump Technical Bulletin No. 703M |
| Gear Reducer (19) | SEW-EURODRIVE Gearmotors and Gear Reducers Operating Instructions 01 805 52 US |
| Electric Motor (31) | Baldor Electric Company Intergral Horsepower D.C. Motor Installation and Operation User Manual MN605 |
| Brake Clutch (25) | Nexen Air Champ Products User Manual FORM NO. L-20134-F-0200 |
| Pressure Display | Red Lion Controls Model IMP Instruction Manual |

Troubleshooting

| Problem | Cause | Solution |
|--|---|--|
| Supply pumps are off. | Overpressure condition | Open the dispense gun and disengage the drive system. Depress Fault Reset Button PB158 (AC) to reset. |
| Pressing the Manual Mode Dispense Button PB169 (AD) does not dispense material | System is in "ROBOT" mode. | Turn Dispense Mode Switch SS169 (AN) to "MANUAL" mode. The manual dispense button does not have an effect on the system while SS169 (AN) is set to "ROBOT". |
| Gear motor does not respond to analog speed control mode. | System is in "POT" speed mode. | The Speed Signal Input Selector Switch SS135 (AM) must be manually set to "ANALOG" in order for an analog signal to drive the motor control board. |
| | ANALOG SPAN potentiometer is set to 0%. | Increase the ANALOG SPAN potentiometer setting. It is recommended that this potentiometer be set to 50% when programming the robot controller. The potentiometer proportionally weights the analog signal. |

Repair



Each figure in the repair section includes an identification table. Use the two letters in the left column of the table to identify a reference number used in one of the three gear pump parts lists.

Remove Gear Pump

1. Relieve pressure. See **Pressure Relief** on page 16.
2. Turn power off with Main Sealer Disconnect Lever (AR). The Power Indicator Light LT111 (AE) will turn off.
3. Disconnect input and output fluid hoses from gear pump (CJ).

| CAUTION | |
|---|--|
| Urethane material should not be exposed to atmosphere. Use grease or petroleum jelly to seal off urethane material in components from atmosphere. | |

4. Remove four screws (CA), lockwashers (CB), and coupling guard (BC). See FIG. 7.

| | 918465 | 918473 | 918477 |
|-----------|--------|--------|--------|
| CA | 138 | 238 | 338 |
| CB | 139 | 239 | 339 |
| CC | 143 | 243 | 343 |



CC CA, CB

FIG. 7: Coupling Guard

5. Remove four screws (CE) and lockwashers (CG) from gear pump spacer (CD). See FIG. 8.

| | 918465 | 918473 | 918477 |
|-----------|--------|--------|--------|
| CD | 105 | 205 | 305 |
| CE | 106 | 206 | 306 |
| CF | 109 | 209 | 309 |
| CG | 117 | 217 | 317 |
| CH | 133 | 233 | 333 |
| CJ | 135 | 235 | 335 |
| CK | 136 | 236 | 336 |
| CL | 137 | 237 | 337 |




FIG. 8: Gear Pump

- Remove four screws (CM), lockwashers (CN), and two o-rings (CL) from the inlet flange (CK) and outlet flange (CH). Check the o-rings for damage and replace as necessary. See FIG. 8 and FIG. 9.

| | 918465 | 918473 | 918477 |
|----|--------|--------|--------|
| CM | 132 | 232 | 332 |
| CN | 153 | 253 | 353 |





FIG. 9: Gear Pump Outlet Flange

- Carefully pull away from the gear reducer the gear pump (CJ), gear spacer (CD) and half of coupling (118, 218, 318) attached to pump. Lay on a clean worksurface. See FIG. 8.
- Remove three screws (101, 201, 301) from the bottom of gear spacer (CD). See FIG. 8.
- Install bypass manifold (104, 204, 304) or spare gear pump (CJ). See FIG. 8.

 It is recommended that you have an extra gear pump on hand to continue operating the gear meter system while the gear pump is repaired.

See **Kawasaki Gear Pump Technical Bulletin No. 703M** for detailed gear pump repair procedures.

Install Gear Pump

- Connect gear pump (CJ) to gear spacer with three screws (101, 201, 301).
- Carefully lower and align the gear pump and gear reducer coupling parts together. Ensure coupling (118, 218, 318) is connected.
- Connect gear pump (CJ) and spacer (CD) to frame (CF) with screws (CE) and lockwashers (CG). See FIG. 8.
- Install inlet flange (CK) and outlet flange (CH), two o-rings (CL), four lockwashers (CN), and screws (CM). See FIG. 9.
- Install coupling guard (CC), four lockwashers (CB), and screws (CA). See FIG. 7 on page 20.
- Connect input and output fluid hoses to gear pump (CJ).

Remove Electric Motor

- Relieve Pressure. See **Pressure Relief** on page 16.
- Turn motor selector switch SS125 (AL) off. LT129 and LT131 (AH) will turn off, indicating that the motor is inactive.
- Turn power off with Main Sealer Disconnect Lever (AR). The Power Indicator Light LT111 (AE) will turn off.
- Open wire box on the electric motor and disconnect A1, A2, and ground wires. See FIG. 10.



FIG. 10

- Remove two screws from clutch housing guards; remove guards. Disconnect black air hoses from the clutch assembly. See FIG. 11.
- Open the wire box on the speed sensor motor adapter (CP). Disconnect the white, red, and black wires. See FIG. 11.
- Loosen fitting (CR) at top of speed sensor motor adapter (CP). See FIG. 11.

| | 918465 | 918473 | 918477 |
|-----------|--------|--------|--------|
| CP | 128 | 228 | 328 |
| CQ | 131 | 231 | 331 |
| CR | 145 | 245 | 345 |





FIG. 11

- Secure electric motor (CQ) to hoist.
- Remove four black socket head cap screws that connect the module brake unit and the module drive unit.
- Pull the electric motor (CQ) and the module drive unit of the clutch assembly away from the module brake unit; lay on worksurface.

CAUTION


The Modular Drive Unit ball bearing is loose fitting by design. Do not allow the ball bearing to fall off the Modular Drive Unit.

- Disconnect the module drive unit and the electric motor (CQ).

 See the Baldor Electric Company Intergral Horsepower **D.C. Motor Installation and Operation user manual MN605** for detailed repair procedures.


Install Electric Motor

- Connect electric motor (CQ) and the module drive unit of the clutch assembly.
- Install electric motor (CQ) and module drive unit to the module brake unit with four black socket head cap screws.
- Tighten fitting (CR) on top of speed sensor motor adapter (CP). See FIG. 11.
- Connect A1, A2, and ground wires in the wire box on the electric motor.
- Install clutch housing guard and connect black air hoses.

 The motor must turn counterclockwise. Reverse A1 and A2 wires if necessary.

Remove Brake Clutch

- See **Remove Electric Motor**.
- Remove four bolts and lockwashers from the gear reducer adapter.
- Disconnect the module brake unit of clutch.

 See the Nexen **Air Champ Products user manual FORM NO. L-20134-F-0200** for detailed repair procedures of the brake clutch (125, 225, 325).



Install Brake Clutch

- Install module brake unit of clutch to gear reducer adapter with four bolts and lockwashers.
- See **Install Electric Motor**.

Parts

Part No. 970175, Bottom Inlet Service Meter


Part No. 970176, Top Inlet Service Meter



Part No. 970177, Horizontal Inlet Gear Meter System

Part No. 970194, Horizontal Inlet Gear Meter System with Heated Hose

Horizontal Inlet Gear Meter System




15.37 in. (390.40 mm)

25.26 in. (641.6 mm)

11

12


Horizontal Inlet Gear Meter System with Heated Hose



Part No. 970175, 970176, 970177, 970194, Gear Meter Systems

| Ref. No. | Part No. | Description | Gear Meter Systems | | | |
|----------|----------|---|------------------------------------|---------------------------------|--|--|
| | | | Bottom Inlet Service Meter, 970175 | Top Inlet Service Meter, 970176 | Horizontal Inlet Service Meter, 970177 | Horizontal Inlet Gear Meter with Heated Hose, 970194 |
| 1 | 617517 | CONTROL, electrical; see page 33 | ✓ | ✓ | ✓ | ✓ |
| 2 | C59755 | KIT, installation, 1 ft disp hose | ✓ | ✓ | ✓ | |
| | C59758 | KIT, 1 ft urethane heated dispense hose | | | | ✓ |
| 3 | | PUMP, gear pump assembly | 918477 See page 31 | 918465 See page 27 | 918473 See page 29 | 918473 See page 29 |
| 4 | 918490 | KIT, repair | ✓ | ✓ | ✓ | ✓ |
| 5 | 918539 | APPLICATOR, ball seat, 3/4 port, 42:1 | ✓ | ✓ | ✓ | |
| 6 | 156172 | FITTING, union, swivel | ✓ | ✓ | ✓ | ✓ |
| 7 | C20487 | FITTING, nipple, hex | ✓ | ✓ | ✓ | |
| 8 | 15B919 | MODULE, isolation valve | | | | ✓ |
| 9 | | FITTING, swivel | | | | ✓ |
| 11 | C59555 | CONTROL, 4 zone controller | | | | ✓ |
| 12 | C07738 | CABLE, jumper 14 soc to 14 pin | | | | ✓ |

Part No. 918465, Top Inlet Gear Pump



Part No. 918465, Top Inlet Gear Pump

| Ref. No. | Part No. | Description | Qty. |
|----------|----------|----------------------------------|------|
| 101 | 109114 | SCREW, cap, socket hd | 3 |
| 102 | 100214 | WASHER, lock | 2 |
| 103 | 101864 | SCREW, cap socket hd | 2 |
| 104 | 617465 | MANIFOLD | 1 |
| 105 | 617505 | SPACER, gear pump | 1 |
| 106 | C19835 | SCREW, cap socket head | 4 |
| 107 | 100133 | WASHER, lock | 4 |
| 108 | | PLUG, o-ring | 1 |
| 109 | | FRAME | 1 |
| 110 | C19736 | SCREW, drive | 6 |
| 111 | | MARKER | 1 |
| 112 | C19008 | FITTING, adapter, swivel | 1 |
| 113 | C06187 | FILTER | 1 |
| 114 | C50125 | BRACKET | 1 |
| 115 | C19445 | FITTING, elbow, street | 4 |
| 116 | C36183 | MUFFLER | 4 |
| 117 | 100731 | WASHER | 4 |
| 118 | 517458 | COUPLING, jaw type flex | 1 |
| 119 | 517456 | GEAR, reducer | 1 |
| 120 | C19075 | SCREW, cap, hex hd | 4 |
| 121 | 100128 | WASHER, lock | 4 |
| 122 | C19407 | FITTING, connector, male | 6 |
| 123 | C12509 | TUBE, nylon, rnd; 7 ft | 1 |
| 124 | 597151 | FITTING, elbow | 2 |
| 125 | C52543 | CLUTCH, brake | 1 |
| 126 | C52546 | STUD, threaded | 4 |
| 127 | 100131 | NUT, full hex | 4 |
| 128 | C52559 | ADAPTER, motor, speed sensor | 1 |
| 129 | 104472 | SCREW, cap | 4 |
| 130 | 100020 | WASHER, lock | 4 |
| 131 | C52556 | MOTOR, D.C. | 1 |
| 132 | | SCREW | 8 |
| 133 | 617449 | FLANGE | 1 |
| 134 | 517473 | TRANSDUCER | 1 |
| 135† | 517457 | PUMP, hi-flo precision gear | 1 |
| 136 | 617448 | FLANGE | 1 |
| 137 | C20261 | O-RING | 2 |
| 138 | 112166 | SCREW, cap, socket hd | 4 |
| 139 | 100016 | WASHER, lock | 6 |
| 140 | 110755 | WASHER, plain | 2 |
| 141 | 100015 | NUT, hex mscr | 2 |
| 142 | | JUNCTION BOX | 1 |
| 143 | C52545 | GUARD, coupling | 1 |
| 144 | C20720 | FITTING, flex conduit; 5 ft | 1 |
| 145 | C20721 | FITTING, flex conduit | 3 |
| 146 | C20819 | FITTING, conduit, tee | 1 |
| 147 | 158491 | FITTING, nipple | 1 |
| 148 | 110138 | CONNECTOR, conduit straight | 1 |
| 149 | C20874 | PACKING, o-ring, conduit sealing | 1 |
| 150 | C06022 | VALVE | 2 |
| 151 | C07430 | CONNECTOR, sealed | 1 |
| 153 | | WASHER, lock | 8 |
| 154 | 517474 | PACKING | 1 |
| 155 | C19766 | SCREW, machine, binding | 5 |
| 156 | | RING | 6 |
| 157 | | WIRE, copper, electrical | 9 |


| Ref. No. | Part No. | Description | Qty. |
|----------|----------|--------------------------|------|
| 158 | 157021 | WASHER, lock | 5 |
| 159 | C07501 | WIRE, copper, electrical | 18 |
| 160 | 100284 | NUT, hex mscr | 5 |
| 163 | C20365 | FITTING, tee, air | 1 |
| 164 | C07431 | CONNECTOR, sealed | 1 |
| 165 | 103345 | SCREW, cap socket hd | 4 |
| 166 | C20004 | SCREW, cap | 2 |

† See **Repair Kits** on page 44 for Gear Pump repair parts (purchase separately).


Part No. 918473, Horizontal Inlet Gear Pump

SIDE VIEW


TOP VIEW



ti11460a



ti11461a



Part No. 918473, Horizontal Inlet Gear Pump






| Ref. No. | Part No. | Description | Qty. | Ref. No. | Part No. | Description | Qty. |
|----------|----------|----------------------------------|------|----------|----------|--------------------------|------|
| 201 | 109114 | SCREW, cap, socket hd | 3 | 259 | | WIRE, copper, electrical | 7 |
| 202 | 100214 | WASHER, lock | 2 | 260 | 157021 | WASHER, lock, int | 5 |
| 203 | 101864 | SCREW, cap socket hd | 2 | 261 | C07501 | WIRE, copper, electrical | 14 |
| 204 | 617465 | MANIFOLD | 1 | 262 | 100284 | NUT, hex mscr | 5 |
| 205 | 617505 | SPACER, gear pump | 1 | 264 | 513421 | WIRE, 3 cond. 18 gauge | 5 |
| 206 | C19837 | SCREW, cap, socket hd | 4 | 265 | | BRACKET, FRL mounting | 1 |
| 207 | 100133 | WASHER, lock | 4 | 266 | 100166 | NUT, full hex | 1 |
| 208 | | PLUG, o-ring | 1 | 267 | C20004 | SCREW, cap | 1 |
| 209 | | FRAME, gear pump | 1 | | | | |
| 210 | C19736 | SCREW, drive | 6 | | | | |
| 211 | | MARKER | 1 | | | | |
| 212 | C19008 | FITTING, adapter, swivel | 1 | | | | |
| 213 | C06187 | FILTER | 1 | | | | |
| 215 | | BRACKET, J-Box | 2 | | | | |
| 216 | C32390 | FILTER, vent, breather | 2 | | | | |
| 217 | 100731 | WASHER | 4 | | | | |
| 218 | 517458 | COUPLING, jaw type flex | 1 | | | | |
| 219 | 517456 | GEAR, reducer | 1 | | | | |
| 220 | C19075 | SCREW, cap, hex hd | 4 | | | | |
| 221 | 100128 | WASHER, lock | 4 | | | | |
| 222 | C19407 | FITTING, connector, male | 2 | | | | |
| 223 | C12509 | TUBE, nylon, rnd | 4 | | | | |
| 224 | C19391 | FITTING, elbow | 2 | | | | |
| 225 | C52543 | CLUTCH, brake | 1 | | | | |
| 226 | C52546 | STUD, threaded | 4 | | | | |
| 227 | 100131 | NUT, full hex | 4 | | | | |
| 228 | C52559 | ADAPTER, motor, speed sensor | 1 | | | | |
| 229 | 104472 | SCREW, cap | 4 | | | | |
| 230 | 100020 | WASHER, lock | 4 | | | | |
| 231 | C52556 | MOTOR, D.C. | 1 | | | | |
| 232 | | SCREW | 8 | | | | |
| 233 | 617449 | FLANGE | 1 | | | | |
| 234 | 517473 | TRANSDUCER | 1 | | | | |
| 235† | 517457 | PUMP, hi-flo precision gear | 1 | | | | |
| 236 | 617448 | FLANGE | 1 | | | | |
| 237 | C20261 | O-RING | 2 | | | | |
| 238 | 112166 | SCREW, cap, socket hd | 6 | | | | |
| 239 | 100016 | WASHER, lock | 6 | | | | |
| 240 | 110755 | WASHER, plain | 6 | | | | |
| 241 | 100015 | NUT, hex mscr | 6 | | | | |
| 242 | | JUNCTION BOX | 1 | | | | |
| 243 | C52545 | GUARD, coupling | 1 | | | | |
| 244 | C20720 | FITTING, flex conduit; 3 ft | 1 | | | | |
| 245 | C20721 | FITTING, flex conduit | 2 | | | | |
| 246 | C20819 | FITTING, conduit, tee | 1 | | | | |
| 247 | 158491 | FITTING, nipple | 1 | | | | |
| 248 | 110138 | CONNECTOR, conduit straight | 2 | | | | |
| 249 | C20874 | PACKING, o-ring, conduit sealing | 1 | | | | |
| 250 | C06022 | VALVE | 1 | | | | |
| 251 | C07430 | CONNECTOR, sealed | 1 | | | | |
| 253 | | WASHER, lock | 8 | | | | |
| 254 | 100643 | SCREW, cap, socket hd | 6 | | | | |
| 255 | C50125 | BRACKET | 1 | | | | |
| 256 | 517474 | PACKING | 1 | | | | |
| 257 | C19766 | SCREW, machine, binding | 5 | | | | |
| 258 | | RING | 6 | | | | |

† See **Repair Kits** on page 44 for Gear Pump repair parts (purchase separately).

Part No. 918477, Bottom Inlet Gear Pump

SIDE VIEW

FRONT VIEW




Part No. 918477, Bottom Inlet Gear Pump

| Ref. | Part No. | Description | Qty. |
|------|----------|----------------------------------|------|
| 301 | 109114 | SCREW, cap, socket hd | 3 |
| 302 | 100214 | WASHER, lock | 2 |
| 303 | 101864 | SCREW, cap socket hd | 2 |
| 304 | 617465 | MANIFOLD | 1 |
| 305 | 617505 | SPACER, gear pump | 1 |
| 306 | C19835 | SCREW, cap, socket hd | 4 |
| 307 | 100133 | WASHER, lock | 4 |
| 308 | | PLUG, o-ring | 1 |
| 309 | | FRAME | 1 |
| 310 | C19736 | SCREW, drive | 6 |
| 311 | | MARKER | 1 |
| 312 | C19008 | FITTING, adapter, swivel | 1 |
| 313 | C06187 | FILTER | 1 |
| 314 | C50125 | BRACKET | 1 |
| 315 | C19445 | FITTING, elbow, street | 2 |
| 316 | C36183 | MUFFLER | 2 |
| 317 | 100731 | WASHER | 4 |
| 318 | 517458 | COUPLING, jaw type flex | 1 |
| 319 | 517456 | GEAR, reducer | 1 |
| 320 | C19075 | SCREW, cap, hex hd | 4 |
| 321 | 100128 | WASHER, lock | 4 |
| 322 | C19407 | FITTING, connector, male | 2 |
| 323 | C12509 | TUBE, nylon, rnd; 6 ft | 1 |
| 324 | C19391 | FITTING, elbow | 2 |
| 325 | C52543 | CLUTCH, brake | 1 |
| 326 | C52546 | STUD, threaded | 4 |
| 327 | 100131 | NUT, full hex | 4 |
| 328 | C52559 | ADAPTER, motor, speed sensor | 1 |
| 329 | 104472 | SCREW, cap | 2 |
| 330 | 100020 | WASHER, lock | 2 |
| 331 | C52556 | MOTOR, D.C. | 1 |
| 332 | | SCREW | 8 |
| 333 | 617449 | FLANGE | 1 |
| 334 | 517473 | TRANSDUCER | 1 |
| 335† | 517457 | PUMP, hi-flo precision gear | 1 |
| 336 | 617448 | FLANGE | 1 |
| 337 | C20261 | O-RING | 2 |
| 338 | 112166 | SCREW, cap, socket hd | 8 |
| 339 | 100016 | WASHER, lock | 8 |
| 340 | 110755 | WASHER, plain | 2 |
| 341 | 100015 | NUT, hex mscr | 2 |
| 342 | | JUNCTION BOX | 1 |
| 343 | C52545 | GUARD, coupling | 1 |
| 344 | C20720 | FITTING, flex conduit; 5 ft | 1 |
| 345 | C20721 | FITTING, flex conduit | 2 |
| 346 | C20819 | FITTING, conduit, tee | 1 |
| 347 | 158491 | FITTING, nipple | 1 |
| 348 | 110138 | CONNECTOR, conduit straight | 1 |
| 349 | C20874 | PACKING, o-ring, conduit sealing | 1 |
| 350 | C06022 | VALVE | 1 |
| 351 | C07430 | CONNECTOR, sealed | 1 |
| 353 | | WASHER, lock | 8 |
| 354 | 517474 | PACKING | 1 |
| 355 | C19766 | SCREW, machine, binding | 5 |
| 356 | | RING | 6 |

| Ref. No. | Part No. | Description | Qty. |
|----------|----------|--------------------------|------|
| 357 | | WIRE, copper, electrical | 9 |
| 358 | 157021 | WASHER, lock | 5 |
| 359 | C07501 | WIRE, copper, electrical | 18 |
| 360 | 100284 | NUT, hex mscr | 5 |
| 362 | 513421 | WIRE, 3 cond. 18 gauge | 8 |

† See **Repair Kits** on page 44 for Gear Pump repair parts (purchase separately).


Part No. 617517, Electrical Control



Inside Electrical Control Panel

See **Wiring Schematics** on page 35.

Front of Electrical Control Panel




Part No. 617517, Electrical Control

| Ref. | No. | Part No. | Description | Qty. |
|------|------|----------|-----------------------|------|
| | 515 | 196165 | BOARD, dc motor drive | 1 |
| | 516▲ | 15F279 | LABEL | 1 |
| | 517▲ | 196548 | LABEL | 1 |


▲ *Replacement Danger and Warning labels, tags, and cards are available at no cost.*

Wiring Schematics


Part No. 617517, Electrical Control




Part No. 617517, Electrical Control



Part No. 617517, Electrical Control




Part No. 617517, Electrical Control




BC-200 CONTROL BOARD JUMPER SETTING TABLE

| JUMPER | SETTING |
|--------|-----------------|
| J1A | 230V |
| J1B | 230V |
| J2 | 10A |
| J3 | 180V |
| J4 | FACTORY SETTING |
| J5 | AFB |
| J6 | NTCL |
| J7 | SPD |
| J8 | S/LT |



SET ANALOG SPAN POTENTIOMETER TO 500 WHEN PROGRAMMING ROBOT.



Part No. 617517, Electrical Control



Part No. 617517, Electrical Control



Part No. 617517, Electrical Control

8

PIN CHART: 120V ROBOT INTERFACE (R52)
TYPE: SINE A431-2P02-1816-E5

| PIN I.D. | WIRE I.D. | COLOR |
|----------|-----------|-------|
| A | 1771 | RED |
| B | 1083 | WHITE |
| C | GND | GREEN |
| D | R52-D | RED |
| E | R52-E | RED |
| F | R52-F | RED |
| G | R52-G | RED |
| H | R52-H | RED |
| I | R52-I | RED |
| J | R52-J | RED |
| K | 2261 | RED |
| L | 2281 | RED |
| M | 2301 | RED |
| N | R52-N | RED |
| O | R52-O | RED |
| P | R52-P | RED |
| Q | R52-Q | RED |
| R | R52-R | RED |
| S | R52-S | RED |
| T | 1831 | RED |
| U | 1813 | RED |
| V | R52-V | RED |
| W | R52-W | RED |
| X | R52-X | RED |
| Y | 1712 | RED |
| Z | R52-Z | RED |
| a | R52-a | RED |
| b | R52-b | RED |
| c | R52-c | RED |
| d | R52-d | RED |
| e | R52-e | RED |
| f | R52-f | RED |
| g | R52-g | RED |

41

PIN CHART: ANALOG INTERFACE ROBOT (R53)
TYPE: AMPHENOL 97-3102A-14S-5P
WIRE 16AWG BLUE, LENGTH 48"

| PIN I.D. | WIRE I.D. | COLOR |
|----------|-------------|-------|
| A | 3131 | BLUE |
| B | 3105 | BLUE |
| C | DO NOT WIRE | - |
| D | GND | GREEN |
| E | DO NOT WIRE | - |

9

PIN CHART: METER INTERFACE (P50)
TYPE: SINE X237-41F2-P20428-E34

| PIN I.D. | WIRE I.D. | AWG | COLOR |
|----------|-----------|-----|---------|
| 1 | 1132 | 16 | RED |
| 2 | 1133 | 16 | RED |
| 3 | GND | 16 | GREEN |
| 4 | 1251 | 16 | RED |
| 5 | P50-5 | 16 | RED |
| 6 | 1101 | 16 | RED |
| 7 | 2062 | 16 | RED |
| 8 | P50-8 | 16 | RED |
| 9 | P50-9 | 16 | RED |
| 10 | P50-10 | 16 | RED |
| 11 | 2024 | 16 | RED |
| 12 | 1083 | 16 | WHITE |
| 13 | P50-13 | 16 | RED |
| 14 | 3032 | 12 | BLACK |
| 15 | 3052 | 12 | BLACK |
| 16 | 3121 | 20 | A 72 |
| 17 | 3105 | 20 | B 72 |
| 18 | 3102 | 20 | D 72 |
| 19 | GND | 20 | SHIELDS |
| 20 | P50-20 | 20 | E 72 |
| 21 | P50-21 | 20 | F 72 |
| 22 | P50-22 | 16 | RED |
| 23 | P50-23 | 16 | RED |
| 24 | P50-24 | 16 | RED |
| 25 | P50-25 | 16 | RED |
| 26 | P50-26 | 16 | RED |
| 27 | P50-27 | 16 | RED |
| 28 | P50-28 | 16 | RED |
| 29 | P50-29 | 16 | RED |
| 30 | P50-30 | 16 | RED |
| 31 | P50-31 | 16 | RED |
| 32 | P50-32 | 16 | RED |
| 33 | P50-33 | 16 | RED |
| 34 | P50-34 | 16 | RED |
| 35 | P50-35 | 16 | RED |
| 36 | P50-36 | 16 | RED |
| 37 | P50-37 | 16 | RED |

USE SINE TYPE 7220 CABLE
2 PAIR 5 COND

48

PIN CHART: SUPPLY PUMPS INTERFACE (4CL3)
TYPE: CROUSE HINDS 4 POLE PLUG W/ 50' CABLE
#5000109-67K OR EQUIV.

| PIN I.D. | WIRE I.D. | COLOR |
|----------|-----------|-------|
| 1 | 1101 | BLACK |
| 2 | 2123 | BLUE |
| 3 | 1083 | BROWN |
| 4 | GND | WHITE |

10


PIN CHART: TRANSDUCER CABLE ASSY (P176)
TYPE: AMPHENOL 97-3106A-10SL-3S
W/ 97-3057-1004-1 CLAMP
WIRE TYPE BELDEN 9501, LENGTH 600"

| PIN I.D. | WIRE I.D. | COLOR |
|----------|-----------|-------|
| A | R52-A | RED |
| B | 2841 | BLACK |
| D | SHIELD | BLACK |

PLUG FACE VIEW
LUMBERG "MIN" STYLE


NOTED ITEMS CAN BE REPLACED WITH X237-4KF2-KALKRC-E36 AND 2 PAIR BELDEN 9463

Gear Meter Junction Box



Gear Meter Junction Box

TERMINALS
 1083
 1083
 1101
 1132
 1133
 1251
 1521
 1541
 1583
 1621
 +2 SPARE
 [GND
 [GND
14 TOTAL



TERMINALS
 2024
 2062
 2521
 2541
 3032
 3052
 3105
 3121
 3102
SHIELD
10 TOTAL

Accessories

Windshield Nozzles

| Part No. | Description | Qty. |
|----------|---------------------------|------|
| C51172 | End Cut Windshield Nozzle | 1 |

Fluid Filters

C58997, Module Filter

| Part No. | Description | Qty. |
|----------|-----------------------|------|
| 518779 | ADAPTER, pipe, female | 2 |
| 515216 | HOUSING, filter | 1 |
| 210658 | VALVE, ball | 1 |
| 116586 | O-RING | 1 |
| 515222 | ELEMENT, filter | 1 |

970126, Header Assembly Filter

| Part No. | Description | Qty. |
|----------|----------------------------|------|
| 210658 | VALVE, ball | 2 |
| 617122 | FRAME, header stand | 1 |
| 102814 | GAUGE, press, fluid | 2 |
| 118854 | VALVE, ball, high pressure | 4 |
| 521975 | FITTING, union, pipe | 4 |
| 518779 | ADAPTER, pipe, female | 4 |
| 518741 | BUSHING | 4 |
| C20490 | FITTING, nipple, hex | 8 |
| 515216 | HOUSING, filter | 2 |
| 516715 | ELEMENT, filter | 2 |
| 100840 | FITTING, elbow, street | 2 |
| 116586 | O-RING | 2 |

Repair Kits

Gear Pump Repair Kits


| Part No. | Description | Qty. |
|----------|-------------|------|
| 241403 | SHAFT, gear | 1 |
| 248253 | SEAL | 4 |
| 108357 | O-RING | 2 |

241404, Hard Metal Repair Kit


| Description | Qty. |
|-------------|------|
| SHAFT, gear | 1 |
| SHAFT, gear | 1 |
| SEAL | 4 |
| DRIVE GEAR | 1 |
| DRIVEN GEAR | 1 |
| SPACER | 4 |

Dimensions

Model 970175, Gear Meter



617517, Electrical Control



| Part No. | Width | Height | Depth |
|---------------------------|-----------------|------------------|-----------------|
| Gear Meter | | | |
| 970175 | 26 in (660 mm) | 59 in. (1498 mm) | 23 in. (584 mm) |
| 970176 | | | |
| 970177 | | | |
| 970194 | | | |
| Electrical Control | | | |
| 617517 | 38 in. (965 mm) | 64 in. (1626 mm) | 12 in. (305 mm) |

Technical Data

D.C. Electric Motor

| | |
|---------------------------------|-----------------|
| Horsepower | 2 HP @ 1750 RPM |
| Maximum current drive | 9.3 amps |
| Average current draw. | 4.7 amps |
| Baldor P/N | CDP3585 |

Air Clutch Assembly

| | |
|-----------------------------|--|
| Shaft size | 0.875 in. diameter bore and output shaft |
| Maximum air supply. | 50 psi (0.34 MPA, 3.44 bar) |
| Nexen P/N | MDB875 |

Gear Reducer Assembly

| | |
|-----------------------------|--|
| Description. | Foot mount parallel helical gear reducer, c-face input, 36.84:1 reduction with flexible coupling |
| SEW Eurodrive P/N | R87AM145 |

Gear Pump Assembly

| | |
|--|--|
| Description. | Inline type, high flow precision gear pump |
| Capacity. | 152 cubic in./min |
| Inlet Thread (on flange) | 1.5 in.-11.5 in. npt (f) |
| Outlet Thread (on flange). | 1.5- 11.5 in. npt (m) |
| Maximum inlet pressure. | 4267 psi (29.4 MPa, 294.19 bar) |
| Maximum outlet pressure | 5689 psi 39.2 MPa, 392.24 bar) |
| Maximum temperature. | 250 °F (121 °C) |
| Maximum viscosity. | 100,000 poise (10,000 Pa.s) |
| Maximum rotational speed. | 50 rpm |
| Displacement. | 50 cc/rev (3.05 cubic in./rev) |
| Recommended fluid filtration | 200 mesh or finer |
| Kawasaki P/N | HF50-CM-28 |
| Wetted parts | D2 tool steel with tufride coating; 1018 carbon steel; fluoroelastomer |

Electrical Control Enclosure

| | |
|-----------------------------------|---|
| Required Voltage Supply | 480 VAC, 3-phase, 60 Hz (not rated for 50 Hz service) |
| FLA | 8.3 Amps |

Graco Standard Warranty

Graco warrants all equipment referenced in this document which is manufactured by Graco and bearing its name to be free from defects in material and workmanship on the date of sale to the original purchaser for use. With the exception of any special, extended, or limited warranty published by Graco, Graco will, for a period of twelve months from the date of sale, repair or replace any part of the equipment determined by Graco to be defective. This warranty applies only when the equipment is installed, operated and maintained in accordance with Graco's written recommendations.

This warranty does not cover, and Graco shall not be liable for general wear and tear, or any malfunction, damage or wear caused by faulty installation, misapplication, abrasion, corrosion, inadequate or improper maintenance, negligence, accident, tampering, or substitution of non-Graco component parts. Nor shall Graco be liable for malfunction, damage or wear caused by the incompatibility of Graco equipment with structures, accessories, equipment or materials not supplied by Graco, or the improper design, manufacture, installation, operation or maintenance of structures, accessories, equipment or materials not supplied by Graco.

This warranty is conditioned upon the prepaid return of the equipment claimed to be defective to an authorized Graco distributor for verification of the claimed defect. If the claimed defect is verified, Graco will repair or replace free of charge any defective parts. The equipment will be returned to the original purchaser transportation prepaid. If inspection of the equipment does not disclose any defect in material or workmanship, repairs will be made at a reasonable charge, which charges may include the costs of parts, labor, and transportation.

THIS WARRANTY IS EXCLUSIVE, AND IS IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO WARRANTY OF MERCHANTABILITY OR WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE.

Graco's sole obligation and buyer's sole remedy for any breach of warranty shall be as set forth above. The buyer agrees that no other remedy (including, but not limited to, incidental or consequential damages for lost profits, lost sales, injury to person or property, or any other incidental or consequential loss) shall be available. Any action for breach of warranty must be brought within two (2) years of the date of sale.

GRACO MAKES NO WARRANTY, AND DISCLAIMS ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, IN CONNECTION WITH ACCESSORIES, EQUIPMENT, MATERIALS OR COMPONENTS SOLD BUT NOT MANUFACTURED BY GRACO. These items sold, but not manufactured by Graco (such as electric motors, switches, hose, etc.), are subject to the warranty, if any, of their manufacturer. Graco will provide purchaser with reasonable assistance in making any claim for breach of these warranties.

In no event will Graco be liable for indirect, incidental, special or consequential damages resulting from Graco supplying equipment hereunder, or the furnishing, performance, or use of any products or other goods sold hereto, whether due to a breach of contract, breach of warranty, the negligence of Graco, or otherwise.

FOR GRACO CANADA CUSTOMERS

The Parties acknowledge that they have required that the present document, as well as all documents, notices and legal proceedings entered into, given or instituted pursuant hereto or relating directly or indirectly hereto, be drawn up in English. Les parties reconnaissent avoir convenu que la rédaction du présente document sera en Anglais, ainsi que tous documents, avis et procédures judiciaires exécutés, donnés ou intentés, à la suite de ou en rapport, directement ou indirectement, avec les procédures concernées.

Graco Information

For the latest information about Graco products, visit www.graco.com.

TO PLACE AN ORDER, contact your Graco distributor or call to identify the nearest distributor.

Phone: 612-623-6921 **or Toll Free:** 1-800-328-0211 **Fax:** 612-378-3505

*All written and visual data contained in this document reflects the latest product information available at the time of publication.
Graco reserves the right to make changes at any time without notice.*

Original instructions. This manual contains English. MM 312744

Graco Headquarters: Minneapolis

International Offices: Belgium, China, Japan, Korea

GRACO INC. P.O. BOX 1441 MINNEAPOLIS, MN 55440-1441

Copyright 2007, Graco Inc. is registered to ISO 9001

www.graco.com

Revised 03/2010