


# AW4062 4-port ADSL2+ Router User's Manual



TECOM Copyright, 2009  
© All Rights Reserved,  
M/C: CPE-AW4062-UM

### **FCC Statement**

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions in this manual, may cause interference to radio communications. This equipment as been tested and found to comply with the limits for a Class B computing device pursuant to Subpart J of Part 15 of FCC rules, which are designed to provide reasonable protection against radio interference when operated in a commercial environment. Operation of this equipment in a residential area is likely to cause interference, in which case the user, at is own expense, will be required to take whatever measures are necessary to correct the interface.

### **CE Declaration of Conformity**

This equipment complies with the requirements relating to electromagnetic compatibility, EN55022 class B for ITE and EN 50082-1. This meets the essential protection requirements of the European Council Directive 89/336/EEC on the approximation of the laws of the Member States relating to electromagnetic compatibility.

### **Environment**

The phone you have purchased, as well as any used batteries must not be disposed of with household waste. You should return these to your distributor if they are able to replace or dispose of them in an approved recycling centre.

### **Trademarks**

Windows 98/2000/XT/NT™ and Internet Explorer™ are registered trademarks of Microsoft Corporation. All other company, brand and product names, like Netscape Navigator™ are trademarks or registered trademarks of their respective owners.



## **WARNING!**

1. Read all installation instructions carefully before connecting the device to its power source.
2. To reduce the risk of electric shock, do not remove the cover from this device or attempt to dismantle it. Opening or removing covers may expose you to dangerous voltage levels. Equally, incorrect reassembly could cause electric shock on re-use of the appliance.
3. Do not expose this device to Fire, direct sunlight or excessive heat.
4. Do not expose the device to rain or moisture and do not allow it to come into contact with water.
5. Do not install the device in an environment likely to present a THREAT OF IMPACT.
6. You may clean this device using a fine damp cloth. Never use solvents (such as trichloroethylene or acetone), which may damage the phone's plastic surface. Never spray this device with any cleaning product whatsoever.
7. Take care not to scratch the surface of plastic housings.
8. The device is designed to work in temperatures from 5°C to 40°C.
9. The this device must be installed at least 1 meter from radio frequency equipment, such as TVs, radios, hi-fi or video equipment (which radiate electromagnetic fields).
10. Do not connect the LAN/PC port to any network other than an Ethernet network.
11. Do not attempt to upgrade your this device in an unstable power environment. This could cause unexpected issues.
12. Do not work on the system or connect or disconnect cables during lightning storms.
13. Children don't recognize the risks of electrical appliances. Therefore use or keep this device only under supervision of adults or out of the reach from children.
14. No repair can by performed by the end user, if you experience trouble with this equipment, for repair or warranty information, please contact your supplier.

# Table of Contents

<b>1. INTRODUCTION.....</b>	<b>4</b>
<b>2. SYSTEM OVERVIEW.....</b>	<b>5</b>
2.1. GENERAL DESCRIPTION.....	5
2.2. SPECIFICATIONS.....	5
<b>3. HARDWARE INSTALLATION.....</b>	<b>7</b>
3.1. PACKAGE CONTENT.....	7
3.2. HARDWARE SETUP PROCEDURE.....	7
3.3. CONNECTORIZATIONS.....	8
3.4. INDICATORS.....	9
<b>4. SOFTWARE CONFIGURATION.....</b>	<b>12</b>
4.1. SET YOUR PC'S ETHERNET PORT.....	12
4.2. ACCESS THE WEB PAGE OF ROUTER.....	13
4.3. LAN CONFIGURATION.....	14
4.4. WIRELESS CONFIGURATION.....	15
4.5. WAN CONFIGURATION.....	24
4.6. SERVICES CONFIGURATION.....	28
4.7. FIREWALL.....	39
4.8. ADVANCE CONFIGURATION.....	49
4.9. DIAGNOSTIC.....	59
4.10. ADMIN.....	62
4.11. STATISTICS.....	69
<b>APPENDIX A. CHANNEL MODE CONFIGURATION.....</b>	<b>71</b>
<b>APPENDIX B. PROTOCOL STACKS.....</b>	<b>76</b>
<b>APPENDIX C. MAPPING PVCS TO VLANS.....</b>	<b>81</b>

## 1. Introduction

The AW4062 is an ADSL2+ router that can be used to connect to a twisted copper pair ADSL2+ broadband network. The AW4062 is backwards compatible to all ADSL modulation technology including G.lite, G.dmt, T1.413, ADSL2 and ADSL2+. AW4062 also supports various Internet service provider networks via common WAN protocol such as PPPOE, PPPOA, Bridge/MER 1483 modes. With advanced features such as remote configuration, the AW4062 reduces provisioning, maintenance and deployment overheads and ensures a hassle free user experience. Leveraging adoption of Annex-M DSL technology, the AW4062 is capable to provide increased upstream rates to better fulfill growing demand from the SOHO/SMB user. Compliant to Annex L technology, the AW4062 can reach users in a larger service radius increasing the operators' Central Office user density. The AW4062 is a reliable and full-featured ADSL2+ router capable of supporting data traffic and IP services which allows for minimum overhead deployment.

This User's Manual mainly contains the guidance to install and configure this ADSL2+ Router using the Web GUI.

## 2. System Overview

### 2.1. General Description

This AW4062 Router is a high-speed ADSL Ethernet router that is specifically designed to connect to the Internet and to directly connect to your local area network (LAN) via high-speed 10/100 Mbps Ethernet, or wireless LAN (WLAN). The ADSL modem is compatible with the latest ADSL standards, including ADSL2 and ADSL2+, and supports up to 24 Mbps downstream and 1.5 Mbps upstream to deliver true broadband speed and throughput.

To ensure fully compatibility, the DSL device was tested with all major DSLAMs, and support standard 10/100 Mbps Base-T Ethernet interface Auto MDI / MDIX 10/100 Switch function allowing user easily to link to PC or other Switches/Hubs. The DSL device is an idea solution for multi-users utilizing build-in channel mode (PPPoE/A, IPoA, IPoE), IP routing, NAT functionalities sharing the ADSL link. The DSL device is also a perfect solution for the residential users, it supports the users with bridge mode in host based PPPoE Client.

### 2.2. Specifications

#### 2.2.1. ADSL Standard

- ITU-T G.992.1(G.dmt)
- ANSI T1.413 Issue 2
- G.992.2 (G.lite)
- G.994.1 (G.hs)
- Auto-negotiating rate adaptation
- ADSL2 G.dmt.bis (G.992.3)
- ADSL2 G.lite.bis (G.992.4)
- ADSL2+ (G.992.5)

#### 2.2.2. Software Features

- RFC-1483/2684 LLC/VC-Mux bridged/routed mode
- RFC-1577 Classical IP over ATM
- RFC-2516 PPPoE
- RFC-2364 PPPoA
- ITU-T 1.610 F4/F5 OAM send and receive loop-back
- 802.1d Spanning-Tree Protocol
- DHCP Client/Server/Relay
- NAT
- RIP v1/v2

- DNS Relay Agent
- DMZ support
- IGMP Proxy/Snooping
- Packet Inspection
- Protection against Denial of Service attacks
- IP Packet Filtering
- QoS
- Dynamic DNS
- Wi-Fi
- WPS

### **2.2.3. Management**

- Web-based Configuration
- Menu-driven Command-line Interpreter
- Telnet Remote Management
- SNMP v1/v2/Trap
- Firmware upgrade through FTP, TFTP and HTTP
- Configuration backup/restore
- Diagnostic Tool
- TR069

## 3. Hardware Installation


### 3.1. Package Content

Upon opening the gift box of AW4062 Router, you will find the following items.

- 1 x AW4062 Router Main Unit
- 1 x 15VDC/800mA power adaptor
- 1 x CD-ROM
- 1 x Quick Install Guide
- 1 x Warranty Card
- 1 x RJ-45 Ethernet cable
- 1 x RJ-11 ADSL line
- 1 x T-Connector
- 1 x T-Connector
- 3 X Microfilters

### 3.2. Hardware Setup Procedure

Referring to the figure below and connect this ADSL router to the ISP ADSL line and PC.



1. Connect RJ-11 Telephone wire from AW4062 Router ADSL port to the T-connector that connects the ADSL line to the DSLAM located at central office. Thus it is the gate to the world-wide Internet.
2. An analog telephone can be connected to ISP Microfilter. This phone can work as

it were connected directly to the PSTN Line (also called as ADSL line now)


3. Connect RJ-45 Ethernet Cable from your PC to AW4062 Router Ethernet port. If you have two or more PC systems, you have to prepare a low-density Ethernet switch or hub for expansion purpose.
4. Connect the AC Power Adaptor (15V) and then the AW4062 Router will start to run and connect the Home local network to the Broadband world.

### 3.3. Connectorizations

All the connectors, reset button power switch and power jack are on the rear panel. The drawing of the rear panel is shown below.







Label	Color	Function
ADSL	Gray	RJ-11 connector: Connect the device to the ADSL.
	Black	Shortly press the Wi-Fi / WPS button to enable / disable Wi-Fi interface <b>(more than 1 and less than 8 seconds)</b> Long press the Wi-Fi / WPS button to enable WPS enrollee <b>(more than 8 seconds)</b>
RESET	Black	Long press RESET button to reset the configuration to factory default and restart the device <b>(more than 10 sec)</b>
ETHERNET 1-4	Yellow	RJ-45 connector: Connect the device to your PC's Ethernet port, or to the uplink port on your LAN's hub or home gateway, using the Ethernet cables.
DC 15V 800mA	Black	Connects to the power adaptor.
ON/OFF	Black	Turn on / off the power.
ANTENA	WHITE	Detachable antenna.

### 3.4. Indicators

The following table is a description of the meaning of the different LEDs on the AW4062:



Label	Color	Function
	Red / Green	Steadily off: Power is off. Red solid on: Power on self test (POST) or fail to boot up. Green blinking: while booting. Green steadily on: Boot process is successful.
ETHERNET 1-4	Y-Green	Steadily off: Wired interface not established (Ethernet cable not detected or not connected properly). Blinking: Traffic is passing thru. Steadily on: Wired interface established (Ethernet cable detected).
WLAN	Y-Green	Steadily off: Wi-Fi is disabled. Blinking: Traffic is passing thru. Steadily on: Wi-Fi is activated.
WPS	Green Yellow Red	Blinking yellow: activation of WPS process (association started, in progress) Solid green: connected successfully; session established then off after 10 seconds. Blinking red: failure (whatever it is during the process)
CONEXIÓN	Y-Green	Steadily off: No ADSL connected. Blink slowly: DSL attempting sync when trying to detect carrier signal. (2Hz with 50% duty) Blinking fast: DSL attempting sync when the carrier has been detected and the modem is trying to train. (4Hz with 50% duty) Steadily On: DSL good sync. Link established.
INTERNET	Y-Green	Steadily off: ADSL connection is not present or modem is configured in bridge mode. Blink: IP connected and IP Traffic is passing thru the device (both ways). Steadily on: PPP connection established or Static WAN IP assigned successfully. Red: Device attempted to become IP connected and failed (no DHCP response, no PPPoE response, PPPoE authentication failed, etc).

**NOTE 1:**

**SPECIAL LED's STATUS WHILE THE FIRMWARE IS BEING UPGRADED:**

- While is being upgraded the Firmware, all the LEDs with the exception of the Ethernet led WILL BLINK IN GREEN AT THE SAME TIME DURING THIS PROCESS (if wireless net was disabled, the WLAN LED will not blink neither).
- After finishing the process all the LEDs will come back to the standard status with a normal behaviour.
- If during the firmware upgrading process the router detect a recoverable fail (punctual fail in the uploading which it is posible to come back with no damage in the system), all the LEDs with the exception of the Ethernet led will keep on in GREEN 15 seconds to inform you about the fail produced. After this period of time, all the LEDs will come back to the normal behaviour.
- If during the firmware upgrading process the router detect an unrecoverable fail (system fail impossible to come back: for example, corrupted file, or router disconnected from the power supply while the firmware upgrading was in process), the on LED (POWER) will keep in RED. In this case it is recommended to contact with the technical assistance support.

**NOTE 2:**

**RESET THE ROUTER TO DEFAULT PARAMETERS**

If in any case you want to reset the configuration to factory default parameters, please follow bellow steps:

- Put a paper clip or a pen in the hole back called "RESET".
- Keep pressing internal button more than 10 seconds.
- Stop pressing the internal button "RESET".
- Then, the router will be restarted.
- This process takes 20 seconds. Check LEDs behaviour comparing with figure of section "3.4. Indicators" to be sure the Reset process was finalized successfully.

## 4. Software Configuration

User can change settings via PC's WEB browser. The following sections describe the set up procedures. After successful setting, when you power on the AW4062 Router, it will boot up and connect to ADSL line automatically. The Router can provide PVC (Permanent Virtual Channel) for "Bridge test" by default. The default configurations for the system are listed below.

- LAN IP address: 192.168.1.1
- NetMask: 255.255.255.0
- UART setting: 115200bps, 8 bits, no parity, 1 stop bit, no flow control.
- VPI/VCI for ATM
  - 8/32 for PPPoE
  - 8/36 for PPPoE with Imagnio service
- ADSL Line mode: Auto-detect.


### 4.1. Set your PC's Ethernet port

AW4062 is an ADSL Router which support DHCP and default enable. You also can set your computer IP Address as [192.168.1.x](#) within the same subnet as AW4062 (default IP address is [192.168.1.1](#)) and netmask (default netmask is [255.255.255.0](#)). It can be done thru the following way.

1. Click start > Control Panel
2. In the Control Panel, double-click Network Connections
3. Right-click Local Area Connection the click Properties
4. Select Internet Protocol (TCP/IP) then click Properties
5. The TCP/IP Properties windows appear. You can select obtain an IP address automatically and click OK to have the AW4062 assign your computer an IP address. Or you can enter the IP within the same subnet as AW4062.
6. If your Internet Service Provider (ISP) gave you Domain Name System (DNS) settings, enter them in the Use the following DNS server addresses fields. If you are not sure of your DNS setting, contact your ISP.
7. Click OK to finish the setting.

## 4.2. Access the Web Page of Router

- Type the Ethernet IP address of the modem/router on the address bar of the browser. Default IP address is **192.168.1.1**.
- The “Enter Network Password” dialog box appears. Type the user name and password and then click OK.
- Default admin user name/password is as follows:  
Username / Password: 1234 / 1234
- Once you have connected to ADSL router. You will see the status page.



**TECOM** **ADSL Router**

Site contents:

- Status
- LAN
- Wireless
- WAN
- Services
- Firewall
- Advance
- Diagnostic
- Admin
- Statistics

### ADSL Router Status

This page shows the current status and some basic settings of the device.

System	
Alias Name	OBSERVA TELECOM, AW4062
Uptime	1 day, 4:48
Firmware Version	1.3.5.17a
DSP Version	2.9.0.3x
Name Servers	80.58.61.250, 80.58.61.254
Default Gateway	

DSL	
Operational Status	ACTIVATING.
Upstream Speed	0 kbps
Downstream Speed	0 kbps

LAN Configuration	
IP Address	192.168.1.1
Subnet Mask	255.255.255.0
DHCP Server	Disabled
MAC Address	001915b78695

WAN Configuration						
Interface	VPI/VCI	Encap	Protocol	IP Address	Gateway	Status
ppp1_vc1	8/36	LLC	PPPoE			down 0sec / 0sec
ppp0_vc0	8/32	LLC	PPPoE			down 0sec / 0sec

This page displays the AW4062 Router current status and settings. This information is read-only except for the PPPoE/PPPoA channel for which user can connect/disconnect the channel on demand. Click the “Refresh” button to update the status

Function buttons in this page:

### Refresh

Click Refresh button to update the status.

### 4.3. LAN Configuration

This page shows the current setting of LAN interface. You can set IP address, subnet mask, IGMP Snooping and Ethernet to Wireless Blocking for LAN interface in this page.

Fields in this page:

Field	Description
IP Address	The IP address your LAN hosts use to identify the device's LAN port.
Subnet Mask	LAN subnet mask.

Function buttons in this page:

#### Add

Click to add a new LAN settings, new settings will tack effect after save into flash memory and no need to restart the system.

#### Apply Changes

Click to save the setting to the configuration. New parameters will take effect after save into flash memory and reboot the system. See section "Admin" for save details.

## Delete Selected

Select one LAN configuration and click to delete this setting.

## 4.4. Wireless Configuration

There are five sub-menus for Wireless configuration: [Basic Settings], [Advance Settings], [Security], [Access Control] and [WPS].

### 4.4.1. Basic Settings

This page is used to configure the parameters for wireless LAN clients which may connect to your Access Point. Please refer to the section – **Basic settings** for details.

Fields in this page:

Field	Description
<b>Disable Wireless LAN Interface</b>	Check it to disable the wireless function for ADSL modem.
<b>Band</b>	Select the appropriate band from the list provided to correspond with your network setting.
<b>Mode</b>	<b>Access Point</b> —The gateway communicates with both clients and bridges.
<b>SSID</b>	Enter a name for your wireless network here. SSID stands for Service Set Identifier.
<b>Channel Number</b>	Drop-down menu that allows selection of specific channel.
<b>Radio Power</b>	The maximum output power: 15mW, 30mW or 60mW.

Function buttons in this page:

**Associated Clients**

Click it will show the clients currently associated with the ADSL modem.

**Apply Changes**

Change the settings. New parameters will take effect after save into flash memory and reboot the system

**4.4.2. Advanced Settings**

This page allows advanced users who have sufficient knowledge of wireless LAN. These setting shall not be changed unless you know exactly what will happen for the changes you made on your DSL device. Please refer to the section – **Advance settings** for details.

Fields in this page:

Field	Description
Authentication Type	<b>Open System:</b> Open System authentication is not required to be successful while a client may decline to authenticate with any particular other client.



	<p><b>Shared Key:</b> Shared Key is only available if the WEP option is implemented. Shared Key authentication supports authentication of clients as either a member of those who know a shared secret key or a member of those who do not. IEEE 802.11 Shared Key authentication accomplishes this without the need to transmit the secret key in clear. Requiring the use of the WEP privacy mechanism.</p> <p><b>Auto:</b> Auto is the default authentication algorithm. It will change its authentication type automatically to fulfill client's requirement.</p>
<b>Fragment Threshold</b>	This value should remain at its default setting of 2346. It specifies the maximum size for a packet before data is fragmented into multiple packets. If you experience a high packet error rate, you may slightly increase the "Fragment Threshold" value within the value range of 256 to 2346. Setting this value too low may result in poor network performance. Only minor modifications of this value are recommended.
<b>RTS Threshold</b>	This value should remain at its default setting of 2347. Should you encounter inconsistent data flow, only minor modifications are recommended. If a network packet is smaller than the preset "RTS threshold" size, the RTS/CTS mechanism will not be enabled. The ADSL modem (or AP) sends Request to Send (RTS) frames to a particular receiving station and negotiates the sending of a data frame. After receiving an RTS, the wireless station responds with a Clear to Send (CTS) frame to acknowledge the right to begin transmission.
<b>Beacon Interval</b>	The Beacon Interval value indicates the frequency interval of the beacon. Enter a value between 20 and 1024. A beacon is a packet broadcast by the ADSL modem (or AP) to synchronize the wireless network. The default is 100.
<b>Data Rate</b>	The rate of data transmission should be set depending on the speed of your wireless network. You should select from a range of transmission speeds, or you can select <i>Auto</i> to have the ADSL modem (or AP) automatically use the fastest possible data rate and enable the Auto-Fallback feature. Auto-Fallback will negotiate the best possible connection speed between the AP and a wireless client. The default setting is <i>Auto</i> .
<b>Preamble Type</b>	The Preamble Type defines the length of the CRC (Cyclic Redundancy Check) block for communication between the AP and mobile wireless stations. Make sure to select the appropriate preamble type. Note that high network traffic areas should use the <i>short preamble</i> type. CRC is a common technique for detecting data transmission errors.
<b>Broadcast SSID</b>	If this option is enabled, the device will automatically transmit their network name (SSID) into open air at regular interval. This feature is intended to allow clients to dynamically discover and roam between WLANs; if this option is disabled, the device will hide its SSID. When this is done, the station cannot directly discover its

---

	WLAN and MUST be configure with the SSID. Note that in a home Wi-Fi network, roaming is largely unnecessary and the SSID broadcast feature serves no useful purpose. You should disable this feature to improve the security of your WLAN.
<b>Relay Blocking</b>	When <b>Relay Blocking</b> is enabled, wireless clients will not be able to directly access other wireless clients.
<b>VMM support</b>	WMM is a QoS solution with industry-wide support that offers strong interoperability, meets the requirements of all market segments, and has global reach. It is available now and will be interoperable with 802.11e. The Wi-Fi Alliance has launched a WMM certification program that establishes a solid foundation for the growth of the Wi-Fi multimedia market, and that facilitates the development of interoperable devices and applications with QoS capabilities. At the same time, WMM greatly improves the enduser experience and enables a wider, more efficient use of Wi-Fi networks everywhere.

Function buttons in this page:

### **Apply Changes**

Click to commit changes.

#### **4.4.3. Security**

This screen allows you to setup the wireless security. Turn on WEP or WPA by using encryption keys could prevent any unauthorized access to your WLAN. Please refer to the section – **Security** for details.

**TECOM ADSL Router**

**Wireless Security Setup**

This page allows you setup the wireless security. Turn on WEP or WPA by using Encryption Keys could prevent any unauthorized access to your wireless network.

**Encryption:**

- WEP
- WPA (TKIP)
- WPA (AES)
- WPA2 (TKIP)
- WPA2 (AES)

Use 802.1x Authentication

WEP 64bits     WEP 128bits

**WPA Authentication Mode:**

Enterprise (RADIUS)     Personal (Pre-Shared Key)

**Pre-Shared Key Format:**

**Pre-Shared Key:**

**Authentication Server:** Port  IP address  Password

*Note: When encryption WEP is selected, you must set WEP key value.*

Fields in this page:

Field	Description
<b>Encryption</b>	<p>There are 5 types of security to be selected. To secure your WLAN, it's strongly recommended to enable this feature.</p> <p><b>WEP:</b> Make sure that all wireless devices on your network are using the same encryption level and key. Click <i>Set WEP Key</i> button to set the encryption key.</p> <p><b>WPA (TKIP):</b> WPA uses Temporal Key Integrity Protocol (TKIP) for data encryption. TKIP utilized a stronger encryption method and incorporates Message Integrity Code (MIC) to provide protection against hackers.</p> <p><b>WPA(AES):</b> WPA uses Advanced Encryption Standard (AES) for data encryption, AES is hardware driven and it's better than TKIP</p> <p><b>WPA2 (TKIP):</b> WPA2 was released and replaces WPA, but is not compatible with older routers and wireless cards. Uses Temporal Key Integrity Protocol (TKIP) for data encryption. TKIP is software driven.</p> <p><b>WPA2 (AES):</b> WPA2, also known as 802.11i, uses Advanced Encryption Standard (AES) for data encryption. AES utilized a symmetric 128-bit block data encryption.</p> <p><b>Note:</b> The AP also can support WPA+WPA2, TKIP+AES for data encryption. The</p>

	actual selection of the encryption methods will depend on the clients, but we <b>recommends</b> WPA2 with AES as the most advanced security protection available
<b>Use 802.1x Authentication</b>	Check it to enable 802.1x authentication. This option is selectable only when the "Encryption" is choose to either <i>None</i> or <i>WEP</i> . If the "Encryption" is <i>WEP</i> , you need to further select the WEP key length to be either <i>WEP 64bits</i> or <i>WEP 128bits</i> .
<b>WPA Authentication Mode</b>	There are 2 types of authentication mode for WPA. <b>WPA-RADIUS:</b> WPA RADIUS uses an external RADIUS server to perform user authentication. To use WPA RADIUS, enter the IP address of the RADIUS server, the RADIUS port (default is 1812) and the shared secret from the RADIUS server. Please refer to "Authentication RADIUS Server" setting below for RADIUS setting. The WPA algorithm is selected between TKIP and AES, please refer to "WPA cipher Suite" below. <b>Pre-Shared Key:</b> Pre-Shared Key authentication is based on a shared secret that is known only by the parties involved. To use WPA Pre-Shared Key, select key format and enter a password in the "Pre-Shared Key Format" and "Pre-Shared Key" setting respectively. Please refer to "Pre-Shared Key Format" and "Pre-Shared Key" setting below.
<b>Pre-Shared Key Format</b>	<b>PassPhrase:</b> Select this to enter the Pre-Shared Key secret as user-friendly textual secret. <b>Hex (64 characters):</b> Select this to enter the Pre-Shared Key secret as hexadecimal secret.
<b>Pre-Shared Key</b>	Specify the shared secret used by this Pre-Shared Key. If the "Pre-Shared Key Format" is specified as <i>PassPhrase</i> , then it indicates a passphrase of 8 to 63 bytes long; or if the "Pre-Shared Key Format" is specified as <i>PassPhrase</i> , then it indicates a 64-hexadecimal number.
<b>Authentication RADIUS Server</b>	If the <i>WPA-RADIUS</i> is selected at "WPA Authentication Mode", the port (default is 1812), IP address and password of external RADIUS server are specified here.

Function buttons in this page:

### Apply Changes

Click to commit changes.

#### 4.4.4. Access Control

This page allows administrator to have access control by enter MAC address of client stations. When Enable this function, MAC address can be added into access control list and only those clients whose wireless MAC address are in the access control list will be able to connect to your DSL device (or AP). Please refer to the section – **Access control** for details.

**TECOM** **ADSL Router**

**Wireless Access Control**

If you choose 'Allowed Listed', only those clients whose wireless MAC addresses are in the access control list will be able to connect to your Access Point. When 'Deny Listed' is selected, these wireless clients on the list will not be able to connect the Access Point.

---

**Wireless Access Control Mode:**

---

**MAC Address:**  (ex. 00E086710502)

**Current Access Control List:**

MAC Address	Select

Fields in this page:

Field	Description
Wireless Access Control Mode	The Selections are: <b>Disable</b> Disable the wireless ACL feature. <b>Allow Listed</b> When this option is selected, no wireless clients except those whose MAC addresses are in the current access control list will be able to connect (to this device). <b>Deny Listed</b> When this option is selected, all wireless clients except those whose MAC addresses are in the current access control list will be able to connect (to this device).
MAC Address	Enter client MAC address and press "Apply Changes" button to add client MAC address into current access control list.

Function buttons in this page:

**Apply Changes**

Click to commit changes.

### **Add**

Click to add this entry into the **Current Access Control List**.

### **Reset**

It restores the original values

The **Current Access Control List** lists the client MAC addresses. Any wireless client with its MAC address listed in this access control list will be able to connect to the device. You can select the entries at the Select column and apply to the following function buttons.

Function buttons for the **Current Access Control List**:

### **Delete Selected**

Delete the selected entries from the list.

### **Delete All**

Flush the list.

## **4.4.5. WPS**

Although home Wi-Fi networks have become more and more popular, users still have trouble with the initial set up of network. This obstacle forces users to use the open security and increases the risk of eavesdropping. Therefore, The Wi-Fi Protected Setup (WPS) is designed to ease set up of security-enabled Wi-Fi networks and subsequently network management (Wi-Fi Protected Setup Specification 1.0h.pdf, p. 8).

The largest difference between WPS-enabled devices and legacy devices is that users do not need the knowledge about SSID, channel and security settings, but they could still surf in a security-enabled Wi-Fi network.

This device supports Push Button method and PIN method for WPS. The following sub-paragraphs will describe the function of each item. The webpage is as below.

**TECOM ADSL Router**

**Wi-Fi Protected Setup**

This page allows you to change the setting for WPS (Wi-Fi Protected Setup). Using this feature could let your wireless client automatically synchronize its setting and connect to the Access Point in a minute without any hassle.

**Disable WPS**

**WPS Status:**  Configured  UnConfigured

**Self-PIN Number:**

**Push Button Configuration:**

**Current Key Info:**

Authentication	Encryption	Key
WPA PSK	TKIP	dwFGZDMPj1FLrJS/HthF

**Client PIN Number:**

Fields in this page:

Field	Description
<b>Disable WPS</b>	Check to disable the Wi-Fi protected Setup.
<b>WPS Status</b>	When AP's settings are factory default (out of box), it is set to open security and un-configured state. "WPS Status" will display it as "UnConfigured". If it already shows "Configured", some registrars such as Vista WCN will not configure AP. Users will need to go to the "Backup/Restore" page and click "Reset" to reload factory default settings.
<b>Self-PIN Number</b>	"Self-PIN Number" is AP's PIN. Whenever users want to change AP's PIN, they could click "Regenerate PIN" and then click "Apply Changes". Moreover, if users want to make their own PIN, they could enter four-digit PIN without checksum and then click "Apply Changes". However, this would not be recommended since the registrar side needs to be supported with four-digit PIN.
<b>Push Button Configuration</b>	Clicking this button will invoke the PBC method of WPS. It is only used when AP acts as a registrar.
<b>Client PIN Number</b>	It is only used when users want their station to join AP's network. The length of PIN is limited to four or eight numeric digits. If users enter eight-digit PIN with

	checksum error, there will be a warning message popping up. If users insist on this PIN, AP will take it.
--	---

Function buttons in this page:

**Regenerate PIN**

Click to regenerate the Self-PIN Number.

**Start PBC**

Click to start the Push Button method of WPS.

**Apply Changes**

Click to commit changes.

**Reset**

It restores the original values.

**Start PIN**

Click to start the PIN method of WPS.


## 4.5. WAN Configuration

There are three sub-menus for WAN configuration: [Channel Comfit], [ATM Settings], and [ADSL Settings].

### 4.5.1. Channel Configuration

ADSL modem/router comes with 8 ATM Permanent Virtual Channels (PVCs) at the most. There are mainly three operations for each of the PVC channels: add, delete and modify. And there are several channel modes to be selected for each PVC channel. For each of the channel modes, the setting is quite different accordingly. Please refer to the section – **Channel Mode Configuration** for details.





# ADSL Router

**WAN Configuration**

This page is used to configure the parameters for the channel operation modes of your ADSL Modem/Router.

---

VPI:  :  Encapsulation:  LLC  VC-MUX Channel Mode:

Enable NAPT:  Admin Status:  Enable  Disable

Enable IGMP:  Enable QoS:

---

PPP Settings: User Name:  Password:

Type:  Idle Time (min):

---

WAN IP Settings: Type:  Fixed IP  DHCP

Local IP Address:  Remote IP Address:

Subnet Mask:  Unnumbered

Default Route:  Disable  Enable

**Current ATM VC Table:**

Select	Inf	Mode	VPI	VCI	Encap	NAPT	IGMP	IP QoS	IP Addr	Remote IP	Subnet Mask	User Name	DRoute	Status	Actions
<input type="radio"/>	ppp0_vc0	PPPoE	8	32	LLC	On	Off	On				adslppp@telefonica.netpa	On	Enable	<input type="button" value="edit"/> <input type="button" value="del"/>
<input type="radio"/>	ppp1_vc1	PPPoE	8	36	LLC	On	Off	Off				tec02002@telefonica.netpi	On	Enable	<input type="button" value="edit"/> <input type="button" value="del"/>

Enable Auto-PVC Search

VPI:  VCI:

**Current Auto-PVC Table:**

PVC	VPI	VCI
-----	-----	-----

### Function buttons in this page:

#### **Add**

Click **Add** to complete the channel setup and add this PVC channel into configuration.

#### **Modify**

Select an existing PVC channel by clicking the radio button at the **Select** column of the **Current ATM VC Table** before we can modify the PVC channel. After selecting a PVC channel, we can modify the channel configuration at this page. Click **Modify** to complete the channel modification and apply to the configuration.


#### **Delete**

Select an existing PVC channel to be deleted by clicking the radio button at the **Select** column of the **Current ATM VC Table**. Click **Delete** to delete this PVC channel from configuration.

### 4.5.2. ATM Setting

The page is for ATM PVC QoS parameters setting. The DSL device support 4 QoS

mode —UBR/CBR/rt-VBR/nrt-VBR.



Fields in this page:

Field	Description
VPI	Virtual Path Identifier. This is read-only field and is selected on the <b>Select</b> column in the Current ATM VC Table.
VCI	Virtual Channel Identifier. This is read-only field and is selected on the <b>Select</b> column in the Current ATM VC Table. The VCI, together with VPI, is used to identify the next destination of a cell as it passes through to the ATM switch.
QoS	Quality of Server, a characteristic of data transmission that measures how accurately and how quickly a message or data is transferred from a source host to a destination host over a network. The four QoS options are: <ul style="list-style-type: none"> <li>– UBR (Unspecified Bit Rate): When UBR is selected; the SCR and MBS fields are disabled.</li> <li>– CBR (Constant Bit Rate): When CBR is selected; the SCR and MBS fields are disabled.</li> <li>– nrt-VBR (non-real-time Variable Bit Rate): When nrt-VBR is selected, the SCR and MBS fields are enabled.</li> <li>– rt-VBR (real-time Variable Bit Rate): When rt-VBR is selected, the SCR and MBS fields are enabled.</li> </ul>
PCR	Peak Cell Rate, measured in cells/sec., is the cell rate which the source may never exceed.

<b>SCR</b>	Sustained Cell Rate, measured in cells/sec., is the average cell rate over the duration of the connection.
<b>MBS</b>	Maximum Burst Size, a traffic parameter that specifies the maximum number of cells that can be transmitted at the peak cell rate.

Function buttons in this page:

**Apply Changes**

Set new PVC QoS mode for the selected PVC. New parameters will take effect after save into flash memory and reboot the system. See section “Admin” for save details.

**Undo**

Discard your settings.

**4.5.3. ADSL Setting**

The ADSL setting page allows you to select any combination of DSL training modes.

The screenshot shows the 'ADSL Router' configuration interface. On the left is a navigation tree with 'Site contents' expanded to show 'ADSL Settings'. The main content area is titled 'ADSL Settings' and contains the following options:

- ADSL modulation:**
  - G.Lite
  - G.Dmt
  - T1.413
  - ADSL2
  - ADSL2+
- AnnexL Option:** (Note: Only ADSL 2 supports AnnexL)
  - Enabled
- AnnexM Option:** (Note: Only ADSL 2/2+ support AnnexM)
  - Enabled
- ADSL Capability:**
  - Bitswap Enable
  - SRA Enable
- ADSL Tone:**
  - Tone Mask

At the bottom of the settings area is an 'Apply Changes' button.

Fields in this page:

Field	Description
<b>ADSL modulation</b>	Choose preferred xDSL standard protocols. G.lite : G.992.2 Annex A G.dmt : G.992.1 Annex A T1.413 : T1.413 issue #2 ADSL2 : G.992.3 Annex A ADSL2+ : G.992.5 Annex A
<b>AnnexL Option</b>	Enable/Disable ADSL2/ADSL2+ Annex L capability.
<b>AnnexM Option</b>	Enable/Disable ADSL2/ADSL2+ Annex M capability.
<b>ADSL Capability</b>	“Bit-swap Enable” : Enable/Disable bit-swap capability. “SRA Enable” : Enable/Disable SRA (seamless rate adaptation) capability.

Function buttons in this page:**Tone Mask**

Choose tones to be masked. Masked tones will not carry any data.

**Apply Changes**


Click to save the setting to the configuration and the modem will be retrained.

**4.6. Services Configuration**

There are four sub-menus for Services: [DHCP Settings], [DNS], [IGMP Proxy] and [RIP].

**4.6.1. DHCP Settings**

You can configure your network and DSL device to use the Dynamic Host Configuration Protocol (DHCP). This page provides DHCP instructions for implementing it on your network by selecting the role of DHCP protocol that this device wants to play. There are two different DHCP roles that this device can act as: DHCP Serve and DHCP Relay. When acting as DHCP server, you can setup the server parameters at the **DHCP Server** page; while acting as DHCP Relay, you can setup the relay at the **DHCP Relay** page.



## ADSL Router

**Site contents:**

- [-] Status
- [-] LAN
- [-] Wireless
- [-] WAN
- [-] Services
  - [-] DHCP Settings
  - [-] DNS
  - [-] IGMP Proxy
  - [-] RIP
- [-] Firewall
- [-] Advance
- [-] Diagnostic
- [-] Admin
- [-] Statistics

### DHCP Settings

This page be used to configure DHCP Server and DHCP Relay.

---

**DHCP Mode:**  None  DHCP Relay  DHCP Server

---

**DHCP Server**  
 Enable the DHCP Server if you are using this device as a DHCP server. This page lists the IP address pools available to hosts on your LAN. The device distributes numbers in the pool to hosts on your network as they request Internet access.

---

**LAN IP Address:** 192.168.1.1    **Subnet Mask:** 255.255.255.0

**IP Pool Range:**  -

**Subnet Mask:**

**Max Lease Time:**  seconds (-1 indicates an infinite lease)

**Domain Name:**

**Gateway Address:**

---

**CONF to PCs:**

**DNS option:**  Use DNS Relay  Set Manually

**DNS1:**

**DNS2:**

**DNS3:**

#### 4.6.1.1. DHCP Server Configuration

By default, the device is configured as a DHCP server, with a predefined IP address pool of 192.168.1.33 through 192.168.1.254 (subnet mask 255.255.255.0).

4.6.1.2. Basic Settings

**TECOM ADSL Router**

**DHCP Settings**

This page be used to configure DHCP Server and DHCP Relay.

**DHCP Mode:**  None  DHCP Relay  DHCP Server

**DHCP Server**  
 Enable the DHCP Server if you are using this device as a DHCP server. This page lists the IP address pools available to hosts on your LAN. The device distributes numbers in the pool to hosts on your network as they request Internet access.

**LAN IP Address:** 192.168.1.1 **Subnet Mask:** 255.255.255.0

**IP Pool Range:** 192.168.1.33 - 192.168.1.254

**Subnet Mask:** 255.255.255.0

**Max Lease Time:** 86400 seconds (-1 indicates an infinite lease)

**Domain Name:** domain.name

**Gateway Address:** 192.168.1.1

**CONF to PCs:**

**DNS option:**  Use DNS Relay  Set Manually

**DNS1:** 80.58.61.250

**DNS2:** 80.58.61.254

**DNS3:**

Fields in this page:

Field	Description
<b>IP Pool Range</b>	Specify the lowest and highest addresses in the pool.
<b>Max Lease Time</b>	The Lease Time is the amount of time that a network user is allowed to maintain a network connection to the device using the current dynamic IP address. At the end of the Lease Time, the lease is either renewed or a new IP is issued by the DHCP server. The amount of time is in units of seconds. The default value is 86400 seconds (1 day). The value -1 stands for the infinite lease.
<b>Domain Name</b>	A user-friendly name that refers to the group of hosts (subnet) that will be assigned addresses from this pool.

Function buttons in this page:

**Apply Changes**

Set new DHCP server configuration. New parameters will take effect after save into flash memory and reboot the system. See section “Admin” for save details.

#### 4.6.1.3. Show Client

User can find the DHCP client which get IP from the device from “**Active DHCP Client Table**” page, to check those information please click the “**Show Client**” button on the **Basic Settings** page, then the “Active DHCP Client Table” page” will show.

#### Active DHCP Client Table

This table shows the assigned IP address, MAC address and time expired for each DHCP leased client.

IP Address	MAC Address	Time Expired(s)	Interface Type
None	----	----	----



Function buttons in this page:

#### Refresh

Click to refresh this table to get the updating information for DHCP clients.

#### Close

Click to close the current page.

#### 4.6.1.4. MAC-Based Assignment

### Static IP Assignment Table

This page is used to configure the static IP base on MAC Address. You can assign/delete the static IP. The Host MAC Address, please input a string with hex number. Such as “00-d0-59-c6-12-43”. The Assigned IP Address, please input a string with digit. Such as “192.168.1.100”.

Host **MAC Address** (**xx-xx-xx-xx-xx-xx**):

Assigned **IP Address** (**xxx.xxx.xxx.xxx**):




**MAC-Base Assignment Table:**

Select	Host MAC Address	Assigned IP Address
--------	------------------	---------------------

Fields in this page:

Field	Description
Host MAC Address	Specify the unique identifier of a device in this field.
Assigned IP Address	Specify one IP for a given device.

Function buttons in this page:

**Assign IP**

Assign an IP to a specifically Device . New parameters will take effect after save into flash memory and reboot the system. See section “Admin” for save details.

**Delete Assigned IP**

Delete selected Assigned IP from the MAC-base Assignment table. You can click the checkbox at the **Select** column to select the filtering rule.

**Closed**

Close this configuration page.

4.6.1.5. *Device IP Range*

## Device IP Range Table

This page is used to configure the IP address range based on device type.

device name:

start address:

end address:

gateway address:

option60:

device type:

reserved option:

option string:

**IP Range Table:**

Select	device name	device type	start address	end address	gateway address	option60	reserved option
--------	-------------	-------------	---------------	-------------	-----------------	----------	-----------------

Fields in this page:

Field	Description
<b>Option 60</b>	To identify the vendor and functionality of a DHCP client. The information is a variable-length string of characters or octets which has a meaning specified by the vendor of the DHCP client. One method that a DHCP client can utilize to communicate to the server that it is using a certain type of hardware or firmware is



	to set a value in its DHCP requests called the Vendor Class Identifier
<b>Device type</b>	User can define the client type such as PC, Camera, HGW, STB, Phone and Unknow device.
<b>Reserved Option</b>	It includes Option 241, 242, 243, 244, 245, which will be used to send information to the DHCP client.

Function buttons in this page:

**Add**

Click to save the rule entry to the configuration.

**Delete**

Delete selected setting from the IP range table. You can click the checkbox at the **Select** column to select the filtering rule.

**Modify**


Change selected setting from the IP range table. You can click the checkbox at the **Select** column to select the filtering rule.

**Closed**

Close this configuration page.

4.6.1.6. *DHCP Relay Configuration*

Some ISPs perform the DHCP server function for their customers' home/small office network. In this case, you can configure this device to act as a DHCP relay agent. When a host on your network requests Internet access, the device contacts your ISP to obtain the IP configuration, and then forward that information to the host. You should set the DHCP mode after you configure the DHCP relay.



Fields in this page:

Field	Description
<b>DHCP Server Address</b>	Specify the IP address of your ISP's DHCP server. Requests for IP information from your LAN will be passed to the default gateway, which should route the request appropriately.

Function button in this page

### Apply Changes


Click to save the setting to the configuration.

## 4.6.2. DNS Configuration

There are two submenus for the DNS Configuration: [DNS Server] and [Dynamic DNS]

### DNS Server

This page is used to select the way to obtain the IP addresses of the DNS servers.



Fields in this page:

Field	Description
<b>Attain DNS Automatically</b>	Select this item if you want to use the DNS servers obtained by the WAN interface via the auto-configuration mechanism.
<b>Set DNS Manually</b>	Select this item to configure up to three DNS IP addresses.

Function buttons in this page:

## Apply Changes

Set new DNS relay configuration. New parameters will take effect after save into flash memory and reboot the system. See section “Admin” for save details.

## Reset Selected

Discard your changes.

## Dynamic DNS

Each time your device connects to the Internet, your ISP assigns a different IP address to your device. In order for you or other users to access your device from the WAN-side, you need to manually track the IP that is currently used. The Dynamic DNS feature allows you to register your device with a DNS server and access your device each time using the same host name. The **Dynamic DNS** page allows you to enable/disable the Dynamic DNS feature.

**Dynamic DNS Configuration**

This page is used to configure the Dynamic DNS address from DynDNS.org or TZO. Here you can Add/Remove to configure Dynamic DNS.

**Enable:**

**DDNS provider:** DynDNS.org

**Hostname:**

**DynDns Settings:**

**Username:**

**Password:**

**TZO Settings:**

**Email:**

**Key:**

**Dynamic DDNS Table:**

Select	state	Hostname	Username	Service
--------	-------	----------	----------	---------

On the **Dynamic DNS** page, configure the following fields:

Field	Description
<b>Enable</b>	Check this item to enable this registration account for the DNS server.
<b>DDNS provider</b>	There are two DDNS providers to be selected in order to register your device with: DynDNS and TZO. A charge may occur depends on the service you select.
<b>Hostname</b>	Domain name to be registered with the DDNS server.
<b>Interface</b>	This field defaults to your device's WAN interface over which your device will be accessed.
<b>Username</b>	User-name assigned by the DDNS service provider.
<b>Password</b>	Password assigned by the DDNS service provider.

Function buttons in this page:

### **Add**

Click Add to add this registration into the configuration.

### **Modify**

Select an entry in **Dynamic DNS Table**. Press “Modify” after change to apply settings.

### **Remove**

Select an existing DDNS registration by clicking the radio button at the **Select** column of the **Dynamic DNS Table**. Click **Remove** button to remove the selected registration from the configuration.

## **4.6.3. IGMP Proxy Configuration**

Multicasting is useful when the same data needs to be sent to more than one hosts. Using multicasting as opposed to sending the same data to the individual hosts uses less network bandwidth. The multicast feature also enables you to receive multicast video stream from multicast servers.

IP hosts use Internet Group Management Protocol (IGMP) to report their multicast group memberships to neighboring routers. Similarly, multicast routers use IGMP to discover which of their hosts belong to multicast groups. This device supports IGMP proxy that handles IGMP messages. When enabled, this device acts as a proxy for a LAN host making requests to join and leave multicast groups, or a multicast router sending multicast packets to multicast group on the WAN side.

When a host wishes to join a multicast group, it sends IGMP REPORT message to the device's IGMP downstream interface. The proxy sets up a multicast route for the interface and host requesting the video content. It then forwards the Join to the upstream multicast router. The multicast IP traffic will then be forwarded to the requesting host. On a leave, the proxy removes the route and then forwards the leave to the upstream multicast router.

The IGMP Proxy page allows you to enable multicast on WAN and LAN interfaces. The LAN interface is always served as downstream IGMP proxy, and you can configure one of the available WAN interfaces as the upstream IGMP proxy.

- Upstream: The interface that IGMP requests from hosts is sent to the multicast router. User can specify IGMP Proxy Upstream interface in the “WAN->Channel Config” page.
- Downstream: The interface data from the multicast router are sent to hosts in the multicast group database.

**TECOM** *ADSL Router*

**IGMP Proxy Configuration**

IGMP proxy enables the system to issue IGMP host messages on behalf of hosts that the system discovered through standard IGMP interfaces. The system acts as a proxy for its hosts when you enable it by doing the follows:

- . Enable IGMP proxy on WAN interface (upstream), which connects to a router running IGMP.
- . Enable IGMP on LAN interface (downstream), which connects to its hosts.

---

**IGMP Proxy:**  Disable  Enable

#### Fields in this page:

Field	Description
<b>IGMP Proxy</b>	Enable/disable IGMP proxy feature

#### Function buttons in this page:

##### **Apply Changes**

Click to save the setting to the configuration.

##### **Undo**

Discard your settings.

#### **4.6.4. RIP Configuration**

RIP is an Internet protocol you can set up to share routing table information with other routing devices on your LAN, at your ISP's location, or on remote networks connected to your network via the ADSL line.

Most small home or office networks do not need to use RIP; they have only one router, such as the ADSL Router, and one path to an ISP. In these cases, there is no need to share routes, because all Internet data from the network is sent to the same ISP gateway.

You may want to configure RIP if any of the following circumstances apply to your network:

- Your home network setup includes an additional router or RIP-enabled PC (other than the ADSL Router). The ADSL Router and the router will need to communicate via RIP to share their routing tables.
- Your network connects via the ADSL line to a remote network, such as a corporate network. In order for your LAN to learn the routes used within your corporate

network, they should both be configured with RIP.

- Your ISP requests that you run RIP for communication with devices on their network.

Fields on the first setting block:

Field	Description
RIP	Enable/disable RIP feature.

Function buttons for the second setting block in this page:

### Apply Changes

Click to save the setting of this setting block to the system configuration

Fields on the second setting block:

Field	Description
Interface	The name of the interface on which you want to enable RIP.
Receive Mode	Indicate the RIP version in which information must be passed to the DSL device in order for it to be accepted into its routing table.
Send Mode	Indicate the RIP version this interface will use when it sends its route information to other devices.

Function buttons for the second setting block in this page:

### Add

Add a RIP entry and the new RIP entry will be display in the table

### Delete Selected

Delete a selected RIP entry. The RIP entry can be selected on the **Select** column of the **RIP Configuration Table**.

### Delete all

Delete all RIP entries on the RIP Configuration Table.

## 4.7. Firewall

Firewall contains several features that are used to deny or allow traffic from passing through the device.

### 4.7.1. IP/Port Filter

The IP/Port filtering feature allows you to deny/allow specific services or applications in the forwarding path.

#### 4.7.1.1. Filter List

The Filter List feature allows you to set the IP/Port Firewall Configuration.

The screenshot shows the web interface for the TECOM ADSL Router. The left sidebar contains a navigation menu with the following items: Site contents, Status, LAN, Wireless, WAN, Services, Firewall (expanded), IP/Port Filter (selected), Filter List, Filter Rule, MAC Filtering, Port Forwarding, URL Blocking, Domain Blocking, DMZ, Advance, Diagnostic, Admin, and Statistics. The main content area is titled "IP/Port Firewall Config" and "IP/Port Firewall Configuration". It features a table titled "IP/Port Filter LIST" with the following data:

Name	Interface	Type	Default Action	Remove
wan_in	WAN	In	Permit	<input type="checkbox"/>
wan_out	WAN	Out	Permit	<input type="checkbox"/>

Below the table are "Add" and "Remove" buttons. The configuration section includes the following fields:

- Firewall Name :
- Firewall Interface :
- Firewall Type :
- Firewall Default Action :

At the bottom of the configuration section are "Apply" and "Cancel" buttons.

---

Fields in this page:

Field	Description
<b>Firewall Name</b>	Specify the filter name for this settings
<b>Firewall Interface</b>	Select the interface for this settings, user can set the interface to WAN, LAN.
<b>Firewall Type</b>	Specify this setting is for outgoing packets or incoming packets.
<b>Firewall Default Action</b>	Specify the default action for this settings, drop or permit.

Function button for this page:

**Add**

Click to add a new setting.

**Remove**

Click to delete the selected settings.

**Apply**

Click to save the setting of default actions to the configuration.


**Cancel**

Discard your settings.

*4.7.1.2. Filter Rule*

The Filter Rule that are used to restrict certain types of data packets through the Gateway.





## IP/Port Filtering Rule

Entries in this table are used to restrict certain types of data packets through the Gateway. Use of such filters can be helpful in securing or restricting your local network.

**Firewall Name:**

**Firewall Interface :**

**Firewall Type :**

---

**Protocol:** 
**Rule Action**

**RejectType:** 
**ICMPType**

**Source IP Address:** 
**Subnet Mask:** 
**Port:**

**Destination IP Address:** 
**Subnet Mask:** 
**Port:**

Current Filter Table:

Select	Firewall	Protocol	RejectType	IcmpType	Src Address	Src Port	Dst Address	Dst Port	Rule Action
<input type="checkbox"/>	WAN_In	TCP			193.152.37.192/28			21-27	Permit
<input type="checkbox"/>	WAN_In	TCP			80.58.63.128/25			21-23	Permit
<input type="checkbox"/>	WAN_In	TCP			172.20.25.0/24			21-23	Permit
<input type="checkbox"/>	WAN_In	TCP			172.20.15.0/24			21-23	Permit
<input type="checkbox"/>	WAN_In	TCP						21-23	Deny
<input type="checkbox"/>	WAN_In	TCP						80	Deny

### Fields on this page:

Field	Description
<b>Firewall Name</b>	The Firewall name is the same which you configured on the "Filter List" page. Click the comboBox to find all the settings which you set on "Filter List" page.
<b>Protocol</b>	There are 3 options available: TCP, UDP and ICMP.
<b>Rule Action</b>	There are 3 options available: Drop, Permit and Reject
<b>Reject Type</b>	If the <b>Rule Action</b> has been set to Reject, then this option can be set. Otherwise it will be black.
<b>ICMP Type</b>	If the <b>Protocol</b> has been set to <b>ICMP</b> , then this option can be set. Otherwise it will be black.
<b>Source IP Address</b>	The source IP address assigned to the traffic on which filtering is applied.
<b>Src Subnet Mask</b>	Subnet-mask of the source IP.
<b>Src Port</b>	Starting and ending source port numbers.
<b>Destination IP Address</b>	The destination IP address assigned to the traffic on which filtering is applied.
<b>Dst Subnet Mask</b>	Subnet-mask of the destination IP.
<b>Dst Port</b>	Starting and ending destination port numbers.

Function button for this page:

**Add**

Click to add a new setting.

**Delete Selected**


Delete a selected Filter rule in the current filter table.

**Delete All**

Delete all the Filter rules in the current filter table.

**4.7.2. MAC Filter**

The MAC filtering feature allows you to define rules to allow or deny frames through the device based on source MAC address, destination MAC address, and traffic direction.



Fields on the first setting block:

Field	Description
Outgoing Interface from	Select the interface to apply the filter: Ethernet (ETH) or Wifi (WLAN)

<b>Outgoing Default Action</b>	Specify the default action on the LAN to WAN bridging/forwarding path.
<b>Incoming Default Action</b>	Specify the default action on the WAN to LAN bridging/forwarding path.

Function button for this first setting block:

### Apply Changes

Click to save the setting of default actions to the configuration.

Fields on the second setting block:

Field	Description
<b>Rule Action</b>	Deny or allow traffic when matching this rule.
<b>Direction</b>	Traffic bridging/forwarding direction.
<b>Src MAC Address</b>	The source MAC address. It must be xxxxxxxxxxxx format. Blanks can be used in the MAC address space and are considered as don't care.
<b>Dst MAC Address</b>	The destination MAC address. It must be xxxxxxxxxxxx format. Blanks can be used in the MAC address space and are considered as don't care.

Function buttons for this second setting block:

### Apply Changes

Click to save the rule entry to the configuration.

Function buttons for the **Current Filter Table**:

### Delete Selected

Delete selected filtering rules from the filter table. You can click the checkbox at the **Select** column to select the filtering rule.

### Delete All

Delete all filtering rules from the filter table.

### 4.7.3. Port Forwarding

Firewall keeps unwanted traffic from the Internet away from your LAN computers. Add a Port Forwarding entry will create a tunnel through your firewall so that the computers on the Internet can communicate to one of the computers on your LAN on a single port.

**TECOM** **ADSL Router**

**Port Forwarding**

Entries in this table allow you to automatically redirect common network services to a specific machine behind the NAT firewall. These settings are only necessary if you wish to host some sort of server like a web server or mail server on the private local network behind your Gateway's NAT firewall.

**Port Forwarding:**  Disable  Enable

**Protocol:**  **Comment:**   **Enable**

**Remote IP Address:**  **Public Port:**  -

**Local IP Address:**  **Local Port:**  -

**Interface:**

**Current Port Forwarding Table:**

Select	Local IP Address	Protocol	Local Port	Comment	Enable	Remote Host	Public Port	Interface
<input type="button" value="Delete Selected"/> <input type="button" value="Delete All"/>								

Fields in this page:

Field	Description
<b>Enable Port Forwarding</b>	Check this item to enable the port-forwarding feature.
<b>Protocol</b>	There are 3 options available: TCP, UDP and Both.
<b>Comment</b>	Specify the rule name.
<b>Enable</b>	Check this item to enable this entry.
<b>Remote IP Address</b>	The source IP address from which the incoming traffic is allowed. Leave blank for all.
<b>Public Port</b>	The destination port number that is made open for this application on the WAN-side
<b>Local IP Address</b>	IP address of your local server that will be accessed by Internet.
<b>Local Port</b>	The destination port number that is made open for this application on the LAN-side.
<b>Interface</b>	Select the WAN interface on which the port-forwarding rule is to be applied.

Function buttons for the setting block:

### Apply Changes

Click to save the rule entry to the configuration.

Function buttons for the **Current Port Forwarding Table**:

### Delete Selected


Delete the selected port forwarding rules from the forwarding table. You can click the checkbox at the **Select** column to select the forwarding rule.

### Delete All

Delete all forwarding rules from the forwarding table.

## 4.7.4. URL Blocking

The URL Blocking is the web filtering solution. The firewall includes the ability to block access to specific web URLs based on string matches. This can allow large members of URLs to be blocked by specifying only a FQDN (such as tw.yahoo.com). The URL Blocking enforces a Web usage policy to control content downloaded from, and upload to, the Web.



**TECOM** *ADSL Router*

Site contents:

- Status
- LAN
- Wireless
- WAN
- Services
- Firewall
  - IP/Port Filter
  - MAC Filtering
  - Port Forwarding
  - URL Blocking
  - Domain Blocking
  - DMZ
- Advance
- Diagnostic
- Admin
- Statistics

### URL Blocking Configuration

This page is used to configure the Blocked FQDN (Such as tw.yahoo.com) and filtered keyword. Here you can add/delete FQDN and filtered keyword.

**URL Blocking:**  Disable  Enable

**FQDN:**

**URL Blocking Table:**

Select	FQDN
<input type="checkbox"/>	

**Keyword:**

**Keyword Filtering Table:**

Select	Filtered Keyword
<input type="checkbox"/>	

Fields in this page:

Field	Description
<b>URL Blocking</b>	Check this item to enable the URL Blocking feature.
<b>FQDN</b>	A fully qualified domain name (or FQDN) is an unambiguous domain name that specifies the node's position in the DNS tree hierarchy absolutely, such as tw.yahoo.com. The FQDN will be blocked to access.
<b>Keywords</b>	The filtered keyword such as yahoo. If the URL includes this keyword. The URL will be blocked to access.

Function buttons in this page:**Apply Changes**

Click to disable/enable the URL blocking capability.

**Add FQDN**

Add FQDN into URL Blocking table.

**Add Keyword**

Add filtered keyword into Keyword Filtering table.

**Delete Selected**


Delete the selected settings; You can click the checkbox at the **Select** column to select the current rule.

**Delete All**

Delete all rules from the current table.

**4.7.5. Domain Blocking**

The firewall includes the ability to block access to specific domain based on string matches. For example, if the URL of Taiwan Yahoo web site is "tw.yahoo.com" and you enter "yahoo.com", the firewall will block all the DNS queries with "yahoo.com" string. So the Host will be blocked to access all the URLs belong to "yahoo.com" domain. That means you can protect your computer, your house, your office and anything else that uses DNS from being able to service domains that you don't want to load.



Fields in this page:

Field	Description
<b>Domain Blocking</b>	Check this item to enable the Domain Blocking feature.
<b>Domain</b>	The blocked domain. If the URL of Taiwan Yahoo web site is tw.yahoo.com, the domain can be yahoo.com.

Function buttons in this page:

**Apply Changes**

Click to disable/enable the Domain Block capability

**Add**

Add domain into Domain Block table.

**Delete Selected**

Delete the selected domain from the Domain Block table. You can click the checkbox at the Select column to select the Blocked domain.

**Delete All**

Delete all rules from the current table.

#### 4.7.6. DMZ

A DMZ (Demilitarized Zone) allows a single computer on your LAN to expose ALL of its ports to the Internet. Enter the IP address of that computer as a DMZ (Demilitarized Zone) host with unrestricted Internet access. When doing this, the DMZ host is no longer behind the firewall.

#### Fields in this page:

Field	Description
<b>Enable DMZ</b>	Check this item to enable the DMZ feature.
<b>DMZ Host IP Address</b>	IP address of the local host. This feature sets a local host to be exposed to the Internet.

#### Function buttons in this page:

##### Apply Changes

Click to save the setting to the configuration.



## 4.8. Advance Configuration

### 4.8.1. ARP table

You can see the show list of learned MAC addresses through ARP in this page.

The screenshot shows the TECOM ADSL Router web interface. On the left is a navigation tree with 'Advance' selected, containing sub-items like 'ARP table', 'Bridging', 'Routing', etc. The main content area is titled 'ARP Table' and contains the following text: 'This table shows a list of learned MAC addresses.' Below this is a table with two columns: 'IP Address' and 'MAC Address'. The table contains two rows of data. A 'Refresh' button is located below the table.

IP Address	MAC Address
172.16.2.1	14:12:11:12:21:B4
172.16.30.203	E0:CB:4E:19:B8:BB

### 4.8.2. Bridging

You can enable/disable Spanning Tree Protocol and set MAC address aging time in this page.

The screenshot shows the TECOM ADSL Router web interface. On the left is a navigation tree with 'Advance' selected, containing sub-items like 'ARP table', 'Bridging', 'Routing', etc. The main content area is titled 'Bridge Configuration' and contains the following text: 'This page is used to configure the bridge parameters. Here you can change the settings or view some information on the bridge and its attached ports.' Below this are configuration fields: 'Ageing Time' set to 300 (seconds), and '802.1d Spanning Tree' set to Disabled. There are three buttons at the bottom: 'Apply Changes', 'Undo', and 'Show MACs'.

Fields in this page:

Field	Description
<b>Ageing Time</b>	Set the Ethernet address ageing time, in seconds. After [Ageing Time] seconds of not having seen a frame coming from a certain address, the bridge will time out (delete) that address from Forwarding Database (fdb).
<b>802.1d Spanning Tree</b>	Enable/disable the spanning tree protocol

Function buttons in this page:**Apply Changes**

Save this bridge configuration. New configuration will take effect after saving into flash memory and rebooting the system. See section "Admin" for details.

**Undo**

Undo changes

**Show MACs**

List MAC address in the table.

**4.8.3. Routing**

The Routing page enables you to define specific route for your Internet and network data. Most users do not need to define routes. On a typical small home or office LAN, the existing routes that set up the default gateways for your LAN hosts and for the DSL device provide the most appropriate path for all your Internet traffic.

- On your LAN hosts, a default gateway directs all Internet traffic to the LAN port(s) on the DSL device. Your LAN hosts know their default gateway either because you assigned it to them when you modified your TCP/IP properties, or because you configured them to receive the information dynamically from a server whenever they access the Internet.
- On the DSL device itself, a default gateway is defined to direct all outbound Internet traffic to a route at your ISP. The default gateway is assigned either automatically by your ISP whenever the device negotiates an Internet access, or manually by user to setup through the configuration.

You may need to define routes if your home setup includes two or more networks or subnets, if you connect to two or more ISP services, or if you connect to a remote corporate LAN.

Fields in this page:

Field	Description
<b>Enable</b>	Check to enable the selected route or route to be added.
<b>Destination</b>	The network IP address of the subnet. The destination can be specified as the IP address of a subnet or a specific host in the subnet. It can also be specified as all zeros to indicate that this route should be used for all destinations for which no other route is defined (this is the route that creates the default gateway).
<b>Subnet Mask</b>	The network mask of the destination subnet. The default gateway uses a mask of 0.0.0.0.
<b>Next Hop</b>	The IP address of the next hop through which traffic will flow towards the destination subnet.
<b>Metric</b>	Defines the number of hops between network nodes that data packets travel. The default value is 0, which means that the subnet is directly one hop away on the local LAN network.
<b>Interface</b>	The WAN interface to which a static routing subnet is to be applied.

Function buttons in this page:

**Add Route**

Add a user-defined destination route.

**Update**

Update the selected destination route on the **Static Route Table**.

**Delete Selected**

Delete a selected destination route on the **Static Route Table**.

### Show Routes

Click this button to view the DSL device's routing table. The **IP Route Table** displays, as shown in Figure.

## IP Route Table

This table shows a list of destination routes commonly accessed by your network.

Destination	Subnet Mask	NextHop	Metric	Iface
192.168.249.0	255.255.255.252	*	0	br0
192.168.1.0	255.255.255.0	*	0	br0
127.0.0.0	255.255.255.0	*	0	lo



#### 4.8.4. SNMP Configuration

Simple Network Management Protocol (SNMP) is a troubleshooting and management protocol that uses the UDP protocol on port 161 to communicate between clients and servers. The DSL device can be managed locally or remotely by SNMP protocol

**TECOM** *ADSL Router*

### SNMP Protocol Configuration

This page is used to configure the SNMP protocol. Here you may change the setting for system description, trap ip address, community name, etc..

**SNMP:**  Disable  Enable

**System Description**

**System Contact**

**System Name**

**System Location**

**System Object ID**

**Trap IP Address**

**Community name (read-only)**

**Community name (write-only)**

Fields in this page:

Field	Description
<b>SNMP</b>	Click this feature to disable/enable the SNMP function.
<b>System Description</b>	System description of the DSL device.
<b>System Contact</b>	Contact person and/or contact information for the DSL device.
<b>System Name</b>	An administratively assigned name for the DSL device.
<b>System Location</b>	The physical location of the DSL device.
<b>System Object ID</b>	Vendors object identifier. The vendor's authoritative identification of the network management subsystem contained in the entity.
<b>Trap IP Address</b>	Destination IP address of the SNMP trap.
<b>Community name (read-only)</b>	Name of the read-only community. This read-only community allows read operation to all objects in the MIB.
<b>Community name (write-only)</b>	Name of the write-only community. This write-only community allows write operation to the objects defines as read-writable in the MIB.

Function buttons in this page:

**Apply Changes**

Save SNMP configuration. New configuration will take effect after saving into flash memory and rebooting the system. See section "Admin" for details.

**4.8.5. Port Mapping**

**TECOM ADSL Router**

Site contents:

- Status
- LAN
- Wireless
- WAN
- Services
- Firewall
- Advance
  - ARP table
  - Bridging
  - Routing
  - SNMP
  - Port Mapping
  - IP QoS
  - QoS Queue
  - Traffic Shape
  - Others
- Diagnostic
- Admin
- Statistics

To manipulate a mapping group:

1. Select a group from the table.
2. Select interfaces from the available/grouped interface list and add it to the grouped/available interface list using the arrow buttons to manipulate the required mapping of the ports.
3. Click "Apply Changes" button to save the changes.

**Note that the selected interfaces will be removed from their existing groups and added to the new group.**

Disabled     Enabled

**Grouped Interfaces**                      **Available Interfaces**

[Empty list box]                      [Empty list box]

[>]                      [<]

Select	Interfaces
Default	LAN1, LAN2, LAN3, LAN4, wlan0, ppp0, ppp1
<input type="radio"/>	
<input type="radio"/>	
<input type="radio"/>	
<input type="radio"/>	

[Apply Changes]

Fields in this page:

Field	Description
<b>Enable</b>	Check to enable the selected route or route to be added.
<b>Available Interfaces</b>	All Ethernet interface,PVC interface and wireless interface will show.
<b>Grouped Interfaces</b>	Group any interface in Available Interface column to this field.

Buttons in this page:

**Apply Changes**

Push to apply changes

**4.8.6. IP QoS**

QoS (Quality of service) is the ability to provide different priority to different applications, users, or data flows, or to guarantee a certain level of performance to a data flow. For example, a required bit rate, delay, jitter, packet dropping probability and/or bit error rate may be guaranteed. User can configure QoS parameters in the following page:

**IP QoS**

Entries in this table are used to assign the precedence for each incoming packet based on physical LAN port, TCP/UDP port number, and source/destination IP address/subnet masks.

IP QoS:  Disabled  Enabled Default QoS: IP Pred

**Specify Traffic Classification Rules**

Source IP:  Netmask:

Port:

Destination IP:  Netmask:  Port:

Protocol:  Physical Port:

**Assign Priority and/or IP Precedence and/or Type of Service and/or DSCP**

Classification Queue: (Click to Select) 802.1p:

Precedence:  TOS:

**IP QoS Rules:**

Traffic Classification Rules							Mark					
Select	Status	Src IP	Src Port	Dst IP	Dst Port	Protocol	Lan Port	Interface	Priority	IP Preced	IP ToS	Wan 802.1p
<input type="checkbox"/>	Enable			81.47.224.0/22		UDP		ppp0_vc0	p0			

Fields in this page:

Field	Description
<b>IP QoS</b>	Check to enable the IP QoS function.
<b>Default QoS</b>	IP Pred or 802.1p is to apply.
<b>Source IP</b>	Source IP for IP packet incoming from Ethernet
<b>Destination IP</b>	Source IP for IP packet incoming from Ethernet
<b>Netmask</b>	The network mask of the destination subnet. The default gateway uses a mask of 0.0.0.0.
<b>Port</b>	Port number is filled in this column.
<b>Protocol</b>	Which Protocol to apply? Protocol TCP, UDP and ICMP.
<b>Physical Port</b>	Which LAN interfaces to apply? LAN interface have LAN 1, LAN 2, LAN 3, LAN 4
<b>Clasiffication Queue</b>	Select the QoS classification Queue
<b>802.1p</b>	Mark 802.1p for incoming IP Packet.
<b>Precedence</b>	Mark IP precedence for incoming IP Packet.
<b>TOS</b>	Mark type of services for incoming IP Packet.

**4.8.7. QoS Queue**

User can set the QoS Queue in the QoS Queue page, when press the Add button, the below page will be shown to user:

The screenshot shows the 'IP QoS Queue Config' page in the router's web interface. On the left is a sidebar menu with 'Advance' expanded to show 'QoS Queue'. The main area has a title 'ADSL Router' and 'IP QoS Queue Config'. Below the title is 'QoS Queue Configuration'. A table titled 'QUEUE CONFIG LIST' shows one entry: 'ppp0\_vc0' with description '8\_32\_p0', precedence '0', queue key '1', and 'Enable' checked. Below the table are 'Add', 'Remove', and 'Save' buttons. Further down are form fields for 'Queue Description', 'Queue Status', 'Queue Interface', and 'Queue Priority', each with a '(Click to Select)' dropdown. At the bottom are 'Apply' and 'Cancel' buttons.

---

Fields in this page:

Field	Description
<b>Queue Description</b>	This description will generate automatically when user set the other option for QoS Queue.
<b>Queue Status</b>	Enable/Disable the Queue status
<b>Queue Interface</b>	Select one interface for this rule.
<b>Queue Priority</b>	Set the queue priority for this rule, the priority range is from 0 to 3.

Function buttons in this page:**Add**

Click to add one rule for QoS Queue.

**Apply**

Click to save the setting to the configuration.

**Cancel**

Discard your settings.

**4.8.8. Traffic Shape**

Traffic shaping allows you to control the traffic going out an interface in order to match its flow to the speed of the remote target interface and to ensure that the traffic conforms to policies contracted for it. Thus, traffic adhering to a particular profile can be shaped to meet downstream requirements, thereby eliminating bottlenecks in topologies with data-rate mismatches. Configure traffic shaping on an interface if you have a network with differing access rates, press Add button on Traffic Shape page you can find the flowing configuration page:



**TECOM** **ADSL Router**

Site contents:

- Status
- LAN
- Wireless
- WAN
- Services
- Firewall
- Advance
  - ARP table
  - Bridging
  - Routing
  - SNMP
  - Port Mapping
  - IP QoS
  - QoS Queue
  - Traffic Shape
  - Others
- Diagnostic
- Admin
- Statistics

### IP QoS Traffic Shaping

Entries in this table are used for traffic control. It only takes effect when ip qos is disabled.

---

**Interface Bandwidth Limitation Table:**  
 PPPoE interface:  kbps

---

**Traffic Shaping Rule Table:**

ID	WAN Inf	Protocol	Src Port	Dst Port	Src IP	Dst IP	rate(kb/s)	Delete
<input type="button" value="Add"/> <input type="button" value="Save/Apply"/>								

Interface:    
 Protocol:    
 Src IP:  Src Mask:    
 Dst IP:  Dst Mask:    
 Src Port:  Dst Port:    
 uplink rate:  kb/s

Fields in this page:

Field	Description
<b>Interface</b>	Select one interface for this rule.
<b>Protocol</b>	There are 5 options available: NONE, ICMP, TCP, UDP and TCP/UDP.
<b>Uplink rate</b>	Set the max uplink rate for one rule.

Function buttons in this page:

**Add**

Click to add one rule for Traffic Shape.

**Save**

Click to save the setting to the configuration.

**4.8.9. Others**

This advanced configuration allows user pass the WAN IP to the LAN side. For example, if the IP PassThrough function has been enabled for PPP0 interface, then the LAN PC which set as DHCP mode will get the IP which provided by ISP as the PPP0.

Fields in this page:

Field	Description
<b>IP PassThrough</b>	Enable/Select the WAN interface for IP PassTrough, and the interface can only be PPPOA or PPPoE.
<b>Lease Time</b>	Set the Lease time.
<b>Allow LAN Access</b>	Enable this function; other LAN PC can communicate with this PC which gets IP as PPP0.

Function buttons in this page:

**Apply changes**

Click to save the changes to the configuration.

## 4.9. Diagnostic

The DSL device supports some useful diagnostic tools.

### 4.9.1. Ping

Once you have your DSL device configured, it is a good idea to make sure you can ping the network. A ping command sends a message to the host you specify. If the host receives the message, it sends messages in reply. To use it, you must know the IP address of the host you are trying to communicate with and enter the IP address in the Host Address field. Click Go! To start the ping command, the ping result will then be shown in this page.

The screenshot shows the web interface of a TECOM ADSL Router. The top navigation bar is blue with the TECOM logo and the text 'ADSL Router'. On the left, a 'Site contents' menu lists various configuration options, with 'Diagnostic' highlighted. The main content area is titled 'Ping Diagnostic' and contains the following text: 'This page is used to send ICMP ECHO\_REQUEST packets to network host. The diagnostic result will then be displayed.' Below this text is a form with a label 'Host Address :' followed by an empty text input field. At the bottom of the form is a button labeled 'Go !'.

Fields in this page:

Field	Description
Host Address	The IP address you want to ping.

Function buttons in this page:

#### Go

Click to start the test.

### 4.9.2. ATM Loopback

In order to isolate the ATM interface problems, you can use ATM OAM loopback cells to verify connectivity between VP/VC endpoints, as well as segment endpoints within the VP/VC. ATM uses F4 and F5 cell flows as follows:


- F4: used in VPs

- F5: used in VCs

An ATM connection consists of a group of points. This OAM implementation provides management for the following points:

- Connection endpoint: the end of a VP/VC connection where the ATM cell are terminated
- Segment endpoint: the end of a connection segment

This page allows you to use ATM ping, which generates F5 segment and end-to-end loop-back cells to test the reachability of a segment endpoint or a connection endpoint.



Fields in this page:

Field	Description
<b>Select PVC</b>	Select the PVC channel you want to do the loop-back diagnostic.
<b>Flow Type</b>	The ATM OAM flow type. The selection can be F5 Segment or F5 End-to-End.
<b>Loopback Location ID</b>	The loop-back location ID field of the loop-back cell. The default value is all 1s (ones) to indicate the endpoint of the segment or connection.

Function buttons in this page:

**Go!**

Click to start the test.

**4.9.3. ADSL**

This page shows the ADSL diagnostic result. Click **Start** button to start the ADSL diagnostic.

**TECOM** **ADSL Router**

**Diagnostics -- ADSL**

Adsl Tone Diagnostics. Only ADSL2/2+ support this function.

	Downstream	Upstream
<b>Hlin Scale</b>		
<b>Loop Attenuation(dB)</b>		
<b>Signal Attenuation(dB)</b>		
<b>SNR Margin(dB)</b>		
<b>Attainable Rate(Kbps)</b>		
<b>Output Power(dBm)</b>		

Tone Number	H. Real	H. Image	SNR	QLN	Hlog
0					
1					
2					
3					
4					
5					
6					
7					
8					
9					
10					

#### 4.9.4. Diagnostic Test

The Diagnostic Test page shows the test results for the connectivity of the physical layer and protocol layer for both LAN and WAN sides.

**TECOM** **ADSL Router**

**Diagnostic Test**

The DSL Router is capable of testing your DSL connection. The individual tests are listed below. If a test displays a fail status, click "Run Diagnostic Test" button again to make sure the fail status is consistent.

Select the Internet Connection:

Fields in this page:

Field	Description
Select the Internet Connection	The available WAN side interfaces are listed. You have to select one for the WAN side diagnostic.

Function buttons in this page:**Run Diagnostic Test**

Click to start the diagnostic test for this WAN interface.

**4.9.5. CPU Usage**

This page shows CPU Usage result. Click **Refresh** button to start the CPU Usage detection.

**TECOM** *ADSL Router*

**CPU Diagnostic**

Simple CPU usage reporting page.

**CPU: busy 0% (system=0% user=0% nice=0% idle=100%)**

Site contents:

- Status
- LAN
- Wireless
- WAN
- Services
- Firewall
- Advance
- Diagnostic
  - Ping
  - ATM Loopback
  - ADSL
  - Diagnostic Test
  - CPU Usage
- Admin
- Statistics

Function buttons in this page:**Refresh**

Click to **Refresh** the test result for CPU.

**4.10. Admin****4.10.1. Commit / Reboot**

Whenever you use the Web configuration to change system settings, the changes are initially placed in temporary storage. These changes will be lost if the device is reset or turn off. To save your change for future use, you can use the commit function.



Function buttons in this page:

### **Commit and Reboot**


Whenever you use the web console to change system settings, the changes are initially placed in temporary storage. To save your changes for future use, you can use the Commit/Reboot function. This function saves your changes from RAM to flash memory and reboots the system.

### **IMPORTANT!**

Do not turn off your modem or press the Reset button while this procedure is in progress.

#### **4.10.2. Backup/Restore**

This page allows you to backup and restore your configuration into and from file in your host.



Function buttons in this page:

**Save**

Click to save the current configuration file.

**Upload**


Click to upload the configuration file.

**Reset**

Click to reset the device to factory settings.

**4.10.3. System Log**

This page will show the system log.





Fields in this page:

Field	Description
<b>System Log</b>	Enable/Disable the system log feature.
<b>Log Level</b>	Set the system log level.
<b>Display Level</b>	Select that which level log will be shown on the log page.

Function buttons in this page:**Apply Changes**

Click to save the setting of system log level to the configuration.

**Save**

Click to save the system log to the local PC.

**Reset**

Click to reset all the settings for system log, remove all the logs on the system log page.

**Refresh**

Click to refresh all the system logs.

**4.10.4. Password**

The first time you log into the system, you use the default password. There are two-level logins: **1234** and **user**. The **1234** and **user** password configuration allows you to change the password for administrator and user.

**TECOM** **ADSL Router**

**Site contents:**

- Status
- LAN
- Wireless
- WAN
- Services
- Firewall
- Advance
- Diagnostic
- Admin**
  - Commit/Reboot
  - Backup/Restore
  - System Log
  - Password
  - Upgrade Firmware
  - Time Zone
  - TR-069 Config
- Statistics

**Password Setup**

This page is used to set the account to access the web server of ADSL Router. Empty user name and password will disable the protection.

**User Name:**

**Old Password:**

**New Password:**

**Confirmed Password:**

Fields in this page:

Field	Description
User Name	Selection of user levels are: admin and user.
Old Password	Enter the old password for this selected login.
New Password	Enter the new password here.
Confirmed Password	Enter the new password here again to confirm.

#### 4.10.5. Upgrade Firmware

To upgrade the firmware for the DSL device:

- Click the **Browse** button to select the firmware file.
- Confirm your selection.
- Click the **Upload** button to start upgrading.

**IMPORTANT!** Do not turn off your DSL device or press the Reset button while this procedure is in progress.

The screenshot shows the web interface of a TECOM ADSL Router. The main heading is "Upgrade Firmware". Below the heading, there is a warning: "This page allows you upgrade the ADSL Router firmware to new version. Please note, do not power off the device during the upload because it may crash the system." Underneath the warning, there is a "Select File:" label followed by an empty text input field and a "浏览..." button. At the bottom of the form area, there are two buttons: "Upload" and "Reset". On the left side, there is a navigation menu with various options like Status, LAN, Wireless, WAN, Services, Firewall, Advance, Diagnostic, Admin, Commit/Reboot, Backup/Restore, System Log, Password, Upgrade Firmware, Time Zone, TR-069 Config, and Statistics.

#### 4.10.6. Time Zone

Simple Network Timing Protocol (SNTP) is a protocol used to synchronize the system time to the public SNTP servers. The DSL device supports SNTP client functionality in compliance with IETF RFC2030. SNTP client functioning in daemon mode which issues sending client requests to the configured SNTP server addresses periodically can configure the system clock in the DSL device

**TECOM** **ADSL Router**

**Site contents:**

- Status
- LAN
- Wireless
- WAN
- Services
- Firewall
- Advance
- Diagnostic
- Admin
  - Commit/Reboot
  - Backup/Restore
  - System Log
  - Password
  - Upgrade Firmware
  - Time Zone
  - TR-069 Config
  - Statistics

### Time Zone Setting

You can maintain the system time by synchronizing with a public time server over the Internet.

---

**Current Time :** Yr  Mon  Day  Hr  Mn  Sec

**Time Zone**

**Select :**

**Enable SNTP client update**

**SNTP server :**     (Manual Setting)

#### Fields in this page:

Field	Description
<b>Current Time</b>	The current time of the specified time zone. You can set the current time by yourself or configured by SNTP.
<b>Time Zone Select</b>	The time zone in which the DSL device resides.
<b>Enable SNTP client update</b>	Enable the SNTP client to update the system clock.
<b>SNTP server</b>	The IP address or the host name of the SNTP server. You can select from the list or set it manually.

#### 4.10.7. TR-069 Config.

TR-069 is a protocol for communication between a CPE and Auto-Configuration Server (ACS). The CPE TR-069 configuration should be well defined to be able to communicate with the remote ACS.

**TECOM** **ADSL Router**

**TR-069 Configuration**

This page is used to configure the TR-069 CPE. Here you may change the setting for the ACS's parameters.

---

**TR069:**  Disabled  Enabled

**ACS:**

**URL:**

**User Name:**

**Password:**

**Periodic Inform Enable:**  Disabled  Enabled

**Periodic Inform Interval:**

---

**Connection Request:**

**User Name:**

**Password:**

**Path:**

**Port:**

**Fields in this page:**

ACS Field	Description
URL	ACS URL. For example, <a href="http://10.0.0.1:80">http://10.0.0.1:80</a> <a href="https://10.0.0.1:443">https://10.0.0.1:443</a>
User Name	The username the DSL device should use when connecting to the ACS.
Password	The password the DSL device should use when connecting to the ACS.
Periodic Inform Enable	When this field is enabled, the DSL device will send an Inform RPC to the ACS server at the system startup, and will continue to send it periodically at an interval defined in <b>Periodic Inform Interval</b> field; When this field is disabled, the DSL device will only send Inform RPC to the ACS server once at the system startup.
Periodic Inform Interval	Time interval in second to send Inform RPC.
Connection Request Field	Description
User Name	The username the remote ACS should use when connecting to this device.
Password	The password the remote ACS should use when connecting to this device.
Path	The path of the device ConnectionRequestURL. The device ConnectionRequestURL should be configured based on the Device_IP, Path and Port as follows:

	http://Device_IP:Port/Path
Port	The port of the device ConnectionRequestURL.

Note: Please enable the Auto-Execution to enable the TR-069 process

## 4.11. Statistics

The DSL device shows the different layer of network statistics information.

### 4.11.1. Interfaces

You can view statistics on the processing of IP packets on the networking interfaces. You will not typically need to view this data, but you may find it helpful when working with your ISP to diagnose network and Internet data transmission problems.

The screenshot shows the web interface for a TECOM ADSL Router. The main heading is 'ADSL Router' and the page title is 'Statistics -- Interfaces'. A sidebar on the left lists site contents including Status, LAN, Wireless, WAN, Services, Firewall, Advance, Diagnostic, Admin, Statistics, Interfaces, and ADSL. The main content area contains a descriptive text and a table of statistics.

This page shows the packet statistics for transmission and reception regarding to network interface.

Interface	Rx pkt	Rx err	Rx drop	Tx pkt	Tx err	Tx drop
eth0	27274	0	0	13933	0	0
wlan0	2667573	0	0	0	0	0
8_32	0	0	0	0	0	0
8_36	0	0	0	0	0	0

Refresh      Reset Statistics

To display updated statistics showing any new data since you opened this page, click **Refresh**.

### 4.11.2. ADSL

This page shows the ADSL line statistic information.



# ADSL Router

Site contents:

- Status
- LAN
- Wireless
- WAN
- Services
- Firewall
- Advance
- Diagnostic
- Admin
- Statistics
- Interfaces
- ADSL

## Statistics -- ADSL Line

Mode	
Latency	
Trellis Coding	Enable
Status	ACTIVATING.
Power Level	LO
Uptime	

	Downstream	Upstream
SNR Margin (dB)	0.0	0.0
Attenuation (dB)	0.0	0.0
Output Power (dBm)	0.0	0.0
Attainable Rate (Kbps)	0	0
Rate (Kbps)	0	0
K (number of bytes in DMT frame)		
R (number of check bytes in RS code word)		
S (RS code word size in DMT frame)		
D (interleaver depth)		
Delay (msec)		
FEC	0	0
CRC	0	0
Total ES	0	0
Total SES	0	0
Total UAS	0	0

## APENDIX A: Channel Mode Configuration

ADSL router supports multiple channel operation modes. This section will show procedures to configure the router.

### Bridge Mode

**TECOM ADSL Router**

### WAN Configuration

This page is used to configure the parameters for the channel operation modes of your ADSL Modem/Router.

VPI:  :  Encapsulation:  L  VC-M  Channel Mode:  ▼

Enable NAPT:  Admin Status:  Enable  Disable

Enable ICMP:  Enable QoS:

---

PPP Settings: User Name:  Password:

Type:  ▼ Idle Time (min):

---

WAN IP Settings: Type:  Fixed IP  DHCP

Local IP Address:  Remote IP Address:

Subnet Mask:  Unnumbered

Default Route:  Disable  Enable

1. Open the WEB page at “WAN interface/Channel Configuration”.
2. Select the Channel Mode to “1483 Bridged”. Set the parameters VPI/VCI and Encapsulation mode according to the CO DSLAM setting.
3. Click “Add” button to add this channel into VC table.
4. Open the WEB page at “Admin/ Commit/Reboot”. Press “Commit” to save the settings into flash memory.
5. The new settings will take effect after reboot the system.

## MER(Mac Encapsulating Routing) Mode

The screenshot shows the 'WAN Configuration' page of a TECOM ADSL Router. The page is titled 'WAN Configuration' and includes a description: 'This page is used to configure the parameters for the channel operation modes of your ADSL Modem/Router.' The configuration fields are as follows:

- VPI:** 0
- VCI:** [empty]
- Encapsulation:**  LLC  VC-Mux
- Channel Mode:** 1483 MER (dropdown menu)
- Enable NAPT:**
- Admin Status:**  Enable  Disable
- Enable IGMP:**
- Enable QoS:**

Below these are the **PPP Settings:**

- User Name:** [empty]
- Password:** [empty]
- Type:** Continuous (dropdown menu)
- Idle Time (min):** [empty]

Below these are the **WAN IP Settings:**

- Type:**  Fixed IP  DHCP
- Local IP Address:** [empty]
- Remote IP Address:** [empty]
- Subnet Mask:** [empty]
- Unnumbered:**
- Default Route:**  Disable  Enable

At the bottom of the configuration area are two buttons: 'Add' and 'Modify'.

1. Open the WEB page at "WAN interface/Channel Configuration".
2. Select the Channel Mode to "1483 MER". Set the parameters VPI/VCI and Encapsulation mode according to the CO DSLAM setting.
3. Set "Local IP Address:" according to the IP that ISP assign for your router. Set "Remote IP Address" to the ISP's gateway.
4. Click "Add" button to add this channel into VC table.
5. Open the WEB page at "Admin/ Commit/Reboot". Press "Commit" to save the settings into flash memory.
6. The new settings will take effect after reboot the system.



## PPPoE Mode

**TECOM** *ADSL Router*

**Site contents:**

- Status
- LAN
- Wireless
- WAN
  - Channel Config
  - ATM Settings
  - ADSL Settings
- Services
- Firewall
- Advance
- Diagnostic
- Admin
- Statistics

### WAN Configuration

This page is used to configure the parameters for the channel operation modes of your ADSL Modem/Router.

**VPI:**     **VCI:**     **Encapsulation:**  LLC     VC-Mux    **Channel Mode:**

**Enable NAPT:**     **Admin Status:**  Enable     Disable  
**Enable IGMP:**     **Enable QoS:**

---

**PPP Settings:** **User Name:**     **Password:**   
**Type:**     **Idle Time (min):**

---

**WAN IP Settings:** **Type:**  Fixed IP     DHCP  
**Local IP Address:**     **Remote IP Address:**   
**Subnet Mask:**     **Unnumbered:**   
**Default Route:**  Disable     Enable

1. Open the WEB page at “WAN interface/Channel Configuration”.
2. Select the Channel Mode to “PPPoE”. Set the parameters VPI/VCI and Encapsulation mode according to the CO DSLAM setting.
3. Enter user/password from your ISP.
4. Click “Add” button to add this channel.
5. Enable DHCP server to allow the local PCs share the PPP connection. Reference to section 4.6.1 DHCP Server Configuration.
6. Set DNS address from your ISP. Reference to section 4.6.2 DNS Configuration.
7. Open the WEB page at “Admin/ Commit/Reboot”. Press “Commit” to save the settings into flash memory.
8. The new settings will take effect after reboot the system.

## PPPoA Mode

**TECOM** **ADSL Router**

**WAN Configuration**

This page is used to configure the parameters for the channel operation modes of your ADSL Modem/Router.

VPI:  VCI:  Encapsulation:  LLC  VC-Mux Channel Mode:

Enable NAPT:  Admin Status:  Enable  Disable

Enable IGMP:  Enable QoS:

PPP Settings: User Name:  Password:

Type:  Idle Time (min):

WAN IP Settings: Type:  Fixed IP  DHCP

Local IP Address:  Remote IP Address:

Subnet Mask:  Unnumbered

Default Route:  Disable  Enable

1. Open the WEB page at "WAN interface/Channel Configuration".
2. Select the Channel Mode to "PPPoA". Set the parameters VPI/VCI and Encapsulation mode according to the CO DSLAM setting.
3. Enter user/password from your ISP.
4. Click "Add" button to add this channel.
5. Enable DHCP server to allow the local PCs share the PPP connection. Reference to section 4.6.1 DHCP Server Configuration.
6. Set DNS address from your ISP. Reference to section 4.6.2 DNS Configuration.
7. Open the WEB page at "Admin/ Commit/Reboot". Press "Commit" to save the settings into flash memory.
8. The new settings will take effect after reboot the system.

## 1483 Routed Mode

The screenshot shows the 'WAN Configuration' page of a TECOM ADSL Router. The page title is 'ADSL Router' and the sub-page is 'WAN Configuration'. A navigation menu on the left lists 'Site contents' including Status, LAN, Wireless, WAN, Channel Config, ATM Settings, ADSL Settings, Services, Firewall, Advance, Diagnostic, Admin, and Statistics. The main content area has a blue header 'ADSL Router' and a sub-header 'WAN Configuration'. Below the header, there is a descriptive text: 'This page is used to configure the parameters for the channel operation modes of your ADSL Modem/Router.' The configuration fields are as follows:

- VPI:** 0
- VCI:** [empty]
- Encapsulation:**  LLC  VC-Mux
- Channel Mode:** 1483 Routed (dropdown menu)
- Enable NAPT:**
- Admin Status:**  Enable  Disable
- Enable ICMP:**
- Enable QoS:**

---

**PPP Settings:**

- User Name:** [empty]
- Password:** [empty]
- Type:** Continuous (dropdown menu)
- Idle Time (min):** [empty]

---

**WAN IP Settings:**

- Type:**  Fixed IP  DHCP
- Local IP Address:** [empty]
- Remote IP Address:** [empty]
- Subnet Mask:** [empty]
- Unnumbered:**
- Default Route:**  Disable  Enable


At the bottom of the configuration area, there are two buttons: 'Add' and 'Modify'.

1. Open the WEB page at "WAN interface/Channel Configuration".
2. Select the Channel Mode to "1483 Routed". Set the parameters VPI/VCI and Encapsulation mode according to the CO DSLAM setting.
3. In WAN IP settings, give the local and remote IP address from your ISP or use DHCP to get them automatically if your ISP support it. Local IP is the address of ADSL router. Remote IP is the ISP's gateway address.
4. Click "Add" button to add this channel.
5. Open the WEB page at "Admin/ Commit/Reboot". Press "Commit" to save the settings into flash memory.
6. The new settings will take effect after reboot the system.

For more information or any question, please consult to your supplier for details.


## APENDIX B: Protocol Stacks

### A.1 1483 Bridged Model




1483 Bridged Channel Mode Scenario

## A.2 1483 MER Model




### 1483 MER Channel Mode Scenario

### A.3 PPPoE Model




### PPPoE Channel Mode Scenario

## A.4 PPPoA Model



PPPoA Channel Mode Scenario

## A.5 1483 Routed Model



### 1483 Routed Channel Mode Scenerio



## APENDIX C: Mapping PVCs to VLANs

The AW4062 Router supports mapping ATM Permanent Virtual Circuits (PVCs) to VLANs, based on the ATM bridging standards of RFC2684. This feature allows an ATM PVC to be configured as a bridging interface and used in conjunction with a VLAN.

Figure B.1 illustrates the how the AW4062 Router adds a VLAN ID and tag to packets subject to PVC-VLAN mapping. In this example, vc3 is mapped to VLAN 20. The AW4062 Router adds VLAN ID 20 and tag 8100 to packets from vc3.




Figure B.1 Adding a VLAN ID and tag to packets from a PVC