


FUJI UG530/430/330 SERIES PROGRAMMABLE OPERATION DISPLAY



USER'S MANUAL <Hardware>

TYPE: UG530H-x
UG430H-x
UG330H-x

Preface

Thank you for purchasing Fuji's Programmable Operation Display, POD UG530/430/330 Series (hereinafter called UG30 Series or POD).

This User's Manual <Hardware> explains system configuration, specifications and handling of the UG30 Series. To enable you to fully utilize the display, carefully read this User's Manual.

For more information on the UG30 Series, refer to the following manuals as well.

Name	Manual No.	Contents
UG Series <Tutorial>	FEH350	Tutorial manual for novices in the UG Series
UG Series <Operation>	FEH375	Describes operating procedures of the screen editor (UG00S-CW) for the UG Series.
UG Series <Function>	FEH376	Describes the functions available with the UG30/20 Series.
UG Series <Supplementary Manual>	FEH376-1	Supplementary information for the UG Series <Function>
UG Series <PLC Connection>	FEH380	Describes connections with PLCs, universal serial communications, etc.
UG Series <CC-Link Communications>	FEH355	Describes the procedure for connecting to a PLC through an optional CC-Link interface.
UG Series <T-Link Communications>	FEH356	Describes the procedure for connecting to a PLC through an optional T-Link interface.
UG Series <SX-BUS Communications>	FEH357	Describes the procedure for connecting to a PLC through an optional SX-BUS interface.
UG Series <OPCN-1 Communications>	FEH358	Describes the procedure for connecting to a PLC through an optional OPCN-1 interface.
UG Series <Variable Name Cooperation Function>	FEH363	Describes the variable name cooperation function to be used between the UG editor and D300win.
UG Series <Temperature Control Network>	FEH365	Describes the procedure for connecting the UG Series with a temperature controller.
UG Series <Ethernet Communications>	FEH366	Describes the procedure of Ethernet communications through an optional Ethernet interface.
UG Series <FL-Net Communications>	FEH367	Describes the procedure for connecting to a PLC through an optional FL-NET interface.
UG Series <PROFIBUS Communications>	FEH368	Describes the procedure for connecting to a PLC through an optional PROFIBUS interface.

For further details about PLCs (programmable logic controllers), see the manual attached to each PLC.

Notes:

1. This manual may not, in whole or in part, be printed or reproduced without the prior written consent of Fuji Electric FA Components & System Co., Ltd.
2. The information in this manual is subject to change without prior notice.
3. Windows and Excel are registered trademarks of Microsoft Corporation in the United States and other countries.
4. All other company names or product names are trademarks or registered trademarks of their respective holders.
5. This manual is intended to give accurate information about POD hardware. If you have any questions, please contact your local distributor.

Record of Revisions

Reference numbers are shown at the bottom left corner on the back cover of each manual.

Printing Date	Reference No.	Revised Contents
November, 2002	FEH377	First edition
April, 2003	FEH377a	Second edition <ul style="list-style-type: none"> • Ladder Transfer Function MITSUBISHI Q00/Q01, FX/FX1S/FX2N series • PLC2Way MITSUBISHI QnH (Q) series CPU, FX series link (A protocol) • OMRON CS1/CS1DNA (Ethernet) • SIEMENS S7-300/400MPI, S7-300MPI Helmholtz SSW7 ADP • KEYENCE KV-700 (Ethernet) • LG GLOFA GM series CPU • IDEC MICRO Smart • VIGOR • DELTA • BALDOR
April, 2004	FEH377b	Third edition <ul style="list-style-type: none"> • Modifications accompanied by company name change • Information on connections with PLCs put into a separate volume entitled "UG Series PLC Connection" (FEH380) • Information on the matrix switch type added • Information on UG430H-SS added

Notes on Safe Use of POD


In this manual, you will find various notes categorized under the following levels with the signal words “DANGER,” and “CAUTION.”



Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.



Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury and could cause property damage.

Note that there is a possibility that the item listed with  CAUTION may have serious ramifications.



- Never use the input function of POD for operations that may threaten human life or to damage the system, such as switches to be used in case of emergency. Please design the system so that it can cope with malfunction of a touch switch. A malfunction of the touch switch will result in machine accident or damage.
- Turn off the power supply when you set up the unit, connect cables or perform maintenance and inspection. Otherwise, electrical shock or damage may occur.
- Never touch any terminals while the power is on. Otherwise, electric shock may occur.
- You must put a cover on the terminals on the unit when you turn the power on and operate the unit. Without the terminal cover in place, an electric shock may occur.
- The liquid crystal in the LCD panel is a hazardous substance. If the LCD panel is damaged, never swallow the leaked liquid crystal. If the liquid crystal spills on your skin or clothing, use soap and wash off thoroughly.
- For POD using a lithium battery, never disassemble, recharge, deform by pressure, short-circuit, nor reverse the polarity of the battery, and never dispose of the battery in fire. Failure to follow these conditions will lead to explosion or ignition.
- For POD using a lithium battery, never use a battery that is deformed, leaks, or shows any other signs of abnormality. Failure to follow these conditions will lead to explosion or ignition.

CAUTION

- Check the appearance of the unit when it is unpacked. Do not use the unit if any damage or deformation is found. Failure to do so may lead to fire, damage or malfunction.
- For use in a facility or for a system related to nuclear energy, aerospace, medical, traffic equipment, or mobile installations, please consult your local distributor.
- Operate (or store) POD under the conditions indicated in this manual and related manuals. Failure to do so could cause fire, malfunction, physical damage or deterioration.
- Understand the following environmental limits for use and storage of POD. Otherwise, fire or damage to the unit may result.
 - Avoid locations where there is a possibility that water, corrosive gas, flammable gas, solvents, grinding fluids or cutting oil can come into contact with the unit.
 - Avoid high temperature, high humidity, and outside weather conditions, such as wind, rain or direct sunlight.
 - Avoid locations where excessive dust, salt, and metallic particles are present.
 - Avoid installing the unit in a location where vibration or physical shock may be transmitted.
- Equipment must be correctly mounted so that the main terminal of POD will not be touched inadvertently. Otherwise, an accident or electric shock may occur.
- Tighten the fixtures of the POD with a torque in the specified range. Excessive tightening may distort the panel surface. Loose tightening may cause POD to come off, malfunction or be short-circuited.
- Check periodically that terminal screws on the power supply terminal block and fixtures are firmly tightened. Loosened screws may result in fire or malfunction.
- Tighten terminal screws on the power supply terminal block equally to a torque of 0.5 N•m. Improper tightening of screws may result in fire, malfunction, or trouble.
- POD has a glass screen. Do not drop or give physical shock to the unit. Otherwise, the screen may be damaged.
- Connect the cables correctly to the terminals of POD in accordance with the specified voltage and wattage. Over-voltage, over-wattage or incorrect cable connection could cause fire, malfunction or damage to the unit.
- Be sure to establish a ground of POD. Ground FG terminal which must be used for the unit. Otherwise, electric shock or a fire may occur.
- Prevent any conductive particles from entering into POD. Failure to do so may lead to fire, damage or malfunction.
- After wiring is finished, remove the paper used as a dust cover before starting to operate POD. Operation with the cover attached may result in accident, fire, malfunction, or trouble.
- Do not attempt to repair POD at your site. Ask us or the designated contractor for repair.
- Do not disassemble or modify POD. Otherwise, it may cause a malfunction.
- We are not responsible for any damages resulting from repair, overhaul or modification of POD that was performed by an unauthorized person.
- Do not use a sharp-pointed tool when pressing a touch switch. Doing so may damage the screen.
- Only experts are authorized to set up the unit, connect the cables or perform maintenance and inspection.
- For POD using a lithium battery, handle the battery with care. The combustible materials such as lithium or organic solvent contained in the battery may generate heat, explode, or catch fire, resulting in personal injury or fire. Read related manuals carefully and handle the lithium battery correctly as instructed.
- When using a POD that has analog switch resolution with resistance film, do not press two or more points on the screen at the same time. If there is a switch between the two pressed points, it may be activated.
- Take safety precautions during such operations as setting change during running, forced output, start, and stop. Any misoperation may cause unexpected machine motions, resulting in machine accident or damage.
- In facilities where a failure of POD could lead to accident threatening human life or other serious damage, be sure that the facilities are equipped with adequate safeguards.
- At the time of disposal, POD must be treated as industrial waste.
- Before touching POD, discharge static electricity from your body by touching grounded metal. Excessive static electricity may cause malfunction or trouble.

[General Notes]

- Never bundle control cables and input/output cables with high-voltage and large-current carrying cables such as power supply cables. Keep these cables at least 200 mm away from the high-voltage and large-current carrying cables. Otherwise, malfunction may occur due to noise.
- Plug connectors or sockets of POD in the correct orientation. Otherwise, it may cause a malfunction.
- Do not use thinners for cleaning because they may discolor the POD surface. Use alcohol or benzine commercially available.
- If a data receive error occurs when POD and the counterpart (PLC, temperature controller, etc.) are started at the same time, read the manual for the counterpart unit and handle the error correctly.
- Avoid discharging static electricity on the mounting panel of the POD. Static charges can damage the unit and cause malfunctions. Otherwise, malfunction may occur due to noise.
- Avoid prolonged display of any fixed pattern. Due to the characteristics of the liquid crystal display, an afterimage may occur. If a prolonged display of a fixed pattern is expected, use the auto OFF function of the backlight.

Contents

Preface

Notes on Safe Use of POD

Chapter 1 Overview

1. Features.....	1-1
2. Models and Peripheral Equipment.....	1-2
POD Models.....	1-2
Peripheral Equipment.....	1-3
3. System Composition.....	1-7
System Composition of UGx30H-xSx (Standard).....	1-7
System Composition of UGx30H-xHx (High-performance).....	1-8

Chapter 2 Specifications

1. Specifications.....	2-1
General Specifications.....	2-1
Display Specifications.....	2-2
Touch Switch Specifications.....	2-2
Function Switch Specifications.....	2-2
Interface Specifications.....	2-3
Clock and Backup Memory Specifications.....	2-3
Drawing Environment.....	2-3
Display Function Specifications.....	2-4
Function Performance Specifications.....	2-5
2. Dimensions and Panel Cut-out.....	2-6
UG330 External View and Dimensions.....	2-6
UG430 External View and Dimensions.....	2-7
UG530 External View and Dimensions.....	2-8
3. Names and Functions of Components.....	2-9
4. Serial Connector (CN1).....	2-12
Serial Connector for PLC Connection.....	2-12
5. Modular Jack (MJ1/MJ2).....	2-13
Modular Jack 1 (MJ1)/2 (MJ2).....	2-13
Editor Setting.....	2-13
Transferring Screen Data.....	2-15
Barcode Reader Connection.....	2-15
6. 10BASE-T (LAN).....	2-16
10BASE-T Connector.....	2-16
Wiring.....	2-17
7. CF Card (CF).....	2-18
Recommended CF Cards.....	2-18
Mounting and Dismounting the CF Card.....	2-18
Notes on Handling the CF Card.....	2-19
8. Printer Connection (PRINTER).....	2-20
Printer Connector (PRINTER).....	2-20
Connection with Printer through Serial Interface.....	2-21

Chapter 3	Installation	
1.	Mounting Procedure	3-1
	Mounting Procedure	3-1
	Mounting Angle	3-1
2.	Power Supply Cable Connection	3-2
	Power Supply Cable Connection	3-2
	Notes on Usage of 100-240 VAC Specifications	3-3
	Grounding	3-3
Chapter 4	Instructions	
1.	Coin-type Lithium Battery	4-1
	Battery Mounting Procedure	4-1
	Battery Replacement	4-2
2.	DIP Switch Setting	4-4
	DIP Switch (DIPSW) Setting	4-4
3.	Function Switches	4-5
	Types	4-5
	[SYSTEM] Switch	4-5
Chapter 5	Connections	
1.	1 : 1 Connection	5-1
2.	1 : n Connection (Multi-drop)	5-2
3.	n : 1 Connection (Multi-link 2)	5-3
4.	n : 1 Connection (Multi-link)	5-4
5.	Universal Serial Communications	5-5
6.	UG-Link	5-6
7.	PLC2Way	5-7
8.	Temperature Control Network	5-8
9.	Ethernet	5-9
10.	Other Networks	5-11
	FL-net (OPCN-2)	5-11
	CC-Link	5-12
	OPCN-1	5-13
	T-LINK	5-14
	PROFIBUS-DP	5-15
Chapter 6	POD Operations	
1.	Operational Procedures	6-1
	POD Operation	6-1
2.	Main Menu Screen	6-3
1.	I/O Test	6-4
1-1.	Self-loop Test	6-5
1-2.	Print Check	6-8
1-3.	SYSTEM & Function Switch Test	6-8
1-4.	Touch Switch Test	6-9
2.	Card Menu Screen	6-11
2-1.	UG00P-MR Menu Screen	6-12
2-2.	Transferring Screen Data from a CF Card	6-14

2-3. Saving Backup Copies of SRAM	6-20
2-4. Messages during Data Transfer.....	6-22
3. Ethernet	6-23
4. SRAM/Clock	6-26
5. Extension Program Information	6-27
6. Extended Function Setting.....	6-28

Chapter 7 Error Correction

1. Error Message	7-1
1. Communication Error.....	7-1
2. Check.....	7-4
3. Warning	7-5
4. SYSTEM ERROR	7-6
5. Touch Switch is Active.....	7-6
2. Troubleshooting	7-7
In the Event of an Error.....	7-7
Probable Symptoms.....	7-7

Chapter 8 Inspection and Maintenance

1. Inspection and Maintenance	8-1
Daily Inspection.....	8-1
Periodical Inspection.....	8-1
2. Warranty Policy	8-2
Inquiries about Failure	8-2
Warranty Period.....	8-2
Free-of-charge Repair.....	8-2
Chargeable Repair.....	8-2

1

Overview

1. Features
2. Models and Peripheral Equipment
3. System Composition

1. Features


The UG30 Series inherits and heightens the features of the UG20 Series as described below.

1. 32k-color Display
32,768-color display makes colorful expression possible.
Bitmap files are clearly displayed in brilliant colors.
2. CF Card Interface as Standard
The CF card can be used for saving multiple screen data, sampling data, recipe data, hard copy images, and other various usages.
Large-sized video capture images, JPEG or WAV files can be saved.
3. Connector for 10BASE-T (for high-performance type only)
This connector enables Ethernet connection with a host computer.
High-speed communications are possible via Ethernet for uploading/downloading screen data and reading/writing data from/to the server.
4. Video Display Upgraded (for high-performance type only/optional)
The video display function is upgraded drastically to allow: saving the current video screen, taking snapshots of multiple exposures, superimposing a semi-transparent operation screen on a video display, showing four video channels at the same time, and so on.
5. Web Server Function (for high-performance type only)
The UG30 screens are converted into HTML files and displayed on the WWW browser using the Ethernet.
6. Animation Function
The animation function enables representation of the field close to the real image.
7. Play of WAV File (for high-performance type only/optional)
WAV files can be played with ease simply by connecting the option unit to the speaker.
It is possible to use sound for notifying the field conditions, such as an occurrence of an error. The monitoring operator can work from a distance.

2. Models and Peripheral Equipment

POD Models

The model name consists of the following information.



The following models are available.

<Analog>

Series and Size	Model Name	Specifications	Remarks
UG330 Series 8-inch	UG330H-VS4	TFT color, 800 × 600 dots, standard, DC power supply	Compliant with CE/UL/cUL
	UG330H-VH4	TFT color, 800 × 600 dots, high-performance, DC power supply	Compliant with CE/UL/cUL
	UG330H-SS4	STN color, 640 × 480 dots, standard, DC power supply	Compliant with CE/UL/cUL
UG430 Series 10-inch	UG430H-TS1	TFT color, 640 × 480 dots, standard, AC power supply	
	UG430H-TS4	TFT color, 640 × 480 dots, standard, DC power supply	Compliant with CE/UL/cUL
	UG430H-TH1	TFT color, 640 × 480 dots, high-performance, AC power supply	
	UG430H-TH4	TFT color, 640 × 480 dots, high-performance, DC power supply	Compliant with CE/UL/cUL
	UG430H-VS1	TFT color, 800 × 600 dots, standard, AC power supply	
	UG430H-VS4	TFT color, 800 × 600 dots, standard, DC power supply	Compliant with CE/UL/cUL
	UG430H-VH1	TFT color, 800 × 600 dots, high-performance, AC power supply	
	UG430H-VH4	TFT color, 800 × 600 dots, high-performance, DC power supply	Compliant with CE/UL/cUL
	UG430H-SS1	TFT color, 640 × 480 dots, standard, AC power supply	
	UG430H-SS4	TFT color, 640 × 480 dots, standard, DC power supply	Compliant with CE/UL/cUL


Series and Size	Model Name	Specifications	Remarks
UG530 Series 12-inch	UG530H-VS1	TFT color, 800 × 600 dots, standard, AC power supply	
	UG530H-VS4	TFT color, 800 × 600 dots, standard, DC power supply	Compliant with CE/UL/cUL
	UG530H-VH1	TFT color, 800 × 600 dots, high-performance, AC power supply	
	UG530H-VH4	TFT color, 800 × 600 dots, high-performance, DC power supply	Compliant with CE/UL/cUL

<Matrix>


Series and Size	Model Name	Specifications	Remarks
UG430 Series 10-inch	UG430H-TS1D	TFT color, 640 × 480 dots, standard, AC power supply	
	UG430H-TS4D	TFT color, 640 × 480 dots, standard, DC power supply	Compliant with CE/UL/cUL
	UG430H-TH1D	TFT color, 640 × 480 dots, high-performance, AC power supply	
	UG430H-TH4D	TFT color, 640 × 480 dots, high-performance, DC power supply	Compliant with CE/UL/cUL
	UG430H-SS1D	TFT color, 640 × 480 dots, standard, AC power supply	
	UG430H-SS4D	TFT color, 640 × 480 dots, standard, DC power supply	Compliant with CE/UL/cUL
UG530 Series 12-inch	UG530H-VS1D	TFT color, 800 × 600 dots, standard, AC power supply	
	UG530H-VS4D	TFT color, 800 × 600 dots, standard, DC power supply	Compliant with CE/UL/cUL
	UG530H-VH1D	TFT color, 800 × 600 dots, high-performance, AC power supply	
	UG530H-VH4D	TFT color, 800 × 600 dots, high-performance, DC power supply	Compliant with CE/UL/cUL

Peripheral Equipment

The following options are available for using the UG30 Series more effectively.




UG00S-CWV3 (configuration software: English/Japanese)
Application software for editing display data for the POD.
(Windows98/NT4.0/Me/2000/XP compatible)
The UG30 Series is supported with ver. 3.00 and later.




UG30A-xxx (option unit)

* This option unit can only be mounted on the high-performance type.
xxx: VIS → Video input + sound output unit
Video images can be displayed on POD directly.
WAV files can be played at an external speaker.
xxs: RIS → RGB input + sound output unit
Screen images displayed on a CRT display can be shown on POD.
WAV files can be played at an external speaker.
xxs: ROS → RGB input + sound output unit
Screen images displayed on POD can be shown on a CRT display.
WAV files can be played at an external speaker.
xxs: SUD → Sound output unit
WAV files can be played at an external speaker.




UG30P-D8 (FLASH memory cassette)


Extension print circuit board to extend the memory for screen data.
The capacity of FLASH memory is 8 Mbyte.

**UG30P-LM (FLASH memory cassette for ladder monitor)**


Extension print circuit board for the ladder monitor function.
The memory for screen data is extended at the same time.
The capacity of FLASH memory is 8 Mbytes. (4 Mbytes for ladder monitor, 4 Mbytes for screen data)

**UG30P-SR (SRAM cassette)**


Extension print circuit board to back-up the memory for sampling data, POD internal memory and memo pad. The capacity of an SRAM cassette is 512 kbyte.

**UG00P-TC (terminal converter)**

Used for connection between the POD and a PLC at the RS-422/485 terminal block.


**UG00P-MR (card recorder)**

The card recorder creates a backup copy of screen data or works as an external memory storage system for memory manager and data logging functions.


**UG00K-xx (memory card) compliant with JEIDA ver. 4.0**

Used with the card recorder when having a backup copy of screen data or saving data on an external medium for memory manager and data logging functions.


SRAM (UG00K-Sxx)	256 kB, 512 kB, 1 MB, 2 MB, 4 MB
FLASH ROM (UG00K-Fxx)	256 kB, 512 kB, 1 MB, 2 MB, 4 MB, 16 MB

**UG00P-MS (memory card editor: English/Japanese)**

Application software for editing data stored on a memory card, SRAM or CF card.
(Windows98/NT4.0/Me/2000/XP compatible)


**UG00P-DI (ACPU/QnACPU/FXCPU dual port interface)**

Add-on connector with two ports, specifically designed for the connector on the MITSUBISHI's ACPU/QnACPU/FXCPU programmer. Operability can be improved when directly connecting the POD to the ACPU/QnACPU/FXCPU programmer.




UG00P-U2 (serial extension I/O)

Used as an external I/O unit for PLC. It has 16 inputs and 16 outputs.




UG03I-x [x: S → SX Bus, J → OPCN-1, T → T-LINK, C → CC-Link,
E(E2) → Ethernet/FL-net (OPCN-2), P → PROFIBUS-DP]
(communication interface unit)

Used for communications with each network. This unit enables connection of multiple PODs to a single PLC. Since other devices on the same network can be connected, it brings about the reduction in costs of the whole system.




UG00C-T (screen data transfer cable) 3 m

Used for connection between the POD and a personal computer, or a personal computer and the card recorder (UG00P-MR).




UG30C-C (printer cable) 2.5 m

Used for connection between the UG30 Series and a printer.
For the CBM292/293 printer, use the UG30C-A printer cable (2.5 m).




UG00C-B (barcode reader connection cable) 3 m

Used for connection between the POD and a barcode reader.




UG00C-H (multi-link 2 master cable) 3 m

Used for Multi-Link 2 connection between the POD master station and the POD slave station.




UG00C-P (temperature controller connection cable) 3 m


Used for connection between the POD and a temperature controller or a PLC via PLC2Way.




UG30C-M (MJ-to-D-sub conversion cable) 0.3 m
Used for connection between the POD and a PLC via PLC2Way.




UGxxxP-PS [xxx: 330 → UG330, 430 → UG430, 530 → UG530]
(protective sheet)
This sheet protects the operation panel surface. (5 sheets/set)



UGxxxP-PT [xxx: 330 → UG330, 430 → UG430, 530 → UG530]
(protective sheet)
This anti-glare sheet protects the operation panel surface. (5 sheets/set)



UG30P-BT (battery for replacement)
Replacement lithium battery for the UG30 Series.




UG330P-BV → UG330H-VH, UG330H-VS
UG320P-BCA → UG330H-SS
UG420P-BFA → UG430H-TH, UG430H-TS
UG420P-BVA → UG430H-VH, UG430H-VS
UG520P-BFA → UG530H-VH, UG530H-VS
(backlight for replacement)
Replacement backlight parts for the UG30 Series. (Some backlights are also used for the UG20 Series.)

3. System Composition


System Composition of UGx30H-xSx (Standard)

The following illustration shows possible system configurations using the UG30 (standard).



System Composition of UGx30H-xHx (High-performance)

The following illustration shows possible system configurations using the UG30 (high-performance).



*1 The option unit (UG30A-xx) is required.

2 Specifications

1. Specifications
2. Dimensions and Panel Cut-out
3. Names and Functions of Components
4. Serial Connector (CN1)
5. Modular Jack (MJ1/MJ2)
6. 10BASE-T (LAN)
7. CF Card (CF)
8. Printer Connection (PRINTER)

1. Specifications

General Specifications

Item		Model					
		UG330		UG430		UG530	
		DC power supply		AC power supply	DC power supply	AC power supply	DC power supply
Power Supply	Rated Voltage	24 VDC		100 - 240 VAC	24 VDC	100 - 240 VAC	24 VDC
	Permissible Range of Voltage	24 VDC \pm 10%		100 - 240 VAC \pm 10%	24 VDC \pm 10%	100 - 240 VAC \pm 10%	24 VDC \pm 10%
	Permissible Momentary Power Failure	Within 1 ms		Within 20 ms	Within 1 ms	Within 20 ms	Within 1 ms
	Power Consumption (Maximum Rating)	UG330H-S 15 W or less	UG330H-V 22 W or less	60 VA or less	30 W or less	60 VA or less	30 W or less
	Rush Current	25 A, 0.7 ms		For 100 VAC: 16 A, 6 ms For 200 VAC: 32 A, 7 ms	30 A, 1ms	For 100 VAC: 16 A, 6 ms For 200 VAC: 32 A, 7 ms	30 A, 1 ms
	Withstand Voltage	DC external terminals to FG: 500 VAC, 1 minute		AC external terminals to FG: 1500 VAC, 1 minute	DC external terminals to FG: 500 VAC, 1 minute	AC external terminals to FG: 1500 VAC, 1 minute	DC external terminals to FG: 500 VAC, 1 minute
Insulation Resistance		500 VDC, 10 M Ω or above					
Physical Environment	Ambient Temperature	0°C to +50°C					
	Storage Ambient Temperature	-10°C to +60°C					
	Ambient Humidity	85% RH or less (without dew condensation)					
	Solvent Resistance	No cutting oil or organic solvent attached to the unit					
	Atmosphere	No corrosive gas or conductive dust					
Mechanical Working Conditions	Vibration Resistance	Vibration frequency: 10 to 150 Hz, Acceleration: 9.8 m/s ² Single amplitude: 0.075 mm, X, Y, Z: 3 directions for one hour					
	Shock Resistance	Pulse shape: Sine half wave Peak acceleration: 147 m/s ² , X, Y, Z: 3 directions six times each					
Electrical Working Conditions	Noise Resistance	1500 Vp-p (pulse width 1 μ s, rise time: 1 ns)					
	Static Electricity Discharge Resistance	Compliant with IEC61000-4-2, contact: 6 kV, air: 8 kV					
Mounting Conditions	Grounding	Grounding resistance: less than 100 Ω					
	Structure	Protection structure: front panel: compliant with IP65 (when using waterproof gasket) rear case: compliant with IP20 Form: in a single body Mounting procedure: inserted in a mounting panel					
	Cooling System	Cooling naturally					
	Weight (kg)	Unit: approx. 1.5	Analog type: Unit: approx. 2.4 Matrix type: Unit: approx. 2.8	Analog type: Unit: approx. 2.7 Matrix type: Unit: approx. 3.2			
	Dimensions W \times H \times D (mm)	233 \times 178 \times 66.1		303.8 \times 231.0 \times 72.0		326.4 \times 259.6 \times 72.0	
	Panel Cut-out (mm)	220.5 ^{+0.5} \times 165.5 ^{+0.5}		289.0 ^{+0.5} \times 216.2 ^{+0.5}		313.0 ^{+0.5} \times 246.2 ^{+0.5}	
Case Color	Black (Munsell N2.0)						
Material	PC/PS resin (Tarflon)						

Display Specifications

Item	Model					
	UG330H-SS	UG330H-VH,VS	UG430H-SS	UG430H-TH,TS	UG430H-VH,VS	UG530H-VH,VS
Display Device	STN color LCD	TFT color LCD				
Display Size	7.7-inch	8.4-inch	10.4-inch			12.1-inch
Colors	128 colors +16-color blinks	32,768 colors +16-color blinks	128 colors +16-color blinks	32,768 colors +16-color blinks		
Resolution W × H (dots)	640 × 480	800 × 600	640 × 480		800 × 600	
Dot Pitch W × H (mm)	0.246 × 0.246	0.213 × 0.213	0.33 × 0.33		0.264 × 0.264	0.3075 × 0.3075
Brightness (cd/m ²)	200	350	220	350	280	350
Contrast Ratio	25 : 1	250 : 1	350 : 1	300 : 1	300 : 1	350 : 1
Angle of Vertical Visibility (°)	+40, -30	+35, -55	+30, -20	+45, -55	+35, -45	+40, -45
Angle of Horizontal Visibility (°)	±50	±50	±45	±70	±50	±55
Backlight	Cold cathode rectifier (exchangeable by users)					
Average Backlight Life* ¹	Approx. 40,000 h	Approx. 50,000 h				
Backlight Auto OFF Function	Always ON, random setting					
Contrast Adjustment	Provided * ²	Not provided				
Brightness Adjustment	Not provided	3 levels * ²				
Surface Sheet	Material: Polycarbonate, 0.3 mm thick					
POWER Lamp	ON when the power is supplied					

*1 When the normal temperature is 25°C, and the surface luminance of the display is 50% of the initial setting.

*2 Adjustable with function switches

Touch Switch Specifications

Item	Specifications	
Method	Analog resistance film type	Matrix resistance film type
Switch Resolution	1024 (W) × 1024 (H)	10.4-inch: 40 (W) × 24 (H)
		12.1-inch: 50 (W) × 30 (H)
Mechanical Life	One million activations or more	
Surface Treatment	Hard-coated, anti-glare treatment 5%	

Function Switch Specifications

Item	Specifications
Number of Switches	8
Method	Digital resistance film type
Mechanical Life	One million activations or more

Interface Specifications

Item	Specifications
Serial Interface for PLC Connection (D-sub 25-pin, female)	RS-232C, RS-422/485 Asynchronous type Data length: 7, 8 bits Parity: Even, odd, none Stop bit: 1, 2 bits Baud Rate: 4800, 9600, 19200, 38400, 57600, 76800, 115200 bps
Serial Interface 1, 2 for Screen Data Transfer/External Connection (Modular jack, 8-pin)	RS-232C, RS-422/485 (2-wire connection) UG00P-MR, Barcode, UG00P-U2, Multi-link 2, Temperature control network/PLC2Way, UG-Link, etc.
Printer Interface for Printer Connection	Compliant with Centronics, half-pitch 36-pin PR201, ESC/P-J84, ESC/P super function, ESC/P24-J84 CBM292/293 printer ^{*1} Barcode printer MR400 EPSON printer: STYLUS PHOTO series ^{*2}
CF Card Interface	Compliant with CompactFlash TM
Ethernet Connection 10BASE-T (Standard with high-performance type)	Compliant with IEEE802.3 Baud rate: 10 Mbps Cables: 100 Ω unshielded twist-pair, category 5, maximum length = 100 m

*1 The CBM292/293 printer cannot print screen hard copies.

*2 For more information, refer to User's Manual <Supplementary Manual> (FEH376-1).

Clock and Backup Memory Specifications

Item	Specifications
Battery Specification	Coin-type lithium primary cell
Backup Memory	SRAM 64 kbyte
Backup Time Period	5 years (ambient temperature at 25°C)
Battery Voltage Drop Detection	Provided (internal memory allocated)
Calendar Accuracy	Monthly deviation ±90 sec (ambient temperature at 25°C)

Drawing Environment

Item	Specifications
Drawing Method	Exclusive configuration software
Drawing Tool	Name of exclusive configuration software: UG00S-CW (Ver. 3.00 and later) Personal computer: Pentium II 450 MHz or above recommended OS: Windows98/Me/NT Ver.4.0/2000/XP Capacity of hard disk required: Free space of approx. 460 Mbyte or more (For minimum installation: approx. 105 Mbyte) Memory capacity: 64 Mbytes or above (128 Mbytes or above recommended) Display: Resolution 800 × 600 or above recommended

Display Function Specifications

Item		Specifications				
Display Language*		Japanese	English/Western Europe	Chinese (traditional)	Chinese (simplified)	Korean
Characters	1/4-size, 1-byte	ANK code	Latin1	ASCII code	ASCII code	ASCII code
	2-byte 16-dot	JIS #1, 2 levels	–	Chinese (traditional)	Chinese (simplified)	Hangul (without Kanji)
	2-byte 32-dot	JIS #1 level	–	–	–	–
Character Size		1/4-size: 8 × 8 dots 1-byte: 8 × 16 dots 2-byte: 16 × 16 dots or 32 × 32 dots Enlarge: W: 1 to 8 times, H: 1 to 8 times				
Number of Displayable Characters		Resolution	640 × 480		800 × 600	
		1/4-size	80 characters × 60 lines		100 characters × 75 lines	
		1-byte	80 characters × 30 lines		100 characters × 37 lines	
		2-byte	40 characters × 30 lines		50 characters × 37 lines	
Characters Properties		Display properties: Normal, reverse, blink, bold, shadow Colors: 32,768 colors + blink 16 colors (UG330H-SS, UG430H-SS: 128 colors + blink 16 colors)				
Graphics		Lines: Circles: Others:	Line, continuous line, box, parallelogram, polygon Circle, arc, sector, ellipse, elliptical arc Tile patterns			
Graphic Properties		Line types: Tile patterns: Display properties: Colors: Color selection:	6 (thin, thick, dot, chain, broken, two-dot chain) 16 (incl. user-definable 8 patterns) Normal, reverse, blink 32,768 colors + blink 16 colors (UG330H-SS, UG430H-SS: 128 colors + blink 16 colors) Foreground, background, boundary (line)			

* In addition, the following fonts are available. For more information, refer to the User's Manual <Function> (FEH376) and the User's Manual <Supplementary Manual> (FEH376-1).
 Gothic, English/Western Europe (HK Gothic), English/Western Europe (HK Times), Central Europe, Cyrillic, Greek, Turkish

Function Performance Specifications

Item		Specifications
Screens		Max. 1024
Screen Memory		Flash memory: Approx. 4,992 kbyte (varies depending on the font)
Switch		768 per screen
Switch Actions		Set, reset, momentary, alternate, to light (Possible to press a function switch and a switch on the display at the same time)
Lamps		Reverse, blink, exchange of graphics 768 per screen
Graphs		Pie, bar, panel meter and closed area graph: No limitation within 256 kbyte per screen ^{*1} Statistics and trend graphs: Max. 256 per layer ^{*2}
Data Setting	Numerical Data Display	No limitation within 256 kbyte per screen ^{*1}
	Character Display	No limitation within 256 kbyte per screen ^{*1}
	Message Display	Resolution: 640 × 480, max. 80 characters (1-byte) 800 × 600, max. 100 characters (1-byte) No limitation within 256 kbyte per screen ^{*1}
Sampling		Sampling display of buffer data (Constant sample, bit synchronize, bit sample, relay sample, alarm function)
Graphic Library		Max. 2560
Multi-Overlaps		Max. 1024
Data Blocks		Max. 1024
Messages		Max. 6144 lines
Patterns		Max. 1024
Macro Blocks		Max. 1024
Page Blocks		Max. 1024
Direct Blocks		Max. 1024
Screen Blocks		Max. 1024
Data Sheets		Max. 1024
Screen Library		Max. 1024
Animation (Frames)		Max. 1023
Temperature Control Network/PLC2Way Table		Max. 32
Time Display		Time display function: provided
Hard Copy		Screen hard copy function: provided
Buzzer		Buzzer: provided, 2 sounds (short beep, long beep)
Auto OFF Function		Always ON, random setting
Self-diagnostic Function		Switch self-test function Communication parameter setting check function Communication check function

*1 The number of setting memory locations is limited to 1024 per screen.


*2 Layer: 4 per screen (base + 3 overlaps)

2. Dimensions and Panel Cut-out


UG330 External View and Dimensions

(Unit: mm)


- Side View




- Front View




- Rear View



- Bottom View




- Panel Cut-out Dimensions




UG430 External View and Dimensions

(Unit: mm)


• Side View




• Front View




• Rear View



• Bottom View




• Panel Cut-out Dimensions




UG530 External View and Dimensions

(Unit: mm)


- Side View




- Front View




- Rear View



- Bottom View




- Panel Cut-out Dimensions




3. Names and Functions of Components


UG330



UG430



UG530



1. Display
This is the display unit.
2. Power lamp (POWER)
Illuminates (green) when the power is supplied to the POD.
3. Function switches
Used for RUN /STOP selection, contrast adjustment, brightness adjustment and backlight ON/OFF (according to the setting).
These switches can be used as user switches in the RUN mode.
4. CF card connector (CF)
Used for inserting the CF card.
5. Printer connector (PRINTER)
Used for printer connection.
6. Modular jack connectors (MJ1, MJ2)
Used for screen data transfer and connection with temperature controller, barcode reader, UG00P-MR, etc.
7. PLC communication connector (CN1)
Used for connection between the POD and a PLC or an external control unit (computer, custom controller, etc).
8. 10BASE-T connector (LAN)..... High-performance type only
Used for Ethernet connection.
9. Power supply terminal block
Supplies the power to the POD (100 to 240 VAC, 24 VDC)
10. Mounting holes
Used for inserting fixtures when securing the POD to the mounting panel.
11. Communication interface unit connector (CN5)
Used for mounting the communication unit (UG03I-xx, optional) for SX-bus, OPCN-1, T-LINK, CC-Link, Ethernet, FL-net (OPCN-2) or PROFIBUS-DP.

12. Option unit connector (CN6) High-performance type only
Used for mounting the option unit (UG30A-xx) for video, sound, RGB IN or RGB OUT.
13. Add-on memory connector (MEMORY)
Used for mounting the optional FLASH memory cassette (UG30P-D8) or SRAM cassette (UG30P-SR).
14. DIP switch
8-bit DIP switch used for setting terminating resistance of the CN1 signal line and the MJ1/MJ2 RS-422/485 signal line.
15. Battery holder
Contains a backup battery for SRAM and clock.
When the battery voltage drops, replace the battery with a new one (UG30P-BT).


4. Serial Connector (CN1)

Serial Connector for PLC Connection

To communicate with the PLC (RS-232C, RS-422/485), connect the cable to the serial connector (CN1) at the bottom of the POD unit.


- For UG330:

Bottom View



- For UG430/UG530:

Bottom View



The serial connector pins correspond to signals as given below.

CN1 (D-sub 25-pin, female)	Pin No.	Signal Name	Contents
	1	FG	Frame ground
	2	SD	RS-232C send data
	3	RD	RS-232C receive data
	4	RS	RS-232C RS request to send
	5	CS	RS-232C CS clear to send
	6		Not used
	7	SG	Signal ground
	8		Not used
	9	+5 V	Use prohibited
	10	0 V	Use prohibited
	11		Not used
	12	+SD	RS-422 send data (+)
	13	-SD	RS-422 send data (-)
	14	+RS	RS-422 RS send data (+)
	15		Not used
	16		Not used
	17	-RS	RS-422 RS send data (-)
	18	-CS	RS-422 CS receive data (-)
	19	+CS	RS-422 CS receive data (+)
	20		Not used
	21	-	Use prohibited (UG330: not used)
	22	-	Use prohibited (UG330: not used)
	23		Not used
	24	+RD	RS-422 receive data (+)
	25	-RD	RS-422 receive data (-)

The following connector is recommended.

Recommended connector	DDK-make 17JE23250-02 (D8A)	D-sub 25-pin, male, metric thread, with hood
-----------------------	-----------------------------	--


5. Modular Jack (MJ1/MJ2)

Modular Jack 1 (MJ1)/2 (MJ2)


This is a modular connector used for connection for screen data transfer, temperature controller, barcode reader, card recorder (UG00P-MR) or serial extension I/O (UG00P-U2).

- For UG330:
- For UG430/UG530:


Bottom View



Bottom View



Pins of modular jacks 1 and 2 correspond to signals as given below.

MJ1/2	Pin No.	Signal Name	Contents
	1	+SD/RD	RS-485 + data
	2	-SD/RD	RS-485 - data
	3	+5 V	Externally supplied +5 V MAX 150 mA
	4	+5 V	
	5	SG	Signal ground
	6	SG	
	7	RD	RS-232C receive data
	8	SD	RS-232C send data

Editor Setting

1. The use of modular jacks 1 and 2 can be set on the editor.
2. Select [Modular] from the [System Setting] menu. The [Modular Jack] dialog is displayed. Select the use of modular jacks 1 and 2 from the following options.

Modular Jack 1	Modular Jack 2
[Editor Port] ^{*1}	[Not Used]
[Card Recorder] ^{*2}	[Card Recorder] ^{*2}
[Barcode] ^{*3}	[Barcode] ^{*3}
[UG00P-U2] ^{*4}	[UG00P-U2] ^{*4}
[Multi-Link] ^{*5}	[Multi-Link] ^{*5}
[Temp./PLC2Way] ^{*6}	[Temp./PLC2Way] ^{*6}
[UG-Link] ^{*7}	[UG-Link] ^{*7}
[Touch Switch] ^{*8}	[Touch Switch] ^{*8}
[Ladder Tool] ^{*9}	[Ladder Tool] ^{*9}
[Modbus Slave] ^{*10}	[Modbus Slave] ^{*10}
[Printer (Serial Port)] ^{*11}	[Printer (Serial Port)] ^{*11}

*1 Refer to the next section "Transferring Screen Data".

*2 Select this option when connecting the card recorder (UG00P-MR).

*3 Refer to the next section "Barcode Reader Connection".

*4 Select this option when connecting the serial extension I/O (UG00P-U2).

*5 Select this open when "Multi-link 2" is selected for [Connection] and "1" is set for [Local Port] on the [Comm. Parameter] dialog.

*6 Select this option when connecting the temperature controller network or PLC2Way.

*7 Select this option for UG-Link connection.

- *8 Select this option when using the touch switch input function with the option unit "UG30A-RIS" mounted.
 *9 Select this option when using the ladder transfer function.
 *10 Select this option for Modbus slave connection.
 *11 Select this option when connecting the printer with serial interface.
 Refer to page 2-20.

Combination of MJ1 and MJ2 Functions

○ : Usable at the same time.

△ : Usable at the same time with UG00S-CW 3.0.0.0, SYSTEM PROG Ver. 1.010 and later

× : Not usable at the same time

MJ2 \ MJ1	Multi-Link 2	Card Recorder	Barcode	UG00P-U2	Temp./PLC 2Way	UG-Link	Touch Switch	Ladder Tool	Modbus Slave	Printer (Serial Port)
Multi-Link 2		○	○	○	△	○	○	×	○	○
Card Recorder	○		○	○	○	○	○	○	○	○
Barcode	○	○		○	○	○	○	○	○	○
UG00P-U2	○	○	○		○	○	○	○	○	○
Temp./PLC 2Way	△	○	○	○		○	○	○	○	○
UG-Link	○	○	○	○	○		○	○	×	○
Touch Switch	○	○	○	○	○	○		○	○	○
Ladder Tool	×	○	○	○	○	○	○		○	○
Modbus Slave	○	○	○	○	○	×	○	○		○
Printer (Serial Port)	○	○	○	○	○	○	○	○	○	

Supplemental Remark:

Multi-link communication and temperature control network/PLC2Way can be used at the same time.

Combination of Communication Unit (UG031-x) and Modular Jack Function

○ : Usable at the same time. × : Not usable at the same time

Communication Unit \ MJ	Multi-Link 2	Card Recorder	Barcode	UG00P-U2	Temp./PLC 2Way	UG-Link	Touch Switch	Ladder Tool	Printer (Serial Port)	Built-in Ethernet
UG031-J	OPCN-1	×	○	○	○	○	○	○	○	○
UG031-T	T-LINK	×	○	○	○	○	○	○	○	○
UG031-C	CC-Link	×	○	○	○	○	○	○	○	○
UG031-E(2)	Ethernet	△ ^{*1}	○	○	○	○	○	○	○	×
UG031-E(2)	FL-net	×	○	○	○	○	○	○	○	×
UG031-P	PROFIBUS-DP	×	○	○	○	○	○	○	○	○
UG031-S	MELSECNET/10	×	○	○	○	○	○	○	○	○



*1 This is not possible when the POD and the PLC are connected via Ethernet.

Transferring Screen Data

- Use modular jack 1 (MJ1) when transferring screen data.
- When [Editor Port] is selected for [Modular Jack 1] on the editor, it is possible to transfer data in the RUN mode because the RUN/STOP mode (on the Main Menu screen) can be automatically selected.
Also RUN/STOP mode is automatically selected for on-line editing and simulation.
- When an option other than [Editor Port] is selected for [Modular Jack 1], select the STOP mode (on the Main Menu screen) and transfer screen data. Simulation or on-line editing is not available.
- When transferring screen data, use our data transfer cable (UG00C-T) 3 m to connect the POD to a personal computer.

Barcode Reader Connection

- It is possible to receive the signal from a barcode reader by connecting the barcode reader at the modular jack (MJ1/2) of the POD.
- To connect a barcode reader to the modular jack (MJ1/2), use our optional cable (UG00C-B).
Length: 3 m with modular plug
- Notes on connection
 - In the case of barcode readers with CTS and RTS control, it may be necessary to install a jumper to RTS and CTS. Otherwise the barcode reader may not work correctly.
 - The external power supply (+5 V) is max. 150 mA. (Refer to page 2-13.)
- When using the barcode reader that was connected to UG400 (POD UG's old version), connect it to the D-sub 9-pin female connector using the UG00C-B cable as shown below.



6. 10BASE-T (LAN)


The connector for 10BASE-T is provided as standard on UG30 (high-performance). To connect Ethernet with UG30 (standard), use the communication unit "UG03I-E(2)". If UG03I-E(2) is attached to UG30 (high-performance), it has priority over the built-in 10BASE-T; 10BASE-T cannot be used.

10BASE-T Connector

Use this connector for Ethernet connection.


- For UG330:

Side View



- For UG430/UG530:


Bottom View



CAUTION

MJ1/2 and LAN connector are 8-pin modular jacks. Check the name plate and insert the connector in the correct position.

The LAN (10BASE-T) pins correspond to signals as given below.


LAN	Pin No.	Signal Name	Contents
	1	TX+	Ethernet send signal (+)
	2	TX-	Ethernet send signal (-)
	3	RX+	Ethernet receive signal (+)
	4	NC	Not used
	5	NC	Not used
	6	RX-	Ethernet receive signal (-)
	7	NC	Not used
	8	NC	Not used

Wiring




CAUTION

When using the LAN port, keep the LAN cable away from the power supply cable as much as possible.




Cable Connection Diagram

Straight cable
(with HUB)



* Unshielded twist-pair cable

Cross cable
(without HUB)



* Unshielded twist-pair cable

Recommended Cable

Use the following recommended cable.

Recommended cable	10BASE-T	Type: Twist-pair cable, category 5
-------------------	----------	------------------------------------

7. CF Card (CF)

Recommended CF Cards

CF cards in compliance with CompactFlash™ can be used.
The operation of the following cards has been verified by us.


Manufacturer	Type	Capacity
Kodak	KPCN-32	32 MB
	SDCFB-64-505	64 MB
SanDisk	SDCFB-xxxx-801	32 MB 64 MB 96 MB 128 MB 192 MB 256 MB 384 MB 512 MB 1 GB
I-O Data Device	CFS-32MA	32 MB
	CFS-xxM(HI)	32 MB 64 MB 128 MB 256 MB 512 MB
	CFS-iVxxx	32 MB 64 MB 128 MB 256 MB 512 MB
Hagiwara Sys-Com	HPC-CFxxZX	32 MB
Melco	RCF-XX	64 MB 128 MB 256 MB 512 MB

Mounting and Dismounting the CF Card

The CF card interface is provided on the side of the unit.


- For UG330:

Side View




- For UG430/UG530:

Side View



1. Insert the card securely into the interface with the card backside outwards viewed from the rear of the unit as shown below.



2. To remove the card, press the eject button. The card pops out.



Notes on Handling the CF Card

1. POD can recognize a CF card in the FAT file system. It cannot recognize a FAT32-formatted CF card.
2. Do not insert or remove the CF card during access. Doing so may destroy data on the CF card. The CF card can be inserted or removed safely when the Main Menu screen is displayed. Before mounting or removing the CF card, be sure to check that the CF card is not being accessed. Doing so may destroy data on the CF card or cause CF card failure. However, if the [Card Menu] switch is pressed on the Main Menu screen and the CF card operation screen is displayed, it is not possible to insert or remove the CF card.
3. Do not turn the power off or on during access to the CF card.
4. Make a backup copy of the CF card at regular intervals.
5. If there should be a disk error and you cannot read/write data, you can scan the disk in Windows to restore the disk data. If not restored, initialize the CF card. Note that the data in the CF card will be completely deleted by initialization. (For more information on scanning the disk or operating Windows, refer to the Windows manual.)
6. The number of writing times per CF card is limited (approx. 300,000 times). Consequently, frequent writing at short intervals may shorten service life of the CF card. To use the CF card for saving sampling data, check the setting for sampling time. Also, avoid repeated writing using a CYCLE macro command.

8. Printer Connection (PRINTER)

When the POD is connected to a printer, a screen hard copy, data sheet or sampling data can be printed.

To connect a printer with parallel interface, insert the cable into the printer connector (PRINTER); to connect a printer with serial interface, insert the cable into a modular jack (MJ1/MJ2).



CAUTION


Be sure to turn the printer off when the POD unit is turned off.

Printer Connector (PRINTER)

This is the printer connector for parallel interface.


- For UG330:

Bottom View



- For UG430/UG530:

Bottom View




The printer interface pins correspond to signals as given below.

PRINT (half-pitch 20-pin)	Pin No.	Signal Name	Contents
	1	STB#	Strobe
	2	PD0	Data 0
	3	PD1	Data 1
	4	PD2	Data 2
	5	PD3	Data 3
	6	PD4	Data 4
	7	PD5	Data 5
	8	PD6	Data 6
	9	PD7	Data 7
	10	GND	
	11	BUSY#	Busy
	12	GND	
	13	SELECT	
	14	INTP#	INP PROME#
	15	PFAT#	FAULT#
	16	GND	
	17	GND	
	18	P+5V	PRN+5
	19	GND	
	20	GND	

Connecting Cable

- To connect the POD to a printer, use our printer cable "UG30C-C" 2.5 m for 20-pin parallel interface.
- For the CBM292/293 printer, use the UG30C-A printer cable (2.5 m).



Compatible Printer Models

Control code system:

- PR201 PC-PR201 series compatible with MS-DOS computer
- ESC-P ESC/P24-J84, ESC/P-J84, ESC/P super function compatible with MS-DOS computer

Others:

- CBM292/293 CBM's line thermal printer (Screen hard copying is not possible.)
- MR400 Sato's barcode printer "MR400 series" (It is not possible to print a screen hard copy, data sheet or sampling data.)
- EPSON STYLUS PHOTO series EPSON color ink jet printer STYLUS PHOTO series (For printer models, refer to the separate User's Manual <Supplementary Manual> (FEH376-1).)

Connection with Printer through Serial Interface

- To connect a printer through serial interface, connect the cable to a modular jack (MJ1/MJ2).
- Refer to the specification sheet of the printer to be used for the connecting cable for serial interface.
For information on MJ1/MJ2 signals, refer to page 2-13.
- When two printers are connected through parallel interface and serial interface, the one connected to MJ1/MJ2 (refer to page 2-13 for the setting) takes precedence.
- Printer models and available print functions are the same as those for parallel interface.

MEMO

Please use this page freely.


3 Installation

1. Mounting Procedure
2. Power Supply Cable Connection

1. Mounting Procedure

Mounting Procedure


- Cut out the mounting panel (max. thick: 5 mm) to match the dimensions shown below.




- Insert four fixtures attached to the POD into the mounting holes, and tighten them with the locking screws.

<Tightening torque>

UG330/UG430	: 0.3 to 0.5 N•m
UG530	: 0.5 to 0.7 N•m




- * When the POD unit is attached to the mounting panel, the fixtures and frame grounds (FG) are connected. To prevent static electricity, be sure to connect the mounting panel to the frame ground.



- Mount the gasket so that it will be sandwiched securely between the unit and the mounting panel.

Mounting Angle

Install the unit within the angle of 15° to 135° as shown on the right.



2. Power Supply Cable Connection







DANGER

Electric shock hazard
Shut the power off before connecting the power supply cable.

Power Supply Cable Connection

- Connect the power supply cable to the terminal on the backside of the unit.
 - UG330
 - UG430/UG530





- When connecting the power supply cable, tighten the terminal screws to the following torque.

Model	Terminal Screw		
	Screw Size	Tightening Torque	Crimp-style Terminal (Unit: mm)
UG330	M3.5	0.5 N•m	7.1 MAX 7.1 MAX
UG430/UG530	M4	0.5 N•m	7.9 MAX 7.0 MAX


- The power source must be within the allowable voltage fluctuation.
- Use a power source with low noise between the cables or between the ground and the cable.
- Use as thick a power supply cable as possible to minimize drop in voltage.
- Keep cables of 100 VAC and 24 VDC sufficiently away from high-voltage, large-current carrying cables.

- Be sure to attach the terminal cover to the terminal block.
 - For UG330:
Attach the terminal cover (supplied) to the terminal block.
 - For UG430/UG530:
When closing the terminal cover, hold one end of the cover as shown below.



Notes on Usage of 100-240 VAC Specifications

- Generally, an isolating transformer improves noise resistance. However, if the display unit is far away from the secondary port of the transformer and noise gets mixed in, an isolating transformer becomes unnecessary.
- If any power voltage fluctuation caused by noise is expected, it is recommended that a voltage stabilizer (effective in noise resistance) be used.




Grounding



Be sure to establish a ground of POD.
(The level of grounding resistance should be less than 100Ω.)

- An independent earth pole must be used for POD.
- Use a cable which has a nominal cross section of more than 2 mm² for grounding.
- Set the grounding point near the POD to shorten the distance of grounding cables.
 - * When the POD unit is attached to the mounting panel, the fixtures and frame grounds (FG) are connected. To detach the FG terminal from the ground, attach the insulating sheet to the fixtures and the mounting panel for insulation.



MEMO

Please use this page freely.

4 Instructions

1. Coin-type Lithium Battery
2. DIP Switch Setting
3. Function Switches

1. Coin-type Lithium Battery

CAUTION


The POD is delivered without inserting the battery connector in the battery holder on the back of the unit.
 Be sure to set the battery when using the calendar function or SRAM.
 Without battery, the contents in the SRAM or calendar will not be retained.

Battery Mounting Procedure

DANGER


Electric shock hazard
 Steps 2 to 5 must be performed when the power to the POD unit is turned off.

1. Turn the unit off.
2. Slide the battery holder cover in the direction of the arrow as shown in the left illustration below to open it.



3. Check that the battery is securely attached to the backside of the cover, and connect the battery connector.
4. Close the battery holder cover.
5. Enter a date five years from now for "Battery replacement" on the sticker on the battery holder.

* The battery status is output to the internal memory \$s167 of the POD.
 If the battery voltage drops before five years has elapsed, replace the battery immediately.



Enter a date five years from now

	MSB	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00	LSB
\$s167		0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	

Memory cassette information reserved (Setting: 0)

- 0: Battery OK
- 1: Battery voltage drop
- 2: No battery

- 0: No memory cassette mounted
- 1: FROM 2 Mbyte (UG20)
- 2: FROM 4 Mbyte (UG20)
- 3: SRAM 512 byte (UG30/UG20)
- 4: FROM 8 Mbyte (UG30)


Memory cassette information reserved (Setting: 0)

6. Turn on the power to the POD unit and check that the battery is correctly mounted on the Main Menu screen.

When the battery is not connected, the [SRAM/Clock] switch blinks and the message "Battery not set" is displayed at the bottom left corner. When the battery is correctly connected, the [SRAM/Clock] switch goes out and the message is cleared.

When the battery voltage has dropped, the message "Brownout Battery" is displayed.

Main Menu screen



Battery Replacement

Safety Instructions on Handling the Battery

Lithium batteries contain combustible material such as lithium or organic solvent. Mishandling may cause heat, explosion or ignition resulting in fire or injury. To prevent accidents, pay attention to the following cautions when handling the lithium battery.

CAUTION



- Be sure to discharge static electricity from your body before battery replacement.
- Use the battery "UG30P-BT" (replacement battery for the UG30) for replacement.
- Rough handling of the battery may cause a fire or chemical burn hazard.
- Do not disassemble, incinerate or heat the battery.
- Observe the local and governmental regulations when disposing of waste batteries.
- Keep batteries out of reach of children (If swallowed, immediately consult a doctor.)
- Never re-charge the battery.
- When the battery leaks or smells, the leaking battery electrolyte may catch a fire. Keep from heat or flame.

Battery Replacement Procedure

Replacement batteries are available from us.

Name	Type	Contents
Replacement battery for the UG30	UG30P-BT	<ul style="list-style-type: none"> Coin-type lithium primary cell 1 pce Cautions sticker 1 pce

- Replace the battery "UG30P-BT" within three minutes after the unit is turned off. If it is not possible to replace within three minutes, use the UG00S-CW editor (cable: UG00C-T) or a CF card and make a backup copy of data in the SRAM.
 - When using the UG00S-CW editor:
 - Start the editor.
 - Click the [Transfer] icon. The [Transfer] dialog is displayed.
 - Select [Display] for [Transfer Device] and [SRAM Data] for [Transfer Data]. To save a backup copy from the editor on the server via Ethernet, check [Transfer through Ethernet/IP Address of the UG Equipped with SRAM]. Keep [Use Simulator] and [Read Comments in Data Transfer] unchecked.
 - Click the [PC <-] under [Transfer Mode].
 - Save the read data in the "*.RAM" file.
 - When using a CF card:

For the backup procedure with a CF card, refer to "Chapter 6 POD Operations".
- Turn the unit off, and open the battery holder. A battery is set at the socket.
- Unplug the battery connector, and remove the battery from the socket. Take out the battery while pressing the center of the battery holder cover as shown in the figure.
 
- Set a new battery. Fit the battery into the socket in such a manner that the red cable side of the battery faces the board and the cable branches from the bottom. Insert the battery in the "b" side first, and push it down to "b" while inserted in the "a" side.
 
- Plug in the battery connector and close the battery holder cover.
- Remove the existing caution sticker. Enter a date five years from now for "Battery replacement" on the new caution sticker, and attach it to the backside of the unit.
- When the backup copy of the SRAM data has been saved in step 1, turn on the unit and load the data to the unit.

2. DIP Switch Setting

DIP Switch (DIPSW) Setting


Set the terminating resistance for RS-422/485 connection with the DIP switch.
When setting the DIP switch, turn the power off.

- For UG330:

- For UG430/UG530:

Side View

Rear View



*1 UG330H-VH4: Available with hardware ver. "a" and later
UG330H-xS4/UG430/UG530: Available with hardware ver. "b" and later
Check the hardware version with the character (in alphabetical order) at the third digit from the left of the serial number on the backside of the POD unit.

* Set DIPSW2 to 4 (not used) to the OFF position.

Terminating Resistance Setting (DIPSW5, 6, 7, 8)

- When connecting the PLC at CN1 via RS-422/485 interface (2-wire connection), set DIPSW7 to the ON position.
- When connecting the PLC at CN1 via RS-422/485 interface (4-wire connection), set DIPSW5^{*1} or 7 to the ON position.
- For the following connections at modular jack 1 (2), set DIPSW6 (DIPSW8) to the ON position.
 - Master station for multi-link 2 connection
 - Temperature controller network/PLC2Way connection via RS-485
 - Card recorder: Connection with the UG00P-MR (optional)
 - Serial extension I/O: Connection with the UG00P-U2 (optional)
 - Connection to the POD at the termination of UG-Link connection via RS-485

CF Auto Load (DIPSW1)

A screen data file saved on a CF card can be auto-loaded as described below.

1. Transfer screen data from the computer to a CF card. (Refer to the User's Manual <Operation> (FEH375) for more information.)
2. Set DIPSW1 in the ON position, and insert the CF card that contains the screen data file.
3. Turn the unit on. The screen data is automatically loaded into the FLASH memory of the unit.



3. Function Switches

Types

- There are eight function switches provided.
[SYSTEM], [F1], [F2], [F3], [F4], [F5], [F6], [F7]

[SYSTEM] Switch

The [SYSTEM] switch works in “alternate” operations. When this switch is pressed once, the switch menu is displayed at the side of the function switches [F1] to [F5], and each function switch corresponds to the menu item displayed in the switch menu. When the [SYSTEM] switch is pressed again, the switch menu disappears, and the function switches [F1] to [F7] work as defined by the user. (page 4-6)



User-defined Function Switches [F1] to [F7]

- When the POD is in the STOP mode, the function switches do not work.
- When the POD is in the RUN mode and the switch menu by the [SYSTEM] switch is not displayed, the function switches can be defined by the user.
- User-defined function switches should be set in the following dialogs of the editor.
 - Settings for each screen
[Edit] → [Local Function Switch Setting] → [Function Switch Setting] dialog
 - Setting for all screens
[System Setting] → [Function Switch Setting] → [Function Switch Setting] dialog

[F1] to [F5] Switch Functions with Switch Menu

Functions		Contents				
F1	Mode	Selects the operation mode between STOP ↔ RUN.				
F2 F3 F4	Contrast Brightness	Item	Contrast Adjustment		Brightness Adjustment	
			Adjust the contrast. Holding down the switch for one second or more changes the contrast rapidly.		Adjusts the screen brightness in three levels.	
		Applicable Models	UG330H-SS		UG430, UG530	
		Adjustment	F2 F3 F4 ←—————→ Dark Medium Pale		F2	F3 ^{*1}
			1 Bright	2 Medium	3 Dark	
F5	Backlight	Turn the backlight on and off. Backlight control should be set on the editor. ([System Setting] → [Unit Setting] → [Unit Setting] dialog, [Backlight] tab window)				
		Always ON	Auto 1/Auto 2/Auto 3		Manual/Manual 2	
		Ignored	<ul style="list-style-type: none"> • The [F5] switch turns the backlight off. • This is valid when the backlight control bit (bit 11) in the read area "n + 1" in the system memory is reset (OFF: 0). 		<ul style="list-style-type: none"> • Manual The [F5] switch turns the backlight off. To turn it on, press somewhere on the screen or a function switch. • Manual 2 The [F5] switch turns the backlight on and off. • [Backlight Power ON Time Control] that determines the backlight status at power-up becomes valid. When the power is turned on: ON → Backlight ON OFF → Backlight OFF 	


*1 When a medium or dark brightness is set, the backlight service life may become shorter.

5 Connections


1. 1 : 1 Connection
2. 1 : n Connection (Multi-drop)
3. n : 1 Connection (Multi-link 2)
4. n : 1 Connection (Multi-link)
5. Universal Serial Communications
6. UG-Link
7. PLC2Way
8. Temperature Control Network
9. Ethernet
10. Other Networks

1. 1 : 1 Connection

- One set of the POD is connected to one PLC (1 : 1 connection).




- The host link unit of the PLC or the CPU port is used and the POD (master station) establishes communications according to the protocol of the PLC. Consequently, it is not necessary to have the dedicated communication program on the PLC (slave station). The POD reads the PLC memory for screen display. It is also possible to write switch data or numerical data entered through the keypad directly to the PLC memory.



- For more information on wiring and communication settings, refer to the User's Manual <PLC Connection> (FEH380).

2. 1 : n Connection (Multi-drop)


One POD is connected to multiple PLCs. (Maximum connectable PLCs: 31)



- For more information on wiring and communication settings, refer to the User's Manual <PLC Connection> (FEH380).

3. n : 1 Connection (Multi-link 2)


- One PLC is connected to a maximum of four PODs.
- An original network is created where the POD (Local Port 1) that is directly connected to the PLC is the master station, and other three PODs are slave stations. Only the master station makes communications directly with the PLC, and the slave stations make communications with the PLC via the master station.



- Communications between the POD master station and the PLC depend on the communication speed set on the PLC. The maximum available speed for the POD is 115 kbps, which is higher than the one available with multi-link connection described in "4. n : 1 Connection (Multi-link)."
- This multi-link connection is available with almost all the PLC models that support 1 : 1 connection. (The connection between the master station and the PLC is the same as the one for 1 : 1 connection.)
- Use the RS-485 2-wire connection between stations of the POD. Please use our multi-link 2 master cable (UG00C-H) for connection between the master station (Local Port 1) and the slave station (Local Port 2).
- When the communication interface unit (example: T-Link, OPCN-1, Ethernet, etc.) is used, "multi-link 2" cannot be used.
- The UG30 and UG20 Series can be used together. The UG20 Series can be the master station. (However, when UG221/UG220 is the master station, the slave station must be UG221/UG220. Also, depending on the hardware version of the UG20 Series, multi-link 2 connection may not be supported. Refer to the User's Manual <UG20 Series Hardware> (FEH352).)
- For more information on wiring and communication settings, refer to the User's Manual <PLC Connection> (FEH380).

4. n : 1 Connection (Multi-link)


- One PLC is connected to multiple PODs. (Maximum connectable units: 31)



- The PLC must be of the type of signal level RS-422/RS485 with station numbers. RS-422 connection between the POD ↔ PLC must be in 2-wire connection.
- The UG30 and UG20 Series can be used together.
- For more information on wiring and communication settings, refer to the User's Manual <PLC Connection> (FEH380).


5. Universal Serial Communications

- A general purpose computer or an ASCII unit of the PLC (master station) controls the POD (slave station) using dedicated commands.



- The POD internal user memory addresses (\$u) must be used for memory allocation for switch, lamp or data display parts.
When the master station specifies a screen number, data is written to the internal memory address (\$u) allocated for the screen. If the screen is switched internally, the new screen number is read and is written to the internal memory address (\$u) allocated for the screen.
- For 1 : 1 connection, the POD can send an interrupt to the master station through switch activation, write command from the keypad, and screen change.
- Use CN1 of the POD for connection with a general-purpose computer. Either signal level RS-232C or RS-422 (RS-485) can be selected.
- In addition to 1 : 1 connection, 1 : n connection is available between the general-purpose computer and the POD via RS-422.
(A maximum of 32 PODs can be connected.)
For 1 : n connection, interrupts cannot be used.


General-purpose computer



- For more information, refer to the User's Manual <PLC Connection> (FEH380).


6. UG-Link

- “UG-Link” is the network where the computer reads from and writes to the internal memory of the POD, memory card, PLC memory or temperature control/PLC2 memory using a dedicated protocol.



- Use the MJ port of the POD for connection with a general-purpose computer. For connection to the PLC using a temperature controller or the PLC2Way function, use the other MJ port and use CN1 for communications with the PLC. Data of the PLC or temperature controller can be collected through communications with the POD. Data collection is available even between the products of different manufacturers.
- Either signal level RS-232C or RS-485 can be selected. With RS-232C, one POD can be connected; with RS-485, a maximum of 31 PODs can be connected.


<RS-485 connection>




- For more information, refer to the User's Manual <PLC Connection> (FEH380).

7. PLC2Way

- The “PLC2Way” function is an original network function where one POD can be connected to two PLCs. Even if the manufacturers of these PLCs are not the same, they can be connected to one POD.




- Connect one PLC to the CN1 connector, and the second PLC to the MJ port.
- With the PLC2Way function, it is possible to communicate with PLCs without special program in the same way as 1 : 1 connection. Two PLCs that are connected to the POD are controlled at the same time, and memory read/write operations are available with these two PLCs.
- Connection at the MJ port can be performed via RS-232C or RS-485 (2-wire). With RS-232C, one PLC can be connected; with RS-485, a maximum of 31 PLCs can be connected.



- Constant reading/sampling of PLC data connected to the MJ port
When read/write memory addresses are preset on the temperature control network/PLC2Way table, background data reading is performed at regular intervals. It is also possible to save the read data in the POD internal buffer, SRAM or CF card.
- Data transfer between PLCs
The PLC memory data can be transferred to another PLC in blocks using a macro command.
- For more information, refer to the User's Manual <PLC Connection> (FEH380).

8. Temperature Control Network


- Using the temperature control network, the POD can be connected to the temperature controller or inverter.
With RS-232C, one PLC can be connected; with RS-485, a maximum of 31 temperature controllers can be connected.




- Data of temperature controllers connected to the POD can be set or monitored.
- Periodical reading/sampling of temperature controller data
When read/write memory addresses are preset on the temperature control network/PLC2Way table, background data reading is performed at regular intervals. It is also possible to save the read data in the POD internal buffer, SRAM or CF card.
- Data transfer
It is also possible to transfer data in the PLC memory, POD internal memory or a memory card to the temperature controller at one time using a macro command. Conversely, data in the temperature controller can be transferred to the PLC memory, POD internal memory or a memory card at one time.
- For more information, refer to the User's Manual <Temperature Control Network> (FEH365).

9. Ethernet


- Transferring data in memory
Data in memory can be transferred to the POD on the Ethernet or to the PLCs linked to the POD as a host by using macro commands (ERead/EWRITE).




- Communications between the server and the POD
 - "HKEtn10.dll" (for UDP/IP protocol) is provided so that the user can create an original application by using Visual C++ or Visual Basic, etc. to allow the server to access the memory device, such as POD internal memory, memory card or the PLC memory linked with the POD as a host..... (a)
 - The macro command (SEND) enables the POD to access the server..... (b)




- Screen data can be transferred from the UG00S-CW editor on the server to the POD.



- Communications between the Ethernet-ready PLC and the POD
 - The POD can communicate with the PLC on the Ethernet.



- The POD can communicate with multiple PLCs on the Ethernet.




- For more information, refer to the User's Manual <PLC Connection> (FEH380).

10. Other Networks

FL-net (OPCN-2)

- FL-net (OPCN-2) is standard specifications of the controller-level FA network that the Manufacturing Science and Technology Center has developed, which enables a communication network between multi-vendor programmable controllers, NCs and robot controllers. It is possible to connect FA controllers and computers, such as programmable controllers (PLCs) or NC controllers (CNCs), of different manufacturers as shown below for control and monitoring.




- To use FL-net (OPCN-2) communications on the POD, the communication interface unit “UG03I-E(2)” must be mounted. When the POD is equipped with the communication interface unit UG03I-E(2), it becomes an FL-net (OPCN-2)-ready device.
- When UG03I-E(2) is mounted for FL-net (OPCN-2) communications on UG30 (high-performance type), the 10BASE-T connector (LAN) provided on the unit cannot be used. Consequently, it is not possible to use FL-net (OPCN-2) communications and Ethernet communications at the same time.
- When transferring screen data, use the 10BASE-T connector on the communication interface unit UG03I-E(2).
Be sure to set the IP address, etc. on the Main Menu and Ethernet screens.
For the setting procedure, refer to “Chapter 6 POD Operations.”
- For more information, refer to the User’s Manual <FL-Net Communications> (FEH367).

CC-Link

- CC-Link is the network that is developed by MITSUBISHI Electric Corporation. The POD works as a local station (intelligent device station).
- To use CC-Link communications on the POD, the communication interface unit "UG03I-C" must be mounted. When the POD is equipped with the communication interface unit UG03I-C, it becomes a CC-Link-ready device.
- For communications with the PLC, no program is required in the same way as communications via a link unit.
- It is possible to perform high-speed communications by connecting multiple remote/local stations to one master station (PLC).


Example: System configuration with two PODs




- For more information, refer to the User's Manual <CC-Link Communications> (FEH355).

OPCN-1

- To use OPCN-1 communications on the POD, the communication interface unit “UG03I-J” must be mounted. When the POD is equipped with the communication interface unit UG03I-J, it becomes an OPCN-1-ready device.
- The POD that supports OPCN-1 communications is a programmable display that can perform data transfer with the master station (PLC, etc.) in compliance with “JEM-F3008 programmable controller field network standard (level 1)” (normally called “OPCN-1”) that is determined by the Japan Electrical Manufacturers' Association.
- The GET/PUT service is supported, and communications with the PLC can be performed without program in the same way as communications via a link unit.
- The POD that supports OPCN-1 communications falls in the TYPE-S51I class.



- It is possible to perform high-speed communications by connecting multiple slave stations to one master station (PLC).
Example: System configuration with two POD units




- For more information, refer to the User's Manual <OPCN-1 Communications> (FEH358).

T-LINK

- To use T-LINK communications on the POD, the communication interface unit "UG03I-T" must be mounted. When the POD is equipped with the communication interface unit UG03I-T, it becomes a T-LINK-ready device.
- The POD that supports T-LINK communications can perform long-distance high-speed data transmission with the Fuji Electric FA's PLC MICREX-F series and MICREX-SX series.
- The POD updates the display when the read data (POD ← PLC) is changed. The POD reads data from the PLC memory addresses that are allocated to the items placed on the screen, such as lamp parts or counter parts.

When switch data or counter setting data on the POD should be written, the POD issues a write command to the PLC and writes the output data to the PLC memory.


These operations are automatically performed on the POD unit and no special communication program is required on the PLC side.



- For more information, refer to the User's Manual <T-Link Communications> (FEH356).

PROFIBUS-DP


- PROFIBUS is an open field bus independent on the bender that is used for various applications in factory automation and process automation. PROFIBUS provides a communication protocol (communication profile) that supports system hierarchy, i.e. DP and FMS.
- When the POD is equipped with the communication interface unit UG03I-P is mounted, PROFIBUS-DP communications can be performed.



The POD can work as a slave station on PROFIBUS-DP.
 A maximum of 12 Mbps is available (automatically set to the BUS baud rate).
 The signal level is RS-485.

* The POD can only communicate with the master PLC.

- PROFIBUS-DP supports I/O communications only. With I/O communication, it is not possible to directly access the device memory (DB or MW) used in the CPU. To enable the POD to have direct access to these memory devices, we supply the function (ladder file) for message communications. When this function is loaded in the master CPU, message communications using our original protocol are enabled, and the POD can have access to any memory address.



- For the procedure of loading our function, refer to the User's Manual <PROFIBUS Communications> (FEH368).

MEMO

Please use this page freely.

6 POD Operations


1. Operational Procedures
2. Main Menu Screen

1. Operational Procedures


POD Operation

Follow the procedure below to operate the POD.

1. Installation and wiring
For more information, refer to “Chapter 3.”
2. Connection with devices including a PLC and a temperature controller
For instructions and precautions on wiring between the POD and other devices, refer to the User's Manual <PLC Connection> (FEH380).
3. POD power-on
 - New POD



- Other than the above
When the check screen below and then the next user screen are displayed correctly, go to step 5.




4. Screen data creation and transfer
 - New POD
“Initial Screen” (page 6-2)
 - Other than the above
Refer to Chapter 5, “Data Transference” in the User's Manual <Operation> (FEH375).
5. Operation start
The POD becomes operable with a PLC or a computer connected to it.
 - * If the POD does not operate normally and shows an error message, eliminate the cause by referring to “Chapter 7.”


Initial Screen

When the power of POD is turned on for the first time, the Main Menu screen shown below on the left is displayed.

Initial screen displayed when power is turned on for the first time





Main Menu screen after transferring screen data



Transferring Screen Data for the First Time


There are four methods for transferring screen data for the first time.

- Transferring screen data via the UG00C-T cable
Transfer screen data from the computer while the initial screen is displayed.
- Transferring screen data using the CF card or the memory card and the card recorder (UG00P-MR)
 - Connect the personal computer with the card recorder and save screen data on the memory card.
 - Insert the CF card into the POD or connect the card recorder and insert the memory card into the card recorder (UG00P-MR).
 - Press the [CF Card (English)] switch. The "Card Menu" screen is displayed.
 
 - Follow the instructions as described in "Card Menu Screen" (page 6-11) and transfer screen data.
- Transferring screen data via Ethernet
 - Press the [IP Address (English)] switch.
 
 - The "Ethernet" screen is displayed. Follow the instructions as described in "Ethernet" (page 6-23) and set the IP address. Press the [Setting Finished] switch. The initial screen is displayed again.
 - Transfer screen data from the computer via Ethernet.
- Auto-uploading screen data from the CF card to the POD
 - Transfer screen data from the computer to a CF card.
 - Turn the POD unit off. Set the DIPSW1 on the unit to the ON position, and insert the CF card.
 - Turn the unit on. The screen data is automatically uploaded from the CF card to the POD.

1. I/O Test

When the [I/O Test] switch on the Main Menu screen is pressed, the following "I/O Test" screen appears.

This screen is used to check that there is no problem with the POD interface and touch switch operation.



*1 When the serial extension I/O (UG00P-U2) is connected, use this button to check that the UG00P-U2 works correctly.


The [Ext. I/O Check] switch appears only when [UG00P-U2] is selected for a modular jack on the editor.

1-1. Self-loop Test

This is a signal test for communications through the CN1, MJ1 or MJ2 connector. Perform this test if the communication is not successful when transferring screen data through MJ1, connecting the PLC using CN1, or selecting multi-link 2, temperature controller/PLC2Way or PLC for MJ1/2, or connecting the card recorder or serial extension I/O.

CN1: RS-232C Signal Test


Turn the [CN1] and [RS232C] switches on.



- SD/RD Test

Check the signals [SD] and [RD].

1. Install a jumper between pins 2 and 3 of CN1 on the backside of the POD unit.
2. Press the [Self-Loop Test] switch. When the [OK] lamp lights up, the test is successfully completed.




* If the [NG] lamp lights up, consult your local distributor.

- CTS/RTS Test


Check the signals [CTS] and [RTS].

1. Install a jumper between pins 4 (RTS) and 5 (CTS) of CN1 on the backside of the POD unit.
2. Press the [RTS] switch and check that both [RTS] and [CTS] lamps light up at the same time. Press the [RTS] switch again and check that both [RTS] and [CTS] lamps go off at the same time.



CN1: RS-485 Signal Test


Turn the [CN1] and [RS485] switches on.



- SD/RD Test

Check the signals [SD] and [RD].

1. Install a jumper between pins 12 and 24 and between pins 13 and 25 of CN1 on the backside of the POD unit.
2. Press the [Self-Loop Test] switch. When the [OK] lamp lights up, the test is successfully completed.




* If the [NG] lamp lights up, consult your local distributor.

- CTS/RTS Test


Check the signals [CTS] and [RTS].

1. Install a jumper between pins 14 (+RTS) and 19 (+CTS) of CN1 and between pins 17 (-RTS) and 18 (-CTS) on the backside of the POD unit.
2. Press the [RTS] switch and check that both [RTS] and [CTS] lamps light up at the same time. Press the [RTS] switch again and check that both [RTS] and [CTS] lamps go off at the same time.




MJ1/2: RS-232C Signal Test


Turn the [MJ1] (or [MJ2]) and [RS232C] switches on.



- RS-232C Self-loop Test
Check the signals [SD] and [RD].
Connect the data transfer cable (UG00C-T) to CN1 for the test.



1. Set the adaptor ADP25-9 (attached to UG00C-T) to the cable UG00C-T. Connect the modular jack side of the cable to MJ1 (or MJ2) and the ADP25-9 side to CN1.
2. Press the [Self-Loop Test] switch. When the [OK] lamp lights up, the test is successfully completed.



* If the [NG] lamp lights up, consult your local distributor.


MJ1/2: RS-485 Signal Test

If you would like to perform MJ1/2 RS-485 signal test, consult your distributor.


1-2. Print Check

Check that the POD transmits the signals to the printer correctly.

1. Connect the POD unit to the printer.
2. Press the [Printer Check] switch. The test is successful when a test page is printed out without problem.




Example:



1-3. SYSTEM & Function Switch Test


Check operations of eight switches provided vertically on the right side of the POD's panel. Press the switch, and check that the lamp on the screen lights up while the switch is held down.




1-4. Touch Switch Test

If a touch switch does not activate at all or if an operation is performed without pressing any touch switch, check that the touch switches on the POD's panel are working properly.

1. Press the [Switch Check] switch. Grids appear on the screen as shown below.



2. Press a position on the panel, and check that the pressed position turns white. The switch is activated normally when the pressed position turns white. To move back to the "I/O Test" screen, press the [F4] switch. To delete white dots press the [F5] switch.




3. If a position different from the pressed position turns white, refer to "Touch Switch Adjustment" on the next page and adjust the touch switch position.


Touch Switch Adjustment

If a position different from the pressed position turns white on the touch switch test screen, follow the steps described below to adjust the touch switch position.


1. Hold down the [SYSTEM] switch and press the [F2] switch on the touch switch test screen. The "Touch Switch Adjustment" screen appears.




2. Press on "1" that is flashing at the corner on the touch switch adjustment screen. When the finger is released, a beep sounds and the position is set. "2" flashes.




3. Press on "2" that is flashing at the corner. When the finger is released, a beep sounds and the position is set. "3" flashes.



4. Press on "3" that is flashing at the corner. When the finger is released, a beep sounds and the position is set. "4" flashes.




5. Press on "4" that is flashing at the corner. When the finger is released, a beep sounds and the position is set.



6. To re-set the positions, press the [F2] switch and follow step 2 and later.

7. Press the [F1] switch. A long beep sounds and the positions are determined. The touch switch test screen is displayed again.

8. To cancel the setting, press the [F3] switch. The touch switch test screen is displayed again.




2. Card Menu Screen

When the [Card Menu] switch on the Main Menu screen is pressed, the following “Card Menu” screen appears.

This screen is used to transfer screen data between the POD and a CF card or a memory card.


Moves back to the Main Menu screen or the initial screen.





1. [Memory Card Card Recorder Menu] switch
Press this switch when connecting the card recorder to the MJ port of the POD and transferring screen data between the POD and a memory card.
2. [Screen Data] switch
Press this switch when transferring screen data between the POD and a CF card.
3. [SRAM] switch
Press this switch when saving backup copies of the SRAM memory or UG30P-SR (SRAM cassette) or when uploading the backup data from the CF card to the POD.

2-1. UG00P-MR Menu Screen

When the [Memory Card Card Recorder Menu] switch on the "Card Menu" screen is pressed, the following "Card Recorder Menu" screen appears.
 This screen is used to transfer screen data between the POD and a memory card.
 The procedure for transferring data is described below.




1. Connecting the UG00P-MR
 - Connect the UG00P-MR cable to the MJ port that is displayed in the "Port Selection" field.
 - MJ1:..... Connect the UG00P-MR to the MJ1 port.
Normally MJ1 is selected.
 - MJ2:..... Connect the UG00P-MR to the MJ2 port. Only when [Memory Card] is selected for [Modular Jack 2], "MJ2" is indicated in the "Port Selection" field.
2. Mounting the Memory Card
 Insert a memory card in to the card recorder (UG00P-MR).
3. Memory Card Information
 Press the [Modular Jack MJ1 (MJ2)] switch.
 The memory card information contained in the inserted memory card is indicated.
 Switches in the "Data Selection" field and "Transfer" field become active.




4. Data Selection and Transfer Selection

In the "Transfer" field, select [Display <-- Card], [Display --> Card] or [Display <--> Card]. Press the desired switch to turn the switch on. Multiple switches can be pressed in the "Data Selection" field.



5. Starting Data Transfer

Press the [Start] switch. Data transfer is started. During data transfer, the [Start] switch changes into [Busy] and flashes. When data is transferred, the following message is displayed.




Press the [OK] switch.

6. Press the [Return] switch. The "Card Menu" screen is displayed again.

2-2. Transferring Screen Data from a CF Card

CF Card Folder Configuration

Folders in the CF card are configured as shown below.



DAT0000 (access folder)

Folder Name	Contents	Folder Name	Contents
BITMAP	Saves pattern data (bitmap data) to reduce the screen data capacity.	RECIPE	Reads and writes recipe data.
CARD	Writes recipe data from the UG30 Series using the UG20-compatible memory manager function.	SAMPLE	Saves history data of the data logging function.
DSP	Reads and writes screen data.	SNAP	Saves video snap images.
FONT	Saves Gothic fonts or language data to reduce the screen data capacity.	SRAM	Saves backup data of SRAM.
HDCOPY	Writes hard copy images in the JPEG file format from the POD (UG330H-SS only: BIN file).	WAV	Saves WAV files for sound output to reduce the screen data capacity.
JPEG	Saves JPEG files for display on the screen (except for UG330H-SS).	WEBSERV	Saves files to be accessed from the Web browser.
MEMO	Saves memo pad data drawn with the POD.		

DSPDEF (screen data auto upload folder)


Folder Name	Contents
DSP	Automatically reads screen data in this folder when the CF card is inserted in the unit after the DIP switch is set.

(Other folders are the same as access folders.)


Transferring Screen Data from a CF Card

The procedure of transferring data between the POD and a CF card is described below.

1. Mounting the CF card
Insert the CF card into the CF card connector at the side of the POD unit.
* Do not remove or insert the CF card in the later steps.
2. Data selection
Select [Screen Data]. When the lamp is red, it is selected.
3. Transfer selection
Select [Display <-- Card], [Display --> Card] or [Display <--> Card].



Data selection




Transfer selection

When [Display <-- Card] is Selected:

Transfer screen data from the computer to the CF card.

1. When [Display <-- Card] is selected, the "Card Transfer" screen is displayed.

Flashes during communication with the CF card.



Indicates the name of the currently selected folder.
The access folder that is set for screen data defaults.
If there is no screen data, "DAT0000" defaults.

Indicates the free space in the CF card.


Used for checking or renaming folder names.

Starts transferring data [Display <-- Card].


Moves back to the previous screen.

Indicates the information of the currently selected folder.

2. Check the folder name, free space, and CF card file information. If the correct folder is selected, move to step 4.
 - Folder Name
Indicates the name of the currently selected folder.
The access folder that is set for screen data defaults.
If there is no screen data, "DAT0000" defaults.
 - Rest Size
Indicates the free space in the CF card.
 - CF Card File Information
Indicates the information of the currently selected folder.
3. To change to another folder, press the [Select Folder] switch.
The "Select Folder" screen is displayed.




- To see the details of the folder, press the [Folder Detail] switch.
The "Folder Detail" screen is displayed.




- Select the desired folder using the [↑]/[↓] switch, and press the [OK] switch.
The "Card Transfer" screen is displayed again and the CF card file information of the selected file is indicated.

- Press the [Select Data] switch.
The [Data Selection] window is displayed and the [Select Data] switch changes to [Start].




Select the desired data, and press the [Select Data] switch.



To cancel the [Data Selection] window, press the [Return] switch.


- During data transfer, the [Start] switch changes into [Busy] and flashes. When data has been transferred successfully, the following window is displayed. However, when [Sys. Program] or [Select All] is selected, the Main Menu screen is displayed without this message window on completion of data transfer.



Press the [OK] switch.
The "Card Menu" screen is displayed.
If any other message is displayed, refer to page 6-22.

When [Display --> Card] is Selected:


1. When [Display --> Card] is selected, the "Card Transfer" screen is displayed.



2. Check the folder name and CF card file information, and press the [Start] switch.

* When the access folder name of screen data is the same as that in the CF card, the CF card file information is indicated on the screen, and data in the POD overwrites the CF card data. Note that the CF card data is lost when data is overwritten.
When the CF card file information is blank, a new file "DSP0000.BIN" is created in the DSP folder.

3. During data transfer, the [Start] switch changes into [Busy] and flashes. When data has been transferred successfully, the following window is displayed.




Press the [OK] switch. The CF card file information shows data that has been transferred. If any other message is displayed, refer to page 6-22.


4. Press the [Return] switch. The "Card Menu" screen is displayed again.

When [Display <--> Card] is Selected:

- When [Display <--> Card] is selected, the "Card Transfer" screen is displayed. Screen data used for comparison is that in the DSP folder under the folder having the same name as the access folder that is set on the POD.



- Press the [Start] switch.
- During data transfer, the [Start] switch changes into [Busy] and flashes. When data has been transferred successfully, the following window is displayed.



Press the [OK] switch.


If any other message is displayed, refer to page 6-22.

- Press the [Return] switch. The "Card Menu" screen is displayed again.


2-3. Saving Backup Copies of SRAM

In this section, the procedure for saving backup copies of the SRAM memory in the POD or UG30P-SR (SRAM cassette) for battery replacement is explained.


1. Press the [SRAM] switch on the "Card Menu" screen. When the lamp is red, it is selected.
2. Select [Display <-- Card], [Display --> Card] or [Display <--> Card].




3. The "SRAM Transfer" screen is displayed.
 - When [Display --> Card] or [Display <--> Card] is selected, the following screen is displayed. Select the CF card folder having the same name as the access folder for screen data in the POD. The name is shown on the screen. The transferred file is named as "SRM0000.BIN".



- When [Display <-- Card] is selected, the following screen is displayed.



- 1) To change to another folder, press the [Select Folder] switch.
(The folder name must be "SRM0000.BIN".)
- 2) The "Select Folder" screen is displayed as shown on page 6-16.
Select the desired folder (refer to page 6-16), and press the [OK] switch.
- 3) Moves back to the "SRAM Transfer" screen.
4. Starting data transfer
Check the folder name, free space and transfer selection, press the [Start] switch.
Data transfer is started.
5. Ending data transfer
When data has been transferred successfully, the following window is displayed.



Press the [OK] switch.
If any other message is displayed, refer to the next page.

6. Pressing the [Return] switch moves back to the "Card Menu" screen.

2-4. Messages during Data Transfer

If an error occurs during data transfer, the message window shown on the right is displayed.



The kinds and the contents of the messages are shown below. The same messages are used for the memory card and CF card. When using the CF card, the "memory card" in the explanation should read as the "CF card".

Messages	Contents
Work normally finished.	The specified operation has been concluded normally.
UG00P-MR not connecting	No card recorder is connected when selecting a modular jack.
UG00P-MR Communication Error	A communication error occurred between POD and UG00P-MR when selecting a modular jack.
Memory-Card not setting	Memory-Card not setting
Memory-Card Capacity over	Cannot write the data into a memory card because the data size in POD is larger than the capacity of a memory card.
Write Protect: ON	Cannot write data into a memory card because the write protect switch in a memory card is ON.
Writing Error occurred.	The error occurred while writing data into a memory card.
Selected data does not exist.	The data in the reading target does not exist.
UG type is different.	The specified type of the data in POD is different from the type of the memory card data.
Selected data can not be read.	The data in a memory card cannot be read.
Reading Error occurred.	The error occurred during writing data into a flash ROM of POD.
Data discrepant	There is some discrepancy in data, when comparing data between a memory card and POD.
Screen data on UG will be broken.	Warning about data destruction in POD that may occur when transferring the font data larger than the present data from a memory card to POD. (The [OK] switch continues transferring; the [Cancel] switch stops transferring.)
Undefined Error occurred.	The error occurred due to some cause other than mentioned above.

3. Ethernet

* For more information on the IP address setting, refer to the User's Manual <Supplementary Manual> (FEH376-1).

The "Ethernet" screen is displayed by pressing the [IP Address (English)] switch on the initial screen when transferring screen data via Ethernet for the first time, or by pressing the [Ethernet] switch on the Main Menu screen when transferring screen data to the POD.

This screen is used for setting the IP address (a number that identifies the POD on the network) that is indispensable for Ethernet communications.

Depending on whether the LAN (10BASE-T) connector at UG30 (high-performance type) or the communication interface unit UG03I-E(2) for UG30 is used, the "Ethernet" screen contents and the required settings vary as described below.

Connection with LAN (10BASE-T) Connector at UG30 (High-performance Type)

Selects [Not Use Network Table] or [Use Network Table].*1

Moves back to the Main Menu screen or the initial screen.

Cursor switches

[Increment/Decrement] switch for the value in the cursor position

Determines the setting such as IP address, and moves back to the Main Menu screen.

Used for checking the 10BASE-T interface.
Normal: Connect
Error: Disconnect

*1 Network Table
Register IP addresses and other information for the POD, PLCs or computers that should be included for Ethernet communications on the editor.
([System Setting] → [Network Table Setting] → [Ethernet] → Edit Network Table)
The registered network table can be used or not used depending on the [Not Use Network Table/Use Network Table] switch.

Network table number


No.	Host Name	IP Address	Send Timeout	Internal Memory Write En...	Memory Card Memory Wr...	Port No
0	PLC1	192.168.1.158	15	Enabled	Enabled	10000
1	POD	192.168.1.68	15	Enabled	Enabled	10000
2	PLC2	192.168.1.66	15	Enabled	Enabled	10000
3						
4						
5						
6						

Not Use Network Table

In the following cases, select [Not Use Network Table].

- Screen data is transferred for the first time via Ethernet.
- The network table is not set for screen data of the POD.
- If the network table is set for screen data of the POD but you would like to use an IP address that is different from that set on the network table tentatively, press the [Use Network Table] switch to select [Not Use Network Table].

When the network table is not set or is not used




1. Set the IP address.
(If necessary, set the default gateway and subnet mask.)
2. Press the [Setting Finished] switch. The IP address is determined.
3. The Main Menu screen is displayed again. (If the "Ethernet" screen is displayed from the initial screen, the initial screen is displayed again.)

Use Network Table

In the following cases, select [Use Network Table].


- The network table is set for screen data of the POD and you would like to change the network table number.

When the network table is used:



1. Set the network table number.
2. Press the [Setting Finished] switch. The IP address is determined.
3. The Main Menu screen is displayed again.

Connection with UG03I-E(2) on UG30



1. Select either [10BASE-T] or [AUI] for the connecting method.
 2. Set the IP address.
(If necessary, set the default gateway and subnet mask.)
 3. Press the [Setting Finished] switch. The settings are determined.
 4. The Main Menu screen is displayed again.
- Rotary Switch and Network Table
Register IP addresses and other information for the POD, PLCs or computers that should be included for Ethernet communications on the editor.
([System Setting]→[Network Table Setting]→[Ethernet]→[Edit Network Table])
Set the network table number with the rotary switch on the communication interface unit UG03I-E(2).

Station number to be set with the rotary switch on the communication interface unit UG03I-E(2)

No.	Host Name	IP Address	Send Timeout	Internal Memory Write En...	Memory Card Memory Wr...	Port No
1	PLC1	192.168.1.158	15	Enabled	Enabled	10000
2	POD	192.168.1.68	15	Enabled	Enabled	10000
3	PLC2	192.168.1.66	15	Enabled	Enabled	10000
4						
5						
6						
7						

Date and Time Setting

1. Move the cursor using the [←] / [→] switch, and change the value by pressing the [+] / [-] switch.
2. When the desired date and time are set, press the [Set] switch to determine the setting.
3. The calendar data is updated as set.

Initializing SRAM


When the SRAM memory or cassette is initialized, the data contained is cleared. Double-check before initializing the SRAM memory or cassette.

1. "Extension" is shown when UG30P-SR (SRAM cassette) is mounted; "Built-in" is shown when it is not mounted.
2. Press the [Format] switch and the [Execute] switch.
The SRAM area is initialized in the current screen data format. When initialization has been completed, the message "**Format Completed**" is displayed.

5. Extension Program Information

When the [Extension] switch on the Main Menu screen is pressed, the following "Extension Program Info." screen appears.

The driver setting and parameter setting for temperature controller/PLC2Way communication, ladder transfer function, Modbus slave communication, etc. are displayed.




6. Extended Function Setting

When the [Editor: MJ1] switch on the Main Menu screen is pressed, the following "Extended Function Setting" screen appears.

Set the baud rate to be used when transferring screen data between the POD and a modem.

1. Select the desired baud rate using the [↑] / [↓] switch, and press the [Setting Finished] switch.
(Setting range: 4800, 9600, 19200, 38400, 57600, 115200)
 - * The function switches and switches on the Main Menu screen are not valid for 15 seconds after the [Setting Finished] switch is pressed.
 - * When the [Setting Finished] switch is pressed, an AT command is automatically sent to the modem and the baud rate used between the POD and the modem is set.
2. The [Main Menu] (local main) screen is displayed automatically. [Modem Connect Mode] automatically appears under [Editor: MJ1].
3. To transfer screen data without a modem, select "Not used" for [Modem Comm. Baud Rate].
For screen data transfer while a computer is connected with UG00C-T, specify [Not Used] for [Modem Comm. Baud Rate].



7 Error Correction


1. Error Messages
2. Troubleshooting

1. Error Message


There are five kinds of error messages displayed on the POD:

1. Communication error
2. Check
3. Warning
4. SYSTEM ERROR
5. Touch Switch is active.

1. Communication Error



* When you go to [Comm. Parameter], bring up the [Detail] tab window and set [Continue] for [Comm. Error Handling], a screen like the one shown below is displayed.



Error Message	Contents	Solution	Remarks
Time-Out	Although a request to send is given to the PLC, no answer is returned within the specified time.	1. Check the communication parameters.	1
		2. Check the cables and wiring.	
		3. Data may be disrupted because of noise. Fix noise.	2
Parity	An error occurred in parity check.	1. Check the cables and wiring.	1
		2. Data may be disrupted because of noise. Fix noise.	2
Framing	Although the stop bit must be [1], it is detected as [0].	1. Check the communication parameters.	1
		2. Check the cables and wiring.	
Overrun	After one character is received, the next character is received before internal processing is completed.	3. Data may be disrupted because of noise. Fix noise.	2
		1. Check the communication parameters.	1
Check Code	The check code in the PLC response was not correct.	2. Data may be disrupted because of noise. Fix noise.	2
		1. Check the communication parameters.	1

* If the above error messages are displayed on the POD without establishing communication between POD and PLC, test the solution of remark "1."
If the error occurs suddenly in communication, test the solution of remark "2."

Error Message	Contents	Solution
Error code received	The PLC sent an error code (NAK).	Examine the CPU error code and solve the problem.
Break	The PLC's SD (TXD) remains at the low level.	Examine the connection between the PLC's SD (TXD) and the POD RD (RXD).
Invalid memory (applicable to MITSUBISHI CPU)	You specified an address that exceeds the memory range of the PLC that you are linked to.	Check the type and range of memory that you set.
Invalid CPU model (applicable to MITSUBISHI CPU)	The PLC currently being supported does not have a corresponding CPU.	Confirm whether or not the CPU that you are using can be used with the POD.
Format	The code of the received data is invalid.	Check 1, 2, 3 described below.
Compare (applicable to HIDIC S10)	Transmission data and received data are different.	Check 1, 2, 3 described below.
NAK (applicable to Allen-Bradley PLC)	A NAK code is received.	Check 1, 2, 3 described below.
TNS discrepant (applicable to Allen-Bradley PLC)	Transmitted TNS data and received TNS data are not in agreement.	Check 1, 2, 3 described below.
Communication Error	An unclear communication error is detected.	Check 1, 2, 3 described below.
Count error (applicable to MITSUBISHI CPU and Q link unit)	The expected data amount is different from the count value.	Check 1, 2, 3 described below.
Command error (applicable to MITSUBISHI CPU and Q link unit)	The response code differs from the expected code.	Check 1, 2, 3 described below.
Invalid cassette (applicable to MITSUBISHI ACPU)	This cassette is not included in the memory cassettes currently being supported.	Contact your local distributor.
Password error (applicable to MITSUBISHI QCPU)	The password is incorrect.	Contact your local distributor.

Solution

1. Confirm link unit settings.
(After making settings, cut power to the PLC.)
2. Go to the editor and confirm the settings in the [Comm. Parameter] dialog in the [System Setting] menu.
3. If errors only occur from time to time, it is possible that there is a noise-based communication error.
* If you still cannot solve the error even after following the suggestions above, contact your local distributor.

Error Messages for Network Communication

• Ethernet

Error Message	Contents	Solution
Ethernet Error: XXXX	The Ethernet status is saved at system memory address \$s518 and a code other than "0" (normal) is received. XXXX: Error No.	For the contents and solution to each error number, refer to Appendix 5 of the PLC Connection Manual separately provided.

• CC-LINK

Error Message	Contents	Solution
I/F Board Err	The I/F unit for CC-LINK has an error.	Contact your local distributor.
No. of Occupy Setting Err	The number of occupy in [Comm. Parameter] is different from the number of occupy by switches.	Check the setting of the number of occupy.
Network I/O Access Err	POD is about to access exceeding the set number of input/output words.	Check the memory for the network I/O in the screen data file.
Station Number Err	The station number set by a switch is not within the setting range (1 to 64).	Specify the station number within the setting range.
Word Writing to Sp. Relay	Word writing to a special relay (M9000 and later) is attempted. (Notes: Only bit writing is possible for special relays when connecting with CC-LINK.)	Do not attempt to perform word writing to special relays.

• OPCN-1

Error Message	Contents	Solution
I/F Board Err	The I/F unit for OPCN-1 has an error.	Contact your local distributor.
Stat. No. out of range	The station number set by a switch is not within the setting range (1 to 127).	Specify the station number within the setting range.
Network Link Error	Cannot connect to the master station in the network.	Check the condition of the master station (PLC). Check the network connection.
Network I/O Access Err	POD is about to access exceeding the set number of input/output words.	Check the memory for the network I/O in the screen data file.
Waiting for Reply	1. Less than "Max_int" time (communication monitoring time for salve station) set on the PLC for OPCN-1 communications 2. Timeout on the editor (The timeout time can be set from [System Setting] → [Comm. Parameter] on the editor.) This error is indicated when the above 1 and 2 are present.	When the "Max_int" time is too long (infinite, for example) on the PLC, it is not possible to know whether or not the response from the PLC is correctly made. This error message disappears when a response from the PLC is received within the "Max_int" time.
Word Writing to Sp. Relay (MITSUBISHI: A Series)	Word writing to a special relay (M9000 and later) is attempted. (Notes: Only bit writing is possible for special relays when connecting with OPCN-1.)	Do not attempt to perform word writing to special relays.

• T-LINK


Error Message	Contents	Solution
T-LINK I/F Board Err	The I/F unit for T-LINK has an error.	Contact your local distributor.
Network I/O Access Err	POD is about to access exceeding the set number of input/output words.	Check the memory for the network I/O in the screen data file.
Access denied by Loader	The PLC loader is being accessed so that processing is not performed on POD. (This error occurs during program transfer from the PLC loader for most cases.)	Wait for the PLC loader to finish processing, and press the [RETRY] switch on the POD screen.
Communication Error Received Code No. 32	An attempt to access an area that does not exist within the PLC is made. Example: A file area (W) that is not defined with the PLC program	Check the PLC memory addresses set in the screen data file.
Communication Error Received Code No. 36	The number of monitor registration points is too small.	Correct the number of monitor registration points. For monitor registration, refer to the User's Manual <T-Link Communications> (FEH356).

- PROFIBUS-DP

Error Message	Contents	Solution
Time-Out	"Check" is displayed 2 or 3 seconds before this error occurs when connecting POD and PROFIBUS-DP in the RUN mode.	The setting for [Own Stat. No.] on POD is discrepant with that for [Address] for [UG series] on the SIMATIC Manager. Check and correct the setting.
	A screen is displayed instantaneously (= communications performed) before this error occurs when connecting POD and PROFIBUS-DP in the RUN mode.	The DB address set on the POD screen may not exist on the PLC (memory over). Check the setting.

2. Check

Error Message	Contents	Solution
Screen No. Error	There is no setting for the received screen.	At the start of communications, the POD regards the value in the read area "n + 2" as the screen number. Check that the value in the read area "n + 2" is an existing screen number on the PLC.
Data has some error. Error : XX (XX : XXX)	There is an error in the created screen data.	"Error : XX (XX : XXX)" indicates the edited screen and the contents of the error. For the error details and solutions, refer to the User's Manual <Function> (FEH376) and correct screen data.




Error Message	Contents	Solution
Communication Error Check I/F driver	Although a request to send is given to the computer, no answer is returned within the specified time.	The I/F driver for simulator is transferred. If you do not use the simulator, uncheck [Use Simulator] before transferring data.

3. Warning

An error may be displayed on the Main Menu screen during data transfer.


This is a warning message.

For the warning details and solutions, refer to the User's Manual <Function> (FEH376) and correct screen data.



4. SYSTEM ERROR

When a system error is detected, the following error screen is displayed on the POD.



ERROR: XX

- 1: Watch dog timer error
- 11: Switch table error
- 30: Request for displaying full error
- 31: Memory allocation system error
- 32: General exceptions/MMU address system error
- 33: RTOS system error
- 34: Memory error
- 35: Inaccurate memory error

The source of the error could be one of the following three problems. Contact your local distributor.

- 1) Program crash due to noise
- 2) Hardware problem
- 3) Bad program

Solve relevant problems by following the directions in "Troubleshooting" (page 7-7).


If the problem persists, contact your local distributor.

5. Touch Switch is Active.

If the power is turned off while a touch switch is activated, the error screen shown on the right is displayed.

Remove your finger from the screen.

If the error screen remains displayed, contact your local distributor.






2. Troubleshooting


In the Event of an Error

Perform the steps below:

1. If the current error matches a symptom in the following table, correct it by following the instructions provided.
2. If the error does not match the symptoms in the table, contact your local distributor. Please provide the distributor with the information on the POD model, serial number, symptom of the error, error message (if shown), etc.

Probable Symptoms

Symptom	Cause	Solution
<p>POD is connected to the PLC; however, communication fails. "Communication Error: Time-Out" appears on the screen.</p> 	<p>Probable causes are:</p> <ol style="list-style-type: none"> 1) Cables are not connected correctly or any cable is disconnected. 2) PLC parameter settings are not correct or disagree with the POD settings. 3) The POD is faulty. 	<p>Solutions are:</p> <ol style="list-style-type: none"> 1) Check the cable connection. 2) Recheck the PLC parameter settings. 3) Perform a self-loop test on the "I/O Test" screen (page 6-5). If the test is not successful, please return the POD to your local distributor immediately.
<p>Communications have been successful. However, opening a certain page always causes a "Communication Error: Error code received" error.</p> 	<p>The error code denotes a PLC error (NAK).</p> <ol style="list-style-type: none"> 1) When the error code appears only on a certain screen, a memory address that does not exist on the PLC may be set on the POD screen. 2) When the error code appears at power-on, a memory address that does not exist on the PLC may be set for communication parameters, buffering area, initial macro, etc. 	<ol style="list-style-type: none"> 1) Check if any address outside the allowable range for PLC memory is set on the screen. 2) Check if any address outside the allowable range for PLC memory is set for communication parameters, buffering area, initial macro, etc.
<p>Communications have been successful. However, "Communication Error: Parity" or "Communication Error: Framing" suddenly occurs.</p> 	<p>Noise may cause the error.</p>	<p>Check if appropriate measures are taken against noise.</p> <p>Example: Check if communication and power cables are bundled together. Try to attach a ferrite core to the communication cable. Try to attach a noise filter to the power supply, etc.</p>

Symptom	Cause	Solution
<p>"SYSTEM ERROR: xx" occurs.</p> 	<p>The following causes are probable, depending on the symptoms.</p> <ol style="list-style-type: none"> 1) Turning the power off and back on corrects the error. ↓ Communication failed because of improper timing. 2) Turning the power off and back on does not correct the error. ↓ A certain condition always causes the error. Or the POD is faulty. 3) A CF card is inserted. ↓ The CF card (front and back) may be reversed. <p>If none of the above matches your error, contact your local distributor.</p>	<ol style="list-style-type: none"> 1) If communication is stable after turning the power on again, continue and observe operation. 2) Make a note of the information on error number, etc. displayed on the screen and contact your local distributor. 3) Check that the inserted CF card faces the correct side.
Switches do not work.	<ol style="list-style-type: none"> 1) Switches do not work in the RUN mode. A beep sounds. ↓ Is the switch interlock enabled? 2) Switch activation position is wrong. On the "I/O Test" screen displayed from the Main Menu screen, press the [Switch Check] switch. On the touch switch test screen, a position different from the pressed position is activated. ↓ The switch activation position may be misaligned. 3) Switches do not work even in the STOP mode. On the "I/O Test" screen displayed from the Main Menu screen, press the [Switch Check] switch. When the touch switch test screen is pressed, nowhere is activated. ↓ POD switches may be faulty. 	<ol style="list-style-type: none"> 1) Check the settings of switch functions, etc. on the editor. 2) Perform a touch switch adjustment (page 6-10). 3) Return the POD to your local distributor.
The screen becomes dark or black.	<ol style="list-style-type: none"> 1) Touching the screen restores it to the previous illuminated state. ↓ The backlight operates automatically as preset. 2) Touching the screen does not restore it. However, the POWER lamp is lit. ↓ The backlight may be at the end of its life. Or the POD may be faulty. 	<ol style="list-style-type: none"> 1) The time for turning off the backlight can be changed on the editor. 2) Return the POD to your local distributor.
Screen data cannot be transferred.	<ol style="list-style-type: none"> 1) Screen data transfer has never succeeded. ↓ There may be some errors in the settings on the computer. 2) Screen data transfer was possible, but is disabled now. ↓ The POD may be faulty. Or, there may be some errors in settings. 3) Transfer via Ethernet There may be some errors in the Ethernet setting. 	<ol style="list-style-type: none"> 1) In the [Transfer] dialog box on the editor, decrease the baud rate by one level. Also check that the correct COM port is selected. 2) Check if the modem connection mode is selected. ("Modem Connect Mode" displayed at the bottom of the Main Menu screen denotes the mode) Also perform an RS-232C self-loop test (page 6-5). 3) Check that the IP addresses set on the editor and the POD are the same. Also check if any error due to Ethernet connection occurs on the POD. <p>If the problem persists, contact your local distributor.</p>

8

Inspection and Maintenance

1. Inspection and Maintenance
2. Warranty Policy

1. Inspection and Maintenance

**DANGER**

Be sure to turn off the power before conducting inspection or maintenance. Failure to do so could cause an electric shock or damage to the unit.

Daily Inspection

- Check that the screws on the POD are tightened firmly.
- Check that the connectors and terminal screws used for connection with other devices are tightened firmly.
- If the display surface or frame is dirty, wipe it with a soft cloth soaked in alcohol (commercially available).
- Conduct periodical inspection once or twice a year. The number of inspections may be increased as necessary if facilities are relocated or modified, or the environment is hot, humid, or dusty.

Periodical Inspection

Inspect the following points periodically.

- Are the ambient temperature and humidity appropriate?
0 to +50°C, 85%RH or less
- Are the environmental conditions appropriate?
- Does the atmosphere contain no corrosive gas?
- Is the source voltage in the allowable range?
With AC power supply: 100 - 240 VAC
With DC power supply: 24 VDC \pm 10%
- Are the POD mounting screws tightened firmly?
- Are the connectors and terminal screws used for connection with other devices tightened firmly?
- Is the lithium primary battery within the expiry date?

2. Warranty Policy

Inquiries about Failure

Please direct inquiries about failure or repair to your local distributor. Your information on the POD model, serial number, symptom of the failure, error message (if shown), etc. will be appreciated.

Warranty Period

The product is under warranty for one year after the date of purchase or delivery to the specified place. On the assumption that the maximum stock period of the product after manufacture is 6 months, the warranty period is limited to 18 months (checked by the serial number) after manufacture. When a warranty period is specified in the contract, however, the period in the contract takes precedence.

Free-of-charge Repair

If the product fails before the expiry of the warranty, it will be repaired free of charge. However, repair of any failure resulting from the causes below will be chargeable even within the warranty period.

- Breakage of or damage to the appearance (case or surface sheet), touch switches, LCD, or other components due to dropping, impact, or mishandling
- LCD or backlight at the end of life
- Fusion of a printed circuit board pattern associated with connection to external devices, or fusion of a pattern in the terminal block or connector section of a printed circuit board caused by short-circuiting of external load circuit
- Overvoltage or different voltage applied due to wiring mistake (power supply terminal, external communication terminal, or other terminal blocks)
- Failure caused by lightning surge
- Failure due to the entry of conductive substances, water, solvent, particles, etc. under inappropriate environmental conditions
- Failure due to inappropriate environmental conditions (e.g. corrosive gas or high humidity)
- Failure due to vibration or impact exceeding the specified level
- Disassembly and modification by the customer or failure obviously resulting from improper handling by the customer

Chargeable Repair

Any failure that occurs after the expiry of the warranty or does not satisfy the requirements for the free-of-charge repair will be repaired on a chargeable basis.

Fuji Electric FA Components & Systems Co., Ltd.

Gate City Ohsaki, East Tower,
11-2, Osaki 1-chome, Shinagawa-ku, Tokyo 141-0032, Japan
Phone: +81-3-5435-7135 ~ 8
Fax: +81-3-5435-7456 ~ 9
URL: [http : // www.fujielectric.co.jp / fcs / eng](http://www.fujielectric.co.jp/fcs/eng)