

Getting Started with NETServer Plus

Overview

This guide provides a quick overview for installing and configuring your NETServer/8 V.34 Plus, NETServer/16 V.34 Plus, NETServer/8 I-Modem Plus, and NETServer/16 I-Modem Plus. For additional information and details, refer to the NETServer Plus manuals as noted.

This guide is divided into four sections:


1. Installing NETServer Plus Hardware
2. Configuring NETServer Plus Software
3. Installing NETServer Manager Plus Software
4. Obtaining NETServer Plus Wizard Setup Information

We recommend that you complete the tasks in this guide in the order they are presented.

1. Installing NETServer Plus Hardware


Note: The NETServer Plus comes with factory default DIP switch settings. Do not change them.

1. **Rack Mount Installation:** Attach the enclosed adapter brackets to the NETServer Plus. Then mount the NETServer plus to the rack. **Desktop Installation:** Attach the four enclosed rubber feet to the bottom of the NETServer Plus.




2. Be sure that the on/off switch on the rear panel is in the off position. Then make the following cable connections:
 - **AC Power:** Connect the AC power cable to the three-pronged power outlet in the upper left-hand corner or the rear of the NETServer Plus.
 - **10Base2 Ethernet:** Connect the Ethernet cable to the Coax port. **10BaseT Ethernet:** Connect the Ethernet cable to the RJ-45 UTP port.
 - **Analog:** Connect the analog phone lines to the RJ-11 ports. **ISDN:** Connect the ISDN phone lines to the RJ-45 ports.
 - **Console Cable:** You must connect the console cable if you do not have a Windows PC connected to the same LAN segment as the NETServer Plus. For local access, use the enclosed null modem adapter to connect the cable directly to the serial port on your PC or terminal. For remote dial-in access, connect the serial port directly to a modem.

NETServer /8 Plus (V.34 or I-Modem)



NETServer Plus /16 (V.34 or I-Modem)



- Once all of the cables are connected, power up the NETServer Plus by turning the on/off switch to the on position.

2. Configuring NETServer Plus Software

Select the configuration method best suited for you from the following three options.

<i>Easiest Method - Configuration Wizard and NETServer Manager Plus</i>	
<i>Use</i>	Windows- and SNMP-based program including setup for the most common network requirements. Use the wizard for IP configuration. Configuration is via Ethernet.
<i>System requirements</i>	Windows 3.1, Windows 95, or Windows NT, Ethernet connection
<i>Recommended experience level</i>	Beginner to advanced
<i>How to start</i>	<ol style="list-style-type: none"> Complete the "Obtain NETServer Plus Wizard Setup Information" section in this guide. Refer to the "Installing NETServer Manager Plus Software" section in this guide to install NETServer Manager Plus software. Double click the NETServer Manager Plus  icon in the USR Management window to start the program. Click the wizard icon  in the NETServer Manager Plus toolbar. Configure NETServer Plus by entering the information you noted in the "Obtain NETServer Manager Plus Wizard Planning Information" section in this document.
<p><i>Note: If you also require IPX and/or AppleTalk, explanation about adding a network is included in the "Using NETServer" section of the Help contents.</i></p>	

Easy Method - Command Line Interface (CLI) Quick Setup	
<i>Use</i>	Use for most common network requirements, including IP, IPX, and AppleTalk. Configuration is via the serial/console port on the rear of the NETServer Plus.
<i>System requirements</i>	Terminal-based or terminal emulation program, Serial connection. Settings - 9600 8-N-1
<i>Recommended experience level</i>	Intermediate to advanced
<i>Refer to...</i>	"Using the CLI Quick Setup Program" section of the <i>Basic Installation and Setup</i> chapter in the <i>NETServer 8/16 Plus CLI Reference Guide</i> .
<i>How to start CLI Quick Setup</i>	Start a terminal session with NETServer Plus through the serial/console port. Respond to the Quick Setup prompts.

Advanced Method - Command Line Interface (CLI)	
<i>Use</i>	Use CLI for configuring NETServer Plus with the full setup and administrative command structure. Configuration is via the serial/console port on the rear of the NETServer Plus. You may also use Telnet once the NETServer Plus is initially configured.
<i>System requirements</i>	Terminal-based or terminal emulation program, Serial connection. Settings - 9600 8-N-1
<i>Recommended experience level</i>	Advanced
<i>Refer to...</i>	<i>NETServer 8/16 Plus User Manual</i> and <i>NETServer 8/16 Plus CLI Reference Guide</i>

3. Installing NETServer Manager Plus Software

This procedure describes how to install the NETServer Manager Plus software.

Note: The following procedure assumes that your floppy disk drive is the a: drive, and that your hard disk drive is the c: drive. If your drive letters are different, substitute them appropriately in the procedure.

1. Insert the NETServer Manager Plus diskette in your PC's floppy drive (for example, drive a:).
2. Click **Start**  and then select **Run**.
3. Type **a:\nsplus.exe** and click **OK**. This opens the Win-zip self extractor utility.
4. Click **OK** on each of the two Win-zip screens that appear.
5. Type **c:\templus** and click **OK** to extract the NETServer Manager Plus setup files to a temporary setup directory on your hard disk drive.
6. Click **OK** after the files have been extracted.
7. Click **Close** to exit the Win-zip self-extractor.
8. Click **Start**  and then click **Run**.
9. Type **c:\templus\setup.exe** and click **OK** to start the NETServer Manager Plus installation.
10. Follow the prompts on your screen to finish the installation.

4. Obtaining NETServer Plus Wizard Setup Information

This section describes how to gather user configuration information required for the NETServer Manager Plus Wizard setup utility.

Wizard overview

Use the wizard to configure users for NETServer Plus access. The wizard will prompt you to enter information for telecommuter, Internet Service Provider, or terminal user access.

The configuration wizard is a Windows-based program. All other operating systems require you to use the Command Line Interface QuickSetup, or the Command Line Interface (CLI). See the *NETServer Plus User Manual*, and the *CLI Reference Guide* for CLI configuration instructions. You do not need to use this form with CLI or CLI Quick Setup.

How to use this planning form

Use the information in this section to record user configuration data for each user or group of users you plan to configure on the NETServer Plus. Network users must be configured for one of three access methods:

- Internet Service access
- Telecommuter access
- Terminal access

We recommend that you complete the tables provided in this section before you begin the Wizard setup program.

Obtain Information for Telecommuter and Internet Service users

The following Wizard screens show you the information required for adding an Internet Service user and a Telecommuter user.

This is the Wizard Setup screen for adding an Internet Service user:

The screenshot shows a wizard setup screen for an Internet Service user. It features a light gray background with several input fields and a radio button group. On the left side, there are four fields: 'User Name:' with a text box, 'Protocol:' with a dropdown menu, 'MTU:' with a text box, and 'Routing:' with a dropdown menu. On the right side, there is a box titled 'IP Address Assignment' containing three radio buttons: 'Unnumbered (0.0.0.0)', 'Dynamic (255.255.255.255)', and 'Specified'. Below the radio buttons is an empty text box.

This is the Wizard Setup screen for adding a Telecommuter user:

The screenshot shows a wizard setup screen for a Telecommuter user. It features a light gray background with several input fields and a radio button group. On the left side, there are five fields: 'User Name:' with a text box, 'Protocol:' with a dropdown menu, 'MTU:' with a text box, 'Routing:' with a dropdown menu, and 'IPX Address:' with a text box. On the right side, there is a box titled 'IP Address Assignment' containing three radio buttons: 'Unnumbered (0.0.0.0)', 'Dynamic (255.255.255.255)', and 'Specified'. Below the radio buttons is an empty text box.

Obtain Information for Terminal Access Users

The following Wizard screen shows you the information required for adding Terminal Access users.

This is the Wizard Setup screen for a Terminal access user:

The screenshot shows a wizard setup screen with the following elements:

- User Name:** A text input field.
- Login Service:** A dropdown menu.
- TCP Port:** A text input field.
- Host Connection Type:** A section containing three radio buttons:
 - Prompt
 - Select
 - Specified
 To the right of the radio buttons is a text input field for specifying a host address.

Table 3 below describes the configuration information required for each Terminal user.

Note: All characters are case sensitive.

Table 3: Terminal User Configuration Field Descriptions

Field	Definition
User name	This field will contain the user name you define for this user account.
Login Service	This is the login service for the user. Select TCP , Rlogin , or Telnet .
TCP Port	This optional parameter specifies the NETServer Plus port number that will be used when a user's application requests a TCP session with this NETServer Plus.
Host Connection Type	This is the type of connection made to this NETServer Plus when the user logs in. Select Prompt to have the NETServer Plus ask a user for an IP address to be connected to when they have logged in. Choose Select to cause a user to be connected to a host from a default host. Select Specified to connect only to the address you specify in the field.

Use Table 4 to list the required Wizard Setup information for each Terminal access user. Use an additional sheet of paper, if necessary. We have provided a sample entry.

Table 4: Terminal User Configuration Information

User Name	Login Service	TCP Port	Host Connection Type
janedoe	TELNET	3	Select

© Copyright 1997 by U.S. Robotics
 8100 North McCormick Blvd.
 Skokie, IL 60076-2999
 All Rights Reserved Worldwide