



Installation Instructions

ControlLogix Data Highway Plus-Remote I/O Communication Interface Module

(Catalog Number 1756-DHRIO)

Use this document as a guide to install the ControlLogix™ Data Highway Plus™-Remote I/O communication interface module. The following table lists what this manual contains and where to find specific information.

Topic	See page
Important User Information	2
Understand Compliance to European Union Directive	4
Preventing Electrostatic Discharge	5
Identify Module Features	6
Set the Network Type and Node Address Switches	7
Prepare the Chassis for Module Installation	8
Determine Module Slot Location	9
Installing or Removing the Module While Power Is Applied	10
Install the Module	11
Wire the Connectors for the Module Channels	13
Connect the Programming Terminal and DH+ or Remote I/O Network	14
Apply Chassis Power	15
Check Power Supply and Module Status	15
Interpreting the Alphanumeric Display	17
Interpreting the LED Status Indicators	18
Where to Find Information on Configuring Your 1756-DHRIO Module	19
Hazardous Location information	20
Specifications	22

Important User Information

Because of the variety of uses for the products described in this publication, those responsible for the application and use of this control equipment must satisfy themselves that all necessary steps have been taken to assure that each application and use meets all performance and safety requirements, including any applicable laws, regulations, codes and standards.

The illustrations, charts, sample programs and layout examples shown in this guide are intended solely for purposes of example. Since there are many variables and requirements associated with any particular installation, Allen-Bradley does not assume responsibility or liability (to include intellectual property liability) for actual use based upon the examples shown in this publication.

Allen-Bradley publication SGI-1.1, *Safety Guidelines for the Application, Installation and Maintenance of Solid-State Control* (available from your local Allen-Bradley office), describes some important differences between solid-state equipment and electromechanical devices that should be taken into consideration when applying products such as those described in this publication.

Reproduction of the contents of this copyrighted publication, in whole or part, without written permission of Rockwell Automation, is prohibited.

Throughout this manual we use the following notes to make you aware of safety considerations:

WARNING

Identifies information about practices or circumstances that have the potential to create an explosion hazard.

ATTENTION

Identifies information about other practices or circumstances that can lead to personal injury or death, property damage or economic loss.

Warning and Attention statements help you to:

- identify a hazard
- avoid a hazard
- recognize the consequences

We use the following note to call attention to critical information:

IMPORTANT

Identifies information that is critical for successful application and understanding of the product.

Change bars are used to indicate information that has changed or been added since the previous version of these instructions.

Understand Compliance to European Union Directive

If this product bears the CE marking, it is approved for installation within the European Union and EEA regions. It has been designed and tested to meet the following directives.

EMC Directive

This product is tested to meet Council Directive 89/336/EEC Electromagnetic Compatibility (EMC) and the following standards, in whole or in part, documented in a technical construction file:

- EN 50081-2 EMC - Generic Emission Standard, Part 2 - Industrial Environment
- EN 50082-2 EMC - Generic Immunity Standard, Part 2 - Industrial Environment

This product is intended for use in an industrial environment.

Low Voltage Directive

This product is tested to meet Council Directive 73/23/EEC Low Voltage, by applying the safety requirements of EN 61131-2 Programmable Controllers, Part 2 - Equipment Requirements and Tests.

For specific information required by EN 61131-2, see the appropriate sections in this publication, as well as the following Allen-Bradley publications:

- Industrial Automation Wiring and Grounding Guidelines, publication 1770-4.1
- Automation Systems Catalog, publication B113

Open style devices must be provided with environmental and safety protection by proper mounting in enclosures designed for specific application conditions. See NEMA Standards publication 250 and IEC publication 529, as applicable, for explanations of the degrees of protection provided by different types of enclosure.

Enclosure and Environmental Requirements Specific To This Product

This product must be mounted within a suitable system enclosure to prevent personal injury resulting from accessibility to live parts. The interior of this enclosure must be accessible only by the use of a tool.

This industrial control equipment is intended to operate in a Pollution Degree 2 environment, in overvoltage category II applications, (as defined in IEC publication 664A) at altitudes up to 2000 meters without derating.

Preventing Electrostatic Discharge

The 1756-DHRIO module is sensitive to electrostatic discharge.

ATTENTION


Electrostatic discharge can damage integrated circuits or semiconductors if you touch backplane connector pins. Follow these guidelines when you handle the module:

- Touch a grounded object to discharge static potential
 - Wear an approved wrist-strap grounding device
 - Do not touch the backplane connector or connector pins
 - Do not touch circuit components inside the module
 - If available, use a static-safe work station
 - When not in use, keep the module in its static-shield bag
-

For additional information refer to publication 1770-4.1, *Industrial Automation Wiring and Grounding Guidelines*.

Identify Module Features

Refer to the following figure to identify the hardware components of the 1756-DHRIO module.




Set the Network Type and Node Address Switches

Before you install the module, you must set the network type switches for each channel. If the network type is Data Highway Plus (DH+), you must also set the node address switches for that channel to a unique address within the range of 00-77.


IMPORTANT

Do not set node address switches if you are using remote I/O.



Prepare the Chassis for Module Installation

Before you install the DHRIO module, you must install and connect a ControlLogix chassis and power supply.




For information on installing these products, refer to the publications listed in the following table.

Chassis Type	Chassis Installation	Power Supply	Power Supply Installation
Series B: 1756-A4, -A7, -A10, -A13	Pub. No. 1756-IN080	1756-PA72/B	Pub. No. 1756-5.67
		1756-PB72/B	
		1756-PA75/A	Pub. No. 1756-5.78
		1756-PB75/A	

Determine Module Slot Location

The figure below shows chassis slot numbering in a 4-slot chassis. Slot 0 is the first slot and is always the leftmost slot in the rack (the first slot to the right of the power supply). You can use any size ControlLogix chassis and install the module in any slot. You can also install multiple 1756-DHRIO modules in the same chassis. You can install as many modules as your power supply can accommodate (i.e., number for which the power supply is rated).



Installing or Removing the Module While Power Is Applied

You can install or remove the module while chassis power is applied if you observe the following precautions.

WARNING

When you insert or remove a module while backplane power is on, an electrical arc may occur. An electrical arc can cause personal injury or property damage by:

- sending an erroneous signal to your system's actuators causing unintended machine motion or loss of process control.
- causing an explosion in a hazardous environment.


Repeated electrical arcing causes excessive wear to contacts on both the module and its mating connector. Worn contacts may create electrical resistance that can affect module operation.

Install the Module


ATTENTION



Do not force the module into the backplane connector. If you cannot seat the module with firm pressure, check the alignment. Forcing the module into the chassis can damage the backplane connector or the module.



Removing or Replacing the Module (When Applicable)




If you are replacing an existing module with an identical one, and you want to resume identical system operation, you must install the new module in the same slot.

Wire the Connectors for the Module Channels


8-pin mini DIN programming terminal connection parallel to channel A when channel A is configured for DH+ communication.

Pin Assignments for Channel A and B Connectors

DH+		Remote I/O	
Pin no:	Desc:	Pin no:	Desc:
1	Clear	1	Blue
	Shield		Shield
2	Blue	2	Clear



Connect the Programming Terminal and DH+ or Remote I/O Network




1
Connect the programming terminal to the 8-pin mini DIN connector.

2
Connect the DH+ or Remote I/O network to the channel A or B connector as appropriate.

IMPORTANT


For hazardous locations, use a 1784-CP13 cable (or equivalent connector) for the programming terminal connection.

Apply Chassis Power



Check Power Supply and Module Status

Alphanumeric status indicator illuminates and cycles through a sequence of messages (described in the table on the following page).



Power Supply indicator is green.

Module OK status indicator is solid red, then flashing green.

Upon powerup the module's alphanumeric display cycles through the following sequences.

Alphanumeric Status Display Powerup Messages

Data Highway Plus

Sequence of display:	Where:
A DH A#xx xxxx	A is the channel (A or B) and DH indicates network type is DH+ xx is the channel's node address xxxx is the channel's status message

Remote I/O

Sequence of display:	Where:
B IO SCAN xxxx	B is the channel (A or B) and IO indicates the network type is Remote I/O SCAN indicates scanner xxxx is the channel's status message

Troubleshooting the Power Supply

If the alphanumeric indicator on the 1756-DHRIO module does not cycle through these messages on powerup, refer to the following table and to the Troubleshooting section that follows.

Power Supply Indicator

If the POWER indicator is:	Power Supply Status is	Recommended Action:
Off	Not operating.	Turn power switch ON. Check power wiring connections. Check fuse.
On	Operating.	None, normal operation.

Interpreting the Alphanumeric Display

Your 1756-DHRIO module displays alphanumeric codes that provide diagnostic information about your module. The alphanumeric display flashes the codes at approximately 1 second intervals. The following table summarizes the codes.

Alphanumeric Display Status Messages

Code	Description	Recommended Action
Data Highway Plus		
OFF LINE	Data Highway Plus link is in STOP state.	Correct the configuration. Refer to the configuration chapter of the Data Highway Plus-Remote I/O Communication Interface User Manual, publication 1756-6.5.14.
DUPL NODE	Data Highway Plus Duplicate node address.	Choose another node address and reset switches.
ONLY NODE	Only node on Data Highway Plus link.	Check the cables.
CNFG FALT	Incorrect Data Highway Plus routing table configuration. Incorrect Data Highway object configuration.	Correct the configuration. Refer to the configuration chapter of the Data Highway Plus-Remote I/O Communication Interface User Manual, publication 1756-6.5.14. Verify the module is inserted into the correct slot.
OK	Normal operation for that channel.	None.
Remote I/O		
MUTE LINK	No adapters found on remote I/O.	Add an adapter to the remote I/O network.
RACK OVER	Rack overlap on remote I/O.	Reconfigure remote I/O racks.
DUPL SCAN	Duplicate scanner on remote I/O.	Check remote I/O adapter settings.
MAX_ DEV_	Maximum devices exceeded on remote I/O.	Remove devices to meet limitations on remote I/O network.
CHAT LINK	Babble detected on remote I/O.	Check remote I/O device and network connections.

Alphanumeric Display Status Messages

Code	Description	Recommended Action
Remote I/O		
OFF LINE	Not trying to communicate.	None. Normal state if controller is not controlling remote I/O.
OK	Normal operation for that channel.	None.

Interpreting the LED Status Indicators

The three LED status indicators on the module provide information about your module and the status of each channel. The following tables outline the indicator condition and the corresponding status, and explain what each condition means.

Module Status - OK Indicator

Condition	Module Status	Recommended Action
Off	Not operating.	Apply chassis power. Verify module is completely inserted into chassis and backplane.
Green flashing	Operating but not routing messages and no controller transferring I/O.	None, if no messages are actively being routed through the module and no controller transferring I/O. To route messages or transfer I/O, use module default configuration or configure module.
Red, then Off	Performing self-test.	None, normal operation.
Green	Operating and routing messages.	Verify module configuration.
Red	In major fault	Reboot module. If red reoccurs, then replace module.
Red flashing	In major fault or configuration fault.	Check alphanumeric indicator and take action described in alphanumeric display status message table beginning on page 17.

Channel Status - Channel A and Channel B Indicators

If the channel A or B indicator is:	in this channel mode:	then the channel status is:	take this action:
Off	All	Not on line.	Place channel on line.
Green	RIO scanner	Active RIO link. All adapter modules are present and not faulted.	None, normal operation.
	DH+	Operating.	None, normal operation.
Green flashing	RIO scanner	One or more nodes faulted or failed.	Check power at other racks.
	DH+	No other node on the network.	Check cables.
Red	All	Hardware fault.	Reboot module. If red reoccurs, then replace module.
Red flashing	RIO scanner	Faulted adapters detected.	Check cables. Check power at other racks.
	DH+	Duplicate node detected.	Check node address.

Where to Find Information on Configuring Your 1756-DHRIO Module

Now that you have installed your Data Highway Plus-Remote I/O module, you must configure it. For this information, refer to the configuration chapter of your *Data Highway Plus-Remote I/O Communication Interface Module User Manual*, publication 1756-6.5.14.

Hazardous Location information

The following information applies when operating this equipment in hazardous locations:

Products marked “CL I, DIV 2, GP A, B, C, D” are suitable for use in Class I Division 2 Groups A, B, C, D, Hazardous Locations and nonhazardous locations only. Each product is supplied with markings on the rating nameplate indicating the hazardous location temperature code. When combining products within a system, the most adverse temperature code (lowest “T” number) may be used to help determine the overall temperature code of the system. Combinations of equipment in your system are subject to investigation by the local Authority Having Jurisdiction at the time of installation.

WARNING**EXPLOSION HAZARD**

- Do not disconnect equipment unless power has been removed or the area is known to be nonhazardous.
 - Do not disconnect connections to this equipment unless power has been removed or the area is known to be nonhazardous. Secure any external connections that mate to this equipment by using screws, sliding latches, threaded connectors, or other means provided with this product.
 - Substitution of components may impair suitability for Class I, Division 2.
 - If this product contains batteries, they must only be changed in an area known to be nonhazardous.
-

Informations sur l'utilisation de cet équipement en environnements dangereux:

Les produits marqués "CL I, DIV 2, GP A, B, C, D" ne conviennent qu'à une utilisation en environnements de Classe I Division 2 Groupes A, B, C, D dangereux et non dangereux. Chaque produit est livré avec des marquages sur sa plaque d'identification qui indiquent le code de température pour les environnements dangereux. Lorsque plusieurs produits sont combinés dans un système, le code de température le plus défavorable (code de température le plus faible) peut être utilisé pour déterminer le code de température global du système. Les combinaisons d'équipements dans le système sont sujettes à inspection par les autorités locales qualifiées au moment de l'installation.





AVERTISSEMENT



RISQUE D'EXPLOSION

- Couper le courant ou s'assurer que l'environnement est classé non dangereux avant de débrancher l'équipement.
 - Couper le courant ou s'assurer que l'environnement est classé non dangereux avant de débrancher les connecteurs. Fixer tous les connecteurs externes reliés à cet équipement à l'aide de vis, loquets coulissants, connecteurs filetés ou autres moyens fournis avec ce produit.
 - La substitution de composants peut rendre cet équipement inadapté à une utilisation en environnement de Classe 1, Division 2.
 - S'assurer que l'environnement est classé non dangereux avant de changer les piles.
-

Specifications

Parameter	Specification
Module Location	ControlLogix chassis
Maximum Backplane Current Load	850mA @ +5.1V dc and 1.7mA @ 24 V dc from I/O chassis backplane
Power Dissipation	4.5W maximum
Thermal Dissipation	15.4 BTU/hr maximum
Environmental Conditions: Operational Temperature Storage Temperature Relative Humidity	0-60°C (32-140°F) -40 to 85°C (-40 to 185°F) 5-95% without condensation
Shock Unpackaged	30g operational 50g non-operational
Vibration Unpackaged	2g from 10-150Hz
Conductors: Wiring Category	Belden 9463 twinaxial 2 ⁽¹⁾
Agency Certification (when product or packaging is marked)	 Listed Industrial Control Equipment  Certified Process Control Equipment Certified Class I, Division 2, Group A, B, C, D  Marked for all applicable directives  Marked for all applicable acts N223
User Manual	Publication 1756-6.5.14

⁽¹⁾ Use this conductor category information for planning conductor routing as described in system level installation manual. Also refer to 1770-4.1, *Industrial Automation Wiring and Grounding Guidelines*.

Reach us now at www.rockwellautomation.com

Wherever you need us, Rockwell Automation brings together leading brands in industrial automation including Allen-Bradley controls, Reliance Electric power transmission products, Dodge mechanical power transmission components, and Rockwell Software. Rockwell Automation's unique, flexible approach to helping customers achieve a competitive advantage is supported by thousands of authorized partners, distributors and system integrators around the world.

Americas Headquarters, 1201 South Second Street, Milwaukee, WI 53204, USA, Tel: (1) 414 382-2000, Fax: (1) 414 382-4444
European Headquarters SA/NV, avenue Hermann Delbroux, 46, 1160 Brussels, Belgium, Tel: (32) 2 663 06 00, Fax: (32) 2 663 06 40
Asia Pacific Headquarters, 27/F Citicorp Centre, 18 Whitfield Road, Causeway Bay, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1946



Publication 1756-IN003A-EN-P - May 2001
Supersedes Publication 1756-5.4 - July 1998

PN 957280-03

© 2001 Rockwell International Corporation. Printed in USA