


Modicon Premium PLCs TSX SAY 100

AS-i Bus Interface Module
Module interface bus AS-i

Quick reference guide
Instruction de service

Edition September 2004



Introduction

• Preface

This document is only concerned with the hardware installation of the TSX SAY 100 AS-i bus master module, from a Premium PLC (TSX 57, PMX 57, PCX 57, PCI 57). For the complete installation of an AS-i bus, the following documents should be consulted :

- the AS-i bus reference manual : XDOC 5511 E (design and installation of the bus)
- the application-specific manuals : TLX DS 57 PL7 30E (software setup)
- the AS-i bus user manual using Unity Pro : 35006197.


• Summary of the AS-i bus

The AS-i bus is a level 0 fieldbus which can be used to connect sensors/actuators. It is used for the communication of discrete data between a bus master and sensor/actuator "slaves".

AS-i comprises three main elements :

- a specific power supply providing a voltage of 30 VDC (TSX SUP A02/A05)
- a bus master (TSX SAY 100 module)
- a number of slaves (communicating sensors / actuators and/or IP20/IP65 interfaces)

Example of an AS-i bus topology from a TSX 57 PLC



Physical presentation

1 Display block comprising 4 status indicator lamps for displaying the module operating modes:

- green **RUN** indicator lamp: on during normal operation of the module.
- red **ERR** indicator lamp: on, it indicates a module fault.
- green **COM** indicator lamp: on, it indicates data exchanges on the AS-i medium.
- red **I/O** indicator lamp: on, it indicates an external I/O fault on the AS-i bus

2 Display block comprising 32 indicator lamps (0 to 31) for diagnostics of the AS-i bus and displaying the state of each slave connected on the bus.

3 Red **AS-i** indicator lamp: on, it indicates a fault on the AS-i power supply.



4 Green **BUS** indicator lamp: on, it indicates that display block 2 is in BUS display mode (displaying the slaves on the bus).

5 Green **I/O** indicator lamp: on, it indicates that display block 2 is in slave "SLV" display mode (display of the I/O bits of the selected slave).

6 Pushbutton "**↑↓**" dedicated to local diagnostics of the AS-i bus. Pressing this pushbutton (long or short presses), combined with the "**+/-**" pushbutton enables the user to move between the various AS-i bus diagnostic modes.

7 Pushbutton "**+/-**" dedicated to local diagnostics of the AS-i bus. Pressing this pushbutton (long or short presses), combined with the "**↑↓**" pushbutton enables the user to move between the various AS-i bus diagnostic modes.

8 CANNON SUB D connector for connection to the AS-i bus.




Mounting/Installation

The TSX SAY 100 module can be mounted in any position in a TSX RKY rack, except for the positions specifically for the power supply and the processor.

The insertion and removal of this module follows the general procedure for inserting and removing modules on Premium PLCs (see installation manual for Premium PLCs).

The module can be inserted and removed with the PLC power supply and the AS-i bus power supply on.

The number of modules per PLC station depends on the type of processor installed:




- | | |
|---|---------------------|
| • TSXP57 0244 processor | : 1 module maximum |
| • TSX/TPMXP57 102, 114, 1634, TPCX 57 1012 processors | : 2 modules maximum |
| • TSX/TPMXP57 212, 214, 2634, PCI 57 204 processors | : 4 modules maximum |
| • TSX/TPMXP57 312, 314, 3634, TPCX 57 3512, PCI 57 354 processors | : 8 modules maximum |
| • TSX/TPMXP57 412, 454, 4634, 554, 5634 processors | : 8 modules maximum |

Connections

• AS-i bus cable

This carries signals and provides the sensors and actuators connected on the bus with a 30 VDC supply.

- AS-i ribbon cable, shaped to prevent incorrect insertion : yellow, wire cross-section 1.5 mm²
- standard round cable with 1.5 mm² or 2.5 mm² cross-section wires
recommended cable : reference H05VV-F2x1.5 complying with standard DIN VDE 0281. Wire cross-section 1.5 mm².



• Cabling routing

- The AS-i cable must be kept away from high energy power cables. To do this, the AS-i cable and the power cables must be in separate ducting and protected from one another by a metal screen
- When the AS-i cable is routed together with the control cables, it is essential that the connections on these control links are made in accordance with standard practice (discharge diode or peak limiters on the terminals of inductive elements, etc)


• Connection of the module to the AS-i bus

A kit (connector + cover) is supplied with the module for connecting it to the AS-i bus.

This connector must be connected to the AS-i bus cable and assembled by the user in accordance with the steps described on the next page.




Connector




cover

- 1 Connect the 2 wires of the AS-i cable to the connector observing the polarities




Note: if in exceptional circumstances a shielded cable is used, this should be connected to the central terminal


- 2 Insert the connector in its cover and secure the cable to the cover



- 3 Close the cover by snapping it shut



- 4 Mount the assembled unit on the module



Displaying the module status

The 4 indicator lamps (RUN, ERR, COM and I/O) located on the front panel of the module inform the user of the operating status of the module and the bus.




Status Indic.	On	Flashing	Off
RUN (green) normally	Module operating	Module self-test (1)	Module faulty or module off
ERR (red)	Serious internal fault, module failure	Module self-test (1) Application faulty, or fault on AS-i bus	No internal fault
COM (green)	– Communication on the	Module self-test (1) on the AS-i bus AS-i bus	No communication
I/O (red)	I/O fault	Module self-tests (1)	Module operating normally

(1) all 4 indicator lamps flash simultaneously during the self-tests when the module is powered up.


Special displays of the TSX SAY 100 module

3 indicator lamps : AS-i, BUS and I/O display data specific to the TSX SAY 100 module.

• AS-i indicator lamp

-  Indicator lamp off: normal operation of the module
-  Indicator lamp on: Power supply fault on the AS-i bus
-  Indicator lamp flashing: automatic addressing initialized


AS-i





















• BUS and I/O indicator lamps

These two indicator lamps show the selected display mode:

- BUS display mode or
- slave display mode.



Module display	SLV BUS indic.	@ I/O indic.	Diagnostics
<div><div>SLV BUS SLV @ I/O</div><div></div></div> <div></div>	On 	Off 	The 32 indicator lamp display block on the front panel of the module is in Bus display mode which shows the slaves present on the bus.
<div><div>SLV BUS SLV @ I/O</div><div></div></div> <div></div>	Off 	On 	The 32 indicator lamp display block on the front panel of the module is in slave (SLV) display mode with the status of the I/O bits of the selected slave displayed.
<div><div>SLV BUS SLV @ I/O</div><div></div></div> <div></div>	Off 	Off 	The 32 indicator lamp display block on the front panel of the module is in slave (SLV) display mode with the address of the selected slave displayed.

Characteristics

AS-i bus	AS-i bus maximum cycle time	5 ms
	Maximum number of slaves on the AS-i bus	31
	Maximum length of the AS-i bus (including all branches without repeater)	100 meters
	Maximum number of I/O	124 inputs + 124 outputs
	AS-i bus nominal supply voltage	30 VDC
TSX SAY 100 module	Programming the module	using the PL7 Junior /Pro and Unity Pro software
	Program response time with 31 slaves for a PLC scan time of 10 ms (1)	typically 27 ms maximum 37 ms
	Current drawn on the internal 5V	110 mA typical/150 mA max.
	Current drawn on the AS-i 30 V	50 mA typical/60 mA max.
	AS-i master profile	M2
	Operating temperature	0 to 60°C (without ventilation)

- (1) Time between an AS-i input activated on the bus, processed in the PLC application and applied to an AS-i output

Safety of personnel

To ensure the safety of personnel, it is essential to:

- connect the PLC ground terminal to earth
- use a SELV (very low safety voltage) AS-i power supply, with 30 VDC nominal voltage
- for PLCs connected to an AC supply, place a residual current device upstream of this supply which will disconnect the PLC power supply source if an earth leakage is detected
- for PLCs connected to an AC supply, ensure that the power supply placed upstream of the PLC is SELV
- use AS-i certified products on the bus

Because of its technology and connections, the AS-i TSX SAY 100 module only takes 5 VDC, and its electrical 0 V is connected to the PLC ground.

Addressing I/O objects using PL7

The AS-i bus is managed by channel 0 of the TSX SAY 100 module. The syntax of the I/O data is as follows:

Inputs	%Ixy.0n.i	x = rack address (0 to 7)
Outputs	%Qxy.0n.i	y = module address in the rack (0 to 10)
		n = number of the slave on the AS-i bus (1 to 31)
		i = number of the slave input or output bit (0 to 3)

Addressing I/O objects using Unity Pro

The AS-i bus is managed by channel 0 of the TSX SAY 100 module. The syntax of the I/O data is as follows:

Inputs	%Ib.evr.m.c	b = bus number (2 to 999)
Outputs	%Qb.evr.m.c	e = number of the slave on the AS-i bus (1 to 31)
		r = virtual rack address (0)
		m = virtual module address (0)
		c = number of the slave input or output bit (0 to 3)

Operating modes of the TSX SAY 100 module

• Fallback position

The fallback mode of the outputs is defined in the configuration screen and can be read :
 - in word using PL7 (%KWxy.0.19:X0=1 : fallback to 0, %KWxy.0.19:X0=0 : maintain state). See the application-specific installation manual "AS-i application specific function".

x = rack address, y = module address.

- in word using Unity Pro (%KWm.m.0.19.0=1 : fallback to 0, %KWm.m.0.19.0=0 : maintain state). See AS-i bus user manual using Unity Pro.

x = rack address, y = module address.

Behavior when the AS-i channel changes to STOP:

- with the reset to 0 option: the outputs are forced to 0, then the communication on the medium stops,
- with the maintain state option: the state of the outputs is maintained, then the communication on the medium stops,

• Automatic addressing of slaves

When this function is validated in the module configuration, a faulty slave can be replaced by a slave of the same type without stopping the AS-i bus and without the necessity for any special operation.

If the replacement slave is programmed with the same address and it has the same profile, it will be automatically inserted in the list of slaves which are detected and activated. If this is not the case, the ERR and AS-i indicator lamps flash simultaneously.

If the new slave is unformatted (address 0, new slave) and it has the same profile, the slave will automatically take the address of the slave which it replaces and will therefore appear in the list of slaves which are detected and activated. If this is not the case, the ERR and AS-i indicator lamps flash simultaneously. These operations are only possible if a single slave in the configuration is faulty.

• Processor fault

If communication with the processor is broken, the module switches to safety position. Causes of the communication break:

- tripping of the processor watchdog if the module is located in the rack containing the processor.
- disconnection of the bus X cable if the module is located in an extension rack.

• Module fault

If there is a serious module fault (faulty component, etc), the module stops the communication with bus X and with the AS-i bus. The same behavior occurs as when a module is removed while powered up.

• Removing the module while it is powered up

Communication with bus X stops, the processor indicates a module fault. Communication on the AS-i bus is also interrupted without warning. In this case, the slaves which have a watchdog set their outputs to the required state and the others remain in the same position and cannot be set to 0 because the module can no longer provide communication.

- **Inserting a module with the power on**

After powering up the module, it waits to receive the configuration from the processor or for one of the "↑↓" or "+/-" pushbuttons to be pressed, otherwise it remains stopped.

- **Fault on the AS-i power supply** (shown by the AS-i indicator lamp being on)

When there is an AS-i power supply fault, the communication stops and :

- the outputs of slaves which have a watchdog are set to the required state, unless the slave draws its power on the AS-i medium
- the commands of the slaves change to 0 as a result of loss of power

- **Breaking of the AS-i medium**

There are several possibilities:


- the medium is cut at the module output: the behavior is the same as when there is a power break with disappearance of all the slaves and indication of a power supply fault
- the medium is cut after the TSX SAY 100 module and AS-i power supply assembly: disappearance of all the slaves and no indication of a power supply fault
- the medium is cut after the TSX SAY 100 module, the AS-i power supply assembly and a number of slaves: disappearance of the slaves located after the break and no indication of a power supply fault

AS-i bus diagnostics

The module display block is used to:

- display each slave on the AS-i bus, (BUS mode)
- the display of the state of the I/O bits of each slave on the BUS (Slave mode "SLV")

These modes are accessed by pressing combinations of the pushbuttons "↑↓" and "+/-" on the TSX SAY 100 module.




0	8	16	24
1	9	17	25
2	10	18	26
3	11	19	27
4	12	20	28
5	13	21	29
6	14	22	30
7	15	23	31

BUSmode

Display of the image of the AS-i bus, each indicator lamp, 1 to 31, corresponds to a slave address on the bus:

- indicator lamp on: slave present
- indicator lamp flashing: slave which is projected and not detected, or detected and not projected
- indicator lamp off: slave neither projected nor detected

0	8	16	24
1	9	17	25
2	10	18	26
3	11	19	27
4	12	20	28
5	13	21	29
6	14	22	30
7	15	23	31



Display mode is indicated when the BUS indicator lamp is on and the I/O indicator lamp is off.

Slavemode (SLV)


Display of the address of the selected slave:

- indicator lamp on: number of the selected slave

Display of the state of the I/O bits of the selected slave


- indicator lamps 0 to 3 display the state of the input bits
- indicator lamps 4 to 7 display the state of the output bits
- indicator lamps on: bit at state 1
- indicator lamp off: bit at state 0 or not significant

0	8	16	24
1	9	17	25
2	10	18	26
3	11	19	27
4	12	20	28
5	13	21	29
6	14	22	30
7	15	23	31



Display mode is indicated when the BUS and I/O indicator lamps are off.


0	8	16	24
1	9	17	25
2	10	18	26
3	11	19	27
4	12	20	28
5	13	21	29
6	14	22	30
7	15	23	31



Display mode is indicated when the BUS indicator lamp is off and the I/O indicator lamp is on.

Moving between the various display modes

BUSmode



Slaves 1 to 31
present

Display of the image
of the AS-i bus

0	8	16	24
1	9	17	25
2	10	18	26
3	11	19	27
4	12	20	28
5	13	21	29
6	14	22	30
7	15	23	31

> 1s
Long press on "↑↓"

Slavemode(SLV)

Display of the address of
the selected slave

Slave
numbers

0	8	16	24
1	9	17	25
2	10	18	26
3	11	19	27
4	12	20	28
5	13	21	29
6	14	22	30
7	15	23	31

> 1s
Long press on "↑↓"

Display of the I/O of
the selected slave

0	8	16	24
1	9	17	25
2	10	18	26
3	11	19	27
4	12	20	28
5	13	21	29
6	14	22	30
7	15	23	31



State of
inputbits

State of
outputbits

> 1s
Long press on "+/-"

Change of direction
Short press on "↑↓"


Change of slave
Short press on "+/-"



• Display of the slaves on the AS-i bus


This mode is displayed by default on power up and shows:

- slaves which are projected and detected (indicator lamps on, steady)
- slaves which are neither projected nor detected (indicator lamps off),
- slaves which are projected and not detected, or which are detected and not projected (indicator lamps flashing).



0	8	16	24
1	9	17	25
2	10	18	26
3	11	19	27
4	12	20	28
5	13	21	29
6	14	22	30
7	15	23	31

Bus display



The image of the AS-i bus is displayed on the entire display block, with each indicator lamp representing a slave address on the AS-i bus.

The user can move between the various modes by pressing combinations of the "↑↓" and "+/-" pushbuttons (see previous diagram).

Two indicator lamps, BUS and I/O, indicate the current display mode. In this example, the BUS indicator lamp is on and the I/O indicator lamp is off indicating that the display is in BUS mode.

In the above example the display block indicates that:

- slaves 1, 4, 10 and 20 (indicator lamps on) are present,
- slave 11 (indicator lamp flashing) is present and not projected, or projected and absent.

• Display of the state of the I/O bits of each slave (slave mode "SLV")

The module display block indicates the state of the I/O bits of each slave present on the bus.


From BUS display mode:

- a **long press** on the "↑↓" pushbutton triggers the change to Slave mode with display of a slave address (1 to 31) which can be changed in an increasing direction (1 to 31) or a decreasing direction (31 to 1) by short presses on the "+/-" pushbutton. In this case, the BUS and I/O indicator lamps on the front panel of the module are off.

From the display of the selected slave:

- a long press on the "+/-" pushbutton triggers the display of the state of the I/O bits of the selected slave, (indicator lamp on = bit at state 1, indicator lamp off = bit at state 0 or no I/O).

Indicator lamps 0 to 3 in the upper part show the state of the input bits of the slave (4 input bits maximum per slave); bits 4 to 7 in the lower part show the state of the output bits of the slave (4 output bits maximum per slave). In this example, the I/O indicator lamp is on and the BUS indicator lamp is off.



Incrementing or decrementing the slave number

When the display block is in Slave "SLV" mode, with display of a slave number, the user can scan the slaves in an increasing (1 to 31) or decreasing (31 to 1) direction. A long press on the "-/-" pushbutton on the TSX SAY 100 module changes the direction.

02



W913294970801A 02

Schneider Electric Industries SAS

Headquarters

89, bd Franklin Roosevelt
F - 92506 Rueil Malmaison Cedex

<http://www.schneider-electric.com>

Owing to changes in standards and equipment,
the characteristics given in the text and images
in this document are not binding us
until they have been confirmed with us.

Printed in Italy

September 2004