

Public Works Canada  
Design and Construction  
Technology

ABC PROGRAM:  
USER'S MANUAL

Version 3.0  
March 1980



---


Computer-Aided Design (CAD)

Information and assistance:

GAD Centre  
Public Works Canada  
7-E, Sir Charles Tupper Bldg.  
Riverside Drive  
Ottawa K1A 0M2

---

Not a departmental publication: do not cite as reference or catalogue in library.



1. **PURPOSE**

This program provides a fast easy-to-use tool to aid in the evaluation of architectural building concepts. The program estimates the effect on annual heating/cooling energy requirements of architectural factors such as shape and size of building, orientation, amount and type of glass, amount of insulation, lighting level, and infiltration.

The program is intended to aid in making decisions about these architectural concepts at the early design stage, when the design alternatives are little more than rough sketches. Since little consideration is given to HVAC system design at this stage, it assumes the use of 'ideal' HVAC systems.

The assumptions contained in the ABC program are adequate for a "first-cut" design tool. This program should be used to compare the relative energy consumption of design options, not as an estimate of the absolute value of building energy consumption. A more detailed energy analysis program, which can account for the many building and system variables, should be used at later stages of design in order to obtain a more accurate estimate of absolute energy consumption.

## 2. DESCRIPTION

This program provides estimates of annual building heating/cooling energy requirements. It uses a table lookup interpolation method based on a database created using hourly calculations (basically the same algorithms and weather data as used by the Meriwether ERE program). The results are equivalent to those obtained using ERE with the following assumptions:

- standard weather and solar data.
- building thermal mass effects are neglected.
- room temperature maintained as stated on database file. (Normally heating to 72°F, and cooling to 78°F.)
- internal load profiles restricted to one value for occupied periods, and another value for unoccupied periods.
- ventilation and infiltration similarly assumed to have one constant value for occupied periods, and another constant value for unoccupied periods. (Infiltration is not a function of outdoor temperature.)
- the system without economizer is one which provides the heating or cooling required. The only outside air provided is that specified for ventilation + infiltration. (This system is the equivalent of Meriwether's Type 3 system. It provides only sensible cooling, and never reheats.)
- the system using economizer is an ideal VAV system supplying the required quantity of air at a temperature of 60°F and dewpoint of 57°F. The minimum on the supply air flow is equal to the ventilation + infiltration.

This program (like Meriwether's ERE) analyses only one zone or thermal block at a time. A thermal block is defined as an area which is thermally homogeneous. That is, each part of the area 'sees' the same thermal loads (e.g. lights, people, solar, transmission, etc.). An additional restriction of ABC is that all windows of a zone must face in the same direction. A building is usually divided into an interior zone, plus one perimeter zone facing each direction. The depth of the perimeter is normally 12-20 feet.

Version 3.0 of the ABC program provides the capability of summing a number of zones together to obtain a building total.

### 3.       **HARDWARE AND DISK REQUIREMENTS**

The ABC program will operate on an IM/70 minicomputer with three floppy disk drives, a video terminal, and a printer. The program is contained on one floppy disk; the database is contained on a separate disk.

Two data base disks are currently available, both for 72-78°F thermostat setting:

- 1) Calgary, Halifax, Montreal, Ottawa, Saskatoon, Toronto, Vancouver.
- 2) Victoria, Quebec City, Winnipeg, Edmonton, Regina, Kamloops, Whitehorse.

## INITIATING THE PROGRAM

(Note: You must terminate each input by hitting carriage return.)

- 'Power-up' the minicomputer as described in 'An Introduction to Running Fortran Programs Under FOS 4.1'.
- Install the 'ABC program' disk into floppy drive no. 1.
- Install an 'ABC Data' disk into floppy drive no. 2. (Two data disks are provided. Choose the disk which contains data for the location of the building you wish to analyse. At present data is available for 14 cities.)
- Type /BA F1.ABC1 (if you don't have a line printer, type /BA F1.ABC0).
- A list of the locations contained on the data disk will be displayed.
- You must specify one of these locations for your analysis.
- There will be a brief pause while the files are readied.
- The program will then ask which system of units you wish to use:
  - Reply: IM If you wish imperial units
  - SI If you wish SI units.
- The program will ask for a project title. This title (maximum of 72 characters) will appear on each page of program output.
- The program will then ask a series of questions pertaining to zone input data. This input data is summarized in Table I. A further description of the input data is given in Section 5.
- Although defaults are provided for most of the inputs it is good practice to enter values at this time (most of the default values are zero).
- If you make an error in input, and notice it before hitting RETURN, you may "backspace" (←) and then enter the correct input. If you notice an error after hitting RETURN, don't worry; proceed to complete the input, after which you may easily correct the error using the editing capability described in Section 5.
- When all input has been provided the program will compute and display the annual heating and cooling requirements.
- The program will then prompt with COMMAND? To obtain a list of valid responses to this prompt, type HELP.
- You may now either change the input data using edit instructions described in Section 5, or you may issue commands to the program as described in Section 6.

TABLE I  
ABC PROGRAM INPUT

LOCATION _____				
UNITS _____		IM	or	SI
PROJECT _____				
_____ ZONE: description _____				
_____ MULT: zone multiplier _____				
_____ AREA: floor area _____				
		ft <sup>2</sup>	or	m <sup>2</sup>
_____ DIRX: direction _____				
_____ WALL: gross wall area _____				
		ft <sup>2</sup>	or	m <sup>2</sup>
	u-value _____	btu	or	watt
		hr.ft <sup>2</sup> OF	or	m <sup>2</sup> OC
_____ WIND: window area _____				
	u-value _____	ft <sup>2</sup>	or	m <sup>2</sup>
	shading ceet. _____	btu	or	watt
		hr.ft <sup>2</sup> OF	or	m <sup>2</sup> OC
_____ ROOF: roof area _____				
	u-value _____	ft <sup>2</sup>	or	m <sup>2</sup>
		btu	or	watt
		hr.ft <sup>2</sup> OF	or	m <sup>2</sup> OC
_____ TIME: occupied - no. of days/week _____				
	unoccupied - no. of days/week _____			
_____ LITE: power to lights - occupied _____				
	- unoccupied _____	watt	or	watt
		ft <sup>2</sup>		m <sup>2</sup>
_____ PEOP: people density - occupied _____				
	- unoccupied _____	ft <sup>2</sup>	or	m <sup>2</sup>
		person		person
_____ VENT: ventilation (min. O.A.) - occupied _____				
	- unoccupied _____	cfm	or	1
		ft <sup>2</sup>		soc.m <sup>2</sup>
	infiltration - occupied _____			
	- unoccupied _____			

## 5. EDITING INPUT

You may use the editing features to change your input data. Input data is organized in groups called data-groups. Each data-group has a 4-character identifier. To edit data enter the identifier for the data-group for which you wish to make a change. The program will prompt you for input. If you do not wish to enter a new value hit carriage return and the data will remain unchanged. (The 'default' value is shown at the right side of the screen.)

The data-groups are:

**ZONE:** This permits you to supply a label to identify the zone. The label may be up to 80 characters (one line).

**MULT:** It is sometimes convenient to specify the input data on the basis of a module (for example a typical floor). The zone multiplier is the number of these modules which make up the zone. In effect, this means that the areas specified for floor area, wall, window and roof are multiplied by the zone multiplier, (range 1. to 9999.9).

**AREA:** Enter floor area (range 1. to 999999999.).

**DIRX:** Enter the direction in which windows for this zone face. Note that all windows must face in the same direction. Valid directions are NORTH, N.E., EAST, S.E., SOUTH, S.W., WEST and N.W. (note that the program recognizes only the first 4 characters, and requires the periods in N.E. etc.). Enter INTR to indicate that the zone is an interior zone (i.e. one with no walls or windows).

**WALL:** Enter gross wall area (range 0. to 999999999.). This should be the total area of the wall including window area. (The program subtracts the window area to get the net opaque wall area.)

The following is input only if wall area is not zero:

- U-value of opaque wall (range 0. to 10.).



**WIND:** Window area may be expressed as either an absolute area or as a percentage of gross wall area.

Enter value for absolute area (range 0. to 999999999.). Enter value followed by % for percentage (range 0. to 100.). (Example 50%).

The following are input only if window area is not zero:

- U-value of window (range 0. to 10.).
- Shading coefficient of window (range 0. to 1.).

**ROOF:** Enter roof area (range 0. to 999999999.).

The following is input only if roof area is not zero:

- U-value of roof (range 0. to 10.).

**TIME:** Internal loads (as well as infiltration and ventilation) may vary with time. One value may be specified for occupied periods and another value for unoccupied periods. The occupied and unoccupied periods are defined in terms of 'days' (7AM-7PM) and 'nights' (7PM-7AM). For example a typical office building occupancy might be:

- Occupied for 5 days per week (weekdays)  
and 0 nights per week
- Unoccupied for 2 days per week (weekends)  
and 7 nights per week.

Note that input must be integer numbers (i.e. no decimal point) in the range of 0 to 7.

**LITE:** Enter power input to lights for occupied and unoccupied periods. This may also include miscellaneous electric loads such as office equipment, etc. (Range 0. to 99.).

**PEOP:** Enter people density expressed as floor area per person for occupied and unoccupied periods. Enter 0 to indicate that there are no people in the room. (Range 0. to 99999.).

**VENT:** Enter ventilation and infiltration rates for occupied and unoccupied periods (range 0. to 99.). Ventilation is the quantity of outside air supplied by the HVAC system (minimum outside air for system with economizer).

## COMMANDS

You may request the program to execute the following commands:

- LIST:** This command causes the input data contained in memory to be displayed on the screen. Input data is shown with the Data-group identifier used for editing data.
- CALC:** This command causes the annual heating/cooling corresponding to the input data in memory to be calculated and the result displayed on the screen.
- PRIN:** This command causes the input data contained in the memory to be printed on the line printer along with the computed heating/cooling corresponding to that input. This provides a permanent record of the analysis.
- BEGI:** This command causes the program to prompt you for all of the input data (using present values as defaults). This may be useful when a number of items of input are to be changed; it acts as a check to make sure you don't forget something.
- STOP:** This command causes the program to stop.

The following commands are used to sum a number of zones to obtain a building total:

- ADD:** This command causes the input data which is presently in memory to be "added" to the building file (a file containing the data for all the zones in the building). The next available zone number will be assigned to the data by the program; remember this zone number because you may wish to access this data later. The data in memory is unchanged by the ADD command.
- SUM:** This command causes the data for each zone on the building file to be read into memory and printed on the line printer along with the computed heating/cooling consumption corresponding to this input. This is followed by a print-out of the building total which is the sum of the zones. Note that the data in memory is destroyed by the SUM command; it is replaced by the data for the last zone in the building file.
- GET:** This command is used to "get" the input data from a particular zone on the building file; this data replaces the input data presently in memory. The input data will be displayed on the screen.

**REP:** This command replaces the data for a particular zone in the building file with the data presently in memory.

**DEL:** This command is used to "delete" a zone from the building file. This means that this zone will no longer be included in the building total for a SUM command. Note that the data for a deleted zone is still present on the building file; it has simply been flagged as a deleted zone. You may still GET this data from the file. (In fact, you can "restore" the deleted file by GETting it and then REPlacing it.)

## 7. ERROR MESSAGES

All input is checked for validity and allowable range: should an error be detected a message will be displayed on the screen and you will be prompted to re-enter the data. Most of the error messages should be self-explanatory.

(Take care to distinguish between the numeral 0 and the letter O.)

The following error messages may occur during execution of the calculation phase of the program:

### -\*\*\* WINDOW AREA EXCEEDS GROSS WALL AREA

- Since gross wall area is the sum of opaque wall plus window area, this represents an impossible situation. Correct your input and try again.

### -\*\*\* OUT OF RANGE OF DATABASE

- The database is defined for only a finite range of conditions. Input data in which both conduction (U-value \* area) and ventilation/infiltration are very small, or internal heat gains (lights + people) are very large, may result in conditions which are outside this range. Check your input.

### -\*\*\* FILE ERROR- CITY NAME

- This means that the city names on the database files do not match. This is a system error: the file may be faulty or a reading error may have occurred. Try again from the beginning.

8. **EXAMPLE**

To illustrate the operation of the program assume a very simple building consisting of two zones: a perimeter zone for which the input data is given in Table II(a), and an interior zone for which the input data is given in Table II(b). Note that Table II(b) shows only those values which are different than for the perimeter zone. The procedure would then be:

- initiate the ABC program as described in Section 4 and input the values given in Table II(a).
- LIST to check for input errors.
- CALC to see if results are reasonable.
- when satisfied that the perimeter zone has been properly input, ADD to building file.
- edit the input to form data for interior zone. This would involve ZONE, AREA, DIRX, ROOF and VENT.
- LIST to check for input errors.
- CALC to see if results are reasonable.
- when satisfied with interior zone, ADD to building file.
- SUM to obtain the building total. The resulting printout is shown on the following pages:

TABLE II(a)  
ABC PROGRAM INPUT

LOCATION	<u>Montreal</u>			
UNITS	<u>IM</u>	IM	or	SI
PROJECT	<u>Example building</u>			
ZONE: description	<u>Perimeter zone-facing south east</u>			
MULT: zone multiplier	<u>1</u>			
AREA: floor area	<u>1000</u>	ft <sup>2</sup>	or	m <sup>2</sup>
DIRX: direction	<u>S.E.</u>			
WALL: gross wall area	<u>950</u>	ft <sup>2</sup>	or	m <sup>2</sup>
u-value	<u>0.13</u>	$\frac{\text{btu}}{\text{hr. ft}^2 \text{ } ^\circ\text{F}}$	or	$\frac{\text{watt}}{\text{m}^2 \text{ } ^\circ\text{C}}$
WIND: window area	<u>45%</u>	ft <sup>2</sup>	or	m <sup>2</sup>
u-value	<u>0.63</u>	$\frac{\text{btu}}{\text{hr. ft}^2 \text{ } ^\circ\text{F}}$	or	$\frac{\text{watt}}{\text{m}^2 \text{ } ^\circ\text{C}}$
shading ceet.	<u>0.94</u>			
ROOF: roof area	<u>500</u>	ft <sup>2</sup>	or	m <sup>2</sup>
u-value	<u>0.085</u>	$\frac{\text{btu}}{\text{hr. ft}^2 \text{ } ^\circ\text{F}}$	or	$\frac{\text{watt}}{\text{m}^2 \text{ } ^\circ\text{C}}$
TIME: occupied - no. of days/week	<u>5</u>			
unoccupied - no. of days/week	<u>0</u>			
LITE: power to lights - occupied	<u>3.0</u>	$\frac{\text{watt}}{\text{ft}^2}$	or	$\frac{\text{watt}}{\text{m}^2}$
- unoccupied	<u>0.25</u>			
PEOP: people density - occupied	<u>200</u>	$\frac{\text{ft}^2}{\text{person}}$	or	$\frac{\text{m}^2}{\text{person}}$
- unoccupied	<u>0</u>			
VENT: ventilation (min. O.A.) - occupied	<u>0.1</u>	$\frac{\text{cfm}}{\text{ft}^2}$		$\frac{1}{\text{soc. m}^2}$
- unoccupied	<u>0</u>			
infiltration - occupied	<u>0.05</u>			
- unoccupied	<u>0.05</u>			

TABLE II(a)  
ABC PROGRAM INPUT

LOCATION	<u>Montreal</u>				
UNITS		<u>IM</u>	IM	or	SI
PROJECT	<u>Example building</u>				
ZONE: description	<u>Perimeter zone-facing south east</u>				
MULT: zone multiplier		<u>1</u>			
AREA: floor area		<u>1000</u>	ft <sup>2</sup>	or	m <sup>2</sup>
DIRX: direction		<u>S.E.</u>			
WALL: gross wall area		<u>950</u>	ft <sup>2</sup>	or	m <sup>2</sup>
u-value		<u>0.13</u>	$\frac{\text{btu}}{\text{hr. ft}^2 \text{ } ^\circ\text{F}}$	or	$\frac{\text{watt}}{\text{m}^2 \text{ } ^\circ\text{C}}$
WIND: window area		<u>45%</u>	ft <sup>2</sup>	or	m <sup>2</sup>
u-value		<u>0.63</u>	$\frac{\text{btu}}{\text{hr. ft}^2 \text{ } ^\circ\text{F}}$	or	$\frac{\text{watt}}{\text{m}^2 \text{ } ^\circ\text{C}}$
shading ceet.		<u>0.94</u>			
ROOF: roof area		<u>500</u>	ft <sup>2</sup>	or	m <sup>2</sup>
u-value		<u>0.085</u>	$\frac{\text{btu}}{\text{hr. ft}^2 \text{ } ^\circ\text{F}}$	or	$\frac{\text{watt}}{\text{m}^2 \text{ } ^\circ\text{C}}$
TIME: occupied - no. of days/week		<u>5</u>			
unoccupied - no. of days/week		<u>0</u>			
LITE: power to lights - occupied		<u>3.0</u>	$\frac{\text{watt}}{\text{ft}^2}$	or	$\frac{\text{watt}}{\text{m}^2}$
- unoccupied		<u>0.25</u>			
PEOP: people density - occupied		<u>200</u>	$\frac{\text{ft}^2}{\text{person}}$	or	$\frac{\text{m}^2}{\text{person}}$
- unoccupied		<u>0</u>			
VENT: ventilation (min. O.A.) - occupied		<u>0.1</u>	$\frac{\text{cfm}}{\text{ft}^2}$	or	$\frac{1}{\text{soc. m}^2}$
- unoccupied		<u>0</u>			
infiltration - occupied		<u>0.05</u>			
- unoccupied		<u>0.05</u>			

TABLE II(b)  
ABC PROGRAM INPUT

LOCATION				
UNITS		IM	or	SI
PROJECT				
<hr/>				
ZONE: description	<u>Interior zone</u>			
<hr/>				
MULT: zone multiplier				
<hr/>				
AREA: floor area	<u>1200</u>	ft <sup>2</sup>	or	m <sup>2</sup>
<hr/>				
DIRX: direction	<u>INTR</u>			
<hr/>				
WALL: gross wall area		ft <sup>2</sup>	or	m <sup>2</sup>
u-value		$\frac{\text{btu}}{\text{hr. ft}^2 \text{ } ^\circ\text{F}}$	or	$\frac{\text{watt}}{\text{m}^2 \text{ } ^\circ\text{C}}$
<hr/>				
WIND: window area		ft <sup>2</sup>	or	m <sup>2</sup>
u-value		$\frac{\text{btu}}{\text{hr. ft}^2 \text{ } ^\circ\text{F}}$	or	$\frac{\text{watt}}{\text{m}^2 \text{ } ^\circ\text{C}}$
shading ceet.				
<hr/>				
ROOF: roof area	<u>600</u>	ft <sup>2</sup>	or	m <sup>2</sup>
u-value		$\frac{\text{btu}}{\text{hr. ft}^2 \text{ } ^\circ\text{F}}$	or	$\frac{\text{watt}}{\text{m}^2 \text{ } ^\circ\text{C}}$
<hr/>				
TIME: occupied - no. of days/week				
unoccupied - no. of days/week				
<hr/>				
LITE: power to lights - occupied		watt	or	watt
- unoccupied		ft <sup>2</sup>		m <sup>2</sup>
<hr/>				
PEOP: people density - occupied		ft <sup>2</sup>	or	m <sup>2</sup>
- unoccupied		person		person
<hr/>				
VENT: ventilation (min. O.A.) - occupied		cfm	or	$\frac{1}{\text{soc. m}^2}$
- unoccupied		ft <sup>2</sup>		
infiltration - occupied	<u>0.</u>			
- unoccupied	<u>0.</u>			



PUBLIC WORKS CANADA 'ABC' PROGRAM-VERSION 3.0

PROJECT:  
EXAMPLE BUILDING

\*\*\*ZONE NUMBER 1

ZONE: PERIMETER ZONE- FACING SOUTH EAST  
 MULT: ZONE MULTIPLIER= 1.0  
 AREA: FLOOR AREA= 1000. (SQ-FT)  
 DIR:: DIRECTION= S. E.  
 WALL: WALL AREA= 950. (SQ-FT) ; U-VALUE= .130 (BTU/HR SQ-FT DEG-F)  
 WIND: WINDOW AREA= 45. % ; U-VALUE= .630 (BTU/HR SQ-FT DEG-F)  
 ; SHADING COEF:= .94  
 ROOF: ROOF AREA= 500. (SQ-FT) ; U-VALUE= .085 (BTU/HR SQ-FT DEG-F)  
 TIME: OCCUPIED PERIOD= 5 DAYS/WEEK ; 0 NIGHTS/WEEK  
 UNOCCUPIED PERIOD= 2 DAYS/WEEK ; 7 NIGHTS/WEEK  
 LITE: OCCUPIED= 3.00 (WATT/SQ-FT) ; UNOCCUPIED= .25 (WATT/SQ-FT)  
 PEOP: OCCUPIED= 200. (SQ-FT/PERSON) ; UNOCCUPIED= 0. (SQ-FT/PERSON)  
 VENT: VENTILATION REQUIREMENTS:  
 OCCUPIED= .100 (CFM/SQ-FT) ; UNOCCUPIED= 0.000 (CFM/SQ-FT)  
 INFILTRATION RATE  
 OCCUPIED= .050 (CFM/SQ-FT) ; UNOCCUPIED= 0.000 (CFM/SQ-FT)

\*\*\*USING DATA FILE: MTL

-MONTREAL REFERENCE YEAR, STANDARD SOLAR, TSTAT=72-78 F.

\*\* ANNUAL REQUIREMENT \*\*

ELECTRICITY (LIGHTS): 10794. (KWH) ; 10.79 (KWH/SQ-FT)

\*\* CONSTANT OPERATION \*\*

HEATING: 57638. (MBTU) ; 57.64 (MBTU/SQ-FT)

COOLING:

-SYSTEM WITHOUT ECONOMIZER= 8452. (TON-HR); 8.45 (TON-HR/SQ-FT)

-SYSTEM WITH ECONOMIZER (VAV)= 2442. (TON-HR); 2.44 (TON-HR/SQ-FT)

\*\* SETBACK (65 F.) WHEN UNOCCUPIED \*\*

HEATING: 46892. (MBTU) ; 46.89 (MBTU/SQ-FT)

COOLING:

-SYSTEM WITHOUT ECONOMIZER= 6201. (TON-HR); 6.20 (TON-HR/SQ-FT)

-SYSTEM WITH ECONOMIZER (VAV)= 1842. (TON-HR); 1.84 (TON-HR/SQ-FT)

PUBLIC WORKS CANADA 'ABC' PROGRAM-VERSION 3.0

PROJECT:  
EXAMPLE BUILDING

\*\*\*ZONE NUMBER 2  
 ZONE: INTERIOR ZONE  
 MULT: ZONE MULTIPLIER= 1.0  
 AREA: FLOOR AREA= 1200. (SQ-FT)  
 DIRX: DIRECTION= INTR  
 ROOF: ROOF AREA= 600. (SQ-FT) ; U-VALUE= .085 (BTU/HR SQ-FT DEG-F)  
 TIME: OCCUPIED PERIOD= 5 DAYS/WEEK ; 0 NIGHTS/WEEK  
 UNOCCUPIED PERIOD= 2 DAYS/WEEK ; 7 NIGHTS/WEEK  
 LITE: OCCUPIED= 3.00 (WATT/SQ-FT) ; UNOCCUPIED= .25 (WATT/SQ-FT)  
 PEOP: OCCUPIED= 200. (SQ-FT/PERSON) ; UNOCCUPIED= 0. (SQ-FT/PERSON)  
 VENT: VENTILATION REQUIREMENTS:  
 OCCUPIED= .100 (CFM/SQ-FT) ; UNOCCUPIED= 0.000 (CFM/SQ-FT)  
 INFILTRATION RATE  
 OCCUPIED= 0.000 (CFM/SQ-FT) ; UNOCCUPIED= 0.000 (CFM/SQ-FT)

\*\*\*USING DATA FILE: MTL  
 -MONTREAL REFERENCE YEAR, STANDARD SOLAR, TSTAT=72-78 F.

\*\* ANNUAL REQUIREMENT \*\*  
 ELECTRICITY (LIGHTS): 12952. (KWH) ; 10.79 (KWH/SQ-FT)

\*\* CONSTANT OPERATION \*\*  
 HEATING: 3963. (MBTU) ; 3.30 (MBTU/SQ-FT)  
 COOLING:  
 -SYSTEM WITHOUT ECONOMIZER= 2095. (TON-HR); 1.75 (TON-HR/SQ-FT)  
 -SYSTEM WITH ECONOMIZER (VAV)= 748. (TON-HR); .62 (TON-HR/SQ-FT)

\*\* SETBACK (65 F.) WHEN UNOCCUPIED \*\*  
 HEATING: 2807. (MBTU) ; 2.34 (MBTU/SQ-FT)  
 COOLING:  
 -SYSTEM WITHOUT ECONOMIZER= 2033. (TON-HR); 1.69 (TON-HR/SQ-FT)  
 -SYSTEM WITH ECONOMIZER (VAV)= 701. (TON-HR); .58 (TON-HR/SQ-FT)

PUBLIC WORKS CANADA 'ABC' PROGRAM-VERSION 3.0

PROJECT:  
EXAMPLE BUILDING

\*\*\* BUILDING TOTAL- SUM OF ZONES \*\*\*

# 1 PERIMETER ZONE- FACING SOUTH EAST  
# 2 INTERIOR ZONE

\*\*\*USING DATA FILE: MTL  
-MONTREAL REFERENCE YEAR, STANDARD SOLAR, TSTAT=72-78 F.

\*\* ANNUAL REQUIREMENT \*\*

ELECTRICITY (LIGHTS):                    23746. (KWH)       ;            10.79 (KWH/SQ-FT)

\*\* CONSTANT OPERATION \*\*

HEATING:                                    61602. (MBTU)       ;            28.00 (MBTU/SQ-FT)

COOLING:

-SYSTEM WITHOUT ECONOMIZER=            10548. (TON-HR);            4.79 (TON-HR/SQ-FT)

-SYSTEM WITH ECONOMIZER (VAV)=        3190. (TON-HR);            1.45 (TON-HR/SQ-FT)

\*\* SETBACK (65 F.) WHEN UNOCCUPIED \*\*

HEATING:                                    49700. (MBTU)       ;            22.59 (MBTU/SQ-FT)

COOLING:

-SYSTEM WITHOUT ECONOMIZER=            8233. (TON-HR);            3.74 (TON-HR/SQ-FT)

-SYSTEM WITH ECONOMIZER (VAV)=        2543. (TON-HR);            1.16 (TON-HR/SQ-FT)

**FOR FURTHER INFORMATION AND ASSISTANCE CONTACT:**

Public Works Canada  
Sir Charles Tupper Building  
Riverside Drive  
Ottawa, Ontario K1A 0M2  
(Tel. 613/998-9513)