


HI-TRAC EMU3



**TRAFFIC DATA MONITORING SYSTEM
INCORPORATING VOLUMETRIC COUNTING
TRAFFIC COUNTING AND CLASSIFYING
AND HIGH SPEED WEIGH-IN-MOTION**

USER MANUAL

TDC Systems Limited
Weston-Super-Mare
ENGLAND

Tel : +44 (0)1934 644299
Fax : +44 (0)1934 644255
Email : sales@tdcsystems.co.uk
Web : www.tdcsystems.co.uk



Contents

| | | |
|-----------|---|-----------|
| 1. | System Overview | 6 |
| 1.1. | Introduction | 6 |
| 1.2. | Remote Site Configuration | 7 |
| 1.3. | Operating Principles | 7 |
| 1.3.1. | Weigh-in-Motion | 7 |
| 1.3.2. | Counter/Classifying with Axle Detection (PLP) – Cycle Detection | 8 |
| 1.3.3. | Counter/Classifying with Axle Detection (LPL) | 9 |
| 1.3.4. | Counter/Classifying without Axle Detection (LL) | 9 |
| 1.3.5. | Volumetric Counter | 10 |
| 1.4. | Advanced Features | 10 |
| 1.4.1. | Piezo Sensor Temperature Non-Linearity Compensation | 10 |
| 1.4.2. | Loop Profiling | 10 |
| 1.5. | HI-TRAC® EMU3 Electronic Unit and Road Sensors | 11 |
| 1.5.1. | The HI-TRAC EMU3 Electronic Unit | 11 |
| 1.5.2. | The Piezo Sensor | 14 |
| 1.5.3. | The Inductive Loop Sensor | 15 |
| 2. | PERFORMANCE AND ACCURACY CRITERIA | 16 |
| 3. | HI-TRAC® Data Storage Capacity | 18 |
| 3.1. | Vehicle-by-Vehicle Data Storage | 18 |
| 3.2. | Statistical Data Files | 19 |
| 3.2.1. | ATMS Data Files | 20 |
| 3.2.2. | Malfunction Management Data Files | 21 |
| 4. | Installing & Connecting HI-TRAC® EMU3 to HI-COMM 100 | 22 |
| 4.1. | Front Panel Display | 22 |
| 4.2. | Connecting HI-TRAC® EMU3 to HI-COMM 100 for the first time | 23 |
| 4.3. | Installing the USB Driver Software | 23 |
| 4.4. | Installing HI-COMM 100 Windows Software | 27 |
| 4.5. | Setting Com Ports Correctly and Connecting to the HI-TRAC | 29 |
| 4.6. | Switching On the HI-TRAC EMU3 | 31 |
| 4.6.1. | Front Panel Display | 31 |
| 4.7. | Switching On the HI-TRAC EMU3 for the First Time | 32 |
| 4.7.1. | Setting HI-TRAC Time (Option 1) | 32 |
| 4.7.2. | Setting HI-TRAC Date (Option 2) | 32 |
| 4.7.3. | Connecting via USB | 33 |
| 5. | HI-TRAC® EMU3 Menu Options | 34 |

| | | |
|-----------|---|-----------|
| 6. | Configuring the HI-TRAC® EMU3 via Keypad and Display | 35 |
| 6.1. | Setting HI-TRAC Time (Option 1) | 35 |
| 6.2. | Setting HI-TRAC Date (Option 2) | 35 |
| 6.3. | Setting Laptop Port (Option 3) | 36 |
| 6.4. | Select USB or Serial Port | 36 |
| 6.5. | COM3 Enabled | 36 |
| 6.6. | Comms Set-Up (Option 4) | 36 |
| 6.6.1. | Access Code | 37 |
| 6.6.2. | Set Baud Rate | 37 |
| 6.6.3. | Modem Windows Off | 38 |
| 6.7. | Lane Config (Option 5) | 38 |
| 6.7.1. | HI-TRAC Lane Configuration | 38 |
| 6.8. | Lane Direction (Option 6) | 40 |
| 6.9. | Lane Settings (Option 7) | 40 |
| 6.9.1. | Set Loop Length | 40 |
| 6.9.2. | Set Loop Factor | 41 |
| 6.9.3. | Set Sensor Spacing | 41 |
| 6.10. | Loop Settings (Option 8) | 42 |
| 6.10.1. | Set Presence Time | 42 |
| 6.10.2. | Set Loop Sensitivity | 43 |
| 6.10.3. | Set Loop Detect | 43 |
| 6.10.4. | Set Drop-out | 44 |
| 6.11. | Using HI-COMM Software to set Loop Settings | 44 |
| 6.11.1. | Loop Sensitivity and Trigger | 45 |
| 6.11.2. | LCF Loop Compensation Factor | 45 |
| 6.11.3. | Drop Out | 46 |
| 6.11.4. | LLCF | 46 |
| 6.12. | Classification Table (Option 9) | 46 |
| 6.12.1. | Editing HI-TRAC Vehicle Classification Table | 46 |
| 6.13. | Using HI-COMM 100 Software to set Classification Parameters | 49 |
| 6.14. | Battery/Temperature (Option 10) | 53 |
| 6.15. | Modem Options (Option 11) | 53 |
| 6.16. | Country (Option 12) | 54 |
| 6.17. | Test Sign (Option 13) – Sign Option | 54 |
| 6.17.1. | Test Output 1 and Output 2 | 54 |
| 6.17.2. | Setting Speed Limits | 54 |
| 6.17.3. | Activating or Deactivating the Sign | 54 |

| | | |
|------------|--|-----------|
| 6.18. | Cycle Set Up (Option 13) – Cycle Option | 55 |
| 6.18.1. | Set Minimum Samples | 55 |
| 6.18.2. | Set Maximum Samples | 55 |
| 6.18.3. | Set Maximum Axle Weight | 55 |
| 6.18.4. | Set Maximum Signal Area | 56 |
| 7. | Menu Map | 57 |
| 8. | Additional Settings and Configuration for the HI-TRAC® EMU3 | 61 |
| 8.1. | Piezo Sensor Interface PCB Settings | 61 |
| 8.2. | Loop Sensor Interface PCB Settings | 62 |
| 8.3. | Reset Security Code | 62 |
| 8.4. | Reset Memory to Default Settings | 63 |
| 9. | BLUETOOTH MAC ANTENNA UPGRADE | 63 |
| 9.1. | Bluetooth Antenna | 63 |
| 9.2. | A Comparison of MAC data to Traffic Counter Flow Rates | 63 |
| 10. | HI-COMM 100 - Example Reports & Screen Displays | 65 |
| 10.1. | Examples of HI-COMM 100 Software Screen Displays | 65 |
| 11. | Appendix A - HI-TRAC Solar Power Systems | 75 |
| 11.1. | Solar Energy | 75 |
| 11.2. | Panel Installation | 76 |

1. System Overview

1.1. Introduction

- The HI-TRAC® EMU3 is a traffic data collection system that can be configured as a weigh-in-motion (HSWIM) system; an automatic vehicle counter/classifier (AVC) or a loop volumetric counter. The HI-TRAC® EMU3 is the 3rd generation of the EMU system and now includes a 32 Megabyte onboard Flash memory with an additional 8Gigabyte microSD memory expandable to 32Gigabyte; greater processing power and much lower power consumption. The HI-TRAC EMU3 provides a low cost means of recording traffic data without interruption to traffic flow and will detect and record traffic at speeds from 1 to at least 250 kph.
- The unit incorporates interfaces to both piezo electric sensors; inductive loop sensors and two road installed temperature probes. The signal from the piezo-electric sensors is used to calculate the axle loading, vehicle speed and vehicle inter-axle separation as the vehicle passes over the road sensor array. The signal from the inductive loops is used to measure induction change as the metal chassis of a vehicle passes into the detection zone of the inductive loop. The temperature probe is an integral part of TDC's advanced temperature compensation system.
- The HI-TRAC EMU3 is designed to be installed in a permanent roadside cabinet.
- The HI-TRAC® EMU3 can be powered from mains supply or solar panel and associated battery/regulator in permanent installations. Alternatively due to its low power consumption it can be powered from a 6v battery for a limited survey period at sites where no other power source is available.
- The system consists of road-installed items of up to 8 piezoelectric sensors (Class 1 WIM applications or Class 2 AVC applications) and 16 inductive loops. A road installed temperature probe is required for WIM applications; allocation is made for two such probes.
- A 4-line by 20-character LCD located on the front panel displays the data recorded from the last vehicle and in conjunction with a 16-key membrane keypad facilitates localised setting of configuration parameters, calibration and other functions.
- The HI-TRAC® EMU3 includes a front panel USB port to facilitate the connection of a laptop computer. Additionally, via a back panel connector, the RS232 port can be connected to a GSM/GPRS or landline modem to facilitate remote data download, administration and real time viewing of traffic.
- Data is stored internally on 32MB Flash Mass Storage Media Drive and MicroSD card providing a maximum storage of over 800,000,000 vehicle records.
- The HI-TRAC® EMU3 system utilizes the *TDC Systems Neural Network Temperature Compensation Algorithm* to continually fine tune temperature compensation for optimum system performance and accuracy.
- The HI-TRAC® EMU3 incorporates an *Advanced Loop Profiling* function. This function utilises an *Advanced Vehicle Loop Signature Identification Algorithm* to enhance vehicle classification accuracy.

1.2. Remote Site Configuration

There are several configurations dependent upon the application:

1. Weigh-in-Motion (High Accuracy) – Up to 4 lanes of Piezo-Loop-Piezo sensor layout using two Class 1 piezo sensors per lane (PLP).
2. Weigh-in-Motion (Low Accuracy) – Up to 8 lanes of Loop-Piezo-Loop sensor layout using one Class 1 piezo sensor per lane (LPL).
3. Counter/Classifying with Axle Detection - Up to 4 lanes of Piezo-Loop-Piezo sensor layout using two Class 2 piezo sensors per lane (PLP). This also provides for bicycle detection in mixed traffic environment.
4. Counter/Classifying with Axle Detection - Up to 8 lanes of Loop-Piezo-Loop sensor layout using one Class 2 piezo sensor per lane (LPL).
5. Counter/Classifying without Axle Detection – Up to 8 lanes of Loop-Loop sensor layout (LL).
6. Volumetric Counting – Up to 16 lanes of single Loop sensor layout (N) or up to 6 lanes of N+1 (LOOP+1 configuration).

The HI-TRAC EMU3 can also be configured as a Bicycle and Motorcycle classifier; a loop profiling classifier and; dependent upon application an Event Monitoring function can be incorporated.

1.3. Operating Principles

1.3.1. Weigh-in-Motion

The piezo-electric sensor outputs electrical charge proportional to the applied pressure of a vehicle axle or wheel passing over it. The electrical charge is converted into a voltage, by the HI-TRAC® EMU3 electronic unit. The voltage signal is monitored by HI-TRAC® EMU3 and used to determine axle detection times. The amplitude of the signal gives an indication of axle weight.

With Piezo-Loop-Piezo sensor configuration, the piezoelectric sensors are installed 3 Metres apart in the road surface. The inductive loop is 2 Metres square. The loop is situated symmetrically between the sensors, in the lane. The time between the same axle being detected on both piezo sensors provides an axle speed measurement.

The separation between each axle pair on the vehicle is calculated from the axle detection times recorded on a single sensor and multiplying by the calculated speed. For improved accuracy this result is averaged over the two sensors.

The inductance value of the road-installed loop changes when a vehicle passes through the loop detection zone. This causes a change in the oscillation frequency of the loop detector circuitry inside the HI-TRAC® EMU3 electronic unit. This change in frequency is monitored by the loop detector and used to determine when vehicles are over the sensor array. The vehicle length is determined from the length of time the inductive loop was *activated* by the metal chassis of the vehicle. The frequency change profile is also used in determining the vehicle class (**Loop Profiling** function).

The inductive loop signal is also used to distinguish between closely moving traffic. If the loop detector output deactivates it is assumed by the HI-TRAC® system that the final axle has been detected on the first piezo sensor (that is the first sensor in the direction of traffic). This is then determined to be the total number of axles on the currently detected vehicle.

Where two or more lanes are installed with sensors the HI-TRAC® EMU3 is capable of determining and recording vehicles that straddle adjacent lanes.

1.3.2. Counter/Classifying with Axle Detection (PLP) – Cycle Detection

The piezo-electric sensor outputs electrical charge proportional to the applied pressure of a vehicle axle or wheel passing over it. The electrical charge is converted into a voltage, by the HI-TRAC® EMU3 electronic unit. The voltage signal is monitored by HI-TRAC® EMU3 and used to determine axle detection times.

With Piezo-Loop-Piezo sensor configuration, the piezoelectric sensors are installed 3 Metres apart in the road surface. The inductive loop is 2 Metres square. The loop is situated symmetrically between the sensors, in the lane. The time between the same axle being detected on both piezo sensors provides an axle speed measurement.

The separation between each axle pair on the vehicle is calculated from the axle detection times recorded on a single sensor and multiplying by the calculated speed. For improved accuracy this result is averaged over the two sensors.

The inductance value of the road-installed loop changes when a vehicle passes through the loop detection zone. This causes a change in the oscillation frequency of the loop detector circuitry inside the HI-TRAC® EMU3 electronic unit. This change in frequency is monitored by the loop detector and used to determine when vehicles are over the sensor array. The vehicle length is determined from the length of time the inductive loop was *activated* by the metal chassis of the vehicle. The frequency change profile is also used in determining the vehicle class (**Loop Profiling** function)

The inductive loop signal is also used to distinguish between closely moving traffic. If the loop detector output deactivates it is assumed by the HI-TRAC® system that the final axle has been detected on the first piezo sensor (that is the first sensor in the direction of traffic). This is then determined to be the total number of axles on the currently detected vehicle.

Where two or more lanes are installed with sensors the HI-TRAC® EMU3 is capable of determining and recording vehicles that straddle adjacent lanes.

The **Bicycle Detection Algorithm** used by the HI-TRAC can distinguish bicycles from other traffic in a mixed traffic environment. The HI-TRAC measures the wheelbase, speed and signal size to distinguish cycles from other traffic.

1.3.3. Counter/Classifying with Axle Detection (LPL)

With the Loop-Piezo-Loop sensor configuration, two 2M x 2M square loops are installed 2.5Metres apart. For the Loop-Piezo-Loop array the piezo sensor is located symmetrically between the two loops. The loops are used to determine vehicle speed calculated from the time difference between loop activations. The additional piezo sensor provides axle spacing measurement.

The principle of operation of the induction loop is based on the measured induction change as the metal chassis of a vehicle passes into the *detection zone* of the inductive loop. The loop has a given inductance, based primarily on number of turns of copper wire and loop size.

The inductive loop forms part of (or is a component in) an oscillator circuit inside the HI-TRAC® EMU3. When the metal chassis of the vehicle enters the detection zone of (or magnetic field emanating from) the inductive loop the overall effect is a small change in loop inductance. This causes a frequency change in the loop oscillator circuit inside the HI-TRAC® EMU3. The HI-TRAC® EMU3 monitors frequency change to determine vehicle presence and type of vehicle (classification) from the frequency change profile as the vehicle passes through the detection zone of the loops.

These frequency change signals are processed and then used to calculate vehicle speed, vehicle length and vehicle presence time over the in-road sensor array and hence provides an indication of the lane occupancy. The inductive loop signal is also used by HI-TRAC® EMU3 to determine vehicle chassis length and as an end-of-vehicle detector to separate closely passing traffic.

1.3.4. Counter/Classifying without Axle Detection (LL)

With Loop-Loop sensor configurations, two 2M x 2M square loops are installed 2.5Metres apart. The loops are used to determine vehicle speed calculated from the time difference between loop activations.

The principle of operation of the induction loop is based on the measured induction change as the metal chassis of a vehicle passes into the *detection zone* of the inductive loop. The loop has a given inductance, based primarily on number of turns of copper wire and loop size.

The inductive loop forms part of (or is a component in) an oscillator circuit inside the HI-TRAC® EMU3. When the metal chassis of the vehicle enters the detection zone of (or magnetic field emanating from) the inductive loop the overall effect is a small change in loop inductance. This causes a frequency change in the loop oscillator circuit inside the HI-TRAC® EMU3. The HI-TRAC® EMU3 monitors frequency change to determine vehicle presence and type of vehicle (classification) from the frequency change profile as the vehicle passes through the detection zone of the loops.

These frequency change signals are processed and then used to calculate vehicle speed, vehicle length and vehicle presence time over the in-road sensor array and hence provides an indication of the lane occupancy. The inductive loop signal is also used by HI-TRAC® EMU3 to determine vehicle chassis length and as an end-of-vehicle detector to separate closely passing traffic.

1.3.5. Volumetric Counter

With a single loop sensor configuration; i.e. one loop installed into each lane, the HI-TRAC EMU3 can be used as a basic traffic volume counter.

N and N+1 configurations are supported to prevent double counting with straddling vehicles.

1.4. Advanced Features

1.4.1. Piezo Sensor Temperature Non-Linearity Compensation

The HI-TRAC® WIM systems incorporates advanced automatic temperature compensation algorithms.

It is understood that WIM sensors have different characteristics of output with temperature due to a number of factors including road surface type, resin, sensor, vehicle type and others.

The variation of output against temperature is repeatable and this fact is used by the HI-TRAC® WIM system to achieve the most accurate weight data. The HI-TRAC® system learns this variation over time by monitoring traffic weight variations against temperature on a per lane basis.

The HI-TRAC® WIM uses *Temperature Non-Linearity (TNL) factors* per degree centigrade per lane to correct for temperature variation of sensor output. Each WIM lane has a temperature compensation profile built up from the TNL factors. It is common for each lane in a system using the same sensors, resin and road surface type to have a different temperature compensation profile.

1.4.2. Loop Profiling

The HI-TRAC® series of traffic monitoring equipment now incorporates TDC Systems Ltd *Advanced Loop Profiling* function. This function utilises an *Advanced Vehicle Loop Signature Identification Algorithm* in the embedded software.

Using the waveform viewing function of the HI-COMM 100 software the Loop Signature Parameters for any particular class of vehicle is observed and stored. The signature will show the frequency change profile of the HI-TRAC® loop detection oscillator as the metal chassis of the vehicle passes over the sensor array.

The loop profiling function enhances the accuracy of vehicle classification and is built into the HI-TRAC® EMU3 as a standard feature.

1.5. HI-TRAC® EMU3 Electronic Unit and Road Sensors

1.5.1. The HI-TRAC EMU3 Electronic Unit

The HI-TRAC® EMU3 electronic unit resides in the roadside cabinet and connects to all of the road-installed items. The HI-TRAC® EMU3 connections include:

- 8 x Piezo Sensor
- 16 x Inductive Loop Sensor
- 2 x Thermistor Probe
- USB Laptop Communication Port (Front Panel)
- RS232 Modem Communication Port (Back Panel)
- Auxiliary I/F for Bluetooth Journey Time device or VMS control
- Ethernet port
- Switched Output I/F
- Modem Power Output (6V DC)
- Battery Power Input (6V DC)

The vehicle data recorded by the HI-TRAC® EMU3 can be retrieved into the HI-COMM 100 Traffic Data Collection Windows software package via a laptop; GSM/GPRS modem or landline modem connection. In addition all HI-TRAC® EMU3 configuration parameters can be programmed using HI-COMM. These settings can be stored into a file on the computer and can later be uploaded from computer to HI-TRAC®.

The system is designed to work via the telephone network using any number of different manufacturer's modems. Either DC powered modem or GSM/GPRS modem will operate with the HI-TRAC® EMU3 system. The HI-TRAC® EMU3 provides the DC power output to the modem. This has the advantage of allowing the HI-TRAC® EMU3 to provide power cycling to the modem each hour (switching the modem off and on again and then re-initializing the modem) to prevent modem latch-up problems.

The HI-TRAC® EMU3 is a 6 volt system. For limited period operation the unit can operate directly from a 6V battery however the system is designed for use from AC Mains via a 6V power regulator. A 6V battery charger and battery can both be connected to the HI-TRAC® EMU3 to provide mains power with standby battery operation.

Alternatively the HI-TRAC® EMU3 can run from a 6 Volt battery and solar array. The size of solar panel is dependent on local sunlight conditions. Typically a 10 Watt solar panel is sufficient to power the HI-TRAC® EMU3 through the year. This can be fitted to the roadside cabinet or for more efficient operation located on a pole alongside the roadside cabinet.

Power consumption of the HI-TRAC® EMU3 with all lanes operating is 0.1 Watts (this does not take into account modem power consumption – the typical power requirement of a GSM Modem in standby mode is 0.05W and when online or making a call this can rise to 1.5W).

The system consists of:

Classifier Electronic Unit

Cable set and battery charger including;-

USB laptop cable

Modem cable (Landline/GSM/GPRS)

Loop Cable

Battery cable

The front and rear panels of the HI-TRAC EMU3 are shown below:





Optional Accessories:

- Solar Panel & Regulator
- GSM/GPRS Modem
- GSM Antenna
- 6V 12AH Battery
- 6V 32AH Battery

Mechanical:

The case is manufactured in stainless steel with a dry powder coat finish. It is fitted with a tactile membrane overlay incorporating a 0 to 9 keypad with dedicated function keys, LCD and LED windows.

1.5.2. The Piezo Sensor

The piezo sensor recommended by TDC Systems Limited is the Roadtrax BL sensor. The specification is as follows:


| | |
|--------------------------|---|
| Output Uniformity: | < $\pm 7\%$ for Class I (WIM) < $\pm 20\%$ for Class II (AVC) |
| Output Temperature Range | -40 to +80°C |
| Temperature Sensitivity | $\pm 0.1\%$ per °C |
| Product Life | 40,000,000 Equivalent Standard Axle Load's (dependent on installation) |

The unique construction of the BL sensor allows it to be installed directly into the road in a flexible format so that it can conform to the profile of the road.

The flat construction of the sensor gives an inherent rejection of road noise due to the road bending effect of an approaching axle and signal detection from adjacent lane activity.

The small cut size (19mm by 19mm slot) in the road minimises the damage which is done to the road, speeds up the installation time and reduces the amount of epoxy that is used for the installation.

For the Weigh-in-Motion installation temperature compensation of the piezo-electric output signal is required for most accurate weight measurement. This is achieved by means of a road-installed temperature sensor probe. The temperature probe is monitored by the HI-TRAC® EMU3 electronic unit.




1.5.3. The Inductive Loop Sensor

The principle of operation of the loop traffic counter is based on the measured induction change as the metal chassis of a vehicle passes into the *detection zone* of the inductive loop. The loop has a given inductance, based primarily on number of turns of copper wire and loop size.

Example: A typical value of loop inductance based on a 3 turn 2-Metre square loop of 2mm Copper Wire with a twisted feeder cable of 10 Metres is 80uH.

The inductive loop forms part of (or is a component in) an oscillator circuit inside the HI-TRAC® EMU3. When the metal chassis of the vehicle enters the detection zone of (or magnetic field emanating from) the inductive loop the overall effect is a small change in loop inductance. This causes a frequency change in the loop oscillator circuit inside the HI-TRAC® EMU3. The HI-TRAC® EMU3 monitors frequency change to determine vehicle presence and type of vehicle (classification) from the frequency change profile as the vehicle passes through the detection zone of the loops.

These frequency change signals are processed and then used to calculate vehicle speed, vehicle length and vehicle presence time over the in-road sensor array and hence provides an indication of the lane occupancy. The inductive loop signal is also used by HI-TRAC® EMU3 to determine vehicle chassis length and as an end-of-vehicle detector to separate closely passing traffic.



2. PERFORMANCE AND ACCURACY CRITERIA

General Performance Data:

| | | |
|----------------------------|---|---|
| Speed Range | : | 1 to at least 250 KPH |
| Storage Capacity | : | 32 Mbytes Flash Memory |
| | : | 8GB Micro SD Card (Upgradeable to 32GB) |
| Vehicle-by-Vehicle Storage | : | 800,000,000 VBV records |
| Lane Capacity WIM | : | 4 Lanes (PLP) |
| Lane Capacity AVC | : | 8 Lanes (LPL or LL) |
| Statistical File Storage | : | 150 days |
| ATMS File Storage | : | 50 Intervals |
| BINNED Data Storage | : | 8 Bins, 1600 Intervals |
| Telemetry Options | : | GSM, PSTN, GPRS |
| Temperature Range | : | -20C to +65C |
| Classification | : | EURO 6 (default) |
| | : | User Configurable |
| | : | Up to 110 Classes |

WIM Accuracy (Typical):

| | | |
|-------------------|---|-----------------|
| Gross Weight | : | ±10% GVW |
| Axle Group Weight | : | ±15% Axle Group |
| WIM Speed Range | : | 20 to 180 kph |

AVC Accuracy:

| | | |
|-----------------|---|--------------|
| Volume | : | 99% |
| Length | : | ±0.5M |
| Gap | : | ±8% |
| Headway | : | ±7% |
| Speed | : | ±1.5% |
| AVC Speed Range | : | 1 to 250 kph |

Classification Accuracy (based on EURO 6):

| | | Loops Only | Loop + Piezo |
|----------|---------------------|------------|--------------|
| Class 1: | Motorbike | 95% | 98% |
| Class 2: | Cars/Vans | 97% | 98% |
| Class 3: | Cars/Vans + Trailer | 97% | 98% |
| Class 4: | Rigid HGV | 97% | 98% |
| Class 5: | Articulated HGV | 97% | 99% |
| Class 6: | Buses and Coaches | 95% | 98% |

Classification Accuracy (based on DfT Scheme):

| | | Loop + Piezo |
|-----------|--------------------------------------|--------------|
| Class 0: | Motorbike | 98% |
| Class 1: | Cars | 98% |
| Class 2: | Vans | 95% |
| Class 21: | Car/Van + Trailer/Caravan | 98% |
| Class 31: | 2 Axle Rigid Truck | 98% |
| Class 32: | 3 Axle Rigid Truck | 98% |
| Class 33: | 4 Axle Rigid Truck | 99% |
| Class 41: | 3 Axle Drawbar Trailer | 99% |
| Class 42: | 4 Axle Drawbar Trailer | 99% |
| Class 43: | 5 Axle Drawbar Trailer | 99% |
| Class 44: | 6 Axle Drawbar Trailer | 99% |
| Class 51: | 3 Axle Articulated Truck | 99% |
| Class 52: | 4 Axle Articulated Truck (1+1+2) | 99% |
| Class 53: | 4 Axle Articulated Truck (1+2+1) | 99% |
| Class 54: | 5 Axle Articulated Truck (1+2+2) | 99% |
| Class 55: | 5 Axle Articulated Truck (1+1+3) | 99% |
| Class 56: | 6 Axle Articulated Truck | 99% |
| Class 61: | Buses and Coaches | 98% |
| Class 7: | 7 or More Axle Vehicle | 99% |
| Class CY: | Bicycles (separate sensors required) | 95% |

3. HI-TRAC® Data Storage Capacity

3.1. Vehicle-by-Vehicle Data Storage

Vehicle-by-Vehicle (VBV) data refers to data stored in the HI-TRAC® EMU3 onboard flash memory for each individual vehicle that is detected by the system. The system stores data on every vehicle detected by the system; the number of days the unit can store the data is configurable from 4 days to a maximum of 128 days with a capacity to store 250,000 vehicle records per day.

Parameters stored on a vehicle-by-vehicle basis include:


- Date
- Time
- Serial Number (unique ID number)
- Number of Axles
- Vehicle Classification Index
- Vehicle Category
- Lane Number
- Direction
- Vehicle Straddling
- Validity Code
- Road Surface Temperature
- Individual Axle Weights (ESA) – WIM Version Only
- Gross Vehicle Weight – WIM Version Only
- Gap - Inter-Vehicle Spacing in cms
- Axle Spacing in cms
- Headway - Time between subsequent vehicles in same lane in msec
- Vehicle Length
- Legal Status (violations such as over-weight, over-height, over-length)

3.2. Statistical Data Files

The HI-TRAC® EMU3 stores in onboard flash memory statistical data files for the previous 150 days of HI-TRAC® operation. These data files include the following information:

- ❑ Average Speed per Vehicle Category per Lane per Day
- ❑ Traffic Volume per Vehicle Category per Lane per Day
- ❑ Traffic Volume per Hour per Lane per Day
- ❑ Axle Volume per Weight Band per Lane per Day
- ❑ Average Gross Weight per Category per Lane per Day (WIM only)

The categories recorded in the Statistical Data files are defined in the Category List stored inside the HI-TRAC® EMU3 onboard flash memory. The Category list can be viewed and/or modified in the HI-COMM 100 software.



Up to 20 categories can be defined. These category names correspond to those defined in the 'Category' text box of the classification table described in the previous section.

3.2.1. ATMS Data Files


ATMS (Advanced Traffic Management System) data files store vehicle data and fault monitoring information over a configurable time period from 1 minute to 12 hours. The data stored in each ATMS file includes:

- Start Date of ATMS interval
- Start Time of ATMS interval
- Period of ATMS interval
- Diagnostic Code for ATMS interval
- Occupancy per Lane for ATMS Interval
- Average Speed per Category per Lane for ATMS Interval
- Traffic Volume per Category per Lane for ATMS interval

The HI-TRAC® EMU3 stores 50 ATMS files for the previous 50 ATMS intervals. The oldest data file is overwritten at the start of a new ATMS interval.

A diagnostic code is stored with each ATMS file. This gives an indication of any system errors that may have occurred during the ATMS interval. To view the definition of diagnostic code, from within the HI-COMM 100 software package, click on the ATMS record of interest and press CTRL and F1 simultaneously. A window appears with definitions of the code.

The diagnostic code is 4 bytes in size. Each bit within the diagnostic code has a definition:



3.2.2. Malfunction Management Data Files

Malfunction management data files are stored on the HI-TRAC® for the previous 8 days (the 8th data file being overwritten at the start of a new day).

The malfunction data file contains information on mains power failures, communication errors, sensor failures and loop failures.

When HI-COMM 100 connects to a HI-TRAC® system it downloads this file. If a new error condition is detected in the malfunction management file a fault log database (Fault.mdb) on the PC located in the application directory is updated with the fault condition. The 'View Malfunction Management' icon illuminates to indicate a new fault has been detected.

4. Installing & Connecting HI-TRAC® EMU3 to HI-COMM 100

4.1. Front Panel Display

The HI-TRAC® EMU3 displays each vehicle that is detected on the front panel LCD dialogue box. An example of the information displayed is as follows:



```

Cat 61:4, L1
35KPH, Axles 2
Time 10:20:02
T4, ID4
  
```

This is the normal weighing/recording display mode of the HI-TRAC® EMU3 electronic unit.

The displayed data is defined as follows: -

| | |
|----------------------|---|
| Cat 61:4 | The vehicle detected was classified as having a class index number of 4 and a class name 61 (this is the UK DfT vehicle category or classification of a bus). |
| L1 | The lane number in which the vehicle was detected. |
| 35KPH | The speed the vehicle was travelling at in kilometres per hour (KPH). |
| Axles 2 | The total number of axles detected on the vehicle. |
| Time 10:20:02 | The time the vehicle was detected. |
| T4 | The total traffic count for the day. |
| ID4 | The unique identifying code (serial number) assigned by HI-TRAC® EMU3 to the vehicle record stored in the system onboard flash memory. |

NOTE: The Classification Index Number is a unique identifying number for a type of vehicle defined by the number of axles on the vehicle, the spacing between axles on the vehicle and the overhang of the vehicle. A Category or Vehicle Classification or Class Name is an identifier for a group of unique vehicle types that fall under the same identity (e.g. A “BUS” is a category which may include several unique sub-classes defining a 2-axle bus, a 3-axle bus and a mini-bus. These sub-classes are identified by their respective class index numbers assigned by HI-TRAC).

4.2. Connecting HI-TRAC® EMU3 to HI-COMM 100 for the first time


NOTE: Minimum Requirement for HI-COMM 100: Windows XP / VISTA / 7



NOTE: To run the printed report output the PC must have Microsoft Excel installed. It is recommended that Microsoft Access is also installed as many of the files generated and utilised by the package are in Microsoft Access .MDB format.

4.3. Installing the USB Driver Software


The installation CD will have both the HI-COMM 100 files and the USB driver files. The first step is to install the USB Driver files and identify the COM Port which is assigned.

1. Locate the zipped USB Driver file and unzip the file to a chosen location on the PC.
2. Locate the folder **CP210xSetupFiles** and open this folder.
3. Locate the executable file **Preinstaller.exe** and run this file.






Open Windows **Device Manager** and select Ports (COM & LPT).





Note the COM Port designated to the USB UART Bridge; in the example below it states COM7. This is the COM Port your HI-TRAC will use to connect to your PC running HI-COMM 100 software. Make a note of the designated COM Port.



If you need to change the designated COM Port the right click on **Silicon Labs CP210x USB to UART Bridge (COMx)** and open **Properties**. Note the example below states COM7 but your PC may indicate a different port.

Click on the **Advanced** button to open the Advanced Settings window. You may choose a different COM Port if required from here but make a note of it to enter in the HI-COMM 100 software site set-up.





USB Driver set-up is now complete; exit Device Manager.


4.4. Installing HI-COMM 100 Windows Software

To install HI-COMM 100 Windows software:

1. Run "Setup.exe" on HI-COMM Installation CD.
2. It may be necessary to re-boot if SETUP updates installation files on the PC – then re-install again (just follow the prompts).
3. If during installation you get a message that the file being copied already exists and is older/newer than the one installed choose the newer file.
4. Run HI-COMM 100 from WINDOWS start menu.
5. At the Log-In prompt enter your name or the organisations name. By default on the drop down options TDC Systems Ltd is listed.





6. To set up a new HI-TRAC site select **Site List** from the tool bar; this opens the **Append HI-TRAC Site List** from which you can create a new site for your HI-TRAC installation.




7. Click on the **Insert** button. This inserts a new site into the site list appending default values into each of the fields. Modify these parameters as follows:
- Enter the Site Number (you can create your own list of site numbers).
 - Enter the Site Name
 - Enter the Site ID Code; this is the serial number on the rear of the HI-TRAC electronic unit.
 - Enter the Baud Rate for communications
 - Enter the telephone number of the modem (if installed)
 - Enter the communications serial port for the modem. In the case of a USB connection this should be set to the COM port indicated in Device Manager (COM 7 in the example above).
 - Enter the modem type (GSM; Land Line, Lease Line or Radio modem)
 - File location is automatically set; we don't recommend this is changed
 - Click **Update** to append data to the site list. Clicking the Update command button inserts a record into the SITELIST.MDB database. All data retrieved from this site will be stored in the *File Location* directory; this is a unique directory for each site.
8. Clicking the **Update** button will also create the site directory or folder in the location specified. Default C:/Program Files/HI-COMM. Click on the **Exit** button to exit the Append HI-TRAC Site List window.

4.5. Setting Com Ports Correctly and Connecting to the HI-TRAC


1. Select **Set-Up** from the tool bar to open the HI-COMM Communication Parameters window.



2. Select the Comms Port tab.



3. Select the Laptop Operation option and set the Laptop Serial Port to the serial port indicated in Device Manager and set in the Append Site List site set-up details (e.g., COM 7).
4. Click on the OK command button to exit.
5. If a USB connection is used from laptop to the HI-TRAC unit you can either set the Laptop Serial Port setting to the COM port as shown above or you can select Use Site Specific Com Port.



6. If selecting Site Specific Com Port ensure that the communications port setting in the site details is the same as the port shown in Device manager when connected via a USB cable.
7. Connect the Laptop cable between the HI-TRAC® EMU3 front panel USB connector and a PC USB port.


4.6. Switching On the HI-TRAC EMU3

4.6.1. Front Panel Display


The HI-TRAC EMU3 LCD will display the initialisation sequence:



```
Power Switch On
Booting...
Init Config *
```




```
Init memory *
Init data files *
Init class table *
Init slave *
```



```
TDC SYSTEMS LTD
HI-TRAC EMU2
Event Monitoring
Traffic Counter
```


The LED's will flash 3 times at the end of the boot up sequence and the display will show:



```
Entering Normal
Detection Mode
```

4.7. Switching On the HI-TRAC EMU3 for the First Time


If this is the first time the unit is switched on then the system time and date needs to be set. Press and hold down the ENTER/MENU button on the HI-TRAC® EMU3 keypad. A menu of set-up options appears on the LCD.



```
HI-TRAC EMU:  
1 HI-TRAC Time  
2 HI-TRAC Date  
3 Laptop Port
```

4.7.1. Setting HI-TRAC Time (Option 1)

Press the '1' key to set the system time.



```
Time Now: 12:30:09  
1. Set Hour: 12  
2. Set Minute: 30  
3. Set Seconds: 09
```

Time settings are made as follows:

To set the hour press '1' and enter the correct hour (0 - 23). Press ENTER.


To set the minute press '2' and enter the correct minute (0 - 59). Press ENTER.

To set the second press '3' and enter the correct second (0 - 59). Press ENTER.

When all the three settings are correct press ENTER to set the system time. The "Time Now" field will be updated.

4.7.2. Setting HI-TRAC Date (Option 2)

Press the '2' key to set the system date.



```
Date: 14/04/2011  
1. Set Year: 2011  
2. Set Month: 04  
3. Set Date: 14
```

To set the year press '1' and enter the correct year (yyyy). Press ENTER.

To set the month press '2' and enter the correct month (1 - 12). Press ENTER.

To set the date press '3' and enter the correct date (1 - 31). Press ENTER.

4.7.3. Connecting via USB

Press the '3' key to select the "Laptop Port" menu option.

Press '1' to select USB Port as the Comms port. Note the "x" to indicate USB Port is selected.



```
Select Laptop Port:
1  USB Port      x
2  Serial Port
3  COM3
```

Press EXIT button, on the keypad, twice to return to normal operating mode – with the *'Entering Normal Detection Mode'* message on the LCD. Only in this mode can the HI-TRAC® EMU3 communicate through the selected Comms port.

In HI-COMM select "Connect to HI-TRAC Site" menu option or click on the **Connect** icon. HI-TRAC® and HI-COMM can now communicate.

5. HI-TRAC® EMU3 Menu Options


The HI-TRAC® EMU3 front panel incorporates a 16-key membrane keypad, which is used in conjunction with the LCD to locally set system parameters. Menu options 1-9 can be selected directly by pressing the corresponding key number; the additional options are selected via the up and down arrows on the keypad.

| | |
|-----------|--|
| Option 1 | HI-TRAC Time Sets the local time. |
| Option 2 | HI-TRAC Date Sets the local date. |
| Option 3 | Laptop Port Selects the communications port for laptop communications. |
| Option 4 | COMMS Setup Sets the Access Code; switched Modem Window On/Off, Enables COM3 and set the Baud Rate. |
| Option 5 | Lane Config Sets system type (Volumetric / Classification / Weigh-in-Motion) and enables or disables the lane. |
| Option 6 | Lane Direction Sets the traffic direction: North/South/East/West. |
| Option 7 | Lane Settings Sets loop length; loop factor and piezo sensor spacing. |
| Option 8 | Loop Settings Sets loop presence time; sensitivity, loop detection and dropout parameters. |
| Option 9 | Classification Enters/edits existing classification detail for each class including a unique identification number, number of axles, inter-axle spacing and overhang. |
| Option 10 | Battery / Temperature The HI-TRAC® EMU3 monitors the battery voltage and view road temperature. |
| Option 11 | Modem options Provides modem status information and switches modem debug On/Off. |
| Option 12 | Country Sets UK; Metric or Imperial units. |
| Option 13 | Test Sign Performs a message sign board test; sets activation parameters and enables or disables the sign. |

6. Configuring the HI-TRAC® EMU3 via Keypad and Display

6.1. Setting HI-TRAC Time (Option 1)

Select HI-TRAC Time from the main menu. The LCD displays the following:



| | |
|-----------------|----------|
| Time Now: | 12:30:09 |
| 1. Set Hour: | 12 |
| 2. Set Minute: | 30 |
| 3. Set Seconds: | 09 |

Time settings are made as follows:

To set the hour press '1' and enter the correct hour (0 - 23). Press ENTER.


To set the minute press '2' and enter the correct minute (0 - 59). Press ENTER.

To set the second press '3' and enter the correct second (0 - 59). Press ENTER.

When all the three settings are correct press ENTER to set the system time. The "Time Now" field will be updated.

6.2. Setting HI-TRAC Date (Option 2)

Select HI-TRAC Date from main menu. The LCD displays the following:



| | |
|---------------|------------|
| Date: | 14/04/2011 |
| 1. Set Year: | 2011 |
| 2. Set Month: | 04 |
| 3. Set Date: | 14 |

To set the year press '1' and enter the correct year (yyyy). Press ENTER.

To set the month press '2' and enter the correct month (1 - 12). Press ENTER.

To set the date press '3' and enter the correct date (1 - 31). Press ENTER.

6.3. Setting Laptop Port (Option 3)

To select HI-TRAC communications port through via which connection is made to TDC Systems HI-COMM 100 software package, select option 3. The LCD will display:



```
Select Laptop Port:
1  USB Port      x
2  Serial Port
3  COM3
```

6.4. Select USB or Serial Port

Press the corresponding number to select which communications port connection is appropriate, e.g. press '2' to select serial port, an 'x' will depict the current selection.

Press EXIT to return to the main menu.

6.5. COM3 Enabled


Press 3 to Enable or Disable communications port COM3.

Press 3 to enable or disable COM3 port; the LCD will display either YES or NO against this option.

Press EXIT to return to the communications set-up window

6.6. Comms Set-Up (Option 4)

Select 'Comms Set-Up' from the main menu. There are 4 sub-menu options; the LCD displays the following



```
1.  Set Access Code
2.  Set Baud Rate
3.  Modem Windows  OFF
```

6.6.1. Access Code

Press 1 to set HI-TRAC® EMU3 Access Code.

```
Input access code
For HI-COMM 100
Connection :
TDCS
```

The access code is a unique alphanumeric code that is sent by the HI-COMM 100 software package to the HI-TRAC® EMU3 system upon connection (either remotely via modem, or locally via the laptop connection). If the access code matches then the HI-COMM operator is allowed access to the HI-TRAC EMU3 system. If the code does not match then the HI-TRAC EMU3 connection fails and HI-COMM 100 software package terminates the connection.

Warning: The access code can be used to limit access to the system. If the access code is changed, by keying in a new code on the HI-TRAC keypad, only HI-COMM 100 operators with the new access code can connect to the HI-TRAC system and retrieve data.

When the connection is established and the correct access code is passed to the HI-TRAC EMU3 via the HI-COMM 100 software package a further transfer occurs which determines the access level (or clearance level) of the operator. Two different statuses are available including 'OPERATOR' and 'ENGINEER'. An Operator can only collect data and perform certain functions whereas an Engineer can access and change all functions and settings on the HI-TRAC EMU3 system.

6.6.2. Set Baud Rate

Press 4 to set the communication speed for the Auxiliary or Bluetooth port and the Modem or COM3 port.

```
1. Aux/Blue:      115200
2. Modem/COM3    19200
```

Press either "1" or "2" and the baud rate setting will rotate through four pre-set settings: 9600, 19200, 57600 and 115200 bits per second.

Press EXIT to return to the communications set-up window

6.6.3. Modem Windows Off

Press 4 to select HI-TRAC® EMU3 Modem Windows Off/On function.


Modem windows ON/OFF is a power saving function; if the modem is always powered 'on' battery life will be reduced. The modem windows function provides a means of selecting the times when the modem is powered on thus allowing remote data download.

The on/off function allows an engineer on site to temporarily disable the time function and test the modem communications.

6.7. Lane Config (Option 5)

6.7.1. HI-TRAC Lane Configuration

To set the system type select Option 5 from the main menu. The LCD will display the following:



```
Select System Type:
1. Volumetric
2. Classification    x
3. Weigh-in-Motion
```

The HI-TRAC EMU3 can be set up as a Volumetric Vehicle Counter; an Automatic vehicle Counter/Classifier or a Weigh-in-Motion system; select 1-3 for the type of system supplied the LCD will then display a screen similar to the one below:



```
1. Lane 1: (L-P-L)
2. Lane 2: (P-L-P)
3. Lane 3: (OFF)
4. Lane 4: (OFF)
```

NOTE: Eight lane settings are available for Volumetric Counting however for Classification and WIM only four lanes can be configured.

Dependent upon the system type selected the sensor configuration can be configured to:

VOLUMETRIC SETTINGS:

- i) Turn off the lane function (OFF)
- ii) Volumetric single loop (LOOP)
- iii) Volumetric N+1 (LOOP+1)

CLASSIFICATION SETTINGS:

- iv) Turn off the lane function (OFF)
- v) Loop – Piezo – Loop (L-P-L)
- vi) Piezo – Loop – Piezo (P-L-P)
- vii) Loop – Loop (L-L)
- viii) Bicycle Detection (CYCLE)
- ix) Bicycle Detection (C-LOOP)

WEIGH-IN-MOTION SETTINGS:

- i) Turn off the lane function (OFF)
- ii) Loop – Piezo – Loop (L-P-L)
- iii) Piezo – Loop – Piezo (P-L-P)
- iv) Bicycle Detection (CYCLE)

To change the sensor configuration press the lane number repeatedly until the correct configuration is displayed.

Press EXIT to return to the main menu set-up window.

6.8. Lane Direction (Option 6)

Setting HI-TRAC Lane Direction for Lanes 1 - 4

Select this option to set up the traffic flow direction for lanes 1 to 4, the LCD will display:

| | | |
|----|---------|-------|
| 1. | Lane 1: | NORTH |
| 2. | Lane 2: | SOUTH |
| 3. | Lane 3: | EAST |
| 4. | Lane 4: | WEST |

To change the direction press the lane number repeatedly until the correct direction for that lane is displayed.

Press EXIT to return to the main menu set-up window.

NOTE: The lane direction parameter is used by the HI-TRAC® EMU3 system to determine how adjacent lanes are monitored for straddling vehicle detection. In the above example lane 1 is marked northbound and lane 2 is marked southbound. In normal operation the HI-TRAC system compares vehicles detected on adjacent lanes simultaneously (within a 5 millisecond window) to determine if the vehicle is the same and is in fact straddling between the two lanes (this is known as the **ANTI-COINCIDENT FUNCTION** of the HI-TRAC® system).

6.9. Lane Settings (Option 7)

To set the sensor configuration of each lane of installation select Option 7 from the main menu. The LCD will display the following:


| | |
|----|----------------|
| 1. | Loop Length |
| 2. | Loop Factor |
| 3. | Sensor Spacing |

6.9.1. Set Loop Length

Select Loop Length from the menu. The LCD will display the following:

| |
|------------------------------------|
| Input a loop number from 1 to 8 |
| 2 |

Enter required loop number. Press Enter key to confirm or Exit key to cancel. (Note: The number of loops will depend upon the system type selected and sensor configuration.)




Input the length of
loop 2 loop in cms:

200

The Loop Length parameter is the length of the loop, which runs parallel to the traffic flow. The HI-TRAC® EMU3 uses this parameter in the calculation of vehicle length.

6.9.2. Set Loop Factor

Select Loop Factor from the menu. The LCD will display the following:




Input a lane number
from 1 to 4:

2

Enter lane number to set the loop factor. Press Enter key to confirm or Exit key to Esc. (Note: The number of lanes shown will depend upon the system type selected.)

Enter the loop correction factor (default value 100) and press Enter key to confirm or Exit key to cancel.




Input the correction
factor for lane 2:

100

The loop factor is used by HI-TRAC® EMU3 to optimise length measurement accuracy. The loop detector has different sensitivity settings, which generate different size zones of vehicle chassis detection. Use the loop factor to optimise length measurement accuracy after changes in loop detector sensitivity setting.

6.9.3. Set Sensor Spacing


Select '3. Sensor Spacing' from the menu. The LCD will display the following:



Input a lane number
from 1 to 2:

1

Enter lane number. Press Enter key to confirm or Exit key to cancel. (Note: The number of lanes will depend upon the system type selected.)



Input sensor spacing
for Lane 1, in mms:


3000

Enter the sensor spacing and press Enter key to confirm or Exit key to Esc

HI-TRAC® EMU3 uses the sensor (piezo or loop) spacing parameter in the calculation of vehicle speed (the distance between sensors divided by the time taken for the same vehicle to be detected on both sensors is directly proportional to vehicle speed).

6.10. Loop Settings (Option 8)

To set the Loop Settings configuration of each individual loop input select Option 8 from the main menu. The LCD will display the following:




1. Presence Time
2. Sensitivity
3. Loop Detect
4. Loop Dropout

6.10.1. Set Presence Time

The presence time is a timing option used to terminate excessively long loop activation. If the loop activation (detect) is active for period of one millisecond greater than the predetermined presence time, the loop activation will terminate. This termination will be deemed the End vehicle & the loop will retune

The default value is 1200 milliseconds. Minimum presence time is 100 milliseconds the maximum allowable is 9999 milliseconds


Select '1. Presence Time' from the menu, LCD will display the following:



Input a loop number
from 1 to 8

1

Enter required lane number. Press Enter key to confirm or Exit key to Esc



Input the Presence
time for loop 1:


1200

Enter required Presence Time for selected loop

Press Enter key to confirm or Exit key to Cancel.

6.10.2. Set Loop Sensitivity


Select '2. Sensitivity ' from the menu. The LCD will display the following:



Input a loop number
From 1 to 8:

2

Enter required lane number. Press Enter key to confirm or Exit key to Cancel.



Input sensitivity
Setting for loop 2:

5


Enter required loop sensitivity threshold setting.

Press Enter key to confirm or Exit key to Cancel.

Note: The higher the value the less sensitivity the loop.

6.10.3. Set Loop Detect

Select '3. Loop Detect' from the menu. The LCD will display the following:




Input loop trigger
constant:

4

Enter Loop Trigger constant setting. Press Enter key to confirm or Exit key to Cancel.

6.10.4. Set Drop-out

Select '4. Loop Dropout' from the menu. The LCD will display the following:




Enter Drop - Out Constant setting. Press Enter key to confirm or Exit key to cancel

6.11. Using HI-COMM Software to set Loop Settings

The HI-COMM 100 software can be used to set the above parameters. Additional adjustment and optimisation of the HI-TRAC® EMU3 is also provided by HI-COMM as shown below.

Click on the **Loop Settings** tab:



6.11.1. Loop Sensitivity and Trigger

The **Loop Sensitivity** determines the loop oscillator frequency change required for the HI-TRAC® to determine loop activation.

As the metal chassis of the vehicle enters the **detection zone** of the inductive loop it causes a change in the effective inductance of the loop. The loop forms part of a loop oscillator electronic circuit. This circuit oscillates at a frequency that is proportional to the effective inductance.

The HI-TRAC® monitors the loop oscillator frequency to determine vehicle presence.

If the frequency changes by more than the Loop Sensitivity for a number of consecutive samples (this number is determined by the **Trigger** setting) then the HI-TRAC® determines that the loop is activated.

In the above example screen the HI-TRAC® will determine vehicle presence if the loop oscillator frequency varies by 4 for 2 consecutive samples.

Variations are measured from the NO DETECT frequency value. This is continually tracked by the HI-TRAC® to eliminate any frequency drift over time.

6.11.2. LCF Loop Compensation Factor

The LCF is a factor that is used to normalise frequency change. It eliminates variations in loops and installations.

The frequency change value is used by the HI-TRAC® to determine vehicle class.

If a loop has 3 turns or 4 turns or if a loop is 2Metres square or 1.5Metres square the value of frequency change for the same vehicle will be different.

The LCF is used to reduce the effect of variations in installation.

To determine the LCF for each lane select a common vehicle and view the Chassis Code displayed in the real time view screen. Record several passes. The LCF is a direct multiplying factor on the Chassis Code. Modify the factor to make the Chassis Code for the selected vehicle be the same for all lanes.

If a certain type of passenger car is used determine the optimum level of Chassis Code for that vehicle – perhaps 100. If on lane 3 this vehicle is only giving a chassis code of on average 80 then increase the LCF from 1000 to 1200 to increase the chassis code by 20%.

The relevance of this factor is purely in the accuracy of vehicle classification. If many sites are installed and the same class table is required to be used on each then every system must be set up the same.

6.11.3. Drop Out

The loop drop out factor is used to determine the end of the loop activation as the vehicle leaves the detection zone of the loop.

A drop out of 3 in the screen above indicates that the loop oscillator must return to the no detect frequency value for a period of 3 consecutive samples before the HI-TRAC® determines that the loop has deactivated.

This factor can be increased for example when a large number of long trucks are *broken up* into two because of a high chassis in the mid-portion of the vehicle.

6.11.4. LLCF

The value of the LLCF factor is used for length adjustment on short vehicles (between 2.5M and 6M). Because of the low chassis on most passenger cars the length measurement on these vehicles tends to come out approximately 10% too long.

If the chassis code (this is the peak frequency change and can be viewed in the real time view mode described previously) on a vehicle is greater than the LLCF and the recorded length of the vehicle is between 2.5M and 6M the HI-TRAC® will reduce the length automatically to take into account the aforementioned effect.

6.12. Classification Table (Option 9)

6.12.1. Editing HI-TRAC Vehicle Classification Table

To enter or edit a vehicle classification select option 12. The LCD will display the following:

```

Input index of class
to be edited (0-109)
then press ENTER:
    0
  
```

To create or edit an existing vehicle class follow the prompts on the LCD.

```

Class Index 0
Number of Axles: 2
  
```

```

Class Index 0
Number of Axles: 2
Class Name: 2
  
```

Class Index 0
Number of Axles: 2
Class Name: 2
Overhang: 0

Input Length Limit
(in cms):

0

Input axle spacing
(in cms):
Min Ax1/Ax2: 2000
Max Ax1/Ax2: 3500

Input gross weight
Limit (in Kgs):

16000

Select axle 1 type:
1. SINGLE AXLE x
2. TANDEM AXLE
3. TRIPLE AXLE

Input group 1 weight
Limit (in Kgs):

6500


Input group 2 weight
Limit (in Kgs):

11000


To delete a vehicle class; select the class to be deleted and enter “0” in the Number of Axles field:



Class Index 0
Number of Axles: 0



Setting the number
Of axles to 0 will
Delete the class and
Erase all VBV memory




Class Index 0 is
deleted. All VBV
data in memory has
been erased!

6.13. Using HI-COMM 100 Software to set Classification Parameters

The HI-COMM 100 Software is more suitable for modification of vehicle classification parameters.

Select the 'Classification' icon from the HI-COMM 100 main toolbar.



The Class Name identifies the vehicle class.

To utilise the HI-TRAC® **Advanced Vehicle Loop Signature Identification Algorithm** click the Utilise Loop Profiling check box.

Use the waveform viewing function of the HI-COMM 100 software to determine the Loop Signature Parameters for the particular class. The signature will show the frequency change profile of the HI-TRAC® loop detection oscillator as the metal chassis of the vehicle passes over the sensor array.

The **Vehicle Chassis Code** is a number that identifies the **maximum value of frequency change** detected by the HI-TRAC® during the passage of the vehicle. The chassis code can be displayed in real-time view mode described above. For each class of vehicle specify the **Min Freq Change** as the lowest value of chassis code expected for the type of vehicle. In the above example the bus will always have a chassis code greater than 70.

For classification purposes the vehicle is divided into front, middle and back.

The maximum value of frequency change of the **front of the vehicle** is compared with the **Lower Threshold** (50) and the **Upper Threshold** (250).


The maximum value of frequency change of the **middle of the vehicle** is compared with the **Upper Threshold** (250).

NOTE: As the middle Lower Threshold is set to zero it is not used in the class detection algorithm.

The maximum value of frequency change of the **back of the vehicle** is compared with the **Lower Threshold** (40) and the **Upper Threshold** (250).

The length of the detected vehicle is compared with the **Minimum Length** (500) and **Maximum Length** (1200) below.

NOTE: For the classification to be made the vehicle detected must comply with all of the defined classification parameters.



The screenshot shows a software interface with five tabs: 'Axle Wt.', 'Axle Space', 'Lane Filter', 'Length', and 'Limits'. The 'Length' tab is currently selected and highlighted. Below the tabs, there is a central panel with two input fields. The first field is labeled 'Minimum Length' and contains the value '500' followed by 'CMS'. The second field is labeled 'Maximum Length' and contains the value '1200' followed by 'CMS'.


NOTE: The classification algorithm includes 2 passes through the classification table to determine a match. **The first correct match is determined to be the vehicle class.** The first pass through the class table compares only the classifications that have the **Utilise Loop Profiling** checkbox checked. The second pass through the class table only compares the classifications that have the Utilise Loop Profiling checkbox unchecked.

In the above example for the detected vehicle to be classified under class index 86 as a Euro 6 Class 6 vehicle (i.e. a bus) the following conditions must be met:

| | | | | |
|---------|----|--------------|----|----------|
| 500 cms | <= | LENGTH | <= | 1200 cms |
| 70 | <= | CHASSIS CODE | | |
| 50 | <= | FRONT HF | <= | 250 |
| | | MIDDLE HF | <= | 250 |
| 40 | <= | BACK HF | <= | 250 |

The MIDDLE LF value of the detected vehicle is used **to detect vehicles pulling trailer units or caravans** whereby the frequency change in the middle part of the vehicle drops below the specified threshold. If a trailer unit is not part of the class defined set the middle Lower Threshold to zero as in the example above.

In the example below Euro 6 Class 3 is defined as a car or van pulling a trailer or caravan:



For a vehicle to be classified as a class 3 the frequency profile must comply with the following:

| | | | | |
|----|----|------------------|--------------|-----------|
| 50 | <= | CHASSIS CODE | | |
| 35 | <= | FRONT HF | <= | 160 |
| | | MIDDLE HF | <= | 160 |
| | | MIDDLE LF | <= | 25 |
| 10 | <= | BACK HF | <= | 160 |

NOTE: Loop drop out (due to of the gap between vehicle and trailer unit) is detected by the MINIMUM VALUE OF FREQUENCY CHANGE (defined by MIDDLE LF). The minimum frequency change in the middle part of the vehicle has to drop below the defined Lower Threshold of 25 to be identified as a class 3.


NOTE: The amount of frequency change is determined not only by the volume of metal on the chassis of the vehicle and the height of the chassis off the ground but also by other installation parameters such as number of turns of loop cable, depth of loop installation, size of loop. The system must be normalised at commissioning by eliminating differences in installation parameters. Use the LCF defined later in section 16 to eliminate any site dependent factors that affect the loop profile measurement.

To print the classification table click on the printer icon, on the toolbar.

The classification table can be uploaded from the HI-TRAC and stored on the PC in the form of a Microsoft Access Database File. Click on the 'Upload to Disk' icon.

The classification table can be downloaded from the PC Microsoft Access Database file to the HI-TRAC. Click on the 'Download to HI-TRAC' icon. This feature is useful for updating all HI-TRAC sites with new classification information. The latest vehicle classification data can also be uploaded automatically using the automatic data download facility.

Click on the picture to assign the correct picture definition for the vehicle classification.



6.14. Battery/Temperature (Option 10)

Select this option to view the current battery voltage and to view and calibrate the temperature reading.

NOTE: The temperature setting is factory calibrated prior to despatch and should not require further adjustment.

```
Battery      6.32V
Temperature  18.5C

Press EXIT
```

Press EXIT to return to the main menu.

6.15. Modem Options (Option 11)

Select this option to display modem information and set modem debug state..

```
1. Modem info
2. Modem debug    NO
3. Send SMS
```

Select option 1 to display the current state of the modem; signal strength and connected network.


```
State:  OFF
Sig:   No signal
Net:
```

Select option 2 to switch the modem debug On/Off.

```
1. Modem info
2. Modem debug    YES
```


6.16. Country (Option 12)

Select this option to set the HI-TRAC® EMU3 to record vehicle parameters; length, weight, speed, etc, to either metric or imperial units.




6.17. Test Sign (Option 13) – Sign Option

If a driver information sign is connected to the HI-TRAC EMU3 you can select this option to test the sign; set speed limits (for sign activation) and activate or deactivate the sign.



6.17.1. Test Output 1 and Output 2

Selecting '1' or '2' will test sign activation; the LCD will display the following whilst the sign is being tested:




6.17.2. Setting Speed Limits

Selecting '3' will set a speed limit to be set which if exceeded the sign will activate.

6.17.3. Activating or Deactivating the Sign

Selecting '4' will switch the sign to Activate YES or Activate NO.



6.18. Cycle Set Up (Option 13) – Cycle Option

If a driver information sign is connected to the HI-TRAC EMU3 you can select this option to test the sign; set speed limits (for sign activation) and activate or deactivate the sign.

1. Min Samples
2. Max Samples
3. Max Axle Weight
4. Max Signal Area

6.18.1. Set Minimum Samples

Set the minimum sample number to detect a bicycle.

```
Input min samples
for cycle axle
then press ENTER
      6
```

6.18.2. Set Maximum Samples

Set the maximum sample number to detect a bicycle.

```
Input max samples
for cycle axle
then press ENTER
      40
```


6.18.3. Set Maximum Axle Weight

Set the maximum axle weight of a bicycle.

```
Input maximum cycle
rear axle wt in kgs
then press ENTER
      300
```


6.18.4. Set Maximum Signal Area

Set the maximum signal area to detect the bicycle.



Input maximum cycle
signal area
then press ENTER
2500

7. Menu Map



7 - LANE SETTINGS

- 1 Loop Length
- 2 Loop factor
- 3 Sensor Spacing

1. Loop Length

Input a loop number from 1 to 8 :
1

Input the length of loop 1 loop in cms :
200

2. Loop Factor

Input a lane number from 1 to 4 :
1

Input the correction factor for lane 1 :
100

3. Sensor Spacing

Input a lane number from 1 to 4 :
1

Input sensor spacing for lane 1, in mms :
3000

8 - LOOP SETTINGS

- 1 Presence Time
- 2 Sensitivity
- 3 Loop Detect
- 4 Loop Dropout

1. Presence Time

Input a loop number from 1 to 8 :
1

Input the Presence time for loop 1 :
1200

2. Set Loop Sensitivity

Input a loop number from 1 to 8 :
1

Input sensitivity settings for loop 1
5

3. Set Loop Detect


Input loop trigger constant:
4

4 Set Drop-out


Input loop drop-out constant:
4

HI-TRAC EMU2 - MENU 2

Menu 3 – Sign Option



Menu 3 – Cycle Option




HI-TRAC EMU2 - MENU 3

8. Additional Settings and Configuration for the HI-TRAC® EMU3

8.1. Piezo Sensor Interface PCB Settings

The TDC Systems HI-COMM 100 software package provides sensor waveform viewing, storage and printing features. Sensor waveform analysis can be performed locally via a laptop (cable) connection or remotely via an installed modem.



When connecting the HI-TRAC® EMU3 to sensors for the first time, perform a sensor test for approximately 100 vehicles and view the results. If the sensor counts are to within +/- 10 % and the loop and vehicle counts tally, the sensors signals are probably good. (Beware of straddling vehicles, they have the effect of increasing the loop count above the vehicle count as they are only recorded as a vehicle in one lane but activate the loops in two lanes.)

If ghost axles have been removed and there is still a large error in sensor counts, greater than 10% difference, then view the sensor waveforms. One of the sensors will have a lower output. Match the outputs by increasing the gain of the sensor with the lower output. Do this by powering down the system and remove the Universal Sensor PCB. There is one sensor PCB mounted on the main HI-TRAC EMU3 PCB which can connect to 4 piezo sensors. Four gain settings per piezo sensor are available by setting the appropriate DIP switches on the Sensor PCB.

Individual sensor gain settings are made by two switches assigned to each sensor.

| | Lanes 1 & 2 Sensor P1 | | Lanes 1 & 2 Sensor P2 | |
|---------------------|-----------------------|-----|-----------------------|-----|
| | SW1 | SW2 | SW3 | SW4 |
| Gain 1 (Min) | ON | ON | ON | ON |
| Gain 2 | OFF | ON | OFF | ON |
| Gain 3 | ON | OFF | ON | OFF |
| Gain 4 (Max) | OFF | OFF | OFF | OFF |

Adjust the gains accordingly and perform the sensor test function again to see the improvement.

8.2. Loop Sensor Interface PCB Settings

Up to 4 loop sensor interface PCB's can be installed in the HI-TRAC EMU3 allowing for eight loop sensors to be connected. Two loops connect to each PCB and their respective oscillator frequency can be changed to ensure that cross-talk between lanes is minimised.

Loop oscillator frequency can be monitored:

- a. Loops 1, 2, 3 & 4 press and hold the '7' and 'Enter' keys
- b. Loops 5, 6, 7 & 8 press and hold the '8' and 'Enter' keys

There should be a difference of at least 10% between the two noted frequencies. If a change is required move the link on the loop sensor PCB. There are 3 possible settings:

- i) Link set left
- ii) Link set right
- iii) Link removed

8.3. Reset Security Code

Input the HI-TRAC
Security Code:

2050

Press Reset & 6 then power on.

8.4. Reset Memory to Default Settings

To reset the system memory press and hold the Exit and Delete keys when switching on. The HI-TRAC EMU3 LCD will display a number of messages as the system performs a memory test; resets vehicle classes and bins, updates the systems and re-initialises.

9. BLUETOOTH MAC ANTENNA UPGRADE

9.1. Bluetooth Antenna

The HI-TRAC EMU3 electronic unit with an upgrade to include Bluetooth® MAC Address antenna uses Bluetooth signals to derive Journey Time information as well as Traffic Movements (Origin and Destination).

The HI-TRAC EMU3 in this case reads the MAC address and a timestamp of Bluetooth devices that are passing the system. A server collects this information from multiple HI-TRAC units within a node and provides matching algorithms based on journey times/ routes/ time of day to provide the user with Journey time information as well as traffic movements within the node.

Bluetooth devices include mobile phones, PDA's, hand-free kits, GPS onboard units, laptops, etc.

It is expected that by 2013 two out of every three new cars will offer Bluetooth connectivity.

9.2. A Comparison of MAC data to Traffic Counter Flow Rates

A direct comparison of vehicle flow to MAC device flow is achieved by installing both a traffic counter/classifier and MAC address reader in a location with minimal pedestrian activity for an extended period of time. In this instance a HI-TRAC EMU with a MAC address reader upgrade has been installed in Matlock, Derbyshire, United Kingdom.

The graphs shown below in Figure 1 and Figure 2 represent the period from the 14th of February 2011 to the 20th of February 2011, and are typical of the results seen at MAC Address reader locations.

As can be seen by comparing the two graphs, the shape of MAC/Vehicle volume throughout the week is the same. The difference between the two graphs can be seen when comparing the maximum volume of vehicles at the 8am hour peak of approx 1000; to the maximum volume of MAC address detected at the 8am peak hour of approx 250.




Figure 1 - Derbyshire County MAC Weekly Volume




Figure 2 - Derbyshire County Vehicle Weekly Volume

10. HI-COMM 100 - Example Reports & Screen Displays


10.1. Examples of HI-COMM 100 Software Screen Displays

Typical software screen displays to help illustrate the functionality and comprehensive features of the HI-COMM 100 software package are portrayed on the following pages.


- HI-COMM 100 Opening Screen (Connected to HI-TRAC)
- Communications Parameters
- HI-TRAC® Configuration
- VBV Data Retrieval
- VBV Real Time Traffic Display
- VBV Real Time Display Configuration
- Diagnostic Functions – Sensor Test, Waveforms & Codes
- Axle Weight & Speed Band Limits
- Vehicle Classification Configuration & Weight Limits
- ESA Parameters
- VBV Memory Allocation & Data Conversion
- Statistical Report Sample:- Average Speed per Category
- Malfunction Management Report Sample
- ATMS Report Sample:- Traffic Volume by Category by Lane




HI-COMM 100 Software
(HI-TRAC® Connected)



Communications Parameters



HI-TRAC® Configuration
(VBV Data Storage Configuration)



VBV Data Retrieval

| Real Time View for M20 Smeeth E/B All Lanes, All Directions, All Categories | | | | | | | | | | | | |
|---|------------|----------|-------------|-------------|-------|--------|-----------|-----------|--------------|----------|-----------|--|
| Serial # | Date | Time | No of Axles | Class Index | Class | Lane # | Speed kph | Speed mph | Gross Weight | Axle Wt1 | Axle Wt 2 | |
| 8438950 | 08/01/2004 | 12:21:27 | 2 | 0 | 1 | 2 | 110.0 | 69.0 | 1,420 | 740 | 690 | |
| 8438951 | 08/01/2004 | 12:21:28 | 2 | 0 | 1 | 3 | 128.0 | 80.0 | 1,030 | 630 | 400 | |
| 8438952 | 08/01/2004 | 12:21:28 | 2 | 35 | 2 | 2 | 114.0 | 71.0 | 1,460 | 840 | 620 | |
| 8438953 | 08/01/2004 | 12:21:31 | 2 | 0 | 1 | 2 | 107.0 | 67.0 | 2,210 | 1,050 | 1,160 | |
| 8438954 | 08/01/2004 | 12:21:33 | 2 | 0 | 1 | 1 | 97.0 | 61.0 | 1,230 | 570 | 660 | |
| 8438955 | 08/01/2004 | 12:21:34 | 2 | 0 | 1 | 2 | 109.0 | 68.0 | 1,090 | 590 | 500 | |
| 8438956 | 08/01/2004 | 12:21:35 | 2 | 0 | 1 | 1 | 76.0 | 48.0 | 630 | 380 | 250 | |
| 8438957 | 08/01/2004 | 12:21:36 | 2 | 0 | 1 | 2 | 99.0 | 62.0 | 1,160 | 670 | 490 | |
| 8438958 | 08/01/2004 | 12:21:37 | 2 | 0 | 1 | 2 | 86.0 | 54.0 | 430 | 270 | 160 | |
| 8438959 | 08/01/2004 | 12:21:47 | 2 | 0 | 1 | 2 | 118.0 | 74.0 | 1,440 | 850 | 590 | |
| 8438960 | 08/01/2004 | 12:21:47 | 2 | 44 | 2 | 1 | 109.0 | 68.0 | 2,690 | 1,490 | 1,200 | |
| 8438961 | 08/01/2004 | 12:21:53 | 2 | 0 | 1 | 2 | 119.0 | 74.0 | 1,430 | 830 | 600 | |
| 8438962 | 08/01/2004 | 12:21:55 | 2 | 0 | 1 | 1 | 79.0 | 49.0 | 1,110 | 550 | 560 | |
| 8438963 | 08/01/2004 | 12:21:56 | 2 | 0 | 1 | 2 | 116.0 | 72.0 | 1,380 | 730 | 650 | |
| 8438964 | 08/01/2004 | 12:22:01 | 4 | 17 | 41 | 1 | 102.0 | 64.0 | 10,300 | 2,600 | 7,470 | |
| 8438965 | 08/01/2004 | 12:22:03 | 5 | 22 | 55 | 1 | 87.0 | 54.0 | 39,020 | 7,990 | 12,870 | |
| 8438966 | 08/01/2004 | 12:22:06 | 2 | 1 | 2 | 3 | 130.0 | 81.0 | 1,370 | 790 | 580 | |
| 8438967 | 08/01/2004 | 12:22:06 | 5 | 22 | 55 | 1 | 83.0 | 52.0 | 34,950 | 5,070 | 9,320 | |
| 8438968 | 08/01/2004 | 12:22:08 | 2 | 0 | 1 | 2 | 97.0 | 61.0 | 990 | 570 | 420 | |
| 8438969 | 08/01/2004 | 12:22:10 | 2 | 0 | 1 | 1 | 99.0 | 62.0 | 1,180 | 570 | 610 | |
| 8438970 | 08/01/2004 | 12:22:12 | 2 | 0 | 1 | 1 | 99.0 | 62.0 | 890 | 540 | 350 | |
| 8438971 | 08/01/2004 | 12:22:17 | 2 | 0 | 1 | 1 | 92.0 | 58.0 | 1,250 | 760 | 490 | |
| 8438972 | 08/01/2004 | 12:22:23 | 2 | 0 | 1 | 2 | 107.0 | 67.0 | 1,640 | 920 | 720 | |
| 8438973 | 08/01/2004 | 12:22:24 | 2 | 1 | 2 | 1 | 93.0 | 58.0 | 2,270 | 1,260 | 1,010 | |
| 8438974 | 08/01/2004 | 12:22:25 | 2 | 0 | 1 | 2 | 110.0 | 69.0 | 920 | 550 | 370 | |
| 8438975 | 08/01/2004 | 12:22:26 | 2 | 0 | 1 | 2 | 128.0 | 80.0 | 810 | 360 | 450 | |
| 8438976 | 08/01/2004 | 12:22:34 | 2 | 33 | 1 | 1 | 118.0 | 74.0 | 1,730 | 870 | 860 | |
| 8438977 | 08/01/2004 | 12:22:34 | 2 | 0 | 1 | 2 | 126.0 | 79.0 | 1,200 | 750 | 450 | |
| 8438978 | 08/01/2004 | 12:22:48 | 2 | 30 | 2 | 1 | 97.0 | 61.0 | 2,380 | 1,290 | 1,090 | |

VBV Real Time View

RTV Display Options
✕

Check Fields Required

- Date of Vehicle
- Time of Vehicle
- Number of Axles
- Class Index
- Vehicle Classification
- Lane Number
- Vehicle Speed (kph)
- Vehicle Speed (mph)
- Gross Vehicle Weight

Other Options

Other Options


Max Speed (Kph) Min Speed (Kph)

Max GVW (Kg) Min GVW (Kg)

No. of Axles

Legal Vehicles Only Only Vehicles with ZERO Validity
 Illegal Vehicles Only
 All Vehicles

VBV Real Time Display Options



Sensor Information


| Lane # | Sensor1 Count | Sensor2 Count | Loop Count | Vehicle Count |
|--------|---------------|---------------|------------|---------------|
| 1 | 960 | 962 | 324 | 319 |
| 2 | 592 | 602 | 284 | 278 |
| 3 | 122 | 123 | 63 | 63 |
| 4 | 0 | 0 | 0 | 0 |
| 5 | 0 | 0 | 0 | 0 |
| 6 | 0 | 0 | 0 | 0 |
| 7 | 0 | 0 | 0 | 0 |
| 8 | 0 | 0 | 0 | 0 |

Lane 1

Interval Test Period: Minutes

Elapsed Time:

Diagnostic Functions
Sensor Waveform & Sensor Test Functions



Diagnostic Functions
(Loop Signature – Car)

Weight Bands

| Weight Bands | Lower Limits (Kg) | Upper Limits (Kg) |
|--------------------|-------------------|-------------------|
| Weight Band # 1 : | 1000 | 1999 |
| Weight Band # 2 : | 2000 | 2999 |
| Weight Band # 3 : | 3000 | 3999 |
| Weight Band # 4 : | 4000 | 4999 |
| Weight Band # 5 : | 5000 | 5999 |
| Weight Band # 6 : | 6000 | 6999 |
| Weight Band # 7 : | 7000 | 7999 |
| Weight Band # 8 : | 8000 | 8999 |
| Weight Band # 9 : | 9000 | 9999 |
| Weight Band # 10 : | 10000 | 10999 |
| Weight Band # 11 : | 11000 | 11999 |
| Weight Band # 12 : | 12000 | 12999 |

Buttons: Cancel, OK

Axle Weight Band Limits

Speed Bands

| Speed Bands | Lower Limits | Upper Limits | Description | Visible in Speed Report |
|-------------------|--------------|--------------|-------------|-------------------------------------|
| Speed Band # 1 : | 0 | 70 | Band 0 | <input checked="" type="checkbox"/> |
| Speed Band # 2 : | 71 | 79 | Band 1 | <input checked="" type="checkbox"/> |
| Speed Band # 3 : | 80 | 95 | Band 2 | <input type="checkbox"/> |
| Speed Band # 4 : | 96 | 99 | Band 3 | <input type="checkbox"/> |
| Speed Band # 5 : | 100 | 170 | Band 4 | <input type="checkbox"/> |
| Speed Band # 6 : | 0 | 0 | Band 5 | <input type="checkbox"/> |
| Speed Band # 7 : | 0 | 0 | Band 6 | <input type="checkbox"/> |
| Speed Band # 8 : | 0 | 0 | Band 7 | <input type="checkbox"/> |
| Speed Band # 9 : | 0 | 0 | Band 8 | <input type="checkbox"/> |
| Speed Band # 10 : | 0 | 0 | Band 9 | <input type="checkbox"/> |
| Speed Band # 11 : | 0 | 0 | Band 10 | <input type="checkbox"/> |
| Speed Band # 12 : | 0 | 0 | Band 11 | <input type="checkbox"/> |

Band Schemes

- Limit 70 Using ACPO Scheme
- Limit 70 Using ACPO Scheme
- Limit 20 Using ACPO Scheme
- Limit 50 Using ACPO Scheme
- Limit 10, Step 10
- Limit >70, Step >10
- Limit >70 Using ACPO Scheme

Scheme Name: Limit 70 Using ACPO Scheme

Buttons: Add, Delete, Update

Units: MPH KPH

Speed Limit: [Dropdown]


Speed Step: [Dropdown]

Speed Limit Value: 85


Display %ile In Report: Yes No

Buttons: Cancel, OK


Speed Band Limits




Vehicle Classification Table
(Axle Weight Limits per Class)




Class Gross Weight Limits



ESA Calculation Parameters



VBV Memory Allocation



VBV Data Conversion

View Statistical Data Files

File View Purge Graphs

- ✓ Average Speed by Category
- Volume by Category
- Volume by Hour
- Average Speed by Hour
- Average Gross Weight by Category
- Volume by Weight Band
- Site Details
- Lane Filter

| Average Speed (Km/Hr) by Category by Lane | | | | | | | | | | | |
|---|------------|----------|---------|---------|---------|---------|---------|---------|---------|---------|---------|
| ME | LANE1 - | LANE1 - | LANE1 - | LANE1 - | LANE1 - | LANE1 - | LANE1 - | LANE1 - | LANE1 - | LANE1 - | LANE1 - |
| 10 | 105 | 112 | 109 | 91 | 96 | 89 | 86 | 90 | 87 | | |
| 10 | 102 | 110 | 108 | 92 | 96 | 88 | 85 | 88 | 88 | | |
| 10 | 103 | 110 | 108 | 93 | 95 | 86 | 85 | 88 | 87 | | |
| 10 | 101 | 111 | 109 | 94 | 95 | 83 | 85 | 83 | 88 | | |
| 10 | 105 | 110 | 107 | 95 | 96 | 89 | 86 | 88 | 88 | | |
| 10 | 104 | 113 | 109 | 96 | 97 | 94 | 88 | 89 | 87 | | |
| 10 | 114 | 114 | 110 | 94 | 100 | 94 | 81 | 91 | 87 | | |
| 305 | 10/11/2003 | 00:00:10 | 110 | 112 | 110 | 95 | 96 | 88 | 86 | 90 | 87 |
| 307 | 11/11/2003 | 00:00:10 | 102 | 111 | 108 | 91 | 95 | 88 | 86 | 89 | 88 |
| 308 | 12/11/2003 | 00:00:10 | 95 | 109 | 107 | 91 | 95 | 88 | 86 | 88 | 87 |
| 309 | 13/11/2003 | 00:00:10 | 103 | 110 | 108 | 95 | 96 | 88 | 86 | 88 | 87 |
| 310 | 14/11/2003 | 00:00:10 | 100 | 110 | 107 | 94 | 96 | 89 | 86 | 89 | 87 |
| 311 | 15/11/2003 | 00:00:10 | 110 | 114 | 111 | 96 | 97 | 96 | 85 | 90 | 89 |
| 312 | 16/11/2003 | 00:00:10 | 123 | 115 | 114 | 94 | 102 | 94 | 82 | 90 | 87 |
| 313 | 17/11/2003 | 00:00:10 | 103 | 109 | 108 | 91 | 96 | 87 | 85 | 89 | 88 |

Statistical Data File

Malfunction Management File

File Purge

| ID_NUMBER | SITE_NAME | SITE_ID | CONNECTION_DATE | CONNECTION_TIME | FAULT_DATE | FAULT_TIME | FAULT_DESCRIPTION | EXTRA_INFORMATION |
|-----------|----------------|---------|-----------------|-----------------|------------|------------|------------------------------------|-------------------------------|
| 363 | M20 Smeeth E/B | 1115 | 08/01/2004 | 16:58:58 | 07/01/2004 | 11:06:00 | Mains Power Failure | Number of Power Failures = 1. |
| 363 | M20 Smeeth E/B | 1115 | 08/01/2004 | 16:58:58 | 07/01/2004 | 09:42:00 | Roadside Cabinet Front Door Opened | Pins 1 & 2 on DOORSWITCH |

Malfunction Management File

View ATMS Data Files

File View Purge Graphs

- Average Speed
- ✓ Traffic Volume
- Occupancy
- Site Details
- Lane Filter

| Traffic Volume by Category by Lane | | | | | | | | | | | |
|------------------------------------|------------|-------------|----------|---------|---------|---------|---------|---------|---------|---------|---------|
| DATE | TIME | IDSTIC_CODE | INTERVAL | LANE1 - |
| 7/2004 | 16:00:00 | 0 | 60 | 5 | 272 | 43 | 1 | 28 | 4 | 3 | |
| 7/2004 | 17:00:00 | 0 | 60 | 5 | 350 | 37 | 1 | 20 | 2 | 4 | |
| 7/2004 | 18:00:00 | 0 | 60 | 3 | 280 | 22 | 2 | 17 | 0 | 0 | |
| 7/2004 | 19:00:00 | 0 | 60 | 0 | 183 | 20 | 2 | 22 | 0 | 1 | |
| 8681 | 06/01/2004 | 20:00:00 | 0 | 60 | 1 | 189 | 16 | 0 | 11 | 2 | 0 |
| 8682 | 06/01/2004 | 21:00:00 | 0 | 60 | 0 | 164 | 15 | 0 | 7 | 1 | 0 |
| 8683 | 06/01/2004 | 22:00:00 | 0 | 60 | 2 | 147 | 6 | 1 | 16 | 1 | 0 |
| 8684 | 06/01/2004 | 23:00:00 | 0 | 60 | 2 | 128 | 19 | 1 | 9 | 0 | 0 |
| 8685 | 07/01/2004 | 00:00:00 | 0 | 60 | 2 | 91 | 11 | 0 | 5 | 0 | 0 |

ATMS Data File

11. Appendix A - HI-TRAC Solar Power Systems

A Photovoltaic system (solar power) is an effective efficient means of powering modern low power electronic equipment. In order for a solar powered system to operate continuously without interruption certain criteria have to be taken in to consideration. Solar power systems are made up of 3 elements, the solar panel for the conversion of the suns energy in to electricity, a voltage regulation and power control unit to manage the current supply and a battery to store surplus energy to operate the equipment over night and during periods of dull weather.

It is crucial that the total operational power requirement of the equipment to be powered is understood, plus the location that the equipment is expected to operate in is known, in order to calculate the correct size of solar panel, the capacity of the battery to operate throughout the night and periods of dull conditions and to calculate the mounting angle of the solar panel for the efficient operation of the solar panel.

11.1. Solar Energy

Solar radiation energy is expressed in “hours of sunlight per metre square” equivalent to, 1-kilowatt hour per square metre per day (kWh/m²/day) this unit is referred to as the “peak sun hour.” The power output of a solar panel is expressed in Watts.

Average peak sun hours for Northern Europe and the Mediterranean:

| Peak Sun Hours | Location |
|----------------|--------------------|
| 0.5 - 1 | Glasgow, Scotland |
| 1 - 1.5 | Dumfries, Scotland |
| 1 - 2 | Southern Britain |
| 3 - 4 | Madrid, Spain |
| 5 - 6 | Cairo, Egypt |

This illustrates that a solar panel would be up to 4 times more effective in Southern Britain than Northern Scotland.

The Photovoltaic cells that make up solar panel fall in to 3 categories, amorphous silicon, Poly Crystalline and Mono Crystalline. The Amorphous panels convert the least amount of energy for a given size and tend to be of the flexible construction with an efficiency of typically 6%. The Poly Crystalline panels are the most cost effective in respect to energy conversion typically converting approximately 13% of the available energy. The Mono Crystalline is the most efficient converting about 15% of the available energy but is the most expensive.

The size and mounting angle of the solar panel is important for the correct operation of the system. The further away from the Equator you place the systems the lower the sun is in the sky, the less sun/hours are available for providing energy. This has an impact on the size of panel required to power the equipment and charge the battery, also the battery capacity needed to power the system throughout the night time hours and during periods of dull conditions especially during the winter months.

11.2. Panel Installation

The solar panel array must be mounted at the correct azimuth and angle to optimise its output.

Azimuth: Solar panels located in the Northern hemisphere should face true South.
Solar panels located in the Southern hemisphere should face true North.

Angle: Systems that need to provide power all year with a fixed solar panel array must be mounted at the appropriate angle above the horizontal.

For all year round operation the mounting angle of a stationary solar panel can be derived from the table below.

| Latitude of Installation | General Location | Mounting angle (from horizontal) |
|--------------------------|------------------|----------------------------------|
| 0° to 4° | Equator | 10° |
| 5° to 20° | Northern Africa | Site latitude + 5° |
| 21° to 45° | Southern Europe | Site latitude + 10° |
| 46 °to 65° | Northern Europe | Site latitude + 15° |

Table showing the maximum angle the sun will reach in the sky at noon for given latitudes.

| Latitude | June | December | General Location |
|----------|------|----------|--------------------|
| 60°N | 53° | 8° | Shetland Islands |
| 55°N | 58° | 12° | Dumfries, Scotland |
| 50°N | 63° | 17° | Southern Britain |
| 40°N | 74° | 27° | Madrid, Spain |
| 30°N | 83° | 37° | North Africa |

The picture in Fig 1 shows two 65 Watt 12 volt panels. The mounting angle can clearly be seen, this installation is located in the North East of England. The mounting angle not only optimises the year round performance but also assists with self-cleaning.



Fig 1

The chart below shows the typical power output of a range of poly crystalline panels ranging from 10 Watts through to 80 Watts, all the panels are rated for 12 Volt operation. The current generated by the panels is listed in Amps this is the maximum current that the panel can produce. The peak voltage is the maximum voltage produced by the panels, this voltage is deliberately higher than the normal operating voltage in order to compensate for losses due to temperature, the higher the temperature the less efficient the panels become.

The chart also shows the dimensions and weights of the various panels.

| Watts | Volts | Current | Peak Voltage | Length | Width | Weight |
|-------|-------|---------|--------------|--------|-------|--------|
| 80 | 12 | 4.75A | 16.8 | 146 | 50 | 9.5 |
| 60 | 12 | 3.56A | 16.8 | 111 | 50 | 7.2 |
| 50 | 12 | 2.97A | 16.8 | 94 | 50 | 6.3 |
| 40 | 12 | 2.37A | 16.8 | 77 | 50 | 5.4 |
| 30 | 12 | 1.78A | 16.8 | 60 | 50 | 3.9 |
| 20 | 12 | 1.19A | 16.8 | 42 | 50 | 3.0 |
| 10 | 12 | 0.59A | 16.8 | 42 | 27 | 1.5 |

A power controller must monitor the output of the solar panel and regulate the voltage to a safe level for the system it is powering, it must also monitor the state of the battery and control the level of charging required, this is important because batteries are easily damaged by incorrect charging and electronic system can be damaged by incorrect supply voltage.

Our range of sophisticated power control regulators controls the output from the solar panel ensuring that the voltage and current produced to power the electronic equipment is kept within the safe working range and that surplus power is used to charge and maintain the battery.



Fig 2

The picture in Fig 2 shows two individual solar systems in operation. One of the pole-mounted 10-Watt solar panels is providing the power for a remote data monitoring station located in the grey cabinet in the foreground. The system is backed up with a rechargeable lead acid battery, charged by the surplus energy produced by the solar panel.

NOTES: