

Table of Contents

Chapter 1 - Safety Instructions

General	1-1
Responsibilities	1-1
Safety Labels	1-2
Safety Concept	1-2
General Safety Regulations	1-3

Chapter 2 - Introduction

Overview	2-1
Range of Application of the ACS 1000	2-1
Intended Audience for this Manual	2-2
What this Manual Contains	2-2

Chapter 3 - Design and Functional Description

Overview	3-1
Fuseless Design	3-1
Control Equipment	3-1
Technical Specifications	3-1
Technical Data	3-1
Standards Fulfilled	3-1
Description of the ACS 1000	3-2
Functional Description	3-2
Power Circuit Interface	3-3
Input Circuit	3-3
Output Circuit	3-3
Control System	3-4
Direct Torque Control DTC	3-4
How does DTC Differ from PWM Flux Vector Drives?	3-5
Layout and Description of Assembly	3-5
Cabinet Design	3-5
Cabinet Sections	3-7
Door Locks	3-9
Lifting Arrangements	3-9
Cooling Circuit	3-9
Control and Monitoring Equipment	3-10
CDP 312 Control Panel	3-11

Standard Control and Monitoring Functions	3-12
General	3-12
Motor Control Features	3-12
Motor ID Run	3-12
Filter ID Run	3-13
Full Torque at Zero Speed	3-13
Enhanced Flying Start	3-13
Flux Optimization	3-13
Power Loss Ride-Through	3-13
Acceleration and Deceleration Ramps	3-14
Critical Speed	3-15
Resonance Frequency Damping (RFD)	3-15
Constant Speeds	3-15
Speed Controller Tuning	3-16
Accurate Speed Control	3-17
Accurate Torque Control without Speed Feedback	3-17
Drive System Features	3-18
Main Circuit Breaker (MCB) Control	3-18
Local and Remote Control	3-19
Local Control	3-19
Remote Control	3-19
Diagnostics	3-20
Actual Signal Monitoring	3-20
Fault History	3-20
Programmable Digital Outputs	3-20
Programmable Analog Outputs	3-20
Input Signal Source Selections and Signal Processing	3-21
Two Programmable Control Locations	3-21
Reference Signal Processing	3-21
Analog Input Processing	3-22
Offset Calibration	3-22
Standard Protection Functions	3-23
Programmable Fault Functions	3-23
Motor Winding Temperature	3-23
Motor Stall	3-23
Underload	3-24
Overspeed	3-24
Undervoltage	3-24
Preprogrammed Protection Functions	3-25
Motor Phase Loss	3-25
Short Circuit in the Rectifier Bridge	3-25
Charging Fault	3-25
Supply Phase Loss	3-25
Overcurrent	3-25
Loadability of the Inverter	3-25
Short Circuit of the Inverter	3-26
Ground Fault	3-26

Operating System	3-26
Measurement Loss	3-26
Battery Test	3-26
Communication Fault	3-26
ID-Run Fault	3-26
Other Protection Functions	3-27
External Motor Protection Trip	3-27
External Transformer Protection Trip	3-27
Process Stop	3-27
External Emergency Off	3-27
MCB Control Fault	3-27
Other Features	3-27
Limits	3-27
Automatic Reset	3-28
Supervision	3-28
ACS 1000 Information	3-28
Parameter Lock	3-28
Built-in PID Controller	3-29
Resonance Frequency Damping (RFD)	3-29
Customer Specific Options	3-29
PC Tools	3-29
DriveWindow	3-29
DriveLink	3-29
DriveSupport	3-30

Chapter 4 - I/O Interfaces and Application Macros

Overview	4-1
Terms and Abbreviations	4-1
Input/Output Boards	4-1
Standard I/O Boards	4-1
I/O Ratings	4-2
Control Voltage Output	4-2
Potentiometer Supply	4-3
Digital Output Home Position	4-3
External Connections	4-3
Location of IOEC Boards	4-3
Pre-defined I/O Signals	4-5
Application Macros	4-11
Overview	4-11
Macro Applications	4-11
Factory	4-11
Speed Control	4-11
Hand/Auto	4-12
PID Control	4-12
Torque Control	4-12

Sequential Control	4-12
Master/Follower	4-12
User 1/User 2	4-12
Factory Macro	4-13
Description	4-13
Control Overview	4-13
Input and Output Signals	4-14
Control Signal Diagram	4-15
Hand/Auto Macro	4-17
Description	4-17
Control Overview	4-17
Input and Output Signals	4-18
Control Signal Logic	4-19
PID Macro	4-21
Description	4-21
Control Overview	4-21
Input and Output Signals	4-22
Control Signal Diagram	4-23
Torque Macro	4-25
Description	4-25
Control Overview	4-25
Input and Output Signals	4-26
Control Signal Diagram	4-27
Sequential Control Macro	4-29
Description	4-29
Control Overview	4-29
Input and Output Signals	4-30
Control Signal Diagram	4-31
Master/Follower Macro	4-33
Description	4-33
Control Overview	4-34
Input and Output Signals	4-35

Chapter 5 - Operation

Safety Instructions	5-1
Introduction	5-1
Conventions	5-1
Start Operation of the ACS 1000	5-2
Preparatory Procedures	5-2
Prerequisites	5-2
Preparatory Steps	5-3
Closing Main Circuit Breaker	5-4
Charging the Capacitor Bank	5-5
Entering Setpoint and Starting Up the ACS 1000	5-6
In Local Control Mode	5-6

In Remote Control Mode	5-7
Changing Setpoints	5-7
In Local Control Mode	5-7
In Remote Control Mode	5-8
Reverse Sense of Rotation	5-8
In Local Control Mode	5-8
In Remote Control Mode	5-9
Local / Remote Selection	5-9
Local Control	5-9
Remote Control	5-9
Changing Control Mode during Operation	5-9
Remote -> Local Control	5-10
Local -> Remote Control	5-10
Disabling Local Operation from CDP 312 Control Panel	5-10
Stopping the ACS 1000	5-11
In Local Control Mode	5-11
In Remote Control Mode	5-11
De-energizing the ACS 1000	5-12
In Local Control Mode	5-12
In Remote Control Mode	5-14
Emergency Stop	5-14
Manual Initiation	5-14
Process Monitoring	5-14
Actual Signal Display	5-15
Full Signal Name Display	5-17
Active Fault Display	5-17
Fault History Display	5-18
Other Operational Actions	5-19
Panel and Display Functions	5-19

Chapter 6 - Parameter Viewing and Editing

Overview	6-1
Safety Instructions	6-1
ACS 1000 Application Parameters	6-1
Parameter Groups	6-1
Start-up Parameters	6-2
Application Macros	6-2
Application Parameter Editing: Overview	6-2
Parameter Editing with the CDP 312 Control Panel	6-6
General	6-6
Conventions	6-6
Prerequisites	6-7
Selection of Actual Signals	6-7
Start-Up Parameters	6-7
Selection or Verification of Application Macro	6-11

Selection of Motor Control Features	6-13
Verification and Modification of Parameters	6-14
Motor Identification Run	6-15
Miscellaneous Functions	6-16
ACS 1000 Information	6-16
Parameter Lock	6-16
Uploading Parameters	6-16
Downloading Parameters	6-17
Copying Parameters to Other Units	6-19
Restoring Default Settings	6-19
User Macros	6-20
Creating a User Macro	6-21
Recalling User Macro Parameters	6-22

Chapter 7 - Preventive Maintenance

Introduction	7-1
Safety Instructions	7-1
Maintenance Schedule	7-3
Required Tools	7-4
Maintenance Instructions	7-4
Standard Procedure for Maintenance	7-4
Outside Cleaning	7-7
Inside Floor Cleaning	7-7
Check of Connections	7-7
Replacement of Air Filters	7-8
Inverter Door Air Inlet	7-8
Control Door Air Inlet	7-8
Replacement of Fan	7-8
Replacement of Fan Bearings	7-10
Replacement of Batteries	7-11
Parameter Backup	7-11
Inspection of Motor, Transformer and MCB	7-12
Maintenance Logbook	7-12
ABB Service Address	7-12

Chapter 8 - Trouble Shooting & Repair

Overview	8-1
Safety Instructions	8-1
Alarm and Fault Handling	8-2
Fault Display on the CDP 312 Control Panel	8-3
Active Fault Display	8-3
Fault History Display	8-4
Standard	

Procedure for Trouble-Shooting	8-5
Repair Work	8-7
Error Messages and Fault Elimination	8-7

Chapter 9 - Transportation, Storage, Disposal and Recycling

Introduction	9-1
Environmental Requirements	9-1
Storage	9-1
Transportation	9-1
Stationary Use	9-1
Packing	9-1
Loading and Unloading	9-3
Lifting Angle	9-4
Center of Gravity	9-4
Unpacking	9-4
Transportation Damages	9-6
Storage	9-6
Storage Conditions	9-6
Periodical Inspections	9-7
Battery	9-7
Storage Instructions for Spare Parts	9-7
Transportation	9-7
Ambient Conditions	9-7
Humidity	9-7
Temperature	9-7
Handling Instructions for Spare Parts	9-8
Temporary Shut Down	9-9
Disposal of Packing Material	9-9
Packing Material	9-9
Disassembly and Disposal of Equipment	9-9

Chapter 10 - Installation

Overview	10-1
Safety Instructions	10-1
Requirements to Foundation, Space and Ambient Conditions	10-2
Ambient Conditions	10-2
Base Dimensions and Clearances	10-2
Floor Levelling and Cable Ducts	10-3
Selection and Dimensioning of Power Equipment	10-3
Main Circuit Breaker / Controller	10-3
Instrumentation and Protection Equipment	10-5
Transformer Primary Cable	10-6
Transformer	10-6

Transformer Secondary Cable	10-6
Motor Cable	10-7
Power Cable Dimensions	10-8
Comments:	10-8
Installation Conditions	10-9
Equipment Grounding	10-9
Auxiliary Power Cable	10-9
Control Cables	10-9
Cable Routing	10-10
Power Cables	10-10
Cable Termination	10-10
Cable Length	10-10
Grounding Wire	10-10
Control Cables	10-10
Mains and Motor Cable Connection Diagrams	10-10
Mechanical Installation	10-12
Required Tools and Parts	10-12
Preparation of Mounting Site	10-12
Displacement to Installation Site	10-13
Mounting the Cabinet	10-13
Electrical Installation	10-16
Mains and Motor Cable Lead-In	10-16
Inserting Mains and Motor Cables	10-18
Grounding Connections	10-21
Insulation Checks	10-21
Mains and Motor Cable Connections	10-22
Auxiliary Power Cable Connection	10-23
Control Cable Connection	10-25
Wiring Tests	10-28
Final Work	10-28
Preparation for commissioning	10-28

Chapter 11 - Commissioning

Overview	11-1
Preparation of Commissioning	11-1
General Preconditions	11-1
High Voltage Equipment	11-1
Auxiliary Voltage Supply and Control	11-1
Cooling Circuit	11-1
Miscellaneous	11-2
Commissioning Procedure	11-2
Required Customer Manpower	11-2
Acceptance	11-2
Warranty	11-2

Appendix A - Technical Data

Appendix B - The CDP 312 Control Panel

Overview	B-1
ACS 1000 Parameter Programming	B-1
Application Macros	B-1
Parameter Groups	B-1
Start-up Data Parameters	B-1
Control Panel	B-1
Display	B-2
Keys	B-2
Panel operation	B-4
Keypad Modes	B-4
Identification Display	B-4
Actual Signal Display Mode	B-4
Actual Signal Display	B-5
Parameter Mode	B-8
Function Mode	B-9
Copying parameters from one unit to other units	B-12
Setting the contrast	B-13
Drive Selection Mode	B-13
Operational Commands	B-13
Local Control	B-13
Remote Control	B-14
Changing Control Location	B-14
Start, Stop, Direction and Reference	B-14

Appendix C - Customer Specific Options

Appendix D - Quality Assurance

Introduction to ABB's QA System	D-1
ISO 9001	D-1
ISO 14000	D-1

Appendix E - Applicable Codes and Standards

Appendix F - Layout and Mechanical Drawings

Appendix G - Wiring Diagrams

Appendix H - Part List

Appendix I - Recommended Spare Parts List

Appendix K - Signal and Parameter Table

Appendix L - Inspection and Commissioning Record

Appendix M - Parameter Setting List

Index

Chapter 1 - Safety Instructions

General

The ACS 1000 is a high voltage device and when misused it can cause damage to personnel and property. When located, installed and connected in accordance with the instructions given in this Manual, the device is safe.

Personnel involved in **installation, commissioning and maintenance** work on the ACS 1000 must be electrical professionals who are fully acquainted with medium voltage (MV) equipment.

Operating the drive does not require special knowledge of frequency converters. However, the user must understand the meaning of the messages on the control panel of the converter. If an alarm or a trip is registered by the converter control, the operator must be able to decide whether to shut down the converter for troubleshooting or repair or to reset the fault message and restart the drive.

This chapter includes the safety instructions that must be complied with when installing, operating and servicing the ACS 1000. If neglected, physical injury and death may follow, or damage may occur to the frequency converter, the motor and the driven equipment. The contents of this chapter must therefore be studied before attempting any work on, or with the unit.

Responsibilities

It is the owners responsibility to insure that each person involved in the installation, commissioning, operation or maintenance of the ACS 1000 has received the appropriate training or instructions and has thoroughly read and clearly understood the safety instructions in this chapter.

When installing the frequency converter as well as during commissioning and maintenance, all personnel involved must observe the relevant general safety regulations and standards for electrical works in medium and low voltage equipment which are in force at the place of installation. Furthermore personnel must make strict compliance with the instructions given in this manual.

ABB Industrie AG declines all liability for any possible damage resulting from failure or negligence to observe this warning.

Safety Labels

Several levels of safety instructions and notes are used in this manual to highlight a potentially dangerous situation. They are marked with one of the following labels:




Danger: This symbol indicates an imminent danger resulting from mechanical forces. A non-observance may lead to life-threatening physical injury or death.



Danger: This symbol indicates an imminent danger resulting from high voltage. A non-observance may lead to life-threatening physical injury or death.



Warning/Caution: This symbol indicates a dangerous situation. A non-observance may lead to physical injury or cause serious damage to the converter.



Note: This symbol emphasizes important information. A non-observance may cause damage to the converter.

Safety Concept


The design and the specific safety devices of the ACS 1000 allow safe installation, commissioning, operation and maintenance of the equipment when used as intended. The ACS 1000 is equipped with the following safety features (see *Figure 1-1*):

- Safety grounding isolator for intermediate DC-circuit
- Electromechanic interlocking system; the safety grounding isolator cannot be closed until the main circuit breaker is open and the DC-circuit is completely discharged.
- Door interlocking system preventing access to live equipment. When the drive is energized, access is possible only to the control equipment.
- Control functions to prevent from dangerous operating conditions
- Full converter protection
- Inputs for external protection devices from transformer, motor and process control

Although the ACS 1000 is safe if all interlocks and safety precautions are operating, some residual danger areas remain if safety instructions are not observed.

The ACS 1000 is operating in a medium voltage environment usually consisting (besides the converter) of a power transformer, a motor, cabling, the driven process and a superimposed control system. The safety concept for the ACS 1000 takes into account the embedding of these components in the sense that no additional threat arises from their interaction with the ACS 1000. However, the safety considerations for the individual external components and for the overall process are not part of the ACS 1000 safety concept.

Figure 1-1 Residual danger areas of the ACS 1000



General Safety Regulations

The safety instructions in this chapter generally apply when working on the ACS 1000. You will find additional instructions and warnings related to particular topics or actions throughout the manual where relevant.

The following regulations must be strictly observed:

- **Intended purpose of use**

The technical specifications (see *Appendix A - Technical Data*) and the intended purpose of use (see *Chapter 2 - Introduction*) must be strictly adhered to.

- **Training of personnel**
Only well trained personnel are allowed to install, operate, maintain or service the ACS 1000. This personnel must be specially instructed about the dangers that can be caused by this equipment.
- **Improper behavior**
Working in a way that could cause dangers to persons or the ACS 1000 is strictly prohibited.
- **Access for untrained and Unauthorized Personnel**
The owner is responsible for making sure that untrained personnel do not have access to the ACS 1000 frequency converter and cannot operate the ACS 1000 and adjoining equipment.
- **Modifications without authority**
Modifications and constructional changes in the ACS 1000 are not allowed. Always contact ABB Industrie AG.
- **Duty of maintenance**
The owner must ensure that the ACS 1000 is used only under proper conditions and in a fully serviceable state.
- **Operating environment**
The owner must guarantee that all ambient conditions specified in *Appendix A - Technical Data* are fulfilled.



Warning: All electrical installation and maintenance work on the ACS 1000 must be carried out by qualified electricians.



Danger: Never work on a powered ACS 1000. The main circuit breaker and the input isolators must always be opened and locked in "OPEN" position. Do not access the main power circuit nor the motor as long as the system is not grounded.

When switching off the mains, always allow the intermediate circuit capacitors to discharge before grounding and starting work on the frequency converter, the motor or the motor cable.

The ACS 1000 and adjoining equipment must be properly grounded and the auxiliary supply voltage must be switched off prior to starting with any work.



Danger: Some loads may apply a mechanical torque on the motor shaft! If the motor can rotate due to such a load, always disconnect, short-circuit or mechanically block the motor before you start work.



Danger: There can be dangerous voltages inside the ACS 1000 from external control circuits (measurement inputs from PT's etc.) even if the ACS 1000 mains power and auxiliary power are shut off. Take appropriate measures when working with the unit, i.e deenergize and disconnect all such external devices (auxiliary supply, heaters, coolers, I/O-interfaces) before you start work.



Danger: This converter can influence the working of **heart pacemakers**. Install a corresponding warning sign at the entrance to the converter room. In case the ACS 1000 is located in an open hall, the safety sign must be at a minimum distance of 6 meters / 20 feet to the converter!

Chapter 2 - Introduction

Overview


This manual provides you with detailed information on the installation and start-up of the ACS 1000 frequency converter, including detailed descriptions of the functions, installation and start-up of the unit. Fault tracing information, technical data and dimensional drawings are included as well.

Range of Application of the ACS 1000

The ACS 1000 is a standard, medium-voltage AC drive, rated according to the technical specifications in *Appendix A - Technical Data*.

The ACS 1000 has been designed as converter drive for squirrel cage induction motors. Standard applications are the control of fans, pumps, conveyors and compressors in petrochemical, mining, water, pulp & paper, cement industries and power generation. The customized engineering content is minimal. Thanks to its outstanding performance, the ACS 1000 is ideally suited for retrofit applications.

Figure 2-1 The ACS 1000. Air Cooled Type



Intended Audience for this Manual

This manual is intended for electrical field professionals who are responsible for installing, commissioning and servicing the ACS 1000 frequency converter.

The audience is expected to have:

- professional education in electrical installation
- knowledge of physical and electrical fundamentals, electrical wiring practices for medium voltage (MV) and low voltage (LV) equipment, electrical components and electrical schematic symbols
- full knowledge of safety aspects (national standards and regulations, hazard prevention) related to work in medium voltage (MV) installations.

On the other hand the audience is not expected to have:

- prior experience of ABB products
- prior experience of frequency converters
- prior experience of the ACS 1000 product family
- prior experience or training of installing, commissioning, operating and servicing the ACS 1000.

What this Manual Contains

Chapter 1 - Safety Instructions: In this chapter, which is placed at the beginning of the manual, the various safety instruction levels used in this manual are explained. This chapter also provides general instructions on safety which must be respected during all work on the ACS 1000.

Chapter 3 - Design and Functional Description contains a short technical overview of the ACS 1000 and a short description of its features and control functions.

Chapter 4 - I/O Interfaces and Application Macros describes standard I/O, control configuration using application macros (Factory, Hand/Auto, PID Control, Torque Control, Sequential Control, Master/Follower) together with the macro-specific I/O and indicates typical applications for each macro.

Chapter 5 - Operation describes safety considerations, preconditions for energizing and operation of the ACS 1000. Furthermore, remote and local control, starting and stopping, changing setpoints, monitoring of actual process values, de-energizing the ACS 1000 and the emergency stop function are described.

Chapter 6 - Parameter Viewing and Editing describes how to view and modify start-up data, how to select application macros and edit other parameters using the CDP 312 control panel. Some ancillary parameter and macro editing features are described as well.

Chapter 7 - Preventive Maintenance includes the maintenance schedule and specific descriptions of all preventive maintenance procedures.

Chapter 8 - Trouble Shooting & Repair explains what to do upon an alarm message and how to proceed in case of an alarm or a converter trip. A list

of fault codes and messages on the CDP 312 control panel as well as explanations of all alarm messages and trip functions is included. The procedure for restarting the converter is described.

Chapter 9 - Transportation, Storage, Disposal and Recycling provides information about environmental conditions to be maintained during transportation and storage, together with instructions for packing, unpacking, lifting and moving . It includes special requirements for storage and conservation together with instructions for periodical inspections. In addition, information on disposal and recycling of material as well as on temporary shut-down and decommissioning of the ACS 1000 is given.

Chapter 10 - Installation specifies the mechanical and electrical requirements to the foundation, cabling and other equipment, gives instructions for mounting (drawings and descriptions), cable routing and termination for power, auxiliary and signal connections (incl. EMC requirements).

Chapter 11 - Commissioning includes an installation checklist and and preconditions for commissioning. In addition, the various commissioning steps are described.

Appendix A - Technical Data lists the ACS 1000 technical specifications.

Appendix B - The CDP 312 Control Panel explains all panel push-buttons and all panel functions.

Appendix C - Customer Specific Options is a documentation of all customer specific options including descriptions and drawings.

Appendix D - Quality Assurance gives you an introduction to ABB's QA system, introduces you to ISO 9001 and ISO 14000 and contains the declaration of CE conformity and the UL/CSA approval.

Appendix E - Applicable Codes and Standards is a list of all applicable codes and standards for the ACS 1000.

Appendix F - Layout and Mechanical Drawings is a collection of mechanical outline drawings showing all relevant information for floor mounting, cable entries, water flanges etc.

Appendix G - Wiring Diagrams is a collection of electrical schematics and terminal diagrams.

Appendix H - Part List is a list of all major components including the parts in the repair tool kit.

Appendix I - Recommended Spare Parts List is a converter specific list of recommended spare parts. Those parts, which have to be exchanged as part of the regular maintenance program, are listed as well.

Appendix K - Signal and Parameter Table includes a complete description of all control parameters.

Appendix L - Inspection and Commissioning Record contains all records from factory testing. Commissioning test records and a provisional acceptance certificate shall also be included in this Appendix.

Appendix M - Parameter Setting List is a customer specific parameter list

with all parameter settings after commissioning.

The *Index* contains an alphabetical list of topics treated in this manual with reference to the corresponding page numbers.

Chapter 3 - Design and Functional Description

Overview

The ACS 1000 is a three phase frequency converter for squirrel cage induction motors. Sophisticated microprocessor circuitry is used for monitoring the motor electromagnetic status. These data and Direct Torque Control enable state-of-the-art sensorless motor control. Additional pulse encoder feedback can be employed in applications where precision speed control is required, or in case of long-time operation near zero speed.

The nearly sinusoidal converter output voltage makes the ACS 1000 ideally suited for retrofit applications with existing standard induction motors without the need for derating.

Fuseless Design

The ACS 1000 features a fuseless protected medium voltage drive. This patented design uses the new power semiconductor switching device, IGCT, for circuit protection.

The IGCT, which is placed between the DC link and the rectifier, can, unlike conventional fuses, directly isolate the inverter of the drive system from the power supply side within 25 microseconds, making it 1000 times faster than the operational performance of fuses.

The ACS 1000 is fitted with hardware and software protection features to safeguard against faults and damages due to improper operating conditions and equipment malfunction.

Control Equipment

The ACS 1000 frequency converter is equipped with advanced features for local and remote control.

Control equipment is integrated in the converter cabinet and provides fully digital and microprocessor based process control, protection and monitoring functions, supplemented with hardware protection circuits as a back-up.

The CDP 312 Control Panel is the basic local user interface for monitoring, adjusting parameters and controlling the ACS 1000 operation.

Technical Specifications

Technical Data See Appendix A - Technical Data


Standards Fulfilled See Appendix E - Applicable Codes and Standards

Description of the ACS 1000

Functional Description The 3-phase AC line voltage is supplied to the rectifier bridges through the 3-winding converter transformer (see *Figure 3-1*). In order to obtain 12 pulse rectification, a 30° phase shift is necessary between the two secondary windings of the transformer. Therefore one secondary is wye-connected while the other is delta-connected.

The two fuseless rectifier bridges are connected in series, such that the DC-voltages are added up. Therefore, the full DC-bus current flows through both bridges.


Figure 3-1 Elementary diagram - ACS 1000



Each leg of the 3-phase inverter bridge consists of a combination of 2 IGCT's for 3-level switching operation: with the IGCT's the output is switched between positive DC voltage, neutral point (NP) and negative DC voltage. Hence both the output voltage and the frequency can be controlled continuously from zero to maximum, using Direct Torque Control.

At the converter output a LC filter is used for reducing the harmonic content of the output voltage. With this filter, the voltage waveform applied to the motor is nearly sinusoidal (see *Figure 3-2*). Therefore, standard motors can be used at their nominal ratings. The filter also eliminates all high dv/dt effects and thus voltage reflections in the motor cables and stresses to the motor insulation are totally eliminated.

Figure 3-2 Voltage and current waveforms at converter output



The precharge resistors limit the current in the main DC-link when the converter is energized. They are bypassed with the protection IGCT's as soon the DC voltage reaches 79%. The main function of these protection IGCT's is to open in case of a fault in order to prevent the rectifier to feed into the fault.

Common mode currents from the inverter are limited with the common mode choke and damped with the common mode damping resistor. Due to its special construction the common mode choke provides full reactance for the common mode currents flowing through transformer secondary cabling, DC-link, output filter and internal grounding bus of the converter. For the main DC-current, on the other hand, the choke forms practically no reactance thus enabling the main current to pass unhindered.

di/dt-chokes (not shown in *Figure 3-1*) are used in the inverter to protect the inverter's free wheeling diodes from excessive rates of current drop during commutation.

Power Circuit Interface

Input Circuit The standard version of the ACS 1000 is equipped with a 12-pulse diode rectifier input (see *Figure 3-1*). This is adequate for most supplying networks and normally the harmonic requirements as demanded by standards such as IEEE 519 can be met.

For operation in particularly sensitive networks, the ACS 1000 can optionally be equipped with a 24-pulse rectifier.

Output Circuit As a standard the ACS 1000 is equipped with a low pass LC sine filter in its output stage. Current feedback is used to actively control filter operation. The low pass frequency is designed to be well below the lowest switching frequency used by the inverter output stage. This greatly enhances the purity of both the voltage and current waveforms applied to the motor. This in turn results in many important benefits:

- Harmonic heating is virtually eliminated. The drive may be used to supply standard medium voltage motors (existing or new) without applying

thermal derating factors.

- Voltage reflection and the associated occurrence of voltage doubling at the motor input terminals is no longer an issue (the causal high frequency content does not exist). Therefore, any standard medium voltage winding insulation system (existing or new) is compatible.
- Motor cables of any length may be utilized without concern (normal voltage drop issues as found in any electrical installation still apply).
- Motor bearing failures attributable to capacitively coupled high frequency current are no longer an issue (the causal high frequency common mode voltage is eliminated).
- Motor insulation is not subjected to the common mode voltage typical for other drive topologies.

Control System


Direct Torque Control DTC

Direct torque control (DTC) is a unique motor control method for AC Drives. The inverter switching is directly controlled according to the motor core variables flux and torque.

The measured motor current and DC link voltage are inputs to an adaptive motor model which produces exact actual values of torque and flux every 25 microseconds. Motor torque and flux comparators compare actual values with the reference values produced by the torque and flux reference controllers. Depending on the outputs from the hysteresis controllers, the pulse selector directly determines the optimum inverter switch positions.

Typical performance figures for the speed and torque control are given in *Standard Control and Monitoring Functions, page 3- 12*.

Figure 3-3 DTC block diagram



How does DTC Differ from PWM Flux Vector Drives?

In DTC, every switching is determined separately based on the values of flux and torque, rather than switching in a predetermined pattern as in conventional PWM flux vector drives.

DTC	Flux Vector
Switching based on core motor variables Flux and Torque	Switching based on separate control of magnetising and torque producing components of current
Shaft speed and position not required	Mechanical speed is essential. Requires shaft speed and position (either measured or estimated)
Each inverter switching is determined separately (every 25 μ s).	Inverter switching based on average references to a PWM modulator. This results in delays in response and wasted switchings.
Torque Step Rise Time (open loop) is less than 10 msec.	Torque Step Rise Time Closed Loop 10 to 20 msec. Sensorless 100 to 200 msec.

For more information on DTC, please refer to the *Technical Guide No. 1 Direct Torque Control (3AFY 58056685 R0025)*.

Layout and Description of Assembly

Cabinet Design

The riveted cabinet construction of the ACS 1000 provides extremely effective protection against electromagnetic emissions compared to traditional frames. In addition, this construction technique provides a solid, yet

flexible and self-supporting framework which avoids the need for additional skeletal support.


The design fulfills the requirements of international standards like UL 347A.

EMC (Electromagnetic Compatibility) has been achieved by minimizing the spacing between the rivets and avoiding the use of paint on the cabinet's inside walls. Paint tends to reduce the effectiveness of metallic bonding which is paramount to successful EMC.

As standard, only the front of the ACS 1000 cabinet is painted while all other walls are galvanized. The cabinet can be entirely painted outside as an option.

EMC performance is further enhanced by the use of metal cable channels, which are an integral part of the folded cabinet construction.

Figure 3-4 The ACS 1000. Air cooled type




Cabinet Sections The ACS 1000 is designed with the inverter unit as one complete section including output filter capacitors and DC link capacitor. This section, located on the right hand side, experiences maximum air flow which is advantageous for the temperature sensitive capacitors. Construction allows easy exchange of IGBT's using a special tool.

The middle section houses the cooling fan, the rectifier stack, protection IGBT's and filter reactor. The construction is such that the fan can be exchanged easily.

The third section, on the left hand side, includes control equipment and also provides space devoted exclusively to cable termination. All control equipment with the exception of one I/O card is located on the front of a swing frame. The remaining I/O card and any optional I/O cards are located behind and to the right of the swing frame. Customer signal terminals are also located in this area. I/O cards have screw-type terminals on which cables totaling 2.5 mm² (AWG12) may be connected. See *Figure 3-5* and *Figure 3-6*.

Figure 3-5 Front view of ACS 1000




Behind the swing frame and a protective separation door is the drive's power terminal section. To provide adequate access to this section, the swing frame can be opened through more than 90°.

The design is such that the swing frame can be opened without dangerously exposing the power terminals.

The standard ACS 1000 cabinet is rated IP21. Higher IP ratings are optionally available.

The ACS 1000 cabinet system provides the flexibility to add cabinet sections to the drive at any time. Sections can be added in widths of 600, 800 and 1000 mm (resp. 24, 32 and 39 Inches).

Figure 3-6 Rear view of ACS 1000



Door Locks All doors are hinged and locked using carriage key locks.

The power section of the drive (multiple doors) includes an electromechanical interlock system that operates in conjunction with the safety grounding switch and electrical interlocks from the main circuit breaker (external). This interlock system insures that none of the power cabinets can be opened until the main source of power is disconnected, the safety grounding switch is closed and the DC link capacitors are discharged. Additionally the same interlock system insures that power cannot be initialized to the drive unless the doors are closed and the safety grounding switch has been opened.


The control section can always be opened.

Lifting Arrangements The cabinets are fitted with lifting lugs as standard. Channels are provided at the base of the unit for lifting by forklift vehicles.

Cooling Circuit The ACS 1000 Type ACS1014-A2 is equipped with forced air cooling as mentioned above. The air intake is located in the front door of the inverter section. The standard grid can optionally be equipped with an air filter

system to minimize air pollution in the converter. The air filter can be replaced from outside while the system is running.

Figure 3-7 Cooling fan inside the converter cabinet (standard)



From the front door intake, the air flows through the heat sinks of the vertical inverter stacks and is then routed to the central section where the fan is located. After passing the fan, the air is blown through the rectifier diode stacks, followed by the motor filter reactor. The exhaust is located on top of the cabinet and provides a natural stack effect in order to direct the air flow after the fan. The exhaust is covered in order to protect the equipment inside mechanically.

Control and Monitoring Equipment


The ACS 1000 can be controlled from several control locations:

- from the detachable CDP 312 Control Panel mounted on the ACS 1000 front door of the control section
- from external control devices, e.g. a supervisory control system, that connect to the analog and digital I/O terminals on the Standard I/O Boards
- through Fieldbus adapter modules
- with PC Tools (*DriveWindow* and *DriveLink*), connected via a PC adapter to the ACS 1000 control board.

Optional analog and digital I/O extension modules can be used to provide extended transformer and motor protection, protection for external cooling equipment (e.g. fans, chillers), on-line synchronization logic, and other customer requirements as needed.

CDP 312 Control Panel

Figure 3-8 CDP 312 control panel



Using the panel it is possible to

- enter start-up data into the drive
- control the drive with a reference signal and with Start, Stop and Direction commands
- display actual values (three values can be read simultaneously)
- display and adjust parameters
- display information on the most recent forty fault events
- upload and download complete parameter sets from one drive to another (this greatly simplifies the start-up procedure of several identical drives).


For further details please refer to *Appendix B - The CDP 312 Control Panel*.

Standard Control and Monitoring Functions

General The ACS 1000 control and protection system is configured and customized through a set of application parameters. These parameters can be programmed by the user, either with the CDP 312 control panel supplied with the converter or with a PC and the DriveWindow software package.

Parameters can be defined by setting them one by one or by invoking a predefined set of parameters which is optimized for a particular application. Such predefined parameter sets are called application macros. Therefore part of the functions described in this chapter will automatically be configured by selecting an application macro.

In the remainder of this chapter you will find the description of the standard control, monitoring and protection functions with references to the related parameters. A description of the basic I/O devices and the application macros of the ACS 1000 you will find in *Chapter 4 - I/O Interfaces and Application Macros*. This and the following chapter are intended to be used as a reference for obtaining quick information on a specific function. A systematic guide for determining the parameter settings and I/O allocation for commissioning you will find in the ACS 1000 *Engineering Manual*.



Configuring the ACS 1000 is a task that requires a professional background going far beyond the knowledge needed for system operation. Therefore parameters and application macros are set during commissioning of the converter by ABB commissioning engineers – based on the information received by the owner – and should normally not be changed afterwards by the user.



Warning: Never change any parameters if you are not thoroughly familiar with the meaning of each parameter and with the consequences resulting from the modification.

Running the ACS 1000, the motor and the driven equipment with incorrect data can result in improper operation, reduction in control accuracy and damage to equipment.

Motor Control Features

Motor ID Run With the *standard motor identification run (ID run)* (input of nameplate data is always required), a quick motor identification is automatically done the first time the Start command is given. During this first start-up the motor is run at zero speed for several seconds to allow a basic motor model to be created. This model is sufficient to allow normal operation.

The unbeatable performance of direct torque control (DTC) is based on an accurate motor model. The parameters of this model are automatically


determined during the *enhanced ID run*. Basic motor nameplate data (power rating, speed, etc.) must first be entered manually. Then the drive is instructed to perform a motor ID run. For optimum parameter determination the load should be disconnected from the motor during the ID run. The ACS 1000 operates the motor under a predetermined set of running conditions for a few minutes. For each running condition motor and inverter feedback responses are measured. Based on these measurements the motor model parameters are calculated and optimized. The final result is an enhanced mathematical model of the motor which functions to provide the DTC controller with accurate flux, torque, and motor speed information.

If no ID run is selected, the converter will be stopped due to *ID run fault*.

Motor ID run can be selected upon entering the so-called start-up parameters of parameter group 99 (parameter 99.12). For further details please refer to *Chapter 6 - Parameter Viewing and Editing, Start-Up Parameters, page 6- 7*.

<i>Filter ID Run</i>	Filter ID run is used to verify output filter data. It is carried out with decoupled motor. Filter ID run is not required for normal operation, its purpose is to facilitate trouble shooting in the output filter circuit.
<i>Full Torque at Zero Speed</i>	A motor fed by the ACS 1000 can develop short-term motor nominal torque at start-up without any pulse encoder or tachogenerator feedback. This feature is essential for constant torque applications. However, if long-term operation at zero speed is required, a pulse encoder has to be applied.
<i>Enhanced Flying Start</i>	The enhanced flying start function of the ACS 1000 is an improved version of the flying start and ramp start features normally found in frequency converters. The ACS 1000 can detect the state of the motor within a very short time. Hence, rapid starting is possible under all conditions. This feature allows easy starting of turbine pumps or windmill fans, for example.
<i>Flux Optimization</i>	Flux optimization of the ACS 1000 reduces the total energy consumption and motor noise level when the drive operates below the nominal load. The total efficiency (motor and the drive) can be improved by 1..10%, depending on the load torque and speed. Flux optimization is activated with parameter 27.01, <i>Flux Control</i> . For further details see <i>Appendix K - Signal and Parameter Table</i> .
<i>Power Loss Ride-Through</i>	If the incoming supply voltage is cut off the ACS 1000 will continue to operate in an active but non-torque producing mode by utilizing the kinetic energy of the rotating motor and load. The ACS 1000 will be fully active as long as the motor rotates and generates energy to the ACS 1000.

Figure 3-9 Loss of supply voltage at nominal load ($f_{out} = 40$ Hz)



The intermediate circuit DC voltage drops to the minimum limit. The controller keeps the voltage steady as long as the main power is absent. The ACS 1000 runs the motor in generator mode. The motor speed falls but the drive is fully active as long as the motor has enough kinetic energy.

Power loss ride through is set with parameter group 39, *Ride Through Function*. For further details see *Appendix K - Signal and Parameter Table*.

Acceleration and Deceleration Ramps

ACS 1000 provides two user-selectable acceleration and deceleration ramps. It is possible to adjust the acceleration/deceleration times (0..1800 s) and select the ramp shape. Switching between the two ramps can be controlled via a digital input.

The available ramp shape alternatives are:


Linear: Suitable for drives requiring long acceleration/deceleration where S-curve ramping is not required.

S1: Suitable for short acc./dec. times.

S2: Suitable for medium acc./dec. times.

S3: Suitable for long acc./dec. times.


S-curve ramps are ideal for conveyors carrying fragile loads, or other applications where a smooth transition is required when changing from one speed to another.



Acceleration and deceleration ramps are set with parameter group 22, *Ramp Functions*. For further details see *Appendix K - Signal and Parameter Table*.

Critical Speed There is a Critical Speed function available for applications where it is necessary to avoid certain motor speeds or speed bands, for example due to mechanical resonance problems. The ACS 1000 makes it possible to set up five different speed settings or speed bands which will be avoided during operation.

Each critical speed setting allows the user to define a low and a high speed limit. If the speed reference signal requires the ACS 1000 to operate within this speed range the *Critical Speeds* function will keep the ACS 1000 operating at the low (or high) limit until the reference is out of the critical speed range. The motor is accelerated/decelerated through the critical speed band according to the acceleration or deceleration ramp.



Critical speed areas are set with parameter group 34, *Critical Speed*. For further details see *Appendix K - Signal and Parameter Table*.

Resonance Frequency Damping (RFD)

In some processes steady state operation at a critical shaft speed cannot be avoided. Likewise, solving the problem through mechanical redesign is usually an expensive and time consuming solution. In such cases Resonance Frequency Damping (RFD) may be used to minimize or eliminate the mechanical resonance.

The user can select whether RFD is enabled. If selected, the speed error is used as input to a resonance damping filter and the user must enter the filter parameter values:

- Resonance Frequency - the mechanical resonance frequency that needs to be eliminated
- Phase Shift - the phase shift between the resonance frequency present and the cancellation signal generated (typically somewhat less than 180°)
- Proportional Gain - the proportional gain which is used in generating the cancellation signal.

Resonance frequency damping is set with parameters 26.2 to 26.5 in group 26, *Torque Reference Handling*. For further details see *Appendix K - Signal and Parameter Table*.

Once parameters have been entered, operation of the resonance frequency damping function is automatic.

Constant Speeds

In the ACS 1000 it is possible to predefine up to 15 constant speeds. Constant speeds are selected with digital inputs. Constant speed activation overrides the external speed reference.


Constant speed values are set with parameter group 33, *Constant Speed*. If the sequential control application macro is used, a standard set of parameter values is selected automatically. For further details see *Appendix K - Signal and Parameter Table*.

Speed Controller Tuning

During the motor identification run the ACS 1000 speed controller is automatically tuned. However, after the ID run, it is possible to manually adjust the controller gain, integration time and derivation action time, if desired. In the enhanced ID run, the motor is driven through a series of movements and the speed controller is tuned based on the load and inertia of the motor and the machine.

Speed controller parameters are set with parameter group 24, *speed control* (if the factory application macro is used, a standard set of parameter values is selected automatically). For further details see *Chapter 4 - I/O Interfaces and Application Macros, Application Macros, page 4- 11* and *Appendix K - Signal and Parameter Table*.

Figure 3-10 Examples of speed response at a speed reference step (typically, 1..20%). Speed step response can be seen by monitoring the actual SPEED signal.



- A : Normally tuned speed controller, autotuning (undercompensated)
- B : Critically compensated speed controller
- C : Optimally tuned speed controller, manual tuning. Better dynamic performance than with A or B
- D : Overcompensated speed controller

Accurate Speed Control

The static speed control error is typically $\pm 0.1\%$ of motor nominal speed, which satisfies most industrial applications. If even more precise speed regulation is required, a pulse encoder can be connected. With a pulse encoder, the static speed control error is typically $\pm 0.01\%$ of motor nominal speed.

The dynamic speed control error is typically $\pm 0.4\%$ sec. at 100% load torque step without a pulse encoder or tachogenerator. With a pulse encoder, the dynamic speed control error is typically $\pm 0.1\%$ sec.

The pulse encoder is an optional device. If used, parameter 75.03 of group *Option Modules* must be activated. Parameters are set with group 50, *Speed Measurement*. For further details see *Appendix K - Signal and Parameter Table*.




Table 3-1 Typical performance figures for speed control, when Direct Torque Control is used.

Speed Control	ACS 1000 no Pulse Encoder	ACS 1000 with Pulse Encoder
Static speed error, [% of n_N]	$\pm 0.1\%$ (10 % of nominal slip)	$\pm 0.01\%$
Dynamic speed error (in % of nominal speed)	0.4 %/sec.*	0.1 %/sec.*


*Dynamic speed error depends on speed controller tuning.

Accurate Torque Control without Speed Feedback

The ACS 1000 can perform precise torque control without any speed feedback from the motor shaft. With torque rise time less than 10 ms at 100% torque reference step compared to over 100 milliseconds in frequency converters using sensorless flux vector control, the ACS 1000 is unbeatable.

By applying a torque reference instead of a speed reference, the ACS 1000 will maintain a specific motor torque value; the speed will adjust automatically to maintain the required torque.

Torque control parameters are set with parameter groups 25 and 26, *Torque Reference and Torque Ref Handling* (If the torque control macro is used, a standard set of parameter values is



selected automatically). For further details see *Chapter 4 - I/O Interfaces and Application Macros, Application Macros, page 4- 11 and Appendix K - Signal and Parameter Table.*

Table 3-2 Typical performance figures for torque control, when Direct Torque Control is used.

Torque Control	ACS 1000 no Pulse Encoder	ACS 1000 with Pulse Encoder
Linearity error	$\pm 4\%$ *	$\pm 3\%$
Repeatability error	$\pm 3\%$ *	$\pm 1\%$
Torque rise time	< 10 ms	< 10 ms

**When operated around zero frequency, the error may be bigger.*

Drive System Features

Main Circuit Breaker (MCB) Control

Closing the main circuit breaker shall be possible exclusively from the converter. This means that a closing request from customer side is forwarded to the ACS 1000 control software. Then the actual closing command is released from the converter to the MCB.

Pre-conditions for closing the main circuit breaker are:

- no protection trip is active and
- no emergency off is active and
- the grounding isolator is open and
- the input isolator (optional) is closed and
- the output isolator (optional) is closed and
- MCB must be in operating position (i.e. not in test position) and
- MCB must have been open for at least 5 seconds and
- no alarm which causes "start inhibit" is active

The signal from the converter to the main circuit breaker to close can be a continuous signal or a single pulse, which is reset upon receiving the status feedback MCB CLOSED from the switchgear. If this status feedback does not arrive after a preset time, the close order is reset and a MCB trip is initiated.

Conditions for opening the main circuit breaker are:

- A MCB open command has been given either from local or remote control or from the fieldbus adapter, or
- the emergency off is active (manually initiated or requested by the converter protection) which activates directly the MCB tripping coil.

The signal from the converter to the main circuit breaker to open is a single

pulse signal which is reset upon receiving the status feedback MCB OPEN from the switchgear. If this status feedback does not arrive after a preset time the signal MCB ORDER TRIP is initiated to open the MCB.


The MCB ORDER TRIP is activated when low signal, which directly activates the tripping coil of the MCB. Several external MCB trip commands can be integrated into this hardwired tripping loop (e.g. transformer and motor supervision relays, process trips, etc.).

MCB control functions are set with parameter 11.4 and parameter group 21, *Start/Stop/MCB Functions* (for control outputs), *Actual Signals* (for status inputs). For further details see the *Engineering Manual* and *Appendix K - Signal and Parameter Table*.


Local and Remote Control

The operation of the ACS 1000 is possible either by local or remote control.

The local control mode is set directly by pushing the LOC/REM push-button on the CDP 312 control panel. On the display this is indicated by an L (local control) as can be seen on the figure below.



Remote control is indicated by an empty field:



Local Control If the converter is switched to local control, local operation from the push-button on the converter front door and from the CDP 312 control panel is possible. In local operation mode no remote control command will be accepted.

Remote Control If the converter is switched to remote control, local operation from the push-button on the converter front door and from the CDP 312 control panel is not possible. Instead all commands like close/open main circuit breaker or start/stop are received through the remote control interface. The reference value for controlling the speed is given as an analog input signal.

Alternatively all remote control signals can be exchanged via a fieldbus interface (optional).

The switch-over from local to remote and vice versa can be disabled by setting the digital input "DISABLE LOCAL" (see *Chapter 4 - Customer*

Interfaces and Application Macros, Table 4-1).

Diagnostics

- Actual Signal Monitoring** 90 Actual Signals are available. The most significant ones are:
- ACS 1000 output frequency, current, voltage and power
 - Motor speed and torque
 - DC Link voltage
 - Active control location (Local / External 1 / External 2)
 - Reference values
 - ACS 1000 inverter air temperature
 - Operating time counter (h), kWh counter
 - Digital I/O and analog I/O status
 - PID controller actual values (if the PID Control Macro is selected)

Three signals can be displayed simultaneously on the control panel.

Ø L	1242	rpm	I
FREQ	55.00	Hz	
CURRENT	80	A	
POWER	55	%	

Actual signals to be displayed can be selected from parameter group1 to 5, *Actual Signals*. For further details see *Chapter 5 - Operation, Actual Signal Display, page 5- 15*.

Fault History The Fault History contains information on the forty most recent faults detected by the ACS 1000. Faults are displayed in words. For further details see *Chapter 5 - Operation, Fault History Display, page 5- 18*.

Programmable Digital Outputs Four programmable digital outputs are at the user's disposition. They can be used as floating change-over contacts. Each output can be selected via parameter setting: ready, running, fault, warning, motor stall, motor temperature alarm / trip, ACS 1000 temperature alarm / trip, reversed selected, external control selected, preset speed limits (2 pcs), intermediate circuit voltage limits, preset motor current limit, reference limits (2 pcs), loss of reference signal, ACS 1000 started, motor operating at reference speed, process PID controller actual value limits (low, high) etc.

By choosing the two optional boards IOEC 3 and IOEC 4, 12 additional digital outputs (6 on each board) are available.

For further details on output allocation refer to the *Engineering Manual*.

Programmable Analog Outputs ACS 1000 offers two programmable current outputs. Analog output signals can be inverted and filtered. The minimum level can be adjusted to 0 mA, 4 mA or 10 mA.

Depending on parameter selection, the analog output signals can represent motor speed, process speed (scaled motor speed), output frequency, output current, motor torque, motor power, DC bus voltage, output

voltage, application block output (the process PID controller output), the active reference, or reference deviation (difference between the reference and the actual value of the process PID controller).

Also, the output can be proportional to the process PID controller actual value of the ACS 1000. The process PID controller actual values can be scaled, inverted and filtered.

For further details on output allocation refer to the *Engineering Manual*.

Input Signal Source Selections and Signal Processing

Note: The ACS 1000 is a speed controlled device. If you need to convert frequency to speed use the following formula:

$$\text{SPEED(rpm)} = \frac{\text{FREQUENCY(Hz)}}{\text{NUMBER OF POLES}} \cdot 120$$

Pole pairs = 1, 2, 3,..

Number of poles = 2, 4, 6,...

Two Programmable Control Locations

The ACS 1000 (with no optional devices) can receive Start/Stop/Direction commands and reference from the integrated control panel or through digital and analog inputs.

It is possible to predefine two separate External Control Locations (EXT1 and EXT2) for both the Start/Stop/Direction commands and the reference signal. The active External Control Location can be changed via the control panel or via a digital input.

The control panel always overrides the other control signal sources when switched to local mode.

Control location functions are set with parameter groups 11, *Start/Stop/Direction/MCB Control* and 12, *Reference Select*. For further details see the *Engineering Manual* and *Appendix K - Signal and Parameter Table*.

Reference Signal Processing

The ACS 1000 can handle a variety of speed reference schemes in addition to the conventional analog input signal and control panel signals.

- The ACS 1000 reference can be given with two digital inputs: One digital input increases the speed, the other decreases it. The active reference is memorized by the control.
- The ACS 1000 can form a reference out of two analog input signals by using mathematical functions: Addition, Subtraction, Multiplication, Minimum selection, and Maximum selection.

It is possible to scale the external reference so that the signal minimum and maximum values correspond to a speed other than the nominal minimum and maximum speed limits.

Speed reference functions are set with parameter group 23, *Speed Ref.* For further details refer to the *Engineering Manual* and to *Appendix K - Signal and Parameter Table*.

Analog Input Processing


The ACS 1000 has two programmable analog inputs: voltage or current inputs (hardware selected). Each of these analog inputs can be processed by adjusting the signal min/max levels, the filtering time constant, and the signal inversion selection with software parameters.

The **minimum setting** of 0 mA (0 V), 4 mA (2 V) or the input tuning can be selected. The tuning function allows the ACS 1000 to read the actual value and define it as minimum signal level.

The **maximum setting** of 20 mA (10 V) or the input tuning can be selected. The tuning function allows the ACS 1000 to read the actual value and define it as maximum signal level.

The analog input signal **filtering time constant** is user-adjustable from 0.01..10 s with software parameters.

Figure 3-11 Analog input filtering time constant



With **inversion** activated, the minimum level of the analog input signal corresponds to the maximum reference and the maximum analog input signal corresponds to the minimum reference.

For further details on analog input allocation refer to the *Engineering Manual*.

Offset Calibration

Automatic offset calibration of analog inputs is possible. For offset calibration, signal cables must be disconnected first from the analog inputs. Analog inputs are calibrated by setting the appropriate parameters *Auto Offset Calib* (in parameter groups 15, 81 and 86).

Offset of the internal current and voltage measurement inputs will be calculated automatically if the grounding isolator is opened after de-energization of the converter.

Standard Protection Functions

The ACS 1000 offers six programmable fault functions and several other non-user adjustable preprogrammed protection functions.

Programmable Fault Functions

Motor Winding Temperature

The motor can be protected from overheating by activating the motor winding temperature supervision.

The calculation of the motor temperature is user adjustable. The temperature supervision is based either on a load curve or on a thermal constant set by the customer or given by the automatically integrated function. The load curve should be adjusted in case the ambient temperature exceeds 30 °C.

Alternatively the ACS 1000 offers as standard three analog inputs for motor winding temperature measurement. If this measurement is connected, the calculation model is disabled.

The values for alarm and trip levels must be set in either case.


Motor temperature protection is set with parameters 30.01 to 30.11 in group *Fault Functions*. For further details see *Engineering Manual* and *Appendix K - Signal and Parameter Table*.

Motor Stall

The ACS 1000 protects the motor if a stall condition is detected. The supervision limits for stall frequency (speed) and stall time can be set by the user. The user can also select whether the stall function is enabled and whether the drive responds with an alarm or a trip when a stall is detected.

The protection is activated if all of the following conditions are fulfilled simultaneously:

Figure 3-12 Stall region of the motor.



- 1 The output frequency is below the set stall frequency
- 2 The drive is in torque limit. The torque limit level can be set by the user. The torque limit level is a basic setup parameter that sets maximum drive output torque. Although it indirectly effects operation of the motor stall protection, it should not be considered a motor stall parameter.
- 3 The frequency and torque levels from conditions 1 and 2 have been present for a period longer than the set stall time.

Motor stall protection is set with parameters 30.12 to 30.14 in group *Fault Functions*. For further details see *Engineering Manual* and *Appendix K - Signal and Parameter Table*.

Underload Loss of motor load may indicate a process malfunction. ACS 1000 provides an underload function to protect the machinery and process in such a serious fault condition. This supervision function checks whether the motor load is above the specified load curve. 5 different load curves can be selected by the customer.


Supervision limits: underload curve and underload time can be chosen as well as the drive response to the underload condition (alarm / trip indication & stop the drive / no reaction).

The protection is activated if all the following conditions are fulfilled simultaneously:

- 1 The motor load is below the Underload curve selected by the user (five options, see *Figure 3-13*).
- 2 The motor load has been below the selected underload curve longer than the time set by the user (Underload time).

Underload protection is set with parameters 30.15 to 30.17 in group *fault functions*. For further details see *Engineering Manual* and *Appendix K - Signal and Parameter Table*.

Figure 3-13 Load curves for underload function



Overspeed Motor speed as determined by DTC is monitored. If motor speed exceeds the maximum permitted motor speed (user adjustable) a trip is initiated. In addition, an input for connection of an external motor overspeed trip is available. A converter trip is also initiated if the external motor overspeed trip is activated (signal active when low).

For further details refer to the *Engineering Manual*.

Undervoltage In order to detect a loss of the net supply, the levels of the positive and negative DC link voltage levels are supervised. If these voltage levels drop below 70% of their nominal levels an undervoltage alarm is initiated and

power loss ride through is activated (provided it is selected). If the DC link voltage levels drop below 65% of their nominal levels an undervoltage trip is initiated.

For further details refer to the *Engineering Manual*.

Preprogrammed Protection Functions

- Motor Phase Loss*** The phase loss function monitors the status of the motor cable connections. The function is useful especially during motor starting: the ACS 1000 detects if any of the motor phases are not connected and refuses to start.
- The phase loss function also supervises the motor connection status during normal operation. The motor operating frequency must be above a minimum level in order for this feature to function. Should a motor phase loss be detected a trip is initiated.
- Overvoltage*** The levels of the positive and negative DC link voltage are supervised to detect whether an improper overvoltage condition develops. If these voltage levels rise above 130% of their nominal levels an overvoltage trip is initiated. On rare occasions, a combination of conditions can result in the motor entering a self excitation mode that can cause the DC link voltage to continue to rise despite the fact that a trip has been implemented. If this condition occurs and if the DC link voltage levels rise above 135% of their nominal levels, a second overvoltage trip is initiated that causes the inner 6 IGCT's to be gated simultaneously such that the motor windings are effectively shunted together. This eliminates the self excitation voltage that is causing the DC link voltage levels to rise. To provide ultimate reliability the second overvoltage trip is implemented both in software and redundantly in hardware (140%).
- Short Circuit in the Rectifier Bridge*** A short circuit in the rectifier bridge is detected by supervising the DC link voltage. If a short circuit is detected a trip is initiated and the drive is disconnected from the supply voltage (MCB opening time ≤ 100 ms).
- Charging Fault*** The intermediate DC link voltage is supervised while charging. If the voltage does not reach a certain level after a pre-set time a trip will be initiated.
- Supply Phase Loss*** If the voltage ripple in the intermediate dc link rises above a pre-set level, a supply phase may be lost. A trip is initiated.
- Overcurrent*** The overcurrent trip limit for the ACS 1000 is 2.2 times the nominal inverter rms current. If this level is exceeded a trip is initiated.
- Loadability of the Inverter*** In order to insure that the inverter section does not exceed normal temperature limits, the current load of the inverter is supervised. If a current/time overload is detected a trip is initiated.

<i>Short Circuit of the Inverter</i>	The inverter is monitored to insure that a short circuit condition does not exist. If a short circuit is detected a trip is initiated.
<i>Ground Fault</i>	The ground current in the output filter circuit is monitored. If it exceeds a certain level, a trip is initiated.
<i>Operating System</i>	The operating system of the microprocessor board supervises different functions within the control software and will initiate a trip if a malfunction is detected. Such faults are displayed as "Control SW fault". Should one of these faults be initiated during operation, the system should be restarted.
<i>Measurement Loss</i>	<p>In order to guarantee proper operation of the protection functions included in the converter, all communications between the control boards are checked cyclically.</p> <p>On the ADCVI board (analog digital conversion for voltage and current) analog signals are converted into digital signals. The digital signals are then transmitted via PPCC (fiber-optic bus system) to the interface board which is the main interface to the converter control.</p> <p>On the interface board the status of the communication is supervised. If a fault is sensed a trip is initiated.</p>
<i>Battery Test</i>	In order to guarantee correct fault indications and proper trip sequencing in the event that the auxiliary power source feeding the drive is lost, the ACS 1000 is equipped with a battery to supply redundant DC control power. While the converter is in operation the charge on the battery is checked periodically by applying a known load and measuring the resulting voltage drop. If the battery is determined to be deficient in its ability to supply power, a fault message is displayed and either a normal stop or an alarm is initiated. Normal stop is initiated if the self excitation speed of the motor is lower than nominal speed. An alarm is set if the self excitation speed is higher than nominal speed. This is determined automatically during the ID run. Default value (if no ID run has been done) is normal stop.
<i>Communication Fault</i>	Except for the measurement boards all communication links are realized by DDCS (Distributed Drive Control System). If one of these links is missing a trip is initiated.
<i>ID-Run Fault</i>	<p>An identification run is done during commissioning. The commissioning engineer enters nominal data for the identification of the system parameters. If the data has not been entered correctly and therefore the system parameters cannot be determined, a trip is initiated.</p> <p>In this case the entered data needs to be corrected and the identification run has to be repeated.</p>

Other Protection Functions

- External Motor Protection Trip** If the customer uses an external motor protection relay it can be connected to a pre-defined protection input of the ACS 1000. The motor protection input is integrated into the tripping loop by a normally closed (NC) contact.
- External motor protection is set with parameter group 35, *External Motor protection*. For further details see *Chapter 4 - I/O Interfaces and Application Macros, Standard I/O Boards, page 4- 1* and *Appendix K - Signal and Parameter Table*.
- External Transformer Protection Trip** If the customer uses an external transformer protection relay it can be connected to a pre-defined protection input of the ACS 1000. The transformer protection input is integrated into the tripping loop by a normally closed (NC) contact.
- External transformer protection is set with parameter group 35, *External Trafo Protection*. For further details see *Chapter 4 - I/O Interfaces and Application Macros, Standard I/O Boards, page 4- 1* and *Appendix K - Signal and Parameter Table*.
- Process Stop** A *process stop* button or relay can be connected to a pre-defined input of the ACS 1000. The actual *process stop* input must be normally closed during normal running. If the *process stop* input opens the drive control initiates a stop order. The type of stop (torque limit, ramp, or coast) is parameter selectable.
- Process stop is set with parameter 16.01 in group *System Ctr Inputs* and parameters 21.03 and 21.04 in group *Start/stop Functions*. For further details see *Chapter 4 - I/O Interfaces and Application Macros, Standard I/O Boards, page 4- 1* and *Appendix K - Signal and Parameter Table*.
- External Emergency Off** If the customer wants to use an External Emergency Off button it can be connected to a pre-defined protection input of the ACS 1000. The External Emergency Off input is integrated into the tripping loop by a normally closed (NC) contact.
- For further details see *Chapter 4 - I/O Interfaces and Application Macros, Standard I/O Boards, page 4- 1*.
- MCB Control Fault** All opening and closing commands to the main circuit breaker (MCB) are supervised for time-out. If the MCB does not change its status within a pre-set time the MCB trip loop (signal active when low) is activated.
- MCB time-out supervision is set with parameters 21.08 and 21.09 in group *Start/stop Functions*. For further details see *Appendix K - Signal and Parameter Table*.

Other Features

- Limits** The ACS 1000 offers adjustable limits for speed, current (max.) and

torque (max.) and protects itself against overvoltage.

For further details see *Engineering Manual* and *Appendix K - Signal and Parameter Table*.

Automatic Reset The ACS 1000 can automatically reset itself after an undervoltage. A user selectable parameter determines whether this feature is implemented. When the feature is activated, fault reset occurs within a few milliseconds after the fault is cleared. The fault has no effect on the drive or process operation; however, it is annunciated as a fault on the drive's panel.

Automatic reset can be used in case of DC undervoltage detection.

A reset counter tracks the number of automatic resets that occur within a set time window. If an excessive number of automatic resets occur within this time window, a system fault trip is initiated and drive operation ceases.

Automatic reset is selected with parameter group 31, *Automatic Reset*. For further details see *Appendix K - Signal and Parameter Table*.

Supervision Programmable supervision is a unique feature of the ACS 1000 which allows the drive to monitor certain user selectable signals. A trigger level can be defined for each signal.

For example, the user may set two speed limits, one current limit, two torque limits, two reference limits and two actual value limits. The digital status of the active limit appears on the control panel display and can also be supervised through relay outputs.

Supervision parameters are set with parameter group 32, *Supervision*. For further details see *Appendix K - Signal and Parameter Table*.

ACS 1000 Information The ACS 1000 software version, test date, and serial number can be displayed.


Information data are stored in parameter group 6, *Information*. For further details see *Appendix K - Signal and Parameter Table*.

Parameter Lock The user can prevent unwanted parameter adjustment by activating the Parameter Lock.

Parameter Lock is set with parameters 16.02 and 16.03 in group *System Ctr Inputs*. For further details see *Appendix K - Signal and Parameter Table*.

Built-in PID Controller There is a built-in process PID Controller in the ACS 1000. The controller can be used to control process variables such as pressure, flow, or fluid level.

Instead of applying a speed reference to the ACS 1000, a process reference (setpoint) is applied via an analog input or the keypad. An actual value (process feedback) is brought back to the ACS 1000 through one of the analog inputs.



The internal PID controller of the ACS 1000 eliminates the need to provide, mount, and wire a separate PID controller.

PID controller data are set in parameter group 40, *PID Control*. Parameter group 40 can only be accessed if the PID control macro is used. A standard set of parameter values is selected automatically in this case. For further details see *Chapter 4 - I/O Interfaces and Application Macros, PID Macro, page 4- 21* and *Appendix K - Signal and Parameter Table*.

Resonance Frequency Damping (RFD) Mechanical resonance frequencies within the system can be damped by means of an integrated algorithm of the control software.

If this function is enabled the control software produces a cancellation signal at the resonance frequency which minimizes or eliminates the mechanical resonance.

See also *Resonance Frequency Damping (RFD), page 3- 15*.

Customer Specific Options Information on additional user specific options that are implemented in your ACS 1000 can be found in *Appendix C - Customer Specific Options*.

PC Tools

DriveWindow *DriveWindow* is an advanced, yet easy-to-use tool for commissioning and control of your ACS 1000. *DriveWindow* consists of several independent parts: the User Interface, the Target Drivers, and the Communication Drivers. With this component structure, enhanced flexibility is achieved to enable working with several different types of products through different target and communication drivers. The look and feel of the *DriveWindow* program remains the same even when the product changes.

DriveLink *DriveLink* is the perfect tool for connecting the ACS 1000 with PC-based monitoring systems such as Intouch[®] and Genesis[®] etc. *DriveLink* is designed to serve as a dynamic data exchange (DDE) tool between the

Target Driver and most of the DDE supporting Windows applications such as MS Excel. The *DriveLink* does not need any other ABB tool to perform its actions.

The *DriveLink* consists of several independent parts: the User Interface, the Target Driver, and the Communication Driver. With this component structure, enhanced flexibility is achieved to enable working with several different types of products through different target and communication drivers. The look and feel of the *DriveLink* program remains the same even when the product changes.

DriveSupport The *DriveSupport* is a multimedia-based diagnostics tool which identifies faults and warnings based on the signal values from the converter. It provides expert knowledge for troubleshooting and servicing of the converter. Actual pictures and step-by-step replacement procedures are available within the tool.

The *DriveSupport* is fully configurable for ABB drive products and/or projects. The user language can be customized, and special faults and warnings can be added based on experience.

In addition, the *DriveSupport* keeps a record of all service activities that have been performed on any part of the converter since start-up. Spare part numbers and contract information can be added to the tool.

The *DriveSupport* works on-line together with the *DriveWindow* tool.

Chapter 4 - I/O Interfaces and Application Macros

Overview

In this chapter information on I/O boards, macro-specific I/O configurations and application macros is given. Typical applications for each macro are listed as well.

Information regarding other customer interfaces can be found in:

- *Chapter 10 - Installation* on connection of mains, motor and auxiliary power and in case of a water-cooled ACS 1000 on cooling water supply
- the *Fieldbus Control Adapter Start-up Manual* on fieldbuses (i.e. Modbus, Profibus...)
- the *Synchronized Bypass Installation and Start-Up Manual*
- the *Braking Chopper Installation and Start-up Manual*

It is recommended to have the wiring diagrams at hand when reading this chapter (see *Appendix G - Wiring Diagrams*).

Terms and Abbreviations

The following terms and abbreviations are used in this chapter:

I/O:	Input/Output
DI:	Digital Input
DO:	Digital Output
AI:	Analog Input
AO:	Analog Output
MCB:	Main Circuit Breaker

If a reference is made to an I/O, for instance DI 2.1, '2' refers to the board (in this case IOEC 2) and '1' refers to the 1st. digital input of the same board.

Input/Output Boards

Standard I/O Boards

The air-cooled ACS 1000 is equipped with IOEC 1 and IOEC 2 as a standard and the water-cooled ACS 1000 is fitted with IOEC 1, IOEC 2 and IOEC 3 as a standard.

Optionally IOEC 3 and/or IOEC 4 can be added to the air-cooled ACS 1000 and IOEC 4 to the water-cooled ACS 1000. When an optional IOEC board is installed in the drive the corresponding manual is attached in *Appendix C - Customer Specific Options*.

Each board provides the following number of I/Os:

Digital Inputs: 14

Digital Outputs: 6
Analog Inputs: 4
Analog Outputs: 2

IOEC 1 is mainly used for internal control signals and the I/Os cannot be accessed by the customer, except for the following:

- DI 1.8 Disable Local, accessible via terminal block X301
- AI 1.1 Ref Value 2, accessible via terminal block X301
- AO 1.1 programmable analog output
- AO 1.2 programmable analog output

If an output of an I/O board is not predefined for a standard function, a macro or an option, the output can be assigned to a binary status signal of the ACS 1000 by setting the corresponding parameter(s) accordingly. In general all I/Os marked 'PROGRAMMABLE' can be used.

Digital inputs marked 'FREE' in the wiring diagrams cannot be programmed by parameters.

I/O Ratings All analog and digital I/Os are floating, galvanically isolated with the following ratings:

Analog Input: 0..20 mA / 4..20 mA or 0..10 V / 2..10 V, scalable by DIP switches
Analog Output: 0..20 mA / 4..20 mA, scalable by parameter
Digital Input: Opto-coupled, rated for 22..250 VAC or 22..150 VDC
Digital Output: two-way contact , rated for 250 VAC, 4 A.

Control Voltage Output All IOEC boards have a built in DC control voltage output which can be used for digital input signals.

Voltage: 24 VDC +15%/-10%
Max. load current: 180 mA
If a higher load current is required, the terminals of two I/O boards have to be connected in parallel
Terminals: X13/9: + 24 VDC
X13/10: 0 V

Potentiometer Supply There is a 10 VDC supply on each IOEC board.

The 10 VDC supply on IOEC 1 can be used for an external setpoint potentiometer which is wired to AI 1.1 (reference value 2).

A potentiometer connected to AI 2.1 (reference value 1) can be supplied by the 10 VDC output of IOEC 2.


The 10 VDC supply is available at:

Terminals: X31/1: + 10 VDC
X32/1: 0 V

Digital Output Home Position A digital output is shown in its home position, provided it is not inverted, as illustrated in *Figure 4-1*:

- When signal *READY* is not active contact X21/1-2 is closed.
- When signal *READY* is active contact X21/2-3 is closed.

Figure 4-1 Digital output home position: example IOEC 2, DO 2.1.



External Connections The default I/O configuration of IOEC 1, IOEC 2, IOEC 3 and IOEC 4 can be seen from the corresponding wiring diagrams in *Appendix G - Wiring Diagrams*. The wiring diagrams show the terminals for all inputs and outputs together with the corresponding signal name.

All contacts are shown in their home (de-energized) position.


The default I/O configuration of IOEC 2 depends on the selected application macro. Refer to paragraph *Application Macros, page 4- 11*.

Location of IOEC Boards The IOEC boards are installed in the control section of the ACS 1000, as shown in *Figure 4-2*.

IOEC 1 is located in the center area of the swing frame. The terminal block X301 which is connected to DI 1.8 DISABLE LOCAL and AI 1.1 REFERENCE VALUE 2 is fitted on the right hand side of the control section.

IOEC 2, IOEC 3 and IOEC 4 are located on the right hand side of the control section. The terminals on the IOEC boards are accessible when the swing frame is open.

Figure 4-2 Location of IOEC Boards



Pre-defined I/O Signals In Table 4-1 to Table 4-6 all predefined I/O signals are listed in functional groups. I/Os of the standard IOEC boards are marked with a dot (●).

Table 4-1 Signals: Remote Control Interface

I/O Signal	Terminals	Remarks	Standard	Signal Inversion
DI 2.1 STANDARD INPUT 1	IOEC 2 X11/1-2	Macro specific I/O	●	not possible
DI 2.2 STANDARD INPUT 2	IOEC 2 X11/3-4	Macro specific I/O	●	not possible
DI 2.3 STANDARD INPUT 3	IOEC 2 X11/5-6	Macro specific I/O	●	not possible
DI 2.4 STANDARD INPUT 4	IOEC 2 X11/7-8	Macro specific I/O	●	not possible
DI 2.5 STANDARD INPUT 5	IOEC 2 X11/9-10	Macro specific I/O	●	not possible
DI 2.6 STANDARD INPUT 6	IOEC 2 X12/1-2	Macro specific I/O	●	not possible
DI 1.8 DISABLE LOCAL	X301 X1-2	External signal which disables local operation via control panel CDP 312	●	not possible
DI 2.7 REM ORD MCB CLOSE	IOEC 2 X12/3-4	External closing command for the main circuit breaker	●	not possible
DI 2.13 REM ORD MCB OPEN	IOEC 2 X13/5-6	External opening command for the main circuit breaker	●	not possible
DI 2.12 REMOTE RESET	IOEC 2 X13/3-4	External signal for fault reset (only certain faults can be reset from remote)	●	not possible
DO 2.1 DRIVE READY	IOEC 2 X21/1-3	Digital output indicating drive is ready for operation (i.e. MCB is closed, DC link is charged, no interlocks are active)	●	possible
DO 2.2 DRIVE RUNNING	IOEC 2 X22/1-3	Digital output indicating drive is running	●	possible
DO 2.3 DRIVE ALARM	IOEC 2 X23/1-3	Digital output indicating an alarm has come up	●	possible
DO 2.4 DRIVE TRIP	IOEC 2 X24/1-3	Digital output indicating drive has tripped	●	possible
DO 3.2 LOCAL MODE	IOEC 3 X22/1-3	Digital output indicating drive is in local mode, control panel CDP312 is in command	¹ ●	possible

Table 4-1 Signals: Remote Control Interface (Continued)

I/O Signal	Terminals	Remarks	Standard	Signal Inversion
AI 2.1 REF VALUE 1	IOEC 2 X31/2-X32/2	Macro specific I/O	●	possible
AI 1.1 REF VALUE 2	X301 X4-5	Macro specific I/O	●	possible
AO 1.1 MOTOR FREQUENCY	IOEC 1 X31/6-X32/6	Default setting: Actual value of motor frequency AO is programmable	●	possible
AO 1.2 MOTOR TORQUE	IOEC 2 X31/7-X32/7	Default setting: Actual value of motor torque AO is programmable	●	possible
AO 2.1 SHAFT SPEED	IOEC 2 X31/6-X32/6	Default setting: Actual value of motor speed AO is programmable	●	possible
AO 2.2 MOT TORQUE FILTERED	IOEC 2 X31/7-X32/7	Default setting: Actual value of filtered motor torque AO is programmable	●	possible

1. Standard only in water-cooled ACS 1000

Table 4-2 I/O Signals: Main Circuit Breaker

I/O Signal	Terminals	Remarks	Standard	Signal Inversion
DI 2.10 MCB IS CLOSED	IOEC 2 X12/9-10	Digital input indicating the main circuit breaker is closed	●	not possible
DI 2.9 MCB IS OPEN	IOEC 2 X12/7-8	Digital input indicating the main circuit breaker is open	●	not possible
DI 2.11 MCB IS AVAILABLE	IOEC 2 X13/1-2	Digital input indicating the main circuit breaker is not faulty, drawn-out or in test position	●	possible
DO 2.6 MCB ORD CLOSE	IOEC 2 X26/1-3	Digital output to close the main circuit breaker, pulse or maintained signal	●	see par. 21.05
DO 2.5 /MCB ORD OPEN	IOEC 2 X25/1-3	Digital output to open the main circuit breaker, pulse or maintained signal	●	see par. 21.05
DO 1.6 /MCB ORD TRIP	X300 X12	Digital output wired to tripping loop, trips the main circuit breaker when low,	●	not possible

Table 4-3 I/O Signals: Transformer (TRAFO)

I/O Signal	Terminals	Remarks	Standard	Signal Inversion
DI 1.13 /EXT TRAFO PROT TRIP	X300 X4-5	External signal from a transformer protection device, signal active when low, wired to tripping loop, in case of trip: - alarm is displayed - main circuit breaker is tripped	●	not possible
DI 3.1 OIL LEVEL ALARM	IOEC 3 X11/1-2	External signal for alarm indication of transformer oil level	1 ●	possible
DI 3.2 TRAFO TEMP ALARM	IOEC 3 X11/3-4	External signal for alarm indication of transformer oil or winding temperature	1 ●	possible
DI 3.3 /TRAFO TEMP TRIP	IOEC 3 X11/5-6	External signal from a transformer oil or winding temperature monitor, trips the drive	1 ●	not possible
DI 3.4 BUCHHOLZ ALARM	IOEC 3 X11/7-8	Signal from Buchholz relay for alarm indication	1 ●	possible
DI 3.5 /BUCHHOLZ TRIP	IOEC 3 X11/9-10	Signal from Buchholz relay, trips the drive	1 ●	not possible
AI 3.1 TRAFO TEMP	IOEC 3 X31/2-X32/2	Signal from transformer oil or winding temperature monitor for alarm indication, drive reaction is set in parameter group 36	1 ●	possible

1. Standard only in water-cooled ACS 1000

Table 4-4 I/O Signals: Motor

I/O Signal	Terminals	Remarks	Standard	Signal Inversion
DI 1.14 /EXT MOT PROT TRIP	X300 X6-7	External signal from a motor protection device, wired to tripping loop, signal active when low, in case of trip: - alarm is displayed - main circuit breaker is tripped	●	not possible
DI 3.11 EXT MOT PROT ALARM	IOEC 3 X13/1-2	External signal from a motor protection device for alarm indication	1 ●	possible
DI 3.6 MOT COOLING ALARM	IOEC 3 X12/1-2	External signal from motor cooling for alarm indication	1 ●	possible
DI 3.7 /MOT COOLING TRIP	IOEC 3 X12/3-4	External signal from motor cooling, trips the drive	1 ●	not possible
DI 3.8 VIBRATION SV ALARM	IOEC 3 X12/5-6	External signal from a motor vibration monitor for alarm indication	1 ●	possible
DI 3.9 /VIBRATION SV TRIP	IOEC 3 X12/7-8	External signal from a motor vibration monitor, trips the drive	1 ●	not possible
DI 3.10 /OVERSPEED TRIP	X300 X8-9	External signal from a motor over-speed monitor, signal is active when low, wired to tripping loop, in case of trip: - alarm is displayed - main circuit breaker is tripped	1 ●	not possible
AI 2.2 MOT WDG TEMP PH U	wired to PT 100 converter, see Wiring Diagram	External signal from a PT100 motor winding temperature sensor in phase U, drive reaction is set in parameter group 30	●	possible
AI 2.3 MOT WDG TEMP PH V	wired to PT 100 converter, see Wiring Diagram	External signal from a PT100 motor winding temperature sensor in phase V, drive reaction is set in parameter group 30	●	possible
AI 2.4 MOT WDG TEMP PH W	wired to PT 100 converter, see Wiring Diagram	External signal from a PT100 motor winding temperature sensor in phase W, drive reaction is set in parameter group 30	●	possible

Table 4-4 I/O Signals: Motor (Continued)

I/O Signal	Terminals	Remarks	Standard	Signal Inversion
AI 3.2 BRG TEMP DE	wired to PT 100 converter, see Wiring Diagram	External signal from a PT100 motor bearing temperature sensor at the driven end, drive reaction is set in parameter group 35	1 ●	possible
AI 3.3 BRG TEMP NDE	wired to PT 100 converter, see Wiring Diagram	External signal from a PT100 motor bearing temperature sensor at the non-driven end, drive reaction is set in parameter group 35	1 ●	possible

1. Standard only in water-cooled ACS 1000

Table 4-5 I/O Signals: Process

I/O Signal	Terminals	Remarks	Standard	Signal Inversion
DI 2.8 /PROCESS STOP	IOEC 2 X12/5-6	External process stop signal (or run enable), signal is active when low drive reaction is set in parameter group 21	●	not possible
DI 1.5 /INT/EXT EMERGENCY OFF	X300 X2-3	External emergency off signal, signal is active when low, wired to tripping loop, in case of emergency off: - alarm is displayed - main circuit breaker is tripped	●	not possible

Table 4-6 I/O Signals: Others

I/O Signal	Terminal	Remarks	Standard	Signal Inversion
DI 3.13 /SUPPL VOLT UNBAL- ANCE	X300 X10-11	External signal from a supply voltage relay, signal is active when low, wired to tripping loop, in case of trip: - alarm is indicated - main circuit breaker is tripped	1 ●	not possible
DI 4.1 EXT WTR COOLING ALARM	IOEC 4 X11/1-2	External signal from a cooling water monitor for alarm indication		possible
DI 4.2 /EXT WTR COOLING TRIP	IOEC 4 X11/3-4	External signal from a cooling water monitor indicating a trip, signal is active when low in case of trip: - alarm is displayed - drive is tripped		not possible
DI 4.3 BRAKE CHOP FAN PUMP ALARM	IOEC 4 X11/5-6	External signal from a cooling fan or pump for braking resistors indicating a alarm, signal is active when low		not possible
DI 4.4 BRAKE CHOP TEMP ALARM	IOEC 4 X11/7-8	External signal from a temperature monitor for braking resistors indicating an alarm, signal is active when low		not possible
DI 4.5 OUTPUT ISOL IS OPEN	IOEC 4 X11/9-10	External signal indicating the output isolator is open		not possible
DI 4.6 OUTPUT ISOL IS CLOSED	IOEC 4 X12/1-2	External signal indicating the output isolator is closed		not possible
DI 4.7 INPUT ISOL IS OPEN	IOEC 4 X12/3-4	External signal indicating the input isolator is open		not possible
DI 4.8 INPUT ISOL IS CLOSED	IOEC 4 X12/5-6	External signal indicating the input isolator is closed		not possible
AI 3.4 OUTSIDE AIR TEMP	IOEC 3 X31/5-X32/5	External actual value of an outside air temperature, drive reaction is set in parameter group 37	1 ●	possible

1. Standard only in water-cooled ACS 1000

Application Macros

Overview An application macro is a pre-programmed control software with specifically adapted parameter sets. Depending on the process, the appropriate macro can be selected thus enabling a quick and easy start-up of the ACS 1000.

All application macros have factory-set parameter values. These default values can be left unchanged or they can be set individually according to the needs by the ABB commissioning engineer. Ask the local ABB service organization if more information is required.

The ACS 1000 can be operated using one of the following macros:

- Factory
- Speed Control
- Hand/Auto
- PID Control
- Sequential Control
- Torque Control
- Master/Follower
- User 1
- User 2

There are six digital inputs on IOEC board 2 marked STANDARD INPUT which are assigned to the application macros. See *Table 4-1, I/O Signals: Remote control interface*. The function of each digital input can change depending on the macro.

If I/Os are used which are not located on IOEC board 2 a reference to the corresponding board is made.

Besides the standard and the macro specific I/Os, various optional I/Os may be defined depending on the converter configuration. Refer to *Appendix C - Customer Specific Options* for more details.

All other customer interface signals are the same for each application macro. See also section *Standard I/O Boards, page 4- 1*.

Macro Applications

Factory The Factory Macro is the **default-set macro**. It covers most of the common applications such as pumps, fans, conveyors and other industrial applications where constant speed is required.

Speed Control The Speed Control Macro can be used for the same applications as the Factory Macro. The only difference to the Factory Macro is that the motor control parameters of the ACS 1000 will not be overwritten and set to 0 when the macro is activated.

- Hand/Auto* The Hand/Auto Macro is suitable for applications where the speed has to be controlled automatically by a process automation system and manually by an external control panel. The active control station is selected via a digital input.
- The macro is also recommendable when two external control stations exist from where the reference value can be set and the drive can be started and stopped. The active control station for the reference value is selected via a digital input.
- PID Control* The PID Macro is intended for the use with closed loop control systems such as pressure control, level control and flow control. For example:
- Booster pumps of municipal water supply systems
 - Automatic level control of water reservoirs
 - Booster pumps of district heating systems
 - Speed control of different types of material handling systems where the material flow has to be regulated.
- Torque Control* The Torque Control Macro is set up for processes requiring torque control, e.g. mixers and slave drives. The torque reference comes from a process automation system or a control panel.
- Sequential Control* The Sequential Control Macro is typically used in processes requiring different constant speed settings and/or different acceleration/deceleration settings in addition to an adjustable speed reference value. Up to seven constant speed settings and two acceleration/deceleration settings are possible. The selection of the different settings can be automatized by a process control system or can be made manually by selector switches which are connected to the corresponding digital inputs.
- Master/Follower* The Master/Follower Macro is designed for applications with several ACS1000 drives where the motor shafts are coupled to each other by gearing, chain, belt etc. Thanks to the Master/Follower macro the load can be evenly distributed between the drives or at some adjustable other ratio which depends on the process.
- User 1/User 2* Each of these two macros allows to save a complete customized parameter set and to recall it at a later instant.

Factory Macro

Description All drive commands and reference settings can be given from the CDP 312 control panel or from an external control station.


The control station is selected with the **LOC REM** key on the control panel. The control panel can be disabled by closing DI 1.8. The digital input can be accessed via terminals X301:1 and X301:2.

In remote control the following default signal interface applies:

- The reference value is connected to AI 2.1.
- The start/stop command is wired to DI 2.1.
- The sense of rotation can be changed with DI 2.2. The default setting is FORWARD. It can be changed to REVERSE either by setting parameter 11.03 to REVERSE or via DI 2.2 if parameter 11.03 has been set to REQUEST before.
- Three constant speeds can be selected via DI 2.5 and DI 2.6 when the drive is in remote control.
- Two preset acceleration/deceleration ramps can be selected via DI 2.4.

When the Factory Macro is active the drive is speed controlled.

Control Overview Figure 4-3 Factory Macro, Control Overview



1 L -> 600.0 rpm 1
 Status Running
 MotSpeed 600.00 rpm
 MotCurr 75.0 %

Reference value, start/stop and direction commands are given from the control panel. To change to EXTERNAL, press **LOC REM** key.

1 -> 600.0 rpm 1
 Status Running
 MotSpeed 600.00 rpm
 MotCurr 75.0 %

Reference value is read from analog input AI 2.1. Start/stop and direction commands are given through digital inputs DI 2.1 and DI 2.2.

Input and Output Signals The default I/O signals of the Factory Macro regarding opening/closing the MCB, starting/stopping the drive, speed, control location, reference and actual values are shown in the following table. The corresponding parameters are listed as well. For further settings refer to *Appendix K - Signal and Parameter Table*.


Table 4-7 Factory Macro, I/O Signals

Digital Inputs/Outputs	Terminal	Parameter	Remarks															
DI 2.1 START/STOP	IOEC 2 X11/1-2	11.01	1 = start 0 = stop															
DI 2.2 DIRECTION	IOEC 2 X11/3-4	11.01	0 = forward 1 = reverse															
DI 2.4 ACCEL/DECELERATION RAMP 1/2	IOEC 2 X11/7-8	22.01	0 = accel / decel ramp 1 selected 1 = accel / decel ramp 2 selected															
DI 2.5 CONST SPEED SEL 1	IOEC 2 X11/9-10	33.01	<table border="1"> <thead> <tr> <th>Sel1</th> <th>Sel2</th> <th>Selection</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>Analog Ref.</td> </tr> <tr> <td>1</td> <td>0</td> <td>Const. Speed 1</td> </tr> <tr> <td>0</td> <td>1</td> <td>Const. Speed 2</td> </tr> <tr> <td>1</td> <td>1</td> <td>Const. Speed 3</td> </tr> </tbody> </table>	Sel1	Sel2	Selection	0	0	Analog Ref.	1	0	Const. Speed 1	0	1	Const. Speed 2	1	1	Const. Speed 3
Sel1	Sel2	Selection																
0	0	Analog Ref.																
1	0	Const. Speed 1																
0	1	Const. Speed 2																
1	1	Const. Speed 3																
DI 2.6 CONST SPEED SEL 2	IOEC 2 X12/1-2	33.01	<table border="1"> <thead> <tr> <th>Sel1</th> <th>Sel2</th> <th>Selection</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>Analog Ref.</td> </tr> <tr> <td>1</td> <td>0</td> <td>Const. Speed 1</td> </tr> <tr> <td>0</td> <td>1</td> <td>Const. Speed 2</td> </tr> <tr> <td>1</td> <td>1</td> <td>Const. Speed 3</td> </tr> </tbody> </table>	Sel1	Sel2	Selection	0	0	Analog Ref.	1	0	Const. Speed 1	0	1	Const. Speed 2	1	1	Const. Speed 3
Sel1	Sel2	Selection																
0	0	Analog Ref.																
1	0	Const. Speed 1																
0	1	Const. Speed 2																
1	1	Const. Speed 3																
DI 1.8 DISABLE LOCAL	X301 X1-2	-	0 = control panel is enabled 1 = control panel is disabled															
DI 2.8 /PROCESS STOP	IOEC 2 X12/5-6	16.01	Process stop or run enable 0 = drive will not start or stop if running															
DI 2.7 REMOTE ORD MCB CLOSE	IOEC 2 X12/3-4	11.04	pulse -> 1 = command for closing the main circuit breaker															
DI 2.13 REMOTE ORD MCB OPEN	IOEC 2 X13/5-6	11.04	pulse -> 1 = command for opening the main circuit breaker															
DI 2.9 MCB IS OPEN	IOEC 2 X12/7-8	21.06	Feedback from MCB 0 = MCB is open 1 = MCB is closed															
DO 2.5 /MCB ORD OPEN	IOEC 2 X25/2-3	21.05	Command to open the MCB pulse -> 0 = MCB is opened															
DO 2.6 MCB ORD CLOSE	IOEC 2 X26/2-3	21.05	Command to close the MCB pulse -> 1 = MCB is closed															

Analog Inputs/Outputs	Terminal	Parameter.	Remarks
AI 2.1 EXTERNAL SPEED REF- ERENCE 1	IOEC 2 X31/2-X32/2	-	Remote speed reference, if "Const Speed Sel 1" & "Const Speed Sel 2" are set to "0"
AO 1.1 MOTOR FREQUENCY	IOEC 1 X31/6-X32/6	15.01	Actual value of motor fre- quency
AO 1.2 MOTOR TORQUE	IOEC 2 X31/7-X32/7	15.06	Actual value of motor torque
AO 2.1 MOTOR SPEED	IOEC 2 X31/6-X32/6	15.11	Motor speed actual value (4...20 mA)
AO 2.2 MOT TORQUE FILTERED	IOEC 2 X31/7-X32/7	15.16	Actual value of filtered motor torque (4...20 mA)

Control Signal Diagram The control signal diagram of the Factory Macro in *Figure 4-4* shows how the control signals i.e. reference value, starting/stopping commands, MCB opening/closing commands are interconnected in the application software of the ACS 1000.

Figure 4-4 Control Signal Diagram of Factory Macro



* for further settings see Signal and Parameter Table

Hand/Auto Macro

Description Start/stop commands and reference settings can be given from the control panel of the ACS 1000 or from one of two external control stations, EXT1 (Hand) or EXT2 (Auto) (see *Figure 4-5*).

The **LOC REM** key on the control panel is used to enable the control panel or the external control stations. The control panel can be disabled by closing DI 1.8. The digital input can be accessed via terminals X301:1 and X301:2.

The remote control station EXT1 or EXT2 is selected with DI 2.5.

The control signals of EXT1 (Hand) for starting and stopping are connected to DI 2.1. Open/close commands for the MCB are wired to DI 2.13 and DI 2.7. The reference value is connected to AI 2.1. The speed reference value is given in rpm.


The commands from EXT 2 (Auto) for starting and stopping are connected to DI 2.2 and for opening/closing the MCB to DI 2.3 and DI 2.4. The reference value is connected to AI 1.1. The analog input on IOEC 1 is accessible through terminals X301:3 and 4. The speed reference value is given as a percentage of the maximum speed of the drive (see parameters 12.7 and 12.8).

One constant speed can be selected through DI 2.6.

The drive is speed controlled when the Hand/Auto Macro is selected.

By default, the direction is fixed to FORWARD (see parameter 11.03).

Control Overview Figure 4-5 Hand/Auto Macro, Control Overview



Input and Output Signals The default I/O signals of the Hand/Auto Macro regarding opening/closing the MCB, starting/stopping the drive, speed, control location, reference and actual values are shown in the following table. The corresponding parameters are listed as well. For further settings refer to *Appendix K - Signal and Parameter Table*.


Table 4-8 Hand/Auto Macro, I/O Signals

Digital Inputs/Outputs	Terminal	Parameter	Remarks
DI 2.1 START/STOP HAND	IOEC 2 X11/1-2	11.01	1 = start 0 = stop
DI 2.6 START/STOP AUTO	IOEC 2 X12/1-2	11.02	1 = start 0 = stop
DI 2.7 REMOTE ORD MCB CLOSE HAND	IOEC 2 X12/3-4	11.04	1 = request for closing the main circuit breaker
DI 2.13 REMOTE ORD MCB OPEN HAND	IOEC 2 X13/5-6	11.04	1 = request for opening the main circuit breaker
DI 2.3 REMOTE ORD MCB CLOSE AUTO	IOEC 2 X11/5-6	11.05	pulse -> 1 = command for clos- ing the main circuit breaker
DI 2.4 REMOTE ORD MCB OPEN AUTO	IOEC 2 X11/7-8	11.05	pulse -> 1 = command for open- ing the main circuit breaker
DI 2.5 EXT1/EXT2 SELECTION	IOEC 2 X11/9-10	12.02	0 = hand selected 1 = auto selected
DI 2.2 CONSTANT SPEED 1	IOEC 2 X11/3-4	33.01	If set to "1" a predefined constant speed reference is selected
DI 1.8 DISABLE LOCAL	X301 X1-2	-	0 = control panel is enabled 1 = control panel is disabled
DI 2.8 /PROCESS STOP	IOEC 2 X12/5-6	16.01	Process stop or run enable 0 = drive will not start or stop if running
DI 2.9 MCB IS OPEN	IOEC 2 X12/7-8	21.06	Feedback from MCB 0 = MCB is open 1 = MCB is closed
DO 2.5 /MCB ORD OPEN	IOEC 2 X25/2-3	21.05	Command to open the MCB pulse -> 0 = MCB open 1
DO 2.6 MCB ORD CLOSE	IOEC 2 X26/2-3	21.05	Command to close the MCB pulse -> 1 = MCB close

Analog Inputs/Outputs	Terminal	Parameter	Remarks
AI 2.1 REFERENCE 1 HAND	IOEC 2 X31/2-X32/2	-	External reference 1 in rpm
AI 1.1 REFERENCE 2 AUTO	X301: X3-X4	-	External reference 2 in %
AO 1.1 MOTOR FREQUENCY	IOEC 1 X31/6-X32/6	15.01	Motor frequency actual value (4...20 mA)
AO 1.2 MOTOR TORQUE	IOEC 1 X31/7-X32/7	15.06	Motor torque actual value (4...20 mA)
AO 2.1 MOTOR SPEED	IOEC 2 X31/6-X32/6	15.11	Motor speed actual value (4...20 mA)
AO 2.2 MOT TORQUE FILTERED	IOEC 2 X31/7-X32/7	15.16	Actual value of filtered motor torque (4...20 mA)

Control Signal Logic The control signal diagram of the Hand/Auto Macro in *Figure 4-6* shows how the control signals i.e. reference value, starting/stopping commands, MCB opening/closing commands are interconnected in the application software of the ACS 1000.

Figure 4-6 Control Signal Diagram of Hand/Auto Macro



* for further settings see Signal and Parameter Table

PID Macro

Description The PID Macro allows to control a process variable - such as pressure or flow - by adjusting the speed of the motor accordingly.

Start/stop commands and reference settings can be given from the control panel of the ACS 1000 or from an external control station.

The **LOC REM** key on the control panel is used to enable the control panel or the external control station. The control panel can be disabled by closing DI 1.8. The digital input can be accessed via terminals X301:1 and X301:2.

Parameter group 40 provides the necessary settings for the PID Macro.

The PID Macro requires IOEC board 4.

The process reference value is connected to AI 1.1. The customer terminals for AI 1.1 are available on terminal block X301.


Two process feedback signals can be used. Actual value 1 is connected to AI 4.1 and actual value 2 to AI 4.2. Parameter 40.06 provides the settings regarding the number of feedback signals and their interconnection.

If the PID controller is part of a higher-level control system and the speed of the motor is to be controlled directly, the speed reference value has to be wired to AI 2.1.

The internal PID controller is bypassed if external control station EXT1 is selected (DI 2.3 is open). Then the ACS 1000 no longer controls the process variable but the speed of the motor directly.

Default actual signals shown on the control panel are MOTOR SPEED, ACTUAL VALUE1 and CONTROL DEVIATION.

Control Overview Figure 4-7 PID Macro, Control Overview



0 L	1242.0 rpm	I
MotSpeed	1242.0 rpm	
Actual Value1	52.00 %	
CtrlDev	0.1 %	

Reference value, start/stop and direction commands are given from the control panel. To change to EXTERNAL, press the **LOC REM** key.

0	52.1 %	I
MotSpeed	1242.0 rpm	
Actual Value1	52.0 %	
CtrlDev	0.1 %	

Reference is read from analog input AI 1.1. Start/stop command is given through DI 2.1 when in direct speed control (EXT1) or through digital input DI 2.6 when in Process Control (EXT2).

Input and Output Signals The default I/O signals of the PID Macro regarding opening/closing the MCB, starting/stopping the drive, speed, control location, reference and actual values are shown in the following table. The corresponding parameters are listed as well. For further settings refer to *Appendix K - Signal and Parameter Table*.


Table 4-9 PID Macro, I/O Signals

Digital Inputs/Outputs	Terminal	Parameter	Remarks															
DI 2.1 START/STOP	IOEC 2 X11/1-2	11.01	1 = start 0 = stop															
DI 2.2 DIRECTION	IOEC 2 X11/3-4	11.01	0 = forward 1 = reverse															
DI 2.3 EXT 1/2 SELECTION	IOEC 2 X11/5-6	12.02	Selection of external reference 0 = EXT 1 1 = EXT 2															
DI 2.4 ACCEL/DECELERATION RAMP 1/2	IOEC 2 X11/7-8	22.01	0 = accel / decel ramp 1 selected 1 = accel / decel ramp 2 selected															
DI 2.5 CONST SPEED SEL 1	IOEC 2 X11/9-10	33.01	<table border="1"> <thead> <tr> <th>Sel1</th> <th>Sel2</th> <th>Selection</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>Analog Ref.</td> </tr> <tr> <td>1</td> <td>0</td> <td>Const. Speed 1</td> </tr> <tr> <td>0</td> <td>1</td> <td>Const. Speed 2</td> </tr> <tr> <td>1</td> <td>1</td> <td>Const. Speed 3</td> </tr> </tbody> </table>	Sel1	Sel2	Selection	0	0	Analog Ref.	1	0	Const. Speed 1	0	1	Const. Speed 2	1	1	Const. Speed 3
Sel1	Sel2	Selection																
0	0	Analog Ref.																
1	0	Const. Speed 1																
0	1	Const. Speed 2																
1	1	Const. Speed 3																
DI 2.6 CONST SPEED SEL 2	IOEC 2 X12/1-2	33.01	<table border="1"> <thead> <tr> <th>Sel1</th> <th>Sel2</th> <th>Selection</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>Analog Ref.</td> </tr> <tr> <td>1</td> <td>0</td> <td>Const. Speed 1</td> </tr> <tr> <td>0</td> <td>1</td> <td>Const. Speed 2</td> </tr> <tr> <td>1</td> <td>1</td> <td>Const. Speed 3</td> </tr> </tbody> </table>	Sel1	Sel2	Selection	0	0	Analog Ref.	1	0	Const. Speed 1	0	1	Const. Speed 2	1	1	Const. Speed 3
Sel1	Sel2	Selection																
0	0	Analog Ref.																
1	0	Const. Speed 1																
0	1	Const. Speed 2																
1	1	Const. Speed 3																
DI 1.8 DISABLE LOCAL	X301 X1-2	-	0 = control panel is enabled 1 = control panel is disabled															
DI 2.8 /PROCESS STOP	IOEC 2 X12/5-6	16.01	Process stop or run enable 0 = drive will not start or stop if running															
DI 2.7 REMOTE ORD MCB CLOSE	IOEC 2 X12/3-4	11.04	pulse -> 1 = command for closing the main circuit breaker															
DI 2.13 REMOTE ORD MCB OPEN	IOEC 2 X13/5-6	11.04	pulse -> 1 = command for opening the main circuit breaker															
DI 2.9 MCB IS OPEN	IOEC 2 X12/7-8	21.06	Feedback from MCB 0 = MCB is open 1 = MCB is closed															
DO 2.5 /MCB ORD OPEN	IOEC 2 X25/2-3	21.05	Command to open the MCB pulse -> 0 = MCB open															
DO 2.6 MCB ORD CLOSE	IOEC 2 X26/2-3	21.05	Command to close the MCB pulse -> 1 = MCB close															

Analog Inputs/Outputs	Terminal	Parameter	Remarks
AI 2.1 ANALOG REFERENCE	IOEC 2 X31/2-X32/2	-	External reference
AI 4.1 ACTUAL VALUE	IOEC 4 X31/2-X32/2	-	Process feedback
AI 4.2 ACTUAL VALUE	IOEC 4 X31/3-X32/3	-	Process feedback
AO 1.1 MOTOR FREQUENCY	IOEC 1 X31/6-X32/6	15.01	Motor frequency actual value (4...20 mA)
AO 1.2 MOTOR TORQUE	IOEC 1 X31/7-X32/7	15.06	Motor torque actual value (4...20 mA)
AO 2.1 MOTOR SPEED	IOEC 2 X31/6-X32/6	15.11	Motor speed actual value (4...20 mA)
AO 2.2 MOT TORQUE FILTERED	IOEC 2 X31/7-X32/7	15.16	Actual value of filtered motor torque (4...20 mA)

Control Signal Diagram The control signal diagram of the PID Macro in *Figure 4-8* shows how the control signals i.e. reference value, starting/stopping commands, MCB opening/closing commands are interconnected in the application software of the ACS 1000.

Figure 4-8 Control Signal Diagram of PID Control Macro



* for further settings see Signal and Parameter Table

Torque Macro

Description The Torque Control Macro is used in applications requiring torque control of the motor. The settings for torque reference and torque reference handling can be adjusted in parameter group 25 and 26 respectively.

The torque reference is given through AI 2.1 as a current signal. By default, 0 mA correspond to 0% and 20 mA to 100% of the rated motor torque.


The start and stop command is given through DI 2.1 and the sense of rotation is changed by means of DI 2.2.

Changing from torque control to speed control is achieved by setting DI 2.3 to low.

It is also possible to change the control location from external to local (i.e. to control panel) by pressing the **LOC REM** key. When LOCAL is selected on the control panel the drive is speed controlled by default. If torque control is required parameter 12.1 KEYPAD REF SELECT has to be changed to REF2 (%). The control panel can be disabled by closing DI 1.8. The digital input can be accessed via terminals X301:1 and X301:2.

Default settings for the display of the control panel are SPEED, TORQUE and CONTROL LOCATION.

Control Overview Figure 4-9 Torque Macro, Control Overview



External Control
 EXT1 (rpm) = Speed Control
 EXT2 (%) = Torque Control

0 L	1242.0 rpm	I
MotSpeed	1242.0 rpm	
MotTorq	66.00 %	
CtrlLoc	LOCAL	

Reference value, start, stop and direction commands are given from the control panel. To change to EXTERNAL press **LOC REM** key.

0	50.0 %	I
MotSpeed	1242.0 rpm	
MotTorq	66.00 %	
CtrlLoc	EXT2	

The reference value is read from AI 2.1 (if torque control is selected) or AI 1.1 (if speed control is selected). Start, stop and direction commands are given through DI 2.1 and DI 2.2. Selection between speed and torque control is done through DI 2.3.

Keypad Control
 REF1 (rpm) = Speed Control
 REF2 (%) = Torque Control

Input and Output Signals The default I/Os of the Torque Macro regarding opening/closing the MCB, starting/stopping the drive, speed, control location, reference and actual values are shown in the following table. The corresponding parameters are listed as well. For further settings refer to *Appendix K - Signal and Parameter Table*.


Table 4-10 Torque Macro, I/O Signals

Digital Inputs/Outputs	Terminal	Parameter	Remarks
DI 2.1 START/STOP	IOEC 2 X11/1-2	11.01	1 = start 0 = stop
DI 2.2 DIRECTION	IOEC 2 X11/3-4	11.01	0 = forward 1 = reverse
DI 2.3 EXT 1/2 SELECTION	IOEC 2 X11/5-6	12.02	0 = speed control 1 = torque control
DI 2.4 ACCEL/DECEL 1/2 SELECTION	IOEC 2 X11/7-8	22.01	0 = accel / decel ramp 1 selected 1 = accel / decel ramp 2 selected
DI 2.5 CONSTANT SPEED SELECTION	IOEC 2 X11/9-10	33.01	If set to "1" the predefined constant speed reference is selected
DI 1.8 DISABLE LOCAL	X301 X1-2	-	0 = control panel is enabled 1 = control panel is disabled
DI 2.8 /PROCESS STOP	IOEC 2 X12/5-6	16.01	Process stop or run enable 0 = drive will not start or stop if running
DI 2.7 REMOTE ORD MCB CLOSE	IOEC 2 X12/3-4	11.04	pulse -> 1 = command for closing the main circuit breaker
DI 2.13 REMOTE ORD MCB OPEN	IOEC 2 X13/5-6	11.04	pulse -> 1 = command for opening the main circuit breaker
DI 2.9 MCB IS OPEN	IOEC 2 X12/7-8	21.06	Feedback from MCB 0 = MCB is open 1 = MCB is closed
DO 2.5 /MCB ORD OPEN	IOEC 2 X25/2-3	21.05	Command to open the MCB pulse -> 0 = MCB open 1
DO 2.6 MCB ORD CLOSE	IOEC 2 X26/2-3	21.05	Command to close the MCB pulse -> 1 = MCB close

Analog Inputs/Outputs	Terminal	Parameter	Remarks
AI 1.1 SPEED REFERENCE	IOEC 1 X31/2-X32/2	-	Speed reference (EXT1)
AI 2.1 TORQUE REFERENCE	IOEC 2 X31/2-X32/2	-	Torque reference (EXT2)
AO 1.1 MOTOR FREQUENCY	IOEC 1 X31/6-X32/6	15.01	Motor frequency actual value (4...20 mA)
AO 1.2 MOTOR TORQUE	IOEC 1 X31/7-X32/7	15.06	Motor torque actual value (4...20 mA)
AO 2.1 MOTOR SPEED	IOEC 2 X31/6-X32/6	15.11	Motor speed actual value (4...20 mA)
AO 2.2 MOT TORQUE FILTERED	IOEC 2 X31/7-X32/7	15.16	Actual value of filtered motor torque (4...20 mA)

Control Signal Diagram The control signal diagram of the Torque Macro in *Figure 4-10* shows how the control signals i.e. reference value, starting/stopping commands, MCB opening/closing commands are interconnected in the application software of the ACS 1000.

Figure 4-10 Control Signal Diagram of Torque Control Macro



* for further settings see Signal and Parameter Table

Sequential Control Macro

Description The macro offers seven preset constant speeds which can be activated by DI 2.4, DI 2.5 and DI 2.6.

The parameters assigned for constant speed settings are in group 33.

Two preset acceleration/deceleration ramps are selectable via DI 2.3.


The start/stop command is connected to DI 2.1 and the sense of rotation can be changed via DI 2.2.

An external speed reference value can be wired to AI 2.1. It is active if DI 2.4, DI 2.5 and DI 2.6 are low.


Operational commands and reference value can also be given using the control panel if set to local. The control panel can be disabled by closing DI 1.8. The digital input can be accessed via terminals X301:1 and X301:2.

Default actual values shown on the Control Panel are FREQUENCY, CURRENT and POWER.

Control Overview Figure 4-11 Sequential Macro, Control Overview



External Control
 EXT1 (rpm) = Speed Control
 EXT2 (%) = Speed Control
 Keypad Control
 REF1 (rpm) = Speed Control
 REF2 (%) = Speed Control



Example of sequential control using constant speeds and different acceleration and deceleration times.

Input and Output Signals The default I/O signals of the Sequential Macro regarding opening/closing the MCB, starting/stopping the drive, speed, control location, reference and actual values are shown in the following table. The corresponding parameters are listed as well. For further settings refer to *Appendix K - Signal and Parameter Table*.

Table 4-11 Sequential Macro Macro, I/O Signals

Digital Inputs/Outputs	Terminal	Parameter	Remarks			
DI 2.1 START/STOP	IOEC 2 X11/1-2	11.01	1 = start 0 = stop			
DI 2.2 DIRECTION	IOEC 2 X11/3-4	11.01	0 = forward 1 = reverse			
DI 2.3 ACCEL/DECEL 1/2 SELECTION	IOEC 2 X11/5-6	22.01	0 = accel / decel ramp 1 selected 1 = accel / decel ramp 2 selected			
DI 2.4 CONST SPEED SEL 1	IOEC 2 X11/7-8	33.01	Sel1	Sel2	Sel3	Selection
DI 2.5 CONST SPEED SEL 2	IOEC 2 X11/9-10	33.01	0	0	0	Analog Ref.
			1	0	0	Const. Speed 1
			0	1	0	Const. Speed 2
DI 2.6 CONST SPEED SEL 3	IOEC 2 X12/1-2	33.01	1	1	0	Const. Speed 3
			0	0	1	Const. Speed 4
			1	0	1	Const. Speed 5
			0	1	1	Const. Speed 6
			1	1	1	Const. Speed 7
DI 1.8 DISABLE LOCAL	X301 X1-2	-	0 = control panel is enabled 1 = control panel is disabled			
DI 2.8 /PROCESS STOP	IOEC 2 X12/5-6	16.01	Process stop or run enable 0 = drive will not start or stop if running			
DI 2.7 REMOTE ORD MCB CLOSE	IOEC 2 X12/3-4	11.04	pulse -> 1 = command to close the main circuit breaker			
DI 2.13 REMOTE ORD MCB OPEN	IOEC 2 X13/5-6	11.04	pulse -> 1 = command to open the main circuit breaker			
DI 2.9 MCB IS OPEN	IOEC 2 X12/7-8	21.06	Feedback from MCB 0 = MCB is open 1 = MCB is closed			
DO 2.5 MCB ORD OPEN	IOEC 2 X26/2-3	21.05	Command to open the MCB pulse -> 0 = MCB open			


Table 4-11 Sequential Macro Macro, I/O Signals (Continued)

DO 2.6 MCB ORD CLOSE	IOEC 2 X26/2-3	21.05	Command to close the MCB pulse -> 1 = MCB close
-------------------------	-------------------	-------	---

Analog Inputs/Outputs	Terminal	Parameter	Remarks
AI 2.1 ANALOG REFERENCE	IOEC 2 X31/2-X32/2	-	External reference
AO 1.1 MOTOR FREQUENCY	IOEC 1 X31/6-X32/6	15.01	Motor frequency actual value (4...20 mA)
AO 1.2 MOTOR TORQUE	IOEC 1 X31/7-X32/7	15.06	Motor torque actual value (4...20 mA)
AO 2.1 SHAFT SPEED	IOEC 2 X31/6-X32/6	15.11	Shaft speed actual value (4...20 mA)
AO 2.2 MOT TORQUE FILTERED	IOEC 2 X31/7-X32/7	15.16	Actual value of filtered motor torque (4...20 mA)

Control Signal Diagram The control signal diagram of the Sequential Macro in *Figure 4-12* shows how the control signals i.e. reference value, starting/stopping commands, MCB opening/closing commands are interconnected in the application software of the ACS 1000.

Figure 4-12 Control Signal Diagram of Sequential Control Macro



* for further settings see Signal and Parameter Table

Master/Follower Macro

Description All drive commands and reference settings for a master follower drive configuration can be given from the control panel of the master drive or from an external control station connected to the master drive. The follower drive(s) receive(s) the control signals via a fibre-optic link from the master drive.



Connect all control signals to the master drive only.

Do not control the follower(s) with its(their) own control panel(s). Disable the control panels of all follower drive(s) by setting parameter 16.02 PARAMETER LOCK to LOCKED to prevent accidental use.

Do not control the follower through a fieldbus system.

Parameter settings and further information regarding the Master/Follower Macro can be found in *Appendix K - Signal and Parameter Table*, parameter group 70.


The active control station - control panel or external control station - is selected by the **LOC REM** key on the control panel of the master. The control panel can be disabled by closing DI 1.8. The digital input can be accessed via terminals X301:1 and X301:2.

In remote control the reference value is connected to AI 2.1, the start/stop command is wired to DI 2.1 and the sense of rotation can be changed with DI 2.2. The default setting for the sense of rotation (parameter 11.03) is FORWARD. It can be changed to REVERSE either by setting parameter 11.03 to REVERSE or via DI 2.2 if parameter 11.03 has been set to REQUEST before (master and follower).

Three constant speeds can be selected via DI 2.5 and DI 2.6 when the drive is in remote control.

Furthermore, the Master/Follower Macro offers two preset acceleration/ deceleration ramps which can be selected via DI 2.4.

Control Overview Figure 4-13 Master/Follower Macro, Control Overview



```

1 L -> 600.0 rpm 1
Status Running
MotSpeed 600.00 rpm
MotCurr 75.0 %
    
```

Reference value, start/stop and direction commands are given from the control panel. To change to EXTERNAL, press **LOC REM** key.

```

1 -> 600.0 rpm 1
Status Running
MotSpeed 600.00 rpm
MotCurr 75.0 %
    
```

The reference value is read from AI 2.1. Start/stop and direction commands are given through DI 2.1 and DI 2.2.

Input and Output Signals The default I/O signals of the Master/Follower Macro regarding opening/closing the MCB, starting/stopping the drive, speed, control location, reference and actual values are shown in the following table. The corresponding parameters are listed as well. For further settings refer to *Appendix K - Signal and Parameter Table*.


Table 4-12 Master/Follower Macro, I/O Signals

Digital Inputs/Outputs	Terminal	Parameter	Remarks															
DI 2.1 START/STOP	IOEC 2 X11/1-2	11.01	1 = start 0 = stop															
DI 2.2 DIRECTION	IOEC 2 X11/3-4	11.01	1 = forward 0 = reverse															
DI 2.4 ACCEL/DECELERATION RAMP 1/2	IOEC 2 X11/7-8	22.01	Selection of ramp time 0 = ramp time set 1 1 = ramp time set 2															
DI 2.5 CONST SPEED SEL 1	IOEC 2 X11/9-10	33.01	<table border="1"> <thead> <tr> <th>Sel1</th> <th>Sel2</th> <th>Selection</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>Analog Ref.</td> </tr> <tr> <td>1</td> <td>0</td> <td>Const. Speed 1</td> </tr> <tr> <td>0</td> <td>1</td> <td>Const. Speed 2</td> </tr> <tr> <td>1</td> <td>1</td> <td>Const. Speed 3</td> </tr> </tbody> </table>	Sel1	Sel2	Selection	0	0	Analog Ref.	1	0	Const. Speed 1	0	1	Const. Speed 2	1	1	Const. Speed 3
Sel1	Sel2	Selection																
0	0	Analog Ref.																
1	0	Const. Speed 1																
0	1	Const. Speed 2																
1	1	Const. Speed 3																
DI 2.6 CONST SPEED SEL 2	IOEC 2 X12/1-2	33.01	<table border="1"> <thead> <tr> <th>Sel1</th> <th>Sel2</th> <th>Selection</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>Analog Ref.</td> </tr> <tr> <td>1</td> <td>0</td> <td>Const. Speed 1</td> </tr> <tr> <td>0</td> <td>1</td> <td>Const. Speed 2</td> </tr> <tr> <td>1</td> <td>1</td> <td>Const. Speed 3</td> </tr> </tbody> </table>	Sel1	Sel2	Selection	0	0	Analog Ref.	1	0	Const. Speed 1	0	1	Const. Speed 2	1	1	Const. Speed 3
Sel1	Sel2	Selection																
0	0	Analog Ref.																
1	0	Const. Speed 1																
0	1	Const. Speed 2																
1	1	Const. Speed 3																
DI 1.8 DISABLE LOCAL	X301 X1-2	-	0 = control panel is enabled 1 = control panel is disabled															
DI 2.8 /PROCESS STOP	IOEC 2 X12/5-6	16.01	Process stop or run enable 0 = drive will not start or stop if running															
DI 2.7 REMOTE ORD MCB CLOSE	IOEC 2 X12/3-4	11.04	pulse -> 1 = command for closing the main circuit breaker															
DI 2.13 REMOTE ORD MCB OPEN	IOEC 2 X13/5-6	11.04	pulse -> 1 = command for opening the main circuit breaker															
DI 2.9 MCB IS OPEN	IOEC 2 X12/7-8	21.06	Feedback from MCB 0 = MCB is open 1 = MCB is closed															
DO 2.5 /MCB ORD OPEN	IOEC 2 X25/2-3	21.05	Command to open the MCB pulse -> 0 = MCB open 1															
DO 2.6 MCB ORD CLOSE	IOEC 2 X26/2-3	21.05	Command to close the MCB pulse -> 1 = MCB close															

Analog Inputs/Outputs	Terminal	Parameter	Remarks
AI 2.1 EXTERNAL SPEED REF- ERENCE 1	IOEC 2 X31/2-X32/2	-	Remote speed reference, if "Const Speed Sel 1" & "Const Speed Sel 2" are set to "0"
AO 1.1 MOTOR FREQUENCY	IOEC 1 X31/6-X32/6	15.01	Motor frequency actual value (4...20 mA)
AO 1.2 MOTOR TORQUE	IOEC 1 X31/7-X32/7	15.06	Motor torque actual value (4...20 mA)
AO 2.1 SHAFT SPEED	IOEC 2 X31/6-X32/6	15.11	Shaft speed actual value (4...20 mA)
AO 2.2 MOT TORQUE FILTERED	IOEC 2 X31/7-X32/7	15.16	Actual value of filtered motor torque (4...20 mA)


The control signal diagrams of the master (see *Figure 4-14*) and of the follower (see *Figure 4-15*) show how the control signals i.e. reference value, starting/stopping commands, MCB opening/closing commands are interconnected in the application software of the ACS 1000. Note that the follower receives all control signals via the fibre-optic link (channel 2, fast drive link) from the master.

Figure 4-14 Control Signal Diagram of Master



* for further settings see Signal and Parameter Table

Figure 4-15 Control Signal Diagram of Follower



* for further settings see Signal and Parameter Table


Chapter 5 - Operation

Safety Instructions

It is the owners responsibility to ensure that each person involved in the operation of the ACS 1000 has received the appropriate instructions and has thoroughly read and clearly understood the safety instructions in *Chapter 1 - Safety Instructions*.



Danger: Operation of this equipment may be dangerous if the safety instructions are not adhered to. See *Chapter 1 - Safety Instructions*.



Note: The manufacturer declines all responsibility for possible damages caused by unauthorized personnel.

Introduction

This chapter outlines the operation of the ACS 1000 when properly installed and commissioned. All regular operation steps are described in detail.

Getting the ACS 1000 ready to start involves the following steps:

- Preparatory procedures
- Closing the main circuit breaker and charging the capacitor bank. The unit is then ready to start
- Setpoint selection
- Run-up to pre-set operating point.

Conventions

In this chapter you will find step-by-step instructions of how to proceed when operating the ACS 1000.

All instructions which require actions from your side are numbered. You are requested to carry out these steps exactly in the prescribed sequence.

Any steps that require actions on the CDP 312 control panel or can be monitored on the display are complemented with a diagram indicating the keys to be activated on the control panel and the resulting information on the display.

Example:

Press Key


CDP 312 Display




- If there are several keys in the “Press Key” field you are requested to select one of them. Depending on your choice there might be different reactions.
- If the **UP/DOWN** keys are shown you can scroll using these keys alternately.
- Always keep keys pressed for some time (0.5-1 sec) in order to avoid misinterpretation.

Actual signals appear with their short name (8 characters) and their current value.

- 1 Press and hold the **ACT** key to view the full signal names.



- 2 Release the **ACT** key to return to normal display.



Start Operation of the ACS 1000

Preparatory Procedures

To prepare the ACS 1000 for operation take the following steps:



Danger: The cooling water system may start automatically as soon as the auxiliary voltage is switched on, even if the converter is de-energized.

Prerequisites

Check that all of the following prerequisites are met:

- 1 Installation and commissioning according to *Chapter 11 - Commissioning* is completed.
- 2 Auxiliary voltage is switched on.
- 3 All drive-specific start-up parameters according to *Chapter 6 - Parameter Viewing and Editing* are set and checked.



Warning: Running the motor and the driven equipment with incorrect start-up data can result in improper operation, reduction in control accuracy.

cy and damage to equipment.

4 Cooling water system is running (if applicable).

Preparatory Steps


5 Close all doors including the rear panel of the inverter section, the protective separation door and the control section front door.



Warning: All doors **including the control section front door** and the separation door behind the swing frame must be closed before energizing the unit. All fastening screws must be mounted and tightened in order to maintain EMC performance. The power section doors must be closed for safety reasons. The front doors are interlocked with the grounding isolator. The control section door must be closed to maintain EMC performance.


6 Open the grounding isolator located on the central section door of the converter.

Figure 5-1 Operating elements on front door



7 Check configuration of the mains circuit:

- input isolator is closed (if applicable)
 - output isolator is closed (if applicable).
- 8 Select local or remote control mode by pressing the **LOC REM** key on the CDP 312 control panel. Local control mode is indicated with a “L” in the first line of the display.



Local control mode can only be selected if it is not disabled with appropriate parameter setting and if the digital input *DISABLE LOCAL* is not active. For a detailed description of remote and local control please refer to the corresponding section in this chapter.

- 9 If control mode is set to **REMOTE** check that remote control is ready.

Closing Main Circuit Breaker


- 10 Check that MCB is in operating position (not drawn out or in test position).
- 11 Check that ACS 1000 is ready:
- No alarm or error message on CDP 312 control panel display
 - No emergency off is active.

If there is still an alarm pending, proceed as described in *Chapter 8 - Trouble Shooting & Repair* to eliminate the fault.

If the system is OK, the CDP 312 control panel displays **READY MCB ON.**



- 12 Clear the fault buffer on CDP 312 control panel (see section *Active Fault Display*, page 5- 17). No error message must be displayed.



Charging the Capacitor Bank


- 13 Switch on the ACS 1000:

- **In local control mode:** press the **MAIN CIRCUIT ONLINE** button on the control section door of the ACS 1000
- **In remote control mode:** automatically via external binary input *REM ORD ON-LINE*.

The CDP 312 control panel displays **CHARGING**.
The charging process lasts a few seconds.




- 14 The unit is now ready. The CDP 312 control panel displays **READY TO START**.




Entering Setpoint and Starting Up the ACS 1000

- In Local Control Mode** 15 To enter the setpoint press **REF** on the CDP 312 control panel.



- 16 Input setpoint (speed, torque, according to application macro requirements; see *Chapter 4 - I/O Interfaces and Application Macros*) by using the **UP/DOWN** keys.



The setpoint change will become active immediately.


- 17 Press a **MODE** key to exit setpoint mode.



- 18 Select the sense of rotation with the  or  key.




Warning: Many processes do not permit to reverse the sense of rotation. The sense of rotation can only be selected if not disabled by setting of parameter 11.3. Make sure that the parameter 11.3 *DIRECTION* is correctly set according to the process requirements (see *Chapter 6 - Parameter Viewing and Editing*).




On the display, the selected sense of rotation will be indicated with an arrow.

- 19 Start the unit by pressing the  key.

In the first place, magnetization takes place.



After a few seconds the motor is driven up to reference speed following a preset ramp.



In Remote Control Mode

- Remote setpoint transmission and remote start are initiated automatically via remote control inputs (see *Chapter 4 - I/O Interfaces and Application Macros, Input/Output Boards, page 4- 1*).

Changing Setpoints


Setpoint changes on the operating system can be made at any time from the active control location (local or remote control).

In Local Control Mode

- 1 Press **REF** on the CDP 312 control panel.




- Input setpoint (speed, torque, according to application macro requirements; see *Chapter 4 - I/O Interfaces and Application Macros, Input/Output Boards*, page 4- 1) by using the **UP/DOWN** keys.



The setpoint change will become active immediately.

- Press the **ACT** key to exit.



In Remote Control Mode

- Remote setpoints are transmitted as 4 - 20 mA signals or via fieldbus from remote control.


Reverse Sense of Rotation

In Local Control Mode

- Select the sense of rotation with the  or  key.



Warning: Many processes do not permit to reverse the sense of rotation. The sense of rotation can only be selected if not disabled by setting of parameter 11.3. Make sure that the parameter 11.3 *DIRECTION* is correctly set according to the process requirements (see *Chapter 6 - Parameter Viewing and Editing* and *Appendix K - Signal and Parameter Table*).



If the motor is running, the speed will automatically ramp to zero and the motor will reverse its sense of rotation and resume preset speed.

On the display, the sense of rotation will be indicated with an arrow:

- If the motor is running, the arrow indicates the actual

sense of rotation. Therefore, the indication will only reverse after the motor has reached zero speed.

- In case of stand-still, the arrow indicates the preselected sense of rotation.


In Remote Control Mode

- Remote change of sense of rotation is initiated automatically via remote control inputs (see *Chapter 4 - I/O Interfaces and Application Macros, Input/Output Boards, page 4- 1*).


Local / Remote Selection

Switching between local and remote control is possible without the need to stop the ACS 1000.

Local control mode is set directly by pushing the LOC/REM pushbutton on the CDP 312 control panel as described earlier in this chapter. On the display this is indicated by an L (local control) as you can see on the figure below.



Remote control is indicated by an empty field:




Local Control If the converter is switched to local, local operation from the pushbuttons on the converter front door and from the CDP 312 control panel is enabled. In local operation mode no remote control command will be accepted.

Remote Control If the converter is switched to remote, local operation from the pushbuttons on the converter front door (except for the emergency off button) and from the CDP 312 control panel is disabled. In remote control mode commands like close/open main circuit breaker or start/stop are initiated by binary inputs or via fieldbus. The reference value for controlling the speed is determined from an analog input signal or via fieldbus.

Changing Control Mode during Operation

- 1 If the control mode is to be set to remote, check that remote control is ready.
- 2 Select local or remote control mode by pressing the **LOC REM** key on the CDP 312 control panel. Local control mode is indicated with a

“L” in the first line of the display.



Local control mode can only be selected if it is not disabled with appropriate parameter setting and if the digital input “Disable local operation” is not active.

Remote -> Local Control

- The motor is not stopping.
- The speed is not changing (initial value for nref is the last actual speed) but can now be changed by the CDP 312 control panel.

Local -> Remote Control

- The motor is not stopping if the operational commands (MCB on/off and start/stop) of the remote system are correctly set.
- The speed is changing to the actual reference value of the analog input following the preset ramp.

Disabling Local Operation from CDP 312 Control Panel

If the parameter *DISABLE LOCAL* is set to "1" then a change from remote control to local control (via the **LOC/REM** pushbutton on the CDP 312 control panel on the converter front door) is not possible anymore. The converter has to remain in the remote control mode.

If the parameter *DISABLE LOCAL OPERATION* is set to “1” during local control, the drive remains in local operation until remote control is selected (via the **LOC/REM** pushbutton on the CDP 312 control panel on the converter front door).

Table 5-1 Binary input

Type	Signal Name	Terminal	Type	Remarks	Standard
DI	DISABLE LOCAL	IOEC 1 X12/5-6	high active	Remote input to disable the possibility for a local/remote switch-over from the CDP 312 Control Panel	●

Table 5-2 Binary outputs

Type	Signal Name	Terminal	Type	Remarks	Standard
RO	LOCAL MODE	IOEC 3 X22/1-3	high active	Local Mode Operation Status Indication, set to “1” in local mode	
RO	DRIVE READY	IOEC 2 X21/1-3	high active	Status Output “Drive Ready” (i.e. MCB closed, DC link charged, no lockout active)	●

Stopping the ACS 1000


Several stop modes including ramp and coast functions can be used for normal operational stop. The active stop mode is preset by adjusting the corresponding parameters.

One of the following stop mode is set with the parameters of group 21 *START-/STOP-/MCB FUNCTION*:

- *STOP RAMPING*: stop following a deceleration ramp with preset ramp time
- *COAST STOP*: torque is set to zero.


Please refer to *Chapter 6 - Parameter Viewing and Editing* for further information on how to set the stop mode and to display the active mode.

In Local Control Mode 1 Press the **STOP** key on the CDP 312 control panel.



The unit stops following the preset stop function. The main circuit breaker remains closed.

After standstill the display shows:



Note: You can always restart the unit by pressing the **START** key while the stopping sequence is still in progress.



Danger: Do not access the main power circuit nor the motor after an operational stop!

The capacitor of the intermediate DC-link is still charged. Prior to accessing the power circuit, disconnect the converter from mains power circuit and ground the system as described in section *De-energizing the ACS 1000*, page 5- 12.

In Remote Control Mode

In remote control mode, a stop is initiated when the STOP command is given by remote control.

The unit stops following the preset stop function. The main circuit breaker remains closed.



Danger: Do not access the main power circuit nor the motor after an operational stop!

The capacitor of the intermediate DC-link is still charged. Prior to accessing the power circuit, disconnect the converter from mains power circuit and ground the system as described in section *De-energizing the ACS 1000*, page 5- 12.

De-energizing the ACS 1000

In Local Control Mode

To disconnect the drive from main power supply, proceed as follows:

- 1 Stop the ACS 1000 by performing the steps described in the previous section.
- 2 Press the main circuit **OFFLINE** button on the control section door of the ACS 1000 (see *Figure 5-1*). The MCB will open.



Danger: Do not access the main power circuit nor the motor as long as the system is not grounded.


After switching off the mains and after the motor has come to a stop, always allow the intermediate circuit capacitors 5 minutes to discharge (yellow indicator **GND.- SWITCH UNLOCKED** must be on) before grounding and starting work on the frequency converter, the motor or the motor cable.

The ACS 1000 and adjoining equipment must be properly grounded prior to starting with any work.


The display shows:.



- 3 Wait (approx. 5 minutes) until the capacitors in the main circuit are discharged to a safe level and the yellow indicator **GND.- SWITCH UNLOCKED** on the control section door is on.



- 4 Close grounding isolator located on the central section door of the converter



The display shows:



- 5 Open input and output isolators (if applicable) and secure the MCB (by drawing it out or locking it).
- 6 The system is now dead and safe access is possible.



Danger: The cooling water system may start automatically even if the converter is de-energized. In order to shut down the cooling system, the auxiliary voltage has to be switched off.

In Remote Control Mode

In remote control mode, a stop is initiated when the corresponding remote order is given by external control (see *Chapter 4 - I/O Interfaces and Application Macros*).


Emergency Stop

Emergency stop is automatically initiated if the tripping loop is opened by any protection device, by remote signal or if the local **EMERGENCY OFF** button is pressed.

Manual Initiation

- 1 For an emergency stop press the red **EMERGENCY OFF** button on the control section door of the ACS 1000 (see *Figure 5-1*). The tripping loop opens, the converter will be stopped by coast stop and the MCB will be opened.

The display shows:



Danger: Do not access the main power circuit nor the motor as long as the system is not grounded.

After switching off the mains, always allow the intermediate circuit capacitors 5 minutes to discharge (yellow indicator **GND.- SWITCH UN-LOCKED** must be on) before grounding and starting work on the frequency converter, the motor or the motor cable.

The ACS 1000 and adjoining equipment must be properly grounded prior to starting with any work .

Process Monitoring

For process monitoring in actual signal display mode two displays can be selected on the CDP 312 control panel:

- the actual signal display
- and the
- fault history display.

Actual signal display mode is selected by pressing the **ACT** key.



When in actual signal display mode, the fast **UP/DOWN** keys allow to

toggle between actual signal display and fault history display.



Actual Signal Display Actual signals are used to monitor ACS 1000 functions and do not affect the performance of the drive. Actual signal values are measured or calculated internally and they cannot be set or altered by the user.

In the actual signal display mode the CDP 312 display continuously shows the actual values of three preselectable signals.

The actual signal display appears first when the actual signal display mode is selected. However, if the drive is in a fault condition, the fault display will be shown instead.

The panel will automatically return to actual signal display mode from other modes if no keys are pressed within one minute (exceptions: status display and common reference display in drive selection mode and fault display mode).

In the actual signal display mode you can monitor three actual signals at a time. Depending on the selected application macro, a default set of 3 signals will be displayed.

A complete list of selectable actual signals (parameter groups 1-9) can be found in *Appendix K - Signal and Parameter Table*.

Proceed as follows to change any of the displayed signals (can be done when system is running):


- 1 Enter the actual signal display mode by pressing **ACT** on the CDP 312 control panel.



- 2 Select a row by using the UP/DOWN keys (a blinking cursor indicates the selected row).




- 3 To activate the actual signal selection option press **ENTER**.




- 4 Select a parameter group using the fast **UP/DOWN** keys.

Please refer to *Appendix K - Signal and Parameter Table* for a list of all available signals (parameter groups 1 to 9).



- 5 Select a signal using the **UP/DOWN** keys.



- 6 To accept the selection and to return to the actual signal display Mode press **ENTER**.




To cancel the selection and keep the original selection, press any of the mode keys **without** pressing **ENTER**. The display will change to the selected Keypad Mode.



Full Signal Name Display Actual signals appear with their short name (8 characters) and their current value.


- 1 Press and hold the **ACT** key to view the full signal names:.




- 2 Release the **ACT** key to return to normal display.



Active Fault Display If a fault or an alarm is generated in the drive, it will be displayed immediately with a flashing text, except if you are in the drive selection mode:



- 1 You can always view any active fault by selecting the actual signal display mode.



- 2 To reset the fault press **RESET**.



After a reset , the fault message will not appear anymore in Actual Signal Display mode. However, the fault is still stored in the fault history and can be viewed there.

From the fault display, it is possible to switch to other displays without


resetting the fault. If no keys are pressed the fault or warning text is displayed as long as the fault exists.

Fault History Display

The fault history provides information on the 40 most recent faults that occurred in your ACS 1000. The name of the fault and the date and time of occurrence are displayed. For complete details on fault analysis please refer to *Chapter 8 - Trouble Shooting & Repair*.


Proceed as follows to view fault history:

- 1 Enter the actual signal display mode by pressing **ACT** on the CDP 312 control panel.




- 2 Select the fault history display with the fast **UP/DOWN** keys.

The most recent fault will be displayed together with the date and time of occurrence.




- 3 Select previous (**UP** key) or next fault (**DOWN** key).



Warning: Do not clear the fault history buffer before you completely clarified a possible error situation. Clearing of the buffer cannot be undone.

- 4 To clear the fault history press **RESET**.



The fault history buffer is now empty.

- 5 To return to the actual signal display mode press a fast **UP/DOWN** key.



Other Operational Actions


Panel and Display Functions

Several panel functions such as contrast of the display can be adjusted. For further information please refer to *Appendix B - The CDP 312 Control Panel*.

Chapter 6 - Parameter Viewing and Editing

Overview

This chapter contains the necessary instructions for checking application parameters as they are programmed in the ACS 1000. When starting the ACS 1000 for the first time after a modification in the driven system or in the control circuit, these application parameters should be checked and, if necessary, adapted.



Note: Parameters and application macros are normally set during commissioning of the process and should not need to be changed by the user afterwards, except if a modification in the system configuration requires to do so.

The start-up parameters form a special group of parameters that allow you to set up the basic ACS 1000 and motor information. Start-up parameters are normally set during commissioning of the driven motor and should not need to be changed afterwards.

Safety Instructions

It is the owners responsibility to ensure that only professionals with the appropriate education (i.e. electrical engineers or equivalent) are involved in the programming of the ACS 1000 parameter set and that each person has received the appropriate instructions and has thoroughly read and clearly understood the safety instructions in *Chapter 1 - Safety Instructions*.



Warning: Never change any parameters if you are not thoroughly familiar with the meaning of each parameter and with the consequences resulting from the modification.

Running the ACS 1000, the motor and the equipment being driven with incorrect data can result in improper operation, reduction in control accuracy and damage to equipment.

ACS 1000 Application Parameters

The control configuration and the application parameters of the ACS 1000 are programmable. Configuring the ACS 1000 includes basically the input of a set of parameters by the commissioning engineer. Some of these parameters are determined automatically by the control system (i.e. the motor characteristic by performing the motor ID run) and cannot be altered by the user.

Parameter Groups

In order to simplify programming, parameters in the ACS 1000 are organized in groups. Typical parameter groups are

- Start-up parameters
- Reference selection
- Analog / binary inputs or output definition parameters (all inputs and

outputs are programmable)

- Actual signals

A complete list of all parameters can be found in *Appendix K - Signal and Parameter Table*.

Start-up Parameters The start-up parameters form a special set of parameters defining the basic system characteristics, such as nominal mains voltage, rated current and other main data of the motor. They must be determined and entered individually for each drive.

Application Macros Application macros are preprogrammed parameter sets that are specially adapted to a specific application. Depending on the process, one can select one of these macros, thus enabling a quick and easy start-up of the ACS 1000.

With application macros, the number of different parameters to be set during start-up is minimized. All parameters have factory-set default values. Leaving them unchanged, a good system performance is obtained in typical situations. One can either use these default values or they can be optimized individually according to your needs (will be done by the ABB commissioning engineer). For more information please refer to *Chapter 4 - I/O Interfaces and Application Macros, Input/Output Boards, page 4- 1* and to the *ACS 1000 Engineering Manual* or ask your local ABB service organization.

Application Parameter Editing: Overview

As already mentioned, good performance is achieved in an typical application even if you leave the default settings unchanged. However, in order to optimize the ACS 1000 for your system configuration it is necessary to check whether the default settings match your requirements and to customize the settings where appropriate. Initially this is done by the ABB commissioning engineer in cooperation with the owner.

Especially if options are added, the corresponding parameters must be checked before start-up. A systematic guide for determining optimum parameter settings can be found in the *Engineering Manual*. The flowchart shown in *Figure 6-1* gives an overview on the complete parameter input procedure as it is carried out during commissioning.

In the remaining part of this chapter you will find detailed instructions of how to proceed when viewing and editing individual parameters in the control system of the ACS 1000.

Figure 6-1 Application parameter programming procedure




Figure 6-1 Application parameter programming procedure (continued)





Figure 6-1 Application parameter programming procedure (continued)



**Parameter Editing
with the CDP 312
Control Panel**

General In this chapter you will find step-by-step instructions of how to proceed when editing parameters of the ACS 1000. With these instructions you should be able to understand the programming procedure, to check the parameters of your system and to make minor adjustments that might be necessary when operating the ACS 1000. Major parameter readjustments should only be necessary in case of modifications in the driven system and must be prepared according to the instructions in the *Engineering Manual*.



Warning: Never change any parameters if you are not thoroughly familiar with the meaning of each parameter and with the consequences resulting from the modification.

Running the ACS 1000, the motor and the equipment being driven with incorrect data can result in improper operation, reduction in control accuracy and damage to equipment.

Conventions All instructions which require actions from your side are numbered. You are requested to carry out these steps exactly in the prescribed sequence.

Any steps that require actions on the CDP 312 control panel or that can be monitored on the display are complemented with a diagram indicating the keys to be activated on the control panel and the resulting information on the display.


Example:

Press Key

CDP 312 Display



- If there are several keys in the “Press Key” field you are requested to select one of them. Depending on your choice there might be different reactions.
- If the **UP/DOWN** keys are shown you can scroll using these keys alternately.
- Always keep keys pressed for some time (0.5-1 sec) in order to avoid misinterpretation.



Note: When you change the parameter values of a standard macro, the new settings will be stored into the Flash PROM of the ACS 1000. They become active immediately and stay active if the power of the ACS 1000 is switched off and on. However, the factory set default values of each standard macro are still available and they can be restored (see section *Restoring Default Settings*, page 6- 19).

Parameter group 99 is common to all standard macros. It comprises the start-up data, i. e. basic system parameters, information on display language and active application macro. A new setting replaces immediately the old setting in the permanent memory and the old settings cannot be restored.

Prerequisites

The following preconditions must be fulfilled in order to view or edit parameters:

- 1 Installation of the system according to *Chapter 10 - Installation* is completed.
- 2 All drive-specific parameters are known.
- 3 Control I/O-wiring is completed and tested.
- 4 Auxiliary voltage is switched on.
- 5 CDP 312 control panel is connected (Alternative: personal computer with "DriveWindow", please refer to the relevant manual).

Selection of Actual Signals

Actual signals are used to monitor ACS 1000 functions and do not affect the performance of the drive. Their values are measured or calculated internally and they cannot be set or altered by the user.

Actual signals can be selected by activating the corresponding parameters in groups 1 to 9. For detailed instructions on how to select and monitor actual signals please refer to *Chapter 5 - Operation, Actual Signal Display*, page 5- 15.

A complete list of the selectable actual signals can be found in *Appendix K - Signal and Parameter Table*.

Start-Up Parameters

The start-up parameters form a special set of parameters that allow you to set up the basic ACS 1000 and motor information. Start-up parameters are normally set during commissioning and should not need be changed afterwards.

Before the system can be started, the start-up parameter set must be entered.




Warning: Running the motor and the equipment being driven with incorrect data can result in improper operation, reduction in control accuracy and damage to equipment.

To access the start-up parameters proceed as follows:

- 1 Check that the main circuit breaker is open and the grounding isolator is closed.
- 2 Select the parameter mode by pressing the **PAR** key.

The parameter mode display appears, indicating the previously selected group and parameter.

When this mode is entered for the first time after power-up, the display will show the first parameter of the first group (parameter 11.1).




- 3 Select parameter group 99 using the fast **UP/DOWN** keys.



- 4 Select the first parameter to be entered (99.1 LANGUAGE) using the slow **UP/DOWN** keys

Please refer to *Table 6-1* with a list of the start-up parameters. A detailed description of each start-up parameter can be found in *Appendix K - Signal and Parameter Table*.



- 5 Press **ENTER** to access edit mode.




- 6 Change the parameter using fast (for numeric values only) and slow **UP/DOWN** keys.



- 7 Press **ENTER** to save the changed value.



Start-up parameters can be entered only if the ACS 1000 is de-energized. If this precondition is not fulfilled, the following message will appear:



To cancel the selection and keep the original value, press any of the mode keys **without** pressing **ENTER**. The display will change to the selected keypad mode.




- 8 Repeat steps 4 to 7 for parameters 99.2 to 99.11 and 99.13 to 99.15 according to *Table 6-1*.

Table 6-1 Group 99, start-up parameters

Parameter	Range/Unit	Description
1 LANGUAGE	Languages	Display language selection.
2 APPLICATION MACRO	Application macros	Application macro selection (see also next section).

Table 6-1 Group 99, start-up parameters (Continued)

Parameter	Range/Unit	Description
3 MOTOR NOM VOLTAGE	0-9000 V	nominal voltage from motor name plate
4 MOTOR NOM CURRENT	0-...A	Rated motor current
5 MOTOR NOM FREQ	8 - 200 Hz	Nominal frequency from motor name plate.
6 MOTOR NOM SPEED	1 ... 18000 rpm	Nominal speed from motor name plate.
7 MOTOR NOM POWER	0 ... 9000 kW	Nominal power from motor name plate.
8 MOTOR COS PHI	0.00 - 1.00	Nominal cos phi from motor name plate.
9 MOTOR INSULATION CLASS	1 ... 5	Motor insulation class from motor name plate (see <i>Appendix K - Signal and Parameter Table</i>)
10 MOTOR COOLING METHOD	1 ... 8	Type of motor cooling system (see <i>Appendix K - Signal and Parameter Table</i>)
11 ALTITUDE A.S.L.	0 ... 5000 m	Operating altitude above sea level
12 MOTOR ID RUN	NO; STANDARD; REDUCED	Selects the type of the motor identification run. Do not set now!
13 MOTOR CTRL MODE	DTC, SCALAR	Selects the motor control mode.
14 APPLIC RESTORE	NO; YES	Restores parameters to factory setting values.
15 DRIVE ID NUMBER	0 - 32767	Drive identification number



Note: Do **not** set parameter 99.12 MOTOR ID RUN (resp. make sure that this parameter is set to “NO”).

Specific instructions of how to use this parameter will follow later in this chapter (see section *Motor Identification Run*, page 6- 15).

Parameter 99.15 DRIVE ID NUMBER is optional.

- 9 To exit the parameter mode press any of the mode keys

or

to select another parameter group to continue with parameter input use the fast **UP/DOWN** keys.

Selection or Verification of Application Macro




Warning: Never change the application macro setting of a system which is already in operation if you do not have a very specific reason to do so.

Changing the application macro setting will affect the basic control structure of the ACS 1000 and the input/output-allocation on the IOEC 2 board. This can result in improper operation, loss of control and damage to equipment.


To view or select an application macro setting proceed as follows:

- 1 Select the parameter mode by pressing the **PAR** key.

The parameter mode display appears, indicating the previously selected group and parameter (when this mode is entered for the first time after power-up, the display will show the first parameter of the first group).



- 2 Select parameter group 99 using the fast **UP/DOWN** keys.



- 3 Select parameter 99.2 APPLICATION MACRO using the slow **UP/**

DOWN keys.




4 Press **ENTER**.




5 Select an application macro using the slow **UP/DOWN** keys.

Please refer to *Table 6-2* for a list of all available application macros.



6 Press **ENTER** to save your selection.



The new application macro with all its related parameter settings (default settings) is now active in the system.



Warning: Once you save the application macro selection – even if the same as before – the actual parameter settings will be overwritten by the default settings of the macro.

Consequently, some of your individual settings might get lost.

To cancel the selection and keep the original application macro, press any of the mode keys **without** pressing **ENTER**. The display will

change to the selected Keypad Mode.



7 To exit the parameter mode press any of the mode keys

or

to check and, if necessary, to modify the parameters proceed as described in section *Verification and Modification of Parameters*, page 6- 14.

Table 6-2 Application macro selection

Macro	Select
Factory	1 FACTORY
Hand/Auto	2 HAND/AUTO
PID Control	3 PID-CTRL
Torque Control	4 T-CTRL
Sequential Control	5 SEQ CTRL
Master/Follower	10 M/F CONTROL

Selection of Motor Control Features

Additional motor control features, such as

- acceleration and deceleration ramps
- power loss ride through
- critical speeds
- resonance frequency damping

can be activated and tuned by setting the appropriate parameters. To view or edit control parameters proceed as described in *Verification and Modification of Parameters*, page 6- 14.

Additional information for determining correct parameter settings can be found in *Chapter 3 - Design and Functional Description* and in the *Engineering Manual*.

Verification and Modification of Parameters

Proceed as follows to verify or to change parameters:

- 1 Before you start entering data, determine the required parameter settings for your application macro or other control features. Refer to *Chapter 3 - Design and Functional Description, Chapter 4 - I/O Interfaces and Application Macros* and to the *Engineering Manual*.


or, to verify the application macro settings

Refer to the parameter list in the appropriate application macro description. All parameters that should be verified according to your application are marked with a “=>”. Before you start entering data, check each value and determine the correct settings.


A complete parameter list is provided in *Appendix K - Signal and Parameter Table* where you can also find a detailed description of each parameter.

- 2 Select the parameter mode by pressing the **PAR** key.


The parameter mode display appears, indicating the previously selected group and parameter (when this mode is entered for the first time after power-up, the display will show the first parameter of the first group).




- 3 Select a parameter group using the fast **UP/DOWN** keys.




- 4 Select a parameter to be entered using the slow **UP/DOWN** keys.




- 5 Press **ENTER**.




- 6 Change the parameter using fast (for numeric values only) and slow **UP/DOWN** keys.



- 7 Press **ENTER** to save the changed value.



To cancel the selection and keep the original value, press any of the Mode keys **without** pressing **ENTER**. The display will change to the selected Keypad Mode.



- 8 Repeat steps 3 to 7 for all remaining parameters.
9 To exit the parameter mode press any of the mode keys

or

to select another parameter group and to continue with parameter input use the fast **UP/DOWN** keys.

Motor Identification Run To follow later. For a short description see Chapter 3 - Design and Functional Description, Motor ID Run, page 3- 12.

Please contact your ABB service representative if you need to change the motor parameters.

Miscellaneous Functions

ACS 1000 Information The ACS 1000 software version, test date, and serial number can be displayed.

Information data are stored in parameter group 6, *information*. A detailed list can be found in *Appendix K - Signal and Parameter Table*.

Proceed as described in *Selection of Actual Signals, page 6- 7* to view.

Parameter Lock The user can prevent unwanted parameter adjustment by activating the Parameter Lock.

Parameter lock is set with parameters 16.02 and 16.03 in group *system ctr inputs*. For further details see *Appendix K - Signal and Parameter Table*.

To set the parameter lock proceed as follows:

- 1 Select parameter 16.02 *Parameter lock* as described in *Verification and Modification of Parameters, page 6- 14, steps 1 to 5*.
- 2 Set parameter 16.02 to LOCKED
- 3 Save and exit as described in *Verification and Modification of Parameters, page 6- 14, steps 7 ff*.


To open the parameter lock proceed as follows:

- 1 Select parameter 16.03 *Pass code* as described in *Verification and Modification of Parameters, page 6- 14, steps 1 to 5*.
- 2 Set the correct pass code. If not known, see *Appendix K - Signal and Parameter Table*.
- 3 Save and exit as described in *Verification and Modification of Parameters, page 6- 14, steps 7 ff*.

Uploading Parameters

If one CDP 312 control panel is used for more than one ACS 1000 unit, it is necessary to copy all parameters from the Flash PROM to the control panel when connecting it to a converter.



Uploading can be performed while the drive is running.



Note: Parameter groups 75 OPTION MODULES and 99 START-UP DATA will not be uploaded.

Proceed as follows for parameter uploading:

Downloading can only be started following a successful upload. Otherwise the following warning will appear:



Note: Parameter groups 75 OPTION MODULES and 99 START-UP DATA will not be downloaded.

Proceed as follows for parameter downloading:

- 1 Select the function mode by pressing the **FUNC** key.




- 2 Select **DOWNLOAD** using the slow **UP/DOWN** keys.



- 3 Press **ENTER** to start downloading.



- 4 During the downloading process only the **STOP** command can be given. To exit the function mode after completion press any of the mode keys.



Copying Parameters to Other Units

You can copy parameters from one drive to another by using the parameter upload and parameter download functions in the function mode. Follow the procedure below:

- 1 Select the correct options (group 75), language and macro (group 99) for each drive.
- 2 Set the rated values according to the name plate for each motor (group 99) and perform the identification run for each motor if required.
- 3 Set the parameters in groups 10 to 97 as preferred in one ACS 1000 drive.
- 4 Upload the parameters from the ACS 1000 as described above.
- 5 Disconnect the panel and reconnect it to the next ACS 1000 unit.
- 6 Ensure that the target ACS 1000 is in local control (L shown on the first row of the display).
If necessary, switch to local control.
- 7 Download the parameters from the panel to the ACS 1000 unit as described above.
- 8 Repeat steps 5 to 7 for all other units.




Note: Parameters in groups 75 and 99 concerning options, language, macro and motor data are not copied.

The restriction prevents downloading of incorrect motor data (group 99). In special cases it is also possible to upload and download groups 75 and 99 and the results of the motor identification run. For more information, please contact your local ABB representative.

Restoring Default Settings

- 1 Select the parameter mode by pressing the **PAR** key.

The parameter mode display appears, indicating the previously selected group and parameter (when this mode is entered for the first time after power-up, the display will show the first parameter of the first group).



- 2 Select parameter group 99 using the fast **UP/DOWN** keys.



- 3 Select parameter 99.11 APPLIC RESTORE using the slow **UP/DOWN** keys.




- 4 Press **ENTER**.



- 5 Select YES using the slow **UP/DOWN** keys.



- 6 Press **ENTER** to save the selection. The default settings for the active application macro are restored.



User Macros In addition to the standard application macros, it is possible to create two user macros. The user macro allows the user to save the parameter settings including group 99, the results of the motor identification run and the control location selection (local or external) into the Flash PROM of the ACS 1000, and recall the data at a later time.

Example: User macros make it possible to switch the ACS 1000 between

two motors (e.g. main and replacement motor) without having to adjust the motor parameters and to repeat the identification run every time the motor is changed. The user can adjust the settings and perform the identification run for both motors, and then save the data as two User Macros. When the motor is changed, only the corresponding User Macro needs to be loaded and the drive is ready to operate.



Warning:


1. User macro load restores also the motor settings of the start-up data group and the results of the motor ID run. Check that the settings correspond to the motor used.
2. The user macro parameter changes are not saved when power is switched off. The parameters revert to the last saved values when the power is switched on again.

Creating a User Macro

Proceed as follows to create a user macro:

- 1 Select the parameter mode by pressing the **PAR** key.

The parameter mode display appears, indicating the previously selected group and parameter (when this mode is entered for the first time after power-up, the display will show the first parameter of the first group).



- 2 Select parameter group 99 using the fast **UP/DOWN** keys.




- 3 Select parameter 99.2 **APPLICATION MACRO** using the slow **UP/DOWN** keys.



- 4 Press **ENTER**.



- 5 Select **USER 1 SAVE** or **USER 2 SAVE** using the slow **UP/DOWN** keys.



- 6 Press **ENTER** to save your selection.



Saving will take a few minutes.

- 7 To exit the parameter mode press any of the mode keys

or

to check and, if necessary, to modify the parameters proceed as described in section *Verification and Modification of Parameters*, page 6- 14.

Recalling User Macro Parameters

In order to recall the parameters saved in the user macro proceed as described above. In step 5 select **USER 1 LOAD** or **USER 2 LOAD** instead of **USER 1 SAVE** or **USER 2 SAVE**.

Chapter 7 - Preventive Maintenance

Introduction

This chapter contains a general maintenance schedule that lists all scheduled maintenance and replacement actions to be carried out by the owner or by specialized ABB service staff. In addition, descriptions for those preventive maintenance tasks that can be carried out by the owner are included.

Maintenance work to be carried out by the owner is generally limited to various cleaning tasks and to parts replacement in the cooling circuit.



Warning: Do not attempt any maintenance work, parts replacement or other actions on the ACS 1000 you are not entitled to according to this manual.

Such maintenance work or installation of replacement parts on the ACS 1000 may only be carried out by service staff of ABB Industrie AG and by their authorized service representatives.

Failure to comply with these regulations will void guarantee and endanger correct operation of the installation.

All maintenance work must be carried out according to the maintenance schedule, on-time, in the described sequence and by authorized personnel.

Unless agreed otherwise in a service contract, it is the owner's responsibility

- to verify that all necessary maintenance work is carried out according to the maintenance plan and
- to call up the local ABB service organization when maintenance work is due.

In order to maintain safe and reliable operation of the ACS 1000, it is strongly recommended to sign a service contract with the local ABB service organization. For more information please contact your local service representative.

Special maintenance and service training courses for professionals are offered by ABB. Customer staff having successfully attended such courses will be certified to do maintenance and repair work on the ACS 1000, provided that the equipment is not under warranty anymore. For further information please contact your local service representative.

Safety Instructions



The ACS 1000 is a high voltage device and when misused it can cause damage to personnel and property. When located, installed and connected in accordance with the instructions given in this manual, the device is safe.


Warning: All electrical work on the ACS 1000 must be carried out by

qualified electricians in compliance with local regulations.

Any work must be done with mains and auxiliary power off. Input and output isolators must be open and secured, any adjoining grounding device must be closed and power cables must be grounded.

Never apply power to the installation unless you have checked that:


- mains and motor connections are ok
- auxiliary power and control connections are ok
- no tools or other foreign objects are left in the cabinet
- All cabinet doors including protective shield and door of the control section are closed.



Danger: Never work on a powered ACS 1000. The main circuit breaker and the input isolators must always be opened and locked in “OPEN” position. Do not access the main power circuit nor the motor as long as the system is not grounded.

When switching off the mains, always allow the intermediate circuit capacitors to discharge before grounding and starting work on the frequency converter, the motor or the motor cable.

The ACS 1000 and adjoining equipment must be properly grounded and the auxiliary supply voltage must be switched off prior to starting with any work.



Danger: Some loads may apply a mechanical torque on the motor shaft! If the motor can rotate due to such a load, always disconnect, short-circuit or mechanically block the motor before you start work.



Danger: There can be dangerous voltages inside the ACS 1000 from external control circuits (measurement inputs from PT's etc.) even if the ACS 1000 mains power and auxiliary power are shut off. Take appropriate measures when working with the unit, i.e deenergize and disconnect all such external devices (auxiliary supply, heaters, coolers, I/O-interfaces) before you start work.

Prior to start working on the ACS 1000 the general safety regulations in *Chapter 1 - Safety Instructions* must be read and understood.

ABB Industrie AG declines all liability for any possible damage resulting from failure or negligence to observe these warnings.

Maintenance Schedule



Warning: Do not attempt any maintenance work, parts replacement or other actions on the ACS 1000 to which you are not entitled by this maintenance schedule.
If you have any doubts, always contact your local ABB service representative for more information.

Maintenance task	To be carried out by		Frequency	Comments
Cubicle cleaning (outside and floor inside)	owner		- according to need - at least yearly	visual check, cleaning if necessary
Cubicle cleaning inside		ABB service*	yearly	visual check, cleaning if necessary
Check of connections (external power and control cable terminations)	owner		- after 1 year - then every 4 years	tighten main cable connections and terminal block connections if necessary
Check of internal connections		ABB service*	- after 1 year - then every 4 years	
General functional and visual inspection		ABB service*	yearly	According to instructions in service documentation (service tool)
Cleaning/replacement of air filter	owner		on occurrence (alarm <i>FanDiff-Pres</i>)	optional equipment
Cleaning/replacement of control door air filter	owner		on occurrence (alarm <i>FanDiff-Pres</i>)	
Replacement of fan bearings	owner	(ABB service)*	> 30'000 hours running time	check parameter 5.05
Replacement of fan	owner	(ABB service)*	> 30'000 hours running time, depending on fan condition	check parameter 5.05
Replacement of batteries	owner	(ABB service)*	upon alarm	

Maintenance task	To be carried out by	Frequency	Comments
Parameter backup and software version check		ABB service*	- upon any parameter modification** - at least every 5 years
Measurement of capacitors		ABB service*	- after 3 year - then every 2 years
Insulation test		ABB service*	every 2 years According to instructions in service documentation (service tool)
Inspection of motor, transformer and MCB	owner	ABB service*	according to the relevant maintenance instructions see relevant maintenance instructions
Spare parts check		ABB service*	yearly check stock according to <i>Appendix I - Recommended Spare Parts List</i>
Check of optional equipment		ABB service*	According to instructions in service documentation (service tool)

*service staff of ABB Industrie AG or authorized service representatives, is usually part of the service contract

** parameter backup can be done by instructed users. DriveWindow software is required.

Required Tools

For maintenance tasks carried out by the owner, the following tools and materials are necessary:

- industrial vacuum cleaner with plastic tube and plastic tip
- compressed air (oil free)
- tool kit
- replacement parts

Maintenance Instructions

Standard Procedure for Maintenance

In order to ensure maximum safety during maintenance activities proceed as follows:

- 1 **Safety measures:** Make sure to be familiar with and to observe all

safety regulations as stated at the beginning of this chapter and in *Chapter 1 - Safety Instructions*.

2 ***De-energize the system***




Danger: Do not access the main power circuit nor the motor as long as the system is still energized or as long as it is not grounded.

After switching off the mains and after the motor has come to a stop, always allow the intermediate circuit capacitors 5 minutes to discharge (yellow indicator **GND.- SWITCH UNLOCKED** must be on) before grounding and starting work on the frequency converter, the transformer, the motor or the cables.


The ACS 1000 and adjoining equipment must be properly grounded and the auxiliary supply voltage must be switched off prior to starting with any work.

- 3 **Switch off auxiliary power supply** (open contactor -Q1) and disconnect all external devices feeding dangerous voltages into the cubicle.

Figure 7-1 Control cabinet



- 4 **Carry out the required maintenance tasks:** refer to the maintenance schedule and to the detailed instructions in this chapter.



Note: For your own safety, follow exactly the instructions in this chapter and never attempt to do any maintenance or repair work on the ACS 1000 beyond these instructions.

- 5 **Check that:**

- mains and motor connections are ok
- auxiliary power and control connections are ok
- no tools or other foreign objects are left in the cabinet
- All cabinet doors including protective shield and door of the control section are closed.



Note: When closing the protective separation door, all fastening screws must be mounted and tightened in order to maintain EMC performance.

- 6 **Switch on the auxiliary voltage:** close contactor -Q1 and -Q11 (and -Q12, in case of redundant fans).

- 7 **Restart the converter** as described in *Chapter 5 - Operation*.
- 8 **Make logbook entry:** Any maintenance activity must be recorded in the maintenance logbook including:
 - date and time
 - maintenance task carried out according to maintenance schedule
 - any special situation or action (scheduled or non-scheduled replacement of parts etc.)

Outside Cleaning Check air inlet and optional air filter for dirt, clean with compressed air and, if necessary, replace air filter (optional equipment, refer to filter manual)

- Inside Floor Cleaning**
- 1 De-energize the system according to *Standard Procedure for Maintenance, page 7- 4*
 - 2 After the grounding switch has been closed, open the front doors
 - 3 Carefully clean compartment floors with the vacuum cleaner (use plastic tip only to avoid damage to equipment).



Warning: Apply special care while cleaning inside the cubicle, especially do not damage the capacitor bushings. In order to avoid damages do **not** clean any other equipment besides the floor!

- 4 Accomplish your maintenance job as described in *Standard Procedure for Maintenance, page 7- 4*.

Check of Connections

- 1 De-energize the system according to *Standard Procedure for Maintenance, page 7- 4*
- 2 After the grounding switch has been closed, open the front doors
- 3 Check if all connections of external power and control cables are fastened tightly.




Warning: Do **not** check the internal cabling! In particular do not tighten the capacitor connections. The capacitor bushings will be damaged when a excessive momentum is applied to the terminals.

- 4 Accomplish your maintenance job as described in *Standard Procedure for Maintenance, page 7- 4*.


Replacement of Air Filters

- Inverter Door Air Inlet*
- 1 Loosen the filter frame by turning the locking bolts (4) a quarter turn counterclockwise and remove the frame (1) from the door (3)
 - 2 Remove the filter mat (2) and insert the replacement mat
 - 3 Mount the filter frame (1) and lock it by turning the locking bolts (4) a quarter turn clockwise
 - 4 Record the date of replacement in logbook



- Control Door Air Inlet*
- 1 Open control section door
 - 2 Pull out the filter mat from its pocket and insert the replacement filter
 - 3 Lock the door and record the date of replacement in the logbook


Replacement of Fan



Note: If your system is equipped with redundant fans, refer to the corresponding *User's Guide* for further instructions.

- 1 De-energize the system according to *Standard Procedure for Maintenance, page 7- 4*
- 2 After the grounding switch has been closed, open the front door of the rectifier section

- 3 Unplug the supply cable (1) of the fan




- 4 Loosen and remove the 2 bolts (2) located to the left and right side using a 13mm wrench




Warning: The total weight of the fan is 100 kg (220 lb).


- 5 Withdraw the fan by sliding it carefully towards the front. Consider the weight of 100 kg and use sufficient manpower when lifting the unit. Support with a forklift if possible.



- 6 Remove the 4 sliding blocks (3) and mount them on the replacement fan. The guiding grooves must be oriented towards the back side (4) of the housing (cable and nameplate are on the front side).



- 7 Lift the fan and slide it back onto the guiding rails
- 8 Press the housing towards the gasket on the right hand side (5), insert and tighten the 2 bolts.




- 9 Accomplish your maintenance job as described in *Standard Procedure for Maintenance, page 7- 4*. Check if the fan works properly when re-energizing the system.


Replacement of Fan Bearings to follow later

Replacement of Batteries

- 1 Open control section door
- 2 Disconnect the batteries
- 3 Loosen the rubber belt (1) around the batteries and remove the batteries



- 4 Place the new batteries and fasten the rubber belt
- 5 Reconnect the cables to both batteries. Make sure that the polarity is set correctly according to the markings on the batteries and on the labels of the cables (see Figure)
- 6 Make a polarity check (see figure below):
 - on the EPS board, unplug the (+)-cable (1,2)
 - connect the terminal of the unplugged cable to the test pin (3). The LED (4) must light up if the polarity is correct.
 - Plug the (+)-cable (2) back to the (+)-pin.



- 7 Lock the door and record the date of replacement in the logbook

Parameter Backup See *Drives Windows* user manual

***Inspection of Motor,
Transformer and
MCB*** See corresponding manuals

***Maintenance
Logbook*** A maintenance logbook with a complete record of any maintenance activity must be kept. Any entry must include:

- date and time
- maintenance task carried out according to maintenance schedule
- any special situation or action (scheduled or non-scheduled replacement of parts etc.)

***ABB Service
Address*** Please ask your ABB sales representative for the address of the local ABB service organization. Contact them if you have any questions.

Chapter 8 - Trouble Shooting & Repair

Overview

The purpose of this chapter is to provide information and instructions on how to proceed when encountering a problem with the ACS 1000. This chapter is addressed to electrical field professionals who are responsible for servicing the ACS 1000. In order to perform the suggested actions in case of a disturbance, no special training is required besides the professional education as indicated in *Chapter 2 - Introduction, Intended Audience for this Manual, page 2- 2.*



Warning: Do not attempt any measurement, parts replacement or other corrective actions on the ACS 1000 which are not described in this chapter.

Repair work or installation of spare parts on the ACS 1000 may only be carried out by service staff of ABB Industrie AG and by their authorized service representatives.

Failure to comply with this regulation will void guarantee and endanger correct operation of the installation.

It is strongly recommended to sign a service contract with ABB. For more information please contact your local service representative.

Special maintenance and service training courses for professionals are offered by ABB. Customer staff having successfully attended such courses will be certified to do maintenance and repair work on the ACS 1000, provided that the equipment is not under warranty anymore. For further information please contact your local service representative.

Safety Instructions

The ACS 1000 is a high voltage device and when misused it can cause damage to personnel and property. When located, installed and connected in accordance with the instructions given in this manual, the device is safe.



Warning: All electrical work on the ACS 1000 must be carried out by qualified electricians in compliance with local regulations.

Any work must be done with mains and auxiliary power off. Input and output isolators must be open and secured, any adjoining grounding device must be closed and power cables must be grounded.

Never apply power to the installation unless you have checked that:

- mains and motor connections are ok
- auxiliary power and control connections are ok
- no tools or other foreign objects are left in the cabinet
- All cabinet doors including separation door behind the swing frame and

door of the control section are closed.



Danger: Never work on a powered ACS 1000. The main circuit breaker and the input isolators must always be opened and locked in “*OPEN*” position. Do not access the main power circuit nor the motor as long as the system is not grounded.

When switching off the mains, always allow the intermediate circuit capacitors to discharge before grounding and starting work on the frequency converter, the motor or the motor cable.

The ACS 1000 and adjoining equipment must be properly grounded and the auxiliary supply voltage must be switched off prior to starting with any work.



Danger: Some loads may apply a mechanical torque on the motor shaft! If the motor can rotate due to such a load, always disconnect, short-circuit or mechanically block the motor before you start work.



Danger: There can be dangerous voltages inside the ACS 1000 from external control circuits (measurement inputs from PT's etc.) even if the ACS 1000 mains power and auxiliary power are shut off. Take appropriate measures when working with the unit, i.e deenergize and disconnect all such external devices (auxiliary supply, heaters, coolers, I/O-interfaces) before you start work.



Danger: The grounding isolator may become ineffective if the power circuit is opened. The main circuit breaker and the input isolators must always be opened and locked in “*OPEN*” position. Any external ground switch must be closed and locked.

Prior to start working on the ACS 1000 the general safety regulations in *Chapter 1 - Safety Instructions* must be read and understood.

ABB Industrie AG declines all liability for any possible damage resulting from failure or negligence to observe these warnings.


Alarm and Fault Handling

If a disturbance occurs anywhere in the converter or in related equipment, it will be indicated with an error message on the CDP 312 control panel or, as alternative, on the *DriveWindow* error display.

Two error message levels are used with the ACS 1000:

- **Fault:** a fault is initiated by a serious disturbance in the converter or in related equipment (transformer, motor etc.) and always implies a converter trip. The converter will remain in tripped state (with the exception of a few faults where the converter will resume operation automatically after the disturbance has disappeared).

In order to restart the system, the fault must be corrected and the error message be manually reset on the CDP 312 control panel.



Note: Some faults require the main circuit breaker (MCB) to be opened. The MCB handling is done by the ACS 1000 control system. Therefore no external opening orders must be applied to the MCB for converter initiated trips.

- **Alarm (warning):** an alarm is given if an irregular situation occurs that does not necessarily require a converter stop. Operation is still possible. However, a persisting alarm condition can often lead to a fault if the disturbance is not cleared within a certain time (e.g. high ambient temperature).

In *Table 8-1* all possible error messages are listed together with information on possible causes and suggestions for remedy. Please note that many of these alarm and fault messages are related to the specific equipment in use (e.g. transformer type, cooling system) or to external protection devices provided by the user. For that reason, some of the messages might never appear in your system since they are not relevant for your application.


For your own safety, follow exactly the instructions in *Table 8-1* when identifying and correcting a disturbance and never attempt to do any repair work on the ACS 1000 beyond these instructions. Before starting with trouble-shooting you must read carefully the warnings stated at the beginning of this chapter.

Fault Display on the CDP 312 Control Panel

The following section gives a concise description of how to display error messages on the CDP 312 control panel. For further details please refer to *Appendix B - The CDP 312 Control Panel* and to *Chapter 5 - Operation*.

Active Fault Display


If a fault or an alarm is generated in the drive, it will be displayed immediately with a flashing text, except if you are in the Drive Selection Mode:



- 1 You can always view any active fault by selecting the Actual Signal Display mode.



- To reset the fault press **RESET**.



After a reset , the fault message will not appear anymore in Actual Signal Display mode. However, the fault is still stored in the fault history and can be viewed there.


From the fault display, it is possible to switch to other displays without resetting the fault. If no keys are pressed the fault or warning text is displayed as long as the fault exists.

Fault History Display

The Fault History provides information on the 40 most recent faults that occurred in your ACS 1000. The name of the fault and the date and time of occurrence are displayed.


Proceed as follows to view fault history:

- Enter the Actual Signal Display mode by pressing **ACT** on the CDP 312 control panel.




- Select the Fault History Display with the fast **UP/DOWN** keys.

The most recent fault will be displayed together with the date and time of occurrence.



- Select previous (**UP** key) or next fault (**DOWN** key).






Warning: Do not clear the fault history buffer before you completely clarified the error situation. Clearing of the buffer cannot be undone.

- To clear the fault history press **RESET**.



The fault history buffer is now empty.

- To return to the Actual Signal Display mode press a fast **UP/DOWN** key.



Standard Procedure for Trouble-Shooting

If a disturbance occurs in your system, proceed as follows:

- Safety measures:** Make sure to be familiar with and to observe all safety regulations as stated at the beginning of this chapter and in *Chapter 1 - Safety Instructions*.
- Check error log in control panel:** record the actual fault and the fault history as described in *Fault Display on the CDP 312 Control Panel*.

Do **not** clear the fault history buffer now!

- Analyze fault situation and make logbook entry:**



Danger: Never work on a powered ACS 1000. The main circuit breaker and the input isolators must always be opened and locked in "OPEN" position. Do not access the main power circuit nor the motor as long as the system is not grounded.

When switching off the mains, always allow the intermediate circuit capacitors to discharge before grounding and starting work on the frequency converter, the motor or the motor cable.

The ACS 1000 and adjoining equipment must be properly grounded

and the auxiliary supply voltage must be switched off prior to starting with any work.


Refer to *Table 8-1* for explanation of the error messages. In the table you will also find suggestions for fault remedy.

Any occurring alarm and fault must be recorded in the logbook including:

- date and time of occurrence
- load conditions (normal, overload or minimum load, continuous or intermittent load etc.)
- any other special situation or operating condition (ambient temperature etc.)

It is essential for an efficient fault analysis to have all these data available when you call your ABB service representative.

4 Try to eliminate the disturbance:




Note: For your own safety, follow exactly the instructions in *Table 8-1* when identifying and correcting a disturbance and never attempt to do any repair work on the ACS 1000 beyond these instructions. Before starting with trouble-shooting you must read carefully the warnings stated at the beginning of this chapter.

If the problem cannot be resolved, always contact your ABB service representative.

Follow the instructions in *Table 8-1*. If you do not succeed with these suggestions, do not try on your own. Call immediately your local ABB service organization.

5 Check that:

- mains and motor connections are ok
- auxiliary power and control connections are ok
- no tools or other foreign objects are left in the cabinet
- All cabinet doors including protective shield and door of the control section are closed.



Note: When closing the protective separation door, all fastening screws must be mounted and tightened in order to maintain EMC performance.

6 Switch on the auxiliary voltage: close contactor -Q1 and -Q11 (and -Q12, in case of redundant fans)

7 Restart the converter as described in *Chapter 5 - Operation*.

8 Reset error log : clear the fault history as described in *Chapter 8 - Trouble Shooting & Repair, Fault Display on the CDP 312 Control*

Panel, page 8- 3 .

Repair Work

During warranty, any repair work is to be done exclusively by ABB service personnel. After expiration of the warranty period repair work with the exception of replacement of parts specifically mentioned in *Chapter 7 - Preventive Maintenance* is to be done only by ABB service personnel or by authorized persons having attended the maintenance and service training as mentioned at the beginning of this chapter. Adequate documentation will be handed out during these courses.

***Error Messages and
Fault Elimination***

See *Table 8-1* and *Table 8-2*.

Table 8-1 Error messages and fault elimination

Message	Possible cause/ meaning of message	Suggested remedy	Indication	Alarm	Fault	MCB open	Comments
AirFiltSupv	Δp (differential pressure) supervision Possible causes: - Air filter is dirty	- Replace air filter - If the fault cannot be located, call local ABB service organization		x			Optional Air cooled converters only
AnInpCalib	Automatic input calibration of IOEC boards not successful	- Disconnect analog inputs and retry - If the fault cannot be eliminated, call local ABB service organization		x			
AnInpCalib	Automatic input calibration of IOEC boards not successful	- Disconnect analog inputs and retry - If the fault cannot be eliminated, call local ABB service organization			x		
Aux Pwr Fail	Failure in 27 V power supply Possible cause: - Loss of auxiliary input voltage	- Check auxiliary input voltage (Terminal X10, see <i>Appendix G - Wiring Diagrams</i>) and auxiliary power supply - If the fault cannot be eliminated, call local ABB service organization			x	x	
AuxFan	Contactor supervision of aux fan Possible causes: - Fan defective - Fan protection relay defective	- Call local ABB service organization			x	x	Water cooled converters only
Battery Down	Battery capacity too low	- Replace battery (see <i>Chapter 7 - Preventive Maintenance</i>) - Call local ABB service organization		x	x		Default setting: depending on application
Battery Miss	Battery is not connected	- Check battery wiring and connections - If the fault cannot be eliminated, call local ABB service organization		x	x		Default setting: depending on application
Brake Chop	Temperature limit of the braking chopper exceeded Possible causes: - Underdimensioning of braking chopper	- Call local ABB service organization		x			Optional
Brake Chop	Temperature limit of the braking chopper exceeded Possible causes: - Underdimensioning of braking chopper	- Call local ABB service organization			x	x	Optional

Table 8-1 Error messages and fault elimination (Continued)

Message	Possible cause/ meaning of message	Suggested remedy	Indication	Alarm	Fault	MCB open	Comments
Brg DE Mios	Loss of analog input from temperature measurement at the driven end bearing Possible causes: - Temperature measuring device defective - Wiring in monitoring circuit disturbed	<ul style="list-style-type: none"> - Check Input <i>BRG TEMP DE</i> on IOEC3 board (signal must be > 2mA) - Check power supply of monitoring device - Check wiring between external temperature measuring device and ACS 1000. - Check cable shielding and grounding - If the fault cannot be eliminated, call local ABB service organization 		x	x		Optional Default setting: programmable
BrgNDE Mios	Loss of analog input from temperature measurement at the non driven end bearing Possible causes: - Temperature measuring device defective - Wiring in monitoring circuit disturbed	<ul style="list-style-type: none"> - Check Input <i>BRG TEMP NDE</i> on IOEC3 board (signal must be > 2mA) - Check power supply of monitoring device - Check wiring between external temperature measuring device and ACS 1000. - Check cable shielding and grounding - If the fault cannot be eliminated, call local ABB service organization 		x	x		Optional Default setting: programmable
BrgTemp DE	Alarm from temperature measurement at the driven end bearing Possible causes: - Excessive/insufficient lubrication or bearing problems - Temperature measuring device defective - Wiring in monitoring circuit disturbed	<ul style="list-style-type: none"> - Check bearing. For details refer to motor manual. - Check Input <i>BRG TEMP DE</i> on IOEC3 board - Check power supply of monitoring device - Check wiring between external temperature measuring device and ACS 1000. - Check cable shielding and grounding - If the fault cannot be eliminated, call local ABB service organization 		x			Optional

Table 8-1 Error messages and fault elimination (Continued)

Message	Possible cause/ meaning of message	Suggested remedy	Indication	Alarm	Fault	MCB open	Comments
BrgTemp DE	<p>Trip from temperature measurement at the driven end bearing</p> <p>Possible causes:</p> <ul style="list-style-type: none"> - Excessive/insufficient lubrication or bearing problems - Temperature measuring device defective - Wiring in monitoring circuit disturbed 	<ul style="list-style-type: none"> - Check bearing. For details refer to motor manual. - Check Input <i>BRG TEMP DE</i> on IOEC3 board - Check power supply of monitoring device - Check wiring between external temperature measuring device and ACS 1000. - Check cable shielding and grounding - If the fault cannot be eliminated, call local ABB service organization 			x		Optional
BrgTemp NDE	<p>Alarm from temperature measurement at the non driven end bearing</p> <p>Possible causes:</p> <ul style="list-style-type: none"> - Excessive/insufficient lubrication or bearing problems - Temperature measuring device defective - Wiring in monitoring circuit disturbed 	<ul style="list-style-type: none"> - Check bearing. For details refer to motor manual. - Check Input <i>BRG TEMP NDE</i> on IOEC3 board - Check power supply of monitoring device - Check wiring between external temperature measuring device and ACS 1000. - Check cable shielding and grounding - If the fault cannot be eliminated, call local ABB service organization 		x			Optional
BrgTemp NDE	<p>Trip from temperature measurement at the non driven end bearing</p> <p>Possible causes:</p> <ul style="list-style-type: none"> - Excessive/insufficient lubrication or bearing problems - Temperature measuring device defective - Wiring in monitoring circuit disturbed 	<ul style="list-style-type: none"> - Check bearing. For details refer to motor manual. - Check Input <i>BRG TEMP NDE</i> on IOEC3 board - Check power supply of monitoring device - Check wiring between external temperature measuring device and ACS 1000. - Check cable shielding and grounding - If the fault cannot be eliminated, call local ABB service organization 			x		Optional

Table 8-1 Error messages and fault elimination (Continued)

Message	Possible cause/ meaning of message	Suggested remedy	Indication	Alarm	Fault	MCB open	Comments
Buchholz	Alarm signal from external Buchholz protection Possible causes: - Gas or air bubble generation in transformer oil circuit - Wiring in protection circuit disturbed - Shielding of control cables not properly grounded	- Inspect transformer according to the instructions in the transformer manual - Check wiring of Buchholz protection circuit (input <i>BUCHHOLZ ALARM</i> on IOEC3 board). - Check if shielding of control cables is properly grounded - If the fault cannot be eliminated, call local ABB service organization		x			Optional
Buchholz	Trip signal from external Buchholz protection Possible causes: - Gas or air bubble generation in transformer oil circuit - Wiring in protection circuit disturbed - Shielding of control cables not properly grounded	- Inspect transformer according to the instructions in the transformer manual - Check wiring of Buchholz protection circuit (input <i>BUCHHOLZ TRIP</i> on IOEC3 board). - Check if shielding of control cables is properly grounded - If the fault cannot be eliminated, call local ABB service organization			x	x	Optional
CalibNot Done	Offset calibration of IOEC boards was not successful	-		x			
CH0 LinkEr	Communication time-out (internal comm.)	- Check fibre optic connections on AMC 3 board - Call local ABB service organization		x	x		Default setting: Not active
CH2 LinkEr	Communication time-out (internal comm.)	- Check fibre optic connections on AMC 3 board - Call local ABB service organization		x	x		Default setting: Not active
Charge Circ	Charging circuit disturbed	- Call local ABB service organization			x	x	
Charging	Charging of intermediate dc-circuit failed Possible causes: - Mains voltage low	- Verify measured dc-voltage (Parameters 2.02 to 2.09) - Check whether mains supply voltage is within the tolerated limits. See <i>Appendix A - Technical Data</i> . - Verify stiffness of mains supply - If the fault cannot be eliminated, call local ABB service organization			x	x	
CoSens-Dirty	Cooling water conductivity sensor is dirty	- Call local ABB service organization		x			Water cooled converters only

Table 8-1 Error messages and fault elimination (Continued)

Message	Possible cause/ meaning of message	Suggested remedy	Indication	Alarm	Fault	MCB open	Comments
Discharging	Discharging failure: DC-link maximum discharging time exceeded	- Call local ABB service organization			x	x	 <p>Danger: Intermediate DC-circuit is still charged</p>
Doing F IDR	Filter ID run is in progress	-		x			
Doing ID Run	ID run is in progress	-		x			
EarthIso-Ctrl	Feedback signal from earth isolator is lost during operation	- Call local ABB service organization			x	x	
EmergStop	External or internal emergency stop order Possible causes: - Emergency stop order - External wiring in emergency stop circuit disturbed - Shielding of control cables not properly grounded	- Check origin of Emergency stop order (see also process control) - Check external wiring and shielding of emergency stop circuit - If the fault cannot be located, call local ABB service organization			x	x	
EPS Fault	Electronic power supply fault	- Call local ABB service organization			x	x	
ExtRef1 Lost	External reference signal 1 lost	- Check origin of reference signal (see also process control) - Check external wiring and shielding of reference circuit - If the fault cannot be located, call local ABB service organization		x	x		Default setting: alarm
ExtRef2 Lost	External reference signal 2 lost	- Check origin of reference signal (see also process control) - Check external wiring and shielding of reference circuit - If the fault cannot be located, call local ABB service organization		x	x		Default setting: alarm

Table 8-1 Error messages and fault elimination (Continued)

Message	Possible cause/ meaning of message	Suggested remedy	Indication	Alarm	Fault	MCB open	Comments
ExtMotCool	Alarm from external motor cooler Possible causes: - Fault in external motor cooling circuit - Wiring in monitoring circuit disturbed - Poor grounding connections	<ul style="list-style-type: none"> - Check motor temperature - Check cooling equipment. Refer to manuals for motor and cooling - Check with logbook if alarm occurs repeatedly and record alarm conditions - Check wiring and connections between relay and converter. Check relay input wiring - Check cable shielding and grounding - If the fault cannot be eliminated, call local ABB service organization 		x			Optional
ExtMotCool	Trip from external motor cooler Possible causes: - Fault in external motor cooling circuit - Wiring in monitoring circuit disturbed - Poor grounding connections	<ul style="list-style-type: none"> - Check motor temperature - Check cooling equipment. Refer to manuals for motor and cooling - Check with logbook if fault occurs repeatedly and record trip conditions - Check wiring and connections between relay and converter. Check relay input wiring - Check cable shielding and grounding - If the fault cannot be eliminated, call local ABB service organization 			x		Optional
ExtMotProt	External motor protection alarm Possible causes: - Due to a motor problem external motor protection relay has been actuated - Wiring in protection circuit disturbed - Shielding of control cables not properly grounded	<ul style="list-style-type: none"> - Check motor and record fault together with load conditions into logbook - Check that all trip limit values are correctly set in the relay - Check wiring between external protection relay and ACS 1000 (input <i>EXT MOT PROT TRIP</i> on IOEC1 board) - Check wiring to relay inputs - Check if shielding of control cables is properly grounded - If the fault cannot be eliminated, call local ABB service organization 		x			Optional

Table 8-1 Error messages and fault elimination (Continued)

Message	Possible cause/ meaning of message	Suggested remedy	Indication	Alarm	Fault	MCB open	Comments
ExtMotProt	External motor protection trip Possible causes: - Due to a motor problem external motor protection relay has been actuated - Wiring in protection circuit disturbed - Shielding of control cables not properly grounded	<ul style="list-style-type: none"> - Check motor and record fault together with load conditions into logbook - Check that all trip limit values are correctly set in the relay - Check wiring between external protection relay and ACS 1000 (input <i>EXT MOT PROT TRIP</i> on IOEC1 board) - Check wiring to relay inputs - Check if shielding of control cables is properly grounded - If the fault cannot be eliminated, call local ABB service organization 			x		
ExtOver-speed	External motor overspeed protection Possible causes : - Wrong parameter settings - Loss of parameter settings or power supply in external relay - Motor is forced to overspeed by driven equipment - Wiring in protection circuit disturbed - Poor grounding connections	<ul style="list-style-type: none"> - Check parameter settings of external relay. Check that settings are not in conflict with converter parameter settings - check power supply of external relay - Check motor loading, especially if driven equipment is dimensioned correctly and functioning properly. Check with logbook if fault occurs repeatedly and record trip conditions - Check wiring and connections between relay and converter. Check relay input wiring - Check cable shielding and grounding - If the fault cannot be eliminated, call local ABB service organization 			x	x	Optional
ExtTrafProt	Trip signal from external transformer protection Possible causes: - Transformer fault - Wiring in protection circuit disturbed - Shielding of control cables not properly grounded	<ul style="list-style-type: none"> - Inspect transformer according to the instructions in the external protection device and transformer manuals - Check wiring of external protection circuit (input <i>EXT TRAF PROT TRIP</i> on IOEC1 board). - Check if shielding of control cables is properly grounded - If the fault cannot be eliminated, call local ABB service organization 			x	x	

Table 8-1 Error messages and fault elimination (Continued)

Message	Possible cause/ meaning of message	Suggested remedy	Indication	Alarm	Fault	MCB open	Comments
ExtWtrCool	Alarm from external motor water cooling equipment Possible causes: - Fault in external motor cooling circuit - Wiring in monitoring circuit disturbed - Poor grounding connections	- Check motor temperature - Check cooling equipment. Refer to manuals for motor and cooling - Check with logbook if alarm occurs repeatedly and record alarm conditions - Check wiring and connections between relay and converter. Check relay input wiring - Check cable shielding and grounding - If the fault cannot be eliminated, call local ABB service organization		x			Optional
ExtWtrCool	Trip from external motor water cooling equipment Possible causes: - Fault in external motor cooling circuit - Wiring in monitoring circuit disturbed - Poor grounding connections	- Check motor temperature - Check cooling equipment. Refer to manuals for motor and cooling - Check with logbook if fault occurs repeatedly and record trip conditions - Check wiring and connections between relay and converter. Check relay input wiring - Check cable shielding and grounding - If the fault cannot be eliminated, call local ABB service organization			x		Optional
Fan 1/2	Trip - fan contactor supervision Possible causes: - Overload - Fan defective - Contactor defective	- Check contactor - Replace fan - If the fault cannot be eliminated, call local ABB service organization			x	x	Air cooled converters only
Fan 1/2	Alarm - fan contactor supervision in case of redundant fans Possible causes: - Overload - Fan defective - Contactor defective	- Check contactor - Replace fan - If the fault cannot be eliminated, call local ABB service organization		x			Air cooled converters only
FanDiffPres	Trip - differential pressure supervision Possible causes: - Fan defective - Power supply for fan disturbed	- Check if doors are properly closed - Check air filter and clean if necessary - If the fault cannot be eliminated, call local ABB service organization			x	x	Air cooled converters only

Table 8-1 Error messages and fault elimination (Continued)

Message	Possible cause/ meaning of message	Suggested remedy	Indication	Alarm	Fault	MCB open	Comments
FanDiffPres	Alarm - differential pressure supervision in case of redundant fans Possible causes: - Fan defective - Power supply for fan disturbed	- Check if doors are properly closed - Check air filter and clean if necessary - If the fault cannot be eliminated, call local ABB service organization		x			Air cooled converters only
Fil Cap Curr	SW supervision- Filter capacitor overcurrent Possible causes: - defective capacitor - short circuited motor	- Check motor connections and cabling - Check fault history buffer for other, possibly related error messages - If the fault cannot be eliminated, call local ABB service organization			x	x	
Filt IDR Reqst	Filter ID run is requested	- Carry out filter ID run		x			
Ground Fault	SW function - protection of converter equipment from ground fault in motor, motor cable and inverter	- Check motor and motor cables. Refer to motor manual - If the fault cannot be located, call local ABB service organization			x	x	depends on application
GUSP 1	Gate power supply	- Call local ABB service organization			x	x	
GUSP 2	Gate power supply	- Call local ABB service organization			x	x	
ID Run Fault	ID run was not successful Possible cause: - Wrong start-up parameter settings	- Verify parameter settings in parameter group 99 and repeat ID run - If the fault reappears, call local ABB service organization			x	x	
ID Run Reqst	ID run is requested (first start-up has been attempted without ID run)	- Carry out ID run		x			
ID Run Stop	ID run has been interrupted by a stop command. This message will be followed by "ID RUN REQST"	- Repeat ID run		x			
InplsolDis	Input isolator feedback discrepancy Possible causes: - Malfunction of isolator or isolator control - Wiring in isolator control circuit disturbed - Shielding of control cables not properly grounded	- Check isolator operation following isolator user manual and circuit diagram. - Check wiring and shielding of isolator control circuit - If the fault cannot be located, call local ABB service organization		x			Optional Two feedback signals do not correspond

Table 8-1 Error messages and fault elimination (Continued)

Message	Possible cause/ meaning of message	Suggested remedy	Indication	Alarm	Fault	MCB open	Comments
InpVolt-Unba	Converter input voltage is not balanced Possible causes: <ul style="list-style-type: none"> - Loss of a phase or voltage unbalance - Loss of aux. power supply for unbalance protection relay - Wiring in monitoring circuit disturbed - Shielding of cables not properly grounded 	<ul style="list-style-type: none"> - Check input mains voltage - Check auxiliary power supply for protection relay - Check protection relay settings - Check wiring and shielding of monitoring circuit - If the fault cannot be located, call local ABB service organization 			x	x	Optional
Inv Curr HW	HW supervision - excessive inverter output current Possible causes: <ul style="list-style-type: none"> - Motor load not matched with inverter ratings - Incorrect motor data - If fault occurs during acceleration, the acceleration time might be too short - Stray currents in motor cabling 	<ul style="list-style-type: none"> - Check fault history buffer for other, possibly related error messages - Check dimensioning of motor and drive. For inverter ratings see Appendix A - ACS 1000 Technical Data - Verify start-up parameters 99.3 to 99.8. Compare with motor nameplate. See Appendix K - Parameter Description - Check if fault occurs <u>only</u> during acceleration. If this is the case, increase the acceleration time (parameters 22.02 and 22.04) - Check motor cable connections - If the fault cannot be eliminated, call local ABB service organization 			x		
Inv Curr SOA	SW supervision of Inverter currents according to safe operating area -excessive inverter output current Possible causes: <ul style="list-style-type: none"> - Motor load not matched with inverter ratings - High supply voltage - Incorrect motor data - If fault occurs during acceleration, the acceleration time might be too short - Stray currents in motor cabling 	<ul style="list-style-type: none"> - Check fault history buffer for other, possibly related error messages - Check dimensioning of motor and drive. For inverter ratings see <i>Appendix A - Technical Data</i> - Verify start-up parameters 99.3 to 99.8. Compare with motor nameplate. See Appendix K - Parameter Description - Check if fault occurs <u>only</u> during acceleration. If this is the case, increase the acceleration time (parameters 22.02 and 22.04) - Check motor cable connections - If the fault cannot be eliminated, call local ABB service organization 			x		

Table 8-1 Error messages and fault elimination (Continued)

Message	Possible cause/ meaning of message	Suggested remedy	Indication	Alarm	Fault	MCB open	Comments
InvAirTemp	Incoming cooling air above limit	<ul style="list-style-type: none"> - Check ambient temperature - If ambient temperature is within limits, call local ABB service organization 		x			Air cooled converters only
InvAirTemp	Supervision of ambient temperature Possible cause: - Ambient temperature too high	<ul style="list-style-type: none"> - Check ambient temperature - If ambient temperature is within limits, call local ABB service organization 			x		Air cooled converters only
IOEC1Link Er	Supervision of communication link	<ul style="list-style-type: none"> - Check connectors on IOEC1 and AMC3 boards - If the fault cannot be eliminated call local ABB service organization 			x	x	
IOEC2Link Er	Supervision of communication link	<ul style="list-style-type: none"> - Check connectors on IOEC2 and AMC3 boards - If the fault cannot be eliminated call local ABB service organization 			x	x	
IOEC3Link Er	Supervision of communication link	<ul style="list-style-type: none"> - Check connectors on IOEC3 and AMC3 boards - If the fault cannot be eliminated call local ABB service organization 			x	x	Optional
IOEC4Link Er	Supervision of communication link	<ul style="list-style-type: none"> - Check connectors on IOEC4 and AMC3 boards - If the fault cannot be eliminated call local ABB service organization 			x	x	Optional
Limit Superv	Supervision if actual or reference signal is at limit.	<ul style="list-style-type: none"> - Check limit settings in parameter group 32 <i>Supervision</i> 		x			
Link AB Lost	Loss of internal communication links	<ul style="list-style-type: none"> - Check connectors in control cabinet - If the fault cannot be eliminated call local ABB service organization 			x	x	
Link C Lost	Loss of internal communication links	<ul style="list-style-type: none"> - Check connectors on interface board and ADCVI board - If the fault cannot be eliminated call local ABB service organization 			x	x	
Link D Lost	Loss of internal communication links	<ul style="list-style-type: none"> - Check connectors on interface board and ADCVI board - If the fault cannot be eliminated call local ABB service organization 			x	x	

Table 8-1 Error messages and fault elimination (Continued)

Message	Possible cause/ meaning of message	Suggested remedy	Indication	Alarm	Fault	MCB open	Comments
Link E Lost	Loss of internal communication links	<ul style="list-style-type: none"> - Check connectors on interface board and ADCVI board - If the fault cannot be eliminated call local ABB service organization 			x	x	
LS Print MI	Voltage supervision across di/dt choke not active Possible reason: - cabling or connection disturbed	<ul style="list-style-type: none"> - Check connectors on interface board and VLSD board - If the fault cannot be eliminated call local ABB service organization 			x	x	
LS Print PL	Voltage supervision across di/dt choke not active Possible reason: - cabling or connection disturbed	<ul style="list-style-type: none"> - Check connectors on interface board and VLSD board - If the fault cannot be eliminated call local ABB service organization 			x	x	
Macr-Change	User macro has been changed	-		x			
MCB Control	Converter control is unable to operate the main circuit breaker Possible causes: - Parameter setting for MCB control not correct - MCB tripped or in test position - Malfunction of MCB - wiring in MCB control circuit disturbed - Shielding of control cables not properly grounded	<ul style="list-style-type: none"> - Check if parameter settings are correct and correspond with circuit breaker requirements: Parameters 21.05 to 21.10. For details refer to MCB specifications and <i>Appendix K - Signal and Parameter Table</i>. - Check MCB operation following MCB user manual and circuit diagram. - Check external wiring and shielding of emergency stop circuit - If the fault cannot be located, call local ABB service organization 	x		x	x	

Table 8-1 Error messages and fault elimination (Continued)

Message	Possible cause/ meaning of message	Suggested remedy	Indication	Alarm	Fault	MCB open	Comments
MCB Dis-crep	One feedback signal from MCB missing Possible causes: - Parameter setting for MCB control not correct - Malfunction of MCB - Wiring in MCB control circuit disturbed - Shielding of control cables not properly grounded	- Check if parameter settings are correct and correspond with circuit breaker requirements: Parameters 21.05 to 21.10. For details refer to MCB specifications and <i>Appendix K - Signal and Parameter Table</i> . - Check MCB operation following MCB user manual and circuit diagram. - Check external wiring and shielding of emergency stop circuit - If the fault cannot be located, call local ABB service organization		x			Two feedback signals do not correspond
MCB Disturb	MCB opens during operation Possible causes: - Parameter setting for MCB control not correct - MCB tripped or in test position - Malfunction of MCB - Wiring in MCB control circuit disturbed - Shielding of control cables not properly grounded	- Check if parameter settings are correct and correspond with circuit breaker requirements: Parameters 21.05 to 21.10. For details refer to MCB specifications and <i>Appendix K - Signal and Parameter Table</i> . - Check MCB operation following MCB user manual and circuit diagram. - Check external wiring and shielding of emergency stop circuit - If the fault cannot be located, call local ABB service organization	x		x	x	
MCB Not-Avl	MCB faulty, drawn out, in "local" mode, etc.	- Check MCB position and operating mode - Check MCB operation following MCB user manual and circuit diagram. - Check external wiring and shielding of emergency stop circuit - If the fault cannot be located, call local ABB service organization		x			

Table 8-1 Error messages and fault elimination (Continued)

Message	Possible cause/ meaning of message	Suggested remedy	Indication	Alarm	Fault	MCB open	Comments
Mot Phase L	SW function - motor phase loss Possible causes: - Motor cabling - Current transformer malfunction	<ul style="list-style-type: none"> - Verify cable connections - Check that motor contactors and safety switches are in proper positions - Check if fault happens only sporadically. If this is the case, the trip might be caused by low speed reference - Check current measurement signals - If the fault cannot be eliminated, call local ABB service organization 			x	x	
Mot Prot SW	Internal motor supervision	<ul style="list-style-type: none"> - Check motor for excessive heat - If the fault persists, call local ABB service organization 			x		
MotCooler	Alarm from converter internal contactor - supervision for the motor cooler Possible causes: - Fault in external motor cooling circuit - Wiring in monitoring circuit disturbed - Poor grounding connections	<ul style="list-style-type: none"> - Check motor temperature - Check cooling equipment. Refer to manuals for motor and cooling - Check with logbook if alarm occurs repeatedly and record alarm conditions - Check wiring and connections between relay and converter. Check relay input wiring - Check cable shielding and grounding - If the fault cannot be eliminated, call local ABB service organization 		x			Optional
MotCooler	Trip from converter internal contactor - supervision for the motor cooler Possible causes: - Fault in external motor cooling circuit - Wiring in monitoring circuit disturbed - Poor grounding connections	<ul style="list-style-type: none"> - Check motor temperature - Check cooling equipment. Refer to manuals for motor and cooling - Check with logbook if fault occurs repeatedly and record trip conditions - Check wiring and connections between relay and converter. Check relay input wiring - Check cable shielding and grounding - If the fault cannot be eliminated, call local ABB service organization 			x		Optional

Table 8-1 Error messages and fault elimination (Continued)

Message	Possible cause/ meaning of message	Suggested remedy	Indication	Alarm	Fault	MCB open	Comments
MotHeater	Alarm from converter internal contactor - supervision for the motor heater Possible causes: - Fault in motor heater - Wiring in monitoring circuit disturbed - Poor grounding connections	- Check heater circuit resistance. See manual for motor heater and <i>Appendix G - Wiring Diagrams</i> - Check wiring and connections between relay and converter. Check relay input wiring - Check cable shielding and grounding - If the fault cannot be eliminated, call local ABB service organization		x			Optional
Motor Stall	SW function - Motor stall: sustained low speed and high current Possible causes: - load conditions do not match with motor and converter ratings - Incorrect parameter settings (e.g. stall frequency limit too high) - Motor load too high - Disturbance in driven equipment	- Check whether actual load conditions match motor and drive ratings - Check whether motor and converter ratings do match throughout the speed range. - Check motor stall parameters 30.02 to 30.04. Refer to <i>Appendix K - Signal and Parameter Table</i> - Check load condition and verify that driven equipment is working properly - If the fault cannot be eliminated, call local ABB service organization		x	x		Default setting: Not active
MotVibrat	Alarm from external protection relay - motor vibration level too high Possible causes: - Excessive motor vibrations due to unbalance or overheated bearing - Vibration measuring device defective - Wiring in monitoring circuit disturbed	- Check motor and bearings. For details refer to motor manual. - Check vibration monitoring device - Check power supply of monitoring device - Check wiring between external temperature measuring device and ACS 1000. Check input wiring of measuring device - Check cable shielding and grounding - If the fault cannot be eliminated, call local ABB service organization		x			Optional

Table 8-1 Error messages and fault elimination (Continued)

Message	Possible cause/ meaning of message	Suggested remedy	Indication	Alarm	Fault	MCB open	Comments
MotVibrat	Trip from external protection relay - motor vibration level too high Possible causes: - Excessive motor vibrations due to unbalance or overheated bearing - Vibration measuring device defective - Wiring in monitoring circuit disturbed	<ul style="list-style-type: none"> - Check motor and bearings. For details refer to motor manual. - Check vibration monitoring device - Check power supply of monitoring device - Check wiring between external temperature measuring device and ACS 1000. Check input wiring of measuring device - Check cable shielding and grounding - If the fault cannot be eliminated, call local ABB service organization 			x		Optional
MotWdgM-Los	Motor winding temperature measuring lost Possible causes: - measuring circuit output < 2 mA - Wiring in protection circuit disturbed - Shielding of control cables not properly grounded	<ul style="list-style-type: none"> - Check Input X31.3/X32.3, X31.4/X32.4 and X31.5/X32.5 on IOEC2 board (signals must be > 2mA) - Check power supply of monitoring device - Check wiring between external temperature measuring device and ACS 1000. - Check wiring to measuring device inputs - Check if shielding of control cables is properly grounded - If the fault cannot be eliminated, call local ABB service organization 		x			
MotWdg Temp HW	Motor winding temperature too high Possible causes: - excessive load - ACS 1000 parameters not properly adjusted to motor data	<ul style="list-style-type: none"> - Check motor ratings, load and cooling - Check torque and power limits (parameters 20.04 and 20.05) - Check motor temperature supervision parameters (parameters 13.21 to 13.35) - If the fault cannot be eliminated, call local ABB service organization 		x			sum of 3 signals

Table 8-1 Error messages and fault elimination (Continued)

Message	Possible cause/ meaning of message	Suggested remedy	Indication	Alarm	Fault	MCB open	Comments
MotWdg Temp HW	Motor winding temperature too high Possible causes: - excessive load - ACS 1000 parameters not properly adjusted to motor data	<ul style="list-style-type: none"> - Check motor ratings, load and cooling - Check torque and power limits (parameters 20.04 and 20.05) - Check motor temperature supervision parameters (parameters 13.21 to 13.35) - If the fault cannot be eliminated, call local ABB service organization 			x		sum of 3 signals
Mot Wdg Temp SW	Motor winding temperature calculation by control SW Possible causes: - excessive load - ACS 1000 parameters not properly adjusted to motor data - Operation at low speeds	<ul style="list-style-type: none"> - Check torque and power limits (parameters 20.04 and 20.05) - Check motor temperature supervision parameters. If necessary readjust the parameters: Parameters 30.01, 30.02 and 30.08 to 30.11. For details refer to <i>Appendix K - Signal and Parameter Table</i> - Check if parameter settings allow operation at low speeds. If motor is operated continuously at low speeds, additional cooling may be necessary - Check motor ratings, load and cooling - If the fault cannot be eliminated, call local ABB service organization 		x			
Mot Wdg Temp SW	Motor winding temperature calculation by control SW Possible causes: - excessive load - ACS 1000 parameters not properly adjusted to motor data - Operation at low speeds	<ul style="list-style-type: none"> - Check torque and power limits (parameters 20.04 and 20.05) - Check motor temperature supervision parameters. If necessary readjust the parameters: Parameters 30.01, 30.02 and 30.08 to 30.11. For details refer to <i>Appendix K - Signal and Parameter Table</i> - Check if parameter settings allow operation at low speeds. If motor is operated continuously at low speeds, additional cooling may be necessary - Check motor ratings, load and cooling - If the fault cannot be eliminated, call local ABB service organization 			x		

Table 8-1 Error messages and fault elimination (Continued)

Message	Possible cause/ meaning of message	Suggested remedy	Indication	Alarm	Fault	MCB open	Comments
No Cur Offs	Attempt to start the converter before the current offsets have been checked	- De-energize converter and close grounding isolator according to <i>Chapter 5 - Operation, De-energizing the ACS 1000, page 5- 12</i> (offset will be calculated automatically when grounding isolator is closed)			x	x	 <p>Danger: When MCB is open, wait 5 minutes before closing grounding switch!</p>
No Filt Data	Filter data missing	- Call local ABB service organization			x	x	
Offset	Offset calibration was not successful	-			x		
OS Fault	Operating system failure	- Call local ABB service organization			x	x	
OutplsolDis	Output isolator feedback discrepancy Possible causes: - Malfunction of isolator or isolator control - Wiring in isolator control circuit disturbed - Shielding of control cables not properly grounded	- Check isolator operation following isolator user manual and circuit diagram. - Check wiring and shielding of isolator control circuit - If the fault cannot be located, call local ABB service organization		x			Optional Two feedback signals do not correspond
OutsAirM-Los	supervision of ambient temperature measurement Possible causes: - Measuring circuit output < 2 mA - Wiring in protection circuit disturbed - Shielding of control cables not properly grounded	- Check if analog input <i>OUTSIDE AIR TEMP</i> on IOEC3 is >2mA - Check wiring and shielding of measuring circuit - If the fault cannot be located, call local ABB service organization		x	x		Water cooled converters only

Table 8-1 Error messages and fault elimination (Continued)

Message	Possible cause/ meaning of message	Suggested remedy	Indication	Alarm	Fault	MCB open	Comments
OutsAir-Temp	Supervision of ambient temperature Possible causes: - High ambient temperature - External measurement device defective - Parameter setting not correct - wiring in monitoring circuit disturbed - Shielding of cables not properly grounded	- Check ambient temperature - If ambient temperature is within limits, check if analog input <i>OUTSIDE AIR TEMP</i> on IOEC3 is within range - Check limit parameter settings 81.16 to 81.20. For details refer to MCB specifications and <i>Appendix K - Signal and Parameter Table</i> - Check wiring and shielding of measuring circuit - If the fault cannot be located, call local ABB service organization		x			Water cooled converters only
OutsAir-Temp	Supervision of ambient temperature Possible causes: - High ambient temperature - External measurement device defective - Parameter setting not correct - wiring in monitoring circuit disturbed - Shielding of cables not properly grounded	- Check ambient temperature - If ambient temperature is within limits, check if analog input <i>OUTSIDE AIR TEMP</i> on IOEC3 is within range - Check limit parameter settings 81.16 to 81.20. For details refer to MCB specifications and <i>Appendix K - Signal and Parameter Table</i> - Check wiring and shielding of measuring circuit - If the fault cannot be located, call local ABB service organization			x		Water cooled converters only
Overspeed	SW function -Motor overspeed (supervision of rotation frequency) Possible causes: - Wrong parameter settings - Motor is forced to overspeed by driven equipment	- Check all parameters (start-up data) of group 99, particularly the nominal speed setting and compare with the motor nameplate - Check parameters in group 12 (reference select) and 20 (limits). Refer to <i>Appendix K - Signal and Parameter Table</i> - Check motor loading, especially if driven equipment is dimensioned correctly and functioning properly. Check with logbook if fault occurs repeatedly and record trip conditions - If the fault cannot be eliminated, call local ABB service organization			x		
Overvoltage	Voltage in the dc-circuit is too high in status "Ready to start"	-					

Table 8-1 Error messages and fault elimination (Continued)

Message	Possible cause/ meaning of message	Suggested remedy	Indication	Alarm	Fault	MCB open	Comments
Overvolt HW	HW supervision - detection of overvoltage in the dc-circuit Possible cause: - Mains supply voltage too high	<ul style="list-style-type: none"> - Verify measured dc-voltage (Parameters 2.02 to 2.09) - Check whether mains supply voltage is within the tolerated limits. See <i>Appendix A - Technical Data</i> - Adjust input transformer taps - If the fault cannot be eliminated, call local ABB service organization 			x	x	
Overvolt SW	Redundant SW supervision - detection of overvoltage in the dc-circuit Possible cause: - Mains supply voltage too high	<ul style="list-style-type: none"> - Verify measured dc-voltage (Parameters 2.02 to 2.09) - Check whether mains supply voltage is within the tolerated limits. See <i>Appendix A - Technical Data</i> - Adjust input transformer taps - If the fault cannot be eliminated, call local ABB service organization 			x	x	
Panel Lost	Control panel connection is disturbed	<ul style="list-style-type: none"> - Check if control panel is connected - Check control panel connection terminals - Replace control panel - If the fault cannot be eliminated, call local ABB service organization 		x			
Panel Lost	Control panel connection is disturbed	<ul style="list-style-type: none"> - Check if control panel is connected - Check control panel connection terminals - Replace control panel - If the fault cannot be eliminated, call local ABB service organization 			x		Active only if converter is in in torque control and local mode.
Press Stop	Alarm after Filter ID run has been completed	<ul style="list-style-type: none"> - Press the <i>STOP</i> key on the CDP 312 control panel 		x			
Process-Stop	Customer system protection input Possible causes: - Stop order from process - wiring in control circuit disturbed - Shielding of control cables not properly grounded	<ul style="list-style-type: none"> - Check if stop order is initiated by process (see process control) - Check external wiring and shielding of control cables - If the fault cannot be located, call local ABB service organization 	x	x			

Table 8-1 Error messages and fault elimination (Continued)

Message	Possible cause/ meaning of message	Suggested remedy	Indication	Alarm	Fault	MCB open	Comments
Process-Stop	Customer system protection input Possible causes: - Stop order from process - wiring in control circuit disturbed - Shielding of control cables not properly grounded	- Check if stop order is initiated by process (see process control) - Check external wiring and shielding of control cables - If the fault cannot be located, call local ABB service organization			x		
Pump 1/2	Trip - pump contactor supervision Possible cause: - Pump defective - Contactor disturbed	- Check contactor - Call local ABB service organization			x	x	Water cooled converters only
Pump 1/2	Alarm - pump contactor supervision in case of redundant pumps Possible causes: - Pump defective - Contactor disturbed	- Check contactor - Call local ABB service organization		x			Water cooled converters only
Ride Through	Ride through function has been activated Possible cause: - Undervoltage detection	- Check if alarm may be caused by a external event (e.g. temporary loss of supply voltage) and record these conditions in the logbook - If fault occurs repeatedly, call local ABB service organization		x			
Ride Through	Ride through function has not been successful Possible cause: - Not sufficient energy - Time criteria exceeded	- Check if trip may be caused by a external event (e.g. temporary loss of supply voltage) and record these conditions in the logbook - Restart the converter - If fault occurs repeatedly, call local ABB service organization			x		
Self Exci HW	HW supervision - detection of self excitation voltage level	- Verify measured dc-voltage (Parameters 2.02 to 2.09) - Check whether mains supply voltage is within the tolerated limits. See <i>Appendix A - Technical Data</i> - If this is not the case, call local ABB service organization			x	x	
Self Exci SW	SW supervision - detection of self excitation voltage level	- Verify measured dc-voltage (Parameters 2.02 to 2.09) - Check whether mains supply voltage is within the tolerated limits. See <i>Appendix A - Technical Data</i> - If this is not the case, call local ABB service organization			x	x	

Table 8-1 Error messages and fault elimination (Continued)

Message	Possible cause/ meaning of message	Suggested remedy	Indication	Alarm	Fault	MCB open	Comments
Short Cir MI	Supervision of di/dt choke voltage Possible causes: - short circuit in inverter minus pole	- Call local ABB service organization			x	x	
Short Cir PL	Supervision of di/dt choke voltage Possible causes: - short circuit in inverter plus pole	- Call local ABB service organization			x	x	
Short Circuit	if undervoltage alarm and fault appear in a time window of 200us, a short circuit in the rectifier has appeared	- Check fault history buffer for other, possibly related error messages - Call local ABB service organization			x	x	
SpeedRef-Los	Speed reference signal lost Possible causes: - Wrong parameter setting - Signal source or wiring disturbed - Shielding of control cables not properly grounded	- Verify parameter settings of limit parameters 13.23 (minimum limit for AI2 on IOEC2 board) and 30.18 (activating AI2) - Measure input signal at AI1 and verify correct signal level - Check external signal source - Check wiring and shielding of control cables - If the fault cannot be eliminated, call local ABB service organization		x	x		Default setting: alarm and maintain last set speed
Supp Phase L	SW function - supervision of supply phase is done by supervising the voltage ripple in the DC link Possible cause: - Loss of a phase or voltage unbalance	- Loss of a phase or voltage unbalance - If the fault cannot be located, call local ABB service organization			x	x	
Swfreq HW	HW function - switching frequency exceeds allowed limit Possible cause: - Control SW error	- Call local ABB service organization			x		
Swfreq SW	Switching frequency too high Possible cause: - System parameters not correct - Wrong current offset	- Check parameter group 99 - Readjust current offset (see error message <i>NO CUR OFFSET</i>) - If the fault cannot be eliminated, call local ABB service organization			x		
Tacho	Supervision of tachometer Possible causes: - Faulty tachometer - Tachometer not compatible with pulse encoder type	- Replace tachometer - If the fault cannot be eliminated, call local ABB service organization		x			Optional

Table 8-1 Error messages and fault elimination (Continued)

Message	Possible cause/ meaning of message	Suggested remedy	Indication	Alarm	Fault	MCB open	Comments
Tacho	Supervision of tachometer Possible causes: - Faulty tachometer - Tachometer not compatible with pulse encoder type	- Replace tachometer - If the fault cannot be eliminated, call local ABB service organization			x		Optional
TrafoTemp	Transformer winding temperature or oil temperature too high Possible causes: - Transformer load too high - Ambient temperature too high - Transformer cooling disturbed - Wiring in protection circuit disturbed - Shielding of control cables not properly grounded	- Check transformer load and ambient temperature and compare with rated figures (make record in logbook). Refer to transformer manual - Check if installation conditions are satisfactory (exposure to sun, obstacles in air flow etc.) - Check cooling equipment. Refer to description of cooling circuit in transformer manual - Check wiring of monitoring circuit (input /OIL TEMP TRIP on IOEC3 board) - Check if shielding of control cables is properly grounded - If the fault cannot be eliminated, call local ABB service organization		x			Optional
TrafoTemp	Transformer winding temperature or oil temperature too high Possible causes: - Transformer load too high - Ambient temperature too high - Transformer cooling disturbed - Wiring in protection circuit disturbed - Shielding of control cables not properly grounded	- Check transformer load and ambient temperature and compare with rated figures (make record in logbook). Refer to transformer manual - Check if installation conditions are satisfactory (exposure to sun, obstacles in air flow etc.) - Check cooling equipment. Refer to description of cooling circuit in transformer manual - Check wiring of monitoring circuit (input /OIL TEMP TRIP on IOEC3 board) - Check if shielding of control cables is properly grounded - If the fault cannot be eliminated, call local ABB service organization			x	x	Optional

Table 8-1 Error messages and fault elimination (Continued)

Message	Possible cause/ meaning of message	Suggested remedy	Indication	Alarm	Fault	MCB open	Comments
TrafTmpM- Los	Transformer winding or oil temperature supervision - loss of analog input Possible causes: - Measuring circuit output < 2 mA - Wiring in protection circuit disturbed - Shielding of control cables not properly grounded	<ul style="list-style-type: none"> - Check input <i>OIL TEMP</i> on IOEC3 board (signals must be > 2mA) - Check power supply of monitoring device - Check wiring between external temperature measuring device and ACS 1000. - Check wiring to monitoring device inputs - Check if shielding of control cables is properly grounded - If the fault cannot be eliminated, call local ABB service organization 		x	x		Optional Default setting: Alarm
TrOilLevel	Transformer oil level low Possible causes: - Incomplete filling - Oil leaking - Wiring in protection circuit disturbed - Shielding of control cables not properly grounded	<ul style="list-style-type: none"> - Check oil level and verify if a complete filling has been accomplished - Check oil gaskets, cooler and tank for damages - Check wiring of monitoring circuit (input <i>OIL LEVEL ALARM</i> on IOEC3 board) - Check if shielding of control cables is properly grounded - If the fault cannot be eliminated, call local ABB service organization 		x			
Tripping Loop	Tripping loop supervision Possible causes: - Protection trip - Open contact in loop - Tripping loop not connected	<ul style="list-style-type: none"> - Check if a protection function has initiated the trip - If not, check external trip circuits - If the fault cannot be eliminated, call local ABB service organization 			x		
Underload	SW function - Underload: motor torque drops below underload curve Possible causes: - Underload curve parameters are not set correctly - Motor load is too low for motor and converter ratings - Motor and converter ratings do not match	<ul style="list-style-type: none"> - Verify underload curve parameters (30.15 to 30.17). Refer to <i>Appendix K - Signal and Parameter Table</i> - Check that normal load is not too low - Verify that driven equipment is working properly - Check whether motor and converter ratings do match throughout the speed range. - If the fault cannot be eliminated, call local ABB service organization 		x	x		

Table 8-1 Error messages and fault elimination (Continued)

Message	Possible cause/ meaning of message	Suggested remedy	Indication	Alarm	Fault	MCB open	Comments
Undervoltage	Detection of temporary undervoltage in the DC-circuit.	<ul style="list-style-type: none"> - Check if alarm may be caused by a external event (e.g. temporary loss of supply voltage) and record these conditions in the logbook - Check fault history buffer for other, possibly related error messages - If fault occurs repeatedly, call local ABB service organization 		x			Ride through function is activated
Undervoltage	Trip due to detection of undervoltage in the dc-circuit.	<ul style="list-style-type: none"> - Check if trip may be caused by a external event (e.g. temporary loss of supply voltage) and record these conditions in the logbook - Check fault history buffer for other, possibly related error messages - If fault occurs repeatedly, call local ABB service organization 			x	x	
Wrong EPLD	Software version mismatch	-			x	x	
WtrCondM-Los	Water conductivity sensor - loss of analog input Possible causes: <ul style="list-style-type: none"> - Measuring circuit output < 2 mA - Wiring in protection circuit disturbed - Shielding of control cables not properly grounded 	<ul style="list-style-type: none"> - Check if analog input <i>WATER CONDUCTIVITY</i> on IOEC1 is >2mA - Check wiring and shielding of measuring circuit - If the fault cannot be located, call local ABB service organization 			x		Water cooled converters only
WtrConduct	Cooling water conductivity is above alarm limit	<ul style="list-style-type: none"> - Check piping for fouling - Check if all valves are in correct position - Replace ion exchanger resin - If the fault cannot be located, call local ABB service organization 		x			Water cooled converters only
WtrConduct	Cooling water conductivity is above trip limit	<ul style="list-style-type: none"> - Check piping for fouling - Check if all valves are in correct position - Replace ion exchanger resin - If the fault cannot be located, call local ABB service organization 			x	x	Water cooled converters only

Table 8-1 Error messages and fault elimination (Continued)

Message	Possible cause/ meaning of message	Suggested remedy	Indication	Alarm	Fault	MCB open	Comments
WtrLevel-Low	Water level in expansion tank is low Possible causes: - Leakage in cooling water circuit - Wiring in monitoring circuit disturbed - Shielding of cables not properly grounded	<ul style="list-style-type: none"> - Check cooling water level - Check if all bleed/drainage valves are closed - Check entire pipe system for leaks (pump packings, tube joints, tubes etc.) - If level is ok, check wiring and shielding of measuring circuit - If the cooling circuit is leaky or if the fault cannot be located, call local ABB service organization 			x	x	Water cooled converters only
WtrPres-Los	Water pressure measurement - loss of analog input	<ul style="list-style-type: none"> - Check if analog input <i>WATER PRESSURE</i> on IOEC1 is >2mA - Check wiring and shielding of measuring circuit - If the fault cannot be located, call local ABB service organization 			x		Water cooled converters only
WtrPres-sure	Cooling water pressure below alarm level	<ul style="list-style-type: none"> - Check water level in the expansion vessel - Check if all bleed/drainage valves are closed - Check entire pipe system for leaks (pump packings, pipe joints, pipes etc.) - If level is ok, check wiring and shielding of measuring circuit - If the cooling circuit is leaky or if the fault cannot be located, call local ABB service organization 		x			Water cooled converters only
WtrPres-sure	Cooling water pressure below trip level	<ul style="list-style-type: none"> - Check water level in the expansion vessel - Check if all bleed/drainage valves are closed - Check entire pipe system for leaks (pump packings, pipe joints, pipes etc.) - If level is ok, check wiring and shielding of measuring circuit - If the cooling circuit is leaky or if the fault cannot be located, call local ABB service organization 			x	x	Water cooled converters only

Table 8-1 Error messages and fault elimination (Continued)

Message	Possible cause/ meaning of message	Suggested remedy	Indication	Alarm	Fault	MCB open	Comments
WtrTemp	Water temperature above alarm level	<ul style="list-style-type: none"> - Check flow in the main water circuit - Check temperature and pressure in the raw water circuit - check the heat exchanger for fouling - If the cooling circuit is leaky or if the fault cannot be located, call local ABB service organization 		x			Water cooled converters only
WtrTemp	Water temperature above trip level	<ul style="list-style-type: none"> - Call local ABB service organization 			x		Water cooled converters only
WtrTempM-Los	Water temperature measurement - loss of analog input Possible causes: <ul style="list-style-type: none"> - Measuring circuit output < 2 mA - Wiring in protection circuit disturbed - Shielding of control cables not properly grounded 	<ul style="list-style-type: none"> - Check if analog input <i>COOLING WATER TEMP</i> on IOEC1 is >2mA - Check wiring and shielding of measuring circuit - If the fault cannot be located, call local ABB service organization 			x		Water cooled converters only

Table 8-2 Indication messages

Message	Possible cause/ meaning of message	Suggested remedy	Indication	Alarm	Fault	MCB open	Comments
Alarm	Summarized signal	- Check fault history display on control panel and proceed according to the specific alarm description	x				
Charging	DC voltage charging state	- none (normal operating status indication)	x				
Defect	A fault cannot be reset, because of a defect	- Call local ABB service organization	x				
Discharging	DC discharging state after switching off MCB	- none (normal operating status indication)	x				
EarthIs-clos	Grounding isolator is closed	- none (normal operating status indication)	x				
ID_Run Req	ID run is requested	- Call local ABB service organization	x				
ID_Run Selec	If ID run is selected	- none	x				
Magnetizing	Magnetization in progress, also indicating flying start	- none (normal operating status indication)	x				
MCB not on	Will be displayed if a start is tried when the MCB is not closed	- Proceed as described in <i>Chapter 5 - Operation</i>	x				
MotWillRun	Before/during ID run	- none	x				
No ID Run	Will be displayed if a start without preceding ID run is tried	- Carry out ID run - If you need assistance, call local ABB service organization	x				
Param Lock	Parameter is locked and can't be modified	-	x				
Process Stop	Customer system protection input Possible causes: - Stop order from process - wiring in control circuit disturbed - Shielding of control cables not properly grounded	- Check if stop order is initiated by process (see process control) - Check external wiring and shielding of control cables - If the fault cannot be located, call local ABB service organization	x	x			
Ready MCB on	Converter ready to energize	- none (normal operating status indication)	x				
Ready to Run	System ready - DC link charged, no faults pending	- none (normal operating status indication)	x				
Running	System running	- none (normal operating status indication)	x				

Table 8-2 Indication messages (Continued)

Message	Possible cause/ meaning of message	Suggested remedy	Indication	Alarm	Fault	MCB open	Comments
Stopping	System stopping	- none (normal operating status indication)	x				
Test sequence	Test after exchange of faulty part	- none	x				
Trip	Summarized signal	- Check fault history display on control panel and proceed according to the specific fault description	x				
Voltage control	Above upper or below lower limit	- Check fault history buffer for other, possibly related error messages	x				
Wait Time-out	Will be displayed if after a trip 3 a restart will be tried before the time for the zero voltage switching is over	- Check fault history buffer for other, possibly related error messages	x				
Write Protec	Will be displayed if it is tried to write over a protected parameter	- none	x				

Chapter 9 - Transportation, Storage, Disposal and Recycling

Introduction

In this chapter you will find all necessary information about proper transportation and storage of the ACS 1000 converter unit and the spare parts as well as about disposal and recycling of materials.

ABB Industrie AG has determined basic requirements for transportation and storage in order not to reduce the reliability of the converter. Environmental requirements for transportation and storage are included in this chapter and must be observed.

For information about ambient conditions during transportation and storage refer also to *Appendix A - Technical Data, Transportation and Storage, page A- 3*.

Environmental Requirements

The packing, transportation and storage conditions are defined on the basis of ABB / HDST4.15/l - Classifications and the following norms:

- Storage* • IEC 721-3-1 Code: 1K5/1Z1/1Z5/1B1/1C2/1S1/1M1
- Transportation* • IEC 721-3-2 Code: 2B1/2C2/2S1
- Stationary Use* • IEC 721-3-3 Code: 3K4/3Z1/3Z7/3B1/3C2/3S1/3M1

For more information please contact your ABB representative.

Packing

The converter is protected against external influences caused by either sea, air or road transportation. The packing is designed to give an optimal protection against



- contamination by water or dust

additionally for sea and air worthy packing against

- mechanical forces
- extreme climatic conditions

The packing is labeled with all relevant warnings and instructions for packaging, handling and storage.

Table 9-1 Warning and instruction labels on the converter packing

Label	Meaning	Application
A		<p>This way up</p> <p>Marked on all cases and open shipped components.</p>
B		<p>Fragile - handle with care</p> <p>Marked on cases containing fragile or sensitive to shock material.</p>
C		<p>Keep dry</p> <p>Marked on cases, plywood cases and cartons that are to be kept dry. Do not put on crates or cases meant for long term storage outdoors.</p>
D		<p>Center of gravity</p> <p>Marked on cases and components that are shipped unprotected (open) and require the indication of the center of gravity.</p>
E		<p>Sling here</p> <p>Marked on all cases and open components where ropes and chains are slung.</p>

The following symbol has become widely used and generally understood. Various customer packing specifications require a marking on the outside of the case if the inner packing of the goods requires the application of a desiccant.

	Label	Meaning	Application
F	 <p>Color of the label is black.</p>	packing with desiccant	On all cases requiring the application of a desiccant. Symbol preferably above the swivel cover of the inspection hole.

ABB's Quality Management assures that the packing of the converter unit corresponds to specific requirements regarding safety and cost efficiency.

The choice of the right conservation concept depends on the final destination of the goods, namely the climatic zone. (Zone A: temperate zone; zone B: tropical zone).

The conservation measures taken for the transport packing are only useful as long as the packing is kept unopened and in its original condition.

Loading and Unloading



For loading and unloading the converter with the help of a hoisting device, following points have to be observed:

Caution: The converter has to be transported in upright position.

Caution: Use always the lifting eyes on the top of the converter.


- The lifting eyes may only be removed after the converter has been installed at its final position. They have to be remounted if the converter has to be transported again.
- The material and diameter of the transport rope or chain have to correspond to the weight of the converter unit.

Lifting Angle The minimum lifting angle between the rope or chain and the converter unit is 45°. (see *Figure 9-1*)


Caution: The fan cover must not be mounted while lifting the converter unit.



Figure 9-1 Lifting Angle



Center of Gravity




Unpacking

For unpacking the converter following steps have to be followed:

- 1 Check the packing condition. Pay attention to damages by mechanical forces, water, humidity, heat or fire.

- 2 In case the packing has been damaged, please proceed as described in section *Transportation Damages*, page 9- 6.
- 3 Remove all packing material carefully (see *Figure 9-2*). Do not use sharp-edged or pointed devices to open the packing in order not to damage the converter casing.
- 4 Check the condition of the converter unit. Pay especially attention to:
 - bent doors and side walls
 - loose electric cables
 - unassembled parts
 - damaged parts
 - dust layers
 - water or humidity (indicator color on side of the box must be blue; if the color is red, the converter has been exposed to excessive humidity.)
 - damages by insects or vermin
- 5 Open the back panel of the inverter section and check the inside condition.
- 6 Check the condition of any accompanying equipment (such as transformer, motor). Please refer to the corresponding manuals.
- 7 Compare the complete delivery with your order. In case any parts are missing, please contact immediately your local ABB service organization and/or the shipping company.

Figure 9-2 Unpacking the converter



To unpack the converter, the following steps have to be followed:

- 1 Remove the top of the box
- 2 Remove the end and the side walls
- 3 Take off the bottom of the box
- 4 Check whether the converter has any transportation damages.

Transportation Damages

In case of transportation damages please proceed as follows:

- 1 Take several photos of the damage(s).
- 2 Return the Transportation Damage Description Form for the ACS 1000 (included at the end of this chapter) together with the photos to the shipping company and a copy to

ABB Industrie AG
Dept.: IA / Sales
CH-5300 Turgi
Switzerland
Fax: +41 56 2993400

Storage

Storage Conditions

The minimum requirements for storage are based on the following norms:

- ABB / HDST 601 070 Classification of environmental conditions.
- IEC 721-3-1 Code: 1K5/1Z1/1Z5/1B1/1C2/1S1/1M1
- IEC 721-3-3 Code: 3K4/3Z1/3Z7/3B1/3C2/3S1/3M1

Storage time: up to 1 year


Microclimatic class: ABB class / HDST 601 012

Pay attention to always fulfill the following conditions during the storage period:

Air temperature: -5° C to + 55° C (23° F to 131° F)

Relative air humidity: 5 to 85 %

Pay attention to always fulfill the ambient conditions during the storage period according to *Appendix A - Technical Data, Transportation and Storage, page A- 3*.



Notice: Take the following measures, if you want to store the converter unit for up to one year. In case of a longer storage period please contact the ABB service organization.

- 1 Place the converter on a wooden frame or pallet.
- 2 Cover all cable inlets and ventilation slots with a wooden panel. Put an impermeable plastic or aluminum foil between the wooden cover and the slots.
- 3 Add the desiccant of the appropriate quality: 1 unit desiccant (30g) absorbs 6g water vapor. According to the used packing material you need the following quantity:
 - PE sheet: 10 units/sqm foil
 - Aluminum foil: 8 units/sqm foil
- 4 Close and lock the doors of the converter unit.

- 5 Use the below listed polyethylene sheet or combined aluminum foil as protective packing and as a protection against moisture:
 - PE sheet: 0,3g/sqm/24h water vapor diffusion
 - Aluminum foil: 0,01g/sqm/24h water vapor diffusion
- 6 Attach humidity indicators (e.g. mechanical hygrometers) behind the protective foil. Place them for example on the front door of the converter.

Periodical Inspections

The storage conditions, the condition of the converter unit as well as of the packing should be checked monthly during the whole storage period. Pay special attention to damages caused by mechanical forces, water, humidity, heat or fire.

If the packing is damaged or if you discover damages caused by water, humidity, heat or fire you have to unpack the converter and check its inner and outer condition. Before storing the converter again, all storage damages have to be repaired. Store the converter as described above.

Battery

The battery has to be taken out of the converter unit for recharging every 6 months.

Storage Instructions for Spare Parts

In order to maintain the converter spare parts in good condition after the delivery and to keep the warranty valid during the warranty period the following must be taken care of:

- The storage place must be vibration and shock free and protected against dampness, frost, heat, dust and sand.

Transportation

The spare parts must be inspected immediately after receipt in order to detect possible transportation damages. Any damage must be reported immediately to the forwarder and insurance company. ABB does not take any responsibility for damages due to external circumstances.

Ambient Conditions

Humidity

The spare parts must be stored in their original packing in a dry, vermin and insect proof room. The place has to be free of corrosive gases.

Relative air humidity: 5 to 85 %

The electronic boards have to be stored in antistatic bags or boxes. The air must be free of corrosive gases, salt or other impurities that could damage electronic equipment and boards. No water condensation is allowed. If you are in doubt whether the maximum allowed humidity is exceeded, you should protect the spares by an external heater for example.

Temperature

The storage temperature range for spare parts is -5 °C to + 55 °C (23 °F to 131 °F), the same as for the converter unit.

Should you store any batteries, the air temperature should not exceed

30 °C (86 °F).


For more information about the warranty period and the condition of the spare parts please consult the commercial terms in the purchasing agreement.

Should you have further questions, please consult your local ABB office or the manufacturer:

ABB Industrie AG, Dept. IA
CH-5300 Turgi
SWITZERLAND

Tel +41 56 299 22 05
Fax +41 56 299 34 00

**Handling
Instructions for
Spare Parts**



Spare parts must be handled carefully and protected against electrostatic discharges always when taken out of the original factory packing. Improper handling may cause damage to sensitive components. The following handling instructions must be followed carefully:

Notice: Even over short distances the spare parts must be transported in packages that are protected against static electricity (cards in a bag or box and components in an enclosure or tube).

Notice: Handle a printed circuit board as if it were a rare collector's phonograph record. Hold the card by its edges. Avoid touching the card's terminals, components and folios.

Notice: Put the card or component down only on a grounded working surface that is protected against electrostatic discharges.

Notice: Handle a faulty card just as carefully as a new one and transport it or send it in a package that is protected against electrostatic discharges.

Temporary Shut Down

When shutting down the ACS 1000 temporarily, the unit must first be de-energized and grounded according to *Chapter 5 - Operation, De-energizing the ACS 1000, page 5- 12*. The same safety precautions as described in *Chapter 8 - Trouble Shooting & Repair, Safety Instructions, page 8- 1* apply.

The directions in *Storage, page 9- 6* are to be observed when placing the unit in storage.

Disposal of Packing Material

The packing is designed for minimum environmental impact. Parts of it are reusable. Dispose of packing material as prescribed by local legislation. If in doubt, ask your local environmental specialist or contact the local authorities.

Packing Material

Listed below is the packing waste arising from unpacking and installing the ACS 1000.

- Wooden frame
- Wooden pallet
- Polyethylene sheet
- Plywood
- Ethylene
- Silicagel

Disassembly and Disposal of Equipment

Before starting the disassembly of the ACS 1000, the unit must be de-energized and grounded according to *Chapter 5 - Operation, De-energizing the ACS 1000, page 5- 12*. The same safety precautions as described in *Chapter 8 - Trouble Shooting & Repair, Safety Instructions, page 8- 1* apply.

None of the materials used in the ACS 1000 give rise to a special threat to the environment when disposed of correctly. However, special attention must be paid to the following equipment when disposed of or recycled:

- Battery
- Capacitors
- Printed circuit boards
- Electronic components

Proceed according to local legislation and prescriptions.

**Transportation Damage Description Form
ACS 1000**

Company / Address:

Customer's Address:

Reporting person (Name / Phone / Fax):

.....

Type of ACS 1000:

ABB FAUF-No. / Serial No. (see nameplate):.....

.....

Scene of damage:

Date of damage: and/or realized Status of shock indicator:.....

Damage of packing visible:

Brief description of damage at the equipment:

.....
.....
.....
.....
.....
.....
.....
.....
.....

Date:

Customer's Signature:

Date:

Transport Company's Signature:.....

Please return this form to:

ABB Industrie AG
Dept. IA / Sales
CH-5300 Turgi

Fax: +41 56 2993400

Chapter 10 - Installation

Overview

In this chapter the mechanical and electrical installation of the ACS 1000 is explained. The instructions include cabinet mounting, grounding, mains, motor and control connections. For information on optional modules and other extras installed in your drive refer to *Appendix C - Customer Specific Options*.

Safety Instructions

The ACS 1000 is a high voltage device and when misused it can cause damage to personnel and property. When located, installed and connected in accordance with the instructions given in this manual, the device is safe.



Warning: All electrical installation and maintenance work on the ACS 1000 must be carried out by qualified electricians in compliance with local regulations.

Any installation work must be done with mains and auxiliary power off. Input and output isolators must be open and secured, any adjoining grounding device must be closed and power cables must be grounded.

Never apply power to the installation unless authorization is given by ABB commissioning staff.



Danger: Never work on a powered ACS 1000. The main circuit breaker and the input isolators must always be opened and secured. Do not access the main power circuit nor the motor as long as the system is not grounded.

When switching off the mains after initial energizing of the system, always allow the intermediate circuit capacitors to discharge before grounding and starting work on the frequency converter, the motor or the motor cable.

The ACS 1000 and adjoining equipment must be properly grounded and the auxiliary supply voltage must be switched off prior to starting with any work.



Danger: There can be dangerous voltages inside the ACS 1000 from external control circuits (measurement inputs from PT's etc.) even if the ACS 1000 mains power and auxiliary power are shut off. Take appropriate measures when working with the unit, i.e deenergize and disconnect all such external devices (auxiliary supply, heaters, coolers, I/O-interfaces) before you start work.

Prior to start working on the ACS 1000 the general safety regulations in *Chapter 1 - Safety Instructions* must be read and understood.

ABB Industrie AG declines all liability for any possible damage resulting from failure or negligence to observe these warnings.

Requirements to Foundation, Space and Ambient Conditions


Ambient Conditions See *Appendix A - Technical Data* for load capacity derating factors and other requirements related to ambient conditions. Derating may be necessary due to the presence of elevated levels in air temperature, altitude, or cooling water temperature. Sufficient air flow must be available (see *Figure 10-1*). Other ambient factors such as relative humidity, air contamination, and shock and vibration must also be in compliance with stated maximum permissible levels.

Base Dimensions and Clearances Drive unit dimensions are shown in drawing *Dimensions and floor mounting* (see *Appendix F - Layout and Mechanical Drawings*). All units must be mounted with adequate free space provided in accordance with *Figure 10-1*.

- Provisions for access to installation site (clearances of passageways etc.) and availability of transportation aids must be ensured prior to installation.

Figure 10-1 ACS 1000 free space requirements. (Dimensions are given in mm with equivalent inches in parenthesis.)

Above ⁽¹⁾	Below ⁽¹⁾	Left / Right	Front ⁽⁴⁾	Back
500 (20) ⁽²⁾⁽³⁾	0 (0)	0 (0)	1000 (39.4)	0 (0)



Notes:

- 1 Dimensions listed do not include space for cable entry which can be from top or from below.
- 2 Dimensions listed are above the blower hood.
- 3 This is a general recommendation to insure proper air flow; actual site conditions may allow this dimension to decrease or force it to increase.
- 4 Dimensions listed indicate maximum necessary door swing area. Additional space may be needed to meet local code requirements.

Floor Levelling and Cable Ducts

The ACS 1000 cabinet must be installed in upright position.

- The floor must be of non-flammable material, with smooth and non-abrasive surface, protected against humidity diffusion, levelled and able to support the weight of the converter (min. 1'000 kg/m²).
- Cable ducts must be of non-flammable material, with non-abrasive surface and protected against humidity, dust and penetration of animals.

Selection and Dimensioning of Power Equipment

The connection from the mains supply to the ACS 1000 drive consists of six basic elements:

- Main circuit breaker / controller
- Instrumentation and protection equipment
- Transformer primary cable
- Transformer
- Transformer secondary cable
- Cable termination - ACS 1000

Recommendations for the dimensioning and installation of each of these elements are given below. All applicable manufacturer's instructions and local regulations must be followed when installing this equipment. If any specific instruction as stated in this manual appears to be in conflict with the requirements, please contact your local ABB representative for further assistance.

Main Circuit Breaker / Controller

The main circuit breaker / controller can be either a vacuum or gas insulated circuit breaker or vacuum controller (medium voltage starter). In either case it should carry basic voltage and current ratings in accordance with the rated primary voltage and current levels of the transformer which is supplied. In addition to the basic electrical characteristics it must also meet specific drive requirements (some items require proper coordination with the instrumentation and protection equipment):

- Tolerate transformer inrush currents without tripping
- Clear transformer secondary short circuits within 100 ms
- Close in response to a close command

- Open within 60 ms in response to an open command (signal active when high)
- Open within 60 ms in response to a trip command (signal active when low)
- Provide a status output which indicates MCB closed
- Provide a status output which indicates MCB open
- Provide a status output which indicates MCB not available (vacuum circuit breaker in test position or vacuum controller disconnect switch in open position)

A configuration example with vacuum circuit breaker is shown in *Figure 10-2* and a configuration example with vacuum controller is shown in *Figure 10-3*.

Figure 10-2 Mains connection scheme with vacuum circuit breaker





Figure 10-3 Mains connection scheme with vacuum controller




Instrumentation and Protection Equipment

Adequate current transformers and protection relaying must provide protection for the transformer and the transformer primary cables. The intended approach for protection is shown in *Figure 10-4*. As shown in the figure the protection can be considered to consist of three areas. The first area identified as *transformer primary fault protection* is an instantaneous trip area that protects against short circuits in the transformer primary windings or in the cables supplying the transformer primary. The lower level of the trip threshold should be adjusted high enough to insure that nuisance tripping does not occur due to transformer inrush currents. The second area identified as *transformer secondary fault protection* is a short delay trip area that protects against short circuits in the transformer secondary windings, the cables from the transformer secondaries to the ACS 1000, or in the input rectifier stages of the ACS 1000. The short time delay provided should be adjustable and should be set long enough to insure that the protection does not trip due to transformer inrush current. The trip level should be adjusted low enough to insure that tripping will occur within 100 ms (including MCB delay time) even when transformers with high input impedance are applied. The final area identified as *overload protection* should provide long term overload protection with an inverse time characteristic. This area is intended to protect the transformer and cables from long term overload conditions.

The protection described can be provided with individual protection relays or with a single microprocessor based unit. Required current transformers

should be sized in accordance with the rated current levels of the transformer. Basic protection configuration and connection should be as previously shown in *Figure 10-2* and *Figure 10-3*.

Figure 10-4 Sample protection scheme



Transformer Primary Cable

The cable from the circuit breaker to the transformer primary has no special requirements. It should carry a voltage rating consistent with the voltage present in the primary circuit. The ampacity rating should be consistent with the size of the transformer being supplied and the protection settings of the protection equipment. Derating of cable ampacity in accordance with maximum expected ambient temperature, raceway fill factors, and any other factors required by local electrical codes should be applied. Installation should be in compliance with standard industry practice for medium voltage equipment.

If required by local electrical code an equipment safety ground wire should be supplied either separately or by including it in the 3 conductor cable. The ampacity of this conductor should be in accordance with the code.

Transformer

All ACS 1000 drives must be supplied from an isolation transformer with multiple phase shifted secondary windings designed in accordance with the pulse number of the input bridge (12 or 24). This transformer may be supplied from ABB with the ACS 1000 or may be supplied through another source in accordance with the specification provided by ABB. The design of the transformer must take into account user line conditions (voltage, short circuit capacity, existing harmonics, etc.) to insure compliance with harmonic standards invoked by the specification. Transformer quality is critical with respect to effecting proper limitation of harmonic currents and voltages. For more information concerning the transformer consult the documentation supplied with the order or reference the transformer specification which was provided when the order was placed.

Transformer Secondary Cable

The cables from the transformer secondaries to the ACS 1000 main power input buses are exposed to common mode voltages resulting from normal inverter operation of the ACS 1000. For this reason it is required that

cable rated 5 kV or higher be utilized for all transformer secondary cabling regardless of the transformer secondary voltage rating (1327, 1903, or 2305 VAC). Maximum installed cable length should not exceed 300 meters (1000 feet).

A cable with 3 individually shielded conductors is recommended in order to insure compliance with EMC requirements, and to provide a low impedance high frequency path through which the common mode currents can flow. Shields should be terminated and grounded in as short a distance as possible at both ends. The ACS 1000 includes a vertical ground bus within the cable termination compartment in order to facilitate this.

Non-shielded 3 conductor cable with a continuous corrugated aluminum armor may be used as an alternate to the individually shielded 3 conductor cable described above. Steel armored or interlocked aluminum armored cable should not be used. Connectors with 360° electrical contact to the armor should be used to terminate the cable ends to ground.

The ampacity rating of the cable should be consistent with 125% of the rated current of the ACS 1000 being supplied (allows for harmonic content) and the protection settings of the protection equipment. Derating of cable ampacity in accordance with maximum expected ambient temperature, raceway fill factors, and any other factors required by local electrical codes should be applied.

Installation should be in compliance with standard industry practice for medium voltage equipment. Cables must be terminated with connectors according to the cable manufacturer's requirements.

If required by local electrical code an equipment safety ground wire should be supplied either separately or by including it in the 3 conductor cable. The ampacity of this conductor should be in accordance with the code.

Motor Cable There are no special requirements to be considered for the cable from the ACS 1000 to the motor. It can be of any length provided that voltage drop is taken into consideration. A voltage rating consistent with the voltage present in the motor circuit must be selected. The ampacity rating should be consistent with the size of the motor being supplied and the overload settings of the motor protection software as input to the ACS 1000. Derating of cable ampacity in accordance with maximum expected ambient temperature, raceway fill factors, and any other factors required by local electrical codes should be applied. Installation should be in compliance with standard industry practice for medium voltage equipment.

Cable screening is not required for the motor cables since converter output voltage and current are sinusoidal. Therefore no measures against common mode currents are needed.

If required by local electrical code an equipment safety ground wire should be supplied either separately or by including it in the 3 conductor cable. The ampacity of this conductor should be in accordance with the code.

Motor cables are terminated within the ACS 1000 in the same way as transformer secondary cables. See *Electrical Installation, page 10- 16* for further details.

Power Cable Dimensions

Table 10-1 lists the recommended cross sections for mains and motor cables. In order to determine the exact dimensions for your application, the actual situation (method of installation, voltage drop due to cable length etc.) and local regulations must be considered. Refer also to the specifications of the cable manufacturer.

Table 10-1 Recommended cable cross section for power cables for the ACS 1000

Type (ACS...)	Motor & Rated Power (kVA)	Nominal current (A)	Ideal installation conditions			Worst case		
			Current density (A / mm ²)	No. of cables	Cross section (mm ²)	Current density (A / mm ²)	No of cables	Cross section (mm ²)
1014-A1	800	111	4,44	1	25	3,17	1	35
1014-A2	1.400	194	5,55	1	35	2,78	1	70
1014-A3	1.800	250	5,00	1	50	2,63	1	95
1014-W1	2.800	389	4,09	1	95	1,62	1	240
1014-W2	4.300	597	3,23	1	185	1,99	1	300
1014-W3	5.600	777	2,59	1	300	1,94	1	400
1013-A1	800	140	4,00	1	35	4,00	1	35
1013-A2	1.400	245	4,90	1	50	2,58	1	95
1013-A3	1.800	315	4,50	1	70	2,10	1	150
1013-W1	2.800	490	3,27	1	150	1,63	1	300
1013-W2	4.300	752	2,51	1	300	1,57	2	240
1013-W3	5.600	980	3,27	2	150	1,22	2	400
1012-A1	800	201	5,74	1	35	2,87	1	70
1012-A2	1.400	351	3,70	1	95	1,90	1	185
1012-A3	1.800	452	3,77	1	120	1,13	1	400
1012-W1	2.800	703	2,93	1	240	1,46	2	240
1012-W2	4.300	1.079	3,60	2	150	1,35	2	400

Comments: See following page

- 1 Apparent power has been taken instead of active power in order to consider the worst case situation
- 2 Insulation rating of the chosen cables for the transformer secondary side is 5 kV or higher
- 3 All chosen cables on the transformer secondary side are shielded / armoured
- 4 The bending radius has to be 10 to 15 times the diameter
- 5 The load factor of the cables is 100%
- 6 The value for the current density is the result of the actual current and the cable cross section

**Installation
Conditions**

Ideal: arrangement side by side in the free air flow, max.

temperature 30°C, max. conductor temperature 70°C

Worst case: installed in a cable duct under the surface, max. ambient temp. 30°C, max. conductor temperature 60°C

**Equipment
Grounding**

It is recommended that the ACS 1000 ground bus in the bottom of the cabinet is connected to the plant ground bus using a 240 mm² (500 MCM) cable.

**Auxiliary Power
Cable**

A 3-phase cable without neutral connector is required for auxiliary power supply. Type and ratings to be selected according to local regulations. For ratings see also *Appendix A - Technical Data*.

Control Cables

Control cables should be provided in accordance with *Table 10-2*. Cable shields should be terminated on the ACS 1000 end only. Either single or multiple twisted pair cables may be used.

Table 10-2 Control Cable Requirements

Signal Type	General Cable Type	Cross-Section (I/O Termination)
Analog In	Twisted pair(s) - Overall Shield	0.5 to 2.5 mm ² / AWG 20 to AWG 12
Analog Out	Twisted pair(s) - Overall Shield	0.5 to 2.5 mm ² / AWG 20 to AWG 12
Digital In	Twisted pair(s)	0.5 to 2.5 mm ² / AWG 20 to AWG 12
Digital Out	Twisted pair(s)	0.5 to 2.5 mm ² / AWG 20 to AWG 12

Cable Routing

Power Cables Routing of mains and motor cables must be carried out in compliance with the local regulations and according to the specifications and recommendations of the cable manufacturer.

- For best EMC performance it is recommended to use three phase cables that are individually shielded and with steel armouring.
- If single phase cables are used, the cables with the three different phases must be grouped close together to ensure EMC performance.
- Phase interchange must be accomplished according to local regulations.
- For high power ratings a maximum of two cables per motor phase can be accommodated by the gland plates of the ACS 1000.
- If the cross section of the cable shielding is less than 50% of the cross section of one phase, an additional grounding wire must be laid along the power cables to avoid excessive heating losses in the cable shieldings. Please refer to the local regulations for further details.

Cable Termination • Cables must be terminated with connectors according to the cable manufacturer's requirements.

Cable Length • The maximum length of the transformer secondary cables is limited to 300 m (1000 ft.). For longer distances special design measures must be considered.

• For the maximum length of the motor cables only the voltage drop in the cable must be taken into consideration. Since the converter output voltages and currents are nearly sinusoidal, reflections, which are typical for converters without output filter, do not occur.

Grounding Wire • Routing of the grounding connection must comply with local regulations. In some countries redundant cable routing is required. For grounding wire dimensions see also *Equipment Grounding, page 10-9*.

Control Cables • Control cables should not be laid in parallel to the power cables. If this cannot be avoided, a minimum distance of 30 cm (12 in) must be maintained between control and power cables.

• Control and power cables should be crossed at an angle of 90°.

Mains and Motor Cable Connection Diagrams *Figure 10-5* shows a typical mains cable connection. The actually applied connecting scheme must comply with local regulations.

Figure 10-5 Typical mains connection: 3-line diagram





Figure 10-6 shows a typical motor cable connection. The actually applied connecting scheme must comply with local regulations.

Figure 10-6 Typical motor connection: 3-line diagram



Mechanical Installation

This chapter provides instructions for moving the ACS 1000 cabinet to the mounting position, fastening it on the floor and preparing it for electrical connection.


Required Tools and Parts

For the installation the following tools are required:

- Basic set of tools
- Set of wrenches
- Drilling machine with concrete drill (for M12 bolts with dowels)
- Knife
- Megger
- Volt- and Ohmmeter
- Special tools as prescribed by cable manufacturer
- Fork lift, crane or other means for moving the ACS 1000

Preparation of Mounting Site

- 1 Before you proceed with the mechanical installation, make sure that all preconditions as described in Section *Requirements to Foundation, Space and Ambient Conditions* are fulfilled.



Note: The following mounting instructions apply for normal mounting conditions in industrial surroundings.


In case of special site conditions (such as ships, cranes etc.) contact your ABB representative for further information on the installation procedure.

- 2 Check the floor levelling with a spirit level. The maximum allowable overall unevenness is $\leq 5\text{mm}$.
If the floor is uneven, it must be levelled.
- 3 If power cables are to be installed from the bottom, provide floor cut-outs according to the arrangement of the cable glands as shown in drawing *Dimensions and floor mounting* (see *Appendix F - Layout and Mechanical Drawings*).
- 4 Drill mounting holes for M12 screws according to the drilling plan in drawing *Dimensions and floor mounting* (see *Appendix F - Layout and Mechanical Drawings*).
- 5 Insert dowels.

Displacement to Installation Site

- 6 If the ACS 1000 has to be moved by crane, mount the crane rails on the front and rear top edge of the converter (see *Figure 10-7*). Rails and screws (size M8/8.8, length 25mm) are part of the supply.

Figure 10-7 mounting crane rails




- 7 Move the ACS 1000 cabinet to the installation site and unpack. Proceed as described in *Chapter 9 - Transportation, Storage, Disposal and Recycling*.



Caution: The converter has to be transported in upright position.

Caution: Use always the lifting lugs on the top of the converter if it is moved by crane.

- 8 Open all cabinet doors including the back side of the inverter section. Check the converter and any accompanying equipment for possible transportation damages. For details please refer to *Chapter 9 - Transportation, Storage, Disposal and Recycling*. In case any parts are defective or missing, contact immediately your local ABB service organization and/or the shipping company.




Note: When re-installing the back panel of the inverter section, all fastening screws must be mounted and tightened in order to maintain EMC performance.

- 9 Close and lock the cabinet doors including the back side of the inverter section.

Mounting the Cabinet


- 10 Carefully move the cabinet to its final mounting position by levering it. Use, for example, an iron bar and place a wooden lath at the bottom edge of the cabinet as shown in *Figure 10-8*.

Figure 10-8 Levering cabinet to place




- 11 Fasten the cabinet with M12 screws and lock washer using the mounting foot fastening plates provided as shown in Figure 10-9. These clamps can be installed either by accessing them from the ends of the cabinet structure or via the access plates that are provided inside the cabinet.

Figure 10-9 Cabinet mounting



- 12** Assemble and mount the air exhaust onto the top of the control section. See *Figure 10-10 Mounting air exhaust*. Use the special M6 screws with rubber coating (part of supply)

Figure 10-10 Mounting air exhaust




- 13** Check that the doors can be opened and locked properly. If not, the cabinet levelling needs improvement.

Check the mechanical door interlock:

- Open the grounding switch: the front doors with the exception of the control door cannot be opened.
- Release the grounding switch lock override using a wire loop (see *Figure 10-11*) and close the switch: the front doors can be opened.

Re-adjust the levelling if the mechanical door interlock does not work properly.




Note: The front doors of the power sections of the ACS 1000 are mechanically interlocked with the ground switch and can only be opened when the ground switch is closed, i.e. the DC-circuit is grounded. The ACS 1000 is shipped with closed ground switch.

If for any reason the ground switch should be in open position and the doors cannot be opened, it is possible to override the door interlocking

system. Proceed as described in *Step 13* and *Figure 10-11*.

Figure 10-11. Grounding switch lock override




Warning: as soon as the installation is terminated, the cover plate must be re-mounted

Electrical Installation

Mains and Motor Cable Lead-In

The mains and motor cables are connected to the ACS 1000 in the left hand section (control section) of the cabinet as illustrated in *Figure 10-12*.

Figure 10-12 Principle of power cable lead-through




Mains and motor cable lead-through is from below or from the roof. The gland plates mounted on top of the control section must be relocated to the base of the cabinet if the cables are led in from below. The maximum conductor diameter is 45 mm.

Figure 10-13. Cable entries from top

Power cable entries

Aux. power and control
cable entries



To locate the terminals see *Figure 10-12* and drawing *Power and Auxiliary Terminals* (see *Appendix F - Layout and Mechanical Drawings*).

Connect the mains and motor cables for the ACS 1000 as described in the following section. Ground the motor cable screen on the motor side as well.

Inserting Mains and Motor Cables



Warning: All electrical installation and maintenance work on the ACS 1000 must be carried out by qualified electricians in compliance with local regulations.

Any installation work must be done with mains and auxiliary power off. Input and output isolators must be open and secured, any adjoining grounding device must be closed and power cables must be grounded.

Never apply power to the installation unless authorization is given by ABB commissioning staff.

For connecting the mains and motor cables to the ACS 1000 proceed as described below (for installation instructions of motor, transformer and other equipment please refer to the relevant manuals):

- 1 Make sure that the ACS 1000 is disconnected from the mains and auxiliary supply network during installation:
 - main circuit breaker (MCB) must be open and in service position (i.e. disconnected from mains and grounded)
 - Motor is disconnected from mains and grounded

- Auxiliary power supply fuse is open
 - Any control equipment to be connected with the ACS 1000 is disconnected.
- 2 Open the cabinet door of the control section.
 - 3 Open the control swing frame and the protective separation door behind it. All power terminals are now accessible.
 - 4 To take measurement for conductor length, strip the mains and motor cables and lead the conductors into the cabinet through the gland plate.



Warning: Do not cut cables inside the cabinet. Make sure that dust and chips from cable cutting and stripping cannot enter the cabinet.

Electrically conducting dust may cause damage or lead to malfunction.

- 5 Mark the required conductor length and withdraw the cables. Cut them to length, strip conductor ends and mount connectors (diameter of cable lug max. M12).
- 6 Lead the conductors into the cabinet through the EMC sleeves of the gland plate as shown in *Figure 10-14* and *Figure 10-15*:
 - Strip cable insulation in the gland area. Tighten the EMC sleeve on the stripped part of the cable with cable ties.
 - Remove the gland plate if cable entry is not possible otherwise and slide it onto the cable. After the grounding connections are made, fasten the gland plate.
 - *IP 54:* Remove the rubber grommets from the gland plates and cut them to adequate diameter for the mains and the motor cable (*Figure 10-15*). To ensure proper sealing, cut along the diameter marking that corresponds to the cable diameter. Slide the grommet onto the cable (*Figure 10-14*). The grommet must sit close in order to prevent water from entering the cabinet. If necessary, seal the junctions with silicone rubber.

Figure 10-14 Cable entry for power cables of ACS 1000 (IP 20 and IP 22). Tighten the EMC sleeve on the stripped part of the cable with cable ties. For IP 54 units, add a rubber grommet on the cable.






Figure 10-15 Cutting rubber grommets to size



- Grounding Connections**
- 7 Lead the grounding wire into the cabinet through an EMC sleeve of the gland plate and fasten it to the grounding bar. If there is no free gland available, lead the grounding wire together with a phase conductor into EMC sleeve.

Figure 10-16 Grounding wire and phase conductor combined in one EMC-sleeve.



Insulation Checks Carry out cable insulation test before connecting the cables:

- 8 Check insulation of each cable with open ends when in final position and check that the results are within the specifications of the cable manufacturer.

**Mains and Motor
Cable Connections**


- 9 Remove bus stubs from power terminals (see *Figure 10-17*). Drill holes (max. M12) for accommodation of cable terminals according to your needs. Terminal screw sizes are to be selected according to cable requirements.



Warning: Do not drill inside the cabinet. Make sure that dust and chips from drilling cannot enter the cabinet. If necessary, remove the bus stubs and drill the mounting holes outside the cabinet.


Electrically conducting dust may cause damage or lead to malfunction.

Figure 10-17 Power terminals with removable bus stubs




- 10 Using the bus stubs, connect the phase conductors of the mains cables to the U1, V1 and W1 terminals and the phase conductors of the motor cable to the U2, V2 and W2 terminals. See *Figure 10-18*. Refer to connector specifications for tightening torques.

Figure 10-18 Principle of power cable lead-through



Cable lead through from top Cable lead through from below

- 11** Connect the shielding ends of all conductors to the grounding bar using pigtailed; (1) in Figure 10-18.
- 12** Close the protective separation door and fasten it with the supplied screws (M6). **All 36 joints must be fixed.**
- 13** Fasten gland and blind plates with the supplied screws (M6). **All joints must be fixed.**



Note: When closing the protective separation door and rearranging the plates, all provided screws must be mounted and tightened in order to maintain EMC performance.


Auxiliary Power Cable Connection

Auxiliary power cable lead-through is from below or from the roof of the control section.

Proceed as follows:

- 14** Lead the auxiliary power cables into the cabinet through the EMC slot of the gland plate that leads to the front area of the control section.
 - *If shielded cables are used:* Strip cable insulation in the gland area. The conductive cushions of the EMC slot should contact the stripped part of the cable. See Figure 10-19.


Figure 10-19 Auxiliary power cable lead-in



- *IP 54 and cable entry from above:* Remove the rubber grommets from the gland plate and cut them to adequate diameter for the auxiliary power cable. To ensure proper sealing, cut along the diameter marking that corresponds to the cable diameter. Slide the grommet onto the cable. The grommet must sit close in order to prevent water from entering the cabinet. If necessary, seal the junctions with silicone rubber.
- Loosen position screws of the lead-trough plate and lead the cables inside the cabinet.
- Push the two halves of the lead-through plate together and tighten the screws. The EMC conductive cushions should press tightly around the bare screens.

- 15 Connect the cable to terminals X10 (U, V, W, PE). To locate the terminals see dimensional drawings (*Appendix G* in this manual).
- 16 *If shielded cables are used:* connect cable shielding to PE, e.g. by using a pigtail (see *Figure 10-20*).

Figure 10-20 Auxiliary power cable connection




Control Cable Connection



Danger: There can be dangerous voltages in the control cables from external circuits (contact sense voltages etc.) even if the ACS 1000 mains power and auxiliary power are shut off. Take appropriate measures when working with the unit, i.e deenergize any external device before you start work.

- 17 Lead the control cables into the cabinet through the EMC slot of the gland plate that leads to the front area of the control section.
 - Strip cable insulation in the gland area. The conductive cushions of the EMC slot should contact the stripped part of the cable. See *Figure 10-21*. If the surface of the screen is covered with nonconducting material, cut the screen carefully without damaging the conductors and reverse-draw it over the insulation (see *Figure 10-21 bottom*).

Figure 10-21 Control cable lead-in




- *IP 54 and cable entry from above:* Remove the rubber

grommets from the gland plate and cut them to adequate diameter for the auxiliary power cable. To ensure proper sealing, cut along the diameter marking that corresponds to the cable diameter. Slide the grommet onto the cable. The grommet must sit close in order to prevent water from entering the cabinet. If necessary, seal the junctions with silicone rubber.

- Loosen position screws of the lead-trough plate and lead the cables inside the cabinet.
- Push the two halves of the lead-through plate together and tighten the screws. The EMC conductive cushions should press tightly around the bare screens.


18 Mark each conductor with stick-on tags for easy identification.

19 Connect the cables to signal terminals X300, X301 and to the IOEC boards (see *Figure 10-22*). They are located to the right hand side of the swing frame. To locate the terminals see dimensional drawings (*Appendix G* in this manual).




Note: Control cable shields must be terminated on the ACS 1000 end only.

Figure 10-22 Control section view, shows the swing frame removed. The I/O boards, signal terminals and auxiliary terminals can also be seen. The door covering power terminals in the rear section of the cubicle is closed.



- 20 Connect the cables to the external control terminals.
- 21 Check that the protective separation door as well as the gland and blind plates are fastened with the supplied screws (M6). **All joints must be fixed.**



Note: all provided screws must be mounted and tightened in order to maintain EMC performance.

Wiring Tests

- 22 Carry out wiring check.

A functional test of the control circuits will be made during commissioning.

- 23 Close the control swing frame.

Final Work



Warning: Never apply power to the installation unless authorization is given by ABB commissioning staff.

Preparation for commissioning

See *Chapter 11 - Commissioning*.

Chapter 11 - Commissioning

Overview

The ACS 1000 may only be commissioned by ABB staff or by their authorized representative.

Functional testing, commissioning and first parameter adjusting is carried out by the technicians of ABB. Testing, final parameter adjustment and performance tests are carried out by ABB staff with the customer present.

Preparation of Commissioning

Check the following preconditions which must be fulfilled before commissioning can be started:

General Preconditions

1 Installation of the ACS 1000 must be completed according to *Chapter 10 - Installation*.

High Voltage Equipment

- 2 High voltage (HV) switchgear is connected and in operable condition.
- 3 Converter transformer is installed, connected and ready for operation.
- 4 The motor is installed, aligned, connected and ready for operation.
- 5 Grounding cables of transformers, converter and motor are connected.
- 6 All cable screens are connected.
- 7 Insulation of cables, transformers and motor has been tested and complies with the specification (insulation test of the converter will be performed by the commissioning engineer). An official test report is available.
- 8 Mains voltage supply is available.
- 9 The driven load (pump, fan, compressor etc.) is ready for coupling and for operation under nominal conditions.

Auxiliary Voltage Supply and Control

- 10 All auxiliary cables are connected
- 11 Auxiliary voltage switchgear is connected and operable
- 12 Control cables are connected:
 - MCB control cables are connected directly to the converter
 - Tripping loop
 - Remote control cabling
 - Cabling of options (Transformer and motor protection, tachometer etc.)
- 13 Auxiliary voltage supply is available.
- 14 the plate of the grounding switch lock override is attached and secured

Cooling Circuit

- 15 Raw water circuit connected to the converter (if applicable)

16 Raw water according to *Chapter 10 - Installation* is available (if applicable)

Miscellaneous 17 All spare parts are available.

18 All necessary process information has been handed over to your ABB sales representative. For details please contact ABB.

19 *For water cooled converters only:* Sufficient deionized water for filling the cooling system of the ACS 1000 is available.

Commissioning Procedure

The commissioning procedure will last 1 to 2 days excluding any waiting time.

Required Customer Manpower

During the whole commissioning period, the customer must provide 1 qualified electrical professional who is

- familiar with medium and low voltage equipment and with the local safety regulations
- familiar with the driven process
- authorized to operate the associated medium and low voltage equipment (MCB, other MV and LV switchgear etc.)
- authorized to operate the driven process for testing purposes.

Acceptance

When commissioning is completed, the commissioning report will be signed by the customer as sign of acceptance and by the ABB commissioning engineer. One copy of this report will be handed out to the customer, the second copy will be sent to ABB Headquarters. The customer will then receive a confirmation from ABB Headquarters including a record of all parameter settings as they were set during commissioning.

Warranty

Warranty will start on the date of acceptance, i. e. upon signing of the commissioning report by both parties, and will last 1 year.

A

- ABB service address 7-12
- Active fault 5-17, 8-3
- Actual signal 3-19
- Actual Signals B-5
- Actual signals 5-15, 6-2
 - Full signal name display 5-17
- Air filters replacement 7-8
- Alarm handling 8-2
- Analog input 3-21, 4-1
- Analog output 3-19, 4-1
- Application macros 4-11, 6-2
 - Factory 4-1, 4-11, 4-13
 - Hand/auto 4-1, 4-11, 4-17
 - Master/follower 4-1, 4-11, 4-34
 - PID control 4-1, 4-11, 4-22
 - Selection 6-11, 6-13
 - Sequential control 4-1, 4-11, 4-30
 - Torque control 4-1, 4-11, 4-26
- Assembly description 3-5
- Automatic reset 3-27

B

- Battery replacement 7-11
- Battery test 3-25

C

- Cabinet design 3-5
- Cable
 - Connections 10-22
 - Wiring tests 10-28
- Cable connection diagrams 10-10
- Cable dimensions 10-8
- Cable ducts 10-3
- Cable routing 10-10
- Cables 10-16
- CDP 312 3-1
- Charging fault 3-24
- Cleaning 7-7
- Clearances 10-2
- Commissioning 10-28, 11-1
 - Acceptance 11-2
 - General procedure 11-2

- Required customer manpower 11-2
- Common mode choke 3-3
- Common mode damping resistor 3-3
- Communication fault 3-25
- Constant speeds 3-14
- Control equipment 3-1, 3-9
- Control functions 3-11
- Control location 3-20
- Control panel 3-1, 3-10, 8-3, B-1
 - Contrast 5-19
 - Display 5-1
 - keys B-4
- Control system 3-4
- Cooling circuit 3-8
- Critical speed 3-14

D

- De-energizing the ACS 1000 5-12
- Device type B-3
- Digital input 4-1
- Digital output 3-19, 4-1
- Dimensioning of auxiliary power cable 10-9
- Dimensioning of control cables 10-9
- Dimensioning of power equipment 10-3
 - Cables 10-6
 - Protection Equipment 10-5
- Direct torque control (DTC) 3-4, 3-11
- Direction B-3
- Disabling local operation 5-10
- Disassembly 9-9
- Disposal 9-9
- Door locks 3-8
- DriveLink 3-28
- DriveSupport 3-29
- DriveWindow 3-28
- DTC block diagram 3-4

E

- Electromagnetic compatibility (EMC) 3-5
- Elementary diagram 3-2
- Emergency off 3-26, 5-14
- Equipment grounding 10-9
- Error messages 8-8

F

- Factory Macro
 - external connections 4-10, 4-15, 4-20, 4-24, 4-28, 4-32, 4-36
- Factory macro
 - Operation diagram 4-13
- Fan bearings replacement 7-10
- Fan replacement 7-8
- Fault display 8-3
- Fault elimination 8-8
- Fault functions 3-22
- Fault handling 8-2
- Fault history 3-19, 5-18, 8-4
 - clearing B-7
 - displaying B-7
- Faults
 - displaying B-8
 - resetting B-8
- Filter ID run 3-12
- Floor levelling 10-3
- Flux optimization 3-12
- Flying start 3-12
- Functional Description 3-1
- Functional description 3-2

G

- Ground fault 3-25
- Grounding 10-9
- Grounding connections 10-21
- Grounding isolator 5-3, 5-12, 10-16
- Grounding switch lock override 10-16

H

- Hand/auto macro
 - operation diagram 4-17, 4-22
- Humidity 9-7

I

- I/O boards 4-1
- ID-number B-3
- ID-run
 - fault 3-25
- Information 3-27
- Input signal source selections 3-20
- Installation 10-1
 - Ambient Conditions 10-2

- Base dimensions and clearances 10-2
- Electrical 10-16
- Foundation 10-2
- Mechanical 10-12
- Required tools and parts 10-12
- Safety 10-1
- Insulation check 10-21
- Intended purpose of use 1-3
- Intermediate DC link voltage 3-24
- Inverter
 - Loadability 3-24
 - Short circuit 3-25

L

- Layout 3-5
- Lifting arrangements 3-8
- Limits 3-26
- Local B-3
- Local control 3-18, 5-9

M

- Main circuit breaker
 - closing 5-4
- Main circuit breaker (MCB) 3-17, 3-26, 10-3
- Maintenance 7-1
 - Check of connections 7-7
 - Logbook 7-12
 - Required tools 7-4
 - Safety 7-1
 - Standard procedure 7-4
- Maintenance schedule 7-3
- Measurement loss 3-25
- Motor ID run 3-11, 6-15
- Motor phase loss 3-24
- Motor protection 3-26
- Motor stall 3-22
- Motor winding temperature 3-22

O

- Offset calibration 3-21
- Operation 5-1
- Options
 - Customer specific C-1
- Overcurrent 3-24
- Overspeed 3-23
- Overvoltage 3-24

P

- Packing 9-1
- Parameter
 - Backup 7-11
 - Downloading 6-17
 - Editing 6-6
 - Modification 6-14
 - Parameter groups 6-1
 - programming procedure 6-3
 - Recalling user macro parameters 6-22
 - Restoring default settings 6-19
 - Safety 6-1
 - Uploading 6-16
 - Verification 6-14
- Parameter Groups 6-1
- Parameter lock 3-27, 6-16
- Parameters
 - selecting B-8
- phase Loss 3-24
- PID controller 3-28
- Power circuit interface
 - Input circuit 3-3
 - Output circuit 3-3
- Power loss ride-through 3-12
- Preparation of mounting site 10-12
- Process monitoring 5-14
- Process stop 3-26
- Protection equipment 10-5

R

- Ramp functions 3-13
- Reference
 - setting B-14
 - value B-3
- Reference signal processing 3-20
- Remote B-3
- Remote control 3-18, 5-9
- Repair work 8-7
- Resonance frequency damping (RFD) 3-14, 3-28
- Run status B-3

S

- Safety 1-1
 - Commissioning 1-1
 - Concept 1-2
 - Improper behavior 1-4

- Installation 1-1, 10-1
- Labels 1-2
- Maintenance 1-1, 7-1
- Operation 5-1
- Parameter 6-1
- Residual danger areas 1-3
- Responsibilities 1-1
 - Trouble shooting 8-1
- Selection of actual signals 6-7
- Sense of rotation 5-8
- Service address 7-12
- Setpoint
 - changing 5-7
 - entering 5-6
- Short circuit
 - Rectifier 3-24
- Signals
 - Main circuit breaker 4-3
 - Motor 4-4
 - Others 4-5
 - Process 4-5
 - Remote control interface 4-2
 - Transformer 4-3
- Spare parts
 - Handling 9-8
- Speed
 - Accurate speed control 3-16
 - Constant speeds 3-14
 - controller 3-15
 - response 3-15
- Squirrel cage induction motors 3-1
- Standards fulfilled 3-1
- Start operation 5-2
- Start-up parameters 6-1, 6-7
- Status row B-3
- Stopping the ACS 1000 5-11
- Storage 9-6
 - Ambient conditions 9-7
 - Battery 9-7
 - Periodical Inspections 9-7
 - Spare parts 9-7
- Supervision 3-27

T

- Technical data 3-1
- Temporary shut down 9-9
- Torque
 - Accurate torque control 3-16
 - Full torque at zero speed 3-12

Training of personnel 1-4
Transformer protection 3-26
Transportation 9-1
 Damages 9-6
 Displacement to installation site 10-13
 Environmental requirements 9-1
 Lifting Angle 9-4
 Loading 9-3
 Unloading 9-3
 Warning and instruction labels 9-2
Trouble shooting
 Safety 8-1
 Standard procedure 8-5

U

Underload 3-22
Undervoltage 3-12, 3-23
Unpacking 9-4
User Macro 6-20
User macros 6-20

W

Warranty 11-2
Wiring tests 10-28