

ACTUATOR LA14



To learn more about LINAK, please visit:

WWW.LINAK.COM

Contents

Preface5

LINAK application policy.....6

Chapter 1

Safety instructions..... 7-8

Chapter 2

Mounting guidelines 9-10

Mounting of cables..... 11

Electrical installation:..... 12

 Recommended fuse 12

 Actuator without feedback 13

Actuator with:

 Relative positioning - Single Hall..... 14-15

 Endstop signals and relative positioning - Single Hall 16-17

 Absolute positioning - Analogue feedback 18-19

 Endstop signals and absolute positioning - Analogue feedback 20-21

 Absolute positioning - Mechanical potentiometer feedback..... 22-23

 Absolute positioning - PWM..... 24-25

 Endstop signals and absolute positioning - PWM..... 26-27

 IC Basic..... 28-30

 IC Advanced - with BusLink..... 31-33

 Correct wiring of Power GND and Signal GND for IC Basic and IC Advanced.....34

 Actuator with Parallel..... 35-37

 The parallel system..... 38-39

 System monitoring for Parallel.....40

 Alignment of the parallel actuator system40

 Parallel manual service mode41

Contents

Chapter 3

Troubleshooting 42-43

Troubleshooting for Parallel..... 44-46

Chapter 4

Specifications..... 47

Usage 47

Actuator dimensions 48

Speed and current curves:..... 49-50

 12V motor..... 49

 24V motor..... 50

Test of conducted and radiated emission..... 51

Label for LA14 52

Key to symbols..... 53

LA14 Ordering example 54

Chapter 5

Maintenance..... 55

Repair 55

Main groups of disposal..... 55

Warranty 56

Declaration of conformity 57

Declaration of incorporation of partly completed machinery..... 58

Adresses 60

Preface

Dear User,

We are delighted that you have chosen a product from LINAK®.

LINAK systems are high-tech products based on many years of experience in the manufacture and development of actuators, electric control boxes, controls, and chargers.

This user manual does not address the end-user, but is intended as a source of information for the manufacturer of the equipment or system only, and it will tell you how to install, use and maintain your LINAK electronics. It is the responsibility of the manufacturer of the end-use product to provide a User Manual where relevant safety information from this manual is passed on to the end-user.

We are sure that your LINAK product/system will give you many years of problem-free operation. Before our products leave the factory they undergo full function and quality testing. Should you nevertheless experience problems with your LINAK product/system, you are always welcome to contact your local dealer. LINAK subsidiaries and some distributors situated all over the world have authorised service centres, which are always ready to help you.

LINAK provides a warranty on all its products. This warranty, however, is subject to correct use in accordance with the specifications, maintenance being done correctly and any repairs being carried out at a service centre, which is authorised to repair LINAK products.

Changes in installation and use of LINAK products/systems can affect their operation and durability. The products are not to be opened by unauthorised personnel.

The User Manual has been written based on our present technical knowledge. We are constantly working on updating the information and we therefore reserve the right to carry out technical modifications.

LINAK A/S

LINAK application policy

The purpose of the application policy is to define areas of responsibilities in relation to applying a LINAK product defined as hardware, software, technical advice, etc. related to an existing or a new customer application.

LINAK products as defined above are applicable for a wide range of applications within Medical, Furniture, Desk, and Industry areas. Yet, LINAK cannot know all the conditions under which LINAK products will be installed, used, and operated, as each individual application is unique.

The suitability and functionality of the LINAK product and its performance under varying conditions (application, vibration, load, humidity, temperature, frequency, etc.) can only be verified by testing, and shall ultimately be the responsibility of the LINAK customer using any LINAK product.

LINAK shall be responsible solely that LINAK products comply with the specifications set out by LINAK and it shall be the responsibility of the LINAK customer to ensure that the specific LINAK product can be used for the application in question.

Chapter 1



Safety instructions

Please read this safety information carefully:

Be aware of the following three symbols throughout the user manual:



Warning!

Failing to follow these instructions can cause accidents resulting in serious personal injury.



Recommendations

Failing to follow these instructions can result in the actuator suffering damage or being ruined.



Additional information

Usage tips or additional information that is important in connection with the use of the actuator.

Furthermore, ensure that all staff who are to connect, mount, or use the actuator are in possession of the necessary information and that they have access to this user manual.

Persons who do not have the necessary experience or knowledge of the product/products must not use the product/products. Besides, persons with reduced physical or mental abilities must not use the product/products, unless they are under surveillance or they have been thoroughly instructed in the use of the apparatus by a person who is responsible for the safety of these persons.

Moreover, children must be under surveillance to ensure that they do not play with the product.

Before you start mounting/dismounting, ensure that the following points are observed:

- The actuator is not in operation.
- The actuator is free from loads that could be released during this work.

Before you put the actuator into operation, check the following:

- The actuator is correctly mounted as indicated in the relevant user instructions.
- The equipment can be freely moved over the actuator's whole working area.
- The actuator is connected to a mains electricity supply/transformer with the correct voltage and which is dimensioned and adapted to the actuator in question.
- Ensure that the voltage applied matches to the voltage specified on the actuator label.
- Ensure that the connection bolts can withstand the wear.
- Ensure that the connection bolts are secured safely.

During operation, please be aware of the following:

- Listen for unusual sounds and watch out for uneven running. Stop the actuator immediately if anything unusual is observed.
- Do not sideload the actuator.
- Only use the actuator within the specified working limits.
- Do not step or kick on the actuator.

When the equipment is not in use:

- Switch off the mains supply in order to prevent unintentional operation.
- Check regularly for extraordinary wear.

Classification

The equipment is not suitable for use in the presence of a flammable anaesthetic mixture with air or with oxygen or nitrous oxide.



Warnings

- Do not sideload the actuator.
- When mounting the actuator in the application ensure that the bolts can withstand the wear and that they are secured safely.
- If irregularities are observed, the actuator must be replaced.
- For actuators with a stroke length below 130mm, the extended position of the mechanical endstop will always be at 130mm. That means, if an actuator has a stroke of 80mm and the endstop switch in outwards direction fails, the actuator will travel additional 50mm before reaching mechanical endstop.



Recommendations

- Do not place load on the actuator housing and do prevent impact or blows, or any other form of stress to the housing.
- Ensure that the cable cover is mounted correctly. Use 1.5Nm torque.
- Ensure that the duty cycle and the usage temperatures for LA14 actuators are respected.
- Ensure that the cable cannot be squeezed, pulled or subjected to any other stress.
- Furthermore, it will be good practice to ensure that the actuator is fully retracted in the "normal" position. The reason is that there will be a vacuum inside the actuator if it is extended which over time can lead to water entering the actuator.
- If the actuator (without integrated controller) is mounted in an application where a mechanical stop prevents the endstop switches in the actuator from being activated, the actuator must be equipped with an electrical safety device (current monitoring) or external limit switch.

Chapter 2

Mounting guidelines

LINAK® linear actuators are quickly and easily mounted by slipping pins through the holes on each end of the units and into brackets on the machine frame and the load.

The mounting pins must be parallel to each other as shown in **Figure 1**. Pins, which are not parallel to each other, may cause the actuator to bend and be damaged.

The load should act along the stroke axis of the actuator as off-centre loads may cause bending and lead to premature failure. **See Figure 2.**

Make sure the mounting pins are supported in both ends. Failure to do so could shorten the life of the actuator. Also, avoid applying a skew load on the actuator.

The actuator can rotate around the pivot point in the front and rear end. If this is the case it is of high importance that the actuator is able to move freely over the full stroke length, both during the development and daily operation. Please pay special attention to the area around the housing where parts can be trapped and cause damage to the application and actuator.

In applications with high dynamic forces LINAK recommends not to use the fully extended or retracted position over longer time, as this can damage the endstop system permanently.

Figure 1





Figure 2



Right

Wrong

Wrong

Wrong

Mounting guidelines



- The mounting pins must have the correct dimension.
- The bolts and nuts must be made of a high quality steel grade (e.g. 10.8). No thread on the bolt inside the back fixture or the piston rod eye.
- Bolts and nuts must be protected so there is no risk for them to fall out.
- Do not use a torque that is too high when mounting the bolts for the back fixture or the piston rod eye. This will stress the fixtures.




Please note:

The piston rod eye is only allowed to turn 0-90 degrees.



Instruction concerning the turning of the piston rod eye and inner tube:

- When mounting and taking into use, it is not permitted to make excessive turns of the piston rod eye. In cases where the eye is not positioned correctly, it is permitted to first screw the eye down to its bottom position, at a maximum torque of 2Nm (1), and thereafter a maximum 90 degrees turn outwards again (2).
- As the piston rod eye can turn freely, it is important to ensure that the eye cannot rotate if the actuator is used in a pull application. If this happens, the actuator will be pulled apart and destroyed.



Warning!

If the actuator is used for pull in an application where personal injury can occur, the following is valid:

It is the application manufacturer's responsibility to incorporate a suitable safety arrangement, which will prevent personal injury from occurring, if the actuator should fail.




Warning!


LINAK's actuators are not designed for use within the following fields:

- Offshore installations
- Explosive environments
- Aeroplanes and other aircraft
- Nuclear power generation


Mounting of cables



1. Unscrew the cover




2. Remove the cover




3. Plug in the cable gently without using any tools

Removing cables



4. Screw the cover back onto the actuator

The torque of the cover screw is approx. 1.5 Nm



5. Use a screwdriver to pull up the cable



- When changing the cables on a LINAK actuator, it is important that this is done carefully, in order to protect the plugs and pins. Before the new cable is mounted, we recommend that the socket is greased with vaseline, to keep the high IP protection and ensure an easy mounting. Please be sure that the plug is in the right location and fully pressed in before the cable lid is mounted.
- We recommend to take some precaution and design the wire connection in a way, where the cable end is kept inside a closed, protected area to guarantee the high IP protection.

Electrical installation



- To ensure maximum self-locking ability, please be sure that the motor is shorted when stopped.
Actuators with integrated controller have this feature incorporated.
- When using soft stop on a DC-motor, a short peak of higher voltage will be sent back towards the power supply. It is important when selecting the power supply that it does not turn off the output, when this backwards load dump occurs.



The power supply for actuators without integrated controller must be monitored externally and cut off in case of overload.


Recommended fuse for actuators without integrated controller

Type	Spindle Pitch (mm)	Thrust max. Push/Pull (N)	Typical Amp. at full load (A) 24V - 12V		Recommended fuse 24V - 12V	
14020xxxxxxxxA...	2	750	-	2.4	-	5
14020xxxxxxxxB...	2	750	1.3	-	2.5	-
14020xxxxxxxxC...	2	750	-	4.2	-	10
14020xxxxxxxxD...	2	750	2.5	-	6	-
14040xxxxxxxxA...	4	300	-	1.7	-	5
14040xxxxxxxxB...	4	300	0.9	-	2.5	-
14040xxxxxxxxC...	4	300	-	2.6	-	10
14040xxxxxxxxD...	4	300	1.3	-	6	-

Actuator without feedback

Connection diagram:

Fig. 1 : 14xxxxxxxx000x0x=xx0xxxxxxxxxx




I/O specifications:

Input/Output	Specification	Comments
Description	Permanent magnetic DC motor. See connection diagram, fig. 1 above	
Brown	12-24VDC (+/-) 12V ± 20% 24V ± 10%	To extend actuator: Connect Brown to positive To retract actuator: Connect Brown to negative
Blue	Under normal conditions: 12V, max. 5A depending on load 24V, max. 2.5A depending on load	To extend actuator: Connect Blue to negative To retract actuator: Connect Blue to positive
Red	Not to be connected	
Black	Not to be connected	
Green	Not to be connected	
Yellow	Not to be connected	
Violet	Not to be connected	
White	Not to be connected	

Actuator with relative positioning - Single Hall

Connection diagram:

Fig. 2 : 14xxxxxxxxOK0x0x=xx0xxxxxxxx0x



Actuator with relative positioning - Single Hall


I/O specifications:

Input/Output	Specification	Comments
Description	The actuator can be equipped with Single Hall that gives a relative positioning feedback signal when the actuator moves. See connection diagram, fig. 2, page 14	
Brown	12-24VDC (+/-) 12V ± 20% 24V ± 10%	To extend actuator: Connect Brown to positive To retract actuator: Connect Brown to negative
Blue	Under normal conditions: 12V, max. 5A depending on load 24V, max. 2.5A depending on load	To extend actuator: Connect Blue to negative To retract actuator: Connect Blue to positive
Red	Signal power supply (+) 12-24VDC	Current consumption: Max. 40mA, also when the actuator is not running
Black	Signal power supply GND (-)	
Green	Not to be connected	
Yellow	Not to be connected	
Violet	Single Hall output (PNP) Movement per single Hall pulse: LA14020 Actuator = 0.2 mm per pulse LA14040 Actuator = 0.4 mm per pulse Frequency: Frequency is 14-26 Hz on Single Hall output depending on load. Every pulse is "ON" for minimum 3ms. Overvoltage on the motor can result in shorter pulses.	Output voltage min. $V_{IN} - 2V$ Max. current output: 12mA Max. 680nF N.B. For more precise measurements, please contact LINAK A/S. Low frequency with a high load. Higher frequency with no load.
	Diagram of Single Hall: Input Hall A  Hall B  Micro - Processor  Single Hall output  Fig. 2.1	
White	Not to be connected	

Actuator with endstop signals and relative positioning - Single Hall

Connection diagram:

Fig. 3 : 14xxxxxxxxOK0x0x=xx1xxxxxxxx0x





*YELLOW/GREEN: Endstop signals out are NOT potential free!

If you wish to use the endstop signals, you will have to keep power on the brown, blue, red and black wires, otherwise the signal will be lost.

Actuator with endstop signals and relative positioning - Single Hall


I/O specifications:

Input/Output	Specification	Comments
Description	The actuator can be equipped with Single Hall that gives a relative positioning feedback signal when the actuator moves. See connection diagram, fig. 3, page 16	
Brown	12-24VDC (+/-) 12V ± 20% 24V ± 10%	To extend actuator: Connect Brown to positive To retract actuator: Connect Brown to negative
Blue	Under normal conditions: 12V, max. 5A depending on load 24V, max. 2.5A depending on load	To extend actuator: Connect Blue to negative To retract actuator: Connect Blue to positive
Red	Signal power supply (+) 12-24VDC	Current consumption: Max. 40mA, also when the actuator is not running
Black	Signal power supply GND (-)	
Green	Endstop signal out	Output voltage min. $V_{IN} - 2V$ Source current max. 100mA NOT potential free
Yellow	Endstop signal in	
Violet	Single Hall output (PNP) Movement per single Hall pulse: LA14020 Actuator = 0.2 mm per pulse LA14040 Actuator = 0.4 mm per pulse Frequency: Frequency is 14-26 Hz on Single Hall output depending on load. Every pulse is "ON" for minimum 3ms. Overvoltage on the motor can result in shorter pulses.	Output voltage min. $V_{IN} - 2V$ Max. current output: 12mA Max. 680nF N.B. For more precise measurements, please contact LINAK A/S. Low frequency with a high load. Higher frequency with no load.
	Diagram of Single Hall: 	
White	Not to be connected	

Actuator with absolute positioning - Analogue feedback

Connection diagram:

Fig. 4 : 14xxxxxxxx0A0x0x=xx0xxxxxxxxx



Actuator with absolute positioning - Analogue feedback


I/O specifications:

Input/Output	Specification	Comments
Description	The actuator can be equipped with electronic circuit that gives an analogue feedback signal when the actuator moves. See connection diagram, fig. 4, page 18	
Brown	12-24VDC (+/-) 12V ± 20% 24V ± 10%	To extend actuator: Connect Brown to positive To retract actuator: Connect Brown to negative
Blue	Under normal conditions: 12V, max. 5A depending on load 24V, max. 2.5A depending on load	To extend actuator: Connect Blue to negative To retract actuator: Connect Blue to positive
Red	Signal power supply (+) 12-24VDC	Current consumption: Max. 60mA, also when the actuator is not running
Black	Signal power supply GND (-)	
Green	Not to be connected	
Yellow	Not to be connected	
Violet	Analogue feedback 0-10V (Option A) 0.5-4.5V (Option B) Special (Option F)	Tolerances +/- 0.2V Max. current output: 1mA Ripple max. 200mV Transaction delay 20ms Linear feedback 0.5%
	4-20mA (Option C) Special (Option F)	Tolerances +/- 0.2mA Transaction delay 20ms Linear feedback 0.5% Output: Source Serial resistance: 12V max. 300 ohm 24V max. 900 ohm
	For all analogue feedbacks it is recommendable to have the actuator to activate its limit switches on a regular basis, to ensure more precise positioning	
White	Not to be connected	

Actuator with endstop signals and absolute positioning - Analogue feedback

Connection diagram:

Fig. 5 : 14xxxxxxxx0A0x0x=xx1xxxxxxxxx



*YELLOW/GREEN: Endstop signals out are NOT potential free!

If you wish to use the endstop signals, you will have to keep power on the brown, blue, red and black wires, otherwise the signal will be lost.

Actuator with endstop signals and absolute positioning -
Analogue feedback


I/O specifications:

Input/Output	Specification	Comments
Description	The actuator can be equipped with electronic circuit that gives an analogue feedback signal when the actuator moves. See connection diagram, fig. 5, page 20	
Brown	12-24VDC (+/-) 12V ± 20% 24V ± 10%	To extend actuator: Connect Brown to positive To retract actuator: Connect Brown to negative
Blue	Under normal conditions: 12V, max. 5A depending on load 24V, max. 2.5A depending on load	To extend actuator: Connect Blue to negative To retract actuator: Connect Blue to positive
Red	Signal power supply (+) 12-24VDC	Current consumption: Max. 60mA, also when the actuator is not running
Black	Signal power supply GND (-)	
Green	Endstop signal out	Output voltage min. $V_{IN} - 2V$ Source current max. 100mA NOT potential free
Yellow	Endstop signal in	
Violet	Analogue feedback 0-10V (Option A) 0.5-4.5V (Option B) Special (Option F)	Tolerances +/- 0.2V Max. current output: 1mA Ripple max. 200mV Transaction delay 20ms Linear feedback 0.5%
	4-20mA (Option C) Special (Option F)	Tolerances +/- 0.2mA Transaction delay 20ms Linear feedback 0.5% Output: Source Serial resistance: 12V max. 300 ohm 24V max. 900 ohm
	For all analogue feedbacks it is recommendable to have the actuator to activate its limit switches on a regular basis, to ensure more precise positioning	
White	Not to be connected	

Actuator with absolute positioning - Mechanical potentiometer feedback


Connection diagram:

Fig. 6 : 14xxxxxxxxOP0x0x=xx0xxxxxxxx0x



Actuator with absolute positioning - Mechanical potentiometer feedback


I/O specifications:

Input/Output	Specification	Comments
Description	The actuator can be equipped with mechanical potentiometer that gives an analogue feedback signal when the actuator moves. See connection diagram, fig. 6, page 22	
Brown	12-24VDC (+/-) 12V ± 20% 24V ± 10%	To extend actuator: Connect Brown to positive To retract actuator: Connect Brown to negative
Blue	Under normal conditions: 12V, max. 5A depending on load 24V, max. 2.5A depending on load	To extend actuator: Connect Blue to negative To retract actuator: Connect Blue to positive
Red	Signal power supply (+)	+10V or other value
Black	Signal power supply GND (-)	
Green	Not to be connected	
Yellow	Not to be connected	
Violet	Analogue feedback Slide potentiometer, 10 kohm 1 kohm = 0 mm stroke 11 kohm = 100 mm stroke The maximum effect: 0.1W	Linearity: ± 20% Minimum lifetime: 15,000 cycles Average lifetime: 40,000 cycles Max. current output: 1mA
White	Not to be connected	

Actuator with absolute positioning - PWM

Connection diagram:

Fig. 7 : 14xxxxxxxx0F0x0x=xx0xxxxxxxxxx



Actuator with absolute positioning - PWM


I/O specifications:

Input/Output	Specification	Comments
Description	The actuator can be equipped with electronic circuit that gives an analogue feedback signal when the actuator moves. See connection diagram, fig. 7, page 24	
Brown	12-24VDC (+/-) 12V ± 20% 24V ± 10%	To extend actuator: Connect Brown to positive To retract actuator: Connect Brown to negative
Blue	Under normal conditions: 12V, max. 5A depending on load 24V, max. 2.5A depending on load	To extend actuator: Connect Blue to negative To retract actuator: Connect Blue to positive
Red	Signal power supply (+) 12-24VDC	Current consumption: Max. 40mA, also when the actuator is not running
Black	Signal power supply GND (-)	
Green	Not to be connected	
Yellow	Not to be connected	
Violet	Digital output feedback 10-90% (Option D) 20-80% (Option E) Special (Option F)	Output voltage min. $V_{IN} - 2V$ Tolerances +/- 2% Max. current output: 12mA It is recommendable to have the actuator to activate its limit switches on a regular basis, to ensure more precise positioning
White	Not to be connected	

Actuator with endstop signals and absolute positioning - PWM

Connection diagram:

Fig. 8 : 14xxxxxxxxOF0x0x=xx1xxxxxxxxx



*YELLOW/GREEN: Endstop signals out are NOT potential free!

If you wish to use the endstop signals, you will have to keep power on the brown, blue, red and black wires, otherwise the signal will be lost.

Actuator with endstop signals and absolute positioning - PWM


I/O specifications:

Input/Output	Specification	Comments
Description	The actuator can be equipped with electronic circuit that gives an analogue feedback signal when the actuator moves. See connection diagram, fig. 8, page 26	
Brown	12-24VDC (+/-) 12V ± 20% 24V ± 10%	To extend actuator: Connect Brown to positive To retract actuator: Connect Brown to negative
Blue	Under normal conditions: 12V, max. 5A depending on load 24V, max. 2.5A depending on load	To extend actuator: Connect Blue to negative To retract actuator: Connect Blue to positive
Red	Signal power supply (+) 12-24VDC	Current consumption: Max. 40mA, also when the actuator is not running
Black	Signal power supply GND (-)	
Green	Endstop signal out	Output voltage min. $V_{IN} - 2V$ Source current max. 100mA NOT potential free
Yellow	Endstop signal in	
Violet	Digital output feedback 10-90% (Option D) 20-80% (Option E) Special (Option F)	Output voltage min. $V_{IN} - 2V$ Tolerances +/- 2% Max. current output: 12mA It is recommendable to have the actuator to activate its limit switches on a regular basis, to ensure more precise positioning
White	Not to be connected	

Actuator with IC Basic

Connection diagram:


Fig. 9 : 14xxxxxxxxxx3x1x=xx0xxxxxxxxxx



 Please be aware that if the power supply is not properly connected, you might damage the actuator!

Actuator with IC Basic

I/O specifications:

Input/ Output	Specification	Comments
Description	Easy to use interface with integrated power electronics (H-bridge). The actuator can also be equipped with electronic circuit that gives an asolute or relative feedback signal. The version with “IC option” cannot be operated with PWM (power supply). See connection diagram, fig. 9, page 28	
Brown	12-24VDC + (VCC) Connect Brown to positive 12V ± 20% 24V ± 10% Standard motor: Fast motor: 12V, current limit 8A 12V, current limit 8A 24V, current limit 5A 24V, current limit 5A	Note: Do not change the power supply polarity on the brown and blue wires! Power supply GND (-) is electrically connected to the housing If the temperature drops below -10°C, all current limits will automatically increase to 9A
Blue	12-24VDC - (GND) Connect Blue to negative 12V ± 20% 24V ± 10% Standard motor: Fast motor: 12V, current limit 8A 12V, current limit 8A 24V, current limit 5A 24V, current limit 5A	
Red	Extends the actuator	
Black	Retracts the actuator	On/off voltages: > 67% of V_{IN} = ON < 33% of V_{IN} = OFF Input current: 10mA
Green	Not to be connected	
Yellow	Not to be connected	


Actuator with IC Basic
I/O specifications:

Input/ Output	Specification	Comments
Violet	Analogue feedback 0-10V (Option A)	Standby power consumption: 12V, 60mA 24V, 45 mA Ripple max. 200mV Transaction delay 20ms Linear feedback 0.5% Max. current output: 1mA It is recommendable to have the actuator to activate its limit switches on a regular basis, to ensure more precise positioning
	Single Hall output (PNP)	Output voltage min. $V_{IN} - 2V$ Max. current output: 12mA For more information see fig. 3.1, page 17
White	Signal GND	For correct wiring of power GND and Signal GND see page 34

Actuator with IC Advanced - with BusLink

Connection diagram:

Fig. 10 : 14xxxxxxxxxx3x1x=xx1xxxxxxxxxx



 Please be aware that if the power supply is not properly connected, you might damage the actuator!


 **BusLink is available for IC Advanced and can be used for:**
Diagnostics, manual run and configuration

Download BusLink software here: <http://www.linak.com/techline/?id3=2363>

For more information and easy set-up of BusLink, please follow this link to view the Quick Guide for BusLink: <http://www.linak.com/techline/?id3=2356>

Actuator with IC Advanced - with BusLink

I/O specifications:

Input/Output	Specification	Comments
Description	Easy to use interface with integrated power electronics (H-bridge). The actuator can also be equipped with electronic circuit that gives an absolute or relative feedback signal. IC Advanced also provides a wide range of possibilities for customisation. The version with “IC option” cannot be operated with PWM (power supply). See connection diagram, fig. 10, page 31	
Brown	12-24VDC + (VCC) Connect Brown to positive 12V ± 20% 24V ± 10% Standard motor: Fast motor: 12V, current limit 8A 12V, current limit 8A 24V, current limit 5A 24V, current limit 5A	Note: Do not change the power supply polarity on the brown and blue wires! Power supply GND (-) is electrically connected to the housing
Blue	12-24VDC - (GND) Connect Blue to negative 12V ± 20% 24V ± 10% Standard motor: Fast motor: 12V, current limit 8A 12V, current limit 8A 24V, current limit 5A 24V, current limit 5A	Current limit levels can be adjusted through BusLink If the temperature drops below -10°C, all current limits will automatically increase to 9A
Red	Extends the actuator	On/off voltages: > 67% of V_{IN} = ON < 33% of V_{IN} = OFF Input current: 10mA
Black	Retracts the actuator	
Green	Endstop signal out	Output voltage min. V_{IN} - 2V Source current max. 100mA Endstop signals are NOT potential free. Endstop signals can be configured with BusLink software according to any position needed. Before configuring virtual endstop, an absolute feedback type must be chosen. Only use one virtual endstop - keep one end open for initialisation
Yellow	Endstop signal in	

Actuator with IC Advanced - with BusLink

I/O specifications:

Input/ Output	Specification	Comments
Violet	Analogue feedback (0-10V): Configure any high/low combination between 0-10V 0-10V (Option G) 0.5-4.5V (Option H) Special (Option X)	Ripple max. 200mV Transaction delay 20ms Linear feedback 0.5% Max. current output. 1mA
	Single Hall output (PNP)	Output voltage min. $V_{IN} - 2V$ Max. current output: 12mA Please be aware that when choosing single hall, feedback position readout and virtual end-stops are not available in BusLink. For more information, see fig. 3.1, page 17
	Digital output feedback PWM: Configure any high/low combination between 0-100% 10-90% (Option K) 20-80% (Option L) Special (Option X)	Output voltage min. $V_{IN} - 2V$ Frequency: 75Hz $\pm$ 10Hz as standard, but this can be customised. Duty cycle: Any low/high combination between 0 and 100 percent. Open Drain source current max. 12mA
	Analogue feedback (4-20mA): Configure any high/low combination between 4-20mA 4-20mA (Option J) Special (Option X)	Tolerances $\pm$ 0.2mA Transaction delay 20ms Linear feedback 0.5% Output: Source Serial resistance: 12V max. 300 ohm 24V max. 900 ohm
	All absolute value feedbacks (0-10V, PWM and 4-20mA)	Standby power consumption: 12V, 60mA 24V, 45 mA It is recommendable to have the actuator to activate its limit switches on a regular basis, to ensure more precise positioning
White	Signal GND	For correct wiring of power GND and Signal GND see page 34




Item number for BusLink cables: 0147999

Please note that the BusLink cables must be purchased separately from the actuator!

Correct wiring of Power GND and Signal GND for IC Basic and IC Advanced

When using the feedback output, it is important to use the right connection setup. Attention should be paid to the two ground connections. Power GND in the Power connector and Signal GND in the Control connector. When using either 0-10V, Hall or PWM feedback, the Signal GND must be used. For optimal accuracy, the Signal GND is connected to the Power GND as close as possible to the feedback input equipment.




Please note that this section only applies for the following feedback options: 0-10V, Hall and PWM.

Actuator with Parallel


Connection diagram:

Fig. 11 : 14xxxxxxxx003x1x=xx1xxxxxxxxZx



- Please be aware that if the power supply is not properly connected, you might damage the actuator!
- The green and yellow wires from parallel connected actuators must NOT be interconnected.

Actuator with Parallel I/O specifications:


Input/Output	Specification	Comments
Description	Parallel drive of up to 8 actuators. A master actuator with an integrated H-bridge controller controls up to 7 slaves. The version with “IC option” cannot be operated with PWM (power supply). See connection diagram, fig. 11, page 35	
Brown	12-24VDC + (VCC) Connect Brown to positive 12V ± 20% 24V ± 10% Standard motor: Fast motor: 12V, current limit 8A 12V, current limit 8A 24V, current limit 5A 24V, current limit 5A	Note: Do not change the power supply polarity on the brown and blue wires! The parallel actuators can run on one OR separate power supplies Power supply GND (-) is electrically connected to the housing
Blue	12-24VDC - (GND) Connect Blue to negative 12V ± 20% 24V ± 10% Standard motor: Fast motor: 12V, current limit 8A 12V, current limit 8A 24V, current limit 5A 24V, current limit 5A	Current limit levels can be adjusted through BusLink (only one actuator at a time for parallel) If the temperature drops below -10°C, all current limits will automatically increase to 9A
Red	Extends the actuator	On/off voltages: > 67% of V_{IN} = ON < 33% of V_{IN} = OFF Input current: 10mA
Black	Retracts the actuator	It does not matter where the in/ out signals are applied. You can either choose to connect the signal cable to one actuator OR you can choose to connect the signal cable to each actuator on the line. Either way this will ensure parallel drive
Green	Endstop signal out	Output voltage min. V_{IN} - 2V Source current max. 100mA NOT potential free
Yellow	Endstop signal in	

Actuator with Parallel
I/O specifications:

Input/Output	Specification	Comments
Violet	Parallel communication: Violet cords must be connected together	Standby power consumption: 12V, 60mA 24V, 45mA No feedback available during parallel drive
White	Signal GND: White cords must be connected together	For correct wiring of power GND and Signal GND see page 34

The parallel system

The parallel drive function will support a number of actuators working jointly.



- It is both possible to run parallel with a single power supply, or to run each actuator with separate power supplies.
- Only standard power and signal cables are available for parallel.

The parallel system

- It does not matter where the IN/OUT signal is applied. The signals of all actuators can be connected together
- When all actuators are connected, a Master will automatically be chosen. E.g. with 5 actuators in one system there will be 1 Master and 4 Slaves. The Master can control up to 7 slaves
- If an overload occurs, the running of the actuators will be stopped and blocked in that direction until an activation in the opposite direction has been made, or the system has been re-powered
- Before entering BusLink mode, all actuators must be disconnected. It is only possible to configure one actuator at a time through BusLink
- When changing the actuator configuration, it is important that all actuators in the system have the same configuration before the system starts running. Otherwise, the actuators will not run
- Actuators will be pre-programmed from our production as 2, 3, 4, 5.. etc. parallel systems. Through BusLink it will be possible to add or remove actuators to/from the system
- In case one of the actuators are broken, the system will not move; not even after re-powering. The broken actuator needs to be replaced, before the system can run again. The system will only run, when it is complete

BusLink is available for Parallel

- BusLink can be used for configuration and diagnostics
- Service counter is available with Parallel

Download BusLink software here: <http://www.linak.com/techline/?id3=2363>

For more information and easy set-up of BusLink, please follow this link to view the Quick Guide for BusLink: <http://www.linak.com/techline/?id3=2356>



Please note that the BusLink cables must be purchased separately from the actuator!
Item number for BusLink cables: 0147999

System Monitoring for Parallel




If one of the actuators have one of the following error conditions, the actuator will immediately STOP:

- H-Bridge fault
- Out of the temperature range (High duty cycle protection)
- Overcurrent (Current cut-off if one or all actuators go in mechanical block)
- SMPS fault
- EOS fault switch
- Hall sensor failure
- Position lost
- Overvoltage (43V DC)

Alignment of the parallel actuator system

If the actuators are not in parallel when starting up, the next movement will run in the following manner:




Parallel manual service mode

With the parallel manual service mode it is possible to drive one or more parallel actuators separately, using the red and black wire from each actuator.

Please follow this procedure to manually extend/retract the parallel actuator(s):

	Procedure	Min.	Max.
First step	Disconnect the Purple and White wires between all actuators	-	-
Hold	Put power on the Red and Black wires for 10-30 seconds	10 sec.	30 sec.
Difference	The Red and Black wires must all be connected to the power supply within 0.5 seconds	0 sec.	0.5 sec.
Release	Disconnect all wires and wait 0.5-2 seconds before the next step	0.5 sec.	2 sec.
Extend/Retract	Now choose either to extend or retract the actuator: To extend the actuator: Connect only the Red wire(s) to the power supply To retract the actuator: Connect only the Black wire(s) to the power supply	-	-
Interval	Switch between running in/out as much as needed, without exceeding the 2.0 seconds interval between disconnecting/connecting the Red and Black wires	-	2 sec.
End	To exit the parallel manual mode, diconnect the Red and Black wires for more than 2.0 seconds	2 sec.	-
Back to parallel mode	Before running in standard parallel mode, reconnect all Purple and White wires	-	-



Chapter 3

Troubleshooting

Symptom	Possible cause	Action
No motor sound or movement of piston rod	The actuator is not properly connected to the power supply Customer fuse burned Cable damaged IC: Wrongly connected: + Brown, - Blue Signal required for moving outwards: + VCC -> RED Wire Signal required for moving inwards: + VCC -> Black Wire	• Check the connection to the power supply or the external control unit (if any) To extend actuator: Connect Brown to positive and Blue to negative To retract actuator: Connect Brown to negative and Blue to positive • Change cable • Check wire connection (Red/ Black) on control unit • Please contact LINAK
Excessive electricity Consumption	Misalignment or overload in application	• Align or reduce load • Try to run the actuator without load • Please contact LINAK
Motor runs but spindle does not move	Gearing system or spindle damaged	• Please contact LINAK
Actuator cannot lift full load	Clutch is worn Motor is damaged Insufficient power supply IC: Current cut off (overload in application)	• Align or reduce load • Check power supply For IC advanced and Parallel only: Connect actuator to BusLink and check the current parameters (inwards/outwards) • Please contact LINAK

Troubleshooting

Symptom	Possible cause	Action
No signal from Feedback	Wrongly Connected: Violet: Signal out White: Signal GND Yellow: Endstop In Green: Endstop Out Cable damaged Bad connection Potentiometer damaged Hall sensor or magnet damaged For IC Advanced only: Check Feedback option - connect to BusLink	• Check wiring • Change cable For IC Advanced only: Connect actuator to BusLink and check current parameters. Initialise the actuator in both directions • Please contact LINAK
Motor runs too slowly or does not run with full force Motor runs in smaller steps	Load is higher than specified Voltage drop in cable (Use of long cables can negatively affect the performance of the actuator) Insufficient power supply IC: Current Cut-off	• Reduce load • Check power supply IC: Connect actuator to BusLink and check current parameters (reason for last stop). For more info, please see page 45
Actuator(s) cannot hold the chosen load	Load is higher than specified	• Reduce load

Troubleshooting for Parallel

Symptom	Possible cause	Action
No actuators in movement	Power supply	• Check power supply source and power connections: Brown + Blue - Please be aware that if the power supply is not properly connected, you might damage the actuator
	Signal connections	• Check parallel communications: Violet = Communication Violet cords must be connected together White = Signal GND White cords must be connected together
	Signal required for moving outwards: + VCC (Red wire) Signal required for moving inwards: + VCC (Black wire)	• Check wire connection (Red/ Black) on control unit
	• Put power on all actuators at the same time, after everything is connected. Then wait 10 seconds before signals for moving In/Out are activated	
Actuator(s) cannot lift full load	Load is higher than specified	• Reduce load • Check for sufficient power supply current • Connect actuator via BusLink one at the time and check monitoring for each actuator (reason for last stop)
Short movements before stops	Actuator NOT connected properly Violet = Parallel communication White = Signal GND	• Check wire connection (Violet/ White) • If OK - Connect actuators via BusLink one at the time and check monitoring for each actuator (reason for last stop). For more info, please see page 45

Troubleshooting for Parallel

Symptom	Possible cause	Action
Signal cable damaged or removed under operation	All actuators stop at the same position	• When seeing a communication error, the system goes into 'position lost' • The signal and power cables MUST be connected to all actuators again • Afterwards, the Parallel system needs re-powering • If one actuator is missing, the system will not work, not even after re-powering
BusLink monitoring: Reason for last stop	H-bridge fault SMPS fault	• Please contact your local supplier for further instructions
	Overcurrent	• The Parallel system cannot continue in the same direction • Reactivation is needed in the opposite direction
	EOS OUT error EOS IN error	• The Parallel system stops at the same time. When seeing an EOS error, the actuator goes into 'position lost', and the system will need initialisation (to initialise, move the actuators into fully retracted position)
	Hall error	• The system stops at the same position. When seeing hall error, the actuator goes into 'position lost', and the system will need initialisation (to initialise, move the actuators into fully retracted position)
	Out of range temperature for ambient location Out of range temperature at FET location The above can be due to high environment temperature or high duty cycle	• The error causes the actuators to stop. After elimination of the error (cooling down) and reactivation of the movement, the actuators will move normally • This may not be used for stop of the system

Troubleshooting for Parallel

Symptom	Possible cause	Action
BusLink monitoring: Reason for last stop	Overvoltage	• When seeing overvoltage, the system stops at the same time. The system needs re-powering and In/Out signals must be removed before next movement
	Undervoltage	• When seeing undervoltage, the system stops at the same time. The system needs re-powering and In/Out signals must be removed before next movement



For more information and easy set-up of BusLink, please follow this link to view the Quick Guide for BusLink: <http://www.linak.com/techline/?id3=2356>

Chapter 4

Specifications


Motor:	Permanent magnet motor 12VDC or 24VDC
Cable:	Motor: 8 x 18 AWG PVC cable
Housing:	The housing is made of casted aluminium, coated for outdoor use and in harsh conditions
Spindle part:	Inner tube: Stainless steel AISI304/SS2333 Acme spindle: Trapezoidal spindle with high efficiency
Temperature range:	- 40° C to +85° C - 40° F to +185° F Full performance +5° C to +40° C
End play:	2 mm maximum
Weather protection:	Rated IP66 for outdoor use. Furthermore, the actuator can be washed down with a high-pressure cleaner (IP69K)
Compatibility:	The LA14 is compatible with SMPS-T160 (For combination possibilities, please see the User Manual for SMPS-T160)

Usage:

- Duty cycle is max. 20% (4 min. drive and 16 min. rest for 2 mm spindle pitch) and max. 40% (8 min. drive and 12 min. rest for 4 mm spindle pitch) at +5 to +40°C ambient temperature
- Storage temperature: -55°C to + 105°C
- Noise level:
 - With standard motor: 50-53 dB (A)
 - With fast motor: 58-63 dB (A)
 - Measuring method DS/EN ISO 3743-1 actuator not loaded



Actuator dimensions

TECHLINE® LA14:





Speed and current curves - 12V motor

The values below are typical values and made with a stable power supply and an ambient temperature of 20° C.



Speed and current curves - 24V motor

The values below are typical values and made with a stable power supply and an ambient temperature of 20° C.



Test of conducted and radiated emission (EMC)

All TECHLINE actuators have been tested in accordance with EN55011 class B (2007) (CISPR 11). A 1m cable has been used in the test set-up.

Actuator without H-bridge


- 1) For normal operation the following is valid:
- Radiated emission requirements are met.
 - Conducted emission requirements are met. However, to meet with these requirements a capacitor has been mounted across the motor wires outside the actuator, and tests have then been made with this capacitor. Capacitor values for some of the TECHLINE actuators can be found in the scheme below.



To comply with EN55011 class B (2007) a capacitor must be added across the motor wires, or the connected control box must have similar/better filtering. The actuator is not delivered with a built in capacitor, because then it would not be possible to PWM the motor for those who would want to do that.

Please view the scheme below for the correct choice of capacitor for the actuator in question.

Product	Capacitor value
LA14	4.7 μ F



- 2) For systems/operations that use PWM-control it is up to the customer to test and meet the requirements.

Actuator with H-bridge

- 1) For normal operation with soft start/stop the following is valid:
- The actuator has been tested when operating with constant 80%-PWM.
 - Radiated emission requirements are met.
 - Conducted emission requirements are met.
- 2) For systems with LINAK PWM regulation (among other things parallel operation and speed regulation) the following is valid:
- Radiated emission requirements are met.
 - Conducted emission requirements are met.
- 3) Speed regulation:
- If the speed is regulated below a nominal speed of 80% (80%-PWM), it is necessary to mount a filter in order to comply with the conducted emission requirements. For systems/operations that are speed regulated, it is up to the customer to test and meet the requirements.

Label for LA14



WE IMPROVE YOUR LIFE
DESIGNED IN DENMARK

Type : 1402013000000A06=11002450CS000
Item No. : J90075
Prod. Date : 2015.11.09
Max Load : Push 750 N / Pull 750 N IP66
Power Rate : 12 V= / Max. 2.4 A
Duty Cycle : 20% Max. 4 min. / 16 min.

 NOT TO BE OPENED BY UNAUTHORIZED PERSONNEL
NE PAS OUVRIR PAR DU PERSONNEL NON AUTORISE



W/O #1234567-0001

MADE BY LINAK A/S DENMARK





Connect on Diagram



User Manual

1. **Type: 1402013000000A06-11002450CS000**
Describes the basic functionality of the product
2. **Item no.: J90075**
Sales and ordering code
3. **Prod. Date: YYYY.MM.DD**
Production date describes when the product has been produced. This date is the reference for warranty claims
4. **Max Load: Push 750N / Pull 750N IP66**
Describes the maximum load that the product can be exposed to in compression and tension. This line also contains a reference to the product's IP protection degree
5. **Power Rate: 12VDC / Max. 2.4 Amp**
Input voltage for the product and maximum current consumption
6. **Duty Cycle: 20%, Max. 4 min. / 16. min.**
The duty cycle defines the maximum period during operation without interruption. After operation, a pause must be observed. It is important that the operator follows the instructions of the duty cycle; otherwise, a possible overload may result in reduced product life/errors
7. **W/O #1234567-0001**
The LINAK work order followed by a unique sequential identification number

Key to symbols

The following symbols are used on the LA14 label.

Symbol	Norms	Approvals
	WEEE Directive 2002/96/EC	Wheelie bin
	<i>Compliance to all relevant EC directives</i>	CE
	C-Tick 2002: The Australian EMC	C-Tick
	China Pollution control mark (also indicates recyclability)	China RoHS legislation
	ISO 7000- 0434A: Caution	
	Operating instructions	

LA14 ordering example

140200400000A06=11002450CS000

0 = Not specified0 = None

Feedback level

Platform: None
0 = None
A = 0-10 V
B = 0.5-4.5
C = 4-20 mA
D = 10-90 %
E = 20-80 %
F = Special

Platform: IC type basic
0 = None
A = 0-10 V

Platform: IC type advanced
0 = None
G = 0-10 V
H = 0.5-4.5 V
J = 4-20 mA
K = 10-90 %
L = 20-80 %
X = Special

Safety Factor:

0 = 2.0

Cable:

0 = None.
S = Straight 0.75m (8-core, Note: If AMP is chosen = 6-core)
T = Straight 1.5m (8-core, Note: If AMP is chosen = 6-core)
R = Straight 5.0m (8-core, Note: If AMP is chosen = 6-core)
X = Special

Plug Type:

0 = None. Is to be chosen, if cable and connectors are not wanted
C = Flying leads. Is to be chosen, if connector is not wanted
J = Deutsch (DT4)
K = AMP superseal
X = Special

Fire Category:

0 = None

Install. Dim.:

min 245 = mm
X: XXX = mm

Brake:

0 = None

Option /Position:

0 = No EOS (Only IC Basic)
1 = Yes EOS (Only IC Advanced)

Piston Rod Eye:

1 = Ø 10.2 With slot auto. steel (BID 245 ->345 mm)
2 = Ø 12.3 With slot auto. steel (BID 245 -> 345 mm)
3 = Ø 12.2 With slot AISI 304 (BID 250 -> 345 MM, only wo POM)
4 = Ø 12.2 With slot AISI 303 (BID 250 ->345 MM, only wo POM)
X = Special

Back fixture:

1 = 0 degrees A = 0 degrees with POM at piston rod and backfixture
2 = 90 degrees B = 90 degrees with POM at piston rod and backfixture

Colour:

*- = Dark Olivish Grey NCS S7000-N

IP:

6 = IP66 + IP69K
9 = Harsh environment housing + IP66/IP69K (Special article number only)

Endstop

0 = Powerswitch (E1)
1 = Signal switch

Motor Type:

A = 12VDC Normal (V1)
B = 24VDC Normal (V2)
C = 12VDC Fast (V1)
D = 24VDC Fast (V2)
X = Other

Platform

0 = None (P0)
* 3 = IC integrated Controller

Feedback

00 = None (F1)
0P = Potentiometer (F6)
0K = Single Hall
0A = Hall potentiometer
0F = PWM

Safety :

00 = None

Stroke Length:

XXX = mm.
Stroke from 19 mm to 130 mm
(Potentiometer: Max. 100 mm)

Spindle Pitch:

020 = 2 mm
040 = 4 mm

Actuator Type:

14 = LA14



IC options:	IC	LINbus	Parallel
LA14 actuator:	√	√	√

Chapter 5

Maintenance

- The actuator must be cleaned at regular intervals to remove dust and dirt and inspected for mechanical damages or wear.
- Inspect attachment points, wires, piston rod, cabinet, and plug, as well as check that the actuator functions correctly.
- To ensure that the pregreased inner tube remains lubricated, the actuator must only be washed down when the piston rod is fully retracted.
- The actuator is a closed unit and therefore requires no internal maintenance.
- In order to maintain a proper performance of the spherical eyes and to increase the resistance against environmental wear, we strongly recommend that the spherical eyes (ball bearings) mounted on actuators from LINAK are greased with anticorrosive grease or similar.

Repair

Only an authorised LINAK® service centre should repair LINAK actuator systems. Systems to be repaired under warranty must be sent to an authorised LINAK service centre.

In order to avoid the risk of malfunction, all actuator repairs must only be carried out by an authorised LINAK Service shop or repairer, as special tools and parts must be used.

If a system is opened by unauthorised personel there is a risk that it may malfunction at a later date.

Main groups of disposal

LINAK's products may be disposed of, possibly by dividing them into different waste groups for recycling or combustion.

Product	Metal scrap	Cable scrap	Electronic scrap	Plastic recycling or combustion
LA14	X	X	X	X

We recommend that our product is disassembled as much as possible at the disposal and that you try to recycle it.

Warranty

There is an 18 months' warranty on TECHLINE products against manufacturing faults calculated from the production date of the individual products (see label). LINAK's warranty is only valid in so far as the equipment has been used and maintained correctly and has not been tampered with. Furthermore, the actuator must not be exposed to violent treatment. In the event of this, the warranty will be ineffective/invalid. For further details, please see standard terms of sale and delivery for LINAK A/S.

Note:

Only an authorised LINAK® service centre should repair LINAK actuator systems. Systems to be repaired under warranty must be sent to an authorised LINAK service centre.

In order to avoid the risk of malfunction, all actuator repairs must only be carried out by an authorised LINAK Service shop or repairer, as special tools and parts must be used.

If a system is opened by unauthorised personnel there is a risk that it may malfunction at a later date.

The actuator is not to be opened by unauthorised personnel. In case the actuator is opened, the warranty will be invalid.

DECLARATION OF CONFORMITY

LINAK A/S
Smedevænget 8
DK - 6430 Nordborg

Hereby declares that

Actuator	14XXXXX000A/B/C/DXXXXXXXXXXXXXXXXXX
	14XXXXX0P0A/B/C/DXXXXXXXXXXXXXXXXXX

complies with the EMC Directive: 2004/108/EC according to following standards:
EN61000-4-2:2009, EN61000-4-3:2006+A1, EN61000-4-4:2004, EN61000-4-5:2006,
EN61000-4-6:2009, EN61000-4-8:2010, EN55011:2009+A1 Class B, EN55016-2-1:2009

Additional information:

The device does also comply with the standard:

EN 61000-6-1:2007, Electromagnetic compatibility (EMC) - Part 6-1: Generic standards -
Immunity for residential, commercial and light-industrial environments

EN 61000-6-3:2007, Electromagnetic compatibility (EMC) - Part 6-3: Generic standards -
Emission standard for residential, commercial and light-industrial environments

Nordborg, 2013-03-25



LINAK A/S

John Kling, B.Sc.E.E.

Certification and Regulatory Affairs

Authorized to compile the relevant technical documentation

Original declaration

DECLARATION OF INCORPORATION OF PARTLY COMPLETED MACHINERY

LINAK A/S
Smedevænget 8
DK - 6430 Nordborg

Herewith declares that LINAK TECHLINE® products
as characterized by the following models and types:

Linear Actuators LA12, LA14, LA22, LA23, LA25, LA30, LA35, LA36, LA37

comply with the following parts of the Machinery Directive 2006/42/EC, ANNEX I, *Essential health and safety requirements relating to the design and construction of machinery*:

1.5.1 Electricity supply

The relevant technical documentation is compiled in accordance with part B of Annex VII and that this documentation or part hereof will be transmitted by post or electronically to a reasoned request by the national authorities.

This partly completed machinery must not be put into service until the final machinery into which it is to be incorporated has been declared in conformity with the provisions of the Machinery Directive 2006/42/EC where appropriate.

Nordborg, 2014-10-20



LINAK A/S
John Kling, B.Sc.E.E.
Certification and Regulatory Affairs
Authorized to compile the relevant technical documentation

Original Declaration

FACTORIES

CHINA

LINAK (Shenzhen) Actuator Systems, Ltd.
Phone: +86 755 8610 6656
Fax: +86 755 8610 6990
E-mail: sales@linak.cn
www.linak.cn

DENMARK

LINAK A/S - Group Headquarters, Guderup
Phone: +45 73 15 15 15
Fax: +45 74 15 80 48
Fax: +45 73 15 16 13 (Sales)
E-mail: info@linak.com
www.linak.com

SLOVAKIA

LINAK Slovakia s.r.o.
Phone: +421 51 75 63 414
Fax: +421 51 75 63 410
E-mail: jp@linak.sk
www.linak.com

USA

LINAK U.S. Inc.
North and South American Headquarters
Phone: +1 502 253 5595
Fax: +1 502 253 5596
E-mail: info@linak-us.com
www.linak-us.com

SUBSIDIARIES

AUSTRALIA

LINAK Australia Pty. Ltd
Phone: +61 3 8796 9777
Fax: +61 3 8796 9778
E-mail: sales@linak.com.au
www.linak.com.au

AUSTRIA

LINAK Repräsentanz Österreich (Wien)
Phone: +43 (1) 890 7446
Fax: +43 (1) 890 744615
E-mail: beinfo@linak.de
www.linak.at

BELGIUM & LUXEMBOURG

LINAK Actuator-Systems NV/SA
Phone: +32 (0)9 230 01 09
Fax: +32 (0)9 230 88 80
E-mail: beinfo@linak.be
www.linak.be

BRAZIL

LINAK Do Brasil Comércio De Atuadores Ltda.
Phone: +55 (11) 2832 - 7070
Fax: +55 (11) 2832 - 7060
E-mail: info@linak.com.br
www.linak.com.br

CANADA

LINAK Canada Inc.
Phone: +1 502 253 5595
Fax: +1 416-255-7720
E-mail: info@linak.ca
www.linak-us.com

CZECH REPUBLIC

LINAK C&S S.R.O.
Phone: +420581741814
Fax: +420581702452
E-mail: ponizil@linak.cz
www.linak.cz

DENMARK

LINAK Danmark A/S
Phone: +45 86 80 36 11
Fax: +45 86 82 90 51
E-mail: linak@linak-silkeborg.dk
www.linak.dk

FINLAND

LINAK OY
Phone: +358 10 841 8700
Fax: +358 10 841 8729
E-mail: linak@linak.fi
www.linak.fi

FRANCE

LINAK France E.U.R.L.
Phone: +33 (0) 2 41 36 34 34
Fax: +33 (0) 2 41 36 35 00
E-mail: linak@linak.fr
www.linak.fr

GERMANY

LINAK GmbH
Phone: +49 6043 9655 0
Fax: +49 6043 9655 60
E-mail: info@linak.de
www.linak.de

INDIA

LINAK A/S India Liaison Office
Phone: +91 120 4393333
Fax: +91 120 4273708
E-mail: info@linak.in
www.linak.in

IRELAND

LINAK UK Limited - Ireland
Phone: +44 (0)121 544 2211
Fax: +44 (0)121 544 2552
+44 (0)796 855 1606 (UK Mobile)
+35 387 634 6554 (Republic Of Ireland Mobile)
E-mail: sales@linak.co.uk
www.linak.co.uk

ITALY

LINAK Italia S.r.l.
Phone: +39 02 48 46 33 66
Fax: +39 02 48 46 82 52
E-mail: info@linak.it
www.linak.it

JAPAN

LINAK K.K.
Phone: 81-45-533-0802
Fax: 81-45-533-0803
E-mail: linak@linak.jp
www.linak.jp

MALAYSIA

LINAK Actuators Sdn. Bhd.
Phone: +60 4 210 6500
Fax: +60 4 226 8901
E-mail: info@linak-asia.com
www.linak.my

NETHERLANDS

LINAK Actuator-Systems B.V.
Phone: +31 76 5 42 44 40
Fax: +31 76 5 42 61 10
E-mail: info@linak.nl
www.linak.nl

NEW ZEALAND

LINAK New Zealand Ltd.
Phone: +64 9580 2071
Fax: +64 9580 2072
E-mail: nzsales@linak.com.au
www.linak.co.nz

NORWAY

LINAK Norge AS
Phone: +47 32 82 90 90
Fax: +47 32 82 90 98
E-mail: info@linak.no
www.linak.no

POLAND

LINAK Polska
Phone: +48 (22) 500 28 74
Fax: +48 (22) 500 28 75
E-mail: dkreh@linak.dk
www.linak.pl

REPUBLIC OF KOREA

LINAK Korea Ltd.
Phone: +82-(0)2-6231-1517
Fax: +82-(0)2-6231-1516
E-mail: scully@linak.kr
www.linak.kr

RUSSIAN FEDERATION

000 LINAK
Phone: +7 495 280 14 26
Fax: +7 495 687 14 26
E-mail: info@linak.ru
www.linak.ru

SPAIN

LINAK Actuadores, S.L.u
Phone: +34 93 588 27 75
Fax: +34 93 588 27 85
E-mail: linakact@linak.es
www.linak.es

SWEDEN

LINAK Scandinavia AB
Phone: +46 8 732 20 00
Fax: +46 8 732 20 50
E-mail: info@linak.se
www.linak.se

SWITZERLAND

LINAK AG
Phone: +41 43 388 31 88
Fax: +41 43 388 31 87
E-mail: info@linak.ch
www.linak.ch

TAIWAN

LINAK A/S Taiwan Representative Office
Phone: +886 2 27290068
Fax: +886 2 27290096
Mobile: +886 989292100
E-mail: michael.chen@linak.com.tw
www.linak.com.tw

TURKEY

LINAK İth. İhr. San. ve Tic. A.Ş.
Phone: +90 312 4726338
Fax: +90 312 4726635
E-mail: sales@linak.com.tr
www.linak.com.tr

UNITED KINGDOM

LINAK UK Limited
Phone: +44 (0)121 544 2211
Fax: +44 (0)121 544 2552
E-mail: sales@linak.co.uk
www.linak.co.uk

DISTRIBUTORS

ARGENTINA

Novotec Argentina SRL
Phone: +[54] (11) 4303-8900
+ [54] (11) 4303-8989
Fax: +[54] (11) 4032-0184
E-mail: info@novotecargentina.com
www.novotecargentina.com

AUSTRALIA

Ballarat Industrial Supplies
www.ballind.com.au

BL Shipways & Co
www.blshipway.com.au

Gas Strut Marine and Industrial
www.gasstrutmarine.com.au

Prime Motion & Control
www.primehyd.com.au

West Vic Industrial Supplies
www.westvicindustrial.com.au

COLOMBIA

MEM Ltda
Phone: +[57] (1) 334-7666
Fax: +[57] (1) 282-1684
E-mail: servicioalcliente@mem Ltda.com.co
www.mem Ltda.com.co

INDONESIA

PL Himalaya Everest Jaya
Phone: +6 221 544 8956
+6 221 544 8965
Fax: +6 221 619 4658
+6 221 619 1925
E-mail: hejplastic-div@centrin.net.id
www.hej.co.id

IRAN

Bod Inc.
Phone: +98 2188998635-6
Fax: +98 2188954481
E-mail: info@bod.ir
www.bod.ir

PERU

Percy Martin Del Aguila Ubillus
Phone: +51 99-883-9879

RUSSIAN FEDERATION

000 FAM
Phone: +7 812 3319333
Fax: +7 812 3271454
E-mail: purchase@fam-drive.ru
www.fam-drive.ru

SINGAPORE

Servo Dynamics Pte. Ltd.
Phone: +65 6844 0288
Fax: +65 6844 0070
E-mail: servodynamics@servo.com.sg
www.servo.com.sg

SOUTH AFRICA

Industrial Specialised Applications CC
Phone: +27 11 312 2292 or +27 11 2077600 (Switch Board)
Fax: +27 11 315 6999
E-mail: garth@isagroup.co.za
www.isaza.co.za

UNITED ARAB EMIRATES

Mechatronics
Phone: +971 4 267 4311
Fax: +971 4 267 4312
E-mail: mechtron@emirates.net.ae
www.mechatronics.ae

For contact details on other countries please visit www.linak.com or contact:

LINAK INTERNATIONAL

Phone: +45 73 15 15 15
Fax: +45 74 15 80 10
Fax: +45 73 15 16 13 (Sales)
E-mail: info@linak.com
www.linak.com

Terms of use

The user is responsible for determining the suitability of LINAK products for specific application. LINAK takes great care in providing accurate and up-to-date information on its products. However, due to continuous development in order to improve its products, LINAK products are subject to frequent modifications and changes without prior notice. Therefore, LINAK cannot guarantee the correct and actual status of said information on its products. While LINAK uses its best efforts to fulfill orders, LINAK cannot, for the same reasons as mentioned above, guarantee the availability of any particular product. Therefore, LINAK reserves the right to discontinue the sale of any product displayed on its website or listed in its catalogues or other written material drawn up by LINAK. All sales are subject to the Standard Terms of Sale and Delivery for LINAK. For a copy hereof, please contact LINAK.



WE IMPROVE YOUR LIFE