

Solar Logic

BERS Pro V4.1

User's Manual




Table of Contents

Introduction	4
What The Program Is Used For	4
User Interface.....	4
Features.....	4
Analysis of Data	4
Simulation Engine	4
Software Details	5
BERS Pro V4.1.....	5
Use of Software.....	5
Contact	5
System requirements.....	5
Processor speed	5
Memory	5
Display	5
Installing BERS Pro from a CD	6
Directory Structure.....	6
Licence.....	7
Licence Details.....	7
Buttons.....	7
Licence Has Expired.....	7
To Renew Your Licence	7
Licence File Not Found.....	8
Main Screen	9
Project Bar	9
Orientation	9
Buttons.....	10
Star Panel	11
Status Bar	11
Starting a Project from Scratch	12
Project Details	14
File name	14
Opening and saving files	14
Location	16
Location From Town Name.....	18
Climate Data	18
Defaults.....	19
Change to the Default Value.....	20
Levels	20
Properties.....	20
Elements.....	20
Importing a background image.....	21
Scanned image	21
Paste from clipboard.....	21
Change colour.....	22
Adjusting image size and position	22
Hiding and restoring the image	23
Editing.....	24
Selecting a node.....	24
Moving nodes.....	25
Add a node.....	25
Delete a node or element	25
Creating a New Zone.....	26
Zone Characteristics.....	26
Air Flow	27
Drawing the Zone	27
Editing the Zone	27
Modelling zones extending over two levels	28
Modelling a zone with a mix of slab on ground and elevated floor	28
Eaves Plan.....	28
Windows.....	29
Modelling windows	29
Adding a new window	29
Window properties.....	29

Editing Windows	34
Custom Windows	34
Window Selection	37
Door	38
Adding a new door.....	38
Editing.....	38
Modelling a zone with a mix of slab on ground and elevated floor	38
External Wall	39
Colour	39
Wall type and insulation.....	40
Wall contact.....	41
Height	41
Internal Wall	42
Partition wall between zones	42
External Floor	44
Under floor space	44
Floor type, floor covering and insulation.....	45
Ceiling Between Levels.....	46
Ceiling type, floor covering and insulation	46
Internal Floor Covering	47
Ceiling to Roof	48
Ceiling type and insulation.....	48
Slope.....	49
Roof space.....	49
Roof	50
Roof type and insulation	50
Slope.....	50
Shape	51
Roof space ventilation	51
Glazing and Frame	53
Stair Well.....	56
Modelling zones extending over two levels	56
Air Flow	57
Natural Ventilation	57
Infiltration	57
Forced Air Movement Using Ceiling Fans	57
Mechanical Ventilation.....	57
Overshadowing by Obstacles	59
Simulation Mode.....	60
Mathematical Basis of BERS	60
Heating	61
Cooling.....	61
Climate file comfort settings.....	61
Detailed Description of Building Elements.....	63
SCRATCH File	63
Simulate	64
Star Panel	64
Analysis.....	65
Temperature Display	67
Select the zone to be displayed.	68
Time period to be displayed.....	68
Changing scale.....	68
Temperature Bins.....	69
Temperature Histograms	70
Short Simulation Report.....	71
Common Buttons.....	72
Thermal and Optical Definitions	73
R value.....	73
U value or Thermal Transmittance	73
SHGC	73
Material capacitance and resistance properties.....	74
Problems and Improvements	76
Intellectual property	76
Licence and Legal Information	76

Introduction

What The Program Is Used For

The BERS (Building Energy Rating Scheme) computer program is a powerful tool that is used to simulate the thermal performance of Australian houses in climates ranging from Alpine to tropical. The star rating that is calculated can be used to show compliance with the thermal regulatory requirements of the Building Code of Australia (BCA).

User Interface

- The graphics based data entry interface has been designed to make the process of thermally modelling buildings fast and accurate.
- Plan images can be imported and displayed in the background.
- Building elements are automatically dimensioned when drawn by the user with a mouse.
- Drawing image scales can be varied as well as the "snap to" grid distance.
- Information about the building and its environment is selected from graphics screens.
- Properties and dimensions can be easily checked or changed with a mouse click on the plan.
- The position of building elements can be easily changed.
- Help screens are available to guide the inexperienced user.
- Calculated data is displayed in graphic form as well as being saved as files or documents.

Features

- Multi-storey buildings comprised of many zones can be modelled.
- Roof lines are drawn by the user enabling eaves widths for walls, doors and windows to be automatically calculated .
- Shading of windows and walls by adjacent walls is automatically calculated.
- Overshadowing by neighbouring buildings, vegetation, mountains etc requires the dimensions and location of the obstacle to be entered only once relative to the building.
- The dimensions of walls, doors and windows are displayed as elevations that are scaled to the plan dimensions.
- Properties can be copied and then pasted to other elements of the same type.
- User constructed information such as window shading schedules, user and client profiles, default building properties etc can be saved, and then later opened and used for future projects.
- Ventilation is automatically calculated from the dimensions and location on the plan of windows, doors and other openings in combination with the wind data in the climate file.

Analysis of Data

- The thermal performance of a building can be analysed in terms of heating and cooling energy per floor area. This is converted to a STAR rating for regulatory compliance.
- A star rating is also assigned to each zone in the building to allow the user to easily identify which zones are working well and which ones need changes to improve performance.
- A record of the last 10 simulations is saved and can be easily accessed to assess progress in increasing the performance of a building.
- The thermal performance of "free running" buildings can also be assessed.
- Hourly temperatures of any zone for up to 4 projects can be displayed graphically.
- The starting date and duration of a period of interest can be selected for display.
- Hourly temperatures can be automatically selected for the display of extreme periods such as "a hot week in summer", "a cold week in winter" etc.
- Any of the 69 climate files can be displayed as hourly temperature graphs as described above.
- Building element properties such as the R-Values, U-Values, Solar Heat Gain Factors, graphs of window transmittance and absorptance curves etc are displayed as building elements are selected.

Simulation Engine

The mathematical "engine" at the heart of the BERS program is the same CSIRO thermal simulation engine used by ACCURATE, the benchmark software for the NatHERS scheme. ACCURATE is text based and does not have a graphics user interface.

Software Details



BERS Pro V4.1

This software is copyright protected.

It remains the intellectual property of Dr Holger Willrath.

The CSIRO owns the copyright to the thermal simulation engine.

No copies of this software may be distributed by the licensee under any conditions.

Use of Software

This software may **only be used** for the purpose of assessing the thermal performance of buildings.


It expressly forbidden to use this software to provide training in the operation of BERS.

Contact Solar Logic for information about the BERS trainer program for those wishing to train assessors in the use of BERS.

Contact

For further information visit the Solar Logic Website at www.solarlogic.com.au

Email Solar Logic at info@solarlogic.com.au




System requirements



Processor speed

BERS uses a simulation program which does a lot of numeric processing.

The time taken to do a simulation depends on the number of zones in the building which is being modelled and the clock speed and type of CPU. A speed equivalent to a 1GHz Pentium is probably a minimum for reasonable simulation times.



Memory

When the program is simulating about 1.2 GB of memory is required. Most computers won't have this so **virtual memory** must be used as well. This is where the hard drive is used temporarily in place of RAM.

The correct sequence for allocating virtual memory in **XP professional** and for **XP home** is:

Start>Control panel > Performance and maintenance > System > Advanced > Performance > Settings > Advanced > Virtual memory > Change > Custom size

Set the **virtual memory** at (1.2 GB – RAM).

Display

The minimum screen resolution required is 1024 x 768.

Installing BERS Pro from a CD


You will need about 500 MB free hard drive space.









Shut down all other programs.

Run [SETUP.EXE](#) from the CD drive.

Directory Structure

When BERS is installed the directory structure is as shown below.



 Data	Contains data used by the BERS Program. This should never be edited or the program will cease to function correctly.
 Default	Contains files of saved default settings
 House	Contains the BERS Project files. These should be archived from time to time.
 Output	Contains the results of the simulations.
 Schedule	Contains the shading schedules.
 Temperature	Contains the hourly temperature output files. This should be cleared out regularly as the files created during each simulation are quite large.
 Utilities	Various BERS utility programs will be added to in this directory.
 Plans	Bitmaps of plans are stored here.

Licence

Licence Details

Each copy of BERS is licenced to a specific licensee.

Details are given in the pop up screen when the software is first opened.

If the [licence file is missing](#) or if the [licence has expired](#) a pop up message to this affect will be displayed.



Buttons



When the help button is pressed the message will relate to any of the problems mentioned above or will show this [Help Screen](#).

Pressing the [Esc](#) key will close the program.



The  button or the [Enter](#) key will close the licence screen.

The [licence expiry](#) date appears in the top window.


[Today's date](#) is displayed in black below.

The [number of days left](#) on the licence is to the right.

The [licencee's name](#) appears in the middle window.

The [licence number](#) appears in the lower window.

Licence Has Expired




The licence to use this software has expired.

To Renew Your Licence

Email Solar Logic at info@solarlogic.com.au

Licence File Not Found




Your Licence File, **BERSPro.LIC** is missing from the BERS41 directory.



Even if your licence has expired it should still be in this directory.

Main Screen

The Main Screen provides the links to all other windows where data is entered or information is displayed.




The building is drawn to scale and may have an image of the plan displayed in the background.

Project Bar

This bar contains the project identifiers. Clicking on the yellow letters opens windows where changes can be made.

Project Name Bribie	Run 2	Location THE GAP	PC 4825	Climate File climat39.TXT
Project Name Bribie	Project Name			
Run 2	Run Number			
Location THE GAP	Location Name			
PC 4825	Post Code			
Climate File climat39.TXT	The climate file name can only be changed by changing the location Name or the location Post Code.			

Orientation



The **orientation** of the site plan can be changed by clicking in the circle and dragging the North arrow to a new position or by entering the "page up" orientation into the edit box.

Buttons



New File A new BERS project will be created.



Open File This opens a previously saved project.



Save File BERS projects are saved in the HOUSE subdirectory.



Save File As BERS projects are saved in the nominated location.



Project Details can be entered as well as the project file name.



The **location** selection determines the climate file used for the simulation.



Import a **Plan**



Hides background plan. Same as  in the background_image screen.



Help and Information



Tools Program "add ons" that facilitate design or calculations.



Print the Screen



Simulation Mode Each zone can be simulated as conditioned or free running.



Simulate



Edit Mode allows changes to be made to the zones and building elements. The nodes are displayed. These nodes can be dragged with the mouse.



The **scale** of the drawing can be changed from 1m represented by 20 to 80 pixels .




Drawing of rooms and roofline can be made to **snap** to a virtual grid of 100, 250, 500 or 1000mm spacing.



The scale and snap settings are displayed to the right of the buttons.



The nodes defining the eaves outline can be nudged one pixel with the direction arrows.



The movement of the cursor can be constrained to move up and down or across, or it can be unconstrained and move in any direction.



Occasionally there may be some information left in the drawing area when a pop-up appears or another screen passes over the top. The refresh button will clear this.



Display the **SCRATCH File**



Display a **Detailed Description** of building Elements



Short Simulation Report




Analysis



Defaults



Create a New Zone



Level 3

Level 2

Level 1

Buildings with up to 6 **levels** can be modelled.
Clicking on the level button will cause that level to be displayed.



Add a **new level above** the currently selected level.



Add a **new level below** the currently selected level.



Delete the level currently selected.




Display the **level above** the currently selected level in dotted outline.



Display the **level below** the currently selected level in dotted outline.


Star Panel

The results from the current as well as previous simulations are displayed.




Status Bar

The status bar at the bottom of the screen will display information such as the name of the file just opened, the zone name and area and cursor position,



and identify the object selected.



Starting a Project from Scratch

The following sequence should be followed when starting a new project.



Press the **New File** button.

This will delete all currently entered information and restore the defaults.



Press the **Project Details** button.

Enter the **Project Name** and **Run Number**, and any other information you may require on output files.



Press the **Location** button.

Select a location by Name or Post Code and and nominate the wind shielding of the site.

Level 1

Starting with the bottom **level** information about the building should now be entered.




Default properties for all building elements are selected so that only exceptions to these properties for any particular building element need be changed.

The **default properties** can be set to be different for each level.



Plans can be **imported** and scaled so that zones can be drawn on top of the drawing.



Select an appropriate scale and “snap to” setting.



Each room of the building should be drawn as a separate **zone**.

Ensuite bathrooms can be included in the bedrooms.



Draw the **eaves** in a similar way to zones. These should be drawn for each level.



To add windows click the **window** button and then click on an external wall where the centre of the window is to be located.



To add doors click the **door** button and then click on an external wall or a partition where the centre of the door is to be located.



To add internal walls click the **internal wall** button and click again inside the target zone where one end of the internal wall is to be anchored. Move the cursor and click the mouse button to finish the wall at the other end.



To add a skylight click on the **skylight** button and click again inside the target zone where the skylight is to be placed.

Alternatively right click inside the target zone where a skylight is to be modelled and select the skylight button.



Stairwells can only be modelled in the zone where the top of the stairs are located.

Stairwells can not be added to level 1.

To add a stairwell click on the **stairwell** button and click again inside the target zone.



Save the job and **simulate**



The **Analysis** screen gives additional information to what is displayed on the star panel.

Make changes one at a time until the required performance level is attained.


Project File Management




A new BERS project will be created.



Opens a previously saved project. The saved project files all have a BER extension. They are contained in the HOUSE subdirectory.



Projects can be saved in any directory. The default directory is the HOUSE subdirectory. File names are determined by the project name and run number and can not be changed here. To change the file name first change the project name in the [Project Details](#) screen.



Projects can be quickly saved in the HOUSE subdirectory without having to negotiate the Save dialog screen. However there is no checking to see if the user wants to replace any existing file with the same name.

Project Details



Project house keeping information can be entered as well as the project file name.

Project Details

Client Details

Name: BrickBilt Builders

Phone: 07 2598 6354 Fax: 07 2598 6354 Email: bbb@powerup.com

Postal Address: P O Box 4563 Cool Bay QLD 4092

Street Address: 17 Ash St Britstone Lane Cool Bay QLD 4092

Assessor Details

Name: Bill Winter

Phone: 041 365289 Fax: 07 6542 3698 Email: bilwinter@woodchuck.com.

Postal Address:

Street Address: 367 Main Drive Caltoogla Qld 2453

Assessor Number: BA 2569

Dwelling Details

D.P. Number: DP TREWQ-14384-78 Unit Number or Name:

Lot Number: OR House Number: 53

Street Name: Broad Ave

OR Development Name:

Suburb or Town: Lakesford

State: NSW Post Code: 2063

Assessment Details

Project Name: Bribie Run Number: 2

Comments: Software: BERS Version: 4.1 Today Date: 29/03/2005

1 + Insulated r2.5 ceiling
Foil in wall

File name


The **Project Name** and the **Run Number** determine the file name.
The combination above produces a file name Bribie2.BER.

Information describing the building or simulation can be entered as text in the comment box.


The run number should be incremented and a note made in the comment box every time a change is made. The file with this new file name should be saved before the simulation is run.

Opening and saving files

Assessor and client details can be saved and reused.



Assessor details can be saved as *.ASS files also located in the SCHEDULE directory. The assessor name can not be changed but other details can be updated.




Client details are saved as *.CLI files that are located in the SCHEDULE directory.


Location



Selecting a location allocates the hourly annual [climate data file](#) used by the simulation engine. [Wind shielding](#) around the site is described.



- The simulation process uses one of 69 annual climate data files.
- The climate data is in the form of hourly values of temperature, humidity, solar irradiation (beam and diffuse), cloud cover, wind speed and wind direction.
- The majority of this data has been collected by the Australian Bureau of Meteorology.
- Each Australian Post Code has been assigned the data set that most closely approximates its climate.
- Some post codes have more than one possible climate file.



The location is displayed as a red dot on the map when sufficient information to determine latitude and longitude has been entered.

All Climates

Display All Climate Zones

All postcode latitude and longitudes are displayed as a colour coded dot. The legend associates the colour to the climate file. The climate file is displayed in the status bar as the cursor passes over.

Current Climate



Display All Other Locations in the Same Climate Zone

Each location sharing the selected climate file is displayed as a colour coded dot.

Show Cities

Display Cities and Latitude, Longitude Lines

Major cities and lines of latitude and longitude are superimposed onto the map.



The **Wind Shielding** combo box is used to modify the outdoor wind speed data (usually measured at an airport) to something closer to what would actually exist around the building.

**Name**

Climate file selection is based on Location name.

**Post Code**

Climate file selection is based on Post Code

**Climate File**

Display the average monthly climatic data as histograms

Location From Postcode**Post Code**

The Post Code can be entered using this screen or by entering the name of the location. There will be more than one location with this Post Code so the correct name must be selected. This will produce a red dot on the location map.

In some cases the area covered by the Post Code is quite large and more than one climate type exists within its boundaries. In this case the most suitable climate file may be selected with the radio buttons.

The location from which the climatic data was obtained is displayed at the bottom of the window.

Location from Post Code

PC 4825

Location Names

- HEALY
- MENZIES
- MICA CREEK
- MILES END
- MORNINGTON
- MOUNT ISA
- PARKSIDE
- PIONEER
- PITURIE
- RYAN
- SOLDIERS HILL
- SUNSET
- THE GAP

Latitude -21.6
Longitude 139.2

Climate File

☒ climat39.TXT
☐ climat38.TXT

Climate File Location
Mt Isa

Location from Name

Name THE GAP

Location Post Code

4061
4825

Post Code 4825
Latitude -21.6
Longitude 139.2

Climate File

☒ climat39.TXT
☐ climat38.TXT

Climate File Location
Mt Isa

Location From Town Name



Name

Climate file selection is based on location name.


Where more than one location with this name is available, the correct Post code must be selected. Clicking on the Post Code will display a red dot on the location map.

In some cases the area covered by the Post Code is quite large and more than one climate type exists within its boundaries. In this case the most suitable climate file may be selected with the radio buttons.

The location from which the climatic data was obtained is displayed at the bottom of the window.

Climate Data

Mean monthly maximum temperature, minimum temperature, solar radiation and humidity for the current climate file can be calculated and displayed.



Display Data in Tabular Form




Print the Graphs

Defaults

DEF

Default properties are used when modelling zones so that only exceptions to these properties need be selected and changed.

- Defaults can be made to apply to the whole building or can be set for each [level](#).
- Properties of the building elements can be assigned the [current default values](#).
- The defaults can be [saved](#) and reused in new projects.



The building elements whose properties are to be affected by the changes are selected by ticking the box under the button.

Change defaults of all levels to those selected from this level

The default values and properties of the selected elements of all levels are changed to the default values of this level. This will not affect the properties of any elements already modelled but all future modelling will adopt these new values


Change all elements on this level to the selected defaults

The properties of the selected elements on this level will be assigned the current default values. This does not include dimensions which will remain as they are.

Change to the Default Value




Default screens allow the properties of elements that have already been modelled to be changed to the current default setting. Properties of all building elements of the same type can be assigned all or some of the properties selected in the default window.



The selection of levels, properties and elements are clarified using the door example above.

Levels




The top option applies the default door properties to the whole building.

If the properties are to apply to more than one but not all levels then it is better to use the




Copy button in the default door screen, change to a new level **Level 2** to be assigned the same default values and



Paste the information into the new default screen then press  and apply the settings to that level only.


Properties



In the case of the door example the top selection would change all the doors to Solid timber but retain the original dimensions.

The second option would turn all the doors into Solid timber doors that are 2100 mm high and 750 mm wide.

Elements



The top selection applies the changes to all doors.

The second selection changes only those elements that had the properties displayed in the default element screen before the last changes were made.


For example if the default door screen showed **Hollow core doors** and this is changed to **Solid timber doors** then the second selection would only change the properties of **Hollow core doors** to **Solid timber doors**.

Importing a background image



An image of the plan can be displayed in the background.

- This image can be scaled and positioned enabling zones to be traced.
- Different plan images can be displayed for each level of the building.
- The appropriate plan image will be displayed when levels are changed.
- Plan images, and the display magnification and positioning are automatically saved and retrieved next time the project is opened.
- The image colour can be changed to provide a more subdued background



Scanned image

A plan can be easily scanned and saved as a bitmap (BMP).


Plans that have been saved as black and white bitmaps can be imported but they can not have the black changed to another colour. To allow colour change import the black and white bitmap into WINDOWS PAINTBRUSH and save it as a 24 bit colour bitmap.

TIF files should also be imported into Paintbrush first and then saved as 24 bit colour bitmaps.

If the image is distorted or rotated then it should be imported into a program such as PHOTOSHOP, adjusted and saved. PHOTOSHOP won't allow black and white bitmaps to be rotated so the image should first be changed into a 24 bit colour bitmap.



Open the BERS41\PLANS directory and display the *.BMP files.



Paste from clipboard



Paste the contents of the clipboard as a background image.

Bitmaps can also be copied onto the clipboard and then pasted into the background.

For example an AUTOCAD drawing being displayed can be captured onto the clipboard by pressing the Prt Sc keyboard key.


PDF files can be copied onto the clipboard by displaying in ADOBE ACROBAT and pressing the Prt Sc keyboard key.

Alternatively they can be imported into a program such as PHOTOSHOP and saved as bitmaps.

Change colour




The bitmaps can be displayed in a more subdued manner. Changing the colour may take several seconds.



Adjusting image size and position




The bitmap image will be imported at a scale of 1:1.




The scale of the bitmap usually exceeds that of the program drawing resolution of between 20 to 80 pixels/m.

Selecting a picture scale magnification using the radio buttons can save time if the scaling is known to be one of those listed.



If the scale is unknown then move the red arrow to a section of the plan where a dimension is included.

Make this dimension as large as possible for the best accuracy.
Check the scale on a different part of the plan to make sure the scan was not distorted.



It can be useful to align the positioning of the picture with the grid to which the zone shapes will conform before tracing zones. The picture position can be adjusted using the X and Y sliders.



These position offsets as well as the magnification can be saved using the Save button and later Restored.




The picture can be returned to the top left hand corner with the Zero button.

Hiding and restoring the image



The background bitmap can be hidden.

This has the same function as  on the main screen.




The background bitmap can be restored.

Editing



Edit mode is used to allow changes to be made to the zones and building elements. Clicking this button hides or displays the nodes which define the position of the walls, doors and windows.

Selecting nodes can display information about the object. The position of the nodes can be changed by clicking and dragging as described below.



Selecting a node

Eaves, window or door nodes are selected by


- Moving the cursor to the node
- Click on the node with the **left hand mouse button**.

Zone nodes can be selected with the cursor by first

- clicking with the left hand mouse button anywhere within the zone containing the node
- and then clicking on the node.
- The selected node will change colour.
- Information about the object selected is displayed on the status bar at the bottom of the screen.
- Holding down the Shift button allows more than one node to be selected.
- Holding down the Ctrl button allows the whole zone to be selected.
- Holding down the Alt button allows all zones on that level to be selected.
- Highlighted nodes can be dragged to a new position.

If several wall nodes are superimposed such as when 2, 3 or 4 rooms meet in a corner, clicking in the Zone A first determines that the node from Zone A is selected.

If an eave node and zone node are superimposed, the eave node will be selected if the zone has not been clicked.



When the nodes in the centre of doors or windows or at the ends of the internal walls are selected with the **right hand mouse button**, a new window will open allowing the properties of these elements to be edited.

Right hand mouse clicking anywhere on a wall will allow the wall properties to be edited. Right hand mouse clicking anywhere in a zone will allow other zone properties to be edited.

Moving nodes

- The selected node/s can be dragged by holding down the left hand mouse button and moving the mouse.
- Windows and doors can't be dragged beyond the wall limit.
- If moving a node causes an overlap of zones the program won't let go of the node until there is no overlap.
- If an internal wall node is dragged outside of its host zone the program won't let go of the node until it is returned to the zone.
- If a complete zone is to be moved for the first time, select a node in the zone, select a second node with the control key down and drag.

Add a node



To add a node to a wall or eaves outline click where the new node is to be located.
If walls have nodes where there is no change in wall direction or property they will be eliminated after a button click.

Delete a node or element



Nodes, internal wall, windows and doors can be deleted by highlighting the node and clicking on the delete button.

Creating a New Zone



- Each room of the building should be drawn as a separate zone.
- Ensuite bathrooms can be included in with a bedroom zone.
- Zoning affects the calculation of air flows from natural ventilation. Rooms separated by walls should not be combined into one zone if, by doing so, the cross-ventilation potential is artificially enhanced.

Zone Characteristics

When a new zone is first drawn it is automatically given a new name and representational colour based on its type. The zone name can be edited at this stage or later in the [Zone Elements](#) screen.



The colour can be changed by clicking on the tile.

The type of zone determines how heating, cooling and internal heating loads are calculated. Each zone can be simulated in one of two [modes](#), conditioned or free running.



This can be changed later with the  button.


In Rating Mode the heating and cooling calculation modes should not be changed from the defaults assigned by the program.

Air Flow


Clicking the  arrow will open the [Air Flow](#) window.
The air flow data can be edited at this stage or later in the [Zone Elements](#) screen.

Drawing the Zone


After clicking the New Zone button click the Left Hand mouse button on the drawing grid to create the first node. Drag the line to the next point where it changes directions and click again.



Continue this until the last node is created on top of the first when the zone becomes complete and assumes a colour similar to the tile.



When the zone is complete, the elements of that zone, ie the walls, floor and ceiling are assigned the default values



If the drawing is unsatisfactory and you wish to stop before the zone is completed, click on the delete

zone button. 

Editing the Zone



To add a node to a wall or eaves outline click where the new node is to be located.

If walls have nodes where there is no change in wall direction or property they will be eliminated after a button click.



Nodes, internal wall, windows and doors can be deleted by highlighting the node and clicking on the **delete** button.



To delete the zone select a node in the zone and click the **delete zone** button.

Modelling zones extending over two levels

- Draw the **zone**.
- Draw another **free running zone** of the same floor area directly **above** the zone.
- Model a **stair well** in the top level having the same area as the floor between the levels.

Modelling a zone with a mix of slab on ground and elevated floor


- **Divide** the room where the floor changes from on ground to elevated.
- Draw the room as **two zones** with different floor types
- Add an **opening** between the zones having the same area as the partition between them.

Eaves Plan



The eaves plan allows the program to calculate the eaves width for each door, window and wall. This determines the amount of shading. Deck roofs and opaque pergolas should be modelled as part of the eaves plan.

After clicking the **Draw Eaves** button click the Left Hand mouse button on the drawing grid to create the first node. Drag the line to the next point where it changes directions and click again. Continue this until the last node is created on top of the first when the eaves outline becomes complete. □-----□



These nodes can be selected with the cursor by clicking with the left hand mouse button.

- The selected node will be highlighted by changing colour.
- Holding down the Shift button allows more than one node to be selected.
- Highlighted nodes can be dragged to a new position.



To delete the eaves highlight one of its nodes and clicking on the delete eaves button.

Windows



Windows and how they are shaded largely determine the amount of solar radiation entering the building and contributing to its heating.

Windows also allow heat flow in and out of the building by virtue of their relatively high conductance and their ability to provide ventilation when open.

Modelling windows

Windows can be selected as a combination of a generic glass and a generic frame, or alternatively [Custom Windows](#) with known characteristics can be selected from a database of proprietary windows.

- Each window can be shaded by eaves and shading devices operating under variable monthly schedules.
- Internal furnishings can be selected to vary the effect of sunlight penetration and heat flow through the glazing.
- Vertical fins that attached to either side of a window can be modelled

Adding a new window



Click the window button and then click on an external wall where the centre of the window is to be located.

Window properties

Generic	Custom Windows
----------------	-----------------------

The generic window screen requires a glass and frame combination to be selected.


- The amount of **tinging** in the **glass** determines the amount of sunlight heating up the room. This is displayed in 3 columns, **Clear**, **Light Tint**, **Heavy Tint**.
- The number of layers of glass and any low emittance coatings determine the heat conductance through the glass. This is displayed in 5 rows, **Single Glazed**, **Single Glazed Low E**, **Double Glazed Low E** and **Opaque**.
- The **opaque elements** in the bottom row can be used to provide ventilation without incurring solar gains.



The conductance of the **frame** is determined by the properties of the composite frame materials.





Custom Windows can be selected by brand name and product.





The **thermal properties** of the selected window are displayed.

Rglass 0.17 Rframe 0.33 Rt 0.19 UA 5.19 SHGC 0.55



The **Window Style** determines the maximum opening possible for ventilation.


Opening 50%




When **window furnishings** are drawn across the window they reduce heat conductance through the window system.

This is displayed as the added **R value**. **Rfurn 0.33**

Window furnishings can also reduce overheating when drawn across sunlit windows.




Shading devices that are attached above or in front of windows reduce overheating when installed on sunlit windows.



Some devices have a fixed amount of shading.

Other shading changes from month to month. Monthly Schedule ☒
A monthly shading schedule can be applied to shading devices and obstructions.
This can be used to model semi transparent pergolas.



The percentage shading per month can be changed by clicking on a node at the top of the bar and dragging it to the required percentage. This value is shown in the display box.


Jan Make all months the same as January. 75% shade cloth can be modelled by dragging the January node to 75 then select this button.
Semi transparent roof sheeting can also be modelled in this way.

Save Save the current monthly shading values.

Open Open a file with a saved monthly shading schedule.

Reset Reset shading back to 100% throughout the year.

Vertical Shading ☒ Each window can be modelled as having vertical fins which provide shading.



The drawing shows the fins on either side of the window shown in plan.
The dimensions can be entered next to the fins in the diagram or below the diagram.





Reset all dimensions to zero.

Head Ht mm

The head height is the distance between the floor and the top of the window.
This dimension is used for the ventilation calculations.

Height	1200 mm	Width	1500 mm	Offset	150 mm
<input type="radio"/> 600 <input type="radio"/> 1800 <input type="radio"/> 900 <input type="radio"/> 2100 <input checked="" type="radio"/> 1200 <input type="radio"/> 2400 <input type="radio"/> 1500 <input type="radio"/> 2700		<input type="radio"/> 600 <input type="radio"/> 1800 <input type="radio"/> 900 <input type="radio"/> 2100 <input type="radio"/> 1200 <input type="radio"/> 2400 <input checked="" type="radio"/> 1500 <input type="radio"/> 2700		<input type="radio"/> -300 <input type="radio"/> 300 <input type="radio"/> -150 <input type="radio"/> 450 <input type="radio"/> 0 <input type="radio"/> 600 <input checked="" type="radio"/> 150 <input type="radio"/> 750	

Dimensions can be selected with the radio buttons entered into the edit boxes.
These dimensions are shown at the same scale as the plan.



The **offset** is the vertical distance from the top of the window to the horizontal projection of the lowest part of the eaves (usually the gutter) onto the wall.

The diagram shows an offset of 150mm where the lowest part of the eaves is 150 mm **above** the top of the window.



If the lowest point is **below** the top of the window (as in a window hood), the offset is given a negative value.


2nd Eaves mm

The eaves plan drawn by the user allows the program to calculate the eaves width for each door, window and wall.


The 2nd Eaves edit box allows the automatically calculated eaves width to be overridden when the value entered is greater than 0.

This is useful if 2 windows above each other in the same wall having different overhangs are to be modelled.






Head Ht	2100	mm	2nd Eaves	0	mm	
Height	600	mm	Width	1200	mm	Offset 150 mm




Head Ht	1200	mm	2nd Eaves	600	mm	
Height	900	mm	Width	1200	mm	Offset 150 mm

Hint. When windows are placed exactly on top of each other their images on the plan will cancel making them impossible to see. This can be overcome to some extent by offsetting the nodes.



Nodes have been horizontally offset




Editing Windows

Moving Windows

Window nodes can be selected with the cursor by clicking with the **left** hand mouse button.

- The selected node will be highlighted by changing colour.
- Highlighted nodes can be dragged to a new position.



Changing Properties

A window whose properties are to be edited must have its node be selected with the cursor by clicking with the **right** hand mouse button.

Deleting Windows



Click on the window node and press the **Delete a Node or Element** button.

Custom Windows



Commercially available windows with known characteristics can be selected from a database.

Custom Windows

OK

Cancel

Name

GGG-05-002a

Brand

Generics

Select Product

GGG-05-001a

GGG-05-002a

GGG-05-003a

GGG-05-004a

GGG-05-005a

GGG-05-006a

GGG-05-007a

GGG-05-008a

Search

Manufacturer

All

U-Value

Max 30.00

Min 0.00

SHGC

Max 1.00

Min 0.00

Window

U-Value 5.46

SHGC 0.84

Frame

Timber

Vision Fraction 0.85

U-Value 3.00

Glass

Single Glazed Clear

Vis Trans 0.89


U-Value 5.88

No Panes 1


UV Trans 0.68

SC 0.99

Solar Transmittance



Solar Absorptance



Selecting a window
Open the Brand drop down list.

Brand

Generics

Bradnam's Windows & Doors

Breezway Louvre Windows

Canterbury Windows and Doors

Christoffel

Crane Aluminium Systems

Dowell Windows

Everglaze Industries

G. James Glass & Aluminium

Generics

Generics (3 mm clear + reflective blind)

Generics (Applied film on 3 mm clear)

Generics (Armorcoat film on 3 mm clear)

Generics (Panorama film on 3 mm clear)

Generics (Solar Gard film on 3 mm clear)

Selecting a brand will open the Product listing for that company.

Select Product

GGG-05-001a

GGG-05-002a

GGG-05-003a

GGG-05-004a

GGG-05-005a

GGG-05-006a

GGG-05-007a


GGG-05-008a

Data relating to glass, frame and the total window is displayed.

Copyright Solar Logic 2007

Window	U-Value	5.46	SHGC	0.84	
Frame	Timber				
Vision Fraction	0.85	U-Value	3.00		
Glass	Single Glazed Clear				
Vis Trans	0.89	U-Value	5.88	No Panes	1
UV Trans	0.68		SC	0.99	

Solar Transmittance and Absorptance curves are displayed.



Search



The Search button finds all products with similar properties either from the entire data base or from a particular Brand.

Name	GGG-05-002a		
Brand	Generics		
Select Product	<div>GGG-05-002a</div> <div>AIR-05-096a</div> <div>AIR-05-099a</div> <div>AIR-05-176a</div> <div>AIR-05-235a</div> <div>ANE-04-007a</div> <div>BRZ-04-081a</div> <div>BRZ-04-101a</div>		
Search	<div><input type="radio"/> Manufacturer</div> <div><input checked="" type="radio"/> All</div>	<div>U-Value</div> <div>Max 5.56</div> <div>Min 5.36</div>	<div>SHGC</div> <div>Max 0.94</div> <div>Min 0.74</div>

The U-Value ranges are automatically set at +/- 0.1(about 2%) and the Solar Heat Gain Coefficient (SHGC) is set to +/- 0.1 (10%).

The U-Value and SHGC ranges can also be set manually.
The product list automatically updates as changes are made.

U-Value	SHGC
Max 30.00	Max 1.00
Min 0.00	Min 0.00



Reset the Maximum and Minimum to encompass all options.

Window Selection




There are thousands of commercially available windows that can be selected for simulation.

The important properties that determine how windows perform in different climates are the total window conductance or **U value** and the solar heat gain coefficient, **SHGC**.


To make the selection process easier proceed in the following way.

Make a selection from the generic window combination of **glass** and **frame**.



Simulate using these combinations until a satisfactory result is obtained.

Change to the Custom Windows mode.




Custom Windows can be selected by brand name and product.

Search



The Search button finds all products with similar properties either from the entire data base or from a particular Manufacturer.



The **U-Value** ranges are automatically set at +/- 0.1 (about 2%) and the **Solar Heat Gain Coefficient** (SHGC) is set to +/- 0.1 (10%).

This gives you a selection of windows from different (or the same) manufacturer which have similar optical and thermal properties to the generic window in the simulation.

Simulate again with the selected proprietary window product.

Door





Doors allow heat flow in and out of the building by virtue of their conductance and their ability to provide ventilation when open.

Doors are defined by their type which determines the thermal resistance and capacitance, and their dimensions.


Shading is determined automatically using eaves plan information.

Adding a new door

Click the door button and then click on an external wall or a partition where the centre of the door is to be located.



Doors connecting zones have the respective zone colour tiles displayed at the top.



Editing

A door whose properties are to be edited must have its node selected with the cursor by clicking with the **right hand** mouse button.

Door nodes can be selected with the cursor by clicking with the **left hand** mouse button.

- The selected node will be highlighted by changing colour.
- Highlighted nodes can be dragged to a new position.



To delete a door click on the door node and press the **Delete a Node or Element** button.

Modelling a zone with a mix of slab on ground and elevated floor

- **Divide** the room where the floor changes from on ground to elevated.
- Draw the room as **two zones** with different floor types
- Add an **opening** between the zones having the same area as the partition between them.





External Wall







External walls are created when a zone is drawn.


- To inspect or **edit** the properties of a wall **right click** on the wall.
- To **move** a node **left click** the node and drag it to its new position.
- To **move** a wall or several sections of wall first use the **Shift Key** to select each node to be moved. Drag the wall sections to the new position.
- To delete a wall click on a node at that is on the anticlockwise end of the wall to be eliminated and press the **Delete a Node or Element** button.

External Wall 1 of Zone 2 Liv/Kitchen 1

 OK
  Cancel

Type	Insulation	Height
 <p>Brick Veneer</p>	 <p>Foil, Reflective One Side, Anti-glare Other</p>	<div style="display: flex; align-items: center;"> <input type="text" value="2400"/> mm </div> <div style="margin-top: 10px;"> <input type="radio"/> 3000 <input type="radio"/> 2700 <input type="radio"/> 2550 <input checked="" type="radio"/> 2400 </div>
<div style="display: flex; align-items: center;"> <div style="border: 1px solid black; padding: 2px;">Thickness</div> <div style="border: 1px solid black; padding: 2px; margin: 0 5px;">110</div> <div style="border: 1px solid black; padding: 2px;">mm</div> </div> <p style="color: red; font-weight: bold;">R 0.24</p>	<p style="color: red; font-weight: bold;">R 0.91</p>	<div style="background-color: #008080; color: white; padding: 5px; text-align: center;">Colour</div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; padding: 5px; margin-right: 5px;"> <div style="background-color: black; color: white; padding: 2px;">Dark</div> <div style="background-color: #ccc; padding: 2px;">Medium</div> <div style="background-color: #eee; padding: 2px;">Light</div> </div> <div style="flex-grow: 1; background-color: #ccc; border: 1px solid #999;"></div> </div> <p style="color: red; font-weight: bold;">Absorptance 0.50</p>
<div style="display: flex; justify-content: space-between; align-items: center;"> L 8.0 m A 14.03 m² Orient 37° Rt 1.14 UA 10.76 </div>		
<div style="background-color: #008080; color: white; padding: 5px; text-align: center;">Beyond the Wall</div> <div style="border: 1px solid #999; padding: 10px; margin-top: 5px;"> <input checked="" type="radio"/> Air <input type="radio"/> Shaded Air <input type="radio"/> Neighbour <input type="radio"/> Earth </div>		



Colour

Colour determines how much of the incident solar radiation is absorbed.

The screenshot shows a 'Colour' dialog box with a blue title bar. It contains a 'Basic colors' section with a 4x8 grid of color swatches. Below this is a 'Custom colors' section with a 2x6 grid of black swatches. A 'Define Custom Colors >>' button is located below the custom colors grid. To the right of the color grids is a large color selection area with a rainbow gradient and a crosshair. Below the color selection area are input fields for 'Hue: 153', 'Sat: 62', 'Lum: 152', 'Red: 137', 'Green: 146', and 'Blue: 186'. There are also buttons for 'ColorSolid', 'Add to Custom Colors', 'OK', and 'Cancel'. In the bottom left corner, there is a 'Colour' label and an 'Absorbance 0.50' label.

Dark, medium and light are often as close as the designer gets to knowing external colours. If the colours are known, clicking on the colour panel will open up a large choice of colours.


The colour value is converted to **absorptance**, the fraction of incident sunlight absorbed and turned into heat.

The door, wall and window dimensions are shown in elevation at the same scale as the plan. The same wall is shown below when the scale is halved.





If the tops of the walls are truncated, switch to a smaller scale.

Wall type and insulation



The wall type and insulation databases will be added to as new products become available.



- The R values displayed in the **Type** panel is for the material of the wall without any airspaces .
- The R value of air spaces and insulation is displayed in the **Insulation** panel.

L 8.0 m A 14.03 m² Orient 37° Rt 1.14 UA 10.76

Length, Area, Orientation, Total wall R value and Total wall transmittance values are also displayed.

Thickness **mm**

The thickness of the main part of the wall can be changed by entering a value in mm.

In a brick veneer wall or a cavity brick wall this dimension would apply to the width of the brick. For a log wall this would be the width of the logs.

Wall contact

Beyond the Wall

☒ Air
☐ Shaded Air
☐ Neighbour
☐ Earth

- Air - normal external wall
- Shaded Air - wall is in shade at all times
- Neighbour - this is a party wall to a neighbouring unit.
- Earth - the wall is in contact with the earth such as a cellar wall

Height

Height **mm**

☐ 3000
☐ 2700
☐ 2550
☒ 2400

- The height of the wall can be changed by entering a value in the box or selecting the appropriate radio button.
- This is the height of the external wall as seen from inside the zone.

Internal Wall



Internal walls may be a **partition wall** between two zones, (interzone wall), or a **wall within a zone**, (intrazone wall).







Partition wall between zones



Interzone partition walls are created when a new zone is first drawn or when zone boundaries are moved. All walls forming boundaries around zones are given 2 sets of properties. Which properties are used depends on whether the wall forms an external boundary or joins to another zone.

- To inspect or **edit** the properties of a wall **right click** on the wall.
- To **move** a node **left click** the node and drag it to its new position.
- To **move** a wall or several sections of wall first use the **Shift Key** to select each node to be moved. Drag the wall sections to the new position.
- To **delete** a wall click on the node that is on the anticlockwise end of the wall to be eliminated and


press the  **Delete a Node or Element** button.

Partition, Wall 5 of Zone 1 and Wall 6 of Zone 2

Type	Insulation	Height
 Cavity Panel 75mm gap Thickness <input type="text" value="10"/> mm R 0.12	 No Insulation R 0.16	<input type="text" value="2400"/> mm <input type="radio"/> 3000 <input type="radio"/> 2700 <input type="radio"/> 2550 <input checked="" type="radio"/> 2400

L 5.0 m A 8.85 m² Orient 90° Rt 0.28 UA 20.02



Internal Wall 1 of Zone 6










Wall within a zone

This type of wall can be used to provide thermal mass to a light weight area.



To draw a wall within a zone first click the  **Insert Internal Wall** button. Click inside the target zone where one end of the wall is to be anchored. Move the cursor and click the mouse button to finish the wall at the other end.

- To inspect or **edit** the properties of a wall within a zone **right click a node** at either end.
- To **move** a node left click the node and drag it to its new position
- The wall can not be dragged out of its zone.
- To delete the wall  click on a node at either end of an intrazone internal wall and press the **Delete a Node or Element** button

The door and wall dimensions are shown in elevation at the same scale as the plan.

If the tops of the walls are truncated, switch to a smaller scale.




Type	Insulation
 Cavity Panel 75mm gap Thickness <input type="text" value="10"/> mm R 0.12	 No Insulation R 0.16

Wall type and insulation


The wall type and insulation databases will be added to as new products become available.

Internal Wall Type



Cavity Panel 75mm gap

Internal Wall Insulation



No Insulation

- The R values displayed in the **Type** panel is for the material of the wall without any airspaces .
- The R value of air spaces and insulation is displayed in the **Insulation** panel.

L 5.0 m A 8.85 m² Orient 90° Rt 0.28 UA 20.02

Length, Area, Orientation, Total wall R value and Total wall transmittance values are displayed.

Thickness **mm**

The **thickness** of the main part of the wall, (in this case the plasterboard), can be changed by entering a value in mm.

Height **mm**

☐ 3000
☐ 2700
☐ 2550
☒ 2400

Height

Wall **height** can be changed by entering a value in the box or selecting the appropriate radio button.

External Floor



The floor to the outside potentially provides a thermal link to the ground as well as useful thermal mass to stabilise air temperatures within the building.

- In warm climates the cooler ground below the floor can serve as a useful heat sink in summer if no carpet or insulation reduces heat flow.
- In cold climates it is useful to insulate the floor to reduce this heat loss from the building.

External Floor of Zone 2 Liv/Kitchen 1

File Info Undo OK Cancel

Type	Insulation	Under Floor Space																					
 Carpet and Underlay Suspended Timber Floor Ru 0.54 Rd 0.54	 Bulk Insulation in Contact with Floor Bulk R Value 1.0 Ru 1.00 Rd 1.00	Height 600 mm <input type="radio"/> 2000 <input type="radio"/> 1500 <input type="radio"/> 1000 <input checked="" type="radio"/> 600 Openness <input type="radio"/> Very Open <input type="radio"/> Open <input checked="" type="radio"/> Enclosed Vent Area mm²/m <input checked="" type="radio"/> 1000 <input type="radio"/> 2000 <input type="radio"/> 3000 <input type="radio"/> 4000 <input type="radio"/> 6000																					
Rtu 1.54 UAu 23.48 Area 40.00 Rtd 1.54 UAd 23.48																							
Zones Sharing the Same Floor Space Combine Separate <table border="0"> <tr> <td>1 Living 1</td> <td><input checked="" type="checkbox"/></td> <td><input checked="" type="checkbox"/> Living</td> </tr> <tr> <td>2 Liv/Kitchen 1</td> <td><input checked="" type="checkbox"/></td> <td><input checked="" type="checkbox"/> Living/Kitchen</td> </tr> <tr> <td>3 Wet Area 1</td> <td><input checked="" type="checkbox"/></td> <td><input checked="" type="checkbox"/> Wet Area</td> </tr> <tr> <td>4 Sleeping 1</td> <td><input checked="" type="checkbox"/></td> <td><input checked="" type="checkbox"/> Sleeping</td> </tr> <tr> <td>5 Corridor 1</td> <td><input checked="" type="checkbox"/></td> <td><input checked="" type="checkbox"/> Corridor</td> </tr> <tr> <td>6 Sleeping 2</td> <td><input checked="" type="checkbox"/></td> <td><input checked="" type="checkbox"/> Sleeping</td> </tr> <tr> <td>7 Garage 1</td> <td><input type="checkbox"/></td> <td><input type="checkbox"/> Garage</td> </tr> </table>			1 Living 1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/> Living	2 Liv/Kitchen 1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/> Living/Kitchen	3 Wet Area 1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/> Wet Area	4 Sleeping 1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/> Sleeping	5 Corridor 1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/> Corridor	6 Sleeping 2	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/> Sleeping	7 Garage 1	<input type="checkbox"/>	<input type="checkbox"/> Garage
1 Living 1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/> Living																					
2 Liv/Kitchen 1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/> Living/Kitchen																					
3 Wet Area 1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/> Wet Area																					
4 Sleeping 1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/> Sleeping																					
5 Corridor 1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/> Corridor																					
6 Sleeping 2	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/> Sleeping																					
7 Garage 1	<input type="checkbox"/>	<input type="checkbox"/> Garage																					

Under floor space

Floor spaces are automatically created when no other zone exists below all or part of the floor of a zone. Zones that share common floor spaces must be grouped together. This includes slab on ground floors.

Zones Sharing the Same Floor Space

Combine Separate

1 Living 1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/> Living
2 Liv/Kitchen 1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/> Living/Kitchen
3 Wet Area 1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/> Wet Area
4 Sleeping 1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/> Sleeping
5 Corridor 1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/> Corridor
6 Sleeping 2	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/> Sleeping
7 Garage 1	<input type="checkbox"/>	<input type="checkbox"/> Garage

Elevated floors require input of the average under-floor **height** to determine the volume required for the ventilation calculation.

Under Floor Space

Height mm

☐ 2000
☐ 1500
☐ 1000
☒ 600

Ventilation

☐ Very Open
☐ Open
☒ Enclosed

Vent Area mm²/m

☒ 1000
☐ 2000
☐ 3000
☐ 4000
☐ 6000

- **Enclosed** indicates that the only ventilation openings are those required for compliance with building codes (see below).
- **Open** indicates that additional openings are provided for ventilation.
- **Very Open** indicates that the sub-floor space is very well ventilated with large openings.

If the **ventilation** type is **Enclosed** then the vent area must be entered as square millimetres per linear metre of the perimeter.

Floor type, floor covering and insulation

External Floor...

Unit Below

Unit Below

Unit Below

Suspended AAC (75mm)

Floor Covering

Bare

External Floor Insulation

Foil, Reflective Down, Antireflective Up, Gap to Floor

- The R value displayed in the **Type** panel is for the floor and covering without any airspaces
- The R value of air spaces and insulation is displayed in the **Insulation** panel.

Rtu 1.54	UAu 23.48	Area 40.00
Rtd 1.54	UAd 23.48	

The thermal resistance, transmittance and area of the floor is also displayed.



Ceiling Between Levels



Internal floors or ceilings between levels do not exchange heat directly with the outside. Uninsulated and uncarpeted floors with high thermal mass can stabilize the extremes in internal air temperature. Light weight timber floors don't offer this potential.

Internal Ceiling of Zone 2 Liv/Kitchen 1

File Info Undo OK Cancel

Type	Insulation
	
Timber Above Plasterboard	No Insulation
Ru 0.26 Rd 0.26	Ru 0.15 Rd 0.19
Rtu 0.41 Rtd 0.45	UAu 49.30 UAd 45.83
Area 28.00	

Ceiling type, floor covering and insulation

Ceiling Type

Diagram showing various ceiling types with their respective thermal properties (R values) displayed below them.

Internal Ceiling Insulation

Diagram showing various insulation types with their respective thermal properties (R values) displayed below them.

- The **floor cover** properties are those of the floor above.
- The R value displayed in the **Type** panel is for the ceiling without any airspaces or floor covering.
- The R value of air spaces and insulation is displayed in the **Insulation** panel.


Rtu 0.41	UAu 14.52	Area 8.25
Rtd 0.45	UAd 13.50	

The thermal resistance, transmittance and area of the internal ceiling is also displayed.


Internal Floor Covering



Floor coverings reduce heat flow into and through floors. Internal floor coverings reduce the ability of mass floors to stabilise internal temperature fluctuations.



The internal floor gets its general properties from the [ceiling below](#), but the floor coverings are selected from this screen.



Ceiling to Roof



Heat flow between the building and the outside air through the ceiling, roof space and roof is potentially larger than through any other building elements other than windows and skylights. Insulating the ceiling has an enormous potential to reduce this heat flow.

Ceiling for Zone 1 Living 1

OK Cancel

Type	Insulation	Slope 0 Deg
 Plasterboard	 Bulk Insulation	
Ru 0.06 Rd 0.06	Bulk R Value 2.5 Ru 2.50 Rd 2.50	Rtu 2.56 Rtd 2.56 UAu 9.75 UAd 9.75 Area 26.50

Zones Sharing the same Roof Space

Combine Separate

1 Living 1	<input type="checkbox"/> Living
2 Liv/Kitchen 1	<input checked="" type="checkbox"/> Living/Kitchen
3 Wet Area 1	<input checked="" type="checkbox"/> Wet Area
4 Sleeping 1	<input checked="" type="checkbox"/> Sleeping
5 Corridor 1	<input checked="" type="checkbox"/> Corridor
6 Sleeping 2	<input checked="" type="checkbox"/> Sleeping
7 Garage 1	<input type="checkbox"/> Garage

Above the Ceiling

☐ Unvented Cavity
☐ Ventilated Cavity
☒ Highly Vented Cav
☐ Roof, no Cavity
☐ Another Apartment

Ceiling type and insulation

Ceiling Type

Plasterboard

Ceiling Insulation


Bulk Insulation

Air Cell

- The R value displayed in the **Type** panel is for the ceiling without any airspaces.
- The R value of air spaces and insulation is displayed in the **Insulation** panel.

Rtu 2.56
 Rtd 2.56
 UAu 9.75
 UAd 9.75
 Area 26.50

The thermal resistance, transmittance and area of the ceiling is also displayed.




Slope


The ceiling slope can be determined by dragging the node or entering the value of the slope angle as degrees in the slope field. Horizontal skylights have zero slope.

Roof space

- Roof spaces are automatically created when no other zone exists above all or part of the ceiling of a zone.
- Zones that share common roof spaces must be grouped together.



The description of the space above the roof automatically changes the description of this space in the [Roof](#) popup window.



- **Unvented** indicates that no specific ventilation openings are provided.
- **Ventilated** indicates that purpose-built ventilation openings are provided.
- **Highly Ventilated** indicates that the roof space is very well ventilated with large openings.
- The **no cavity** option replaces the roof cavity with a still air gap.
- If **another apartment** exists above this dwelling the roof and roof space information is ignored.

Roof





Roof spaces are automatically created when no other zone exists above the ceiling of a zone. Zones that share common roof spaces can be selected in the [Ceiling](#) screen.

Roof for Zone 2 Liv/Kitchen 1


OK Cancel

Type	Insulation	Slope 22 Deg
<p>Corrugated Iron</p> <p>Ru 0.00 Rd 0.00</p>	<p>Foil, Reflective Side Down, Anti-glare Up</p> <p>Ru 0.23 Rd 0.28</p>	
Roof Shape <ul style="list-style-type: none"> <input checked="" type="radio"/> Hip <input type="radio"/> Hip and Gable <input type="radio"/> Gable both ends <input type="radio"/> Skillion 	Roofspace Ventilation <ul style="list-style-type: none"> <input type="radio"/> Unvented Cavity <input type="radio"/> Ventilated Cavity <input checked="" type="radio"/> Highly ventilated Cavity <input type="radio"/> Unvented, no Cavity <input type="radio"/> Neighbour, no Roof 	Colour <p>Dark Medium Light</p> <p>Absorptance 0.50</p>
<p>Rtu 0.23 Rtd 0.28</p>		

Roof type and insulation




Slope




The roof slope can be determined by dragging the node or entering the value of the slope angle as degrees in the slope field. This determines the area of the roof and the volume of the roof space.

Shape

The roof shape determines the area of the roof and the volume of the roof space.




Hip Roof




Hip roofs minimize roof area and roof space volume.

Gable Roof




The triangular ends are assumed to have similar thermal properties to the roof.

Hip/Gable Roof




The triangular end is assumed to have similar thermal properties to the roof.

Skillion Roof



The triangular ends and the rectangle above the ceiling line are assumed to have similar thermal properties to the roof.


Roof space ventilation



- **Unvented** indicates that no specific ventilation openings are provided.
- **Ventilated** indicates that purpose-built ventilation openings are provided.
- **Highly Ventilated** indicates that the roof space is very well ventilated with large openings.
- The **no cavity** option replaces the roof cavity with a still air gap.
- If **another apartment** exists above this dwelling the roof and roof space information is ignored.

Colour

Colour determines how much of the incident solar radiation is absorbed.



Dark, medium and light are often as close as the designer gets to knowing external colours. If the colours are known, clicking on the colour panel will open up a large choice of colours.

The colour is converted to **absorptance**, the fraction of incident sunlight absorbed and turned into heat.

Skylights and Clerestory Windows



Skylights contribute to the amount of solar radiation entering the building. They also allow heat flow in and out of the building by virtue of their relatively high conductance.

To **Add a skylight** or clerestory window **left click** on the skylight button and then **left click** in the zone that is to have the skylight. If the zone already contains a skylight then addition skylights can be added when editing.

To **edit the properties** of a Skylight or Clerestory Window (high set vertical windows) **right click** in the zone containing the skylight.



To model a **true Skylight** and not a Clerestory Window box is unchecked.

Skylight 1 for Zone 6

☐ Clerestory Window

Type
Single glazed clear, tubular

Frame
Timber and aluminium

GEN-04-010a
R_{glass} 0.21
R_{frame} 0.17
R_t 0.20
UA 7.14

Slope 45 Deg

Skylight Shaft
Length mm 50
Reflectance 50 %
Insulation R value 1.0
☐ Diffuser

Height 1200 mm
600 900 1200 1500 1800 2100 2400 2700



Width 1200 mm
600 900 1200 1500 1800 2100 2400 2700

Skylight Number 1
+ X

Orientation
352° 37° 82°
307° 127°
262° 217° 172°


Total Area 1.44 m²

Glazing and Frame




GEN-04-010a	
R _{glass}	0.21
R _{frame}	0.17
R _t	0.20
UA	7.14

The thermal properties are displayed as different combinations of glass and frame are selected.




Slope

The slope can be determined by dragging the node or entering the value of the slope angle as degrees in the slope field. Horizontal skylights have zero slope.





Orientation


One of 8 orientations is selected by clicking on the appropriate button. The position of the button is given relative to the drawing. The drawing shows the UP direction of the screen as 37° East of North. The actual orientation is displayed on the button.




Skylight Shaft

Enter the length and reflectance of the shaft. If insulated enter the R value. If a diffuser exists at the bottom of the skylight shaft check the box.

Skylight characteristics can be copied  and pasted .



Clerestory Windows



These are high set vertical windows.

The Clerestory Window option allows windows to be modelled in internal walls which become external walls towards the top, or where no wall exists below the window.

The extra bit of [wall containing the glazing](#) is also modelled.

Skylight 1 for Zone 6

Generic Custom ☒ Clerestory Window

Product
GGG-05-005a

Brand
Generics

Frame
Generic: Aluminium

Glass
5mm Panasap Dark Grey

Style
Louvres
Opening 90%

Furnishing
Drapes and Pelmet
Rfurn 0.33

Head Ht 3500 mm
Eaves 1200 mm
Offset 200 mm
Net Ext Wall Area 35.63 m²

Height 1200 mm
Width 1200 mm

Skylight Number 1
Total Area 1.44 m²

Orientation
352° 37° 82°
307° 127°
262° 217° 172°

1.44 m²

GGG-05-005a

Rglass 0.17
Rframe 0.14
Rt 0.49
UA 2.91
SHGC 0.55

Skylight 1 for Zone 6

Generic Custom ☒ Clerestory Window

Glass
Single Glazed, Tinted

Frame
Aluminium

GGG-05-005a

Rglass 0.17
Rframe 0.14
Rt 0.49
UA 2.91
SHGC 0.55

There are some limitation to the properties assigned to clerestory windows compared to normal windows. The **eave** information is not derived from the eaves plan so it must be entered by the user. External **shading devices** can not be modelled.

The **net wall area** is the total area of this external wall minus the clerestory window area. Wall properties are considered to be the same as the **default wall properties**.

See the **window** section for an explanation of the other properties. The **Custom** Window selection is the same as for normal windows.

Stair Well



Stair wells provide ventilation between different levels of the building.

Stairs can only be added if there is a zone below where the target zone is clicked.

The **available area** is the common area between the 2 zones minus any area already containing a stairwell.

Modelling zones extending over two levels

- Draw the **zone** on the first floor.
- Draw another **free running zone** of the same floor area directly **above** the zone.
- Model a **stair well** in the top level having the same area as the floor between the levels.

Air Flow



This screen allows some changes to be made to the air flow characteristics of each zone.

Natural Ventilation

The location and dimensions of doors, windows and other ventilation devices determines the air flow through the building.

The [Window Style](#) determines the maximum opening possible for ventilation.
Insect screens reduce the air flow.

Infiltration

This is the uncontrolled ventilation.

Draught seals should be provided to all windows and external doors of the zone.

The air speed is calculated on an hourly basis by the engine.

Air Flow for Z1 Living 1

Information icon, OK, Cancel

Natural ventilation

Insect screens ☒

Infiltration

Draught seals to all doors and windows ☒

Unsealed chimney ☐

Vent for unflued gas heater ☐

Wall or ceiling vents 0

Unsealed exhaust fans 0

Vented downlights 1

Forced air movement

Number of ceiling fans 4

Diameter mm: 900, 1200, 1400

Swept Fan Area
13 % of floor area 34.5m²

Forced Air Movement Using Ceiling Fans

Fans move air which doesn't change ambient temperature but increases comfort in hot conditions by producing lower skin temperatures by increasing the evaporation of sweat.

The [maximum cooling benefit](#) of these fans is as follows:

- 900 mm: 0.50 m/s. Cooling benefit = 1.6 degrees
- 1200 mm: 0.66 m/s. Cooling benefit = 2.4 degrees
- 1400 mm: 0.77 m/s. Cooling benefit = 2.8 degrees

This cooling benefit may be [reduced](#) according to the floor area and number of fans

"Rules of thumb" :

Bedrooms	1 x 1200 mm fan in each
Other Zones	
7.5 - 10m ²	1 x 900 mm fan
10 - 30m ²	1 x 1200 mm fan
30 - 60m ²	2 x 1200 mm fan
60 - 90m ²	3 x 1200 mm fan

Mechanical Ventilation

This is the movement of air through the room with a blower or extractor.

When implemented, the Air Changes per Hour must be calculated from the manufacturer's data sheets.

Editing a zone

Clicking in a zone with the [Right Hand mouse button](#) will allow information about the zone to be displayed and edited.

Only the relevant element buttons are displayed. The Roof button may not be needed for lower floors, and the Skylight and Stair Well buttons are not displayed if none have been modelled.




A down stairs room has been selected. Part of the ceiling has a roof above and the other part has room above.



An upstairs room has been selected.

When a [New Zone](#) is first drawn it is automatically given a new name based on its type. This name can be edited then or at this stage.



Calling this as sleeping zone automatically assumes the default condition that heating and cooling will be assessed. This can be changed here or at the [Simulation Mode](#) screen.



[Air Flow](#)



[External Floor](#)



[Ceiling Between Levels](#)



[Floor Covering Between Levels](#)



[Ceiling to the Roof Space](#)



[Roof](#)



[Skylight](#)



[Stair Well](#)

Overshadowing by Obstacles





Obstructions to sunlight, such as neighbouring buildings, trees or mountains can have their shading impact modelled.



Up to 3 obstructions in each of 4 directions can be selected.


Below is the data entry screen for obstruction to the **North** and another for obstructions to the **East**.



The dimensions L1 and L2 are measured from the axis on the screen.

D is measured from the other axis.

In many cases the dimensions will be negative.



A monthly shading schedule can be applied to any obstacle such as a deciduous tree or vertical shade cloth.



This will **reset all the dimensions** of the selected obstruction including the shading schedule.



Copy dimensions and shading schedule.



Paste previously copied dimensions and shading schedule.

Simulation Mode



Mathematical Basis of BERS

The mathematical thermal simulation program at the heart of the BERS program is the ACCURATE engine. This much enhanced version of the engine used in all previous versions of BERS was developed with AGO funding by the CSIRO.



The climate data is in the form of hourly values of temperature, humidity, solar irradiation (beam and diffuse), wind speed and direction, and cloud cover. The majority of this data has been collected by the Australian Bureau of Meteorology. It has been converted into a useable format under contract to the AGO.



Bureau of Meteorology

Each Australian Post Code has been assigned the data set that most closely approximates its climate.

Thermal simulation can be undertaken in one of two modes, conditioned or free running. In Rating Mode the heating and cooling calculation modes should not be changed from the defaults assigned by the program.

Conditioned

Conditioned


In a "conditioned" zone, heating and cooling is available to maintain comfort. In rating mode all zones of type Living, Living/Kitchen and Sleeping are heated and cooled to maintain comfort while zones of type Garage, Wet Area and Corridor are not. Ticking the Heat and/or Cool check boxes changes the type of simulation.

Simulation Mode					
		<input type="radio"/> Conditioned <input type="radio"/> Free Running		<input checked="" type="checkbox"/> OK	
Zone	Name	Heat	Cool	Type	
1	Living 1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Living	
2	Living/Kitchen 1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Living/Kitchen	
3	Sleeping 1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Sleeping	
4	Wet Area 1	<input type="checkbox"/>	<input type="checkbox"/>	Wet Area	
5	Corridor 1	<input type="checkbox"/>	<input type="checkbox"/>	Corridor	
6	Sleeping 4	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Sleeping	
7	Living 2	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Living	
8	Sleeping 2	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Sleeping	
9	Living 3	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Living	
10	Garage 1	<input type="checkbox"/>	<input type="checkbox"/>	Garage	

Free Running

Free running

Zones which are not ticked are "free running" where the zone just reaches a temperature which is in dynamic equilibrium with its environment. No heating or cooling is available to maintain comfort in these zone.



In zones of type Living, Living/Kitchen, heating and cooling are available when needed from 7 am to 12 pm.

In zones of type Sleeping, heating and cooling are available from 4 pm to 9 am.

Although heating and cooling are available between these times, they are not invoked unless required, as described below.

Heating

Heating is applied if the zone temperature at the end of the hour without heating is below the heating thermostat setting. Enough heat is supplied so that the zone temperature at the end of the hour is equal to the thermostat setting.

Cooling

Cooling is invoked in a more complicated way.

1. If at the end of the hour the zone condition (i.e. temperature and moisture content) without cooling or ventilation is within the comfort region on the psychrometric chart, cooling is not invoked. The comfort region is a parallelepiped, the boundaries of which are:

Top: Absolute moisture content = 12 g/kg

Bottom: Absolute moisture content = 0 g/kg (normally it is 4 g/kg but AccuRate will not invoke cooling merely because the air is too dry)

Right: ET* line based on (Cooling Thermostat + 2.5) degrees

Left: Not relevant

2. If at the end of the hour the zone condition without cooling or ventilation is outside the comfort region, ventilation is switched on (i.e. windows and other openings in this zone are opened) if the zone temperature is above the outdoor air temperature. The new zone temperature is calculated and an indoor air speed is estimated. If the indoor air speed is above 0.2 m/s, the comfort region described above is extended in two ways: the top boundary becomes the 90%RH line, and the right boundary becomes an ET* line based on (Cooling Thermostat + 2.5 + dT), where

$$dT = 6*(v - 0.2) - 1.6*(v - 0.2)^2,$$

where v is the indoor air speed (m/s).

3. If the zone condition is still outside the extended comfort region, the zone openings are closed and sufficient cooling is applied so that the zone temperature at the end of the hour is the cooling thermostat setting.

Note that the cooling calculations include a model of a residential air conditioner cooling coil, so that dehumidification occurs when cooling is invoked. The dehumidification energy is reported as the latent cooling energy

Climate file comfort settings


The lower value for the heating of sleeping zones (15°C) applies between midnight and 7.00 am and the higher (18°C) between 8.00 am and 4.00 pm.

Climate Number	Name	State	Heating °C Sleeping	Heating °C Living	Cooling °C
1	Darwin	NT	15 or18	20	26.5
2	Pt Hedland	WA	15 or18	20	27.0
3	Longreach	QLD	15 or18	20	27.0
4	Carnarvon	WA	15 or18	20	26.0
5	Townsville	QLD	15 or18	20	26.5
6	Alice Springs	NT	15 or18	20	26.5
7	Rockhampton	QLD	15 or18	20	26.0
8	Moree	NSW	15 or18	20	26.0
9	Amberley	QLD	15 or18	20	26.0
10	Brisbane	QLD	15 or18	20	25.5
11	Coffs Harbour	NSW	15 or18	20	25.0
12	Geraldton	WA	15 or18	20	25.0
13	Perth	WA	15 or18	20	25.0
14	Armidale	NSW	15 or18	20	24.0
15	Williamtown	NSW	15 or18	20	25.0
16	Adelaide	SA	15 or18	20	25.0
17	Sydney	NSW	15 or18	20	25.5
18	Nowra	NSW	15 or18	20	24.5
19	Charleville	QLD	15 or18	20	27.0
20	Wagga	NSW	15 or18	20	25.0
21	Melbourne	VIC	15 or18	20	24.0
22	East Sale	VIC	15 or18	20	23.0
23	Launceston	TAS	15 or18	20	22.5
24	Canberra	ACT	15 or18	20	24.0
25	Cabramurra	NSW	15 or18	20	23.0
26	Hobart	TAS	15 or18	20	23.0
27	Mildura	VIC	15 or18	20	25.0
28	Richmond	NSW	15 or18	20	24.5
29	Weipa	QLD	15 or18	20	26.0
30	Wyndham	WA	15 or18	20	27.5
31	Willis Is	QLD	15 or18	20	26.5
32	Cairns	QLD	15 or18	20	26.5
33	Broome	WA	15 or18	20	27.0
34	Learmouth	WA	15 or18	20	26.5
35	Mackay	QLD	15 or18	20	26.0
36	Gladstone	QLD	15 or18	20	26.0
37	Halls Creek	WA	15 or18	20	27.0
38	Tennant Creek	NT	15 or18	20	27.0
39	Mt Isa	QLD	15 or18	20	27.0
40	Newman	WA	15 or18	20	28.0
41	Giles	WA	15 or18	20	27.5
42	Meekatharra	WA	15 or18	20	28.0
43	Oodnadatta	SA	15 or18	20	27.0
44	Kalgoorlie	WA	15 or18	20	26.0
45	Woomera	SA	15 or18	20	26.0
46	Cobar	NSW	15 or18	20	26.5
47	Bickley	WA	15 or18	20	24.5
48	Dubbo	NSW	15 or18	20	25.0
49	Katanning	WA	15 or18	20	24.5
50	Oakey	QLD	15 or18	20	25.0
51	Forrest	WA	15 or18	20	25.5
52	Swanbourne	WA	15 or18	20	25.0
53	Ceduna	SA	15 or18	20	24.5
54	Mandurah	WA	15 or18	20	25.0
55	Esperance	WA	15 or18	20	24.0
56	Mascot	NSW	15 or18	20	24.5
57	Manjimup	WA	15 or18	20	23.5
58	Albany	WA	15 or18	20	23.5
59	Mt Lofty	SA	15 or18	20	23.0
60	Tullamarine	VIC	15 or18	20	24.0
61	Mt Gambier	SA	15 or18	20	23.5
62	Moorabbin	VIC	15 or18	20	24.0
63	Warrnambool	VIC	15 or18	20	23.0
64	Cape Otway	VIC	15 or18	20	23.0
65	Orange	NSW	15 or18	20	23.0
66	Ballarat	VIC	15 or18	20	23.5
67	Low Head	TAS	15 or18	20	23.0
68	Launceston	TAS	15 or18	20	23.5
69	Thredbo	NSW	15 or18	20	23.5

Detailed Description of Building Elements



This screen can be used to check what has been modelled in the building. Most building elements are described in detail.



Refresh the screen if changes have been made.




This report can be [printed](#).

SCRATCH File



This is the file that the BERS front end writes to the simulation engine.
It will not mean anything to most users and is only used for diagnostic purposes.



The column and row give the location of the cursor.

Simulate



This runs the thermal simulation engine. The speed depends on the computer and the complexity of the building design.

```

*****
*                                     *
*      AccuRate Engine Version 2.11   *
*      CALCULATIONS IN PROGRESS.  PLEASE WAIT  *
*                                     *
*      Developed with funding support from the  *
*      Australian, State and Territory Governments, *
*      through the Energy Efficiency Working Group *
*      of the Ministerial Council on Energy      *
*                                     *
*****
CALCULATIONS COMPLETED FOR JAN
CALCULATIONS COMPLETED FOR FEB
CALCULATIONS COMPLETED FOR MAR
CALCULATIONS COMPLETED FOR APR
CALCULATIONS COMPLETED FOR MAY
CALCULATIONS COMPLETED FOR JUN
CALCULATIONS COMPLETED FOR JUL
CALCULATIONS COMPLETED FOR AUG
CALCULATIONS COMPLETED FOR SEP_

```

The results are displayed in the [Analysis](#) window.

Star Panel

This panel contains the Simulate and Analysis buttons as well displaying results from previous simulations.



Open the [Analysis](#) window.



The [history](#) of the last 10 simulations can be examined.
The last simulation is 1, second last is 2 etc.



The [project name](#) and [climate file name](#) corresponding to the simulation results are displayed when the history focus is changed.



The simulation results are displayed as [stars](#). Up to 10 stars may be displayed in half star increments.



A [lemon](#) means zero stars.



Results are also displayed in [MJ/m²](#).



The record of the last 10 simulations can be [erased](#).


Analysis



Simulated projects can have the energy performance of the whole building or of each zone within the building analysed.



The [house](#) button gives information about the whole building.



The [history](#) of the last 10 simulations can be examined. The last simulation is 1, second last is 2 etc.



The [project name](#) and [climate file name](#) corresponding to the simulation results are displayed when the history focus is changed.



The simulation results are displayed as [stars](#). Up to 10 stars may be displayed in half star increments.



A [lemon](#) means zero stars.

C20.3 H 62.8 T 83.1


Results are also displayed in [MJ/m²](#).



The record of the last 10 simulations can be [erased](#).



The [zone](#) button gives information about each zone in the building.



The [up/down](#) buttons allow different zones to be selected.



The Analysis form can be [printed](#).




Hourly temperatures can be [Displayed](#).

Temperature Display




Hourly temperatures of any zone can be displayed. This temperature profile can be compared with

- temperature profiles from other zones of the building
- temperature profiles of similar zones from other projects
- hourly temperatures from climate files can also be displayed.




The climate files contain hourly climatic data.


The temperature data from any of these files can be displayed by pressing and select from the files.




The display of this file can be toggled on or off by clicking in the check box next to the file name.

Select the zone to be displayed.

To compare temperature profiles of different zones  open the temperature output files in the Temperature subdirectory. Up to 4 projects can be compared at any one time.



As each zone is selected the temperature profile will be displayed in a unique colour.




Any curve can be temporarily hidden or displayed using the check box.




will delete the curve completely. To display it again the zone must be reselected.

Time period to be displayed.




The starting date and the number of days to be displayed can be selected.



Extreme periods can be automatically selected from the drop down list.

Changing scale

The scale of the graph can be changed with the up/down scroll arrows. Dragging with the Right Hand mouse button can be used to change the position of the graph.



Temperature Bins



The hourly zone temperatures can be displayed in bins of one degree increment that give the frequency of a particular temperature occurring in a zone.

These temperature bins range from <10 to >36°C. The window can be scrolled horizontally to display the complete data set.

The zones that have been selected for each project can have their temperature distribution compared.

Temperature Distribution																	
		Number of Hours per Year that the Zone Spends at Each Temperature															
Temperature Bin		<10	10	11	12	13	14	15	16	17	18	19	20	21	22	23	
P1 Bedroom 1		224	283	429	524	623	596	639	609	562	589	509	551	500	407	357	
P2 Bedroom 1		6	22	111	325	562	720	704	687	693	691	660	678	818	470	407	
P3 Bedroom 1		0	0	0	28	315	877	930	865	560	537	590	685	1048	682	539	



C:\BERS41\Temperature
tempsR25IntMass.txt

Alternatively any temperature data output file can be opened and have the temperatures binned. The name of the file that has been selected will be displayed.

Temperature Distribution																	
		Number of Hours per Year that the Zone Spends at Each Temperature															
Temperature Bin		<10	10	11	12	13	14	15	16	17	18	19	20	21	22	23	
Outdoor		1161	569	752	832	698	764	641	519	493	471	364	315	233	159	137	
Rumpus/Family/K		0	0	0	12	131	396	594	683	717	765	743	923	1209	792	698	
Bedroom 1		0	0	0	28	315	877	930	865	560	537	590	685	1048	682	539	
Bedroom 2		0	0	0	33	572	1165	1060	792	403	628	553	759	957	877	467	
Bedroom 3		0	0	0	41	475	1134	1042	852	466	598	621	724	965	790	447	
Bathroom/WC		0	0	0	10	485	1280	1164	753	454	683	631	801	931	817	438	
Laundry		0	0	0	0	47	837	1109	1262	537	539	707	874	940	972	495	
Garage		107	191	418	589	725	659	704	664	601	514	495	511	425	358	338	
Roof Space		1274	484	533	549	526	498	479	449	452	402	340	271	266	202	180	
Dining/Lounge		0	5	47	243	595	933	886	750	613	574	601	694	880	656	486	
Study		0	0	30	258	773	914	871	617	537	581	603	731	1001	586	450	
Entry		0	0	0	0	199	1363	821	1067	443	558	591	847	912	1170	502	
GroundZone		0	0	0	0	0	420	1466	1299	845	550	1136	775	1069	1153	47	
Underside of Ro		1536	493	526	504	452	456	435	383	396	315	290	277	258	213	186	
Top of Ceilings		1218	469	533	531	518	504	466	448	431	403	351	297	270	204	188	




The data can be printed. Landscape mode should be selected.


Temperature Histograms



Temperature data can be displayed as a series of histograms. The height of each bar is proportional to the number of hours the zone spends at the temperature given at its base.



The zone of interest can be selected from a drop down list.



The scale of the graph can be changed by using the scale arrows.



The graph can be printed.

Short Simulation Report



The simulation results are displayed together with details of the location of the dwelling, the client and the assessor.

Short Simulation Report											
<div style="display: flex; justify-content: space-between; align-items: center;"> <div> <p>Building Energy Rating Scheme</p> <table border="1" style="margin: 0 auto;"> <tr> <td>Project</td> <td>Bribie</td> <td>Run 2</td> </tr> <tr> <td>Location</td> <td>THE GAP</td> <td>PC 4825</td> </tr> <tr> <td>Climate</td> <td>climat39.TXT</td> <td>29/03/2005</td> </tr> </table> </div> </div> <div style="display: flex; justify-content: space-around; align-items: center; margin-top: 10px;"> <div> <p>BERS V4.1 H. Willrath Copyright 2004</p> </div> <div style="text-align: center;"> <p>★★★★★</p> <p>Cooling Heating Total</p> <p>43.1 40.3 83.4</p> </div> <div> <p>Solar Logic www.solarlogic.com.au</p> </div> </div>			Project	Bribie	Run 2	Location	THE GAP	PC 4825	Climate	climat39.TXT	29/03/2005
Project	Bribie	Run 2									
Location	THE GAP	PC 4825									
Climate	climat39.TXT	29/03/2005									
Dwelling Details											
D P Number	DP TREWQ-14384-78	Unit Number or Name									
Lot Number	<input type="text"/> OR House Number	<input type="text"/>									
Street Name	Broad Ave										
Development Name	<input type="text"/>										
Suburb or Town	Lakesford										
State	NSW	Post Code: 2063									
Client Details											
Name	BrickBilt Builders										
Phone	07 2598 6354	Fax: 07 2598 6354 Email: bbb@powerup.com									
Postal Address	P O Box 4563 Cool Bay QLD 4092										
Street Address	17 Ash St Britstone Lane Cool Bay QLD 4092										
Assessor Details											
Name	Bill Winter										
Phone	041 365289	Fax: 07 6542 3698 Email: bilwinter@woodchuck.com									
Postal Address	<input type="text"/>										
Street Address	367 Main Drive Calkoogla Qld 2453										
Assessor Number	BA 2569										
This an accurate assessment of the building.											
Signed by the assessor		Date / /									

Project	Bribie	Run 2
Location	THE GAP	PC 4825
Climate	climat39.TXT	29/03/2005

★★★★★		
Cooling	Heating	Total
43.1	40.3	83.4

Project Details are summarised together with the heating and cooling energy load.



This report can be [printed](#).

Common Buttons



Information and help. Gets you to the BERS help file.



New. Start anew. Will destroy current information.



Open a file which will overwrite current information.



Save the information in a file.



colour of the zone or zones containing the element.



Reset parameters to what they were before changes were made.



Change all elements of that type to the current default.



Copy parameters.



Paste previously copied information.



Delete whatever the focus is on.



Print screen or file.



Refresh the screen.



OK

Accept all changes and close the window.



Cancel

Close the window without making any changes.

Thermal and Optical Definitions

R value

This is the resistance to heat flow between two surfaces at different temperatures.
Units are m^2K/W .

Bulk materials have R values proportional to their thickness,

$$R=d/k$$

where k is *conductivity*
d is thickness

The R value for air gaps varies in a non linear way with distance.

U value or Thermal Transmittance


This is calculated as the reciprocal of the total resistance.

Transmittance has the same units as *conductance* but conductance is calculated surface to surface while transmittance is calculated from internal air film to external air film.

SHGC

The Solar Heat Gain Coefficient is the fraction of solar energy incident on a window that is ultimately converted to heat entering into the room.

Solar radiation passing through the glass is absorbed by the room and converted to heat.
Some of the radiation absorbed by the glass is transferred as heat into the room.



Material capacitance and resistance properties.

The following thermal capacitance and resistance values are used by the CSIRO thermal simulation engine.

- Resistances and capacitances listed are for a material thickness of 1.0 m.
- The actual resistance and capacitance of the material used in a construction is the product of its thickness and the value in the table.

Index	Name	Capacitance	Resistance
1	Aerated autoclaved concrete block	525.0	7.70
72	Air-Cell Retrosshield or Glareshield - not including air gaps	0.1	0.14
2	Aluminium	2358.4	0.01
3	Bituminous roof membrane	1646.4	6.25
4	Brickwork: generic extruded clay brick (typical density)	1453.6	1.64
5	Brickwork: generic pressed clay brick (typical density)	1929.2	1.11
71	BST lightweight concrete	1128.0	3.33
6	Carpet	147.7	17.60
7	Carpet underlay (felt)	147.7	25.00
8	Carpet underlay (rubber)	470.9	12.50
9	Carpet 10 + felt underlay 10	147.7	21.30
10	Carpet 10 + rubber underlay 8	279.2	15.33
11	Ceramic tile	1600.0	0.88
12	Concrete block 190 denseweight (not core-filled)	972.4	0.97
13	Concrete block 190 denseweight (core-filled at 1500 centres)	1177.4	0.97
52	Concrete block 190 lightweight (not core-filled)	802.6	1.22
53	Concrete block 190 lightweight (core-filled at 1500 centres)	1008.5	1.22
14	Concrete block 140 denseweight (not core-filled)	1001.4	1.14
15	Concrete block 140 denseweight (core-filled at 1500 centres)	1200.3	1.14
54	Concrete block 140 lightweight (not core-filled)	827.2	1.44
55	Concrete block 140 lightweight (core-filled at 1500 centres)	1026.1	1.44
56	Concrete block 110 denseweight (not core-filled)	1140.5	1.28
57	Concrete block 110 lightweight (not core-filled)	941.6	1.69
16	Concrete block 90 denseweight (not core-filled)	1237.3	1.36
58	Concrete block 90 lightweight (not core-filled)	1060.4	1.87
17	Concrete block 90 denseweight (core-filled)	2112.0	0.69
18	Concrete: standard (2400 kg/m ³)	2112.0	0.69
66	Conpolcrete	329.0	12.80
19	Copper	3516.0	0.00
20	Cork tile	900.0	12.50
21	Felt (undercarpet)	165.6	21.70
63	Fibre-cement sheet	1251.6	3.13
22	Fibre-cement sheet (compressed)	1680.0	2.00
23	Generic resistance (k = 0.1)	8.8	10.00
24	Generic resistance (k = 0.3)	8.8	3.33
25	Glass	2108.4	0.95
26	Granite	2385.0	0.35
59	Hollowcore precast concrete panel 200	1478.4	0.85
60	Hollowcore precast concrete panel 150	1478.4	0.89
27	Lead	1436.4	0.03
28	Linoleum	1092.0	4.55
29	Marble	2393.6	0.67
30	Masonite	1716.9	4.55
31	Mud brick	1500.0	1.30
32	Particleboard	832.0	8.30
33	Plaster (cement:sand 1:4)	1590.0	0.91
34	Plasterboard	924.0	5.90

35	Plywood (softwood)	795.0	7.14
36	Polycarbonate	1380.0	4.40
37	Rammed earth	1940.0	0.80
69	Reflective blind	0.0	0.00
38	Roof tiles (clay)	1770.2	1.19
39	Roof tiles (concrete)	2112.0	0.69
40	Sand (building)	1200.0	3.33
41	Sandstone	1840.0	0.77
42	Slate	1987.5	0.67
43	Softboard	400.0	16.70
44	Soil (average)	1613.0	0.83
45	Steel	3900.0	0.02
46	Straw board	336.0	12.35
47	Straw bale rendered	125.0	10.10
70	Styrocon	500.0	4.27
64	Timbercrete (solid)	1171.0	3.21
65	Timbercrete (hollow)	834.0	3.21
61	Timber (softwood)	1057.5	10.00
62	Timber (hardwood)	1414.9	6.25
48	Timber (Jarrah)	1801.6	5.00
49	Timber (Mountain ash)	1414.9	6.25
50	Timber (Radiata pine)	1057.5	10.00
51	Vinyl (floor tiles)	1722.0	1.27
67	Water	4192.0	1.67
68	Window film	0.0	0.00
201	Cellulose fibre: loose fill (k = 0.04)	50.2	25.00
209	Glass fibre batt (k = 0.057 density = 7 kg/m3)	6.2	17.54
210	Glass fibre batt (k = 0.044 density = 12 kg/m3)	10.6	22.73
218	Polyethylene foam (k = 0.04)	10.8	25.00
219	Polyester or polyester/wool blanket (k = 0.063 density = 8 kg/m3)	8.0	15.87
220	Polyester or polyester/wool blanket (k = 0.045 density = 16 kg/m3)	16.0	22.22
228	Polystyrene expanded (k = 0.039)	5.4	25.64
236	Polystyrene extruded (k = 0.028)	10.9	35.71
244	Polyurethane rigid foamed aged (k = 0.028)	10.8	35.71
252	Rockwool loose fill (k = 0.04)	58.9	25.00
253	Rockwool batt (k = 0.033)	29.4	30.30
261	Wool loose fill (k = 0.08)	14.4	12.50
262	Wool/polyester batt 80/20 (k = 0.059 density = 8 kg/m3)	9.6	16.95
263	Wool/polyester batt 80/20 (k = 0.045 density = 16 kg/m3)	19.2	22.22

Problems and Improvements

If the software does not appear to be operating as expected, please contact your distributor or Solar Logic.

Solar Logic is committed to the continual improvement of this product. If you have any suggestions of changes or additions you would like see, please contact:

Solar Logic
162 Blackwood St.
Mitchelton
Queensland 4053
Tel 07 3355 2608
email info@solarlogic.com.au
web solarlogic.com.au

Intellectual property

This manual and the BERS software is the intellectual property of Dr Holger Willrath of Solar Logic, Queensland Copyright 2007. This manual may not be copied without the written permission from the copyright holder.

Licence and Legal Information

The CSIRO owns the copyright to the thermal simulation engine used in BERS Pro.

The BERS Software is owned by Solar Logic. Solar Logic grants to the user a nonexclusive licence to use this BERS Software solely for the rating of dwellings and only for the period during which the licence is valid. The user may not commercially distribute, sublicense, resell, or otherwise transfer for any consideration, or reproduce for any such purposes, the BERS software or User's Manual, or any other printed or digital material, or any modification or derivation thereof, either alone or in conjunction with any other product or program.

THIS BERS SOFTWARE IS PROVIDED TO THE USER "AS IS." SOLAR LOGIC MAKES NO WARRANTIES, EITHER EXPRESS OR IMPLIED, WITH RESPECT TO THIS BERS SOFTWARE AND/OR ASSOCIATED MATERIALS PROVIDED TO THE USER, INCLUDING BUT NOT LIMITED TO ANY WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR AGAINST INFRINGEMENT OTHER THAN TO REPLACE ANY DEFECTIVE DISKS. SOLAR LOGIC DOES NOT WARRANT THAT THE FUNCTIONS CONTAINED IN THE SOFTWARE WILL MEET YOUR REQUIREMENTS, OR THAT THE OPERATION OF THE SOFTWARE WILL BE UNINTERRUPTED OR ERROR-FREE, OR THAT DEFECTS IN THE SOFTWARE WILL BE CORRECTED. FURTHERMORE, SOLAR LOGIC DOES NOT WARRANT OR MAKE ANY REPRESENTATIONS REGARDING THE USE OR THE RESULTS OF THE USE OF THE SOFTWARE OR ANY DOCUMENTATION PROVIDED HERewith IN TERMS OF THEIR CORRECTNESS, ACCURACY, RELIABILITY, OR OTHERWISE. NO ORAL OR WRITTEN INFORMATION OR ADVICE GIVEN BY SOLAR LOGIC OR A SOLAR LOGIC AUTHORIZED REPRESENTATIVE SHALL CREATE A WARRANTY OR IN ANY WAY INCREASE THE SCOPE OF THIS WARRANTY.

LIMITATION OF LIABILITY - SOLAR LOGIC AND ITS LICENSORS ARE NOT LIABLE FOR ANY CLAIMS OR DAMAGES WHATSOEVER, INCLUDING PROPERTY DAMAGE, PERSONAL INJURY, INTELLECTUAL PROPERTY INFRINGEMENT, LOSS OF PROFITS, OR INTERRUPTION OF BUSINESS, OR FOR ANY SPECIAL, CONSEQUENTIAL OR INCIDENTAL DAMAGES, HOWEVER CAUSED, WHETHER ARISING OUT OF BREACH OF WARRANTY, CONTRACT, TORT (INCLUDING NEGLIGENCE), STRICT LIABILITY, OR OTHERWISE.

