

User Manual



Coffee machine 1800S

English

02.02.001

Congratulations on the purchase of your WMF coffee machine

The WMF 1800 S coffee machine is a fully automatic single cup machine for espresso, café crème, cappuccino, milk coffee, latte macchiato, milk foam and hot water. Options include steam dispensing and the preparation of hot Choc beverages, with two different types of Choc (Twin Choc).

Each beverage is freshly brewed at the press of a button which guarantees a high quality beverage. User guidance is provided by a graphical touch-screen display on the coffee machine.

Please be sure to follow the instructions in the Software chapter ▷Settings ▷Water hardness and capacity, and to make the necessary settings.



Please read the User Manual prior to using the coffee machine.

Ensure that the staff has access to the User Manual.

Important.

Follow chapter 1 ▷ User Manual Signs and Symbols, page 8.

Follow Safety chapter, starting on page 55.

Observe the additional instructions:

Cleaning instructions 1800 S



In the event of failure to comply with maintenance information (▷ Maintenance), no liability is accepted for any resultant damage.

Similarly all guarantee / warranty obligations cease to apply in such cases.

Chapter 1 Introduction	6
1.1 Parts of the coffee machine	6
User Manual Signs and Symbols	8
Glossary	9
Chapter 2 Operation	10
2.1 Switch on coffee machine	10
2.2 Beverage dispensing	10
2.3 Milk or milk foam (optional)	10
2.3.1 Dispense milk or milk foam.	10
2.3.2 Connect up the milk.	11
With WMF Cooler, WMF Cup&Cool (optional)	11
Standard	11
2.4 Height adjustment of the combi spout	12
2.5 Bean hopper / product hopper	12
2.6 Twin Topping hopper / Twin Choc hopper (optional)	12
2.7 Manual insert (optional) / tablet insert	13
2.8 Grounds container	14
2.9 Grounds disposal through the counter (optional)	14
2.10 Drip tray	15
2.11 Switch off the coffee machine	15
Chapter 3 Software	16
3.1 An overview	16
3.2 Ready to operate	18
3.2.1 "Warm rinse" pad (optional).	18
3.2.2 Barista pad (optional)	18
3.2.3 Information.	18
Service	18
Care	18
Brew time	19
Journal	19
Timer	19
3.2.4 Main menu.	19
3.3 Main menu	20
3.3.1 Milk and foam.	20
Milk foam quality	20
Latte macchiato pause interval	20
3.3.2 Timer program.	21
Timer state	21
Set timer	21
Copy day	22
Timer overview	22
Delete timer	23
Timer information	23


Table of Contents

3.3.3	Care	24
	Cleaning program	24
	Foamer cleaning	24
	Mixer rinsing	25
	Filter change	25
	Rinse filter	25
	Customer Check-up (optional)	25
3.3.4	Settings	26
	Recipes and buttons	26
	Selecting the beverage buttons when setting	
	Adjust values	
	Start a preparation test with the current values	
	Save setting	
	Cup volumes	
	Change recipes	
	Sequence of ingredients additions	
	Button allocation	
	Select grinder for a coffee beverage	
	Select the portion controller for the Choc beverage	
	Weigh grounds	
	Boiler temperature	28
	Reset	28
	Time and date	28
	Display language	29
	Display contrast	29
	Water filter is fitted	29
	Water hardness	29
	Capacity	29
	Warm-up rinsing	29
	Foamer rinsing (optional)	29
	Rinsing interval	29
	Operating options	30
	Illumination (optional)	31
	Milk (optional)	31
	Eco-mode	32
3.3.5	PIN entry display	32
3.3.6	PIN rights, access control	33
	Cleaning level	33
	Setting level	33
	Accounting level	33
	Delete PIN	
3.3.7	Accounting numbers of beverages	34
Chapter 4 Other settings		35
4.1	Mechanical settings	35
4.1.1	Set grinding degree	35
4.2	Labelling of beverage buttons	35
Chapter 5 Care		36
5.1	Cleaning intervals overview	36
	For all cleaning instructions	37

5.2	Daily cleaning	37
5.2.1	Cleaning program	37
5.2.2	Milk system cleaning	37
	Milk system cleaning Standard	37
	Milk system cleaning Plug&Clean	38
5.2.3	Mixer rinsing	38
5.2.4	Combi spout cleaning	38
5.2.5	Milk container cleaning (optional)	38
5.2.6	General cleaning	38
5.3	Weekly cleaning	39
5.3.1	Choc / Topping mixer cleaning (optional)	39
5.4	Regular cleaning	40
5.4.1	Brewing unit cleaning	40
5.4.2	Bean hopper cleaning	42
5.4.3	Product hopper cleaning (optional)	42
5.5	Filter change	43
Chapter 6 HACCP cleaning schedule		44
Chapter 7 Maintenance		46
7.1	Coffee machine maintenance	46
7.2	WMF Service	47
Chapter 8 Messages and instructions		48
8.1	Messages for operation	48
8.2	Error messages and malfunctions	51
8.3	Errors without error message	54
Chapter 9 Safety		55
9.1	Hazards to the operator	55
9.2	Hazards to the coffee machine	57
9.3	Intended use	57
9.4	Directives	57
9.5	Duties of the owner / operator	58
9.6	Warranty claims	59
	No warranty is provided:	59
Appendix: Cleaning instructions (Standard)		60
Appendix: Technical data		61
Technical data for coffee machine		61
Conditions for usage and installation		61
Appendix: Accessories and spare parts		64
Index		66




Chapter 1 Introduction

1.1 Parts of the coffee machine



- 1 Bean hopper (optional 1 or 2)
- 2 Tablet insert (depending on the model)
- 3 Choc hopper / Topping hopper / Twin Topping hopper / Twin Choc hopper (optional)
- 4 Beverage buttons
- 5 Touch-screen display
- 6 Side illumination
- 7 Left machine door
- 8 Height adjustable combi spout with integrated milk foamer
- 9 Plug&Clean connection (optional)
- 10 Removable drip tray with drip grid
- 11 ON/OFF switch
- 12 Adjustable screen
- 13 Grounds container
- 14 Brewing unit
- 15 Timer and clock display
- 16 Information pad
- 17 Messages / error messages
- 18 Menu pad (opens main menu)
- 19 Barista pad (optional)
- 20 "Warm rinse" pad (optional)

User Manual Signs and Symbols



Tip
Instructions



Cross reference




Start position
Main menu

If the menu symbol is shown in this User Manual, the description starts at the main menu start position.

Call up the main menu

- * Touch the unlit display for longer than 5 seconds
The "Ready to operate" display is activated and illuminated.
- * Touch the **MENUE** menu pad
The main menu is displayed.
There are other display options ▷ Main menu.



Main menu

Glossary

Term	Explanation
•	• Listings, selection options
※	※ Individual steps
<i>Text in italics</i>	<i>Description of coffee machine state and/or explanations of automatic steps.</i>
Beverage dispensing	Dispensing coffee, hot water or Choc beverages
Capacity	For example the capacity of the water filter in litres of water it can filter
Carbonate hardness	Quoted in °dKH. The water hardness is a measure of the calcium dissolved in the water.
Choc	Hot chocolate
Grounds chute	▷ Grounds disposal through counter, page 14
Mains tap	Water stop valve, angle valve
Milk system	Combi spout, milk nozzle and milk hose
Mixer system	Complete module, mixer with portion controller for Choc / Topping
O-rings	Seals
Pre-infusion	Prior to brewing cycle, coffee is briefly infused in order to ensure a more intense release of its aromatic substances.
Pressing	Automatic pressing of ground coffee prior to brewing cycle.
Rinsing	Intermediate cleaning
SB mode (self-service mode)	Self-service customer operation (SB)
Topping	Milk powder
Twin Topping	Divided hopper for two kinds of powder, such as Choc and Topping

Chapter 2 Operation

2.1 Switch on coffee machine

- ※ Press the ON/OFF switch for longer than 5 seconds

Coffee machine switches on and heats up.

When the coffee machine is ready to dispense beverages, the beverage buttons light up.

PIN access control
▷ Software
▷ Settings
▷ Operating options
page 30

▷ Timer program
page 21

If vending machine is connected
▷ User Manual of vending machines.

2.2 Beverage dispensing


Pressing the beverage buttons triggers dispensing of the beverage selected.

- Lit up button = ready to dispense
- Flashing button = beverage dispensing
- Unlit button = not ready to dispense / button disabled

- ※ Place a suitably sized cup below the combi spout

- ※ Press the desired beverage button

The desired beverage is dispensed.



Button allocation
▷ Software ▷ Settings
▷ Recipes and buttons
page 26

2.3 Milk or milk foam (optional)

2.3.1 Dispense milk or milk foam

- ※ Press the beverage button assigned to milk or milk foam

Dispensing occurs. Dispensing runs for as long as the button is held.

2.3.2 Connect up the milk

Use a suitable milk nozzle on the combi spout.

Milk nozzle

- for cooled milk white or green
- for uncooled milk caramel

With WMF Cooler, WMF Cup&Cool (optional)

- * Insert the milk nozzle for cooled milk into the milk connection on the combi spout
- * Remove the milk container out of the cooler
- * Push the milk container lid back
- * Pour milk into the milk container
- * Place the lid back on the container
- * Insert the adapter on the milk hose into the connection in the milk container lid
- * Push the milk container back in carefully


The milk hose is inserted into the adapter.

Standard

- * Insert the suitable milk nozzle into the milk connection on the combi spout
- * Open the milk packaging and place on the left next to the coffee machine
- * Open the milk cover
- * Insert the milk hose through the opening
- * Insert the milk hose with the beige milk nozzle into the milk pack

The hose must not be under tension or bent when adjusting the height of the combi spout.

- * Close milk cover



Cooler milk container



Cooler adapter



Version without cooler

2.4 Height adjustment of the combi spout

The combi spout is height adjustable.

- ✱ Take hold of the combi spout from the front and push to the desired height

Height adjustment range of the combi spout:

70 mm–180 mm



2.5 Bean hopper / product hopper

If possible, refill product hopper in advance.

Fill the hoppers no more than the amount needed for one day, in order to maintain the freshness of the products.

*Coffee beans into
bean hopper,*

*Choc powder into
Choc hopper,*

*Topping powder into
Topping hopper.*

2.6 Twin Topping hopper / Twin Choc hopper (optional)

Divided hopper for two kinds of powder, such as Choc and Topping, or two different types of Choc.

- Left side: Choc; right side: Topping, or
- Left side: Choc 1; right side: Choc 2



2.7 Manual insert (optional) / tablet insert

Coffee machines with three product hoppers have only a tablet insert. Ground coffee must not be inserted into the tablet insert.

The manual / tablet insert is located in the centre of the coffee machine cover.

Tablet insert is used:

- For inserting cleaning tablets

Manual insert is used:


- For inserting cleaning tablets
- When using an additional coffee types, such as decaffeinated coffee
- for a coffee trial

Add ground coffee or cleaning tablet only after the display message.

Preparation of ground coffee using the manual insert

- * Open manual insert lid
- * Insert ground coffee (max. 16 g)
- * Close manual insert lid
- * Press the desired beverage button

For beverages on second level, touch the shift pad before opening the manual insert.



Tablet insert



Manual insert

2.8 Grounds container

The grounds container receives the used coffee grounds. It has enough capacity to store coffee grounds from approx. 50 brewing cycles.

The coffee machine will inform you when the grounds container needs emptying.

Beverage dispensing is blocked for as long as the grounds container is removed.


- * Push combi spout all the way up
- * Push up adjustable screen over grounds container
- * Remove grounds container
- * Empty and replace grounds container
- * Confirm process on the display

If grounds container cannot be replaced, check chute for coffee residue and remove.

Always empty grounds container before replacing. Replacing without emptying results in the grounds container being overfilled. The coffee machine will be soiled. This may cause subsequent damage to the machine.



Clean daily
▷ Care
page 36



2.9 Grounds disposal through the counter (optional)

The coffee machine can be fitted with grounds disposal through the counter. In this case, both the grounds container and the coffee machine base have an opening that passes through the on-site counter on which the machine is placed. The spent coffee grounds are collected in a large container under the counter.



Grounds disposal through the counter cannot be retrofitted.

Clean coffee grounds chute daily
▷ Care
page 36

2.10 Drip tray

- * Carefully remove the drip tray for cleaning



Replace carefully so that no water accidentally drips down.

Clean drip tray daily ▷ Care



Caution.
Hot liquids.
Move the drip tray
carefully.

Observe the Safety chapter.

2.11 Switch off the coffee machine

The coffee machine must be cleaned daily prior to switching it off.

- * Press the ON/OFF switch for longer than 5 seconds until coffee machine switches off
- * Turn off mains tap



PIN access control

▷ Software

▷ Settings

▷ Operating options
page 30

We do not accept any warranty for damage resulting from failure to observe this requirement.




Follow the manual.

Observe the Safety chapter.

Chapter 3 Software

3.1 An overview

Ready to operate (if display is activated)






✱ Touch the unlit display for longer than 5 seconds
The "Ready to operate" display is activated and illuminated.



There are various setting options for the "Ready to operate" display.



If there are errors, the relevant  pad is displayed.
If Cleaning , Descaling  or Filter change are required, this is displayed.
Other display options ▷Settings ▷Operating options.

"Ready to operate" display pads Chapter 3.2



Warm rinsing (optional)
Chapter 3.2.1



Barista
(strength of the coffee) (optional)
Chapter 3.2.2



Main menu
Chapter 3.2.4



Information
Chapter 3.2.3



Error message
Touching the pad calls up the error message.










Care message
*Touching the pad leads directly to the menu.
Cleaning required.*










*Self-service and
operating options
▷ Settings
page 30*

Main menu functions (pads)

Chapter 3.3

	Milk and foam <i>Chapter 3.3.1</i>
	Timer program <i>Chapter 3.3.2</i>
	Care <i>Chapter 3.3.3</i>
	Settings <i>Chapter 3.3.4</i>
	PIN entry <i>Chapter 3.3.5</i>
	PIN rights, access control <i>Chapter 3.3.6</i>
	Accounting <i>Chapter 3.3.7</i>

Menu control pads

	Save settings
	Start or confirm a step
	Back to the higher menu level Cancel / leave without saving (Exit)
	Clear or reset
	Start preparation test / coffee trial
 	Increase or reduce setting values
 	Forward or back one step in listings

3.2 Ready to operate

3.2.1 "Warm rinse" pad (optional)

※ Touch the "warm rinse" pad 

A rinse of the pipes with hot water starts. The water warms the brewing system and guarantees an optimum coffee temperature.

Recommended after a longer brewing pause, especially before dispensing a cup of espresso.

*"Warm rinse" pad (active / inactive)
▷ Settings ▷ Operating options
page 30*

3.2.2 Barista pad (optional)

※ Touch the Barista pad 

The coffee strength will be altered for the next brewing cycle only.



weaker (-15%)



normal, as per setting



stronger (+15%)

*Barista pad (active / inactive)
▷ Settings ▷ Operating options
page 30*

3.2.3 Information


※ Touch the  Information pad on the "Ready to operate" display

The Information menu appears.

The "Information" main menu contains the following selection options.

Service

- Service location (contact details)
- Start-up data
- Next maintenance date
- Software version
- Serial number



Care

- Journal
 - Journal log of last cleaning
- Cleaning information
 - Info on last cleaning
- Descaling information
 - Info on last / next descaling
- Water filter information (optional)
 - Remaining capacity information

Brew time


- Brew and dispensing time of last beverage dispensed

Journal

- List of logged error and status messages (for telephone support)

Timer

- Display the timer state (ON/OFF)
- Display the next switching time




3.2.4 Main menu


Call up the main menu

* Touch the unlit display for longer than 5 seconds
The "Ready to operate" display is activated and illuminated.

* Touch the **MENUE** menu pad
The main menu is displayed.




"Ready to operate" display



... with additional pads

Delayed fade-in
 ▷ Settings ▷ Operating options
 page 30

3.3 Main menu



MENUE



Other illustrations of the main menu for protected levels.

▷ PIN rights, access control page 33

3.3.1 Milk and foam

Milk foam quality

The milk foam quality is set here.
This setting will apply to all beverages with milk foam.
Compensates for variations in milk characteristics.

Reduce setting value -> finer foam and lower dispensing temperature

Increase setting value -> coarser foam and higher dispensing temperature

MENUE



MENUE



foam quality

Latte macchiato pause interval

Latte macchiato is more successful if the interval between milk and milk foam dispensing is lengthened.

Reduce setting value -> shorter interval

Increase setting value -> longer interval

MENUE



macch.interrupt

3.3.2 Timer program

The timer program sets the switch on and switch off times. The "Timer program" main menu contains the following selection options.

- Timer state
- Set timer
- Timer overview
- Delete timer
- Timer information

Timer state

* Touch **timer status**

Activate / deactivate timer = ON/OFF

Set timer

* Touch **timer adjustment**

Program the switch on and switch off times.

* Touch **operating time**

The "operation time" display appears. Here the day, time, and desired operation are set.

* Set day (Day)

- 1 = Monday
- 2 = Tuesday, etc. up to 7 = Sunday
- 1-5 = Monday to Friday (weekdays)
- 1-7 = entire week (Monday to Sunday)

* Set the time (hours, minutes)

* Set the desired switching time (action)

- Switch on time = **I** (on display)
- Switch off time = **O** (on display)

* Confirm with **OK**

or

* Delete with **C**




PIN rights, access control
 ▷ Software
 ▷ Settings
 ▷ PIN rights, access control
 page 33



When the timer is activated, the timer symbol appears on the display.



Example:



in day 1-5 or day 1-7, the switching times are copied to the indicated days.

Select desired settings with the pads **+** and **-**.

Current selection is inversely displayed.



Display programmed switching times

- * Touch the **+** and **-** pads under **prg**

*Programmed switching times are displayed here.
Up to 16 switching times (events) per day can be programmed.*

Programmed times are sorted chronologically.

*Any new switching time is sorted chronologically immediately upon entry and confirmation with **OK**.*

*Touching the **oi** pad directly accesses the timer overview.*

Copy day

Any day may be copied to other days, complete with its switching times.

- * Touch **timer adjustment**

Program the switch on and switch off times.

- * Touch **operating time**

- * Touch the number pad under **day**

The selection of the week days is displayed.

- * Scroll through to page 4

- * Touch **copy day**

The selection of the week days is displayed again.

- * Select the day that you want to copy

- * Touch **insert day**

*Select the day you want to copy the time settings to
The day is copied.*

*In day 1–5 or day 1–7, the
switching times are copied to the
indicated days.*

*The individual days 1,2,3...7 are
displayed.*



To check times
▷ Timer overview

Timer overview


Checking the programmed switching times:

- * Touch **timer overview**

The switching times overview for the week is displayed graphically. Switch on times are indicated by bars.



Example:



*switching times Monday to Friday
(1–5).*

*On time 7 a.m. (7:00)
Off time 6 p.m. (18:00)*

Delete timer


- * Touch **delete timer** on page 2 of the timer main menu
 - * Scroll to desired day and touch to select
A safety query now appears querying whether deletion is actually intended.
 - * Confirm with **OK**
The day is deleted with all its switching times.
- Besides individual days, "all workdays" or the entire week can also be deleted.



This process cannot be undone.

Timer information

Touching **timer info** calls up a display with the next switching time and the timer state (ON/OFF).





3.3.3 Care

Cleaning and descaling programs are started from the Care main menu. Filter change (optional) and maintenance actions are confirmed here.

The "Care" main menu contains the following selection options.

- Cleaning program
- Foamer cleaning
- Mixer rinsing
- Filter change
- Rinse filter



In the Software chapter ▷ Care display-guided sequences are described in detail.

Physical cleaning actions are described in the Care chapter.

Cleaning program


※ Touch **cleaning prog.**

The daily cleaning program starts.

The program automatically executes foamer cleaning if milk beverages have been dispensed. Mixer rinsing follows for the WMF 1800 S with mixer system.

The cleaning program sequence is described in the cleaning instructions.

Prior to carrying out cleaning, please note the safety instructions in the safety chapter. Read the cleaning instructions and the Care chapter, starting on page 36.



Foamer cleaning

※ Touch **foamer cleaning**


Foamer cleaning starts.

Optional Plug&Clean cleaning.

Foamer cleaning is carried out automatically as an integral part of the full cleaning program.



▷ Cleaning program





Mixer rinsing

The mixer lift must be in the top position.

* Touch **mixer rinsing**

Mixer rinsing starts.

Mixer rinsing is performed automatically by the cleaning program when a mixer system is installed.



Caution.

Hot liquids in the dispensing area.

Observe the Safety chapter.

Filter change

If the filter capacity is exceeded, there will be a message once per day that a filter change is due.

The filter must be changed within one week; otherwise, the message will be displayed after every brewing cycle.

* Change filter

* Confirm filter change

After filter change there is an automatic program sequence to rinse and bleed the anti-scale filter and water system. Hot water runs out of the hot water spout during this process.



Observe water filter instructions.

Displays lead step by step through the program.

Follow the instructions.



Caution.

Scalding hazard.

Observe the Safety chapter.

Rinse filter

The Filter rinse option enables water system and filter rinsing and bleeding following long intervals in operation.

* Touch **filter rinsing**

Hot water runs out of the hot water spout during this process.



Caution.

Scalding hazard.

Observe the Safety chapter.

Customer Check-up (optional)

This point can be selected by trained personnel if the WMF Service function has been enabled.

Query: has customer check-up been performed?
yes / no



3.3.4 Settings

Recipes and buttons

※ Touch **recipes/button**

The **recipes/button** menu contains the following selection options.

- Cup volumes
- Change recipes
- Button allocation
- Weigh grounds

Selecting the beverage buttons when setting

※ Press the desired beverage button

Adjust values

※ Adjust values with the **+** and **-** pads


Start a preparation test with the current values

※ Touch **Test**

The values are not saved yet.

Save setting

※ Save with **OK**



- +** = more
- = less
- Exit** = exit without change
- OK** = save the values
- Test** = start test

Cup volumes

Cup volumes are matched to the cups used.
Individual beverage ingredients are matched to the new cup volumes with no effect on composition and quality.

Change recipes

All beverages


- Coffee** ↑ ↓ Ground coffee quantity / Choc powder quantity
- Water** ↑ ↓ Water volume

Milk beverages

- Milk foam** ↑ ↓ Milk foam volume
- Milk** ↑ ↓ Milk volume



Change recipes display



Example: ground coffee quantity

Coffee beverages

Quality

The five available quality levels affect the coffee brewing. The higher the quality level, the more intensive the release of the flavour and aromatic substances in the coffee.

Quality 1 After pressing, space is provided for the ground coffee to swell.

Quality 2 After pressing, the coffee is brewed immediately.

Quality 3 After pressing, a pre-infusion occurs.

Quality 4 After pressing and a pre-infusion, a second wet pressing occurs.

Quality 5 After pressing, a pre-infusion occurs. In addition the brew time is automatically extended.



Quality



Instructions.

If very finely ground coffee is used with a small amount of brewing water, a high quality level can cause a brewing water flow error.

Sequence of ingredients additions

The sequence of additions is only possible for beverages whose recipe contains at least two ingredients.

The sequence in which the individual additions will be dispensed.

Adjustable additions

- Coffee
- Milk
- Milk foam
- Choc

Set the sequence

- Upper line: set start position for dispensing milk, milk foam or Choc.
- Lower line: set start position for coffee brewing

✱ Touch the start position pad until the desired addition is displayed

The next addition will be displayed each time it is touched.

Sequence of dispensing from left to right.

Sequence examples



First coffee and milk foam at the same time and then milk



First milk foam, then milk, then coffee



First milk, then milk foam, then coffee

Button allocation

The beverages are assigned to the beverage buttons. This button allocation is set here.

- * Press the beverage button
- * Select the desired recipe, for example espresso, from the list

Select grinder for a coffee beverage

(only for 2 grinders)

- * Press the beverage button
- * Select recipe, for example espresso
- * Select grinder (on the right or left)

Select the portion controller for the Choc beverage

(only for Twin Choc)

- * Press the beverage button
- * Select recipe, for example milk Choc 1
- * Select portion controller (on the right or left)

Weigh grounds

- * Empty and replace grounds container
- * Touch **weigh grounds**

The process dispenses ground coffee directly into the grounds container and the grounds may then be weighed.

The grind quantity is dispensed once.

Boiler temperature

- * Set desired boiler temperature
(Change brewing water temperature)
(default setting range 80–100 °C)

Reset

The coffee machine software is restarted.

Time and date

Clock time and date are set here.

Load a new recipe:

the previous settings will be overwritten by the factory standard values for the new recipe.

Only adjustable recipes are indicated.



The product hopper cannot be selected for the Chociatto beverage.



MENUE



boiler temp.

MENUE



reset

MENUE



time / date



Display language

The language used in the display is set here.



Display contrast

Contrast of the display is set here.

(Default value is 70)



Water filter is fitted

Whether water filter is fitted or not is entered here.

This affects the descaling intervals.



Water hardness

The water hardness (carbonate hardness) is set here.



Capacity

The water filter capacity is set here.

The water filter capacity can be found in the water filter documentation.



Warm-up rinsing

Whether the coffee machine should rinse the brewing unit with hot water after heating up is set here.

Recommended setting: active.



Foamer rinsing (optional)

Whether automatic foamer rinsing should occur after the last beverage with milk components is dispensed.

yes / no



Rinsing interval

The time elapsed between the last time a beverage with milk was dispensed and a foamer rinsing.

Recommended setting: 2 minutes.



Operating options

The following operating options are available.

- "Warm rinse" pad (active / inactive)
- Barista pad (active / inactive)
- 2. level (active / inactive)
- ON/OFF switch (direct / via PIN)
- Cancel beverage (yes / no)
- Menu pad (immediate / delayed)
- Error message (normal / symbol)

"Warm rinse" pad (optional)

Standard: inactive.

Barista pad

Standard: inactive.

2nd level / shift pad

Can only be set by WMF Service upon request.

ON/OFF switch

Recommendation for self-service: via PIN.

If "via PIN" is set, then the PIN for the Cleaning level will be queried before switching on or off.

Cancel beverage

Standard: no.

Menu pad

Recommendation for self-service: delayed.


If "delayed" is set, the menu pad will only be shown if the display is pressed for 5 seconds.

Standard: delayed.

Error message

normal: all messages are shown on the display.

Symbol: messages that require immediate action are shown on the display.

All other messages are displayed as symbol .

※ Touch the  symbol

All messages are displayed.



If customers serve themselves then some functions can be switched to inactive.

The pads will not be displayed on the "Ready to operate" display.

▷ PIN rights, access control
page 33

▷ To the main menu
page 20



*With illumination (optional):
messages that require immediate action are accompanied by flashing side illumination.*

SB mode (self-service)

Standard: SB mode.

- It is not possible to interrupt the beverage dispensing cycle
- Menu pad is no longer displayed
- Error message Symbol
- Barista pad and "warm rinse" pad not displayed (optional)



Individual options can be changed under the "Operating options" menu item.


SB mode messages

- Beans empty
- Milk empty (cooler milk container)
- Grounds container full
- Grounds container missing
- Manual insert open
- Clean the coffee machine
- Open water supply valve
- Brewing unit error
- Error message with error number

Illumination (optional)

* Set the colour values here of the LEDs for the desired illumination colour

Setting examples	red	green	blue
light sequence	1	0	0
(permanent colour change)			
amber	25	30	0
blue	0	0	30



Milk (optional)

The empty milk message can be activated here.

* Touch **milk**
Beverage lockout yes / no




Beverage lockout no

Beverages can be dispensed until the milk container is actually empty.



Beverage lockout yes

Input is requested as to how many beverages can be dispensed after the message has appeared. After this number of beverages has been dispensed, beverages with milk are blocked from further dispensing. Beverage lockout is removed when the milk container is filled.



Eco-mode

If Eco-Mode is set to "active," the steam boiler temperature is reduced 10 minutes after the last beverage is dispensed. The display illumination and the optional side illumination are switched off. The beverage buttons remain lit. If a beverage with milk content is to be dispensed when the temperature is reduced, the coffee machine needs about 15 seconds to heat up. Beverage dispensing starts after the machine has heated up.

Eco-mode

(active / inactive)

Standard: inactive

The Eco-Mode can be activated here.


Switch off

(never / after 30 min./60 min./90 min./120 min./150 min./180 min.)


Standard: never


The time after the last beverage is dispensed is adjusted here. If this time is exceeded, the coffee machine automatically shuts off.

It can be set in increments of 30 minutes.



3.3.5 PIN entry display

Individual authorisation levels can be protected using a PIN. For access to a PIN-protected level, the PIN must be entered via  pad.


* Touch the  pad in the main menu

Numerical keyboard display appears.

* Enter required 4-figure PIN

* Confirm with **OK**

Following entry of a valid PIN, the assigned functions are available.



PIN entry display

3.3.6 PIN rights, access control

If a PIN has been assigned for a particular level, no access will be granted without a PIN.

Cleaning level

On entering the valid PIN, access to:



= Care



= PIN-protected ON/OFF switch



Cleaning level access

Setting level

On entering the valid PIN, access to:



= Setting the milk foam quality



= Timer program




= Care



= PIN-protected ON/OFF switch



= Settings (only cup volumes)



Setting level access

Accounting level

On entering the valid PIN, access to:



= Setting the milk foam quality



= Timer program



= Care



= PIN-protected ON/OFF switch




= Settings (beverage, general, others)



= Assign PIN rights, access control




= Accounting numbers of beverages



Accounting level access


A PIN may be assigned to any level. The levels are hierarchical.

Example: the PIN for the **setting** level is valid for **cleaning** and **setting** levels, but not for the **accounting** level.



PIN entry display

Example:



*PIN entry for Cleaning level 1234
This PIN is carried over to the higher levels.*

- * Touch the **PIN** pad in the main menu
- * Select desired level

Example: **cleaning**

Numerical keyboard display appears.

- * Enter any desired 4-digit number

Number entered is displayed.

- * Confirm with **OK**

This level is now PIN-protected.

When a PIN is assigned to a subordinate level, that PIN is automatically copied to higher levels if the latter are not already PIN-protected.

Example:

	access-control	PIN
1	accounting	7777
2	setting	9876
	cleaning	1234

*PIN entry for
cleaning level: 1234
setting level: 9876
accounting level: 7777*

Delete PIN

Entering 0000 will delete access control for the given level.
Deletion the PIN of one level automatically deletes the subordinate PINs.

3.3.7 Accounting numbers of beverages

- * Touch **counter**

The counter menu displays the counter for each beverage.

Read counter

- * Touch desired beverage on the display

Delete counter

- * Touch the **C** clear pad

If no beverage is selected, on touching the **C** clear pad a dialogue appears in the display querying whether the counter readings for all beverages should be zeroed.

The "Accounting numbers of beverages" function should be protected with a PIN to prevent unauthorised access.





Chapter 4 Other settings

4.1 Mechanical settings

4.1.1 Set grinding degree

- * Remove bean hoppers
- Preset grinding degree is now visible.*
- * Release coffee dispensing and wait until grinder starts up
- * With grinder running, alter grinding degree as desired on the side of the coffee machine using the multitool

Grinding degree 1 → fine 

Grinding degree 6 → coarse 



Multitool



Display grinding degree

Bruising or crushing hazard.

Never reach into the grinders with coffee machine running and product hoppers removed.



Caution.
Bruising or crushing hazard.

Observe the Safety chapter.

4.2 Labelling of beverage buttons

First switch off the coffee machine in order not to trigger dispensing inadvertently.

- * Pull out existing labelling behind front glass in a downward direction
- * Write on label stickers as desired using the WMF template
- * Stick on label mount and re-insert behind the front glass panel

The template can be printed out on adhesive labels or paper.

Stick paper to label mount using an adhesive sticker.



Free download of WMF label template from
www.servicecenter.wmf.com

Matching adhesive labels:
Zweckform-Avery No. 3659

Chapter 5 Care

Regular cleaning is essential in order to ensure problem-free operation of the coffee machine and to ensure optimum coffee quality.


Prior to and after every instance that the machine is shut off for several days, perform all cleanings.

We do not accept any warranty for damage resulting from failure to observe this requirement.

5.1 Cleaning intervals overview

Care					
Daily	Weekly	Regularly	Message	Optional	
x				0	Foamer rinsing
x					Cleaning program
x				0	Foamer cleaning
x					Milk system cleaning Standard
	x			0	Milk system cleaning Plug&Clean
x				0	Mixer rinsing
x				0	Milk container cleaning
x					Grounds container cleaning
x					Drip tray cleaning
x					Housing cleaning
(x)	x			0	Mixer cleaning
		x			Brewing unit cleaning
		x			Bean hopper cleaning
		x		0	Product hopper cleaning
			x	0	Filter change

- Daily – Daily, at least once per day and as required
- Weekly – Weekly cleaning
- Regularly – Regularly as required
- Message – After the display shows a message
- Optional – Optional (depending on the model)
- (x) – Daily as required



Caution.
Health hazard.
Follow the HACCP schedule.



Follow the manual.
Observe the Safety chapter.

- ▷ page 29
- ▷ Cleaning instructions
- ▷ page 38
- ▷ page 39
- ▷ page 40
- ▷ page 42
- ▷ page 43

For all cleaning instructions

For all cleaning programs, the combi spout, the milk nozzle, and the milk hose must be installed.



Caution.
Hot liquids in the
dispensing area.

Observe the Safety chapter.

Step for step instructions

▷ *Cleaning instructions*

5.2 Daily cleaning

5.2.1 Cleaning program

The cleaning program leads step by step through foamer cleaning, the mixer rinsing and the machine cleaning via software.

5.2.2 Milk system cleaning

Milk system cleaning ▷ Cleaning instructions.

The milk system consists of:

- Combi spout
- Milk nozzle
- Milk hose



Caution.
Hot liquids in the
dispensing area.

Observe the Safety chapter.

The milk system must be thoroughly cleaned and sanitized at least once a day, after no more 24 hours. For machines with Plug&Clean, this must be done as part of the machine cleaning at the end of operation. If this Plug&Clean cleaning is not done, then the combi spout must be disassembled and cleaned manually.



Caution.
Follow the hygiene
instructions.

See HACCP cleaning schedule

Milk hose should be changed at regular intervals.

Combi spout cleaning

▷ *Cleaning instructions*

Milk system cleaning Standard

Cleaning consists of two, or optionally three parts.

- Automatic foamer rinsing after each beverage with milk or milk foam (optional)
- Display-guided foamer cleaning
- **Once per day**, place combi spout, milk hose and milk nozzles in a cleaning solution

Milk system cleaning Plug&Clean

Cleaning with Plug&Clean consists of three parts.

- Automatic foamer rinsing after each beverage with milk or milk foam
- Display-guided Plug&Clean cleaning
- **Once per week**, place combi spout, milk hose and milk nozzles in a cleaning solution



Plug&Clean cleaning program
▷ *Cleaning instructions*

5.2.3 Mixer rinsing

Mixer rinsing is an intermediate cleaning of the mixer. Mixer rinsing is an integral part of the cleaning program.

The mixer lift must be in the top position.



Mixer rinsing
▷ *Cleaning instructions*

5.2.4 Combi spout cleaning

Thorough cleaning of the milk system. The exact procedure of this manual cleaning is described in the cleaning instructions.



Combi spout cleaning
▷ *Cleaning instructions*

5.2.5 Milk container cleaning (optional)

Clean the milk container thoroughly every day.



Caution.
Follow the hygiene instructions.

See HACCP schedule.

5.2.6 General cleaning

Grounds container cleaning (grounds chute, optional)

- * Empty grounds container and rinse under running water
- * Clean with a clean, damp cloth

Drip tray, housing and front panel

- * Clean the cold coffee machine using a damp cloth
- * Wipe dry using a fine woollen cloth or chamois leather

Cleaning metal surfaces

For cleaning metal cover parts (matte surface) we recommend WMF Purargan® cleaner.

Do not clean with scouring powders or the like. There is a risk of causing scratches or scores. Do not use any sharp cleaners or implements. Use soft cloths for cleaning.

Order numbers for the WMF care program
▷ *Appendix*
Accessories and spare parts
page 64

Switch off the coffee machine before cleaning the front panel to avoid a beverage being accidentally dispensed.



Hazards to the machine.

Follow the manual.

5.3 Weekly cleaning

5.3.1 Choc / Topping mixer cleaning (optional)

Choc mixer / Topping mixer

Cleaning will be more frequent depending on powder consumption.

- * Switch off the coffee machine using the ON/OFF switch
- * Disconnect mains plug
- * Open left machine door
- * Pull the green mixer release
- * Slide the mixer lift downward

The mixer is now accessible.

- * Pull off mixer hose from mixer to combi spout
- * Turn stud on bayonet connector underneath the mixer bowl counter-clockwise

Mixer bowl is released from the retaining catch.

The propeller for the mixer is now visible.

- * The propeller can be cleaned with a cloth
- * Dismantle two-piece mixer bowl
- * Clean both parts of mixer bowl and mixer hose under warm running water
- * Allow all parts to dry completely
- * Re-assemble all components

On re-assembly, all openings must face in the same direction.

- * Replace mixer bowl
- * Turn stud on bayonet connector back clockwise
- * Push mixer hose onto mixer bowl fitting again, and plug in combi spout
- * **Push mixer lift upwards until it engages in the release**
- * Close left machine door

Ensure that mixer hose is replaced securely.
This is important, as otherwise hot water or hot Choc / Topping beverage may escape.



Mixer release



open



Ensure that the spiral guide is seated and the hose is not pinched.



Caution.
Scalding hazard.

Observe the Safety chapter.

5.4 Regular cleaning

5.4.1 Brewing unit cleaning

The brewing unit should be cleaned as required and at regular intervals. Recommendation: weekly.

- * Switch off the coffee machine using the ON/OFF switch
- * Disconnect mains plug
- * Push combi spout all the way up
- * Remove grounds container forward
- * Remove the drip tray




Brewing unit is now fully accessible.

Burn hazard.

Allow brewer to cool before cleaning.

Hold firmly, as the brewing unit can slip downwards.

Never use force. Danger of breakage.



- * With one hand, reach into the chute under the brewing unit and release the retaining catch (illustration 1)
- * Slowly guide the brewing unit downwards, tilt and pull forward
- * Remove the brewing unit and hold firmly (illustration 2)



Illustration 1



Illustration 2

Use the multitool from the accessories.

- * Turn the thread on the brewing unit head counter-clockwise (illustration 3) until the wiper is in the forward position
- * Push the springs outwards over the edge and unlock (illustration 4)
- * Swing the insertion unit upwards
- * Clean the brewing sieve under running water or with a cloth
- * Remove coffee grounds residue using a paint-brush or scrubber
- * Rinse the brewing unit under running water

Never clean the brewing unit in a dishwasher and never use any cleaner additives.

- * Dry the brewing unit with a cloth
- Allow to dry completely before reinstalling in the coffee machine.

Remove coffee grounds residue from the chute.

- * Wipe out the coffee grounds towards the front or suck out using a vacuum cleaner

Refit the brewing unit after it has been dried.

- * Replace springs in insertion unit (illustration 4)
- * Hold the pusher compressed and replace the brewing unit in the chute against rear cover
- * Push the brewing unit upwards until it engages in the lock
- * Insert the grounds container
- * Close the adjustable screen

If the brewing unit cannot be replaced without resistance: turn thread on the brewing unit head slightly to the left or right with the multitool until the brewing unit slides into the guide.

Never use force.



Illustration 3



Hazards to the machine.

Follow the manual.



Illustration 4



Brewing sieve



Hazards to the machine.

Follow the manual.

5.4.2 Bean hopper cleaning

The bean hoppers should be cleaned as required and at regular intervals. Recommendation: monthly.

- * Switch off the coffee machine using the ON/OFF switch
- * Disconnect mains plug
- * Release bean hoppers lock using multitool by turning in a clockwise direction
- * Lift bean hoppers out
- * Completely empty bean hoppers and wipe out thoroughly with a damp cloth
- * Allow bean hoppers to dry completely
- * Refill and replace bean hoppers
- * Lock with the multitool by turning counter-clockwise



open



close



Never reach into the coffee grinders.

Never clean the bean hoppers in a dishwasher.



Caution.

Bruising or crushing hazard.

Observe the Safety chapter.

5.4.3 Product hopper cleaning (optional)

Choc / Topping, Twin Topping, Twin Choc

Cleaning will be more frequent depending on powder consumption.

- * Switch off the coffee machine using the ON/OFF switch
- * Disconnect mains plug
- * Unlock product hopper with multitool by turning counter-clockwise
- * Lift product hopper out and empty completely
- * Unscrew union nut at front and rear
- * Remove the dosing auger



open



close

- * Thoroughly wipe out hopper with a damp cloth
- * Thoroughly clean individual dosing auger components
- * Allow product hopper and individual components to dry completely
- * Re-assemble and replace the dosing auger and screw on union nuts



Portion controller with individual parts, dosing auger

Ensure correct orientation of discharge.



- * Refill and replace product hopper
- * Lock with the multitool by turning clockwise



Special features of the Twin Choc hopper / Twin Topping hopper

The Twin Choc hopper is divided in the middle and has two separate compartments for two different types of Choc or Topping.

Never clean product hoppers in the dishwasher.



Dismantled dosing augers

- 1 = Topping
- 2 = Choc

With Twin Choc:
dosing auger 2 is used
twice.

5.5 Filter change

Follow the water filter User Manual for a filter change. After a filter change, perform a rinse as guided by the display.



▷ Software ▷ Filter change
page 25

Filter change message
▷ Messages and instructions
page 48

Chapter 6 HACCP cleaning schedule

You are required by law to ensure that your customers are not subject to any health hazards as a consequence of the consumption of the food items you serve.

A HACCP schedule (Hazard Analysis Critical Control Points) for risk identification and assessment is required. You should carry out a risk analysis on your premises. The aim of the analysis is to recognize and pre-empt food hygiene hazard points. For this purpose, monitoring and, where necessary, test procedures must be established and implemented.

With correct installation, care, maintenance, and cleaning, WMF coffee machines meet the requirements described above. If care and cleaning of the coffee machine is not carried out properly, dispensing milk beverages will constitute a food hygiene hazard point.


Please observe the following points in order to comply with the HACCP cleaning schedule:

*"Food Hygiene Ordinance from
05.08.1997"*

*Use our HACCP cleaning schedule
for monitoring of regular cleaning.*

Sanitize the milk system daily

- Follow the cleaning instructions for the milk system contained in the cleaning instructions. This will ensure that your system contains a minimum of bacteria at commencement of operation.

You can call up the logs of the most recent cleaning operations via Information pad .



Always commence operation with a freshly opened cooled milk pack

- Original packaged UHT milk is usually free from harmful bacteria. Always open a new cooled pack at commencement of operation.
- Ensure absolute cleanliness when opening the milk pack. Germs can be introduced from dirty hands or tools when opening.

*Recommendation:
only use UHT milk with a 1.5% fat
content.*



Keep milk cool.

- Always have a new cooled milk pack handy.
- If cooling is not used during operation, then the milk must be used up very quickly. Cool the milk occasionally if needed.
- If little milk is used, cooled milk must be placed in the refrigerator again during operation.

At commencement of operation milk should be at approx. 6–8 °C.

Depending on the setting, one litre of milk is sufficient for approx. 20 cappuccinos.

WMF AG offers a range of refrigeration options (e.g., WMF countertop coolers or WMF milk coolers).

Recommendation for Choc and Topping (optional)

Regularly clean the product hopper. See the instructions in the Care chapter.

See chocolate / Topping manufacturer's instructions.



Caution.
Follow the hygiene instructions.

See Care chapter.

HACCP cleaning schedule

Month _____ Year _____

Use only cooled UHT milk, to prevent health risks due to bacteria.
For Choc and Topping, use only products that have not exceeded their expiration date.

Cleaning steps:

1. Run the cleaning program
 - ▷ Cleaning instructions
- 2a. Milk foamer cleaning (combi spout)
 - ▷ Cleaning instructions
- 2b. Daily mixer cleaning
 - ▷ Cleaning instructions
- 3a. Clean the foamer and change out the combi spout after 4 hours of operation time (absolutely required for low number of dispense cycles, or if milk is not cooled)
- 3b. Weekly mixer cleaning and regular product hopper cleaning (Care chapter)
4. General machine cleaning

Date	Cleaning steps				Signature
	Time				
	1	2	3	4	
1.					
2.					
3.					
4.					
5.					
6.					
7.					
8.					
9.					
10.					
11.					
12.					
13.					
14.					
15.					
16.					

Date	Cleaning steps				Signature
	Time				
	1	2	3	4	
17.					
18.					
19.					
20.					
21.					
22.					
23.					
24.					
25.					
26.					
27.					
28.					
29.					
30.					
31.					

Chapter 7 Maintenance

Please observe that this is a professional industrial coffee machine which needs regular maintenance and descaling. Timing of descaling is calculated by the coffee machine and depends on the degree of hardness of the local mains water and whether or not a water filter is fitted. The maintenance date is based on the degree of use of the coffee machine and is shown on the display. The coffee machine may continue to be operated after the message, but Customer Care or contract maintenance should be carried out promptly to ensure correct functioning and so as to avoid any consequent damage.

7.1 Coffee machine maintenance

The following care or maintenance stages are provided:

- Customer Check-up after the display message; may be undertaken by the user / operator.
- Maintenance 1 / maintenance 2 after the display message; may only be undertaken by trained personnel or by WMF Service, as in this instance components affecting safety must be replaced.
- Revision after the display message; may only be undertaken by trained personnel or by WMF Service, as in this instance components affecting safety must be replaced.



Descaling
▷ Software ▷ Care
page 24



Customer Check-up after the display message see Customer Check-up Instructions in Customer Check-up Kit.
▷ Accessories and spare parts
page 64

Service maintenance message
▷ Messages and instructions
page 48



For other maintenance work and repairs, please contact your local WMF Service.
The telephone number can be found on the address sticker on the coffee machine and on the delivery note.

7.2 WMF Service

You can reach the WMF Service Center if the local service point is not known.

WMF AG
Eberhardstraße
D - 73309 Geislingen (Steige)



Chapter 8 Messages and instructions


8.1 Messages for operation

Error message

(▷ Software ▷ Settings ▷ Operating options)

normal: all messages are shown on the display.

Symbol: messages that require immediate action are shown on the display.

All other messages are displayed as symbol .

✱ Touch the  symbol

All messages are displayed.



With illumination (optional):
messages that require immediate
action are accompanied by
flashing side illumination.

Refill beans


✱ Top up bean hopper (refer to display)


✱ Check:

- Is the product hopper lock open?

▷ Care

- Beans do not feed through

✱ Stir with a large spoon and confirm with 



Empty milk message

✱ Refill milk



Empty grounds container

✱ Empty grounds container




Grounds container missing

✱ Replace grounds container correctly and close adjustable screen



Grounds container emptied?

✱ Confirm that the grounds container has indeed been emptied




Manual insert open

✱ Close the manual insert



Open water supply valve

- * Turn on water mains supply and confirm



Brewing unit error


- * Remove brewing unit
- * Clean brewing sieve
- * Replace brewing unit and ensure that it engages correctly in the lock



Error message with error number

Error number is displayed.

▷ Error messages / malfunctions



Error message with error number


Error number is displayed.

- * Call WMF Service



Change filter

- * Change filter within one week
 - * Confirm the change in the Care menu
- Follow water filter instructions.*



Cleaning message – clean soon

- * Clean the coffee machine soon
- The message is also displayed in the Information pad.*



Cleaning message – clean now

- * Clean the coffee machine now
- The message is also displayed in the Information pad.
Cleaning required. The coffee machine can only be used after the cleaning operation.*



Descaling Message

- * Call WMF Service



Customer check-up message

- * Carry out Customer Check-up within one week
- * Confirm execution in the Care menu



Maintenance message

✱ Call WMF Service



Heating up

The coffee machine can heat up



Ready to operate

The display illumination can be activated.



Beverage dispensing



Warm rinsing

The coffee machine performs a warm rinsing operation.



Activate "Ready to operate" display

✱ Touch the unlit menu pad for longer than 5 seconds

The display illumination switches on.


Menu pad, Information pad, error messages and cleaning messages are displayed.

▷ "Ready to operate" display



Optional pads

The Barista pad, "warm rinse" pad and the "shift pad" are displayed. The various options must first be activated.



Optional

Display "warm rinse" pad and Barista pad

8.2 Error messages and malfunctions

Basic procedure on display of error messages or malfunctions.

- * Switch coffee machine off and then on again after a few seconds
- * Repeat the process which led to the error


In many cases, this eliminates the malfunction and you can continue working.

If this is not successful: find the error message or error number in the following error list and follow the sequence of actions indicated.

If this does not rectify the error or if the error indicated is not listed please call WMF Service.


Some messages lead to blocking of individual functions. You will notice this by the fact that the beverage button illumination goes out. The beverage buttons that are still illuminated can continue to be used.

Your WMF 1800 S is provided with a diagnostics program. Any errors that occur are shown on the display. The error messages listed may also be caused by an interruption to the mains electricity supply.

If there is a current error or a message to the operator, the  pad is displayed.

- * Touch 

Error number is displayed.

Error number	Error description	Action instructions
6	Brewing unit lockup current / brewing unit stiff	<ul style="list-style-type: none"> * Switch off the coffee machine * Clean the brewing unit <p>▷ Care ▷ Brewing unit cleaning, page 40</p>
26 36	Right grinder blocked Left grinder blocked 	<ul style="list-style-type: none"> * Switch off the coffee machine * Disconnect mains plug * Remove bean hopper * Turn grinder disk counter-clockwise using only Multitool (square button) (see illustration) * Replace hopper * Switch on the coffee machine <p>▷ Care ▷ Bean hopper cleaning, page 42</p> <p>If this occurs frequently:</p> <ul style="list-style-type: none"> * Set grinding degree one stage coarser <p>▷ Other settings ▷ Set grinding degree, page 35</p>
88	Boiler: over-temperature	Beverage dispensing temporarily blocked. <ul style="list-style-type: none"> * Check that mains tap is on or that the water tank is filled and inserted correctly <p>If still not OK:</p> <ul style="list-style-type: none"> * Switch off the coffee machine * Clean the brewing unit <p>▷ Care ▷ Brewing unit cleaning, page 40</p> <ul style="list-style-type: none"> * Switch on and try again <p>(Release follows when cooled down to normal temperature).</p> <ul style="list-style-type: none"> * Switch off the coffee machine, allow to cool and switch on again
89	Boiler: heat-up time error	<ul style="list-style-type: none"> * Switch off the coffee machine and on again
161	Flow error: brewing water	<p>Between each of the following steps switch off the coffee machine and on again. If error not remedied carry out the next step.</p> <ul style="list-style-type: none"> * Check that mains tap is on or that the water tank is filled and inserted correctly * Clean the brewing unit <p>▷ Care ▷ Brewing unit cleaning, page 40</p> <ul style="list-style-type: none"> * Set grinding degree coarser <p>▷ Other settings ▷ Set grinding degree, page 35</p> <ul style="list-style-type: none"> * Reduce quality <p>▷ Settings ▷ Recipes, page 26</p>



Error number	Error description	Action instructions
163	Flow error: warm rinsing	<i>Between each of the following steps switch off the coffee machine and on again. If error not remedied carry out the next step.</i> <ul style="list-style-type: none">* Check that mains tap is on or that the water tank is filled and inserted correctly* Clean the brewing unit <i>▷ Care ▷ Brewing unit cleaning, page 40</i>
186	Steam boiler: level	<i>Beverage dispensing temporarily blocked.</i> <ul style="list-style-type: none">* Check that grounds container is correctly inserted* Switch off the coffee machine and on again
188	Heater error	<ul style="list-style-type: none">* Switch off the coffee machine, disconnect mains plug* Call WMF Service
189	Steam boiler: heat-up time error	<ul style="list-style-type: none">* Switch off the coffee machine and on again

8.3 Errors without error message

Error pattern	Action instructions
No hot water dispensing but water in grounds container	<ul style="list-style-type: none"> * Clean hot water spout * Call WMF Service (coffee dispensing possible)
No Choc or Topping dispensing but water in grounds container	<ul style="list-style-type: none"> * Do not use Choc or Topping dispensing * Call WMF Service (coffee dispensing possible)
Choc or Topping portioner blocked, Choc or Topping dispensed only with water	<ul style="list-style-type: none"> * Clean portion controller ▷ <i>Care ▷ Product hopper cleaning, page 42</i> * Empty powder * Turn dosing auger manually until all powder is removed * If necessary rinse with water * (Allow to) dry completely
Coffee dispensing on the left / right differs	<ul style="list-style-type: none"> * Clean the combi spout ▷ <i>Cleaning instructions</i>
No milk foam / milk output, but milk in milk container	<ul style="list-style-type: none"> * Check whether the milk hose is kinked or squashed * Re-route milk hose correctly * Clean the combi spout * Check whether milk nozzle is blocked ▷ <i>Cleaning instructions</i>
Milk foam incorrect, temperature too cold or too hot	<ul style="list-style-type: none"> * Change milk nozzle <ul style="list-style-type: none"> - green milk nozzle for cooled milk - white milk nozzle for uncooled milk * Clean the combi spout ▷ <i>Cleaning instructions</i>
Pump runs continuously, water in grounds container	<ul style="list-style-type: none"> * Switch off the coffee machine and on again * If error not remedied call WMF Service
Milk foamer and water tank: assembly / disassembly stiff	<ul style="list-style-type: none"> * Lightly smear the O-rings with WMF gasket grease ▷ <i>Instructions in Customer Check-up Kit.</i>
Choc / Topping hopper cannot be replaced	<ul style="list-style-type: none"> * Manually turn the drive for the dosing auger at the portion controller slightly in a clockwise direction

Chapter 9 Safety

9.1 Hazards to the operator

At WMF, safety is one of the most essential product features. The effectiveness of safety devices can only be ensured if the following points are observed:

- Read the User Manual carefully prior to use.
- Do not touch hot machine components.
- Do not use the coffee machine if it is not working properly or if it is damaged.
- Use the coffee machine only when it is completely assembled.
- Built-in safety devices must never be altered.
- This device is not designed for persons (including children) with limited physical, sensory, or mental capabilities or who lack the required experience and/or knowledge, unless they are supervised by a person responsible for their safety or have received instructions from them about how the device should be used.
- Children should be supervised to ensure that they do not play with the device.

Despite the safety devices, every coffee machine poses hazard potential if incorrectly used. Please observe the following instructions when using the coffee machine so as to prevent injury and health hazards:

Scalding hazard.

When dispensing coffee, Choc / Topping, hot water and steam there is hazard of scalding in the dispensing area. Ensure that there is always a cup under the spout when dispensing beverages.

Burn hazard.


The brewing unit must be cleaned only when the coffee machine is cold. The brewing unit can get hot.





Caution.
Failure to follow safety instructions can result in death or serious injury.

Follow the safety instructions.




Caution.
Hot liquids in the dispensing area.

Scalding hazard.



Caution.
Hot steam.

Burn hazard.



Caution.
Hot surfaces.

Burn hazard.

Bruising or crushing hazard.

There is a bruising or crushing hazard when handling all moving parts. Do not reach into the bean hopper or the brewing unit opening when the coffee machine is switched on.



Caution.
Bruising or crushing
hazard.

Risk of injury.

Health hazard.

The product hoppers (coffee beans / Choc / Topping) and manual insert may only be filled with materials for the use intended.



Caution.
Health hazard.

Only use as intended.

Health hazard.

When handling special cleaners for the milk foamer, cleaning tablets, and the descaling solution, follow the protective measures on the packaging. The special cleaners for the milk foamer and cleaning tablets are irritants. Only put in cleaning tablet or descaling solution after the display message.



Caution.
Health hazard.

**Follow the instructions of the
label on the cleaning agents.**

Irritation and scalding hazard.

Never reach under the spouts while cleaning / descaling. Cleaning fluid / descaling solution runs out of the combi spout when cleaning / descaling.



Caution.
Health hazard.

**Irritation and scalding hazard
in the dispensing area.**

Slipping hazard

Fluids can be discharged from the coffee machine if used improperly or if errors occur. These fluids can cause a slipping hazard.



Caution.
Slipping hazard if fluids
are discharged

Slipping hazard

9.2 Hazards to the coffee machine

Please observe the following instructions so as to prevent problems with and damage to the coffee machine:

- For water with carbonate hardness in excess of 5 °dKH, a WMF water filter must be fitted; otherwise, the coffee machine can be damaged due to build-up of scale.
- For insurance reasons always ensure that, at the end of operation, the mains tap for the water supply is turned off and the mains plug is unplugged.

- We recommend damage prevention measures such as:
 - installation of a suitable water monitor in the mains water supply
 - installation of smoke alarms
- After shut off for several days we recommend running the cleaning program at least twice before reusing the machine.

▷ *Cleaning instructions*

9.3 Intended use

The WMF 1800 S is designed to dispense coffee beverages, milk beverages and/or powdered beverages (Choc and Topping) in various variations into cups or pots. In addition, the device can generate steam for heating milk and dispensing hot water. This device is also intended for industrial and commercial use and for use by professionals and trained users in shops in the consumer goods industry and agricultural holdings, or for the commercial use by non-professionals. The device can be used as a self-service device if it is supervised by trained personnel.

The use of the device is also subject to the "General Terms and Conditions" of WMF AG and this User Manual. Any other use or use that goes beyond the aforementioned is considered incorrect use. The manufacturer shall not be liable for any damage resulting from this.

Under no circumstances may the WMF 1800 S be used to dispense and heat liquids other than coffee, hot water (beverages, cleaning) or milk (cooled, pasteurised, homogenised, UHT).

9.4 Directives

The device fulfils the requirements of the German Food and Feed Code (LFGB), the Regulation on Commodities (BedGgstV), the EU regulation No. 10/2011 as well as the EU regulation No. 1935/2004 in the currently valid editions.

When used properly, the device does not present a health hazard or other unreasonable hazard.

The materials and raw materials used fulfil the requirements of the Regulation on Commodities as well as the EC regulations No. 10/2011.

The device fulfils the requirements of all applicable regulations in the directives MD (MR) 2006/42/EC (EG), Directive 2004/108/EC (EMV), Directive 2011/65/EC (ROHS), Directive 2002/96/EC (WEEE).

The EC declaration of conformity is included with the device. The device bears the CE mark.

Any modifications that are not approved by WMF will cause this declaration to become invalid. Currently valid national rules apply in countries outside of the European Union.

This device is subject to the directive on waste electrical and electronic equipment (WEEE / EU directive) and may not be disposed of as domestic waste.



*For disposal, contact WMF Service.
Address ▷ page 47*

Requirements traceability pursuant to EC regulation No. 1935/2004 and Good Manufacturing Practice within the meaning of EC regulation No. 2023/2006 are ensured and guaranteed.

9.5 Duties of the owner / operator

The operator of such equipment must ensure regular maintenance by WMF Service technicians, their agents or other authorised persons, and checking of safety devices.

Access to the service area is permitted only for persons with knowledge and practical experience with the device, especially regarding safety and hygiene.

The coffee machine must be set up by the operator such that care and maintenance can be performed without hindrance.

In office / floor supply or similar self-service applications, only staff instructed in operation of the coffee machine should supervise the coffee machine. Trained personnel should carry out care procedures and be available for questions regarding use.

The operator shall ensure that electrical equipment and operating facilities are in a fit state (e.g. to BGV A3) [German Accident Prevention Association or equivalent]. In order to ensure the operating safety of your coffee machine, it is essential to perform regular checks of the safety valves and the pressure containers, among other checks. These measures are conducted by WMF Service or by WMF authorised service personnel as part of the maintenance work.

Machine cleaning must be carried out using only the WMF special cleaning agent intended by WMF for the coffee machine (tablets), and for the milk system (cleaning liquid).

*WMF special cleaning agent,
▷ Appendix
Accessories and spare parts
page 64*

The manufacturer's specifications regarding maintenance cycles and frequency of maintenance (▷ Maintenance) must be observed.

9.6 Warranty claims

During the warranty period of 12 months from transfer of risk, the purchaser has statutory warranty entitlements. The vendor should always be afforded the opportunity to rectify errors within an appropriate period.

Claims that exceed the above terms, in particular damage claims as a result of consequential damage, are excluded to the extent that this is legally permissible.

Material defects shall be reported to the vendor immediately and in writing.

No warranty is provided:

- On any parts subject to natural wear and tear. This includes seals, mixers, and brewing unit, among other items.
- For malfunctions due to the effect of the weather, scale build-up, chemical, physical, electrochemical or electrical effects, unless attributable to a fault on the part of WMF.
- If a water filter is not fitted even though the local water supply requires use of a water filter and malfunctions occur as a consequence.
- With respect to faults which occur as a result of failure to follow handling instructions and regulations, maintenance and care of the device (e.g. User Manual and maintenance instructions).
- With respect to faults which occur as the result of failure to use original WMF spare parts or incorrect assembly by the purchaser or by third parties or by faulty or negligent treatment.
- With respect to the consequences of improper modifications undertaken without our consent or by repair or reconditioning work on the part of the purchaser or by third parties.
- With respect to faults caused by inappropriate or improper use.

▷ Instructions in Customer Check-up Kit.



The customer is advised in the order confirmation whether or not use of a water filter is required.



▷ Maintenance
page 46

Cleaning instructions 1800 S

Please refer to the User Manual.
 Follow the overview of the cleaning interval schedule in the Care chapter in the User Manual.
 Print out the first cleaning, read the User Manual, Care chapter.

1800S

Standard Cleaning Program

 1 Press button 1 0.5 l of clear, cold water	 2 Press button 2 0.5 l of clear, cold water	 3 Press button 3 0.5 l of clear, cold water	 4 Press button 4 0.5 l of clear, cold water	 5 Press button 5 0.5 l of clear, cold water
<p>⊗ Touch 200</p> <p>⊗ Open the manual insert</p> <p>⊗ Pour 0.5 l of clear, cold water</p>	<p>⊗ Touch 200</p> <p>⊗ Insert milk hose</p> <p>⊗ Touch 200</p>	<p>⊗ Touch 200</p> <p>⊗ Frame cleaning reminder appears on display</p> <p>⊗ Touch 200</p>	<p>⊗ Touch 200</p> <p>⊗ Frame cleaning reminder appears on display</p> <p>⊗ Touch 200</p>	<p>⊗ Touch 200</p> <p>⊗ Frame cleaning reminder appears on display</p> <p>⊗ Touch 200</p>

Water cleaning

 1 Press button 1 0.5 l of clear, cold water	 2 Press button 2 0.5 l of clear, cold water	 3 Press button 3 0.5 l of clear, cold water	 4 Press button 4 0.5 l of clear, cold water	 5 Press button 5 0.5 l of clear, cold water
<p>⊗ Touch 200</p> <p>⊗ Open the manual insert</p> <p>⊗ Pour 0.5 l of clear, cold water</p>	<p>⊗ Touch 200</p> <p>⊗ Insert milk hose</p> <p>⊗ Touch 200</p>	<p>⊗ Touch 200</p> <p>⊗ Frame cleaning reminder appears on display</p> <p>⊗ Touch 200</p>	<p>⊗ Touch 200</p> <p>⊗ Frame cleaning reminder appears on display</p> <p>⊗ Touch 200</p>	<p>⊗ Touch 200</p> <p>⊗ Frame cleaning reminder appears on display</p> <p>⊗ Touch 200</p>

Milk rinsing

 1 Press button 1 0.5 l of clear, cold water	 2 Press button 2 0.5 l of clear, cold water	 3 Press button 3 0.5 l of clear, cold water	 4 Press button 4 0.5 l of clear, cold water	 5 Press button 5 0.5 l of clear, cold water
<p>⊗ Touch 200</p> <p>⊗ Open the manual insert</p> <p>⊗ Pour 0.5 l of clear, cold water</p>	<p>⊗ Touch 200</p> <p>⊗ Insert milk hose</p> <p>⊗ Touch 200</p>	<p>⊗ Touch 200</p> <p>⊗ Frame cleaning reminder appears on display</p> <p>⊗ Touch 200</p>	<p>⊗ Touch 200</p> <p>⊗ Frame cleaning reminder appears on display</p> <p>⊗ Touch 200</p>	<p>⊗ Touch 200</p> <p>⊗ Frame cleaning reminder appears on display</p> <p>⊗ Touch 200</p>

WMF

1800S

1800S

Standard Cleaning Program

 1 Press button 1 0.5 l of clear, cold water	 2 Press button 2 0.5 l of clear, cold water	 3 Press button 3 0.5 l of clear, cold water	 4 Press button 4 0.5 l of clear, cold water	 5 Press button 5 0.5 l of clear, cold water
<p>⊗ Touch 200</p> <p>⊗ Open the manual insert</p> <p>⊗ Pour 0.5 l of clear, cold water</p>	<p>⊗ Touch 200</p> <p>⊗ Insert milk hose</p> <p>⊗ Touch 200</p>	<p>⊗ Touch 200</p> <p>⊗ Frame cleaning reminder appears on display</p> <p>⊗ Touch 200</p>	<p>⊗ Touch 200</p> <p>⊗ Frame cleaning reminder appears on display</p> <p>⊗ Touch 200</p>	<p>⊗ Touch 200</p> <p>⊗ Frame cleaning reminder appears on display</p> <p>⊗ Touch 200</p>

Water cleaning

 1 Press button 1 0.5 l of clear, cold water	 2 Press button 2 0.5 l of clear, cold water	
--------------------------------------------------------------	--------------------------------------------------------------	--

Appendix: Technical data

Technical data for coffee machine

Nominal power rating * (depending on the special model)	3 kW (2.75 kW–3.25 kW *)
Recommended daily capacity espresso, café crème	up to 180 cups per day
Overall hot water output	approx. 20 liters per hour
Coffee bean hopper	left and right each approx. 1 000 g middle approx. 550 g
Choc / Topping hopper	approx. 1 000 g
Twin Choc / Topping hopper	twice approx. 500 g
Mains power connection *	1/N/PE 230 V 50 Hz
Illumination	LED class 1
External dimensions	Width 326 mm Height incl. bean hopper 680 mm Depth 556 mm
Weight empty	approx. 33–43 kg (depending on the model)
Continuous sound pressure level (Lpa) **	< 70 dB(A)

We reserve the right to make technical modifications.

* For special models see model label, values given above are for the basic model.

** A-evaluated sound pressure level Lpa (slow) and Lpa (impulses) at operating personnel workplace is under 70 dB(A) in any working mode.

Conditions for usage and installation

Necessary on-site preparatory work for electricity, water and drainage connections at the customer's premises are to be arranged by the machine owner / operator. The work must be carried out by authorised installation technicians in compliance with general, country-specific and local regulations. The WMF service engineers may only connect the coffee machine to existing prepared connection points. WMF Service is neither authorised nor responsible for carrying out any on-site installation work prior to connection. The potential equalization terminal is installed by WMF Service if needed.

Mains voltage tolerance range	230 V +6% and -10 %, Mains voltage interruption < 50 ms: no interruption of function
Water supply	3/8 inch hose connector with mains tap, and filter with 0.2 to 0.25 mm mesh size, on site. Min. 0.2 MPa flow pressure at 2 litres / minute, max. 0.6 MPa. Water temperature max. 35 °C. The set of hoses provided with the new coffee machine and/or the new water filter must be used. Do not use old hoses.
Water quality	For drinking water with carbonate hardness above 5 °dKH, a WMF water filter should be fitted upstream.
Water drain tube	Tube a minimum of DN 19, minimum downward slope of 2 cm/m
Ambient temperature	+5 °C to max. +35 °C (empty the water system in case of frost).
Maximum humidity	80 % relative humidity without condensation. Do not use device outdoors.
Degree of protection	IP X0
Installation surface	The device must be placed on a level, flat, and sturdy surface. The device is not intended to be located on a surface that is sprayed or cleaned with a water hose, steam jets, steam cleaner, or similar devices.
Installation clearances	For operating, service and safety reasons the machine should be installed with a clearance of not less than 50 mm at the back and sides from the building or non-WMF components. A minimum working space of 800 mm in front of the coffee machine is recommended. A clear height of 1,100 mm from the top of the supporting surface should be ensured. The height of the installation surface above the floor is at least 850 mm. If the coffee machine connections are to be run downwards through the counter, please make space for the lines, which can reduce the usable space below the machine.
Installation dimensions of the water filter	See the User Manual for the water filter.

These specifications for the electrical connection and the standards quoted apply for connecting the coffee machine in EU countries. It may be necessary to also observe additional country-specific regulations. Outside the EU countries, acceptance of the standards quoted is to be checked by the legal entity or natural person who wishes to use the coffee machine.

The local power supply must be constructed according to IEC 364 (DIN VDE 0100). To improve safety, the device should be fitted with an FI 30 mA earth leakage current circuit breaker complying with EN 61008. (Type B residual current circuit breakers provide reliable tripping even if the fault current is smooth. This ensures a high level of safety.) Near the device or about 30 cm below the counter top there should be a shockproof socket as a single-phase connection installed locally on the rear or side wall of the counter substructure or a country-specific single-phase socket. If the mains cable for this device is damaged then it must be replaced by our service personnel or a similarly qualified person, in order to prevent hazards. The mains cable must not come into contact with hot surfaces. The mains switch and plug top are part of the on-site installation. The coffee machine may not be fitted with a fixed permanent mains connection if installed on a transporting trolley (a mobile station).

In order to avoid possible faults from arising on our shielded data lines due to potential equalisation currents between the devices, an additional potential equalisation unit should be planned for devices connected to the vending system. (See EN 60309)

Appendix: Accessories and spare parts

Number	Unit	Designation	Order No.	Model
Complete combi spout Choc				
1	Pcs	Single spout	33 2549 0000	all
1	Pcs	Steam nozzle compl. with seal Ø 2.3 (2.9 KW)	33 2864 3300	
1	meter	Milk hose	00 0048 4948	all
1	Pcs	Milk hose spring	33 0190 3000	all
1	Pcs	Milk hose sleeve	33 2180 5000	all
Choc / Topping mixer				
0,25	meter	Mixer hose	00 0048 0064	Choc / Topping
1	Pcs	Mixer hose spring	33 2292 6000	Choc / Topping
1	Pcs	Mixer bowl	33 2318 0000	Choc / Topping
Constant water supply, drainage				
1	Pcs	Connecting tube for constant water supply	33 2292 1000	all
1	Pcs	Angle for drain tube	33 2165 8000	all
1,5	meter	Drain tube	00 0048 0042	all
Accessories / tools				
1	Pcs	Multitool	33 2323 1000	all
Documentation / instructions				
1	Pcs	Set of documents: • User Manual WMF 1800 S • Cleaning instructions WMF 1800 S	33 2552 0010	all
Complete bean hopper				
1	Pcs	Large bean hopper	33 2851 2099	all
1	Pcs	Large bean hopper lid	33 2806 3100	all
1	Pcs	Closing plate	33 2265 5000	all
1	Pcs	Medium bean hopper	33 2854 2000	all
1	Pcs	Medium bean hopper lid	33 2854 3000	all

Number	Unit	Designation	Order No.	Model
Product hopper Choc / Topping				
1	Pcs	Choc product hopper	33 2845 4199	Choc
1	Pcs	Topping product hopper	33 2845 4299	Topping
1	Pcs	Product hopper lid Choc / Topping	33 2806 3100	Choc / Topping
1	Pcs	Twin Choc product hopper	33 2845 4399	Twin Topping
1	Pcs	Twin Topping product hopper	33 2845 4099	Twin Topping
1	Pcs	Product hopper lid Twin Choc / Twin Topping	33 2806 4100	Twin Topping
1	sheet	Labels for product hopper	33 2315 3000	all
Coffee grounds container				
1	Pcs	Coffee grounds container	33 2272 4000	all
Brewing unit				
1	Pcs	Brewing unit	33 2823 6199	all
Drip tray / drip grid				
1	Pcs	Drip tray (standard)	33 2254 9000	all
1	Pcs	Drip tray (when using an integrated or under-counter cooler)	33 2254 9200	all
1	Pcs	Drip grid	33 2465 8000	all
1	Pcs	Cup stop	33 9394 2200	all
Potential equalization terminal				
1	Pcs	Angle	33 2107 1100	
1	Pcs	Toothed wheel	00 0047 2257	
1	Pcs	Flathead screw M6X16	00 0047 3414	
1	Pcs	Hex nut	00 0047 2055	
Customer Check-up Kit				
1	Pcs	Customer Check-up Kit	33 2861 7000	all
Scale filter / water filter				
1	Pcs	Water filter Bestmax M (complete kit)	03 9331 0001	all
1	Pcs	Replacement cartridge for water filter	33 2426 5000	all
Order numbers for the WMF care program				
1	bottle	WMF Special cleaner for milk foamer	33 0683 6000	all
1	pack	Special cleaning tablets (100 pieces)	33 2332 4000	all
1	Pcs	Pipe cleaner	33 0350 0000	all
1	Pcs	Cleaning brush	33 1521 9000	all
1	tube	WMF Molykote "gasket grease"	33 2179 9000	all

Index

A

Access control 33
Accessories and spare parts 64
Accounting level 33
Accounting numbers of beverages 34
Additions 27
Adjustable additions 27

B

Barista pad 16, 18, 30
Bean hopper 7
Bean hopper cleaning 42
Beverage buttons 26
Beverage dispensing 10
Boiler temperature 28
Brewing unit cleaning 40
Brewing unit error 49
Brew time 19
Button allocation 28

C

Call up the main menu 8
Capacity 29
Care 18, 24, 36
Care message 16
Change recipes 26
Choc hopper 7
Choc powder quantity 26
Cleaning instructions 60
Cleaning intervals overview 36
Cleaning level 33
Cleaning metal surfaces 38
Cleaning program 24, 37
Cleaning schedule 44
Coffee bean hopper 61
Coffee machine maintenance 46
Combi spout cleaning 38
Conditions for usage and installation 61
Connect up the milk 11
Cooler adapter 11
Cool milk 11, 45
Copy day 22
Cup&Cool 11
Cup volumes 26

D

Daily cleaning 37
day counter 34
Delete counter 34
Delete PIN 34
Delete timer 23
Diagnostics program 51
Dispense milk or milk foam 10
Display contrast 29
Display language 29
Display switching times 22
Drip tray 15
Drip tray, housing and front panel 38
Duties of the owner / operator 58

E

ECO-mode 32
Electrical connection 62
Empty grounds container 48
Empty milk message 31
Error list 51
Error message 16, 49, 51
Error messages 51
Errors without error message 54

F

Filter change 25, 43
Foamer cleaning 24
Foamer rinsing 29

G

Glossary 8
Ground coffee quantity 26
Grounds container cleaning 38
Grounds container missing 48

H

HACCP cleaning schedule 44
Hazards to the coffee machine 57

I

Information 16, 18
Introduction 6

J

Journal 19

L

Labelling of beverage buttons 35
Latte macchiato 20
Latte macchiato pause interval 20

M

Main menu 16, 20
Main menu functions (pads) 17
Maintenance 46
Malfunctions 51
Manual insert 13
Mechanical settings 35
Menu control pads 17
Menu pad 30
Messages and instructions 48
Milk and foam 20
Milk container 38
Milk foam dispensing 10
Milk foam quality 20
Milk foam volume 26
Milk nozzle 11
Milk system rinsing Standard 38
Milk volume 26
Mixer cleaning 39
Mixer rinsing 25, 38
Multitool 35

N

No warranty is provided 59

O

ON/OFF switch 30
Open water supply valve 49
Operating options 29, 30
Operation 10
Original WMF spare parts 59
Other settings 35

P

Parts of the coffee machine 6
PIN entry 32
PIN rights 33
Potential equalization terminal 61
Preparation of ground coffee using the manual insert 13

Q

Quality 27

R

Read counter 34
Ready to operate 16, 18
"Ready to operate" display pads 16
Recipes and buttons 26
Recommendation for Choc and Topping 45
Refill beans 48
Regular cleaning 40
Reset 28
Rinse filter 25
Rinsing interval 29

S

Safety devices 55
Sanitize milk system 44
SB mode (self-service mode) 31
Scale filter is fitted 29
Second level 30
Self-service 30, 31
Sequence of dispensing 27

Sequence of ingredients additions 27
Service 18
Set grinding degree 35
Set timer 21
Setting level 33
Settings 26
Shift pad 30
Software 16
Switch off 15
Switch off time 21, 22
Switch on the coffee machine 10
Switch on time 21, 22

T

Tablet insert 7
Technical data 61
Time and date 28
Timer 19, 21
Timer information 23
Timer overview 22
Timer program 21
Timer state 21
Topping hopper 7
To the main menu 19
Touch-screen display 7
Twin Topping 9
Twin Topping hopper 7, 12

U

User Manual Signs and Symbols 8
User Manual Symbols 8

W

"Warm rinse" pad 18, 29, 30
Warm rinsing 16
Warm-up rinsing 29
Warranty claims 59
Water filter 25, 43, 46, 59
Water filter rinsing 25
Water hardness 29
Weekly cleaning 39
Weigh grounds 28
WMF Service 47



Your nearest WMF Service:

© 2011–2012 WMF AG

All rights reserved, in particular duplication, distribution and translation rights.
No part of this manual may be reproduced in any form or processed, duplicated or distributed using electronic systems without written consent.

Design and production / typesetting and print presentation:
TecDoc GmbH; Geislingen, info@tecdocgmbh.de

Original User Manual. Printed in Germany.

We reserve the right to make technical modifications.

21.01.2013

I800S