

The logo for Sefram, featuring the word "Sefram" in a white, sans-serif font on a red rectangular background. Below the red background is a thin grey horizontal line.

**Sefram**

**RECORDERS**

**DAS1600 – DAS800**

**INSTRUCTION MANUAL**

Edition December 2013

M1600001A/1

Thank you for buying a SEFRAM recorder and for your trust in our company. The main goal of our various teams (engineering office, production, commercial, after sales...) is to meet your requests as much as possible while designing and updating high-tech products.

You will find with a recorder a CD-ROM including:

The instruction manual of the DAS1600 and DAS800 recorders  
The "SeframViewer" software for printing and treating record files under Windows®

We ask you to read carefully this instruction manual for an optimal use of your recorder.

For any additional information, our teams are at your disposal:



Sales service e-mail: [sales@sefram.fr](mailto:sales@sefram.fr)

After-sales service e-mail: [sav@sefram.fr](mailto:sav@sefram.fr)

Technical support e-mail: [support@sefram.fr](mailto:support@sefram.fr)

Fax: +33 (0)4 77 57 23 23

Web: [www.sefram.fr](http://www.sefram.fr)



Copyright Sefram, 2006. All rights reserved  
Any copy of this document, total or partial, requires the authorization by Sefram.

## **GUARANTEE**

Your instrument is guaranteed for two years for labor and parts against any manufacturing defect and/or functioning hazard. This guarantee extends from the delivery date and ends 730 calendar days later.

In case of guarantee contract, this will cancel or replace these guarantee conditions hereabove.

The guarantee conditions by SEFRAM are available on the website [www.sefram.com](http://www.sefram.com). The general guarantee conditions should prevail on the following conditions that they sum up.

This guarantee does not cover the result of any abnormal use, handling mistake or mistake in the storage conditions outside the defined range.

In case of application of the guarantee, the user shall return, at its own expenses, the relevant appliance to our factory:

SEFRAM Instruments & Systèmes  
Service Après-Vente  
32, Rue Edouard MARTEL  
BP 55  
42009 SAINT-ETIENNE CEDEX 2

And add a description of the observed breakdown to the appliance.

The standard supplies provided with the appliance (cables, outlets...), the consumables (batteries ...) and the optional supplies (suitcases...) are guaranteed for 3 months against any manufacturing defect.

Such items as a LCD screen or a touchpad are guaranteed only for a normal use.

The guarantee does not cover wearing, accidental breaks or consecutive to a shock or any abnormal use.

The factory options integrated to the appliance are guaranteed for the same duration as the appliance itself.

In case of replacement or repair of the product, the remaining guarantee duration shall be:

- The remaining duration of the guarantee if the appliance is still under guarantee
- If the guarantee duration is less than 90 days, the replaced part is guaranteed for 90 days

Any replacement part becomes the property of the user and the exchanged parts become the property of SEFRAM.

In case of intervention by an insurance company, the product becomes the property of the insurance company upon its exclusive request. Else, it shall remain property of the user.

The guarantee covers exclusively the materials manufactured and provided by SEFRAM.

Any intervention by the user or any third party without prior authorization by the company voids the guarantee.

The user shall be responsible for the return of its appliance to our site. Hence, it shall provide for a conditioning that shall correctly protect the appliance while shipping. It shall subscribe, at its own expenses, any insurance required for the transport.

The SEFRAM company reserves the right to refuse any product wrongly conditioned and not to take in charge any break consecutive to the transport.

Particular case of the battery: There is a Li-ion battery as a standard equipment of this appliance. It shall not be transported outside the appliance. In no case shall the user replace it. Its replacement in the factory is necessary to check the charge system and the protective securities.

### **What to do in case of malfunction?**

In case of malfunction or for any advice for use, please contact the technical support by SEFRAM Instruments & Systèmes: 0825 56 50 50 / 2

A technician shall answer you and give you any information required to solve your problem.

### **What to do in case of failure?**

In case of failure of your appliance, please contact the technical support: 0825 56 50 50 / 2

### **Some advice!**

### **Some technical help!**

SEFRAM Instruments & Systèmes commits itself to help you on the phone about the use of your appliance.

Please call or Technical Support:



Or e-mail:

[support@sefram.fr](mailto:support@sefram.fr)

We thank you for your trust.

# CONTENT

<b>1. IMPORTANT INFORMATION.....</b>	<b>1.1</b>
1.1. PARTICULAR PRECAUTION MEASURES .....	1.1
1.2. SECURITY INSTRUCTIONS.....	1.2
1.3. SYMBOLS AND DEFINITIONS.....	1.2
1.4. CONFORMITY AND LIMITATIONS OF THE APPLIANCE.....	1.3
<b>2. PRESENTATION.....</b>	<b>2.1</b>
2.1. GENERAL.....	2.1
2.2. DESCRIPTION.....	2.2
2.2.1 Rear or upper side.....	2.2
2.2.2 Edge side.....	2.4
2.3. LCD SCREEN .....	2.5
2.3.1. Description of the screen.....	2.5
2.3.2. Bar graph patterns.....	2.6
2.4. SCREEN KEYS.....	2.7
2.5. . UPDATING THE INTERNAL SOFTWARE.....	2.9
<b>3. SET-UP AND PRECAUTIONS OF USE.....</b>	<b>3.1</b>
3.1. PRECAUTIONS FOR STORAGE OF THE RECORDS .....	3.1
3.2. POWER .....	3.1
3.2.1. Fuse.....	3.3
3.2.2. Turning on the DAS1600 – DAS800.....	3.3
3.3. CONFIGURATION AT START-UP.....	3.3
3.4. CONNECTION TO THE MEASUREMENT NETWORKS .....	3.4
3.4.1. Voltage measurement.....	3.4
3.4.2. Temperature measurement with a thermocouple .....	3.4
3.4.3. Gauge strain measurement.....	3.5
3.4.4. Temperature measurement with PT100 and PT1000.....	3.7
3.4.5. Intensity measurement.....	3.8
3.4.6. Earth.....	3.8
3.5. ROUTINE MAINTENANCE.....	3.10
3.6. CALIBRATION OF THE OFFSETS .....	3.11
3.7. DEFAULT SETUP.....	3.11
3.8. EXPERT MODE.....	3.12
3.9. KEYBOARD LOCKING .....	3.12
<b>4. USE.....</b>	<b>4.1</b>
4.1. « MODE MEMORY » KEY .....	4.1

4.2.	« MODE FILE » KEY .....	4.1
4.3.	« GO/NO-GO » KEY .....	4.2
4.4.	« USER MANUAL » KEY .....	4.2
4.5.	« POWER ANALYSIS » KEY .....	4.2
4.6.	« SETUP ANALYZER » KEY .....	4.2
4.7.	« SETUP » KEY .....	4.3
4.7.1.	<i>Analogical channels</i> .....	4.6
4.7.2.	<i>Functions between channels</i> .....	4.10
4.8.	« LOGIC CHANNELS » KEY .....	4.17
4.9.	« VALIDITY » KEY .....	4.18
4.10.	« F(T) » KEY .....	4.19
4.11.	« XY » KEY .....	4.22
4.12.	« NUMERIC » KEY .....	4.23
4.13.	« TRIGGER » KEY .....	4.24
4.14.	« REPLAY » KEY .....	4.25
4.15.	« START/STOP » KEY .....	4.26
4.16.	« SCREEN COPY » KEY .....	4.27
4.17.	« HOME » KEY .....	4.27
<b>5.</b>	<b>TRIGGERS</b> .....	<b>5.1</b>
5.1.	TRIGGER WITH COMBINATION ANALOG CHANNEL .....	5.2
5.1.1.	<i>Analog channel (only one threshold)</i> .....	5.2
5.1.2.	<i>Combination Analog channel (several thresholds)</i> .....	5.3
5.1.3.	<i>Threshold triggering</i> .....	5.5
5.1.4.	<i>Slope trigger</i> .....	5.6
5.2.	TRIGGER WITH LOGICAL CHANNELS .....	5.7
<b>6.</b>	<b>MATHEMATICAL CALCULATIONS</b> .....	<b>6.1</b>
6.1.	DEFINITIONS .....	6.1
6.2.	TYPES DE CALCULATIONS .....	6.2
<b>7.</b>	<b>MEMORY MODE</b> .....	<b>7.1</b>
7.1.	SET-UP AND TRIGGERING OF THE DATA ACQUISITION .....	7.1
7.2.	SAMPLING PERIOD .....	7.3
7.3.	INTERNAL MEMORY, BLOCKS .....	7.3
7.4.	START POSITION .....	7.4
7.5.	DOUBLE TRIGGER MODE .....	7.5
7.6.	RECORDING .....	7.6
7.7.	REPLAY .....	7.8
<b>8.</b>	<b>GO/NOGO MODE</b> .....	<b>8.1</b>
8.1.	SET-UP AND TRIGGERING OF THE DATA ACQUISITION .....	8.1
8.2.	CREATING OF THE FRAME .....	8.3
8.3.	USE OF THE FRAME .....	8.4
<b>9.</b>	<b>FILE MODE</b> .....	<b>9.1</b>

9.1.	SET-UP AND TRIGGERING OF THE DATA ACQUISITION .....	9.1
9.2.	ANNOTATION .....	9.2
9.3.	LIMITATION .....	9.3
9.3.1.	<i>Binary file</i> .....	9.4
<b>10.</b>	<b>POWER ANALYSER .....</b>	<b>10.1</b>
10.1.	GENERAL .....	10.1
10.2.	INSTALLATION: "SET-UP ANALYZER" MENU .....	10.2
10.3.	DISPLAY OF THE SIGNAL: .....	10.4
10.4.	TRIGGER MENU .....	10.6
10.4.1.	<i>Parameter acquisition file</i> .....	10.7
10.4.2.	<i>Acquisition file of the harmonics</i> .....	10.7
10.4.3.	<i>Recordable parameters</i> .....	10.7
10.5.	RECORD .....	10.8
10.6.	MEASUREMENT METHOD .....	10.9
<b>11.</b>	<b>FILE MANAGEMENT .....</b>	<b>11.1</b>
11.1.	GENERAL .....	11.1
11.2.	MANAGING THE SET-UP FILES .....	11.2
11.2.1.	<i>Saving set-up files</i> .....	11.3
11.2.2.	<i>Loading set-up files</i> .....	11.3
11.3.	MANAGING THE DATA ACQUISITION FILES .....	11.4
11.3.1.	<i>Saving acquisition files</i> .....	11.4
11.3.2.	<i>Loading acquisition files</i> .....	11.5
11.4.	RECYCLE BIN .....	11.5
<b>12.</b>	<b>PRINTING .....</b>	<b>12.1</b>
12.1.	SET-UP AND START OF THE PLOT .....	12.2
12.2.	SELECTION OF THE PRINTER .....	12.3
12.3.	PRINTER FOR USB CONNECTION .....	12.4
<b>13.</b>	<b>INPUT / OUTPUT .....</b>	<b>13.1</b>
13.1.	ADDITIONAL INPUT / OUTPUT CONNECTOR .....	13.1
13.2.	LOGICAL INPUTS .....	13.2
13.2.1.	<i>Use</i> .....	13.2
13.3.	ALARM OUTPUTS .....	13.3
13.3.1.	<i>Use</i> .....	13.3
13.4.	POWER SUPPLY OUTPUT .....	13.3
13.5.	EXTENSION BOX FOR INPUT/OUTPUT INTERFACE .....	13.4
13.5.1.	<i>Use</i> .....	13.6
<b>14.</b>	<b>INTERFACE .....</b>	<b>14.1</b>
14.1.	ETHERNET INTERFACE .....	14.1
14.1.1.	<i>General</i> .....	14.1
14.2.	NTP PROTOCOL .....	14.3
14.3.	WIFI CONNECTION .....	14.4

14.4.	OPERATING SOFTWARE .....	14.7
14.4.1.	File transfer under FTP.....	14.7
14.4.2.	Display under SeframViewer.....	14.8
14.4.3.	Control with VNC Viewer: .....	14.9
<b>15.</b>	<b>TECHNICAL SPECIFICATIONS .....</b>	<b>15.1</b>
15.1.	ISOLATED 1000V INPUTS .....	15.1
15.1.1.	General characteristics .....	15.1
15.1.2.	Voltage record.....	15.2
15.1.3.	RMS record.....	15.2
15.1.4.	Derivative and integral record.....	15.2
15.1.5.	Frequency record .....	15.3
15.1.6.	Counting record .....	15.3
15.1.7.	Sampling.....	15.3
15.1.8.	Bandwidth.....	15.3
15.2.	ISOLATED 500V INPUTS .....	15.5
15.2.1.	General characteristics .....	15.5
15.2.2.	Voltage recording.....	15.5
15.2.3.	RMS recording .....	15.6
15.2.4.	Derivative and integral record.....	15.6
15.2.5.	Temperature record.....	15.7
15.2.6.	Frequency record .....	15.7
15.2.7.	Counting record .....	15.7
15.2.8.	Sampling.....	15.8
15.2.9.	Bandwidth.....	15.8
15.2.10.	General Characteristics .....	15.9
15.2.11.	Voltage record.....	15.9
15.2.12.	RMS record.....	15.10
15.2.13.	Derivative and integral record.....	15.10
15.2.14.	Temperature record.....	15.10
15.2.15.	Sampling.....	15.10
15.2.16.	Bandwidth.....	15.10
15.3.	STRAIN GAUGE INPUTS.....	15.11
15.3.1.	General characteristics .....	15.11
15.3.2.	Voltage record.....	15.11
15.3.3.	RMS record.....	15.12
15.3.4.	Derivative and integral record.....	15.12
15.3.5.	Strain gauge record.....	15.12
15.3.6.	Temperature record.....	15.13
15.3.7.	Sampling.....	15.13
15.3.8.	Bandwidth.....	15.13
15.4.	ADDITIONAL INPUTS / OUTPUTS .....	15.14
15.4.1.	Logic channels.....	15.14
15.4.2.	Alarm Outputs .....	15.14



15.4.3.	<i>External power supply</i> .....	15.14
15.5.	CIRCUIT ANALYSIS.....	15.15
15.5.1.	<i>Ranges and Accuracies Voltage and Intensity</i> .....	15.15
15.5.2.	<i>Frequency</i> .....	15.16
15.5.3.	<i>Power factor</i> .....	15.16
15.5.4.	<i>Peak factor</i> .....	15.16
15.5.5.	<i>Harmonics rate calculated in power analysis</i> .....	15.16
15.6.	DISPLAY.....	15.17
15.7.	MEMORY ACQUISITION.....	15.17
15.8.	ACQUISITION ON FILES.....	15.17
15.9.	COMMUNICATION INTERFACE.....	15.17
15.10.	MISCELLANEOUS.....	15.18
15.10.1.	<i>USB connector</i> .....	15.18
15.10.2.	<i>Screen connector</i> .....	15.18
15.11.	ENVIRONMENTAL CONDITIONS.....	15.19
15.11.1.	<i>Weather conditions</i> .....	15.19
15.11.2.	<i>Mains</i> .....	15.19
15.11.3.	<i>Dimensions and weight</i> .....	15.19
15.12.	ELECTROMAGNETIC COMPATIBILITY, SECURITY.....	15.20
15.12.1.	<i>Electromagnetic compatibility</i> .....	15.20
15.12.2.	<i>Security, Isolation Class, Installation Category</i> .....	15.21
15.13.	MISCELLANEOUS.....	15.21
15.13.1.	<i>Internal saving battery</i> .....	15.21
15.14.	ACCESSORIES.....	15.22
15.14.1.	<i>Accessories provided with the appliance</i> .....	15.22
15.14.2.	<i>Accessories and options</i> .....	15.22
15.14.3.	<i>Consumable items</i> .....	15.22
<b>16.</b>	<b>APPENDIX.....</b>	<b>16.1</b>
16.1.	INFORMATION ABOUT THE CALIBER OF THE INPUTS.....	16.1
16.1.1.	<i>Inputs of isolated voltage type</i> .....	16.1
16.1.2.	<i>Inputs of multiplexed card voltage type</i> .....	16.2
16.1.3.	<i>Input of thermocouple type</i> .....	16.2
16.2.	ACCURACY OF THE THERMOCOUPLE MEASUREMENTS.....	16.3
16.3.	MEASUREMENT ACCURACY FOR PT100.....	16.5
16.4.	ACCURACY OF INSTANT MEASUREMENT ACCORDING TO THE FILTERS.....	16.7
16.5.	NOTE ON THE MEASUREMENT UNITS FOR A GAUGE STRAIN.....	16.8
16.5.1.	<i>Conversion rules</i> .....	16.8
16.5.2.	<i>Calculation details</i> .....	16.8
16.5.3.	<i>Display of the characteristics of the bridge in mV/V</i> .....	16.10
16.5.4.	<i>Example of unit change</i> .....	16.10
16.6.	ACCURACY CLASS – CLASS INDEX.....	16.11

## 1. IMPORTANT INFORMATION

**Please read carefully the following instructions before using your recorder.**

### 1.1. Particular precaution measures

**Do not use** the product for any other use than specified.

**Use normalized cables** to connect the appliance to the measurement points.

**Use the provided power cable** to avoid any degradation of the appliance and guarantee its characteristics in measurement.

**To prevent any risk of electric shock**, do not plug or unplug the measurement cables when connected to the power supply.

**Do not use in a wet environment.**

**Do not use in an explosive environment.**

**In case of defect or for the maintenance**, only a qualified personal should be allowed to work on the appliance. In this case, it is necessary to use Sefram spare parts.

**Do not open the appliance** when live.

## 1.2. Security instructions

For a correct use of the appliance, the users must abide by the security and use requirements as described in this manual.

Specific alert signals appear all along this manual.

In case of need, there are alert symbols on the appliance:



This is a CLASS 1 appliance: in case of any electrical or external defect during use, the current is evacuated to the earth to protect the user.



You **MUST NOT** disconnect the protective of the appliance.

## 1.3. Symbols and definitions

**Symbols appearing in this document:**



**Caution:** potential danger for the user.



**Attention:** potential danger for the appliance and/or the connected equipment.



**Remark:** important information.

**Symbols on the appliance:**



**Danger (High Voltage):** immediate corporal danger.



**Attention:** refer to the instruction manual. Potential damages to the appliances connected to the instrument or to the instrument itself.



**Earth:** accessible parts connected the earth of the appliance.

#### 1.4. Conformity and limitations of the appliance

The DAS1600 and DAS800 recorders are conform to the norm CEI 61010-1 (2001-02).

See chapter "**Technical specifications**".



**Attention:** Never apply a voltage higher to the maximum admissible voltage between the channels and between a channel and the earth.

## 2. PRESENTATION

### 2.1. GENERAL

The DAS1600 and DAS800 are programmable recorders that allow to measure and record voltages, intensities, temperatures etc.... as well as on 16 logic channels.

The DAS1600 can be configured with 6 boards maximum (72 channels max), universal isolated or isolated strain gauge, or non-isolated multiplexed. The DAS800 has not an integrated thermal printer and possesses just 1 board.

You have 3 available types of inputs:

- isolated universal inputs through 6-channel module, up to 6 modules
- non-isolated differential inputs, multiplexed through 12-channel module, up to 6 modules
- isolated strain gauge through 6-channel modules
- 1000 V inputs through 6-channels modules

Several work modes are available:

- a Memory mode for acquisition on internal fast memory
- a File mode for acquisition on an internal hard drive or USB stick
- a Template mode for acquisition on a pre-recorded template
- a Circuit Analysis mode to make measurements on the circuit

The "operator-recorder" dialog is made easier thanks to very clear menus on a wide LCD screen. The measurement parameters can be easily configured: you can do it with the keyboard on the touchscreen, with a stylus or with a mouse and an external keyboard.

The DAS1600 and DAS800 recorders can be fully programmed through Ethernet link.


---

## 2.2. DESCRIPTION

The 2 recorders have the same input-output connectors on the rear (or upper) side.

### 2.2.1 Rear or upper side

- 1- a RJ45 connector for the ETHERNET 10/100BaseT interface
- 2- a SUB-D 15-pin connector for monitor output
- 3- 4 USB-2 ports at the rear and 2 USB-2 ports at the edge
- 4- a SUB-D 25-in connector for the 16 logic inputs and the alarm outputs
- 5- access to the 3 A, B and C input modules (isolated or non-isolated according to the configuration of the appliance)
- 6- an earth pole
- 7- Power supply ON/OFF switch. In the case of a device with the battery option, this button doesn't switch ON or OFF the DAS but only switch on or off the battery charge.
- 8- a mains plug
- 9- (Battery option) Device ON/OFF. This button enables you to turn ON or OFF the device, with external power supply if the switch button (7) is turned on, or with the battery power supply (switch button 7 turned off).

**DAS1600 – DAS800**

The isolated universal input modules have 2 security poles for each input:

- 1 red pole: input « + »
- 1 black pole: input « - »

The non- isolated universal input modules have 5 screw terminals for each input:

- 2 « + » and « - » poles for each voltage input
- 2 « I+ » et « I- » poles for the PT100 input
- 1 earth pole

For the other input-output poles, see chapter « **Input / Output** ».


### **2.2.2 Edge side**

The edge side of the recorders includes:  
a LCD TFT back-lighted color screen



## 2.3. LCD SCREEN

### 2.3.1. Description of the screen



The different zones on the screen:


- 1- STATUS: acquisition mode, acquisition status or printing status
- 2- VALIDATION: selection of the channels to use
- 3- CHANNEL: name of the currently used channel
- 4- PARAMETERS: name of the modifiable parameters and their current values;
- 5- PRINTING SCREEN: for displaying the recorder on screen
- 6- COPY CHANNEL: copies the configurations of a channel to the selected channels
- 7- LOGIC INPUTS: real time status of the logic channels
- 8- MODE: current mode (here Memory mode)
- 9- ANALOGIC INPUTS: bargraph of the current values of the inputs
- 10- MAIN MENU: gives access to the main menu to change the mode, the function, access to the notice...
- 11- GRAPHICAL ZONE: visualization of the printings
- 12- SHORTCUTS : (from left to right)
  - Real time graphic F(t)
  - Replay
  - Start/Stop record

### 2.3.2. Bar graph patterns

The bar graph, located in the screen's left corner, has two different running mode depending on the number of board connected to the device.

➔ **Less than 3 board connected** : All the channels are displayed

➔ **More than three board connected** : A new menu appears at the bar graph top letting you choose between three different channels groups




Visualization modes:

1-SORT BY BOARD: Choose the board from which you want to display channels

2-CHANNELS ON: Only selected channels will be displayed

3-FUNCTIONS : Only mathematical channels will be displayed


## 2.4. SCREEN KEYS




- « **USER MANUAL** » key: display of the instruction manual of the DAS1600 /DAS800



- « **LOGIC CHANNELS** » key: configuration of the logic channels



- « **CONFIG** » key: general configuration of the appliance (language, date and time, alarm outputs, software updates...)



- « **CHANNEL** » key: access to the parameters of each channels, access to the functions between channels




- « **VALIDITY** » key: selection of the channels for each acquisition (on paper, screen, internal memory or file)



- « **SETUP ANALYZER** » key: configuration of the parameters for circuit analysis



- « **POWER ANALYSIS** » key: launching measurements of power, harmonics... of the circuit



- « **TRIGGER** » key: launching parameters of the acquisitions (on paper, internal memory or file according to the current MODE)



- « **REPLAY** » key: display on screen of the acquisitions on internal memory or file, measurement cursors, zoom, calculations



- « **Start/Stop** » key: launching of the data acquisition under the all MODES



- « **MODE : MEMORY** » key: configuration of the parameters of measurement record into internal memory




- « **MODE : FILE** » key: configuration of the parameters of measurement record on file



- « **MODE : GO/NOGO** » key: configuration of the parameters of measurement record into internal memory under a template



- « **XY** » key: real time display on screen of the validated channels in XY mode



- « **F(t)** » key: real time display on screen of the validated channels



- **C** » key: real time display on screen of the digital values of the validated channels

## 2.5. . UPDATING THE INTERNAL SOFTWARE

The internal software is regularly updated with its latest evolutions. These updates are available on our website.

To update the software, copy the file provided onto an USB stick. Plug it on one of the USB ports at the rear of the appliance.

Press the  key, then select the « **Modification Version/Option** » parameter line and validate « **Charge** ».

A window pops up; select « **modif** » on the line « **Modification Version** ».



The internal software copies automatically the required files to the new version.

Turn off and on when the update is finished.

## 3. SET-UP AND PRECAUTIONS OF USE

### 3.1. Precautions for storage of the records

In order to preserve the quality of the paper records, it is advisable to respect handling precautions:

- Never use laminate pouches
- Store away from light, in a cool and dry place.

Cardboard pouches are advisable.

### 3.2. POWER

The recorders work on normalized mains (See chapter Technical specifications).

They are designed for indoor use.



MAINS CONNECTION

These instruments must be connected to the mains with the provided cord.



SECURITY

These instruments are **security class I** according to the classification CEI1010 (NF EN 61010) Security rules for electrical appliances for measurement, regulation and laboratory.

They must be powered ob a 1-phase circuit according to the **installation category II** (overvoltage category).



GROUNDING

These instruments must be connected to the earth with the provided cord.



It is **FORBIDDEN** to interrupt the grounding inside or outside the instrument: it would make the instrument **DANGEROUS**.



In case of more than three 500V board are plugged to the device, it is **obligatory** to connect the two protection grounds (the auxiliary protection earth and the power cord's earth)  
The interruption of one of this ground, in the device or outside the device is **FORBIDDEN** and make it **DANGEROUS**..



The use of the battery requires **imperatively** to plug the device's protection earth or the power supply wire for safety reasons  
For the devices plugged to 500V board the maximum number of board authorized is lowered to 3..

### 3.2.1. Fuse

The user cannot reach the protective fuse of the power supply.  
In case of power defect, contact the after-sales service.

Type for DAS1600: 2.5 A, 20 mm quick HBC

### 3.2.2. Turning on the DAS1600 – DAS800

You turn the DAS1600 and DAS800 recorders on at the rear of the appliance, by triggering the **ON/OFF** switch to "**I**".

A light "ON" at the front side of the keyboard confirms that your appliance is energized.

After starting up the internal software, the recorder displays a homepage specifying:

- the software version:                   Version x.y
- the number of channels:               6, 12, 18 or more

Then switches automatically to a visualization mode « **F(t)** » or « **XY** » (oscilloscope).

## 3.3. CONFIGURATION AT START-UP

At power up, the appliance starts with the configuration at the latest stop (voluntarily or after power shortage).



If the configuration has changed at the power-up, contact the after-sales service.

If the initial configuration is wrong, you can start with the default configuration:

You must then press several times the top right of the appliance at the start-up until the homepage shows up (at the place of the main Menu key under normal conditions).



## 3.4. CONNECTION TO THE MEASUREMENT NETWORKS

### 3.4.1. Voltage measurement

**Isolated input module 500V:** The voltage measurement is made between the red and black poles of the inputs with wires equipped with male security banana plugs (according to CEI 1010).

**Isolated input module 1000V:** Voltage measurement is made between the red and white poles.

**Non-isolated differential input module:** The voltage measurement is made between the « + » and « - » poles of the inputs with wires on the screw terminal block.

**Isolated strain gauge input module:** The voltage measurement is made between the « + » and « - » poles of the inputs with wires on the screw terminal block.

### 3.4.2. Temperature measurement with a thermocouple

**Isolated input module:** The voltage produced by the thermocouple effect must be measured between the red and black poles of the concerned input. To guarantee a right measurement, connect directly both ends of the thermocouple cord on banana plugs. Plug these two banana plugs onto the input you want with respect for the polarity.











Do not use male banana plugs for welding: the soldered joint would alter the thermocouple effect.

**Non-isolated differential input module and Isolated strain gauge input module:** The voltage produced by the thermocouple effect must be measured between the « + » and « - » poles of the inputs with wires on the screw terminal. To guarantee the right measurement, plug directly both ends of the thermocouple cord on to the input you want with respect for the polarity.

### 3.4.3. Gauge strain measurement


Only possible with the isolated strain gauge input module.

Signals of the connector

	1	1: measurement input –
	2	2: measurement input +
	3	3: ground of the measurement drawer (connection of the cable shield)
	4	4: - pole of the powering of the strain gauge bridge (-1V or -2.5V)
	5	5: control of the powering – of the field (6-wire mode)
	6	6: + pole of the powering of the strain gauge bridge (+1V or +2.5V)
	7	7: control of the powering + of the field (6-wire mode)
	8	8: I+ pole


Wiring of a complete 4-wire bridge:

Programming the channel in « gauge » « complete bridge » type (see chapter Channel)



Wiring of a complete 6-wire bridge:


Programming the channel in « gauge » « complete bridge » type (see chapter Channel)



Wiring of a half bridge:

Programming the channel in « gauge » « half bridge » typ (chapter Channel)


The other half bridge is internal to the appliance (2 resistances 10 k $\Omega$  0.1% 10 ppm)



Measurement of a voltage:

Programming the channel in « voltage » type (chapter Channel)

Apply the measurement between « - » and « + »




### 3.4.4. Temperature measurement with PT100 and PT1000


The PT100 probe must be connected on the « I+ » and « I- » poles (1 mA current generator output) (I+ and ground for the input strain gauge module). The PT100 probe is only possible on the isolated strain gauge input module (0.1 mA output).

The voltage produced by the PT100 must be measured between the « + » and « - » poles with one of the following assemblies: 2 wires, 3 wires or 4 wires. The 4-wire mounting makes the measurement value independent from the resistance of the line.

2-wire mounting:




3-wire mounting:



4-wire mounting:

You only have to select the type of measurement PT100 2, 3 or 4 wires on the configuration of the corresponding channel; See chapter « **Channels** ». (PT100 3 wires not possible on the isolated strain gauge module input)



### 3.4.5. Intensity measurement

**Isolated input module:** it is possible to make intensity measurements with a **shunt** between the red and black poles of the treated input.

**Non-isolated differential input module:** it is possible to make intensity measurements with a **shunt** between the « + » and « - » poles of the treated input.

In this case, select the "**current**" type in the parameters of the selected channel.

Connect the measurement wires to the poles of the shunt.

The results are displayed directly in A or mA according to the caliber of the selected channel.

### 3.4.6. Earth

For measuring very low voltage values, the problem of the parasite voltages induced by electromagnetic fields or ordinary mode voltages are all the more important than the selected sensitivity is high. Hence, it is important that the outer cables are correctly settled.

There are various causes to such difficulties:

- uncertainty about the true origin of the disturbing voltages and impedances
- uncertainty about the parasite capacities of the circuits and cables
- no access to the point of injection of the ordinary mode voltage from the circuit providing the signal to record
- non-conformity of some appliances to the valid norms

- sometimes, ignorance of the source impedances of the signals to record.

**IT IS ADVISABLE TO RESPECT THE FOLLOWING PRESCRIPTIONS**

1/ The **mechanical groundings** of every appliances must be **earthed**.

The mechanical grounding of the recorder is connected to the earth through the cord of the mains or thanks to the protective wire.

However, if the other appliances of the mounting do not include this possibility, it is advisable to gather their mechanical groundings with the one of the recorder, since it is available on a bush at the rear of the appliance.

2/ If the source of the signal to record has a **low internal impedance**, you will use **twisted wires**. If the source of the signal to record has a **high internal impedance**, you will use **shielded wires**.

3/ When gathering the groundings of the various items of the measurement chain, you'd better check that there is no differential ground potentials between them in order to prevent any short-circuit. In case of doubt, use a voltmeter to measure it after placing a weak charge (i.e. 1 k $\Omega$ ) between the poles.

### 3.5. Routine maintenance

The maintenance is not restricted to cleaning the outside of the appliance. Any other operation requires some qualified personal.



**Unplug the appliance before any intervention.**

Do not leave water flow into the appliance, to prevent any risk of electric shock.

Regularly clean the recorder in respect with the following instructions:

- use water and soap to cleanse the front and rear plates
- never use any product made of essence, benzene or alcohol that would attack the silk-screenings
- wipe with a soft lint-free cloth
- use an antistatic product to cleanse the screen


### 3.6. Calibration of the offsets

You can easily calibrate the inputs of the recorder for the offsets of voltages and thermocouples.

To do so:

- Let the appliance work for 20 minutes (ambient temperature between 20 and 25 °C).
- On each input, connect the « + » pole to the « - » pole (resp. red and black poles for the isolated inputs).
- Validate every channel 'ON'

- Push



- At « **Option** », select « **Modif.** ».
- At « **Electrical calibration** », select « **Modif.** ».
- Eventually, select « **Calibration Offset** ». Then, you only have to select the channel(s) to calibrate.

By pressing « **Confirm** », you launch a calibration. It will last ca. 5 minutes

### 3.7. Default setup

You may restore the default factory settings to cancel any mistake in the calibration coefficients:

- Press



- At « **Option** », select « **Modif.** ».
- At « **Electrical calibration** », select « **Modif.** ».
- Eventually, select « **Reload Factory coeff.** ».


By pressing « **Confirm** », you restore the default factory settings.



### 3.8. Expert mode

You can configure the recorder in Expert mode to lock some keys or functions of the appliance:

- Press




- At « **Option** », select « **Modif.** ».
- At « **Expert Mode** », select « **Modif.** ».
- Enter the password « **Sefram** », then select « **Confirm** ».

The Expert mode is then launched. To deselect it, you only have to follow the same process. The password is also « Sefram ». If you wish to change the password, contact the Sefram assistance.

### 3.9. Keyboard locking

You can also completely lock the recorder: no key will be available any more.

- Press



- At « **Option** », select « **Modif.** ».
- At « **Keypad locked** », select « **Modif.** ».

The keyboard will lock 5 seconds after pressing « **Confirm** ». All keys of the appliance will be locked. To unlock the recorder, you must push two or three times in a row on « **Home** ». This touch is displayed as a yellow padlock when the keyboard is locked.

## 4. USE

The chapter describes in details the effect of each key of the front side keyboard.

These actions are also available with a mouse of an external PC-type keyboard (see chapter **Presentation**)

The description of the keys and their actions is valid for both DAS1600 and DAS800. If not (specificities), the text will specify the type of appliance.

### 4.1. « Mode Memory » key



Quick data acquisition into internal memory of the measured signals

- use: quick short-time data acquisition (transitory)
- possibilities: complex start of the data acquisition, action after data acquisition, simultaneous record on a file

### 4.2. « Mode File » key



Quick data acquisitions on internal hard drive or USB stick of the measured signals

- use: quick long-time data acquisition (only restricted to the size of the memory)
- possibilities: complex starts, action after the data acquisition, acquisition of very big amounts of data

### 4.3. « Go/No-go » key



Quick data acquisition into internal memory of the measured signals

- use: quick short-time data acquisition (transitory) to detect non-repetitive events
- possibilities: complex starts, in particular with exceeding pre-recorded template from a channel, action after the data acquisition, simultaneous record on a file

### 4.4. « User manual » key



This key gives you easy access to the user manual of the recorder (DAS1600 / DAS800).

### 4.5. « Power Analysis » key

The circuit analysis option makes it possible to measure powers and harmonics. The measured values can be displayed in real time or recorded. See chapter Circuit Analysis.


### 4.6. « Setup Analyzer » key




This key gives you access to the circuit analysis configuration. See chapter Circuit Analysis.

The circuit analysis option makes it possible to measure powers and harmonics. The measured values can be displayed in real time or recorded. See chapter Circuit Analysis.

## 4.7. « Setup » key



General configuration of the appliance, control of the alarm outputs, TCP/IP network address, calibration of the channels, updating of the internal software.



- ➔ **Language:** selection of the language of the appliance
- ➔ **Screen shut off:** turning off the backlighting of the LCD screen, configuration of the delay
- ➔ **Date & Hours:** date and hour of the appliance (for NTP, see 16.1.2)
- ➔ **Modification Version/Option:** updating the internal software (see chapter Presentation)
- ➔ **Graphics options:** you can now change some graphical options to optimize the display:
  - **Bargraph: max on the right** to reverse the maximum and the minimum of the bargraph.
  - **Automatic filename :** To automatically name your REC file with the record's date and hour.
  - **Graphics: maximum on bottom** to reverse the maximum and the minimum values of the graph (the minimum will be upside)
  - **Cursor: the values follow the curves** to follow the value with the cursor everywhere on the curve

- **Change color on overtake:** to select a color for the curve each time it passes over a selected threshold. You will see easily when it passes over thresholds.

---

→ **Options:** possibility to switch to Expert mode, lock the keyboard, calibrate the offsets and restore the default factory coefficients (see 3. Set-up and precautions of use) modify text files structure for recording and erase all the files in the hard disk. You may also add an e-mail address to warn you when the data acquisition is over and test a network by adding the address...

→ **Network :** Change of the various IP and options

- DHCP validity
- IP address of the appliance
- Address mask
- Gateway address
- DNS and NTP address

→ **Set Up:** initialization of the appliance in its typical configuration, save / recovery into internal ROM, internal hard disk or USB stick

**ATTENTION:** the current configuration will be lost

→ **Alarm A:** use of the A alarm output (relay contact)

- **Disabled:** no condition controls the contact; it remains always open
- **Trigger:** control through a combination of analogical or logic channels on several thresholds (See chapter Triggers)
- **On the record triggering:** control through triggering of a data acquisition
- **Paper error:** control through lack of paper or opening of the printing block
- **Automatic add of markers in recordings**

In all cases, the contact is **open** if the condition is **true**.

→ **Alarm B:** use of the B alarm output (logic output 0-5 V)


- **Disabled:** no condition controls the output; it always remains low (0 V)
- **Trigger:** control through a combination of analogical or logic channels on several thresholds (See chapter Triggers)
- **On the record triggering:** control through triggering of a data acquisition
- **Paper error:** control through lack of paper or opening of the printing block
- **Automatic add of markers in recordings**

In all cases, the contact is **low (0 V)** if the condition is **true**.

➔ Alarm C: same as Alarm B




The text file structured can be modified from the menu « Setup » « Option » «Text file format »




- ➔ **Number format:** Depending on the software you want to use to process the text file, the separator between the integer part and the decimal part could be a point or a coma.
- ➔ **Delimiter:** Character used to separate all the different data in the text file.

## Channel key



Configuration of the channels. After pressing this key, you select a module, then a channel to access its parameters. You can also access this menu by selecting a channel on the left of the screen.



### 4.7.1. Analogical channels

- **Name of the channel:** give a name to the channel (26 characters max.)
- **Color:** allows you to change the color of the display on screen
- **Thickness:** changes the thickness of the measurement curve on screen and on paper, from 1 to 8 pixels

---

→ **Type:** selection of the type of measurement on the input

For isolated universal input module

- voltage, intensity, frequency, thermocouple or counter
- direct, RMS, derivative or integral
- value of the shunt for intensity measurement
- selection of the type for thermocouple, compensation, unit

For multiplexed non-isolated input module

- voltage, intensity, thermocouple, PT100
- direct, RMS, derivative or integral
- value of the shunt for intensity measurement
- selection of the type for thermocouple, compensation, unit
- PT100 4-wire, 3-wire or 2-wire

For isolated strain gauge input module

- voltage, current, thermocouple, gauge, PT100, PT1000 (2-wire or 4-wire)
- direct, RMS, derivative or integral
- value of the shunt for intensity measurement
- selection of the type for thermocouple, compensation, unit
- voltage of the strain gauge bridge 2 V or 5 V
- complete bridge or half bridge
- initialization of the strain gauge (zeroing)
- gauge coefficient

- Derivative of integral input: the user selects according to the signal with an integration time filter (this time is the same for all channels) and a channel filter.

In integral mode, a setup allows a zeroing of all channels.

→ **External sensor:** Assigns an external sensor to the selected channels

→ **Calibration Sensor:** For calibration of the minimum and maximum values for the selected channels



---

→ **Filter:** positioning of a filter on the input

- 10kHz, 1kHz, 100Hz, 10Hz for analogical filters
  - 1Hz, 10s, 100s or 1000s for digital filters
- (according to the type of signal and to the card)

→ **Function:** assigns a mathematical function to the channel

- **Without:** no function
- **Change of unit:** changes the unit of the measurement made on the channel; you will be able to program a couple of dots X1, Y1 and X2, Y2 for a scaling
- **Calculation:** available mathematical functions, associated parameters and unit (the  $ax+b$  function is identical to the change of unit, but instead of producing a couple of dots, you give a intercept (b) and the slope (a).

→ **Range:** settling of the caliber

The caliber is the measurement range matching the total width of the screen, where the channel is displayed.

You can settle finely the value of the caliber in order to take advantage of the whole width of the display on screen or paper.

→ **Centre zero:** zero adjustment of the channel

The zero (or center or offset) is the central value of the measurement.

You can settle finely the value of the caliber in order to take advantage of the whole width of the display on screen or paper.

N.B: When using a mathematical function or a scale change, the zero matches the zero in the selected unit.

→ **Position:** position of the zero on screen or paper, between -100 and 100%:

ex. In RMS mode, it is interesting to have the zero at the minimum value (-100%): the maximum value will be equal to the caliber.

The lower zone of the LCD screen shows the min. and max. values (limits) possible for the measure values and the zero position.

A warning message shows up on the right when the analogical thresholds are out of measurable range.

→ **Trigger T1:** display of the position of the triggering threshold #1 on screen and paper

→ **Trigger T2**: same for the threshold #2


When the logarithm sensor option is selected the previous window lets appear new range of configurations:




- **Maximum decade value:** Maximum in the ordinate axis
- **Number of decade:** Ordinate axis' division number.
- **Corresponding voltage:** Maximum voltage corresponding to the value entered in the **Maximum decade value** menu.
- **Slope volt per decade :** Slope associated with the sensor

### 4.7.2. Functions between channels

Up to 24 mathematical channels can be added from the menus below:




Enable/disable mathematical channels



Add or delete a mathematical function

Mathematical function names from FA to FX


A mathematical function consists in a text file called script which contains the mathematical instructions. Function's script is accessible by clicking on its name in the bar graph.



Edit function parameters

Click here to edit the script

### 4.7.2.1 Script editor



- ➔ **Functions:** Shortcut to add easily a basic mathematical function in the script
- ➔ **Channels:** Select in the list the channel name you want to add to the script
- ➔ **Copy to:** Copy the script and the configuration of the currently edited script to another mathematical channel
- ➔ **Erase :** Erase all the text of the currently edited script
- ➔ **Examples :** A basic script examples list
- ➔ **Exit:** Return to the channel configuration menu.

### 4.7.2 2. Scripts syntax

Mathematical scripts' syntax is inherited from the programming language C. Programming scripts is a rigorous exercise which imply to respect some elementary rules to avoid error messages.

The three fundamental rules are:

- **Rule 1** : Every instructions or calculation must end with a semi-colon ;
- **Rule 2** : Channels name must be written between simple quotes like (the number of spaces must also be respected) 'Channel A1'
- **Rule 3** : Each variable must be declared only once with the keyword **var**. Example: **var** MyVariable=3;
- **Rule 4**: The result is stored in the current function channel by using the keyword **function**. Example : **function**=2;

By respecting these four rules, a basic script adding the Channel A1, Channel A2 and Channel A3 will look like:



```
Function : F A
0 function='Channel A 1'+ 'Channel A 2'+ 'Channel A 3';
```

**Rule 4:** The current channel is FA. The function keyword will thereby store the result in FA.

**Rule 2:** Channels name are between simple quotes

**Rule 1:** The calculation end with a ;

For long scripts it will be better to use intermediate variables to ease the maintenance or the future modifications. As mentioned in the rule 3, each variable must be declared before its use:

```
Functions Channels Copy to
Function : F A
0 var a=2+1/3*'Channel A 2';
1 var b=3*'Channel A 1';
2 function=a+b;
```

**Rule 3:** Variable a is declared

**Rule 3:** Variable b is declared

**Rule 1:** The semi-colons end the different calculation.


Addition of a and b, the current function being FA the result is store in FA. The keyword var is no more used to refer to the already declared variable.

Variable names must only contain alphanumeric character and at the opposition of channels' names they must not be written between simple quotes.

In addition to the linear mathematical operators as +, -, x, /, it is possible to use non linear mathematical function with variables and channels. The list of these functions can be found in the menu Function in the editor's toolbar. A function is used by writing its name followed by a list of parameters between parentheses separated with comas.

Example: The channel rise to the 3th power:

```
Functions Channels Copy to
Function : F A
0 function=pow('Channel A 1',3);
```



Mathematical functions	Syntax	Examples
cosinus	cos(b)	a=cos(b) ; or function=cos('Voie A1') ;
sinus	sin(b)	a=sin(b) ; or function=sin('Voie A1') ;
tangent	tan(b)	a=tan(b) ; or function=tan('Voie A1') ;
arccosine	acos(b)	a=acos(b) ; or function=acos('VoieA1') ;
arcsine	asin(b)	a=asin(b) ; or function=asin('Voie A1') ;
arctangent	atan(b)	a=atan(b) ; or function=atan('Voie A1') ;
Neperian logarithm	log(b)	a=log(b) ; or function=log('Voie A1') ;
Decimal logarithm	log10(b)	a=log10(b) ; or function=log10('Voie A1') ;
exponential	exp(b)	a=exp(b) ; or function=exp('Voie A1') ;
Square root	sqrt(b)	a=sqrt(b) ; or function=sqrt('Voie A1') ;
x^y	pow(x, y)	a=pow(x,y) ; or function=pow('Voie A1',2) ;
Hyperbolic cosine	cosh(b)	a=cosh(b) ; or function=cosh('Voie A1') ;
Hyperbolic sine	sinh(b)	a=sinh(b) ; or function=sinh('Voie A1') ;
Hyperbolic tangent	tanh (b)	a=tanh(b) ; or function=tanh('Voie A1') ;





It is possible to realize the nth root by using the mathematical equation  $\sqrt[n]{x} = x^{1/n}$ . hereby the 3th root of a variable X will be written in the script:

```
var X=2;
pow(X, 1/3) ;
```

### 4.7.2.3 Error messages

Scripts start running as soon as the text editor is closed. If the current script contains an error, a contextual window will inform you at the editor's close.

Example: The lack of a semi-colon at the calculation end




Common errors are

- ➔ Lack of a semi-colon
- ➔ A bad channel's name has been entered. Channel's names must be entered exactly as they were named ( with the same number of spaces, the same case ...)
- ➔ A variable has not been declared
- ➔ A variable is used without being initialized
- ➔ The script depends on another script



#### 4.7.2.4 Editor advanced use

Adding channel's names to the script is eased by the menu Channels in the toolbar. With a simple click the selected name will appear in the script editor with the good structure, case and spaces.



It is strongly advised to use this functionality instead of writing manually the channel name

The replacement of a channel name by another is accessible by clicking on an already written channel in the script editor and by choosing another in the menu Channels in the toolbar



#### 4.8. « Logic channels » key



Record: (200µs)  
Stopped

Logic channels: 1

Color: [Color Selection]

Validity:

Ground: 5,17,4,3  
12 V: 16  
Alarm A: 15-2  
Alarm B: 14  
Alarm C: 1

Logical channel '1'

double thickness  
 Change color

Logic Off


1	1 (p13)	Vlog 1	0	9 (p 9)	
0	2 (p25)	Vlog 2	1	10 (p21)	
1	3 (p12)	Vlog 3	0	11 (p 8)	
1	4 (p24)	Vlog 4	0	12 (p20)	
1	5 (p11)		0	13 (p 7)	
1	6 (p23)		0	14 (p19)	
1	7 (p10)		0	15 (p 6)	
0	8 (p22)		0	16 (p18)	

- **Logic channels:** selection of the color of the channel on screen and its name
- **Validity:** validation of the data acquisition and printing of the logic channels. Selection of the number of logic channels between 1 and 16. Attention: the number of displayed channels may be lower if the height of the display zone is too low.
- **Logic channel "1":** doubles the thickness and selects a color for the channel when reaching the value 1. This function makes it clearer whether a channel is equal to 1 and not 0.

#### 4.9. « Validity » key




Selection of the channels displayed on screen, printed on paper or recorded on memory or file.



After pressing this key, select the channels you want to display on screen, print or record into the internal memory or on file. Check or Uncheck Select All to select all or unselect all a board's channels.


Proceed the same way to validate the functions between channels (treated as additional channels). Mathematical functions with script errors are printed in red.

#### 4.10. « F(t) » key



Real time display of the measurements on the LCD screen with 1000 dots.

The **F(t)** display mode (oscilloscope mode) allows you to visualize the validated channels in real time on screen, make measurements with cursors, add automatic measurements for amplitude and time, then save into a file or print on the acquisition paper when finished.



➔ **Setup Screen:** Configuration of the measurement display on screen

- Display **F(t)**, Display **XY**
- **Calculation validity** opens up a small window where you can select the number of channels concerned with the calculations and the selected function. You can move this window by pressing on the top left of it. You access the adjustments by pressing on the top right of it.

```
Voie A 4[Fréq] 25.00 Hz
Voie A 2[Max]= 15.943 V
Voie A 3[Pic_Pic] 2.3453 V
Voie A 4[Bas]=-3.7540 V
```

- **Display boundary** to display the limits on screen.
- **Vertical screen.**
- Display of the **nouns**, of the **digital** values, possibility to show up a window for the **digital** values.
- Possibility to customize the screen by changing the **background colors**, **reticules** and **cursors**. Possibility to display your own **background**.

- 
- **Diagram:** Display on screen of diagrams.
    - You may display **logic channels outside the screens** above (**top**) or below (**bottom**) and adjust the **height** of the logic channels.
    - **1/2 screens:** you can display diagrams on 1 or 2 screens
    - **Number of screen:** change the number of the screen(s)
    - You can display diagrams in **logarithmic mode**.
    - **Number of divisions:** number of divisions of the screen or of the paper, up to 20.
    - **Position of channel:** dispatch of the channels in the diagrams; select the channel you want and press the arrows to move it.
  
  - **Print screen:** You can print the displayed screen.
  
  - **Fullscreen mode:** **The menu is no more displayed and all the screen space is used by the graph. To return to a normal visualization click anywhere on the screen.**
  
  - **Validity:** gives you direct access to the « Validity » key to select the channels to display.
  
  - **Freeze screen:** freezes the measures on screen to make measurements with cursors, calculations, saves or to print measurement son screen (1000 dots) under F(t) mode.  
You will also have access to:
    - **Restart screen:** unfreezes the screen
    - **Cursors Time** displays the horizontal cursors (2) to make time measurements on the display; move the cursor by selecting 1 or 2, then turn the code-selection switch, or click on the cursor with the mouse if connected
    - **Cursors Voltage** displays the vertical cursors (2) to make amplitude measurements on the display; proceed as for the time cursors to move them. You may also change the caliber / zero to zoom or move your measurement on screen, zoom between cursors, manually select the values of the calibers and restore the original calibration.

By clicking on the window associated with time cursor, the way the information is displayed can be changed:

- Values follow the curves:** Time values are directly displayed on the graph
- Transparency:** Choose if curves or cursor values must be printed in the foreground.

- **Time base:** change the time base of scan under F(t) display from 100 $\mu$ s/div to 10min/div; each division includes 100 display dots, hence a sampling cadency of 1 Mech/s (1 $\mu$ s) at 0,16 ech/s (6 s).
- **Auto Set:** Allows an auto set of the pending display.



Under F(t) mode (oscilloscope mode), the scan is in « triggered » mode for time bases < 100 ms/div, and in « scrolling » mode above.

In « triggered » mode, you can set the trigger of the displayed data acquisition. You can then select:


- the triggering channel
- the triggering active edge
- the vertical and horizontal positions of the trigger.

→ **Analyzer FFT:** This mode makes it possible to determine the frequency response of the selected signal. Pressing this key opens a window with a few settings:


- **Opacity:** you can adjust the opacity of the FFT analysis by using the arrows to increase or decrease
- **Window:** you can adjust a window (Hann, Blackmann, Hamming) to increase the efficiency of the analysis
- **Sample number:** to change the number of samples
- **Sample:** to adjust the time of the signal

You can also change the parameters of the reticule and select the channel to analyze.

#### 4.11. « XY » key



The **XY** display mode allows you to visualize the validated channels in real time on screen in comparison with each other. One of the channels defines the horizontal axis; the other channels define the dots according to the vertical axis.



→ **Setup Screen:** Configuration of the measurement display on screen

- Visualization **F(t)**, Visualization **XY**
- **Display boundary** to display the limits on screen.
- **Dot** or **Vector**: Display either of the true dot or of the vector between the dots. If the frequency of the channels is higher than the frequency of dot display (0.1 Hz), you may see false pictures.
- Possibility to customize the screen by changing the **background colors**, **reticules** and **cursors**. Possibility to display your own **background**.

→ **Print screen:** You can print the signal displayed on screen

→ **Setup Plot : Print options**

→ **Pen down (yes or no):** If you press Yes, the current curves show up; if you press no, the display does not stop, but remains hidden (the display keeps on but is not visible)

→ **Reset:** This key allows you to erase the curve and relaunch on a blank page

→ **Channel X:** selection of the channel on the horizontal axis (screening)

→ **Channel Y:** selection of the channel on the vertical axis; you may select several ones.


→ **Cursor**: Displays the vertical and horizontal to make the measurements.

→

#### 4.12. « Numeric » key



The **Numeric** display mode makes it possible to visualize the digital values of the validated channels in real time on screen. No action is possible in this mode.





### 4.13. « Trigger » key



Channels data acquisition programming in Memory, File and Go/Nogo modes.

Selection of the actions after data acquisition or display and validation in real time of the data back-up.

A screenshot of a software interface for configuring a trigger. On the left, a vertical blue bar contains six channel labels: A1, A2, A3, A4, A5, A6, and FA, each with a black input field and a green checkmark. Below this is a "Logic On" section with a grid of 12 colored squares. The main area is titled "Trigger" and has a "File" tab selected. It contains two panels: the left panel has "USB/" and "File\_Record\_000X" buttons, "File length:" (No limit), and "Sample Rate:" (200µs) settings; the right panel has a checked "save secondary file" checkbox, a "Record Channels" button, and "Sample Rate:" (200µs) settings. Below these are "Start" and "Automatic" buttons, a "Next..." button with a "Change Setup" arrow, and a "Modify" button. At the bottom, there are checkboxes for "Add File REC Title:", channel recording status for "A" and "F", and a warning icon with the text "Warning : The sampling rate is too fast for the number of channels". The top of the interface shows a toolbar with icons for file, play, stop, and home, along with a clock showing 19:14:44.

The programming of the triggers is different according to the current mode (Direct, Memory, Template or File).

See the chapter about the current mode for a more detailed description.

#### 4.14. « Replay » key

Display on screen of the data acquisitions available in the internal memory or in files in the hard drive or a USB stick.



This function has nearly all the same commands as the display functions « **XY** » and « **F(t)** ». The only differences comes from « **File manager** » command that allows you to select a file or save the current display into a file and the « **Load set up** » menu that will load the configuration and the scripts associated to the displayed file.

##### → Files manager:

- **Load file:** selection of the file to display
- **Save data to disk:** saves the current display into a file (internal memory / USB stick)



When the size of the acquisition data to display is important, it may take time to load and display dots.

In this case, the display is made in 2 steps:

- one quick phase for the display of the general shape of the curve : some dots may not appear
- one phase where all data acquisition dots are displayed: an indication of the percentage of advancement is displayed at the bottom of the screen

#### 4.15. « Start/Stop » key

This key has various effects according to the current mode of the appliance.



- **Memory** mode: launching the data acquisition into internal memory; the appliance waits for the **initial** trigger condition
- **Go/Nogo** mode: launching the data acquisition into internal memory; the appliance waits for the **initial** trigger condition
- **File** mode: launching the data acquisition to file; the appliance waits for the **initial** trigger condition

In any case, you only have to press the « Start/Stop » key once again to stop the record before the condition of **Stop**.



In **Memory**, **Go/Nogo** or **File** mode, the appliance switches automatically to the display of the current data acquisition

The following items appear on top left of the screen:

- the number of the current block, if possible
- the current sampling rate
- the state of acquisition (waiting for trigger, acquisition xx%, ...)
- the opening of a back-up file, if required
- a bargraph showing the percentage of data acquisition made and the percentage of data acquisition displayed

#### 4.16. « Screen copy » key

You can copy the display on screen to a file:

- use the Screen Impr. key or your PC keyboard
- use the Print Screen key of the recorder



The file will be created either onto an USB stick, if present, or onto the hard disk.

The name of the file will be bmpxxxxx.bmp (incrementing name).

On the hard disk, the files will be saved into the FolderBMP directory.

You can either copy this directory onto an USB stick or delete it. You can use a ftp link to download or erase the files.

#### 4.17. « Home » key



This key gives you access to the main menu with all the keys.

## 5. TRIGGERS

This chapter describes all triggers available in this appliance.

You can use them with:

- « **Setup** » key, parameters « **Alarm A, B and C** »
- « **Trigger** » key, parameters « **Start** » and « **Stop** »

### ➔ edge/level trigger

- on an edge: you need a change of state  
Example: channel A1, positive edge, threshold = 0 V: trigger when the signal turns from negative state to positive state.
- on a level: you don't need to pass a threshold  
Example: channel A1, high level, threshold = 0 V: trigger if the signal is positive

Alarms only have level triggers.

### ➔ **Analog / Logical channels**: trigger according to analogical or logic channels


- ### ➔ **Analog channel** (only one threshold) / **Combination Analog channel** (several thresholds):
- triggering from only one channel and one threshold
  - or complex triggering from several channels and several thresholds; see description below.

Such complex triggering is only possible with analogical channels.

## 5.1. Trigger with Combination Analog channel

After selection of the triggering on analogical channels, the following line on screen allows you to set up the triggering condition. It depends on the selection between only one or several thresholds.

### 5.1.1. Analog channel (only one threshold)



→ **Channel:** selection of the channel on which the triggering threshold is applied


→ **Threshold 1 / Threshold 2:** selection of the threshold to set up; each channel is tested against 2 thresholds. For example, you can program an initial condition on the channel A1 and the threshold 1, and a stop condition on the same channel A1 and the threshold 2.

→ **Level/Edge:**

- Level: Select of the level, either > superior, or < negative.
- Front: Selection of the active front of the channel against the threshold. For example: the condition A1 (s1)↑ 0.500A becomes TRUE when the channel A1 becomes higher than 0.5 A.

### 5.1.2. Combination Analog channel (several thresholds)

After selection of a trigger according to Combination Analog channel, there are several ways to set up the complex triggering condition:



- ➔ One threshold (OR): the first achieved condition validates the trigger
- ➔ All thresholds (AND): all conditions must be simultaneously achieved to validate the trigger
- ➔ Slope (OR): trigger according to the slope of signals; the first achieved condition validates the trigger
- ➔ Channel: selection of the channel of the triggering threshold
- ➔ Threshold 1 / Threshold 2: selection of the threshold to set up; each channel is tested against 2 thresholds. For example, you can test an initial condition on the channel A1 and the Threshold 1, and a stop condition on the same channel A1 and the Threshold 2.


**→ Level/Edge:**

- Level: Selection of the level, either > superior, or < negative.
- Edge: Selection of the active edge of the channel against the threshold. For example, the condition A1 (s1)↑ 0.500A becomes TRUE when the channel A1 becomes higher than 0.5 A.

**→ Add:** Allows you to add an additional channel. To suppress a channel, press its value (for example 0.00 V) in the table on the left and select « **Erase** ».



5.1.3. Threshold triggering




Example: the trigger hereabove is  
Trigger if

- Channel A1 increasing and equal to the threshold S1 with value 0.500 A OR
- Channel A2 increasing and equal to the threshold S1 with value 0.500 V OR
- Channel A2 increasing and equal to the threshold S2 with value 0.500 V OR
- Channel A3 decreasing and equal to the threshold S1 with value 0.500 V

The same analysis is valid for the trigger AND (all thresholds).

5.1.4. Slope trigger



Example: the trigger hereabove is


Trigger if

- Channel A1 increasing with a positive slope of 0.500 V over a 1s period OR
- Channel A2 increasing with a positive slope of 0.500 V over a 1s period OR
- Channel A3 increasing with a positive slope of 0.500 V over a 1s period

This triggering mode is not used with alarms.

## 5.2. Trigger with Logical Channels

After selection of the triggering on Logic Channels, the following line allows you to set up the triggering condition.



The 16 logic channels can be used in the triggering instruction:

- either active at 0 state (less than 1.6 volt)
- or active at 1 state (higher than 4.0 volts)
- or not used at X.

AND/OR: the mathematical function And/Or is applied on each channel.

## 6. MATHEMATICAL CALCULATIONS

You can make mathematical calculations on the results of the data acquisitions.

You can access them from the « **F(t)** » function and the « **Replay** » if a data acquisition is displayed on screen.

### 6.1. Definitions

Press the key « **Setup Screen** », then select « **Calculation validity** » to open the calculation window. Press on top right of the window to access the set-up:

- **Opacity**: to adjust the level of opacity of the window
- **Mathematical calculation**: to set the number of simultaneous calculations (max. 6).
- Select the **name of the channels** to which you want to assign the calculation function, then select the **calculation function** for each channel.

20 various mathematical calculations are suggested in 3 categories:

- **Amplitude**: min. value, max value, peak to peak, low, high, amplitude, on oscillations
- **Time**: frequency, period, increase time, decrease time, positive width, negative width, positive and negative cyclic ratio
- **Calculation**: average, cyclic average, RMS and cyclic RMS

Up to **6 calculations** can be displayed on screen simultaneously.

The values are displayed in rectangles above the diagrams where appear:

- the number of the channel (with the corresponding color)
- the type of calculation
- the value of calculation

The calculations are made in real time; their result is updated every 300 ms.


The calculation is made on the 1000 dots displayed on screen. Hence, the time resolution is 0.1%.













Calculations can be made on every channel. However, you cannot made calculations:

- on addition channels functions of other channels  
(example  $F3=A1+B2$ )
- if the channels have not been recorded (validation ON/OFF)

## 6.2. Types de calculations



Explicative scheme	Math. function	Calculation	Observation
	Minimum		<b>The lowest value of the negative voltage</b>
	Maximum		<b>The highest value of the positive voltage</b>
	Peak to Peak	Max-Min	
	Low		<b>The most frequent value under the median</b>
	High		<b>The most frequent value above the median</b>
	Amplitude	High-Low	
	Positive over-oscillation	$\frac{Max - High}{Amplitude} \times 100$	
	Negative over-oscillation	$\frac{Low - Min}{Amplitude} \times 100$	
	Frequency	$\frac{1}{Period}$	<b>Average frequency</b>
	Period	$\frac{Duration\ of\ N\ periods}{N}$	<b>Average duration of a complete cycle as calculated on as many periods as possible</b>

	Time of increase	$T_1 = 10\%$ Amplitude $T_2 = 90\%$ Amplitude Time of increase = $T_2 - T_1$	
	Time of decrease	$T_1 = 90\%$ Amplitude $T_2 = 10\%$ Amplitude Time of decrease = $T_2 - T_1$	
	Positive impulsion width	Measurement of the time of the <u>1<sup>st</sup> positive impulsion</u> made at 50% of the amplitude	
	Negative impulsion width	Measurement of the time of the <u>1<sup>st</sup> negative impulsion</u> made at 50% of the amplitude	
	Positive cyclic ratio	$\frac{\text{positive impulsion duration}}{\text{period}}$	
	Negative cyclic ratio	$\frac{\text{negative impulsion duration}}{\text{period}}$	
	Average	$Moy = \frac{1}{N} \times \sum_{i=1}^N V_i$ N: total number of dots	<b>Calculation on the whole graphic window</b>
	Cyclic average	$Moy = \frac{1}{(N_2 - N_1)} \times \sum_{i=N_1}^{N_2} V_i$ $N_2 - N_1$ : number of dots between full periods	<b>Calculation on as many periods as possible</b>
	RMS	$RMS = \sqrt{\frac{1}{N} \sum_{i=1}^N (V_i)^2}$	<b>Calculation on the whole graphic window</b>
	Cyclic RMS	$RMS = \sqrt{\frac{1}{(N_2 - N_1)} \sum_{i=N_1}^{N_2} (V_i)^2}$	

## 7. MEMORY MODE

This chapter describes the **Memory Mode** to record the measurements made on the channels in real time into internal memory.


You can start and stop the data acquisition under various conditions.

You can also activate a simultaneous back-up of the measurements on a file.

### 7.1. Set-up and triggering of the data acquisition

Press the « **Trigger** » key.

Set-up of the data acquisition into internal memory



→ **Number of blocks:** Dividing the internal memory into blocks:

- 1, 2, 4, 8, 16, 32, 64 or 128
- Erase blocks: deleting all blocks: the pending block is #1

→ **Sample Rate:** sampling rate of the channels

- advancement paced **internally** from **1 μs to 10 min**
- advancement paced **externally** through the **Logic channel 16**

• **save secondary file:** simultaneous record of the measurements on a file

- **Without:** no simultaneous back-up
- **With:**
  - **File name:** directory and name of the back-up file
  - **Record channels:** shortcut of the « **Validity** » key to select the channels to record
  - **Sample Rate:** sampling rate of the channels



- 
- **Pre Trigger:** set-up of the position of the initial trigger in the data acquisition
    - Acquisition before and after triggering (before and after launching); See chapter « Memory mode » (Possibility to prevent the triggering during the pre-triggering phase)
  
  - **Start:** start condition of the data acquisition
    - **Manual:** with the « **Record** » key
    - **Trigger:** on combination of analogical and logic channels; see chapter 5 « **Triggers** »
    - **Awaiting:** after a delay or at a specific date and hour
    - **Automatic:** immediate; automatic stop when the block is full
  
  - **Stop:** stop condition of the data acquisition
    - **Automatic:** when the block is full
    - **Trigger:** on combination of analogical and logic channels; see chapter « **Triggers** »
    - **Double Trigger** start mode: see the following chapter.



« **Impossible** » shows up when all possibilities of back-up are exceeded: reduce the sample rate or the number of channels



See chapter **File Mode** to know the restrictions of the record on file

- **Next . . .:** actions after the end of the data acquisition
  - **Save in file:** save the data acquisition to a file of the real time back-up has not been validated (or is impossible)
  - **Send Email:** this option shows up if you previously added an e-mail address in the « **Additional Options** » in the « **Setup** » menu
  - **Plot:** drawing the simultaneous data acquisition into memory
  - **Stop:** no action
  - **Rearm:** restarts the drawing; return to waiting the launching condition
  - **Change setup:** loading a configuration; return to waiting the launching condition

## 7.2. Sampling period

When the frequency of the input signals is too high, it is necessary to back up the measured signals at a high sampling rate: this is the **Memory Mode**.

Sampling is measuring up the instant value of a signal at a regular period and storing these values.

To get a satisfactory data acquisition of a periodic signal, you have to select a sampling period compatible with the period of the signals on the input poles of the recorder.



A 10-dot accuracy per signal period is minimum to get a satisfactory drawing

## 7.3. Internal memory, blocks

You can part the memory available on the recorder into blocks that will be filled successively during the data acquisition.

La acquisition data amount is worth  $N / (B * V)$

N= total memory required

B = number of blocs

V = number of channels to record

Example: 32 Mwords memory, 16 blocks on 3 channels 'ON': you will get

$$N = 32\ 554\ 432 / (16 * 3) = 699\ 050 \text{ words / channel.}$$

Any new data acquisition automatically enters the first empty block (in ascending order).

When all blocks are full, any new data acquisition shifts the previous blocks: the block number N is shifted into block N-1; the 1<sup>st</sup> block will be lost. The new data acquisition takes the place of the last block.

## 7.4. Start position

The acquisition into a memory block is based on the principle of « rotating memory »:

- The memory is filled from the initial condition
- The memory is filled as long as the stop condition is not valid; if the memory is full, the filling restarts from the beginning of the memory zone (block)

Hence, the memory block always contains the last N samples.


The user always has the possibility to choose the moment where the samples in memory will be frozen; to do so, all you need is a delay between the start moment and the begin of the effective memorization process.

This delay may be positive or negative: stored samples may be either before or after or both before and after the triggering moment.


You can also not deactivate the trigger: you will be able to test the trigger before triggering for the case where the trigger activates before the end of this phase.

In case of repetitive signals, you will deactivate the trigger.

Memorization with a -50% delay  
in reference to the begin of memorization



Memorization with a +50% delay  
in reference to the begin of memorization



## 7.5. Double Trigger Mode

In this mode, you use a start trigger and a stop trigger.

The values will be measured between these two triggers.

The data acquisition will stop automatically when:

- the stop condition is valid, or
- the memory block is full



An information window sums up the general set-up of the data acquisition:

- channels and functions between validated channels for data acquisition
- number of dots per channel (function of the number of blocks)
- total time of data acquisition (function of the sampling rate)
- position of the trigger (function of pre-triggering)

Channels recorded :

A: 1 2 3 4 5 6



42666K words/channel  
Acquisition time : 9.21D

## 7.6. Recording

The launching of the data acquisition is made by pressing of « **Start/Stop** » key.



The following items appear on top left of the screen:


- the number of the current block, if possible
- the current sampling rate
- the state of acquisition (waiting for trigger, acquisition xx%, ...)
- the opening of a back-up file, if required



If the data acquisition time of the recording is less than 2 minutes, all the data acquisition is displayed.  
You cannot leave this page in this case: only when the data acquisition stops can you change of menu.



For longer acquisition times, you can zoom on a part of the data or change of page.  
When changing of menu, you can return to the data acquisition by pressing the "**Record**" key.



Additional menu keys:

➔ Display:

- Total: the whole memory content is displayed and refreshed while data acquisition.
- Zoom: the filling rate shows you the acquisition state; it gives you access to the time and voltage cursors.
- Scrolling: displays the pending acquisition.

➔ Forcing trigger: You can force the triggering of the channels.



You cannot display another block than the current one, draw or save into an acquisition file, as soon as it is not over.

At the end of the data acquisition, the appliance automatically switches to the « **Replay** » screen.

## 7.7. Replay

Display of the data acquisition available in internal memory or in files.  
Possibility to start the drawing on paper.



On top left of the screen, it shows up:

- the number of the displayed block
- the sampling rate of the block
- the date of the trigger
- the number of dots per channel in this block

- **File manager:** Selection of the memory block or of the file to display; possibility to save the data acquisition
- **Load set up :** Load the set up and the scripts associated to the currently visualized file.
- **Setup Plot:** Set-up of the acquisition plot; key « Start plot »
- **Setup Screen:** Set-up of the display on screen; See chapter Use
- **Diagram:** Display of diagrams on screen; See chapter Use
- **Validity:** Validation of the channels ON/OFF
- **Cursor Time:** vertical cursors, zoom; See chapter Use
- **Cursor Voltage:** horizontal cursors; See chapter Use
- **Analyzer FFT:** Determine the frequency response of the signal; See chapter Use

## 8. GO/NOGO MODE

This chapter describes the **Go/Nogo Mode** to record the calculations made on the channels in real time into internal memory.


You can launch the data acquisition under various conditions. The acquisition **Stops** when the measures exceed a previous acquisition as defined as a **Go/Nogo**.

You can activate a simultaneous back-up of the measurements onto a file.

### 8.1. Set-up and triggering of the data acquisition

Press the « **Trigger** » key.

Set-up of the data acquisition into internal memory with a template.



- **Number of blocks:** parting of the internal memory into blocks
  - 1, 2, 4, 8, 16, 32, 64 or 128
  - Erase blocks: deleting all blocks: the pending block is #1
  
- **Sample Rate:** sampling rate of the channels
  - advancement paced **internally** from **1 µs to 10 min**
  - advancement paced **externally** through the **logic channel 16**
  
- **save secondary file:** simultaneous record of the measurements on a file
  - **Without:** no simultaneous back-up
  - **With:**
    - **File name:** directory and name of the back-up file
    - **Record channels:** shortcut of the « **Validity** » key to select the channels to record
    - **Sample Rate:** sampling rate of the channels



- **Start:** Start condition of the data acquisition
  - **Manual:** with the F2 key « **Forcing Trigger** »
  - **Trigger:** on combination of analogical and logic channels ; See chapter **Triggers**
  - **Awaiting:** after a delay or at a specific date and hour
  - **Automatic:** immediate; automatic stop when the block is full
  
- **Pre trigger:** set-up of the position of the start trigger of the data acquisition
  - acquisition before and after triggering; See chapter « Memory mode »
  
- **Channels for Go NoGo:** selection of the channels to compare with the template (when pressing the « Go/Nogo channels » key, you have access to the definition of the template)



« **Impossible** » shows up when all possibilities of back-up are exceeded: reduce the sample rate or the number of channels



See chapter **File Mode** to know the restrictions of the record on file.


- **Next . . .:** actions after the end of the data acquisition
  - **Save in file:** save the data acquisition to a file of the real time back-up has not been validated (or is impossible)
  - **Send Email:** this option shows up if you previously added an e-mail address in the « **Additional Options** » in the « **Setup** » menu
  - **Plot:** drawing the simultaneous data acquisition into memory
  - **Stop:** no action
  - **Rearm:** restarts the drawing; return to waiting the launching condition
  - **Change setup:** loading a configuration; return to waiting the launching condition

## 8.2. Creating of the frame

In the « **Trigger** » page, set up the « **Go/Nogo Channels** » parameter by selecting a channel and a logic operator (AND or OR)

Launch a normal data acquisition or display a previously recorded file with the « **Replay** » function.

The appliance displays the current template. It is characterized with 2 curves (min. and max.) around the channel selected as a reference for the template. The 2 curves are saved into ROM.



Pressing « **Files manager** » and then « **Change Go/Nogo** », you have access to the following page:


- ➔ **Color**: change the color of the template
- ➔ **DX** and **DY**: these keys draw the 2 curves min. and max.
- ➔ **Start** and **End**: restriction of the amount of memory where the test of Stop trigger is made
- ➔ **Save**: as soon as the template is right, you can save it into ROM.
- ➔ **Esc**: Back to the previous page; the template remains unchanged

### 8.3. Use of the frame

The comparison with the template stops the data acquisition. This comparison will be made on the « **Go/Nogo Channels** » selected in the « **Trigger** » page.

The information window at the bottom of the « **Trigger** » page sums up the general set-up of the data acquisition:

- channels and functions between channels validated for data acquisition
- channels and functions between channels compared to the template
- number of dots per channel (function of the number of blocks)
- the total acquisition time (function of the sampling rate)
- the position of the trigger (function of the pre-triggering)



The data acquisition is made as previously (See chapter **Memory Mode**).

When the memory block is full, the appliance checks that all the dots on the Go/Nogo Channels are between the 2 reference curves (min. and max.) of the template.


If all dots are between the curves, the data acquisition restarts (within the same block). Else, the data acquisition stops.

## 9. FILE MODE

This chapter describes the **File Mode** to record the calculations made on the channels in real time into a file. The start and stop of the plot can be triggered under various conditions.

### 9.1. Set-up and triggering of the data acquisition

Push the « **Trigger** » key.  
Set-up of the data acquisition to a file.



- **File name:** directory and name of the data acquisition file
  - directory of the data acquisition file
  - name of the data acquisition file
- **File length:** selection of the length of the file (unlimited...)
- **Sample Rate:** sampling rate of the channels
  - advancement paced **internally** from **1  $\mu$ s to 10 min**
  - advancement paced **externally** through the **logic channel 16**
- **Add a title to REC files:** Possibility to add a title to a file which will appear in the upper toolbar when the file is displayed.

- 
- **Save secondary file:** simultaneous record of the measurement to a file
    - **Without:** no simultaneous back-up
    - **With:**
      - **File name:** directory and name of the back-up file
      - **Record channels:** shortcut of the « **Validity** » button to select the channels to record
      - **Sample Rate:** sampling rate of the channels
  
  - ➔ **Start:** Start condition of the data acquisition
    - **Manual:** with the F2 key « **Forcing Trigger** »
    - **Trigger:** on combination of analogical and logic channels ; See chapter **Triggers**
    - **Awaiting:** after a delay or at a specific date and hour
    - **Automatic:** immediate; automatic stop when the block is full
  
  - ➔ **Stop:** stop condition of the data acquisition
    - **Automatic:** when the block is full
    - **Trigger:** on combination of analogical and logic channels; see chapter « **Triggers** ». See chapter **Triggerings**.
    - **Double Trigger** start mode; see chapter **Memory Mode**.
  
  - ➔ **Pre-trigger:** set-up of the position of the start of the data acquisition
    - Pre-trigger of the acquisition (before start) ; See chapter « **Memory Mode** »
  
  - ➔ **Post- trigger:** set-up of the position of the start of the data acquisition
    - Post-trigger of the acquisition (after start) ; See chapter « **Memory Mode** »
  
  - ➔ **Next . . . :** actions after the end of the simultaneous data acquisition
    - **Send Email:** this option shows up if you previously added an e-mail address in the « **Additional Options** » in the « **Setup** » menu
    - **Plot:** drawing the simultaneous data acquisition into memory
    - **Stop:** no action
    - **Rearm:** restarts the drawing; return to waiting the launching condition
    - **Change setup:** loading a configuration; return to waiting the launching condition

## 9.2. Annotation

During the data acquisition, you can annotate the file; a vertical line associated with a text will be integrated to the file when the user presses the F9 key (Annotation).

In case of power shortage, if the file has not been correctly closed, the annotations will be lost).

The SeframViewer software makes it possible to display these annotations onto a PC.

### **9.3. Limitation**

The real time data acquisition onto a file is limited by the transfer rate between the inputs and by the hard drive write speed.

It is advisable not to create too big files: they are long to read.

As an example, circa 5 min are required to read a 170 Mo "REC" file with the Flexpro software.

### 9.3.1. Binary file

The maximum transfer rate onto a hard drive is 6 Mwords/s.

To know the number of channels that you can record at a given acquisition period, follow the following formula:

$$\text{*number of channels} = 6\,000\,000 \times \text{acquisition period}$$

Example: acquisition period: 10  $\mu$ s  
Number of channels = 6 000 000 x 10  $\mu$ s = max. 60 channels



« **Impossible** » shows up when all possibilities of back-up are exceeded: reduce the sample rate or the number of channels

## 10. POWER ANALYSER

### 10.1. GENERAL

The circuit analysis option makes you possible to measure powers and harmonics. The measured values can be displayed in real time or recorded. The channels that are not used for the measurements of power or energy values keep on working normally. For example, in case of three-phase current, you may have interest to record the neutral current on other channels. It is also possible to record logic channels.



THIS FUNCTION IS NOT POSSIBLE FOR APPLIANCES THAT DO NOT INCLUDE AN ISOLATED 6-CHANNEL INPUT CARD

Launching the circuit analyzer includes:

- Start: Press the « **POWER ANALYSIS** » key
- Description of the circuit and cables: « **Setup Analyzer** » menu
- Selection of the selected type of analysis and value: « **Trigger** » menu
- Display (Oscilloscope, Numeric, Harmonics) : « **Visualization real time** » menu
- Data acquisition: « **Start/Stop** » key



**Attention:**

The connection of the inputs on the installation to test should be made by an authorized personal. Connect the earth pole before connecting the live lines.



## 10.2. Installation: "Set-up Analyzer" Menu

In the main menu, by pressing the « **POWER ANALYSIS** » key, you directly access the configuration page of the channels. You can also access this page through the « **Setup Analyzer** » key.

In this page, you select the type of circuit and the parameters of the inputs.



 The screenshot shows the "Setup Analyzer" interface. On the left, a blue sidebar displays real-time data: U1: 241.9 V, U2: 272.0 V, U3: 270.4 V; I1: 100.8 A, I2: 100.8 A, I3: 100.8 A; P1: 18.67 KW, P2: 18.67 KW, P3: 56.02 KW; and Freq: 50.000 Hz. The main area is titled "Three Phase Star Record: Stop" and contains several configuration sections:
 

- Type of circuit:** Radio buttons for Single Phase, Star (selected), Delta, and Delta Aaron. A "Frequency <60Hz" field and a "Reset" button are also present.
- Voltage:** Radio buttons for Direct and transformer. A "Nominal Voltage" field is set to 240 V.
- Current:** Radio buttons for Current Clamp (selected), Shunt, and C.T(Transfo.). A "Ratio" field is set to 1 A / 1 V. An "External sensor" button is also visible.
- Nominal Current:** A field is set to 100 A.

 At the bottom, a schematic diagram shows a three-phase star connection with three phases (yellow, green, red) and a neutral line (blue). Six measurement points are indicated by colored circles and numbered 1 through 6.

### ➔ Type of circuit:

- selection of the basis set-up of the circuit (**Single-phase**, three-phase (**Star / Delta / Delta Aaron**)).
- Selection of the **frequency** (< 60 Hz / < 500 Hz / < 1000 Hz)
- **Reset:** to set up the channels in a basis configuration.

### ➔ Voltage:

- « **Direct** » or « **Transformer** ». Select this set-up if the circuit voltage is submitted to a transformer. You have to type the transformation ratio.
- **Nominal Voltage:** The appliance automatically selects the right caliber. You only have to specify the nominal voltage of the circuit. Attention: if this value is too far from the true voltage value, it may induce excessive or inaccurate caliber values.

- **Current:** The same is worth as for the voltage; you select the type of current input (clamp, transformer, shunt). In each configuration, you must select the associated parameters:
- for « **Current clamp** »: Primary current, Secondary voltage (these are intensity/voltage clamps)
  - for « **C.T. (Transfo.)** » (transformer + shunt): Primary and secondary currents and value of the shunt
  - for « **Shunt** »: value of the shunt, in Ohms
  - the **nominal current** is also defined like the nominal voltage
  - possibility to assign an **external sensor** to the selected channels.
- The data acquisitions are synchronized with the calculation of the frequency on channel 1.
  - In three-phase mode, the circuit is symmetrical: you can only have 2 used intensity inputs; hence, the third one will need to be calculated.

### Cables and check:

The cables of the circuit are directly displayed. Any mistake with the cables may lead to false measurement values.

The color of the channels matches the color of each input.

You can see that the U1, U2 and U3 voltages are linked with the odd inputs A1, A3 et A5. The I1, I2 and I3 intensities are linked with the even inputs A2, A4 et A6.

For example, in Aaron Triangle mode, the free channels will be A5 and A6

### Fresnel diagram:

You can check the accuracy of the cable assembly by displaying the Fresnel diagram. The length of the vectors is not proportional to the effective value of the intensities: the user needs to check the consistency of what is specified.

The position of the voltage vectors is calculated with reference to the V1 voltage.

Attention: The angles are of the significant voltages/intensities either for the shape factor (P.F) or of the fundamental values.

Hence, you can know whether the connection is direct or reverse. The intensity vectors are calculated with reference to the corresponding voltages.



**Attention:** Mistakes may have been done even if nothing weird appears. In any case, the cable mounting must be achieved with caution by a qualified personal.

### Warning messages:

These messages lay appear in red at any moment on top of the screen:

- Impossible to synchronize the signal: the frequency is wrong, the signal is too weak or too noisy.


- Caliber overrun: The voltage or the intensity is too high for the specified nominal value; you have to change the value or use another probe.

### 10.3. Display of the signal:

By pressing the Direct Display key, you get access to the following parameter windows.

You can access this page even during data acquisition.

Each of these windows can be deactivated.



→ **Display Fresnel:** display of the signal and the RMS values and frequency for the inputs (see the previous paragraph)

→ **Display Parameters:** display of the values of each defined parameter (see the following paragraph)

→ **Display Harmonics:** This window is updated ca. 4 times per second.

Selection of the channels: you can select either all voltage channels (U1,U2,U3), all current channels (I1,I2,I3), all circuit channels (U1,U2,U3+I1,I2,I3) or only one channel (these channels are also used to record harmonics (see paragraph 11.4.2))

→ **Display Oscilloscope:** The oscilloscope mode makes it possible to recognize the exact shape of the signals and helps find cable mounting errors.

- The time base depends on the frequency of the signal (at least one rotation)
- You can add additional channels and new screens

- The used calibers are indicative and do not reflect the true values of the inputs (the min. and max. positions match the maximum authorized values)
- **Analyse file:** You can open a new text file (**RT\_Analyse.txt**) that contains the data of the parameters and instant harmonics.
- **Record a new value:** to record a value at the very moment when you press the key
  - **Open a new file:** pressing the INIT key updates the page and clears every previous values
  - **Read file:** displays all recorded values.
- You can copy the screen any time into a bmp file.

## 10.4. Trigger Menu

When the appliance is set up, you have to select the type of measurement to make: power analysis or energy analysis. You select the parameters by pressing directly the channel you want on the left of the screen.

The screenshot displays the software interface for a power analyser. The top status bar shows 'Three Phase Delta Record: Stop', the time '10:03:56', and the user 'HOME PRINCIPAL'. The left sidebar contains a list of measurement data for three channels (U1, U2, U3) and their corresponding currents (I1, I2, I3), along with various power and THD metrics. The main area is titled 'Trigger' and contains a 'File' section with a folder path 'HD/FolderREC/' and a file name 'File\_Record\_000X'. Below this, there are controls for 'File length' (set to 'No limit') and 'Sample Rate' (set to '20ms'). A checkbox labeled 'Record Harmonics file' is checked, and a 'Speed' control is set to '1 s'.

U1: 587.8 V  
U2: 331.3 V  
U3: 262.2 V  
I1: 140.1 A  
I2: 49.7 A  
I3: 91.6 A  
F = 50.000 Hz

U1rms= 587.8 V  
U2rms= 331.3 V  
U3rms= 262.2 V  
I1rms= 140.1 A  
I2rms= 49.7 A  
I3rms= 91.6 A  
UICF= 0.000  
I1THD= 97.8 %  
I2THD= 58.5 %  
I3THD= 40.0 %  
P T= 60.48 KW  
P T= 60.48 KW  
P T= 60.48 KW  
P T= 60.48 KW  
P FT= 0.853  
Freq= 49.983 Hz

Three Phase Delta Record: Stop 10:03:56 HOME PRINCIPAL

### Trigger

File

HD/FolderREC/ File\_Record\_000X

File length : No limit

Sample Rate : 20ms

Record Harmonics file

Speed : 1 s

### 10.4.1. Parameter acquisition file

You first have to set up the acquisition period, the length and the name of the file and the directory of use.

Contrarily to the file mode, there is no trigger: as soon as the recording is started, the parameter values are recorded; the data acquisition will stop when pressing the « Acquisition Stop » key.


### 10.4.2. Acquisition file of the harmonics

At the same time, you can record harmonics of the signals in text mode. You select the acquisition period of the harmonics (from 1 second to 1 hour).

The recorded channels are the same as specified in the « Display » page (chapter 11.3).

The file that you create has the same name as the parameter file, but with the .txt extension. A text editor or Excel will be able to read it (but not SeframViewer).

### 10.4.3. Recordable parameters



→ **Number of parameters:** the possible values are 1 to 24.

→ **Validity parameter:** to select the validated channels.

→ **Parameter:** To select the channel to parameter. You can choose:

- **Voltage and Current:**

- **rms:** RMS
- **dc:** average value (DC offset)
- **Crest:** maximum value between the max. and min. peak values
- **Crest Factor:** ratio between the crest value and the RMS (1.414 for a sinusoid signal)
- Harmonic distortion rate **THD:** specifies the total presence of harmonics as a ratio to the fundamental component of the signal
- Distortion factor **DF:** DF% specifies the total presence of harmonics as a ration to the true efficient value of signal.

- **Power:**
    - **P:** Active
    - **Q:** Reactive
    - **S:** Apparent
  - **Energy:** cumulative value; initialization at page « Display »
  - **Power/factor**
  - **Frequency:** the calculation of frequency is made on the input U1
  - **Harmonics:** selection of the channels, whose harmonics you want to display
  - **Other channels:** to select another input channel.
- 
- Standard acquisition channel: you can choose any available channel
  - Logic channel: only the last parameter can be set up this way.

In voltage and intensity mode, you can select each line (example U1, I2) or the global value of the circuit (Ut, It)

For each parameter, you can change the following values:

- ➔ **Color:** color of the displayed parameter on a graph. For additional and logic channels, the colors are as defined for each of those channels.
- ➔ **Caliber:** the caliber is defined with the nominal values of voltages and intensities. For example, for a nominal voltage of 230 V, the caliber shall be 400 V centered around 200 V (hence, 0 to 400 V). You can change the minimum and maximum for better accuracy. For example, you can display the signal U1 between 220 V and 240 V

## 10.5. Record

You launch the data acquisition by pressing the « **Record** » key. It is paced at the rate of the integration period. You can also record the parameters into a file (real time save on a hard disk).

Unlike the normal record mode, there is only one block and the complete data acquisition is displayed in real time.

During the data acquisition, you cannot change the data acquisition parameters, but you can change the display parameters (zoom, color, validity of display, etc.).

You can also display the signals under scope mode or display the parameters under numeric mode.

To stop the data acquisition, press « **Stop Acquisition** ».

In case of power shortage during the data acquisition, the registered file is correctly closed. At re-energizing, any new data acquisition will be made with possible opening of a new file.

## 10.6. Measurement method

Root Mean Square: 
$$X_{rms} = \sqrt{\frac{\sum_{k=1}^N x_k^2}{N}}$$

Average value: 
$$X_{mean} = \frac{1}{N} \sum_{k=1}^N x_k$$

Active Power: 
$$P = \frac{1}{N} \sum_{k=1}^N v_k * i_k$$

Apparent Power: 
$$S = U * I$$

Reactive Power: 
$$Q = \sqrt{S^2 - P^2}$$

Power Factor: 
$$FP = \frac{P}{S}$$

Crest Factor: 
$$FC = \frac{X_{crest}}{X_{rms}}$$

Distortion Rate: 
$$THD = \sqrt{\frac{X_i^2 - X_{fond}^2}{X_{fond}^2}}$$

Distortion Factor: 
$$DF = \sqrt{\frac{X_i^2 - X_{fond}^2}{X_i^2}}$$

Total Active Power: 
$$P_T = P_1 + P_2 + P_3$$

Total Reactive Power: 
$$Q_T = Q_1 + Q_2 + Q_3$$

Total Apparent Power: 
$$S_T = \sqrt{P_T^2 + Q_T^2}$$

Total voltage: 
$$U_T = \sqrt{\frac{U_1^2 + U_2^2 + U_3^2}{3}}$$

Total Intensity: 
$$I_T = I_1 + I_2 + I_3$$

Total Power Factor 
$$FP_T = \frac{P_t}{S_t}$$

Energy: the cumulative value of power P; you can clear this value in the Display page

*Attention:* the maximum value of the energy in acquisition mode is limited to

$E = P_n * H$

$P_n$  = nominal power

$H$  = 12 hours



## 11. FILE MANAGEMENT

### 11.1. General

For all possible files, the appliance has an internal hard disk and can receive an USB stick that makes it possible to:


- save or reload the total set-up of the recorder
- save or display a data acquisition.

The set-up files have a \*.CNF extension.

The data acquisition files have a \*.REC extension.

You can create directories and save files into them. To do so, press the « **Set-up** » key in File mode, then select « **Save on Disk** ».

Press « **Add Folder** » when suggested.




- **USB key:** read / write to an USB stick (if connected at the start-up of the appliance)
- **Add Folder:** creation of a directory; you can type its name with an alphanumeric keyboard on screen.
- **Visualisation Recycled:** gives access to deleted files in case of recovery.



It is very advisable to work under a directory and not at the root of the hard disk.  
When you delete a directory, all files within are deleted.

## 11.2. Managing the set-up files


The page to manage the set-up files is linked to the "**Set-up**" key.  
Their name has a \*.CNF extension.



- **Reset Set up**: initialization of the appliance under a standard set-up
- **Save on Disk**: back-up of a set-up to a file on the internal hard disk or an USB stick
- **Load on Disk**: loading a set-up from a file on the internal hard disk or an USB stick

### 11.2.1. Saving set-up files

Press the « **Save on Disk** » key.



You can type the name of the file with an alphanumeric keyboard on screen, or with an external PC-type keyboard if connected.

### 11.2.2. Loading set-up files

Press the « **Load on Disk** » key.

Select the directory, then the file to load, and click « **Load** ».



Attention: You will lose the current set-up.

## 11.3. Managing the data acquisition files

### 11.3.1. Saving acquisition files

To save the data acquisition, you must define the parameters of the triggers.

There are 2 ways to save data acquisitions into the appliance:


- by recording data acquisitions into internal memory through the blocks in memory mode and template mode (see the chapters Memory mode and Template mode)
- by recording the data acquisitions on a disk (see File mode).

The « save additional file » function makes it possible to record all the data acquisition (all blocks at a time).

At the save file stage using «**Files manager**» → «**Save data to disk**» two file formats are possible:

Once the acquisition completed, the files can be saved in two different formats :

- **Binary file:** These files can be opened by the device, SeframViewer and Flexpro. It contains all the data and configurations.
- **Fichier text:** Only save the physical channels (not the mathematical channels) and cannot be open by the device. Its purpose is to be used with Excel.



### 11.3.2. Loading acquisition files

Press « **Replay** » then « **Files manager** ». Press once again on « **Load file** », then select the file you want to load.

Select the directory and the name of the file to load to display it on screen.

You can load the set-up of the channels (type, name, functions etc....) and their validations: to do so, validate « **Load Set-up** »

### 11.4. Recycle bin

When you erase a file, it is saved in a hidden directory.

The content of the recycle bin is limited to a little more than 5 Go. In case of overrun, the oldest files are definitively erased.

To display this recycle bin, you only have to open the Directory page and press « **Visualisation Recycled** »: the files show up in blue. You will be able to open the files, save them to an external stick or a FTP Link or read/erase them.

You can also empty the bin.

## 12. PRINTING

This chapter describes the direct printing of the results on a local printer connected to a DAS1600 or a DAS800.

The connection is made with one of the available USB connectors.

You start the printing with the « **Print** » key from the following functions:

- « **F(t)** » and « **XY** », « **Set-up Plot** » key (stopped scan)
- « **Replay** » and « **Start/Stop** », « **Set-up Plot** » key

You can create a file copying the display on screen:

- Screen Print key of a PC keyboard
- Screen Print key of the recorder



The file will be created either on the USB stick, if present, or on the hard disk.

The name of the file will be bmpxxxxx.bmp (incremental name)

On the hard disk, the files will be saved into the FolderBMP directory.

You will be able either to copy this directory on an USB stick or to delete it. You will also be able to use a ftp link to recover these files or delete them.

---

## 12.1. Set-up and start of the plot

Press the « **Set-up Plot** » key from the « **F(t)** », « **XY** », « **Start/Stop** » or « **Replay** » functions.  
Under « **XY** » or « **F(t)** », the scan must be stopped ( « Freeze screen » key) to access to this key.

Under « **Replay** » or « **Start/Stop**», a memory block or a file must be displayed on screen to access to this key.

For the DAS1600 and DAS800 you have to set up a few parameters:



- **Printer Set-up:** selection of the type of printer in a list; see the following chapter.
- **Margin:** width of the margin in millimeters (depends on the selected printer)
- **Launch plot:** starts the printing

## 12.2. Selection of the printer

The « **Set-up Printer** » key launches a printer selection software in the list of existing printers.



Click the « **Add** » button to find the local printer.





Click a small arrow on the left of « **Network Printer** ». The software will look for the printers connected to the network.

Select the manufacturer and the model of the printer, then click on « Forward ».

The software will search the drivers. You will have to select the right driver.

If the software does not find the right drivers for a PostScript driver, you'd better find drivers as close as possible from the local printer: If your printer does not appear in the selection list, you can try any similar printer by the same manufacturer – its driver will probably be the same.

You can check the driver used with your printer on the website: [http://openprinting.org/printer\\_list.cgi](http://openprinting.org/printer_list.cgi)

Example:

For the TOSHIBA e-STUDIO255 printer, you can use the driver of the TOSHIBA e-STUDIO205 printer .

### 12.3. Printer for USB connection

You can connect the recorder to a printer with a USB connector.

In this case, the connected printer will show up directly on screen:




In case of problem by the set-up of a new printer,  
you can reboot the basis printer in the « Set-up » page

## 13. INPUT / OUTPUT

### 13.1. Additional Input / Output Connector

The connector is at the rear (SUB-D 25 male pins).




The ground of the power supply is the mechanical earth of the casing of the SUB-D25

Pin no	I/O	Nom des signaux
13	I	Logic channel 1
25	I	Logic channel 2
12	I	Logic channel 3
24	I	Logic channel 4
11	I	Logic channel 5
23	I	Logic channel 6
10	I	Logic channel 7
22	I	Logic channel 8
9	I	Logic channel 9
21	I	Logic channel 10
8	I	Logic channel 11
20	I	Logic channel 12
7	I	Logic channel 13
19	I	Logic channel 14
6	I	Logic channel 15
18	I	Logic channel 16
5		Ground
17		Ground
4		Ground
16	O	Power 9-15V 0.2A
3		Ground
15		Alarm A
2		Alarm A
14	O	Alarm B
1	O	Alarm C

## 13.2. Logical inputs

The non-connected inputs have the following circuit:



The non-connected inputs are 0 V potential (level 0).

Number of logic channels: from 1 to 16.

TTL level: 3.3 V (protected until 24 V)

To create a rising edge, you only have to create a connection between the power supply 12 V input and the output of the connector.

Similarly, to create a falling edge, you only have to remove this connection.

You can also use a TTL 3.3 V output signal.

### 13.2.1. Use

#### Plot and display:

These channels are plotted on the left or the right side of the paper according to the selected format.

They are displayed at the top or the bottom of the screen according to the selected position.

They are numbered from the right to the left.

Each channel is plotted between two dotted lines that specify the limits.

The height of the reticules is min. 2mm for the plot.

#### External clock:

You can use the channel #16 (pin #21 on the connector) to synchronize the channels in all modes (Memory, Go/Nogo and File).

The max. speed of the paper is ca. 12 mm/s.

In « Text » writing of the measurements, the paper scroll is made the same way. In this case, the transcription frequency is restricted to 1 Hz.

In other modes, the data acquisition is up to 500 KHz.

**Triggers:**

You can use the external channels to trigger the plot and the data acquisitions (start or stop) (Mode AND or OR).  
See chapter « **Triggers** ».

### 13.3. Alarm outputs

Contacts and outputs available at the rear connector (A1 / A2), B and C.

The A1/A2 contact is a « off voltage contact » with no potential (24 V /200 mA).

The B and C outputs are TTL 5 V.

When the appliance is off voltage, the contact A1/A2 is open and the B and C outputs have a 5 k $\Omega$  impedance.

#### 13.3.1. Use

Signalizing internal events toward the outer environment to the recorder (triggers on analogical or logic channels, states of the printing block...)  
See chapter « **Use** », paragraph « « **Set-up** » key ».

### 13.4. Power supply output

There is a power supply output +12 V limited to 0.2 A on the pin #23 of the connector.

The grounding of the power supply is the mechanical earth.

You can also use this output to supply energy to a sensor or an electric circuit to manage the logic inputs.



The 12 V may disappear in case of intensity overload (> 0.2 A). In such a case,  
You have to turn off the appliance a few minutes before switching it on again.

### 13.5. Extension box for input/output interface

The extension box makes it possible to detect a voltage and convert it into a logic signal for all 16 logic channels.

The inputs are isolated between each other and from the ground.

The « green » terminal block of each channel is isolated from the red and black bushes of the same channel.

The 10-pin terminal block (non-isolated) makes it possible to supply energy under 3.3 V, 5 V or 12 V to an external circuit and to connect alarm outputs.

#### Use:

Connect the 25-wire cable between the I/O connector of the DAS800/DAS1600 and the box (4 on figure 1).

Connect the signals according to the case:

90 V to 250 V AC or DC, red and black bushes (1 on figure 1)

10 V to 48 V AC or DC, pins #1 and #3 of the « green » terminal block (2 on figure 1)

< 10 V AC or DC, between pins #1 and #2 of the « green » terminal block (3 on figure 1)





Fig 1

**The extension box for input/output interface option (code 984405500) makes it possible to:**

- convert an alternative voltage (example: 230 V 50 Hz) into a logic signal 1
- easily connect inputs from the 16 logic channels
- isolate the 16 logic inputs (250 V= $\sim$  between channels, 250 V= $\sim$  between channels and ground)
- easily connect alarm outputs with a screw terminal
- supply energy to an external accessory with 3.3 V, 5 V or 12 V with a screw terminal


**Connection of the logic channels according to the signal voltage:**

- 0 to 250 V = $\sim$




Through a banana plug isolated between the red and black bushes  
 Max. voltage available: 250 V AC or DC  
 Typical trip threshold (AC or DC): 48 V  
 Frequency: 45 to 440 Hz  
 Non-detected low threshold (AC or DC): 0 to 10 V  
 Detected high threshold (AC or DC): 60 V to 250 V  
 Isolation: 250 V= $\sim$  between channel and ground

- 0 to 48 V = $\sim$



Through pole and screw between the dots #1 and #3 of the screw terminal  
 Max. voltage available: 48 V AC or DC  
 Frequency: 45 to 440 Hz  
 Typical trip threshold (AC or DC): 9 V  
 Non-detected low threshold (AC or DC): 0 to 2 V  
 Detected high threshold (AC or DC): 10 V to 48 V  
 Isolation: 50 V= $\sim$  between channel and ground

- 0 to 10 V= $\sim$



connection 0 - 10 V logic channel 1

Through screw terminal between the dots #1 and #2 of the screw terminal  
 Max. voltage available: 10 V AC or DC  
 Frequency: 45 to 440 Hz  
 Typical trip threshold (AC or DC): 2.2 V  
 Non-detected low threshold (AC or DC): 0 to 1 V  
 Detected high threshold (AC or DC): 3 V to 10 V  
 Isolation: 50 V= $\sim$  between channel and ground

**Response time:**

To detect the alternative signal, the signal of the logic channels is rectified and filtered  
 Typical delay for a rising edge: 10 ms  
 Typical delay for a falling edge: 50 ms

**13.5.1. Use**

Link the box to the input/output connector of the appliance with the 25-pin connector provided with the option.  
 Connect the logic channels to record with respect to the max. authorized voltages

**Power supplies / Alarms:**

Masse	3.3V	5V	12V	Masse	Alarme A contact 1	Alarme A contact 2	Alarme B	Alarme C	Masse
1	2	3	4	5	6	7	8	9	10

max. current 3.3 V: 200 mA  
 max. current 5 V: 200 mA  
 max. current 12 V: 200 mA  
 Alarm A contact 1 and 2: open in case of alarm, isolation 50 V<sub>max</sub> / ground  
 Alarme B: logic output 0 V / 5 V non-isolated  
 Alarme C: logic output 0 V / 5 V non-isolated

## 14. INTERFACE

### 14.1. Ethernet interface

#### 14.1.1. General

You can remotely use the recorder with its Ethernet interface through the TCP-IP protocol.  
Plug the recorder onto your network with a straight cable on the 10/100 BASE-T connector (RJ45) at the rear of the appliance.

You can use the recorder with a 10 Mbit/s or 100Mbit/s Ethernet network.

If your network includes a BNC cable, you need an external hub to convert the BNC signal into RJ45 signal (use a straight cable).

If your PC has no network, you can also use a crossover cable directly between the PC and the recorder.

#### Crossover cable

Connector 1		Connector 2	
Broche	Signal	Broche	Signal
1	TX+	3	RX+
2	TX-	6	RX-
3	RX+	1	TX+
6	RX-	2	TX-

The recorder uses the TCP/IP protocol to dialog with the PC. You can then give it an IP address with a subnet mask.  
Ask your network administrator for an IP address with the corresponding subnet mask. Type the values, then turn off and on the appliance to validate the new address.



---

*If you have no network administrator:*

Check that the TCP/IP driver is installed on your machine.

For a PC under Win 95 or Win 98:

From the Windows browser, go to "Workstation" then "Configuration panel" then "Network".

Check that the TCP/IP protocol is installed, then check the IP address and the subnet mask.

You must take care to define an IP address and a subnet mask compatible with the remote computer.

The port used by the recorder is **Port #23**.

**Case with DHCP:** if you use a DHCP server, it will automatically assign an address to the recorder; you can read this address in the « Set-up » page.

**Case with manual IP:**

For example, in I mode, you can have:

PC	IP=192.135.20.00	mask = 255.255.255.0
Recorder	IP=192.135.20.01	mask = 255.255.255.0

Refer to the definition of the classes of IP addresses.

Programming:

You can create your own software under Visual Basic, Visual C++, etc. for example with the Winsock.dll driver by Microsoft.

Then, you will only have to send the appliance instructions designed in the following paragraphs.

---

## 14.2. NTP Protocol

Using the NTP clock (network time protocol) gives triggers with accuracy better than 50 milliseconds. For that, you need to install the recorder in your computer network with a fix IP.

Go to the Set-up page, then to the Ethernet page: 0.0.0.0

Give the recorder:

- The address of the gateway (IP of the router) (no use with DHCP)
- 2 addresses IP DNS (domain name system). The default addresses are Open DNS (208.67.222.222 and 208.67.220.220). Else, you can use DNS addresses by your Internet provider (for some servers, you only have to type the IP address of the gateway) (inutile en DHCP).
- a NTP server; the defaults server if the French NTP server: fr.pool.ntp.org. For more information, visit the website <http://www.ntp.org/>

You can use an internal NTP server inside your network or a server close to your home (preferably use secondary servers (layer 2) for France). You will find the list of the French servers in [http://www.cru.fr/NTP/serveurs\\_francais.html](http://www.cru.fr/NTP/serveurs_francais.html)

Once the appliance restarted, you can test if it can communicate with the various IP addresses.

In the Set-up page, go to the Date page:

You can select either the internal date or the synchronization of the appliance under NTP.

In this case, you must also tell the recorder your time shift and the possible use of daylight saving time (Europe only).

France and western Europe are in the GMT+1 zone.

After restarting the appliance, the recorder will synchronize with the NTP server.

The date in the date window is displayed red when searching.

As soon as the synchronization process begins, the date is displayed blue.

If the date never turns blue, check the cables and the various IP addresses in the Ethernet page: you can test the link with the "test" line.

### 14.3. WIFI connection


You can also connect the appliance through a Wifi tick by plugging it into a USB port.

The wifi routed is used without encrypted key. Securify is guarented by using MAC address.

Once the stick inserted, go to the « Set-up » menu. Under Network, you should see a second line with « no more network ».




Pressing the « Modif. » key opens a utility program to activate the Wifi link.



Then, go to the « Devices » tab and check that your Wifi stick has been identified.

Then, click « New » and select Wireless connection, then « Forward ».



The name of your Wifi stick shows up. Select it, then click « Forward ».



On this page, you must type the network parameters.

On the « network name (SSID): » line, you must select « Specified » and type the name of your network.


Then, you only have to follow the last steps of set-up and apply it.

After that, you Wifi peripheral should be visible in the list of configurable peripherals. In the « Modify » tab, you must :

- check "Controlled by NetworkManager"
- check "Activate the peripheral at start-up": the peripheral will automatically start up at energizing of the computer.

In the second tab you can see the MAC address of your wifi key

Don't forget to save the setup ( files -> save)



In case of trouble at setting up, click « Help » and then « Content » to display the help guide.

Once the network activated, and after a restart its name should show up in the Set-up menu under the Ethernet connection.

## 14.4. Operating software

You can transfer the data acquisitions files to a PC computer.

The SeframViewer software is provided on a CD-ROM with the appliance. It displays the recorded files.

It works under WINDOWS XP, 2000, Vista with Framework 2.0

Using files on a PC requires two steps:

- Transfer the files from the appliance to the PC with the FTP protocol with your Internet browser, for example
- Display of the files with the SeframViewer software

### 14.4.1. File transfer under FTP

- **Using the explorer of Windows (IE9 for example )**

This process is recommended because the date of the transferred files will be identical with the date of the initial files. In addition, the transfer speed will be optimal (> 5Mo/s for 100BaseT).

You'd better have Internet Explorer 8 or more.

Go to Tools → Connect a network reader

Click « Open a storage session or a network server »

Under « Internet network address », type ftp:// and the IP address of your recorder

You can give a name to this link; it will always remain active among the « network favorites »

- **Using a web browser** (internet explorer, firefox, opera etc.)

Launch your browser and type the connection address (See chapter **Set-up**):

« **Ftp://** » and the IP address of your recorder


then press « Enter » from your computer.

You have direct access to the directories of your recorder, including the data acquisition files: **HD**: main directory on the internal hard disk of your appliance

After selection of the directory where you recorded your data acquisitions, you can rename them, move them, copy them or delete them.

Transfer your files to your computer to use them with the provided SeframViewer software or FLEXPLO.

## 14.4.2. Display under SeframViewer



Launch the SeframViewer software (or double-click on a file) then open a .REC file.

You can select:

- the channels to display
- the f(t) or xy mode
- the autocalibration of the channels.

Your data acquisition file is displayed on screen. All functions of SeframViewer are available.

Use the user manual included with the software to discover all the available functions of SeframViewer by clicking the last icon « **Detailed help** ».

In command mode of Windows<sup>®</sup>, you can also directly create a result file (text or Excel file) by typing the following line (see Menu sub-menu Options of the help):

SeframViewer myfiler.rec /x creates an Excel file

SeframViewer myfile.rec /t creates a text file.


### 14.4.3. Control with VNC Viewer:

This software makes it possible to remotely control the recorder.

<http://www.realvnc.com/download/vnc/> allows you to easily download the software. Select the.exe file.

You only have to follow the instructions of the site to install the software. At the end of the installation, you can choose a version for your VNC viewer (some versions are charged). Select the version you want according to the desired applications.

You only have to open the « VNC viewer » where you downloaded it.



On the VNC Server line, you must type the IP address of your recorder and click « Connect »

You will be able to control your recorder with your computer.



## 15. TECHNICAL SPECIFICATIONS

### 15.1. Isolated 1000V inputs

#### 15.1.1. General characteristics

*Number of inputs per module* 6

*Impedance :*

11M $\Omega$  impedance for calibers < 10Volts

10M $\Omega$  impedance for other calibers

*Maximum admissible voltage:*

Between the measured channel and the mechanical ground : 1000 V DC or 1000 V AC 50 Hz

Between the two channels' poles : 1000 V DC ou 1000 V AC 50 Hz

*Installation category:* overvoltage category : III-1000V and category IV-600V

*Isolation:* Between the ground and the measurement channels: >100 M $\Omega$  for 1500 V DC.

Common mode parasites: Test according to EN 61143


*Kind of measures:*

Voltage, current (with external shunt)

Frequency

**15.1.2. Voltage record**

<i>Maximum caliber</i>	4000 V	(-2000 V to +2000 V)
<i>Minimum caliber</i>	100 mV	(-50 mV to +50 mV)
<i>Offset</i>	Adjustment of the center per 1/5000 of the full scale or 1/2 caliber	
<i>Maximum offset</i>	+ 5 calibers.	(without exceeding the range from -2000V to + 2000V)
<i>Accuracy</i>	+/-0.2 of the full scale +/- 0.2% of the offset	
<i>Offset shift</i>	100ppm/°C	



**15.1.3. RMS record**

Software RMS calculation

<i>Sampling</i>	200 μs
<i>Max frequency</i>	500 Hz
<i>Peak factor</i>	2,2 and 2000 V max. instantaneous
<i>Accuracy</i>	+/- 1 % (sinusoïdal signal)
<i>Response delay</i>	100 ms typical ( 40 ms @ 50 Hz)
<i>Max measurable voltage</i>	1000V AC

**15.1.4. Derivative and integral record**

*Integration time:* (common to all channels) from 200 μs to 1 s

*Input Caliber:* adjustable from ± 0.50 mV to ± 2000 V

*Input filters:* see bandwidth paragraph

**15.1.5. Frequency record**

*Accuracy* 100 mV rms min.  
 Decision threshold: Variable from -99 V to 99 V with 0.1 V steps  
 (valid for frequencies < 10 Hz)  
*min. cyclic ratio* 10%  
*Frequency* between 10 Hz and 100 kHz.  
*Accuracy* 0.02% of the full scale

**15.1.6. Counting record**

Decision threshold: Variable from -99 V to 99 V with 0.1 V steps  
 min. Sensitivity: +100 mV + 1% of the decision threshold  
 max. Counting for record: 65536 (at higher values, the counter is zeroed).  
 max. digital Counting:  $4 \cdot 10^9$

**15.1.7. Sampling**

*Resolution* : 14 bits  
*Max sampling frequency:*  
 Memory and File modes: 1  $\mu$ s (= 1 MHz)  
  
*Max sampling period.* : 10 min

**15.1.8. Bandwidth**

-3 dB bandwidth:

Caliber	Bandwidth
$\geq 100$ V	26 KHz
$\geq 10$ V et <100V	20 kHz
<10V	3 kHz

Internal analog filters: 10 KHz ,1 KHz, 100 Hz,  
Slope : 60 dB/décade

*Software digital filters: programmable from 50Hz to 0.01Hz*

## 15.2. Isolated 500V inputs

### 15.2.1. General characteristics

*Number of inputs per module*      6

*Impedance:*

Impedance > 25 MΩ for calibers < 1 V  
 Impedance = 1 MΩ for the other calibers

*Optional card 984402300:*

Impedance = 10 MΩ for the other calibers

*Maximum admissible voltages:*

between the measurement channel and the mechanical ground: + 500 V DC or 500 V AC 50 Hz  
 between the 2 poles of a channel: + 500 V DC or 500 V AC 50 Hz

*Category of installation:* overvoltage category: III 600 V

*Isolation:* between the ground and the measurement channel: >100 MΩ under 500 V DC.

*Parasites of common mode:* test according to the norm EN 61143

*Type of measurements:*

Voltage, intensity (through external shunt)  
 Frequency  
 Thermocouple J, K, T, S, B, N, E, C, L

### 15.2.2. Voltage recording

<i>max. Caliber</i>	1000 V	(-500 V to +500 V)
<i>min. Caliber</i>	1 mV	(-0.5 mV to +0.5 mV)
<i>Offset</i>	Adjustment of the center per 1/5000 of the full scale or 1/2 caliber	

<i>Max Offset</i>	+ 5 range (except 1000 V)
<i>Accuracy</i>	$\pm 0.1\%$ of full scale $\pm 10 \mu\text{V}$ $\pm 0.1\%$ of the offset
<i>Offset shift</i>	100 ppm/°C $\pm 1 \mu\text{V}/^\circ\text{C}$

*Classe C index*            see appendix

### 15.2.3.      **RMS recording**

RMS calculation with the software

<i>Sampling</i>	200 $\mu\text{s}$
<i>Max. Frequency</i>	500 Hz
<i>Peak factor</i>	2.2 and 600 V max. instantaneous
<i>Accuracy</i>	$\pm 1 \%$ (sine signal)
<i>Response delay</i>	100 ms typical (40 ms @ 50 Hz)
<i>measurable max. Voltage</i>	424 V AC

### 15.2.4.      **Derivative and integral record**

*Integration time:* (common to all channels) from 200  $\mu\text{s}$  to 1 s

*Input Caliber:* adjustable from  $\pm 0.5 \text{ mV}$  to  $\pm 500 \text{ V}$

*Input filters:* see paragraph bandwidth

**15.2.5. Temperature record**

Sensor	Domain of use
J	-210°C to 1200 °C
K	-250°C to 1370 °C
T	-200°C to 400 °C
S	-50°C to 1760 °C
B	200°C to 1820 °C
E	-250°C to 1000 °C
N	-250°C to 1300 °C
C	0°C to 2320 °C
L	-200°C to 900 °C

Accuracy of the thermocouples as specified in the appendix  
 Compensation of the cold junction of the thermocouples J, K, T, S, N, E, C, L:  $\pm 1.25$  °C  
 Calculation every ca. 5 ms.

**15.2.6. Frequency record**

*Accuracy* 100 mV rms min.  
 Decision threshold: Variable from -99 V to 99 V with 0.1 V steps  
 (valid for frequencies < 10 Hz)  
*min. cyclic ratio* 10%  
*Frequency* between 10 Hz and 100 kHz.  
*Accuracy* 0.02% of the full scale

**15.2.7. Counting record**

Decision threshold: Variable from -99 V to 99 V with 0.1 V steps  
 min. Sensitivity: +100 mV + 1% of the decision threshold  
 max. Counting for record: 65536 (at higher values, the counter is zeroed).  
 max. digital Counting:  $4 \cdot 10^9$

### 15.2.8. Sampling

*Accuracy:* 14 bits  
*max. Sampling Frequency:*  
     Memory and File modes: 1  $\mu$ s (= 1 MHz)  
  
*max. Sampling Period:* 10 min

### 15.2.9. Bandwidth

*Bandwidth at -3 dB:*

Caliber	Bandwidth
> 1 V	100 kHz
> 50 mV	50 kHz
20 mV	30 kHz
10 mV	30 kHz
5 mV	20 kHz

*Carte optionnelle 984402300 :*

Caliber	Bandwidth
>10V	>20 kHz
> 500 mV	>10 kHz
> 50 mV	>50 kHz
20 mV	>30 kHz
10 mV	>30 kHz
5 mV	>20 kHz

*Internal analogical Filters:* 10 kHz ,1 kHz, 100 Hz, 10 Hz  
*Slope :* 20 dB/decade

*Software Filters:* *from 50Hz to 0.01Hz*



Multiplexed inputs

### 15.2.10. General Characteristics

*Number of inputs per module*            12

*Inputs of type non-isolated differential*

*Impedance:*

Impedance >10 MΩ for calibers ≤ 2 V  
 Impedance = 2 MΩ for all other calibers

*Maximum admissible voltages:*

between the measurement channel and the mechanical ground:    48 V DC  
 between the 2 poles of a channel:    48 V DC

*max. common mode Voltages:*

± 3 V for calibers ≤ 2 V  
 ± 50 V for all other calibers

*Type of measurements:*

Voltage, intensity (through external shunt)  
 Thermocouple J, K, T, S, B, N, E, C, L  
 PT100 2, 3 or 4 wires

### 15.2.11. Voltage record

<i>max. Caliber</i>	50 V (-25 V to +25 V)
<i>min. Caliber</i>	1 mV
<i>Offset</i>	software adjustment of the center
<i>Accuracy</i>	± 0.1% of full scale ± 10 μV ± 0.1% of the offset
<i>Offset shift</i>	100 ppm/°C ± 1 μV/°C

### 15.2.12. RMS record

Software RMS calculation

<i>Resolution</i>	200 $\mu$ s	<i>Peak factor</i>	2.2	<i>Response delay</i>	typically 100 ms
<i>Max. Frequency</i>	100 Hz	<i>Accuracy</i>	$\pm 1\%$ (sine signal)		

### 15.2.13. Derivative and integral record

*Integration time:* (common to all channels) from 200  $\mu$ s to 1 s

*Input Caliber:* adjustable from  $\pm 0.5$  mV to  $\pm 25$  V

*Input Filters:* see paragraph Bandwidth

### 15.2.14. Temperature record

- Thermocouple: see chapter 16.1.4

- PT100:

Domain of use from -200 to 850  $^{\circ}$ C

Accuracy of the thermocouples and PT100: see the appendix, PT100 2, 3 or 4 wires.

Calculation every ca. 5 ms

*max. corrective resistance:*

- PT100 2 wires: 30  $\Omega$     - PT100 3 wires: 100  $\Omega$

### 15.2.15. Sampling

*Resolution:* 16 bits

*Max. Sampling Period:*

Memory and file modes: 200  $\mu$ s (= 5 kHz)

*Max. Sampling Period:* 10 min

### 15.2.16. Bandwidth

*Bandwidth at -3 dB* 1 kHz

*Software Filters only:* from 50Hz to 0.01Hz

## 15.3. Strain gauge inputs

### 15.3.1. General characteristics

*Number of inputs per module :* 6

*Voltage, thermocouple and strain gauge measurement (the strain gauge bridge is powered by the drawer)*

Inputs of type isolated differential

*Impedance:*

Impedance = 2 M $\Omega$  for calibers < 1 V

Impedance = 1 M $\Omega$  for calibers  $\geq$  1 V

*Maximum admissible voltages:*

Between a measurement input or the ground and the mechanical ground: 200 V DC

*Maximum voltages between inputs, between input and drawer ground:  $\pm$  50 V*

*Isolation: between mechanical ground and measurement channel: >1000 M $\Omega$  under 500 V*

*Type of measurements:*

Voltage, intensity (through external shunt), thermocouple, strain gauge

*The accuracy values below are specified for the 1Hz filter.*

### 15.3.2. Voltage record

<i>max. Caliber</i>	50 V
<i>min. Caliber</i>	1 mV
<i>Offset</i>	adjustment of the center by 1/5000 of full scale or 1/2 caliber
<i>max. Offset</i>	$\pm$ 50 V (zero offset $\pm$ 5 calibers without changing the caliber)
<i>Accuracy</i>	$\pm$ 0.1% of full scale $\pm$ 10 $\mu$ V $\pm$ 0.1% of the offset
<i>Offset shift</i>	100 ppm/ $^{\circ}$ C $\pm$ 1 $\mu$ V/ $^{\circ}$ C
<i>Noise</i>	< 20 $\mu$ V without a filter

### 15.3.3. RMS record

Software RMS calculation

<i>Resolution</i>	200 $\mu$ s
<i>max. Frequency</i>	500 Hz
<i>Peak factor</i>	2,2
<i>Accuracy</i>	$\pm 1$ % (sine signal)
<i>Response delay</i>	typically 100 ms

### 15.3.4. Derivative and integral record

*Integration time:* (common to all channels) from 200  $\mu$ s to 1 s

*Input Caliber:* adjustable from  $\pm 0.5$  mV to  $\pm 25$  V

*Input Filters:* see paragraph Bandwidth

### 15.3.5. Strain gauge record

The selected unit is  $\mu$ STR (micro strain). Gauges also express the measurement in mV/V

The equivalence is: 2000  $\mu$ STR = 1 mV/V

<i>Automatic Zero</i>	$\pm 25000$ $\mu$ STR
<i>Power Voltage of the bridge</i>	2 V and 5 V (symmetrical $\pm 1$ V and $\pm 2.5$ V)
<i>Gauge Coefficient</i>	2 (adjustable between 1.8 and 2.2)
<i>max. Caliber</i>	50 000 $\mu$ STR
<i>min. Caliber</i>	1000 $\mu$ STR
<i>Offset</i>	adjustment of the center by 1/5000 of full scale or 1/2 caliber
<i>max. Offset</i>	$\pm 50000$ $\mu$ STR
<i>Accuracy</i>	$\pm 0.1\%$ of full scale $\pm 5$ $\mu$ STR $\pm 0.1\%$ of the offset
<i>Offset shift</i>	100 ppm/ $^{\circ}$ C $\pm 1$ $\mu$ V/ $^{\circ}$ C

**15.3.6. Temperature record**

- Thermocouple: see chapter 17.1.4

- PT100:

Domain of use from -200 to 850 °C

Accuracy: see appendix

PT100 2 or 4 wires

Calculation every ca. 5 ms

*Max. corrective Resistance:*

2-wire PT100: 30 Ω

**15.3.7. Sampling**

*Accuracy:* 16 bits

max. Sampling Period

*Memory and File modes:* 10 μs (= 100 kHz)

**15.3.8. Bandwidth**

*Bandwidth @ -3 dB* >18 kHz

*Analogical low-pass Filters 60 dB / decade* 1 kHz, 100 Hz, 10 Hz

*Software low-pass Filters* from 50Hz to 0.01Hz

---

## 15.4. Additional Inputs / Outputs

### 15.4.1. Logic channels

<i>Number of channels</i>	16
<i>Input Impedance</i>	4.7 k $\Omega$
<i>Sampling Frequency</i>	same as the main inputs
<i>max. admissible Voltage</i>	24 V

### 15.4.2. Alarm Outputs

<i>Alarm A</i>	voltage-free contact (relay) (24 V / 100 mA).
<i>Alarms B and C</i>	TTL outputs 5 V

Voltage-free appliance when the circuits are open.

### 15.4.3. External power supply

<i>nominal Voltage</i>	12 V / mechanical ground
<i>max. Intensity</i>	0.2 A restricted by reloading fuse

## 15.5. Circuit analysis

The specified accuracies require that the nominal values are correct.

### 15.5.1. Ranges and Accuracies Voltage and Intensity

#### *RMS Voltage:*

- Range: from 1 mV rms to 400 Vrms
- Accuracy: 0.5% of the nominal voltage

#### *RMS Intensity:*

- Range: the intensity is always to be referred to a corresponding voltage: the input value must be within the limits specified for the voltage. In most cases, the instrument you are using to measure the intensity conditions the measuring range.
- Accuracy: 0.5% of the nominal intensity + error margin of the measuring instrument

#### *Active power:*

- Accuracy: Intensity error margin + Voltage error margin

#### Example

Measurement of a 230 V voltage and a 10 A intensity with a SP221 clamp (1% accuracy; input 1 A yields output 100 mV on the circuit analyzer).

- *Voltage:* accuracy 0.5 %
- *Intensity:* accuracy  $0.5\% + 1\% = 1.5\%$
- *Power:* accuracy  $0.5\% + 1.5\% = 2\%$

#### Power supply voltage and frequency of the appliance:

In the case where the DAS1600 is in nominal functioning conditions (see chapter 10.7), the influence errors resulting from the power supply voltage and frequency are negligible within 10% distortion and  $\pm 2\%$  frequency variation (in case of circuit power supply by generating unit).

#### Magnetic fields:

The current sensors must compulsory be in conformity with the valid norms and have the CE mark. Their influence on the recorder is negligible for a field 100 A/m @ 50 Hz. As far as possible, keep the sensors away from any magnetic source when used.

**15.5.2. Frequency**

*Ranges:* from 10 to 100 Hz - 400 Hz  $\pm$  20% - 1000 Hz  $\pm$  20%  
*Accuracy:* 0.01 Hz  
*Sensitivity:* 5% of the nominal voltage

**15.5.3. Power factor**

*Accuracy:* measurement value  $\pm$  0.05

**15.5.4. Peak factor**

*Peak accuracy:* 0.5% of the nominal voltage or intensity  
*Peak factor:* accuracy 1 % up to 5

**15.5.5. Harmonics rate calculated in power analysis**

*Range:* THD: from 0 % to 600 %  
 FD: from 0 % to 100 %  
*Accuracy:* measurement value  $\pm$  2.5%

*Harmonics:* ca. 2 up to order 50  
*Range:* from 0 % to 600 %  
*Accuracy:* measurement value  $\pm$  1 % up to the 30<sup>th</sup> harmonics;  
 measurement value  $\pm$  1.5 % from the 31<sup>st</sup> up to the 50<sup>th</sup> harmonics



## 15.6. Display

<i>Screen</i>	TFT 15.4 inches, color, back-lighted LED
<i>total Accuracy</i>	1280x800 dots

## 15.7. Memory acquisition

<i>Memory length</i>	128 Mwords (partible up to 128 blocks)
<i>max. Sampling Period</i>	10 min
<i>max. Sampling Frequency</i>	1 MHz

*Position of the triggers* -100% to +100%

## 15.8. Acquisition on files

<i>Internal hard disk size</i>	500 Go min.
<i>max. transfer rate</i>	6 Mwords/s

The true transfer rate depends on the number of channels to get and on the current mode.

## 15.9. Communication interface

Communication (remote control) only through Ethernet.

possible DHCP

<i>Speed</i>	10/100/1000 base-T
<i>Connector</i>	RJ45
<i>Protocol</i>	TCP/IP
<i>Connection port</i>	23

**15.10. Miscellaneous****15.10.1. USB connector**

For a keyboard, a mouse for printer and memory sticks.

*Standard*                      USB 1.1 / USB 2 (according to the appliance)  
*Type*                              4 connectors USB-2 at the rear + 2 connectors USB-2 at the front

**15.10.2. Screen connector**

*Type*                              DB15, 15 dots high density

## 15.11. Environmental conditions

### 15.11.1. Weather conditions

<i>Working temperature</i>	0°C to 40°C (0°C to 30°C for DAS800SV)
<i>max. relative humidity</i>	80 % condensation-free
<i>Storage temperature</i>	-20°C to 60°C

### 15.11.2. Mains

<i>Voltage range</i>	115 V AC or 230 V AC (85 V AC to 264 V AC) (automatic selection) 120 V DC to 370 V DC
<i>Frequency</i>	47 to 63 Hz
<i>Inrush current</i>	< 40 A peak
<i>Consumption</i>	55 W max.

Internal fuse not accessible to the user: contact the after-sales service by SEFRAM

### 15.11.3. Dimensions and weight

<i>Height</i>	298 mm	
<i>Width</i>	394 mm	
<i>Depth</i>	218 mm	with extensions: Depth: 295 mm
<i>Weight DAS1600</i>	8 kg	Weight: 10 kg

## 15.12. Electromagnetic compatibility, security

### 15.12.1. Electromagnetic compatibility

Désignation	Méthode d'essai	Spécification	Limite/Niveau	Essai applicable	Classe/ Critère
Émission rayonnée	NF EN 55011 (2010) *	30 MHz à 230 MHz 230 MHz à 1 GHz	Mesure à 3 mètres 50 dB $\mu$ V/m QP 57 dB $\mu$ V/m QP	Oui	Classe A
Émission conduite (accès alim. AC.)	NF EN 55011 (2010) *	0,15 MHz à 0,5 MHz 0,5 MHz à 5 MHz 5 MHz à 30 MHz	79 dB $\mu$ V QP 73 dB $\mu$ V QP 73 dB $\mu$ V QP (Valeur AV = QP-13 dB)	Oui	Classe A
Courant harmonique	CEI 61000-3-2 (2005)	-	-	Non (1)	-
Variation de tension et flicker	CEI 61000-3-3 (2008)	-	-	Non (2)	-
Immunité enveloppe	CEI 61000-4-2 (2008) *	Décharges Contact Air	N = $\pm$ 4 kV N = $\pm$ 8 kV	Oui	Critère B
	CEI 61000-4-3 (2008) *	80 MHz à 1 GHz 1,4 GHz à 2,0 GHz AM 80% 1000 Hz	10 V/m sans modulation 3 V/m sans modulation	Oui	Critère A
	CEI 61000-4-3 (2008) *	2,0 GHz à 2,7 GHz AM 80% 1000 Hz	3 V/m sans modulation	Oui (3)	Critère A
	CEI 61000-4-8 (2009)	-	-	Non (4)	-
Immunité accès Alim AC	CEI 61000-4-4 (2004) *	5-50 ns / 5 kHz	$\pm$ 2 kV	Oui	Critère B
	CEI 61000-4-5 (2005) *	1,2/50 $\mu$ s	Ligne/Ligne : $\pm$ 1 kV Ligne/Terre : $\pm$ 2 kV	Oui	Critère A
	CEI 61000-4-6 (2008) *	150 kHz à 80 MHz AM 80% 1000 Hz.	3 Vrms sans modulation	Oui	Critère A
	CEI 61000-4-11 (2004) 85V * 250V * (5) 264V	Réduction 100% 1 période Réduction 80% 10 périodes Réduction 30% 25 périodes Réduction 100% 250 périodes		Oui	Critère B Critère C Critère A Critère C
Immunité Autres câbles	CEI 61000-4-4 (2004) *	5-50 ns / 5 kHz	$\pm$ 1,0 kV	Oui (7)	Critère A
	CEI 61000-4-5 (2005)	1,2/50 $\mu$ s	Ligne/Terre : $\pm$ 1 kV	Oui (8)	Critère A
	CEI 61000-4-6 (2008) Câble terre * Câble Ethernet	150 kHz à 80 MHz AM 80% 1000 Hz	3 Vrms sans modulation	Oui (7)	Critère A

\* Test conditions: connection of the tested equipment with a cable connected to the ground pole of the frame (benchmark 9, paragraph 2.2.1); see paragraph 3.4.6 Earth

Assessment criteria for the function applied during the test:

Criterion A: Normal behavior within the limits of specification.

Criterion B: Temporary self-recoverable deterioration or loss of function.

Criterion C: Temporary deterioration or loss of function requiring an intervention by the user or a reset of the system.



This is a class A device. Class A devices are meant to be used in an industrial environment. Electromagnetic compatibility is not ensured in others environments.

### 15.12.2. Security, Isolation Class, Installation Category

Class 1 product

*Security* conform with EN61010-1

*Pollution degree* 2

*Installation category* (overvoltage category)

Mains input category II

Measurement input category III 600 V, overvoltage 6000 V



Particular precautions are necessary to preserve the conformity of the product, particularly the use of shielded cables.

### 15.13. Miscellaneous

#### 15.13.1. Internal saving battery

Saving the configurations and the clock

*Battery* lithium 3.0V button battery

*Preservation of the data* min. 5 years

The user cannot change it: contact the after-sale service.

## 15.14. Accessories

### 15.14.1. Accessories provided with the appliance

User manual  
 Help CD with software and notes

Common accessories:

- 1 mains cable 241510312
- 1 female 25-pin connector 214200251
- 1 connector hood 214299014
- 1 mouse 298505112

- Accessories isolated 6-channel module: 984401100
  - 1 black banana plug per channel 215508020
  - 1 red banana plug per channel 215508021
- Accessories multiplexed differential 12-channel module: 984402100
  - 1 screw terminal block per channel 315018045
- Accessories isolated gauge strain 6-channel module 984402550
  - 1 screw terminal block per channel 315018048

### 15.14.2. Accessories and options

Universal 6-channel module see the after-sales service  
 Universal 6-channel module (10 M $\Omega$  inputs) 984402300  
 Gauge strain 6-channel module see the after-sales service  
 Multiplexed 12-channel module see the after-sales service  
 1000V 6-channel module see the after-sales service  
 Transportation case 984167000  
 Rack 19" (DAS800/1600) 916007000  
 Shunt 0.01  $\Omega$  1% 3 A plug-in 910007100

Shunt 0.1  $\Omega$  1% 1 A plug-in 910007200  
 Shunt 1  $\Omega$  0.1% 0.5 A plug-in 989006000  
 Shunt 10  $\Omega$  0.1% 0.15 A plug-in 912008000  
 Shunt 50  $\Omega$  0.1% 0.05 A plug-in 989007000  
 Shunt 0.01  $\Omega$  0.5% 30 A external (plugs) 207030301  
 Shunt 0.001  $\Omega$  0.5% 50 A external (terminals) 207030500  
 Crossover Ethernet cable 910007300  
 FLEXPRO basis software 910008100  
 FLEXPRO complete software 910008200

### 15.14.3. Consumable items

Kit for 6-channel module 984010000  
 Kit for 12-channel module 984402100

## 16.15 Battery option

DAS 1600/800 can be equipped with and an optional battery preventing the loose of data in case of power shutdown. The option specifications are detailed below:

<i>Battery charging time with the DAS turned off</i>	<3h
<i>Battery charging time with the DAS turned on</i>	<6h
<i>Battery autonomy</i>	>2h

The front LED of the battery powered devices has three operating modes:

- LED lights up: The device is ON (Push button ON).
- LED is off: The device is off and not connected to an external power source (Back switch button OFF, and push button OFF)
- LED is blinking: The device is off and connected to an external power source. (Back switch button ON, and push button OFF).

The led is not a battery charge indicator. To check the battery charge, use the charge icon in the device's status bar when this one is turned on.



The battery is charging.



The device is powered by the battery.



The use of the battery requires **imperatively** to plug the device's protection earth or the power supply wire for safety reasons  
For the devices powered by a battery, plugged to 500V board, the maximum number of board authorized is lowered to 3..

## 16. APPENDIX

### 16.1. Information about the caliber of the inputs

Reminder: The caliber is the difference between the max. and min. displayable value on screen or paper. The origin is the middle of the screen or paper.

#### 16.1.1. Inputs of isolated voltage type

CALIBER	Origin offset	Min. Measurable	Max. measurable
1 mV	±5 mV	-5.5 mV	+5.5 mV
2 mV	±10 mV	-11 mV	+11 mV
5 mV	±25 mV	-27.5 mV	+27.5 mV
10 mV	±50 mV	-55 mV	+55 mV
20 mV	±100 mV	-110 mV	+110 mV
50 mV	±250 mV	-275 mV	+275 mV
100 mV	±500 mV	-550 mV	+550 mV
200 mV	±1 V	-1.1 V	+1.1 V
500 mV	±2.5 V	-2.75 V	+2.75 V
1 V	±5 V	-5.5 V	+5.5 V
2 V	±10 V	-11 V	+11 V
5 V	±25 V	-27.5 V	+27.5 V
10 V	±50 V	-55 V	+55 V
20 V	±100 V	-110 V	+110 V
50 V	±250 V	-250 V	+250 V
100 V	±450 V	-500 V	+500 V
200 V	±400 V	-500 V	+500 V
500 V	±250 V	-500 V	+500 V
1000 V	0	-500 V	+500 V

These inputs are equipped with an analogical offset system of the origin that may reach up to  $\pm 5$  times the caliber value. Hence, you have to shift the measurement limits without changing the resolution up to 5 times the caliber value.

The software allows you to program any caliber and any offset; then, it selects the real analogical caliber and the best adapted offset according to the table below (closest caliber and origin offset with upper value)



### 16.1.2. Inputs of multiplexed card voltage type

These inputs do not have any analogical offset: offsets are calculated by the software.  
The real caliber is the one, whose range includes the programmed range.

CALIBER	MEASUREMENT RANGE
1 mV	-500 $\mu$ V to +500 $\mu$ V
2 mV	-1 mV to +1 mV
5 mV	-2.5 mV to +2.5 mV
10 mV	-5 mV to +5 mV
20 mV	-10 mV to +10 mV
50 mV	-25 mV to +25 mV
100 mV	-50 mV to +50 mV
200 mV	-100 mV to +100 mV
500 mV	-250 mV to +250 mV
1 V	-500 mV to +500 mV
2 V	-1 V to +1 V
5 V	-2.5 V to +2.5 V
10 V	-5 V to +5 V
20 V	-10 V to +10 V
50 V	-25 V to + 25 V

### 16.1.3. Input of thermocouple type

Thermocouple measurements are treated as voltage measurements.

For a given temperature measurement range, the software determines the voltage caliber the following way:

- « T » being the absolute value of max. measurable temperature, in °C
- Add 40°C to take the max. cold solder temperature into account
- Search the corresponding voltage U in the thermocouple table
- Programming the caliber, whose measurement range includes U
- For isolated channels, no offset is used

#### Example:

You can program a measurement range between -50 and +50°C with a J thermocouple

- max. absolute value  $T = 50^{\circ}\text{C}$
- adding 40°C  $T + 40 = 90^{\circ}\text{C}$
- corresponding voltage U according to the table ThJ  
 $U = 4.726\text{mV}$
- Caliber: 10mV (measurement range: -5 mV to +5 mV)

## 16.2. Accuracy of the thermocouple measurements

The following measurement inaccuracies are given as max. values: the typical values are 2 to 3 times weaker.

The measurement accuracy for temperature is the addition of several possible inaccuracy sources:

Pl: accuracy of linearization

Ps: accuracy of cold solder

Pm: accuracy of measurement of the equivalent voltage

The total accuracy is then:  $P_t = P_l + P_s + P_m$

For the recorder:

$P_l = \pm 0.25 \text{ }^\circ\text{C}$  for all thermocouples

$P_s = \pm 1.25 \text{ }^\circ\text{C}$  for all thermocouples

$P_m = (0.1\% \text{ of the voltage caliber} + 10 \text{ } \mu\text{V})$  divided by the thermocouple slope in  $\mu\text{V}/^\circ\text{C}$

Measurement accuracy:  $P_m$

The measurement accuracy  $P_m$  depends on the voltage caliber used by the appliance (see the previous paragraph) and on the slope of the thermocouple. You will use the slope for the thermocouple at  $0^\circ\text{C}$ , since it varies according to the temperature; but the variation is generally of the second order for the accuracy calculation.

Slope of the thermocouples:

J	K	T	S	B
$50 \text{ } \mu\text{V}/^\circ\text{C} (@ 0^\circ\text{C})$	$40 \text{ } \mu\text{V}/^\circ\text{C} (@ 0^\circ\text{C})$	$40 \text{ } \mu\text{V}/^\circ\text{C} (@ 0^\circ\text{C})$	$10 \text{ } \mu\text{V}/^\circ\text{C} (@ 500^\circ\text{C})$	$9 \text{ } \mu\text{V}/^\circ\text{C} (@ 1000^\circ\text{C})$

E	N	C	L	
$60 \text{ } \mu\text{V}/^\circ\text{C} (@ 0^\circ\text{C})$	$26 \text{ } \mu\text{V}/^\circ\text{C} (@ 0^\circ\text{C})$	$18 \text{ } \mu\text{V}/^\circ\text{C} (@ 1000^\circ\text{C})$	$50 \text{ } \mu\text{V}/^\circ\text{C} (@ 0^\circ\text{C})$	

---

**Example of accuracy calculation**

We make a measurement between  $-50^{\circ}\text{C}$  and  $+50^{\circ}\text{C}$  with a J thermocouple with compensation for cold solder.

$$P_t = P_l + P_s + P_m + P_d$$

$$P_l = \pm 0.25^{\circ}\text{C} \text{ (linearization accuracy)}$$

$$P_s = \pm 1.25^{\circ}\text{C} \text{ (compensation for cold solder)}$$

Used caliber	10 mV (see the previous example)
Accuracy for voltage measurement	$0.1\% * 10 \text{ mV} + 10 \mu\text{V} = 20 \mu\text{V}$
Slope of thermocouple J	$50 \mu\text{V}/^{\circ}\text{C}$
Accuracy $P_m$	$P_m = 20/50 = 0.4^{\circ}\text{C}$
Total accuracy	$P_t = 0.25 + 1.25 + 0.4 = 1.9^{\circ}\text{C}$

### 16.3. Measurement accuracy for PT100

The following measurement inaccuracies are given as max. values: the typical values are 2 to 3 times weaker.

The measurement accuracy for temperature is the addition of several possible inaccuracy sources:

Pl: accuracy of linearization

Pz: accuracy of the zeroing

Pm: accuracy of measurement of the equivalent voltage

Pd: accuracy of the measurement offsets

The total accuracy is then:  $P_t = P_l + P_z + P_m + P_d$

For the recorder:

$P_l = \pm 0.1 \text{ } ^\circ\text{C}$  for all PT100

$P_z = \pm 0.25 \text{ } ^\circ\text{C}$  for all PT100

$P_d = \pm 0.10 \%$  of the offset

$P_m =$  data in the tables

Measurement accuracy:  $P_m$

The measurement accuracy  $P_m$  depends on the voltage caliber used for the appliance. The measurement error margin, in  $^\circ\text{C}$ , will be the voltage error margin divided by the slope, in  $\text{V}/^\circ\text{C}$ .

For all voltage calibers, the accuracy is  $\pm 0.1\% \pm 10 \mu\text{V}$ .

Slope as a function of temperature:

<b>Temperature (<math>^\circ\text{C}</math>)</b>	-200	-100	0	200	400	600	800
<b>Slope (<math>\mu\text{V}/^\circ\text{C}</math>)</b>	378	354	342	321	301	281	260

Measurement accuracy of the equivalent voltage at 0°C:

Temperature Caliber	Tension Caliber	max. Tension error [ $\mu\text{V}$ ]	max. Error in °C
<b>20</b>	<b>10</b>	<b>20</b>	<b>0.06</b>
<b>50</b>	<b>20</b>	<b>30</b>	<b>0.09</b>
<b>100</b>	<b>50</b>	<b>60</b>	<b>0.18</b>
<b>200</b>	<b>100</b>	<b>110</b>	<b>0.32</b>
<b>500</b>	<b>200</b>	<b>210</b>	<b>0.60</b>
<b>1000</b>	<b>500</b>	<b>510</b>	<b>1.50</b>
<b>2000</b>	<b>1000</b>	<b>1010</b>	<b>3.00</b>

### Example of accuracy calculation

We make a measurement around 240°C on the 500°C caliber centered on 0°C with a PT100 probe.

$$P_t = P_l + P_z + P_m + P_d$$

$$P_l = \pm 0.1 \text{ °C} \quad (\text{accuracy of linearization})$$

$$P_z = \pm 0.25 \text{ °C} \quad (\text{accuracy of zero})$$

$$P_d = 0 \quad (\text{no offset})$$

Calculation of  $P_m$ :

Calculation of the slope at 240°C:  $321 + (301-321) \times (240-200) / (400-200)$ , which means 317  $\mu\text{V}/\text{°C}$ , thus  $P_m = 210 / 317 = \pm 0.66 \text{ °C}$

max. total accuracy:

$$P_t = 0.1 + 0.25 + 0.66 = \pm 1.01 \text{ °C}$$

## 16.4. Accuracy of instant measurement according to the filters

The accuracy of instant measurement is specified with a 10 Hz filter:  $\pm 0.1\%$  of full scale  $\pm 10 \mu\text{V} \pm 0.1\%$  of the offsets

For higher frequency filters and for weaker calibers (high gain), the noise will be stronger (the product gain x bandwidth is constant): you have to add a noise specification. For example, you cannot get an instant accuracy of 0.1% on a 1 mV caliber without a filter.

The table below gives you the typical noise peak to peak for various calibers and filters, as a % of the caliber.

The measurements are made on a continuous voltage source « - » grounded to the source of voltage to get free from the common mode.

Caliber	1 mV	2 mV	5 mV	10 mV	20 mV	50 mV	100 mV	200 mV	>200 mV
Filter	1 kHz	1 kHz	1 kHz	10 kHz	10 kHz	10 kHz	w/o	w/o	w/o
Typical noise	3%	1.5%	0.7%	1%	0.6%	0.2%	0.6%	0.5%	0.3%

The noise is proportional to the square root of the bandwidth. To know the noise level on other filter positions, you only have to calculate the square root of the bandwidth ratio.

### Example:

Noise at 10 mV with a 10 Hz filter?

Noise = 1% with a 10 kHz filter

Ratio = square root (10000/10) = 32

Thus, the noise level will be lowered by a 32 factor

Noise = 0.03% with a 10 Hz

## 16.5. Note on the measurement units for a gauge strain

The basis unit selected for the measurements on gauge strain is  $\mu\text{S}$  (micro Strain) applied to a complete bridge equipped with only one constraint-sensitive resistance.

If the bridge is equipped with 2 or 4 constraint-sensitive resistances, or if the characteristics of the bridge are given in  $\text{mV/V}$ , you can easily change of unit by using the change-of-unit function.

Fundamentally, the measurement is always a measurement of voltage.

### 16.5.1. Conversion rules

Complete bridge with 1 active resistance active: constraint = default measurement ( $\mu\text{S}$ )

Complete bridge with 2 active resistances: constraint = default measurement divided by 2 ( $\mu\text{S}$ )


Complete bridge with 4 active resistances: constraint = default measurement divided by 4 ( $\mu\text{S}$ )

Display in  $\text{mV/V}$ : use the unit change **1  $\text{mV/V}$   $\Leftrightarrow$  2000  $\mu\text{S}$**

Display in V (if excitation = 2 V and  $G = 2$ ): **1  $\mu\text{V}$   $\Leftrightarrow$  1  $\mu\text{S}$**

### 16.5.2. Calculation details

- Case of the complete bridge with only one variable resistance (default case)



$V_{in}$ : excitation voltage of the bridge

$G$ : gauge factor

$R$ : resistance of the gauge strain

$V_{out}$ : voltage measured between the middle point of the bridge

$S = \Delta L/L$ : lengthening of the gauge or constraint (strain)

For a bridge with 4 identical resistances, where one resistance changes with a variation  $\Delta R$ , you can demonstrate:

$$V_{out} \approx (V_{in} / 4) * (\Delta R/R)$$

$$\text{We have : } \Delta R/R = G * \Delta L/L$$


$$V_{out} = (V_{in} / 4) * G * \Delta L/L \quad (1)$$

$$\mathbf{V_{out} = (V_{in} / 4) * G * S} \quad (1)$$

In the general case  $G = 2$ , we get:


$$\begin{aligned} \text{for } V_{in} = 2 \text{ V} &\rightarrow V_{out} = S &&\rightarrow 1 \mu\text{V} \Leftrightarrow 1 \mu\text{S} \\ \text{for } V_{in} = 5 \text{ V} &\rightarrow V_{out} = 2.5 * S &&\rightarrow 2.5 \mu\text{V} \Leftrightarrow 1 \mu\text{S} \end{aligned}$$

- Case of the complete bridge with 2 variable resistances



$$\mathbf{V_{out} = (V_{in} / 2) * G * S}$$

- Case of the complete bridge with 4 variable resistances



$$V_{out} = (V_{in}) * G * S$$



### 16.5.3. Display of the characteristics of the bridge in mV/V

For some bridges, the characteristics are given in mV/V

The equation (1) is equivalent to:

$$V_{out}/V_{in} = G * S / 4$$

For  $G = 2$ , we get  $V_{out}/V_{in} = S/2$

Hence  $1\text{mV/V} \Leftrightarrow 2000 \mu\text{S}$

### 16.5.4. Example of unit change

A weighting gauge strain system shows: 0.89 mV/V for 600 g

Conversion into  $\mu\text{S}$  ( $G=2$ )  $\rightarrow 0.89*2000 \rightarrow 1780 \mu\text{S}$  for 600 g

Using a change of unit with the parameters:

Unit: gram

X1=0

Y1=0

X2=1780  $\mu\text{S}$

Y2=600 g

The display is now directly in grams.

---

## 16.6. Accuracy class – class index

This is a key concept of the CEI recommendation; it tends to alleviate the list of specifications. For that, it introduces the notion of ACCURACY CLASS function of the CLASS INDEX C. The normalized values of the class index are: C = 0.1; 0.25; 0.5 and 1.

The inherent error (in the reference conditions) should not exceed  $\pm C$  % (the manufacturer can also specify the inherent error restriction as an absolute value (for example  $\pm 5$  mV) for the first calibers).

The variations (of the measured value), when an influence value varies in the nominal domain of use, will not exceed:

- C % for the position for the externally induced magnetic induction and for the parasite voltages
- 0.5 C% for the power supply source
- 0.3 C% according to the class index for the ambient temperature (0.15 % for the class 0.25).

In addition, the insensitivity range must not exceed:

- C% in the reference conditions
- 1.5C% for the maximal resistance of the external measurement circuit
- 2C% for the parasite voltages
- 

At last, the overrun must not exceed 2C% (4C% for the limits of the power source).



**DECLARATION OF CE CONFORMITY**

according to EEC directives and NF EN 45014 norm  
*DECLARATION DE CONFORMITE CE*  
suivant directives CEE et norme NF EN 45014



**SEFRAM INSTRUMENTS & SYSTEMES**  
32, rue Edouard MARTEL  
42009 SAINT-ETIENNE Cedex 2 ( FRANCE)

Declares, that the below mentioned product complies with :  
*Déclare que le produit désigné ci-après est conforme à :*

**The European low voltage directive 2006/95/EEC :**  
*La directive Européenne basse tension 2006/95/CE*

**NF EN 61010-1 Safety requirements for electrical equipment for measurement, control and laboratory use.** Règles de sécurité  
pour les appareils électriques de mesurage, de régulation et de laboratoire.

**The European EMC directive 2004/108/EEC :**  
**Emission standard EN 61326-1, EN 61326-2-1.**  
**Immunity standard EN 61326-1, EN 61326-2-1.**  
*La directive Européenne CEM 2004/108/CE :*  
*En émission selon NF EN 61326-1, EN 61326-2-1.*  
*En immunité selon NF EN 61326-1, EN 61326-2-1.*

**Installation category** *Catégorie d'installation :* Réseau 300 V cat II  
Mesure 600 V Cat III

**Pollution degree** *Degré de pollution :* 2

**Product name** *Désignation :* Recorder *Enregistreur*

**Model Type :** DAS 1600- DAS 800

**Compliance was demonstrated in listed laboratory and record in test report number**  
*La conformité a été démontrée dans un laboratoire reconnu et enregistrée dans le rapport numéro* RC DAS 1600

**SAINT-ETIENNE the :**  
Thursday, 06 June 2013

**Name/Position :**  
CLERJON / Quality Manager

