

## Foreword

Dear Users,

Thanks for choosing our alarm system. For better operation of the system, please read the instruction manual carefully before using.

After reading, please keep the manual carefully for future reference.

## Copyright Information

- The product, including but not limited to granted or pending patents, is under protection of the patent laws of PRC or other countries.
- We reserve the rights for modification of the specification or price of the product.

## Security Overview

Read the following security precaution measures to prevent any personal injury or damage to the product, while making the best of its function.

- Use the correct power supply. voltage: 12V, current: >1A.
- To avoid the damage of the main unit caused by wrong connection, installation shall be performed by professionals.
- Please don't press the touch keyboard of the main unit heavily.
- Please don't use the product in damp environment.
- Please don't use the product under inflammable and explosive conditions.
- Keep the surface of the product clean and dry.
- Maintain proper ventilation.

## Foreword

This manual introduces the performance characteristics and operation procedure of the product.

- Chapter 1 Functions and Advantages of Alarm System's Main Unit
- Chapter 2 Introduction of Interface and Panel of Alarm System's Main Unit
- Chapter 3 Main Unit Startup Procedure
- Chapter 4 Relevant Settings for Alarm System's Main unit
- Chapter 5 Routine Use and Maintenance
- Chapter 6 System Troubleshooting
- Chapter 7 Service and Technical Support
- Chapter 8 Appendix: Product Parameters
- Chapter 9 Appendix: Factory Setting Parameters
- Chapter 10 Appendix: List of countries Where the Product is Suitable for Use

## Chapter 1 Functions and Advantages

Wireless **GSM** intelligent anti-theft electronic alarm system is an innovative mobile intelligent alarm device integrating **GSM** digital signal processing techniques and imported STC microprocessor, and a variety of technologies including digital voice announcer, SMS, learning code pairing, etc. In addition, this alarm system is highly automatic, giving automatic voice or SMS alert in the event of emergency without intensive manual settings required. Features of stability, reliability, safety, and humanizing control enable it to be widely used for security in shops, convenience stores, offices, villas, residential communities, etc.


- 128X64 dot matrix display in both Chinese and English language. The built-in clock is convenient for time checking.
- Original operation system for the main unit allows simple operation.
- Support card access control system, needless to carry the traditional remote control.
- **4** wired and **10** wireless zones, each can support 10 detectors (the maximum is 100).
- Code pairing for up to **8** wireless remote controls.
- Built-in intercom speakers with high acoustic quality and large volume.
- Arm/disarm at regular time.
- Preset **6** alarm phone numbers, which the main unit shall dial automatically to make voice alarm.

- Preset **3** SMS numbers, to which the main unit shall send the alarm SMS automatically.
- **10s** of manual recording.
- Built-in digital voice announcer, which shall report alarm conditions automatically.
- Built-in SMS in English/Chinese, which shall be sent automatically.
- Telephone function, allowing communication with any phone via the main unit dialing.
- One key control to arm the system via remote control or telephone when at home or outside.
- Programming for alarm place: help-seeking, fire, gas, door lock, living room, window, balcony or surrounding alarm.
- Various programming functions for zones, such as real time, delayed, 24 hours and bypass.
- Learn the code pairing through wireless way. It is easy to add new parts in safe and efficient way.
- Various functions, such as remote control, system arming/disarming, monitoring and intercom.
- Inquire event recording: the main unit can record all the information of 40 alarm events automatically.
- Multi-arming modes: real-time arming via remote control, delayed system arming when outgoing, arming at home, arming at appointed time, remote arming via phone.
- Maintain the top priority of alarm: If there is alarm while calling, no matter incoming or outgoing, the main unit shall hang up call and dial the alarm phone immediately.
- Built-in lithium battery with high capacity to enable alarm while power-off.
- The system will be more secure if use GSM+Line alarm

## Chapter 2 Introduction of Interface and Panel of Alarm System's Main Unit



- 1: Main unit display screen with 128X64 resolution, supporting Chinese/English language
- 2: Main unit status indicator
  - POWER: Indicator for power-on and work status of the main unit  
Quick flicking at 1s interval means the GSM network is under registration.  
Flicking every 3s means the main unit is in normal standby status and ready for alarm.
  - ARM: arming when outgoing indicator
  - HOME: arming at home indicator
  - SET: Setting status indicator, it shall be on when entering the system setting.
  - SIGNAL: Wireless signal indicator, it shall be on when effective wireless signals are available or under special functions.
  - ALARM: Alarm indicator
- 3: Touch keyboard: the key of the system is touch screen of resistance-type, which requires a certain level of force. DO Not press it heavily. .
  - : Key for arming when outgoing by the main unit at appointed time
  - : Key for arming at home by the main unit
  - : Call key. Input phone number, and press CALL key, the main unit shall dial immediately and enter into the calling status. Press CALL key while calling to hang up.
    - SOS: Emergency help key
    - ESC: Clear the keyboard entry, or return to the previous step.
    - ENTER: Confirmation key



## 4: Function interface of the main unit

1	T_VCC	External keyboard power supply: 12V voltage
2	T_GND	Grounding external keyboard
3	A	Connecting external keyboard A
4	B	Connecting external keyboard B
5	GND	Grounding
6	Zone 1	Wired zone 1 input, adopting normal on/off prober
7	GND	Grounding
8	Zone 2	Wired zone 2 input, adopting normal on/off prober
9	GND	Grounding
10	Zone 3	Wired zone 3 input, adopting normal on/off prober
11	GND	Grounding
12	Zone 4	Wired zone 4 input, adopting normal on/off prober
13	GND	Grounding
14	G_ANT	External antenna grounding
15	ANT	External antenna

## 5: Built-in battery switch

- 6: POWER: Power in。
- 7: SP:Siren in。
- 8: TEL:Telephone    LINE: Telephone line。

### **Chapter 3    Main Unit Startup Procedure**

It is important to startup the main unit correctly, which may affect the normal operation and service life of itself.

- Step1: Disconnect the main unit with power supply, for it is prohibited to operate the main unit in power on status, such as inserting/pulling off the interface kits and the SIM card
- Step2: Install the SIM card
- Step3: Insert the 12V power supply adapter of the main unit. The main unit shall enter into self-checking status and show the startup information. Check whether the POWER indicator flickers quickly every 1s. If the POWER indicator is not on, re-start the main unit after 10s interval. Repeated power on/off operations in a short while may reduce its service life.
- Step4: After the main unit registered successfully on the network, the POWER indicator shall flicker every 3s.

Step5: Turn on the battery switch.

Step6: Check whether the GSM signal strength is more than 3 bars, for weak signal may affect the normal operation of the main unit.

## Chapter 4 Relevant Settings for Alarm System's Main Unit

### Enter into System Setting

The setting of the main unit can only be carried out in the system setting status, in which the SET indicator shall be on. At that time, Key 2/8/4/6 is for turning the menu up/down/left/right respectively. Please follow the way below to enter into the setting:

When the system is disarmed, input the 6-digit setting password (the factory setting is 888888), and then press ENTER key to confirm. When the main unit emits a beep tone, the system enters setting status with the SET indicator on, showing the setting menu for remote control. The detailed operation diagram is as

follows:

Diagram1: System disarmed status




Diagram2: Input setting password




Diagram3: Press ENTER key to enter setting status



## Add Remote control

The system can support up to 8 remote controls. It is required to enter the system setting for adding remote controls. The remote controls must be coded, which may be high-rate or low-rate. For anti-interference, the software of the main unit has blocked these special coding. If the coding of the remote control is identical with the one saved in the main unit, it shall fail to add new remote control. The detailed way is as follows: enter the Remote Control menu, and then press Key 4 or 6 to choose the target one; Press Key 8 to turn to the Coding menu, and then press ENTER key to confirm; after the remote control transmits signals, and the main unit identifies the remote control, press ENTER key to confirm and save. The detailed operation diagram is as follows:




Diagram 4A: the main unit can identify the remote control coding correctly



Diagram 4B: The coding of remote control is identical with the one saved in the main unit




Diagram5: Press ENTER key to save the remote control coding



## Delete Remote Control

When the remote control is broken or lost, its information shall be deleted from the main unit. The deleted remote control can not control the main unit. The detailed way is as follows: enter the Remote control menu, press Key 4 or 6 to choose the target remote control. Press Key 8 to turn to the Delete menu, and then press ENTER key to confirm. The main unit shall show that the deletion is successful. The detailed operation diagram is as follows:

Diagram1: Enter Remote control menu





Diagram2: Choose the target remote control



Diagram3: Press ENTER key to confirm the deletion.



## Code Pairing in Zone

This system can support up to 10 wireless zones, each of which can save 10 detectors (the maximum is 100). It is required to enter the system setting to add new detectors. The remote controls must be coded, which may be high-rate or low-rate. For anti-interference, the software of the main unit has blocked these special coding. If the coding of the detector is identical with the one saved in the main unit, it shall fail to add new remote control. The detailed way is as follows: enter the Zone menu, and then press Key 4 or 6 to choose the target one; Press Key 8 to turn to the Coding menu, and then press ENTER key to confirm; after the detector transmits signals, and the main unit identifies the detector, press ENTER key to confirm and save. The detailed operation diagram is as follows.

Diagram1: Enter Zone menu




Diagram2: Choose the target zone, and then press ENTER key



Diagram3: Ready to receive the detector signal.




Diagram 4A: the main unit can identify the detector coding correctly





Diagram 4B: The coding of the probe is identical with the one saved in the main unit already




Diagram5: Press ENTER key to save the detector coding



## Delete Zone

When the detector is broken or desired to be deleted, its information shall be deleted from the main unit. The deleted remote control can not control the main unit. The detailed way is as follows: enter the Zone menu, press Key4 or 6 to choose the target zone. Press Key8 to turn to the Delete menu, and then press ENTER key to confirm. The main unit shall show that the deletion is successful. The detailed operation diagram is as follows:



### Change Installation Location of Zone

After identifying the installation location for the detector, the system can send out correct alarm SMS. This system can support up to 8 kinds of installation locations: help-seeking in emergency, fire alarm, gas leakage alarm, door lock alarm, living room alarm, window alarm, balcony alarm and surrounding alarm, to meet the users' requirements. The detailed way is as follows: enter the Zone menu, press Key2 or 8 to choose the installation location of zone menu. Press ENTER key to confirm and choose the relevant installation location. The detailed operation diagram is as follows:

Diagram1: Enter Zone menu




Diagram2: Turn down to choose installation place menu



Diagram3: Press ENTER key to choose the installation place



Diagram4:





Before setting, the content of the SMS sent by the zone 1 is: Zone 01 fire alarm.

After setting, the content of the SMS sent by the zone 1 is: Zone 01 gas leakage alarm.

## Change Zone Alarm Condition


The alarm conditions for all zones of the system can be changed freely. There are 3 supporting modes: Arming alarm when outgoing/arming alarm staying home, disarming alarm. For example, when the gas

detector is required to enable the alarm inspection all day long, it is necessary to enable alarm under system arming, home arming and system disarming. The detailed way is as follows: enter the Zone menu, press Key 2 or 8 to choose Home menu. Press ENTER key to enable or disable this function. Set the same alarm condition for outgoing arming and system disarming modes. The detailed operation diagram for changing the effective conditions for home arming is as follows:







## Enable/Disable Siren when Zone Makes Alarm

All the zones of the system can enable/disable the siren to reduce the noise interference according to the user's demand. The detailed way is as follows: enter the Zone menu, press Key 2 or 8 to choose the Siren menu. Press ENTER key to enable or disable this function. The detailed operation diagram for changing the effective condition for siren is as follows:



## Enable Delayed Alarm in Zone

All the zones of the system can set delayed dialing and enable siren after a valid alarm to meet the various requirements of users. The detailed way is as follows: enter the Zone menu, press Key2 or 8 to choose the Delay menu. Press ENTER key to choose enable or disable this function. The detailed operation diagram for changing the effective condition for delayed dialing is as follows:



## Set System Alarm Phone

This system can set 6 alarm phone numbers, which the system shall dial circularly to send out alarm information until one of the phones confirms the reception with key operation, and then the system shall stop dialing and the siren. Otherwise, the system shall dial circularly 3 times before stopping. The detailed way for setting the phone numbers is as follows: enter the Phone number menu, press Key 4 or 6 to choose the serial No. of phone numbers ,and press ENTER key to confirm .Input the desired phone numbers, then press ENTER key again to save. The detailed operation diagram for setting the alarm phone is as follows:

Diagram1: Enter Phone number menu




Diagram2: Choose target phone number, and then press ENTER.






Diagram3: Input phone number.






### Delete or Modify System Alarm Phone




The detailed way for deleting the phone numbers is as follows: enter the Phone Number menu, press Key 2 or 8 to choose the serial No. of phone numbers. Press ENTER key to confirm the deletion. The detailed operation diagram for deleting the alarm phone is as follows:





### Set System Alarm SMS Number



This system can set 3 alarm SMS numbers, to which the system shall send out the relevant SMS after a valid alarm. The detailed way for setting the SMS numbers is as follows: enter the SMS number menu, press Key 4 or 6 to choose the serial No. of SMS numbers, and press ENTER key to confirm. Input the desired phone numbers, then press ENTER key again to save. The detailed operation diagram for setting the SMS number is as follows:





### Delete or Modify System SMS number

The detailed way for deleting the SMS number is as follows: enter the SMS number menu, press Key 2 or 8 to choose the serial No. of SMS numbers. Press Key 8 to choose the Delete menu, and then press ENTER key to confirm the deletion. The detailed operation diagram for deleting the SMS number is as follows:








### Set Network Center Function

The network function of community shall be supported by the alarm center, the protocol of which shall be compatible with the system's protocol or networking may not work. This system supports phone center and SMS network center. If you need to use the network function, please contact us. The setting of network function includes center phone numbers, user IDs, and other parameters.

Set center phone number: enter the Network Centers menu, and the Phone Center menu, and then press ENTER key to enter setting status. Input the phone center number and save it. The detailed operation diagram is as follows:



Set user ID: enter the Network Centers menu, and the Phone Center menu. Press Key **6** to move right to choose the User ID menu and press Enter. Input the user ID, press Save key to save it.

The detailed operation diagram is as follows:

Diagram1: Enter Network Centers menu




Diagram2: Choose user ID and confirm.




Diagram3: Input user ID




Diagram4: Save the user ID



Upload alarm to the network center: enter the Network centers menu, and the Phone Center menu. Press Key 6 to move right to choose the Alarm Report menu, and press ENTER to enable/disable this function.





The detailed operation diagram is as follows:



Upload system arming/disarming report to the network center: enter Network centers menu, and then enter the Phone Center menu. Press Key **6** to move right to choose the Arm Report menu, and press

ENTER key to enable/disable this function.

The detailed operation diagram is as follows:




## Set Function of Recording for 10s

This system can make recording for 10s in advance, which will be sent out via alarm phone call, giving a brief description of the alarm.

Make audio recording: enter the Recording menu, and enter Start Recording menu. Press ENTER to start recording with medium volume. At this time, speak to the main unit. After counting down for 10s, the recording will stop.

The detailed operation diagram is as follows:







## Play Recording for 10s

Play the audio recording: enter the Recording menu, and enter Start Recording menu. Press Key 6 to

choose the Playback menu, and then press ENTER key to play the recording. The recording can be made again if users are not satisfied,


The detailed operation diagram is as follows:



## Set System Date

The date format of this system is year/month/day, with the year range between 00-99. The setting way is: enter the Time menu, and enter the Date menu. Press Enter to input the correct date, and save it.





The detailed operation diagram is as follows:



## Set System Time

The time format of this system is 24-hour format. The setting way is: enter the Time menu, and then enter the Date menu. Press Key 6 to choose the Time menu, then input correct time and save it.


The detailed operation diagram is as follows:



## Set Time for System Arming

After setting the arming time, the main unit will enter the arming when outgoing status at the appointed time, which can save users' time for daily manual setting. The setting way is: enter the Time menu, and then enter the Date menu. Press Key 6 to choose the Timely Arm menu, then input correct time and save it.


The detailed operation diagram is as follows:



## Set Time for System Disarming

After setting the arm time, the main unit will enter the disarming status at the appointed time, which can save users' time for daily manual setting. The setting way is: enter the Time menu, and then enter the Date menu. Press Key 6 to choose the Timely disarm menu, then input correct time and save it.


The detailed operation diagram is as follows:



## Enable Wireless Control Function

This system supports the function of wireless control for home appliances and sirens. To enable this function, it is required to operate in the following way: enter the Wireless Control menu, and then enter the Control menu. Press Enter key to enable this function.


The detailed operation diagram is as follows:



## Wireless Siren Code Pairing

This system supports the function of wireless siren to eliminate the arrangement of wire. It is required to code pairing the wireless siren with the main unit. The way for setting is: enter the Wireless Control menu, and then enter the Control menu. Press Key 6 to enter the Wireless Siren menu, and choose the option of Transmission. Then the main unit shall transmit a wireless signal to control the code pairing of the wireless siren.

The detailed operation diagram is as follows:



## Wireless Siren Encryption

When the wireless siren confronts repeated codes or interruption, it is required to encrypt the wireless siren signal transmitted by the main unit before transmission, and then make code pairing with the wireless siren again. The way for setting is: enter the Wireless Control menu, and then enter the Control menu. Press Key 6 to choose the Wireless siren menu, and press Key 8 to choose the option of Encryption. Input 4 digits randomly, and save it

The detailed operation diagram is as follows:

Diagram1: Enter Wireless Control menu




Diagram2: Enter Control menu



Diagram3: Press Key6 to choose Wireless siren, and press Key 8 to choose Encryption




Diagram5: Input 4 digits randomly





Diagram6: Save the numbers




## Wireless Control for Home Appliance

This system can support up to 8 lines of wireless control for home appliances. Please refer to the wireless siren setting for the way to make code pairing with the home appliance. The operation of wireless control for home appliance requires the use of wireless control. Please contact us if need to use this function.

## Modify Operating Password

The operating password is used by users for daily operation. Please take not of it properly, users can not control the main unit if the password is lost. The factory setting of the password is 1234. It is recommended to set the password to your own convenience during formal operation. The way for setting the password is: Enter the Settings menu, and then enter the Operate password menu. Input 4-digit operating password and save it.





## Modify Program Password

The program password is used by users for setting the system. Please remember it clearly, otherwise, users can not set the main unit. The factory setting of the password is 888888. It is recommended to set the password as the one easy to remember during formal operation. The way for setting the password is: enter the Settings menu, and then enter the Operate password menu. Press Key 6 to choose the Program password menu. Input 6-digit as program password and save it.







Diagram4: Input password, and save it



### Modify Time for Delayed Arming

After pressing the ARM key, the main unit shall be in the arming status at the appointed time. The factory default time for delayed arming is 60s with the time range between 1s-99s. It is recommended to adjust it in line with actual demand during formal operation. The way for modifying the time for delayed arming is: enter the Settings menu, and then enter the Operate password menu. Press Key6 to choose the Delay arm menu. Input the desired time and save it.

Diagram1: Enter into Settings menu



Diagram2: Enter into Operate password menu




Diagram3: Press Key6 to enter into Delay arm menu



Diagram4: Input time, and save it



### Modify Time for Delayed Alarm

When the function of delayed alarm is valid, the main unit shall alarm at the appointed time. The factory setting for delayed alarm is 40s with the time range between 1s-99s. It is recommended to adjust it in line with actual demand during formal operation. The way for modifying the time for delayed alarm is: enter the Settings menu, and then enter the Operate password menu. Press Key 6 to choose the Delay alarm menu. Input the desired time and save it.

Diagram1: Enter into Settings menu




Diagram2: Enter into Operate password menu



Diagram3: Press Key6 to enter into Delay alarm menu



Diagram4: Input time, and save it



### Enable/Disable Voice Prompt Function

This system supports the function of voice prompt. When users arm/disarm via remote control, the main unit shall broadcast the relevant status through voice prompt. The factory setting for the voice prompt is: enable. It is recommended to adjust it in line with actual demand during formal operation. The way for modifying the voice prompt is: enter the Settings menu, and then enter the Operate password menu. Press Key 6 to choose the Voice prompt menu, and choose to enable/disable it.

Diagram1: Enter Settings menu



Diagram2: Enter Operate password menu



Diagram3: Press Key6 to enter Voice prompt menu



Diagram4: Choose the option of Enable or Disable



### Enable/Disable Siren Prompt Function

This system has the function of siren prompt. When users enable/disable arm via remote control, the main unit shall beep as siren to let users hear in long distance and know whether it is under normal control. The factory setting for the siren prompt is: disable. It is recommended to adjust it in line with actual demand during formal operation. The way for modifying the siren prompt is: Enter the Settings menu, and then enter the Operate password menu. Press Key 6 to choose the Siren prompt menu, and choose to enable/disable it.

Diagram1: Enter into Settings menu



Diagram2: Enter into Operate password menu



Diagram3: Press Key6 to enter into Siren prompt menu



Diagram4: Choose the option of Enable or Disable



### Enable/Disable System Backlight

The backlight of display screen and keys shall be off automatically when there is no action to press the keys. It is required to set to keep the backlight on. The factory setting for the backlight is: disable. It is recommended to adjust it in line with actual demand during formal operation. The way for modifying the backlight is: enter the Settings menu, and then enter the Operate password menu. Press Key6 to choose the Backlight on menu, and choose to enable/disable it.

Diagram1: Enter Settings menu




Diagram2: Enter Operate password menu



Diagram3: Press Key 6 to enter backlight on menu



Diagram4: Choose the option of Enable or Disable



### Enable/Disable Siren when making Emergency Help Alarm via Remote Control

The factory setting is that there is no siren when users press the Emergency help key on the remote control. It is recommended to adjust it in line with actual demand during formal operation. The way for modifying the siren is: enter the Settings menu, and then enter the Operate password menu. Press Key 6 to choose the Remote siren menu, and choose to enable/disable it.


Diagram1: Enter Settings menu




Diagram2: Enter Operate password menu



Diagram3: Press Key 6 to enter Remote siren menu





### Enable/Disable SMS when Arming/Disarming

When users arm/disarm the main unit, other users may not know it. Set the SMS to let all users know the status of the system in time. It is recommended to adjust it in line with actual demand during formal operation. The way for modifying the SMS is: enter the Settings menu, and then enter the Operate password menu. Press Key 6 to choose the Arm disarm SMS menu, and choose to enable/disable it.





Diagram4: Choose the option of Enable or Disable



## Set System Language

This system can support both Chinese and English language, the switch way for which is: enter the Settings menu, and then enter the Operate password menu. Press Key 6 to choose the Language menu, and choose to enable/disable it.

Diagram1: Enter Settings menu




Diagram2: Enter Operate password menu



Diagram3: Press Key 6 to enter Language menu



Diagram4: Choose language of Chinese or English



### The number of telephone ringing

After the call from set telephone lines, Ring after how many times to answer. Method: enter into Setup system, confirm, enter into the operation code menu, press 6 to choose telephone ringing frequency menu to decide the choice ringing frequency

Diagram1: Enter Settings menu





Diagram2: Enter Operate password menu




Diagram3: Press Key 6 to enter line rings menu






### typeof alarm

Sets the system alarm circuit, the system can select phone linealarm, Or GSM line alarm, or telephone line road + GSM line alarm.Method: entre into Setup system, confirm,enter into theoperation code menu, press 6 to choose the alarm mode menu to decide the choicealarm way.





## Restore Factory Setting

When the system is unstable, it is recommended to restore the factory setting in the following way: enter the Settings menu, and then enter the Operate password menu. Press Key 6 to choose the Factory setting menu, and choose the option of Restore. The main unit shall show that “Please wait back to default setting”. After restoring the factory setting, the main unit shall exit from the setting condition.





Diagram4: Restore factory setting



### Emergency Setting when Forgetting Password

If users forget the password, they can input order as 95175308246 in disarming status, and then the main unit shall show that “Please wait back to default password”. After restoring successfully, the factory setting for operating/program password is 1234/8888888 respectively. The detailed operation diagram is as follows:

Diagram1: in system disarmed status




Diagram2: input order of 95175308246




Diagram3: Restore factory setting



Diagram4:

After restoring password, the operating/program password is 1234/8888888 respectively.

## Chapter 5 Routine Use and Maintenance

### System Disarming


The purpose of disarming the main unit is let it not in the status of alert. One way is normal disarming after operation of arming, and the other is to stop the main unit making alarm. After being disarmed, the zones shall not work except the 24-hour arming ones.

Press digital keyboard of the main unit to input **[User password]**, plus **[#]**. The information of “system disarmed” showing on the main unit means that the operation of disarming is successful.

Remote control: press **[🔑]** key on the remote control.

The main unit control: **[Password] + [ENTER]**.

Diagram1: System disarmed status



### System Arming


“System arming” means that the main unit shall be armed wholly: when there is no person at home, it is

required to detect all the armed range with all the detectors on. When any detection source (such as invasion of thief, fire or gas leakage) triggers the detector, it shall make alarm immediately.

Press **[ARM]** key on the keyboard of the main unit, it shall beep once every 1 second after the appointed time and show the information about “system armed”, which means the arming is successful.

Remote control: **press [📶] key on the remote control once.**

The main unit armed: **press [ARM] key to let the main unit arming in delayed time.**



## Home Arming

“Home arming” means the main unit shall be armed partly: when there is someone at home, If it is required, for safety reasons, to enable some of the detectors (at door, window, balcony or surrounding, for example) and disable the others (such as at living room, triggered by hosts), the home arming is suitable.

Press **[STAY]** key on the keyboard of the main unit, **it shall show that “Home arm”**, which means the operation is successful.

The main unit control: **press [STAY] key to let the main unit in the status of home arming.**

Remote control: **press [**↵**] key on the remote control once.**



### **Answer Alarm**

Once the main unit makes alarms, the siren shall send out voice prompt and dial the preset phone numbers automatically to make voice alarm. If no one answers one of the phone calls, the main unit shall turn to dial the left phones automatically until dialing all the preset phones three times circularly.

If someone responds to the phone call, he/she can hear the alarm information from the receiver. At that time, press the keys on the phone (or mobile phone) to realize various functions:

Hang up directly: Just like no one answering the phone call, the main unit shall dial all the preset phones three times circularly.

**Press [\*] key:** read the alarm information.

**Press [1] key:** the main unit shall stop alarm, and arm without dialing again.

**Press [2] key:** the main unit shall stop alarm, and disarm without dialing again.

**Press [3] key:** the main unit shall disable the siren and monitor the site for 30s. Continue pressing if more time is desired for monitoring. Identify whether there is abnormal sound at home or any thief has invaded in.

**Press [4] key:** Enable the function of intercom on site for 30s.

## **Remote Control**

After Dialing the phone numbers connected with the main unit through phones or mobile phones, users shall hear the voice prompt as “Please input the password” from the receiver after the preset ringing. After Inputting the correct password (the operating password is 1234, each of which with keytone when inputted shall be viewed as effective one), users shall hear the voice prompt as “Please input the instruction”; Otherwise, users shall hear the voice prompt as “The password is wrong, please input again”. After entering into the remote control status, users shall implement the remote control via pressing the phone keys.

**Press [1] key:** the main unit shall enter the arming status, and users shall hear the voice prompt as “System armed” from the receiver.

**Press [2] key:** the main unit shall enter the disarming status, and users shall hear the voice prompt as “System disarmed” from the receiver.

**Press [3] key:** the main unit shall monitor the site for 30s, if continuous monitoring is required, press **[3]** key again to extend time for 30s.

**Press [4] key:** Enable the function of intercom on site for 30s

## Emergency Help

There are some accidents happening at home, such as old people or children get sick, who need first-aid, the fire breaks out at home, or ruffians invade into house to rob and calling **110** is desired. At that time, just press **[SOS]** key on the main unit, [] key on the remote control or the wireless emergency key, the alarm system shall make alarm via dialing the preset phones automatically.

Remote control: **press [] key on the remote control once.**

The main unit control: **press [SOS] emergency key on the keyboard of the main unit**




## Dial Phone

This system has the function of dialing, via which users can dial any phone numbers directly. It can be used as a convenient fixed phone. For example, in the status of system disarmed, input the phone number **[13800138000]** by pressing the keyboard, and then press [CALL] key. After beeping a long sound, the main unit shall show that it is dialing the phone **-13800138000**. If dialing successfully, user can start communication, and after finishing, press [CALL] key again to hang up. At that time, the system is in

the status of disarmed.

### Inquire Alarm Record

This system can save 30 historical alarm records with the last one as the first record. When storing more than 30 records, the system shall delete the oldest one automatically. The way for inquiring the alarm records is: Input 00 in the status of system disarmed, and then press ENTER to enter the inquiry status. Press Key 4 or 6 to turn the pages to check the records. Press ESC key to exit from the inquiry status. The detailed operation diagram is as follows:



### System Self-checking

Although being used every day, the system shall be maintained and inspected periodically, in order to ensure its stability, reliability and security. Normally, the main unit shall be inspected wholly every three month, and the

detectors shall be inspected every one month, at least once every three months.

Main Unit Inspection:

1. Whether the main unit can be armed/ disarmed normally.
2. Whether the main unit can dial to make alarm normally.
3. Whether the main unit can receive the signal of the detector, and whether the backup battery is normal.

Prober Inspection:

1. Trigger the detector by hand to check whether it can make alarm normally.
2. Inspect all the batteries of the detectors to check whether they are under voltage.
3. Test the transmission function of the wireless detector to check whether it can communicate with the main unit.

## **Chapter 6 System Troubleshooting**

Fail to detect the network: Is the SIM card fit properly? Install again

Is the PIN code of the SIM card set? Cancel it.

Is the mobile signal not strong enough at the installation location? Change the place

Alarm failure: Is the code normal or is code pairing successful? Identify the correct code, and carry out code pairing again.

Is the prober under voltage or is its transmission distance not long enough? Replace the battery.

Dialing failure: Is the mobile signal strong enough? Change the location of the main unit.

Is there enough balance in the GSM card? Check and recharge it.

Check whether the phone numbers have been set correctly.

Siren failure: Are the positive and negative poles of the siren contacted properly? Check Is the zone set as mute alarm? Reset

Voice disorder: Have users recorded voice before? Record again.

Remote control failure: Is the remote control password inputted correct? (Its factory setting is 1234)

---

## Chapter 7 Service and Technical Support

Our company guarantees that the alarm system will be free of defects in material and workmanship within 3 years since the date of shipment by the authorized distributors. If the product has been found any defect during the warranty period, please contact with the sales department or service station nearby. Under no conditions shall our company be liable for any indirect or special damage. If you get into any trouble when using the product, please contact with us directly in the China mainland or the local distributors outside PRC.

You can visit our website to get the address lists of our service centers around the world.

Thanks for your support.

## Chapter 8 Appendix: Product Parameters

Input Voltage:	DC12V /1A
----------------	-----------

Standby Current:	<35mA
------------------	-------

Alarm Current:	<450mA
----------------	--------

Wireless Frequency	315MHz, 2262 / 4.7MΩ
--------------------	----------------------

GSM System: 900/1800MHz /4 frequencies  
are available

Backup Battery: NI-HI AAA\*6 DC7.2V

Siren Loudness: 110dB

## Chapter 9 Appendix: Factory Setting Parameters

Zone	Arm	at Home	Type	Alarm Condition	Siren
Zone1	Enable	Disable	Real-time	Door lock alarm	Enable
Zone2	Enable	Disable	Real-time	Living-room alarm	Enable
Zone3	Enable	Enable	Real-time	Window alarm	Enable
Zone4	Enable	Enable	Real-time	Balcony alarm	Enable
Zone5	Enable	Enable	Real-time	Fire alarm	Enable
Zone6	Enable	Enable	Real-time	Gas alarm	Enable
Emergency key	Enable	Enable	<b>24H</b>	Help alarm	Disable

<b>7-10</b>	Enable	Disable	Real-time	Help alarm	Enable
Wired Zone (7-10)	Enable	Disable	Real-time	Help alarm	Enable
Programming password:	<b>888888</b>	Remote control:		Enable	
Operating password:	<b>1234</b>	Siren prompt:		Disable	
Siren duration:	<b>180s</b>	Home appliance control:		Configure optionally	

## Chapter 10 Appendix: List of Countries Where the Product Is Suitable For Use

For the product with 4 frequencies, it is available via the GSM network around the world.

For the product with 900/1800MHz, it is available in the following regions:

## Asia

East Asia: China, Mongolia, North Korea, Japan

Southeast Asia: Philippines, Vietnam, Laos, Bona, Thailand, Malaysia, Brunei, Singapore, Indonesia, East Timor

South Asia: Nepal, Bhutan, Bangladesh, India, Pakistan, Sri Lanka, Maldives

Central Asia: Kazakhstan, Kyrgyzstan, Tajikistan, Turkmenistan, Uzbekistan

West Asia: Afghanistan, Bahrain, Iraq, Iran, Syria, Jordan, Lebanon, Israel, Palestine, Saudi Arabia, Qatar, Kuwait, The United Arab Emirates (UAE), Oman, Yemen, Georgia, Armenia, Azerbaijan, Turkey, Cyprus

## Europe

North Europe: Finland, Sweden, Norway, Iceland, Denmark, the Faroe Islands (Denmark)

East Europe: Estonia, Latvia, Lithuania, White Russia, Russia, Ukraine, Moldova

Central Europe: Poland, Czech, Slovakia, Hungary, Germany, Austria, Switzerland, Liechtenstein

West Europe: Britain, Ireland, Holland, Belgium, Luxembourg, France, Monaco

South Europe: Romania, Bulgaria, Serbia, Macedonia, Albania, Greece, Slovenia, Croatia, Italy, Vatican, San Marino, Malta, Spain, Portugal, Andorra

Africa

East Africa: Ethiopia, Eritrea, Somalia, Djibouti, Kenya, Tanzania, Uganda, Rwanda, Burundi, Seychelles

Central Africa: Chad, Central Africa, Cameroon, Equatorial Guinea, Gabon, The Republic of Congo, The Democratic Republic of the Congo, Sao Tome and Principe

West Africa: Mauritania, Western Sahara (not independent), Senegal, Gambia, Mali, Burkina Faso, Guinea, Guinea-Bissau, Cape Verde, Sierra Leone, Liberia, Ivory Coast, Ghana, Togo, Benin, Niger, Ganary Islands (Spain)

South Africa: Zambia, Angola, Zimbabwe, Malawi, Mozambique, Botswana, Namibia, South Africa, Swaziland, Lesotho, Madagascar, Comorin, Mauritius, Reunion (France), Saint Helena (British)

Oceania: Australia, Papua New Guinea, Solomon Islands, Vanuatu, Micronesia, Marshall Islands, Palau, Nauru, Kiribati, Tuvalu, Samoa, Fiji, Tonga, The Cook Islands (New Zealand), Guam (U.S.A.), New Caledonia (France), Polynesia, The Cook Islands (New Zealand), Wallis and Futuna (France), Niue (New Zealand), Tokelau (New Zealand), American Samoa, Mariana (U.S.A).