

Job Spooler

User's Reference Guide

END USER LICENSE AGREEMENT

NOTICE TO USER: This End User License Agreement (“Agreement”) is a legal contract between you, the end user, and Kyoceramita Corporation (“Kyoceramita”). By using the products described in this user manual, by opening shrink-wrap package containing Software or downloading Software to your computer you agree to be bound by the terms of this License. This Agreement applies to the enclosed software (“Software”) and related explanatory written materials (“Documentation”).

1. License Grant

Kyoceramita grants to you a non-exclusive license to use the Software. The term Use shall include storing, loading, installing, executing or displaying the Software with one computer.

2. Ownership and Copyright

The copyright and the intellectual property rights in regard to the Licensed Articles is owned by Kyoceramita and/or its licensors/suppliers. You acknowledge and agree that the Licensed Articles, and its structure, organization and code are proprietary and valuable trade secrets of Kyoceramita and/or licensors/suppliers. You further acknowledge and agree that all right, title and interest in and to the Licensed Articles, including associated intellectual property rights, are and shall remain, with Kyoceramita and/or licensors/suppliers. This License Agreement does not convey to you an interest in or to the Licensed Articles, but only a limited right of use revocable in accordance with the terms of this License Agreement.

3. Restrictions

You may not adapt, modify, de-compile, disassemble, and reverse engineer or otherwise attempt to derive the source code for the Software. You may not rent, lease, sublicense, modify, adapt, pledge, lend, share or transfer versions or copies of the Software. You may not create derivative works based upon the Software or any part thereof.

4. Copies

You may not make copies of the Licensed Articles unless Kyoceramita’s prior written consent is obtained provided that you may make one copy of the Software solely for backup purposes.

5. Transfer

You may not transfer the Software, any copies or related Documentation or the License granted under this Agreement to a third-party transferee without Kyoceramita’s prior written consent.

6. Limited Warranty

Kyoceramita warrants, for your benefit alone, for a period of 90 days from the date of commencement of this License Agreement (referred to as the “Warranty

Period”) that the Software shall operate substantially in accordance with the functional specifications in the Documentation. Kyoceramita specifically does not warrant that the Software will operate uninterrupted or error-free. If during the Warranty Period, a defect in the Software appears, you may contact the Kyoceramita for either a replacement or, if so elected by Kyoceramita, refund of amounts paid by you under this License Agreement. In no event will Kyoceramita be held liable for any damages, including loss of data, lost profits, or any other incidental, consequential, or indirect damages arising from the use of, or failure or inability to use this Software on any theory of liability. This limitation applies even if Kyoceramita have been advised of the possibility of such damages.

7. Export Requirements

You may not export, re-export the Software, any copy or adaptation without Kyoceramita’s prior written consent or in violation of any applicable Law or Regulation of the country in which you are located and in which the Software is installed.

8. Termination

Kyoceramita may terminate your license by written notice to you for failure to comply with any term of this Agreement. This License Agreement will also terminate upon your sale, transfer or disposal of the equipment having the Software embedded therein. Upon termination, you shall immediately destroy the Software and any copies thereof, delete the Software from the hard drive of any product or computer in which it was installed, together with all Documentation.

9. No Waiver

The failure of any party to enforce any rights granted hereunder or to take action against the other party in the event of any breach hereunder shall not be deemed a waiver by that party as to subsequent enforcement of rights or subsequent actions in the event of future breaches.

10. Notice to U.S. Government End Users

U.S. GOVERNMENT RESTRICTED RIGHTS: The Licensed Articles are provided with restricted rights. Use, duplication, or disclosure by the government is subject to restrictions set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7013, and paragraph (c)(1) and (2) of the Commercial Computer Software - Restricted Rights clause at FAR 52.277-19. The Software is a “commercial item,” as that term is defined at 48 C.F.R. 2.101, consisting of “commercial computer software” and “commercial computer software documentation,” as such terms are used in 48 C.F.R. 12.212. Consistent with 48 C.F.R. 12.212 and C.F.R. 227.7202-1 through 227.7202-4, all U.S. Government End Users acquire the Software with only those rights set forth herein. The manufacturer is: Kyoceramita Corporation, No. 26-2 Nishi-Shinjuku 1-chome, Shinjuku-ku, Tokyo 163-0512, Japan.

NOTICE:

Kyoceramita Corporation has made every effort to ensure that the information in this manual is complete and accurate; however, constant efforts are also being made to improve and update this product. Therefore, Kyoceramita Corporation shall not be liable for errors in this manual or for any consequential damages resulting from the use of this manual. The information contained herein is subject to change without notice.

FEDERAL OR STATE LAWS MAY PROHIBIT THE COPYING OF CERTAIN DOCUMENTS OR INFORMATION, RESULTING IN FINES OR IMPRISONMENT FOR VIOLATORS.

WEB SITE ADDRESS:

To obtain additional product information, visit our Web site at:

<http://www.Kyoceramita.com/home/index.cfm>

Contents

1 Section 1: Introduction

To the User	2
About Web Utilities and Job Spooler	2
Documentation	2
Conventions Used in This Manual	3
Key Features	4
Where To Go from Here: Job Spooler User's Reference Guide	5
Where To Go from Here: Web Utilities User's Reference Guide	5

2 Section 2: Using Job Spooler

The General User and The System Administrator	8
Accessing the Job Spooler Page	9
Model	9
Network Card Serial Number	9
Job Spooler Setup	10
<i>User Mode</i>	<i>10</i>
<i>User ID</i>	<i>10</i>
<i>Password</i>	<i>10</i>
<i>Changing the User Mode</i>	<i>11</i>
<i>Setting a User ID</i>	<i>13</i>
Job Spooler's Active Button	14
<i>Monitoring Active Jobs</i>	<i>14</i>
<i>Using the Non-Operation Mode Sub-Menus</i>	<i>16</i>
<i>Scrolling the Active Jobs Display</i>	<i>16</i>
<i>Expanding and Compacting the Active Print View Fields</i>	<i>17</i>
<i>Canceling a Job</i>	<i>19</i>
Job Spooler's Hold Button	21
<i>Accessing Hold Jobs</i>	<i>21</i>
<i>Hold Page Print View Menu Fields</i>	<i>23</i>
<i>Canceling Hold Jobs</i>	<i>23</i>
<i>Reprinting Hold Jobs</i>	<i>24</i>
Job Spooler's Done Button	26
<i>Done Page Print View Menu Fields</i>	<i>26</i>

A Appendix A: Index 29

Section

1

Introduction

- **To the User**
- **About Job Spooler**
- **Key Features**

To the User

Welcome to Kyoceramita Job Spooler. This section includes an overview of the User's Reference Guide and a description of Job Spooler. In order to familiarize yourself with this product, please read this section *before* attempting to use Job Spooler.

About Web Utilities and Job Spooler

Job Spooler is an accessory function of Web Utilities. If you have this additional function, the button for Job Spooler will be active in Web Utilities.

The Kyoceramita Web Utilities allows you to monitor and administrate the printing activities of your Kyoceramita printers via the web. You do this by accessing the print controller's IP address. With Web Utilities, you may:

- Monitor the status of the printer's IP Controller, Engine and NIC Card
- Customize the printer's IP Controller, Engine and NIC Card settings
- Manage the maintenance schedule of the printer's engine

The Kyoceramita Job Spooler allows the user to monitor print, copy, scan and fax jobs. The **Active** page lists all jobs currently printing or in queue to be printed. The **Hold** page lists jobs that are archived on the controller's hard drive. The **Done** page shows all jobs that have been printed or cancelled. The **Setup** page allows the System Administrator to enable a level of security that then requires that a User ID be entered to allow certain Job Spooler functions.

Documentation

If you get Job Spooler, you will also have Web Utilities. The reverse, however, is not true since Web Utilities can be purchased without the addition of Job Spooler. For this reason, two User's Reference Guides are required for those who have Web Spooler.

The primary User's Reference Guide is for Web Utilities. That guide provides a comprehensive overview of Web Utilities. In-depth specifics about the functionality of the Main Page, the Printer Status Page, the Scanner Setup Page, the Network Setup Page, the Printer Setup Page, the About Page and the Help Page are provided in the Web Utilities User's Reference Guide. That User's Reference Guide also contains System Requirements, a Troubleshooting Appendix, a Glossary of Terms and an Index. For this reason we recommend that you read and familiarize yourself with the Web Utilities User's Reference Guide *before* you read the Job Spooler User's Reference Guide.

The Job Spooler User's Reference Guide provides specific instructions for using and administrating the Job Spooler Page. An Index for the Job Spooler User's Reference Guide is also provided.

Conventions Used in This Manual

The following terminology is used throughout this manual:

1. Print controller or IP controller is a Print Controller
2. A Printer, an IP-Engine or an Engine is a Copier
3. A Network Interface Card is a NIC Card
4. A printing system that combines the products listed in items 1, 2 and 3 above is a Kyocera Document System
5. Windows 98 is Microsoft Windows 98
Windows Me is Microsoft Windows Me
Windows NT4.0 or Windows NT is Microsoft Windows NT4.0
Windows 2000 is Microsoft Windows 2000
Windows XP is Microsoft Windows XP
6. When referencing multiple Microsoft OSs, they will appear as follows:
Windows 95/98/Me
Windows N.T4.0/2000/XP
Windows NT/2000/XP
Windows 95/98/Me/NT/2000/XP

Key Features

Kyoceramita's Job Spooler increases Web Utilities wide range of monitoring abilities by adding the following features:

1. View the Job List

From the Job Spooler's page, the user can see a list of all jobs and can note any condition that would require the user's attention.

2. View a List of All Jobs in the Printer including:

- Active Jobs (both the IP Controller's Spooled Jobs and the Copier's Spooled Jobs)
- Jobs on Hold
- Jobs that are Completed, Cancelled or have Errors

3. View Specific Information about Printer Jobs including:

- Print Order
- User Name
- Type of Job/Mode
- File Name
- Job Status
- Received Time
- Minute(s) to Go

Where To Go from Here: Job Spooler User's Reference Guide

Section Two: Using Job Spooler

Section Two explains how a System Administrator may set up Job Spooler. It also explains how a General User may use Job Spooler to access basic information about jobs and how a user may Hold, Cancel or Reprint from Job Spooler.

Appendix A: Index

This Appendix provides an index of all topics used in the Job Spooler User's Reference Guide.

Where To Go from Here: Web Utilities User's Reference Guide

Should you have specific questions about Web Utilities, please locate the Web Utilities User's Reference Guide. Once you have that document, you will find information organized as specified below:

Section One: Introduction

Section Two: Accessing Web Utilities

Section Two provides instructions for accessing a device using Web Utilities.

Section Three: Using Web Utilities

Section Three explains how a General User may use Web Utilities to access basic functional information about the selected printer. It also provides information about accessing Kyoceramita's web site and the Web Utilities Help system.

Section Four: Administrating Web Utilities

Section Four provides configuration and setting instructions for the system administrator. All these functions are password-protected.

Appendix A: Glossary

This Appendix provides a glossary of all terms used in the Web Utilities User's Reference Guide.

Appendix B: Index

This Appendix provides an index of all topics used in the Web Utilities User's Reference Guide.

Using Job Spooler

Section

2

- **Setup Page**
- **Active Page**
- **Hold Page**
- **Done Page**

The General User and The System Administrator


The Web Utilities User's Reference Guide organizes information based upon the needs of the user. There are two types of users: The General User and the System Administrator. Since these types of users are also referenced in the Job Spooler User's Reference Guide, a brief description of each follows.

A **General User** is someone interested in easily locating information about a printer including specifics like the system name, the system location and the printer's status. The General User might also use Web Utilities to access Kyoceramita's home page and further research Kyoceramita Corporation, its products and the technical support offered. The Web Utilities Help file might also be useful to the General User.

The **System Administrator** would use Web Utilities to facilitate device management. Password-protected functions such as configuring the Scanner Setup, changing the network settings and changing the printer settings may all be completed using Kyoceramita's Web Utilities.

The **Job Spooler Page** is primarily useful to the General User. However, the functions available to the General User can be restricted by the System Administrator.

This section provides Setup instructions for the System Administrator. It also provides complete instructions for all the available functions of Job Spooler.

 **Note:** Section Three of the Web Utilities User's Reference Guide provides an in-depth discussion of the **Main Page**, the screen that appears when Web Utilities opens. Kyoceramita recommends that you familiarize yourself with that information before proceeding.

Job Spooler Setup

Before providing instructions for Job Spooler Setup, the following concepts need to be understood.

User Mode

Two types of User Modes are available:

- **All User:** If Job Spooler is set to this mode, all users will be able to see and to affect all jobs sent to Job Spooler.
- **Per User:** If Job Spooler is set to this mode, a user must enter their User ID to gain access to the Hold page. After entering their ID, only their Hold jobs are visible (and accessible) on the Hold page.

In the Per User mode, a User ID may or may not be required to cancel jobs on the Active page. Please see *Job Spooler's Active Page* for specifics about this feature.

User ID

If Job Spooler is set in the **Per User** mode, a User ID is required to access the Hold page. A User ID is implemented using this procedure:

- **Create the User ID:** Each user must first create their own User ID. This is done through the Print Driver.
- **Utilize the User ID:** Once the User ID has been created, it can be used to access the user's jobs on the Hold page. No other user's Hold jobs are accessible.

Password

The Web Utilities System Password can be used by a System Administrator to affect all jobs regardless of the mode Job Spooler is running. The default system password is **sysadm**. Instructions for changing the password may be found in Section Four of the Web Utilities User's Reference Guide.

Changing the User Mode



Note: The default User Mode for Job Spooler is **Per User**.

The User Mode may be set to **Per User** or **All User**. To set the User Mode to either of these options, follow this procedure:

1. Open the **Job Spooler** page.
2. There are four buttons just below the Network Card Serial Number. These are called the **Main Menu** buttons. Click the **Setup** button, the last button on the right side. The **Setup** page opens (Figure 3.2).
3. Two **Setup Sub-buttons** have been added to the menu. Click the **Set User Mode** button. The **User Mode** screen opens (Figure 3.3).
4. The **Current User Mode** is displayed. Should you wish to change this mode, enter the system password.



Note: The default system password is **sysadm**. Instructions for changing the password may be found in Section Four of the Web Utilities User's Reference Guide.

5. Click **Accept**. If the Mode has been changed, a new screen will open, informing you that the change was accepted (Figure 3.4).
6. Click the **Job Spooler** function button to return to Job Spooler.




Figure 3.2 - Job Spooler Setup Page




Figure 3.3 - Job Spooler Setup Page: User Mode Screen




Figure 3.4 - Job Spooler Setup Page: User Mode Accepted Screen

Setting a User ID

If Job Spooler is set to the **Per User** mode, a user ID is required to access the Hold page. After entering an active User ID, a person can access all documents that person has held in Job Spooler.

Setting a User ID must be done through the Print Driver. Please refer to the print driver manual for instructions.

User Name

This is the name of the person who originated the job.

Type

This field indicates the source from which the job originated. The options are: Fax Receive, Fax Send, Scan, Print and Copy.

The following four options are available only when the Tandem Mode is enabled. A brief description of each follows:

Print (M): When displayed, this indicates that the job is printing on the Master Engine.

Print (S): When displayed, this indicates that the job is printing on the Sub-Engine.

Copy (M): When displayed, this indicates that the job is copying on the Master Engine.

Copy (S): When displayed, this indicates that the job is copying on the Sub-Engine.

File Name

This is the user-assigned name of the document that will be printed.

Status

This field indicates the status of the job. The message options are as follows:

- Receiving
- Waiting for RIP
- Ripping Data
- IP Holding
- Data in Engine
- Data in IP
- Data Uploaded to PC
- Copying
- Printing
- Scanning
- Sending Fax
- Receiving Fax
- Engine Hold
- Error

- Download to Engine
- Data Upload to IP
- Canceling
- Done

Received Time

This is the time the IP or the Engine printer received the job that will be printed. For a Copy or Scan job, this field indicates the time the Engine received the job. For a Print job, this field indicates the time the IP received the job.

Minute(s) to Go

Once the job is in the engine, a time increment appears in this field. This indicates the amount of time remaining before the specific job is completed.

Using the Non-Operation Mode Sub-Menus

The **Active Print View Menu** can display a maximum of 15 jobs. In addition, there are two modes of display for viewing the job fields: **Expand** or **Compact**. You control these features by using the **Non-Operation Mode Sub-Menus** (Figure 3.5).

Scrolling the Active Jobs Display

The **Non-Operation Mode Sub-Menus** consist of three buttons: **Prev 15**, **Next 15** and **Expand/Compact** (Figure 3.5). Between these buttons, text is displayed. This text identifies the rows that are currently displayed in the **Active Print View Menu**. The total number of jobs in the **Active Print View Menu** is also provided.

Should you wish to view the Next 15 jobs or the Previous 15 jobs, follow this procedure:

1. Open the **Job Spooler** page.
2. Click the **Active** button. The **Active Jobs** page opens (Figure 3.5).
3. Below the **Main Menu** buttons are the **Non-Operation Mode Sub-Menus**. Click the **Next 15** button to access information about the next 15 jobs. After you have clicked this, the text display between the **Non-Operation Mode Sub-Menus** will change to reflect that rows that are now on display in the **Active Print View Menu**.
4. Should you wish to return to the earlier view, click the **Prev 15** button.

Expanding and Compacting the Active Print View Fields

The viewable area of the **Active Print View Menu** display is, by default, compacted to a smaller size. As a result, longer entries in fields like the **User Name** or **File Name** may be cut off. To increase the viewable area of these fields, follow this procedure:

1. Open the **Job Spooler** page.
2. Click the **Active** button. The **Active Jobs** page opens (Figure 3.7).
3. Below the **Main Menu** buttons are the **Non-Operation Mode Sub-Menus**. Click the **Expand** button. The viewable display area will increase and the button will now read **Compact** (Figure 3.6).
4. Should you wish to reduce the display field, click the **Compact** button and the fields will return to the original, smaller size and the button will again read **Expand** (Figure 3.7).

Canceling a Job

Two types of jobs may be cancelled from the Active Print View Menu: Print and Print (M). The other types of jobs—Print (S), Copy, Copy (M), Copy (S) and Scan—cannot be cancelled.

Should you wish to cancel a job, follow this procedure:

1. Open the **Job Spooler** page.
2. Click the **Active** button. The **Active Jobs** page opens (Figure 3.7).
3. Locate the job you wish to cancel in the **Active Print View Menu** then click on that job. The job will be highlighted and the **Operation Mode Sub-Menus** will appear (Figure 3.8).



Note: *The User ID field will only be displayed if Job Spooler has been set for the **Per User** mode. The User ID associated with the selected job must be entered in the specified field before the job can be cancelled.*

4. If Job Spooler is set for the **Per User** mode, enter the **User ID** (or the System Password). If Job Spooler is set for the **All User** mode, this step is not required.

Note: *Once you enter the User ID, that information is saved. Should you wish to alter additional jobs created by the same user, you will not need to re-enter the User ID unless you close the Browser. Closing the Browser is the saved User ID from Job Spooler.*



5. Click **Cancel Job**. The button will highlight and one of the following status messages will appear to the right of the User ID field (Figure 3.9):

Please wait, canceling . . .

Invalid User ID! : The User ID entered is incorrect for the selected job. Make sure you have the correct ID.

Cannot cancel job!

When the job is successfully canceled, the Operation Sub-Menus will be replaced by the Non-Operation Mode Sub-Menus.

Web Utilities Version 3.0
Information access and control of your printer

Model: **Printing System(2)**
Network Card Serial Number: **EB7301**

Active Hold Done Setup

Cancel Job User ID:

Operation Mode Sub-Menus

Row	User Name	Type	File Name	Status	Received Time	Minute(s) to go
1	Administrator	Print	Microsoft Word - Test.doc	Printing	11/06/00 10:26:31 PM	1

Figure 3.8 - Operation Mode Sub-Menus: Per User Mode

Web Utilities Version 3.0
Information access and control of your printer

Model: **Printing System(2)**
Network Card Serial Number: **EB7301**

Active Hold Done Setup

Cancel Job Please wait, canceling... Expand

Row	User Name	Type	File Name	Status	Received Time	Minute(s) to go
1	Administrator	Print	Microsoft Word - Test.doc	Printing	11/06/00 10:26:31 PM	1

Figure 3.9 - Job Status Screen

Job Spooler's Hold Button

Job Spooler allows the user to archive print documents to the controller's hard drive. When a document is held in Job Spooler, it is available for printing and reprinting based on the user's needs. A held job stays in Job Spooler until the originating user or the system administrator actively cancels the job.

Before you can use this page, you must enable this function. Please refer to the print driver manual for instructions.

Accessing Hold Jobs

To access jobs held in Job Spooler, follow this procedure:

1. Open the **Job Spooler** page.
2. Click the **Hold** button. If Job Spooler is in **Per User** mode, the User ID screen opens (Figure 3.10).
3. Enter your User ID or the System Administration password.

Note: See Setting a User ID earlier in this section for information about this procedure.



Note: The default system password is **sysadm**. Instructions for changing the password may be found in Section Four of the Web Utilities User's Reference Guide.

4. Click **Accept**. The **Hold** page opens (Figure 3.11).

Hold Page Print View Menu Fields

The **Active Print View Menu** provides the following information about each Held Job:

Row #

This number indicates the position of the job in the queue. Job ID 1 is the first job that will be printed.

User Name

This is the name of the person who originated the job.

Type

This field indicates the source from which the job originated.

File Name

This is the user-assigned name of the document that is held.

Received Time

This is the time the IP or the Engine printer received the job. For a Copy or Scan job, this field indicates the time the Engine received the job. For a Print job, this field indicates the time the IP received the job.

Canceling Hold Jobs

From the **Hold** page you may reprint a job or cancel a job.

Should you reprint an item on the **Hold** page, the job will be sent to the **Active** page until it has printed. Once printed, the job will then appear on the **Done** page. The job will still remain on the **Hold** page, however, unless you or your system administrator cancel it.

You cancel jobs on the **Hold** page by following the same procedure used to cancel jobs on the **Active** page. Turn to the section listed below for complete instructions:

- **Canceling a Job:** page 19

Reprinting Hold Jobs

From the **Hold** page you may reprint a job.

Should you reprint an item on the **Hold** page, the job will be sent to the **Active** page until it has printed. Once printed, the job will then appear on the **Done** page. The job will still remain on the **Hold** page, however, unless you or your system administrator cancel it.

To reprint a job, follow this procedure:

1. Open the **Job Spooler** page.
2. Click the **Hold** button. If Job Spooler is in **Per User** mode, the User ID screen opens (Figure 3.10).
3. Enter your User ID or the System Administration password.

Note: See Setting a User ID earlier in this section for information about this procedure.



Note: The default system password is **sysadm**. Instructions for changing the password may be found in Section Four of the Web Utilities User's Reference Guide.

4. Click **Accept**. The **Hold** page opens (Figure 3.11).
5. Locate the job you wish to reprint in the **Active Print View Menu** then click on that job. The job will be highlighted and the **Hold** page **Operation Mode Sub-Menus** will appear (Figure 3.12).
5. Click **Reprint**. The button will highlight and one of the following status messages will appear to the right of the User ID field (Figure 3.13):

Please wait, reprinting . . .

Invalid User ID!

When the job is successfully reprinted, the Operation Mode Sub-Menus will be replaced by the Non-Operation Mode Sub-Menus.

Job Spooler's Done Button

Job Spooler collects information about completed or canceled jobs. This information can be found on the **Done** page. To access the **Done** page, follow these instructions:

1. Open the **Job Spooler** page.
2. Click the **Done** button. The **Done** page opens (Figure 3.14).

Done Page Print View Menu Fields

The **Active Print View Menu** provides the following information about each Done Job:

Row

This number indicates the position of the job in the queue. Job ID 1 is the first job that will be printed.

User Name

This is the name of the person who originated the job.

Type

This field indicates the source from which the job originated. The options are: Fax Receive, Fax Send, Scan, Print and Copy.

The following four options are available only when the Tandem Mode is enabled. A brief description of each follows:

Web Utilities Version 3.0
Information access and control of your printer

Model: Printing System(2)
Network Card Serial Number: EB7301

Active Hold **Done** Setup

Prev 15 Next 15 Row:1 - 15, Total:47 Expand

Row	User Name	Type	File Name	End Time	Result
1	Administrator	Print	Microsoft Word - Test.doc	11/06/00 10:23:53PM	Completed
2	Administrator	Print	Microsoft Word - Test.doc	11/06/00 10:23:48PM	Completed
3	Administrator	Print	Microsoft Word - Test.doc	11/06/00 10:23:41PM	Completed
4	Administrator	Print	Microsoft Word - Test.doc	11/06/00 10:23:35PM	Completed
5	Administrator	Print	Microsoft Word - Test.doc	11/06/00 10:23:34PM	Completed
6	Administrator	Print	Microsoft Word - Test.doc	11/06/00 10:23:33PM	Completed
7	Administrator	Print	Microsoft Word - Test.doc	11/06/00 10:23:33PM	Completed
8	Administrator	Print	Microsoft Word - Test.doc	11/06/00 10:23:27PM	Completed
9	Administrator	Print	Microsoft Word - Test.doc	11/06/00 10:23:27PM	Completed
10	Administrator	Print	Microsoft Word - Test.doc	11/06/00 10:23:25PM	Completed
11	Administrator	Print	Microsoft Word - Test.doc	11/06/00 10:23:25PM	Completed
12	Administrator	Print	Microsoft Word - Test.doc	11/06/00 10:23:19PM	Completed
13	Administrator	Print	Microsoft Word - Test.doc	11/06/00 10:23:13PM	Completed
14	Administrator	Print	Microsoft Word - Test.doc	11/06/00 10:22:51PM	Completed
15	Administrator	Print	Microsoft Word - Test.doc	11/06/00 10:22:16PM	Completed

Figure 3.14 - Done Page

Print (M): When displayed, this indicates that the job is printing on the Master Engine.

Print (S): When displayed, this indicates that the job is printing on the Sub-Engine.

Copy (M): When displayed, this indicates that the job is copying on the Master Engine.

Copy (S): When displayed, this indicates that the job is copying on the Sub-Engine.

File Name

This is the user-assigned name of the document that was be printed.

End Time

The time the job was completed.

Results

There are three options for this field:

- **Completed:** The job has been printed/reprinted.
- **Cancelled:** The job has been cancelled and is no longer stored in Job Spooler.
- **Error:** Scan to Email/Scan to FTP has failed to upload the document to the PC.

Appendix

A

I n d e x

A

Active Jobs

monitoring 42

Active Jobs Display 44

scrolling the 44

Active Jobs Menu

compacted view

illustration 46

expanded view

illustration 46

Active Jobs Page

Canceling a Job 47

illustration 42

Non-Operation Mode Sub-Menus 42

Print View Menu fields 42

Type 43

Active Print View Fields 45

Active Print View Menu 42, 52

All User

defined 38

C

Canceling

Hold Jobs 51

Canceling a Job 47

status messages 47

Compacting

Active Print View Fields 45

D

Done Page

File Name 55

illustration 53, 54

Print View Menu Fields 54

E

Expanding

Active Print View Fields 45

F

File Name 55

G

General User

defined 36

H

Hold Jobs

accessing 49

canceling 51

releasing 51, 52

Hold Page

illustration 50

Hold Page Operation Sub-Menus

illustration 53

Hold Page Status Message

illustration 53

Hold User ID Page

illustration 50

I

Illustrations

Active Print Job Menu
 compacted view 46
 expanded view 46
Active Print Jobs Page 42
Done Page 53, 54
Hold Page 50
Hold Page Operation Sub-Menus 53
Hold Page Status Message 53
Hold User ID Page 50
Job Spooler Page 37
Job Spooler Setup Page 40
Job Status Screen 48
Operation Mode Sub-Menus 48
User Mode Accepted Screen 41
User Mode Screen 40

J

Job Spooler

documentation 58
key features 60
Setup Page 39

Job Spooler Page

accessing 37
illustration 37

Job Spooler Setup Page

illustration 40

Job Status Screen

illustration 48

M

Main Menu buttons 39

N

Non-Operation Mode Sub-Menus 42

using 44

O

Operation Mode Sub-Menus 47, 52

illustration 48

P

Password 38

default 39
Web Utilities 38

Per User

defined 38

Per User Mode

setting a User ID 41

Print Driver 41

Print View Menu Fields

Done Page 54

R

Reprint button 52

S

Scrolling

Active Job Display 44

Set User Mode button 39

Setup Button

function described 38

Setup Page 39

sub-buttons 39

Status Messages

for canceling 47

for reprinting 52

System Administrator

defined 36

T

Type 43

U

User ID

creating a 38

saving the 47

utilizing the 38

User Mode

changing the 39

default 39

User Mode Accepted Screen

illustration 41

User Mode Screen

illustration 40

Using

Non-Operation Mode Sub-Menus 44

W

Web Utilities

documentation 58

Main Page 36

relationship to Job Spooler 58