

High-bright Display Modules

Catalog Number 2711P-RDT12H

Topic	Page
Important User Information	2
Environment and Enclosure	3
Outdoor Installation	3
Hazardous Locations	4
Environnements dangereux	5
Wiring and Safety Guidelines	7
About the Terminals	8
Install the Terminal	8
Logic Module Compatibility	12
External Power Supply For Nonisolated DC Terminals	12
External Power for Isolated DC Terminals	13
Remove and Install the Power Terminal Block	14
DC Power Connections	15
Ethernet Cable	16
Troubleshooting	17
Specifications	21
Additional Resources	23

About the Module

This document provides instructions on how to install the PanelView™ Plus, PanelView Plus CE, and PanelView Plus 6 high-bright display module in a panel or enclosure.

Refer to the installation instructions shipped with the logic module and communication module for field installation of these components.

For complete information on installing, wiring, and troubleshooting the terminals, refer to the publications listed under [Additional Resources](#).

Important User Information

Read this document and the documents listed in the additional resources section about installation, configuration, and operation of this equipment before you install, configure, operate, or maintain this product. Users are required to familiarize themselves with installation and wiring instructions in addition to requirements of all applicable codes, laws, and standards.

Activities including installation, adjustments, putting into service, use, assembly, disassembly, and maintenance are required to be carried out by suitably trained personnel in accordance with applicable code of practice.

If this equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.

In no event will Rockwell Automation, Inc. be responsible or liable for indirect or consequential damages resulting from the use or application of this equipment.

The examples and diagrams in this manual are included solely for illustrative purposes. Because of the many variables and requirements associated with any particular installation, Rockwell Automation, Inc. cannot assume responsibility or liability for actual use based on the examples and diagrams.

No patent liability is assumed by Rockwell Automation, Inc. with respect to use of information, circuits, equipment, or software described in this manual.

Reproduction of the contents of this manual, in whole or in part, without written permission of Rockwell Automation, Inc., is prohibited.

Throughout this manual, when necessary, we use notes to make you aware of safety considerations.



WARNING: Identifies information about practices or circumstances that can cause an explosion in a hazardous environment, which may lead to personal injury or death, property damage, or economic loss.



ATTENTION: Identifies information about practices or circumstances that can lead to personal injury or death, property damage, or economic loss. Attentions help you identify a hazard, avoid a hazard, and recognize the consequence.

IMPORTANT Identifies information that is critical for successful application and understanding of the product.

Labels may also be on or inside the equipment to provide specific precautions.



SHOCK HAZARD: Labels may be on or inside the equipment, for example, a drive or motor, to alert people that dangerous voltage may be present.



BURN HAZARD: Labels may be on or inside the equipment, for example, a drive or motor, to alert people that surfaces may reach dangerous temperatures.



ARC FLASH HAZARD: Labels may be on or inside the equipment, for example, a motor control center, to alert people to potential Arc Flash. Arc Flash will cause severe injury or death. Wear proper Personal Protective Equipment (PPE). Follow ALL Regulatory requirements for safe work practices and for Personal Protective Equipment (PPE).

Environment and Enclosure

See the [Outdoor Installation](#) section for additional enclosure and certification information on the high-bright display modules.



ATTENTION: This equipment is intended for use in a Pollution Degree 2 industrial environment, in overvoltage Category II applications (as defined in IEC publication 60664-1), at altitudes up to 2000 m (6561 ft) without derating.

This equipment is considered Group 1, Class A industrial equipment according to IEC/CISPR Publication 11. Without appropriate precautions, there may be potential difficulties ensuring electromagnetic compatibility in other environments due to conducted as well as radiated disturbance.

This equipment is supplied as open-type equipment. It must be mounted within an enclosure that is suitably designed for those specific environmental conditions that will be present and appropriately designed to prevent personal injury resulting from accessibility to live parts. The interior of the enclosure must be accessible only by the use of a tool. The terminals meet specified NEMA Type and IEC ratings only when mounted in as panel or enclosure with the equivalent rating. Subsequent sections of this publication may contain additional information regarding specific enclosure type ratings that are required to comply with certain product safety certifications.

In addition to this publication, see:

- Industrial Automation Wiring and Grounding Guidelines, for additional installation requirements, Allen-Bradley publication [1770-4.1](#).
- NEMA Standards publication 250 and IEC publication 60529, as applicable, for explanations of the degrees of protection provided by different types of enclosure.

Outdoor Installation

When using the high-bright display module, catalog number 2711P-RDT12H, outdoors, considerations in maximizing the field life of the front bezel and display are the following:

- Selecting the proper enclosure
- Orientation of the terminal

Both ultraviolet and infrared radiation can reduce the field life of any electronic device. While the materials used in the terminal bezels provide long field life, that life can be improved by proper installation.

Ultraviolet (UV) radiation from the sun causes all plastics to fade or yellow and become brittle over time. Using an antiglare overlay, catalog number 2711P-RGT12, will protect the front of the terminal from direct exposure to UV radiation and greatly increase its field life.

When installing the high-bright display module in an environment where the front of the terminal will be in direct sunlight during the hottest part of the day and the external ambient temperature can exceed 40 °C (104 °F), use the visor kit, catalog number 2711P-RVT12. The visor reduces the solar load on the front of the display and helps to maintain internal temperatures within specification.

The high-bright display module has a built-in temperature sensor that automatically reduces the backlight intensity if the temperature inside the cabinet exceeds 55 °C (131 °F). This reduces the risk of damage to the display.

The paint color, size, and power dissipated by the internal components of an enclosure affect the temperature rise inside the cabinet. Hoffman, a Rockwell Automation Encompass Partner, has information to assist you with enclosure selection and heating/cooling accessories to meet the temperature requirements of the installed equipment. See website <http://www.hoffmanonline.com>.

Stirring fans or active cooling may be required in high altitude and high ambient temperature locations to keep the internal enclosure temperature below 55 °C (131 °F). Use a heater in installations where the ambient temperature is below 0 °C (32 °F).

The backlight of the high-bright display generates a significant amount of heat when set to full intensity. To minimize the amount of heat generated and extend the life of the backlight, decrease the display intensity by using the screen saver with a 5...10 minute delay.

Avoid placing the terminal on the south (north in the southern hemisphere) or west side of the cabinet, if possible. This will reduce the heat rise due to solar loading during the hottest part of the day.

Mount the terminal vertically to minimize solar loading on the display. Do not mount the terminal in a sloped enclosure if it will be exposed to direct sunlight.

Hazardous Locations

This equipment is suitable for these locations:

- Class I, Division 2 Groups A, B, C, D
- Class II, Division 2 Groups F, G
- Class III
- Ordinary, nonhazardous locations only

The following statement applies to use in hazardous locations.



WARNING: Explosion Hazard

- Substitution of components may impair suitability for hazardous locations.
 - Do not disconnect equipment unless power has been switched off and area is known to be nonhazardous.
 - Do not connect or disconnect components unless power has been switched off.
 - All wiring must comply with N.E.C. articles 501, 502, 503, and/or C.E.C. section 18-1J2 as appropriate.
 - Peripheral equipment must be suitable for the location in which it is used.
-

The PanelView Plus, PanelView Plus CE, or PanelView Plus 6 terminals have a temperature code of T4 when operating in a 55 °C (131 °F) maximum ambient temperature. Do not install the terminals in environments where atmospheric gases have ignition temperatures **less** than 135 °C (275 °F).

Environnements dangereux

Cet équipement ne peut être utilisé que dans les environnements suivants :

- Classe I, Division 2, Groupes A, B, C, D
- Classe II, Division 2, Groupes F, G
- Classe III
- ou environnements non-dangereux

La mise en garde suivante s'applique à une utilisation en environnement dangereux.



WARNING: DANGER D'EXPLOSION

- La substitution de composants peut rendre cet équipement impropre à une utilisation en environnement dangereux.
- Ne pas déconnecter l'équipement sans s'être assuré que l'alimentation est coupée ou que l'environnement est classé non dangereux.
- Ne pas connecter ou déconnecter des composants sans s'être assuré que l'alimentation est coupée.
- L'ensemble du câblage doit être conforme, selon le cas, aux articles 501-4(b), 502-4(b) et 503-3(b) du Code national de l'électricité des Etats-Unis.
- L'équipement périphérique doit être adapté à l'environnement dans lequel il est utilisé.

Le code de température de fonctionnement des terminaux PanelView Plus, PanelView Plus CE, ou PanelView Plus 6 est T4 pour une température ambiante maximale de 55 °C (131 °F). N'installez pas les terminaux dans des environnements contenant des gaz atmosphériques inflammables à moins de 135 °C (275 °F).

USB Ports

The terminals contain universal serial bus (USB) ports that comply with hazardous location environments. This section details the field-wiring compliance requirements and is provided in accordance with the National Electrical Code, article 500.

PanelView Plus 700 to 1500 Terminals Control Drawing

Associated Nonincendive Field Wiring Apparatus




Table 1 - PanelView Plus 700 to 1500 USB Port Circuit Parameters

V _{oc}	I _{sc}	C _a		L _a	
		Groups A and B	Groups C and D	Groups A and B	Groups C and D
5.25V DC	1.68 A	10 μF	10 μF	15 μH	15 μH

Selected nonincendive field wiring apparatus must have nonincendive circuit parameters conforming with Table 2.

Table 2 - Required Circuit Parameters for the USB Peripheral Device

V _{max}	≥	V _{oc}
I _{max}	≥	I _{sc}
C _i + C _{cable}	≤	C _a
L _i + L _{cable}	≤	L _a

Application Information

Per the National Electrical Code the circuit parameters of nonincendive field wiring apparatus for use in hazardous locations shall be coordinated with the associated nonincendive field wiring apparatus such that their combination remains nonincendive. The PanelView Plus 700 to 1500 and the USB peripheral device shall be treated in this manner.

The circuit parameters of the PanelView Plus 700 to 1500 USB port are given in Table 1. The USB peripheral device and its associated cabling shall have circuit parameters with the limits given in Table 2 for them to remain nonincendive when used with the PanelView Plus 700 to 1500 USB port. If cable capacitance and inductance are not known the following values from ANSI/ISA-RP 12.06.01-2003 may be used:

$$C_{cable} = 60 \text{ pF/ft}$$

$$L_{cable} = 0.20 \text{ μH/ft}$$

Nonincendive field wiring must be wired and separated in accordance with 501.10(B)(3) of the National Electrical Code (NEC) ANSI/NFPA 70 or other local codes as applicable.

This associated nonincendive field wiring apparatus has not been evaluated for use in combination with another associated nonincendive field wiring apparatus.

Symbol Definitions

V_{oc}	Open circuit voltage of the host USB port.
I_{sc}	Maximum output current of the host USB port.
V_{max}	Maximum applied voltage rating of the USB peripheral device. V_{max} shall be greater than or equal to V_{oc} in Table 1 ($V_{max} \geq V_{oc}$).
I_{max}	Maximum current to which the USB peripheral device can be subjected. I_{max} shall be greater than or equal to I_{sc} in Table 1 ($I_{max} \geq I_{sc}$).
C_i	Maximum internal capacitance of the USB peripheral device.
C_a	Maximum allowed capacitance of the USB peripheral device and its associated cable. The sum of C_i of the USB peripheral device and C_{cable} of the associated cable shall be less than or equal to C_a ($C_i + C_{cable} \leq C_a$).
L_i	Maximum internal inductance of the USB peripheral device.
L_a	Maximum allowed inductance of the USB peripheral device and its associated cable. The sum of L_i of the USB peripheral device and L_{cable} of the associated cable shall be less than or equal to L_a ($L_i + L_{cable} \leq L_a$).

Wiring and Safety Guidelines

Use publication NFPA 70E, Electrical Safety Requirements for Employee Workplaces, IEC 60364 Electrical Installations in Buildings, or other applicable wiring safety requirements for the country of installation when wiring the devices. In addition to the NFPA guidelines:


- connect the device and other similar electronic equipment to its own branch circuit.
- protect the input power by a fuse or circuit breaker rated at no more than 15 A.
- route incoming power to the device by a separate path from the communication lines.
- cross power and communication lines at right angles if they must cross.
- Communication lines can be installed in the same conduit as low level DC I/O lines (less than 10V).
- shield and ground cables appropriately to avoid electromagnetic interference (EMI).
- Grounding minimizes noise from EMI and is a safety measure in electrical installations.

For more information on grounding recommendations, refer to the National Electrical Code published by the National Fire Protection Association.

For more information, refer to Wiring and Grounding Guidelines for PanelView Plus Devices Technical Data, publication [2711P-TD001](#). You can locate this publication in the literature library at this website <http://www.rockwellautomation.com/literature/>.

About the Terminals

High-bright display modules are available only as separate components. Logic modules and communication modules must be ordered separately.



Attach the logic module and communication module to the display module before panel installation. See the instructions shipped with each module.

Parts List

These items are shipped with the terminals:

- Power terminal block
- Mounting clips
- FactoryTalk View software preloaded
- Installation instructions and panel cutout template

Required Tools

These tools are required for installation:

- Panel cutout tools
- Small, slotted screwdriver
- Torque wrench (1b•in)

Install the Terminal

Before installing the terminal in a panel, review these topics:

- Mounting clearances
- Panel cutout dimensions
- Product dimensions

Mounting Clearances

Allow adequate clearance around the terminal, inside the enclosure, for adequate ventilation. Consider heat produced by other devices in the enclosure. The ambient temperature around the terminals must be between 0...55 °C (32...131 °F).

These minimum clearances are required for ventilation:

- Top clearance: 51 mm (2 in.)
- Bottom clearance: 102 mm (4 in.)
- Side clearances: 25 mm (1 in.)
- Back clearance: 25 mm (1 in.)

Minimum side clearance for insertion of memory card is 102 mm (4 in.).

Panel Cutout Dimensions

Use the full size template shipped with your terminal to mark the cutout dimensions.

The 1250 Touch PanelView Plus, PanelView Plus CE, and PanelView Plus 6 Terminals are 257 mm (10.11 in.) high and 338 mm (13.29 in.) wide.

Mount the Terminal in a Panel

Four mounting clips secure the terminal to the panel.



ATTENTION: Disconnect all electrical power from the panel before making the panel cutout.

Make sure the area around the panel cutout is clear.


Take precautions so metal cuttings do not enter any components already installed in the panel.

Failure to follow these instructions may result in personal injury or damage to panel components.


Follow these steps to mount the terminal in a panel.

1. Cut an opening in the panel by using the panel cutout shipped with the terminal.

2. Make sure the terminal sealing gasket is properly positioned on the terminal.
This gasket forms a compression type seal. Do not use sealing compounds.




3. Place the terminal in the panel cutout.
4. Slide the ends of the mounting clips into the slots on the terminal.



5. Tighten the mounting clip screws by hand until the gasket seal contacts the mounting surface uniformly.



- Tighten the mounting clip screws to a torque of 0.90...1.1 N•m (8...10 lb•in) by using the specified torque sequence, making sure not to over-tighten.




ATTENTION: Tighten the mounting clips to the specified torque to provide a proper seal and prevent damage to the product. Rockwell Automation assumes no responsibility for water or chemical damage to the product or other equipment within the enclosure because of improper installation.

Product Dimensions


The illustration shows product dimensions for the PanelView Plus, PanelView Plus CE 1250, and PanelView Plus 6 touch screen terminals with the high-bright display module. Depth dimensions are shown for:

- base configured unit (display module and logic module).
- base configured unit with communication module.

Measurements are in mm (in).



a 74 (2.90) Display to Logic Module
 b 101 (3.99) Display to Communication Module



Logic Module Compatibility

The high-bright display module is only compatible with the following DC logic modules.

PanelView Plus, PanelView Plus CE, and PanelView Plus 6 Logic Modules

Cat. No.	Description
PanelView Plus 700 to 1500 Logic Modules	
2711P-RP2	Logic module with 128 MB flash/128 MB RAM, DC input
PanelView Plus CE 700 to 1500 Logic Modules	
2711P-RP6	PanelView Plus CE logic module with 128 MB flash/128 MB RAM, DC input
PanelView Plus 6 700 to 1500 Logic Modules	
2711P-RP8D	PanelView Plus 6 logic module with 1 GB flash/512 MB RAM, DC input
2711P-RP9D	PanelView Plus 6 logic module with 1 GB flash/512 MB RAM, DC input, extended features

The high-bright display module is not compatible with AC logic modules catalog number 2711P-RPxAx.

External Power Supply For Nonisolated DC Terminals

TIP

To identify nonisolated DC logic modules refer to the PanelView Plus Terminals User Manual, publication [2711P-UM001](#).


Use a single, 24V DC power supply, such as catalog number 2711P-RSACDIN, to power each PanelView Plus device. Using a separate, isolated and ungrounded source to power each terminal prevents ground loop currents from damaging the terminals.

The output on the power supply must be isolated from the input and not connected to earth/ground.



ATTENTION: Use a Class 2 or SELV supply as required by local wiring codes for your installation. The Class 2 and SELV power sources provide protection so that under normal and single-fault conditions, the voltage between the conductors, and between the conductors and functional earth or protective earth does not exceed a safe value.

Multiple AC Power Supplies to Power Multiple DC Terminals



External Power for Isolated DC Terminals

TIP Isolated DC logic modules are identified by catalog number 2711P-RPx Dx.

Use an SELV or PELV 24V DC power supply, such as catalog number 2711P-RSACDIN, to power the isolated DC PanelView Plus terminal.

The isolated DC terminals may be powered by the same power source as other equipment.




ATTENTION: Use an SELV or PELV supply as required by local wiring codes for your installation. The SELV and PELV power sources provide protection so that under normal and single fault conditions, the voltage between conductors and earth ground does not exceed a safe value.

Earth/Ground Connection

PanelView Plus devices with a DC power input have an earth/ground terminal that you must connect to a low-impedance earth/ground. The earth/ground connection is on the rear of the display module.

IMPORTANT The earth/ground connection to ground is mandatory. This connection is required for noise immunity, reliability, and Electromagnetic Compliance (EMC) with the European Union (EU) EMC directive for CE-mark conformance. This connection is required for safety by Underwriters Laboratory.

The earth/ground terminal requires a minimum wire gauge.

Attribute	Value
Symbol	 GND
Wire Type	Stranded or solid, Cu 90 °C (194 °F)
Wire Gauge	14...10 AWG
Terminal Screw Torque	1.13...1.36 N•m (10...12 lb•in)

On most PanelView Plus devices, the earth/ground terminal is internally connected to the DC-terminal within the product.



ATTENTION: Damage or malfunction can occur when a voltage potential exists between two separate ground points. Make sure the terminal does not serve as a conductive path between ground points at different potentials.

The PanelView Plus devices have isolated and nonisolated communication ports.

For more information refer to the PanelView Plus Terminals User Manual, publication [2711P-UM001](#).

Remove and Install the Power Terminal Block

The terminals ship with a power terminal block installed. You can remove and reinstall the terminal block for ease of installation, wiring, and maintenance.



WARNING: Explosion Hazard

- Substitution of components may impair suitability for hazardous locations.
 - Do not disconnect equipment unless power has been switched off and area is known to be nonhazardous.
 - Do not connect or disconnect components unless power has been switched off.
 - All wiring must comply with N.E.C. articles 501, 502, 503, and/or C.E.C. section 18-1J2 as appropriate.
 - Peripheral equipment must be suitable for the location in which it is used.
-




ATTENTION: Disconnect all power before installing or replacing components. Failure to disconnect power may result in electrical shock or damage to the terminal.

- Series A to D, DC logic modules use a three-position terminal block.
- Series E or later, DC logic modules use a two-position terminal block.

Follow these steps to remove the terminal block.

1. Loosen the two screws that secure the terminal block.

2. Gently pull the terminal block away from the connector.



Follow these steps to install the terminal block.

1. Reattach the terminal block to the connector until seated.
2. Tighten the two screws that secure the terminal block to the connector.

DC Power Connections

DC-powered PanelView Plus devices have an integrated 24V DC power supply. Both isolated and nonisolated power supplies have these ratings:

- 24V DC nominal (18...32V DC)
- 70 W maximum (2.9 A at 24V DC)

The power supply is internally protected against reverse polarity of the DC+ and DC- connections.

The input power terminal block supports these wire sizes.

Wire Specifications for DC Input Power Terminal Block

Attribute	Value
Wire Type	Stranded or solid, Cu 90 °C (194 °F)
Dual-wire Gauge ⁽¹⁾	22...16 AWG
Single-wire Gauge	22...14 AWG
Terminal Screw Torque	
Logic module, series A to D	0.23...0.34 N•m (2...3 lb•in)
Logic module, series E and later	0.56 N•m (5 lb•in)

(1) Two-wire max per terminal.

Connect DC Power



WARNING: Explosion Hazard


Do not disconnect equipment unless power has been switched off and the area is known to be nonhazardous.

Disconnect all power before installing or replacing components. Failure to disconnect power may result in electrical shock or damage to the terminal.

Follow these steps to connect the terminal DC power.

1. Verify that the terminal is not connected to a power source.
2. Secure the DC power wires to the terminal block.
Follow the markings on the terminal blocks and the terminal for proper connections.
3. Secure the earth/ground wire to the earth/ground terminal screw at the bottom of the display.

DC Power Supply Connections



Ethernet Cable

For PanelView Plus 700 to 1500 terminals, use Belden 7921A shielded Ethernet Category 5e cable according to TIA 568-B.1 and RJ45 connector according to IEC 60603-7 for compliance with the European Union 89/336/EEC EMC Directive.

The maximum cable length between the terminal's Ethernet port and a 10/100 Base-T port on an Ethernet hub (without repeaters or fiber) is 100 m (328 ft). For additional information, refer to the EtherNet/IP Media Planning and Installation Manual, publication [ENET-IN001](#).



WARNING: Do not connect or disconnect any communication cable with power applied to this device or any device on the network. An electrical arc could cause an explosion in hazardous location installations. Be sure that power is removed or the area is nonhazardous before proceeding.

Troubleshooting

If the terminal is not operating correctly, check the power, display settings, status indicators, and review the system start-up and error messages.


Check for Adequate Power

A terminal that does not receive adequate power could cause unpredictable behavior. Verify the power requirements in the [Specifications](#) table.

Check Status Indicators

The terminal has two status indicators to isolate operating problems.

- COMM indicator (green) for communication
- FAULT indicator (red) for hardware faults



When the terminal starts, the fault indicator should be off, except for a few brief flashes, and the comm indicator on. If the indicators remain off, the power supply or logic module has failed. Check the power cable. If the power is not within range, replace the power supply. If the power is within range, replace the logic module. After a successful startup, both indicators are off and controlled by the application running on the terminal.

The table shows indicator states if the terminal powers up and stops during startup.

Indicator States if the Terminal Stops During Startup

Fault (Red) Indicator	Comm (Green) Indicator	Description	Recommended Action
Blinking red indicator identifies a recoverable error.			
Blinking	Off	Last firmware download failed.	Reload firmware by using Firmware Upgrade Wizard (FUW) utility.
Blinking	Blinking	EBC boot loader firmware failed or is missing.	Reload firmware by using Firmware Upgrade Wizard (FUW) utility.
Blinking	On	Windows CE OS firmware failed or is missing.	Reload firmware by using Firmware Upgrade Wizard (FUW) utility.
Solid red indicator identifies a nonrecoverable or fatal error.			
On	Off	Fatal hardware error occurred.	Replace the logic module.
On	Blinking	Fatal hardware error in display.	Replace the display module.

Check the Display

If the terminal display is dim or unreadable:

- check the brightness setting of the display. From Configuration mode on the terminal, access Terminal Settings>Display Intensity.
- check the Screen Saver settings. The backlight may be turning off or dimming the display unexpectedly. From Configuration mode on the terminal, access Terminal Settings>Display>Screen Saver.
- check the display temperature. From the Configuration mode on the terminal, access Terminal Settings>Display>Display Temperature. The high-bright display module has a built-in temperature sensor that automatically reduces the backlight intensity if the temperature inside the cabinet exceeds 55 °C (131 °F).

Start-up Information Messages

Start-up information messages display in a specific sequence on the terminal during startup and typically display for a few seconds. These messages do not require that you perform any action.

Message #	Message	Description
37	Video Initialized	Configures and initializes the graphics video system.
30	Watchdog Test	Tests the watchdog circuitry to verify system integrity.
1	RAM Test	Tests the RAM memory.
31	Stuck Key	Checks the integrity of the function key hardware.
31.5	Stuck Touch	Checks the integrity of the touch screen hardware.

Message #	Message	Description
32	Battery Test	Checks the integrity of the battery hardware.
2.5	Registry Search	Locates and loads the most recent, valid registry. Multiple copies of the registry are maintained. If power is lost during a registry update, a valid registry is available the next time power is applied to the terminal.
2	Image Search	Checks for a new OS firmware upgrade on the external CompactFlash card and the serial port.
50	External CF	Transfers a new OS firmware upgrade from the external CompactFlash card to the terminal. Message may display for several minutes.
23	Internal CF	Programs the OS firmware just downloaded into the internal flash memory. Message may display for several minutes.
24	CRC Check	Checks the integrity of the OS firmware.
28	Starting System	Launches the operating system (OS).
29	System Check ###	Internal file system integrity check (### is percent progress indicator).
29.1	System Check	Internal file system integrity check disabled. Contact technical support.

Start-up Error Messages

When an error occurs, the terminal displays an error number with a text message. The word ERROR! appears under the message in different languages.

Displayed Message
ERROR! FEHLER! ERREUR! ERRORE!

Error #	Message	Description	Recommended Corrective Action
1	RAM Test	RAM test failure.	Reset the terminal. If error persists, reseat the SO-DIMM RAM module. If error still persists, replace the logic module.
23	Internal CF	Error programming the new OS firmware to internal CompactFlash card.	Reload the firmware. If error persists, replace the internal CompactFlash card. If error still persists, replace the logic module.
24	CRC Check	Checksum of the OS firmware failed.	Reload the firmware. If error persists, replace the internal CompactFlash card. If error still persists, replace the logic module.
30	Watchdog Test	Watchdog test failure.	Reload the firmware. If error persists, replace the logic module.
31	Stuck Key	Function key failure.	Check that nothing is pressed against a key. Reset the terminal without key presses. If error persists, replace the display module.
31.5	Stuck Touch	Touch screen failure.	Check that nothing is pressed against the touch screen. Reset the terminal without pressing the touch screen. If error persists, replace the display module.
32	Battery Test	Battery failure.	Replace the battery. If error persists, replace the logic module.

20 High-bright Display Modules

Error #	Message	Description	Recommended Corrective Action
33.5	NVRAM Access	Nonvolatile memory failure.	Upgrade the system firmware to revision 3.10.03 or later.
40	EXE Check	System OS firmware is missing or corrupt.	Reload the firmware. If error persists, replace the internal CompactFlash card. If error still persists, replace the logic module.
50	External CF	Error loading the OS firmware from the external CompactFlash card.	Reload the firmware. If error persists, replace the external CompactFlash card and attempt the firmware upgrade again.

Specifications

PanelView Plus, PanelView Plus CE, and PanelView Plus 6 Terminals with High-bright Display Module

Attribute	2711P-RDT12H
Display	
Display type	Color active matrix, thin film transistor (TFT) liquid crystal display (LCD)
Display size	12.1 in.
Display area (W x H)	246 x 184 mm (9.7 x 7.2 in.)
Display resolution	800 x 600
Luminance	1000 cd/m ² (Nits)
Backlight	Not replaceable
Touch screen	Analog resistive
Electrical	
Input voltage, DC	24V DC nom (18... 32V DC)
Power consumption, DC	70 W max (2.9 A @24V DC)
Mechanical	
Dimensions, (HxWxD) approx. for based configured unit without communication module	
1250 high-bright touch	282 x 363 x 74 mm (11.12 x 14.30 x 2.90 in.)
Weight for base configured unit without communication module	
1250 high-bright touch	3.2 kg (7.1 lb)
General	
Battery life	4 years min. at 25 °C (77 °F)
Clock	Battery-backed, ±2 minutes per month
Status indicators	COMM (green), Fault (red)
External CompactFlash storage	512 MB max

Environmental Specifications

Specification	2711P-RDT12H
Temperature, operating	0...55 °C (32...131 °F)
Temperature, nonoperating	-20...70 °C (-13...158 °F)
Vibration	10...57 Hz, 0.012 pk-pk displacement 57...500 Hz 2.0 g pk acceleration
Shock, operating	15 g at 11 ms
Shock, nonoperating	30 g at 11 ms
Relative humidity	5...95% without condensation
Enclosure ratings	NEMA Type 12, 13, 4X (indoor use only), IP54, IP65

Certifications

Certification ⁽¹⁾	2711P-RDT12H
c-UL-us	UL Listed Industrial Control Equipment, certified for use in US and Canada. See File E10314. UL Listed Industrial Control Equipment for use in: <ul style="list-style-type: none"> ● Class I, Div 2, Group A, B, C, D ● Class II, Div 2 Groups F, G ● Class III Hazardous Locations
CE (EMC)	European Union 89/336/EEC EMC Directive, compliant with: EN 61000-6-2; Industrial Immunity EN 61000-6-4; Industrial Emissions
CE (LVD)	EN 61131-2; Programmable Controllers
C-Tick	Australian Radiocommunications Act, compliant with: AS/NZS CISPR 11; Industrial Emissions

(1) See the Product Certification link on <http://www.ab.com> for declarations of conformity, certificates, and other certification details.

Additional Resources

These documents contain additional information concerning related products from Rockwell Automation.

Resource	Description
PanelView Plus Terminal User Manual, publication 2711P-UM001	Provides an overview of the PanelView Plus and PanelView Plus CE terminals and gives information on how to install, operate, configure, and troubleshoot these devices.
Wiring and Grounding Applications for PanelView Plus Devices Technical Data, publication 2711P-TD001	Provides additional information on wiring and grounding the PanelView Plus and PanelView Plus CE terminals.

You can view or download publications and translated versions of these installation instructions at <http://www.rockwellautomation.com/literature/>.

To order paper copies of technical documentation, contact your local Rockwell Automation distributor or sales representative.

Rockwell Automation Support

Rockwell Automation provides technical information on the Web to assist you in using its products.

At <http://www.rockwellautomation.com/support> you can find technical and application notes, sample code, and links to software service packs. You can also visit our Support Center at <https://rockwellautomation.custhelp.com/> for software updates, support chats and forums, technical information, FAQs, and to sign up for product notification updates.

In addition, we offer multiple support programs for installation, configuration, and troubleshooting. For more information, contact your local distributor or Rockwell Automation representative, or visit <http://www.rockwellautomation.com/services/online-phone>.

Installation Assistance

If you experience a problem within the first 24 hours of installation, please review the information that's contained in this manual. You can also contact a special Customer Support number for initial help in getting your product up and running.

United States or Canada	1.440.646.3434
Outside United States or Canada	Use the Worldwide Locator at http://www.rockwellautomation.com/rockwellautomation/support/overview_page , or contact your local Rockwell Automation representative.

New Product Satisfaction Return

Rockwell Automation tests all of its products to help ensure that they are fully operational when shipped from the manufacturing facility. However, if your product is not functioning and needs to be returned, follow these procedures.

United States	Contact your distributor. You must provide a Customer Support case number (call the phone number above to obtain one) to your distributor to complete the return process.
Outside United States	Please contact your local Rockwell Automation representative for the return procedure.

Documentation Feedback

Your comments will help us serve your documentation needs better. If you have any suggestions on how to improve this document, complete this form, publication [RA-DU002](#), available at <http://www.rockwellautomation.com/literature/>.

Rockwell Automation maintains current product environmental information on its website at

<http://www.rockwellautomation.com/rockwellautomation/about-us/sustainability-ethics/product-environmental-compliance.page>.

- Allen-Bradley, PanelView, Rockwell Automation, and Rockwell Software are trademarks of Rockwell Automation, Inc. Trademarks not belonging to Rockwell Automation are property of their respective companies.

Rockwell Otomasyon Ticaret A.Ş., Kar Plaza İş Merkezi E Blok Kat:6 34752 İçerenköy, İstanbul, Tel: +90 (216) 5698400

www.rockwellautomation.com

Power, Control and Information Solutions Headquarters

Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444
Europe/Middle East/Africa: Rockwell Automation NV, Pegasus Park, De Kleetlaan 12a, 1831 Diegem, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640
Asia Pacific: Rockwell Automation, Level 14, Core F, Cyberport 3, 100 Cyberport Road, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846

Publication 2711P-IN026F-EN-P - February 2015

Supersedes Publication 2711P-IN026E-EN-P - September 2008

PN-267001

Copyright © 2015 Rockwell Automation, Inc. All rights reserved. Printed in the U.S.A.