

# **Honeywell**

---

## **ST 3000 Smart Pressure Transmitter Quick Start Installation Guide**

**34-ST-25-24**

**Revision 9**

**July 2011**

---

## Notices and Trademarks

Copyright 2011 by Honeywell  
Revision 9 July 2011

SFC, Smartline, and ST 3000 are U.S. registered trademarks of Honeywell Inc.  
HART<sup>®</sup> is a trademark of the Hart Communication Foundation.  
FOUNDATION<sup>™</sup> is a trademark of the Fieldbus Foundation.

### WARRANTY/REMEDY

Honeywell warrants goods of its manufacture as being free of defective materials and faulty workmanship. Contact your local sales office for warranty information. If warranted goods are returned to Honeywell during the period of coverage, Honeywell will repair or replace without charge those items it finds defective. The foregoing is Buyer's sole remedy and is **in lieu of all other warranties, expressed or implied, including those of merchantability and fitness for a particular purpose.** Specifications may change without notice. The information we supply is believed to be accurate and reliable as of this printing. However, we assume no responsibility for its use.

While we provide application assistance personally, through our literature and the Honeywell web site, it is up to the customer to determine the suitability of the product in the application.

### About This Document

This document provides descriptions and procedures for the Quick Installation of your ST 3000 Transmitter.

Various other documents are available for reference that describes how to Install, Configure, and Operate the ST 3000 Transmitter. These can be ordered on CD or hardcopy, or may be downloaded from <http://honeywell.silverw.com>. (Registration is required at this site)

| Document Title   | Document #  |
|--|-------------|
| ST 3000 Smart Transmitter and SFC Smart Field Communicator Model STS103                        | 34-ST-25-14 |
| ST 3000 FF Transmitter with Foundation Fieldbus Option Installation and Device Reference Guide | 34-ST-25-15 |
| ST 3000 Smart Transmitter Release 300 with HART Communications Option User Manual              | 34-ST-25-17 |
| SMV 3000 Smart Multivariable Transmitter User's Manual   | 34-SM-25-02 |
| RMA Smart Meter User's Manual  | 34-ST-25-08 |
| Smart Field Communicator Model STS103 Operating Guide  | 34-ST-11-14 |
| Smartline Configuration Toolkit SCT 3000 Installation and Start-up Guide                       | 34-ST-10-08 |
| MC Toolkit User Manual   | 34-ST-25-20 |

---

## Contacts

### World Wide Web

The following lists Honeywell's World Wide Web sites that will be of interest to our customers.

| Honeywell Organization      | WWW Address (URL)  |
|-----------------------------|--|
| Corporate                   | <a href="http://www.honeywell.com/ps/hfs">http://www.honeywell.com/ps/hfs</a>  |
| Honeywell Process Solutions | <a href="http://hpsweb.honeywell.com/Cultures/en-US/">http://hpsweb.honeywell.com/Cultures/en-US/</a><br><a href="http://www.honeywell.com/ps">http://www.honeywell.com/ps</a> |
| International               | <a href="http://www.honeywell.com/business/global.asp">http://www.honeywell.com/business/global.asp</a>  |

### Telephone

Contact us by telephone at the numbers listed below.

|                          | Organization                | Phone Number                                   |
|--------------------------|-----------------------------|--|
| United States and Canada | Honeywell Inc.              | 1-800-343-0228 Sales<br>1-800-525-7439 Service |
| Asia Pacific             | Honeywell Asia Pacific Inc. | (852) 8298298 Hong Kong                        |
| Europe                   | Honeywell PACE              | [32-2] 728-2111 Brussels                       |
| Latin America            | Honeywell Inc               | (305) 364-2355 Sunrise, Florida USA            |








### Technical Assistance

|                    |  |
|--------------------|--|
| By Telephone       | Honeywell Solution Support Center Phone:<br>1-800-423-9883 (U.S. only)<br>Outside the U.S. call: 1-602-313-6510  |
| Additional Help    | You may also seek additional help by contacting the Honeywell distributor who supplied your ST 3000 transmitter.   |
| By E Mail          | You can also e-mail your technical questions or comments about this product to:<br>Honeywell Solution Support Center e-mail: <a href="mailto:ace@honeywell.com">ace@honeywell.com</a>  |
| Problem Resolution | If it is determined that a hardware problem exists, a replacement transmitter or part will be shipped with instructions for returning the defective unit. Please do not return your transmitter without authorization from Honeywell's Solution Support Center or until the replacement has been received. |

---

## Symbol Definitions

The following table lists those symbols used in this document to denote certain conditions.

| Symbol  | Definition  |
|---|---|
|    | This CAUTION symbol on the equipment refers the user to the Product Manual for additional information. This symbol appears next to required information in the manual.  |
|    | <b>WARNING</b><br><b>PERSONAL INJURY:</b> Risk of electrical shock. This symbol warns the user of a potential shock hazard where HAZARDOUS LIVE voltages greater than 30 Vrms, 42.4 Vpeak, or 60 VDC may be accessible. <b>Failure to comply with these instructions could result in death or serious injury.</b> |
|    | ATTENTION, Electrostatic Discharge (ESD) hazards. Observe precautions for handling electrostatic sensitive devices  |
|    | Protective Earth (PE) terminal. Provided for connection of the protective earth (green or green/yellow) supply system conductor.  |
|   | Functional earth terminal. Used for non-safety purposes such as noise immunity improvement. NOTE: This connection shall be bonded to protective earth at the source of supply in accordance with national local electrical code requirements.   |
|  | Earth Ground. Functional earth connection. NOTE: This connection shall be bonded to Protective earth at the source of supply in accordance with national and local electrical code requirements.  |
|  | Chassis Ground. Identifies a connection to the chassis or frame of the equipment shall be bonded to Protective Earth at the source of supply in accordance with national and local electrical code requirements.  |

---

---

# Contents

|          |   |           |
|----------|---|-----------|
| <b>1</b> | <b>MOUNTING THE TRANSMITTER.....</b>                            | <b>7</b>  |
| 1.1      | Typical Bracket mounted and Flange Mounted Installations .....  | 7         |
| 1.2      | Bracket Mounting .....  | 7         |
| 1.3      | Flange Mounting.....  | 10        |
| 1.4      | Flush Mounting.....   | 11        |
| 1.5      | High Temperature Transmitter Mounting.....                      | 11        |
| 1.6      | Remote Seal Mounting .....                                      | 12        |
| 1.7      | Conduit Entry Plugs and Adapters.....                           | 13        |
| <b>2</b> | <b>TRIM THE TRANSMITTER .....</b>                               | <b>15</b> |
| 2.1      | Procedure to Trim the Transmitter.....                          | 15        |
| <b>3</b> | <b>SET THE JUMPERS.....</b>                                     | <b>16</b> |
| 3.1      | Changing Default Failsafe Direction .....                       | 16        |
| 3.2      | Optional Write Protect Jumper .....                             | 17        |
| <b>4</b> | <b>CONNECT THE WIRING AND POWER UP.....</b>                     | <b>18</b> |
| 4.1      | Summary .....   | 18        |
| 4.2      | Wiring Connections .....  | 19        |
| 4.3      | Lightning Protection .....                                      | 19        |
| 4.4      | Additional Considerations for Wiring SMV 3000 Transmitter ..... | 20        |
| <b>5</b> | <b>CERTIFICATIONS.....</b>                                      | <b>21</b> |
| 5.1      | Product Certifications .....                                    | 21        |
| 5.1.1    | Approved Manufacturing Locations .....                          | 21        |
| 5.1.2    | European Directive Information .....                            | 21        |
| 5.2      | Hazardous Location Certifications.....                          | 22        |
| 5.2.1    | FM™ Approvals (USA).....  | 22        |
| 5.2.2    | Canadian Standards Association (CSA).....                       | 23        |
| 5.2.3    | IECEX International Electrotechnical Commission (LCIE).....     | 24        |
| 5.2.4    | SAEx (South Africa) .....                                       | 24        |
| 5.2.5    | INMETRO (CERTU SP Brazil).....                                  | 25        |
| 5.2.6    | ATEX Certification (LCIE) .....                                 | 26        |
| 5.2.7    | Pressure Equipment Directive (PED).....                         | 27        |
| 5.2.8    | Other Certifications.....                                       | 27        |



---

# 1 Mounting the Transmitter

## 1.1 Typical Bracket mounted and Flange Mounted Installations




Figure 1

## 1.2 Bracket Mounting

Optional mounting bracket, see Figure 2

Existing mounting bracket, see Figure 3

Rotate the transmitter housing, see Figure 4

Level a transmitter with small absolute or differential pressure spans, see Figure 5.

## Optional Mounting Bracket

Position bracket on 2-inch (50.8 mm) or, and install “U” bolt around pipe and through holes in bracket. Secure with nuts and lockwashers provided.

Figure 2 Example - Angle mounting bracket secured to horizontal or vertical pipe.




Figure 2

## Existing Mounting Bracket

Align appropriate mounting holes in transmitter with holes in bracket and secure with bolts and washers provided.

NOTE: If the meter body is hexagonal, you must use the additional bracket supplied. If meter body is round, discard the bracket

Figure 3 Example – LGP model transmitter mounted to optional angle mounting bracket.

| If Transmitter is....                                       | Then....  |
|---|---|
| DP type with double-ended process heads and/or remote seals | Use alternate mounting holes in end of heads                                  |
| GP and AP with single-ended head                            | Use mounting holes in side of meter body                                      |
| In-line GP and AP (LGP model)                               | Use smaller “U” bolt provided to attach meter body to bracket<br>See Figure 3 |
| Dual head GP  | Use mounting holes in end of process head                                     |

LGP and LAP models




Figure 3



## Rotating Transmitter Housing

Loosen set screw on outside neck of transmitter one full turn. Rotate Transmitter housing in maximum of 180 degree increment in left or right direction from center to position you require and tighten set screw (1.46 to 1.68 Nm/13 to 15 lb-in).

Figure 4 Example – Rotating Transmitter Housing.




Figure 4

## Leveling Transmitters with Small Absolute or Differential Pressure Spans


Mounting position of these transmitters is critical due to the smaller transmitter spans.

To minimize these positional effects on calibration (zero shift), take the appropriate mounting precautions that follow for the given transmitter model.

See Figure 5 and Figure 6 for suggestions on how to level the transmitter using a spirit balance.


To perform a **Zero Trim** after leveling, refer to Section 0.

Models STA122 and STA922



For a model STA122 or STA922 transmitter, you must ensure that the transmitter is vertical when mounting it. You do this by leveling the transmitter side-to-side and front-to-back.

Figure 5



Mount transmitter vertically to assure best accuracy. Position spirit balance on pressure connection surface of AP body.

**Figure 6**

### 1.3 Flange Mounting


To mount a flange mounted transmitter model, bolt the transmitter's flange to the flange pipe on the wall of the tank.

On insulated tanks, remove enough insulation to accommodate the flange extension.

It is the End User's responsibility to provide a flange gasket and mounting hardware that are suitable for the transmitter's service condition.

To prevent degradation of performance in Flush-Mounted Flanged Transmitters, exercise care to ensure that the internal diameter of the flange gasket does not obstruct the sensing diaphragm.

To prevent degradation of performance in Extended Mount Flanged Transmitters, ensure that there is sufficient clearance in front of the sensing diaphragm body.



**Figure 7**

## 1.4 Flush Mounting

To mount a flush mounted transmitter model, cut a hole for a 1-inch standard pipe in the tank or pipe where the transmitter is to be mounted.

See Figure 8

Weld the 1-inch mounting sleeve to the wall of the tank or to the hole cut on the pipe. Insert the meter body of the transmitter into the mounting sleeve and secure with the locking bolt. Tighten the bolt to a torque of  $6,4 \text{ Nm} \pm 0,30 \text{ Nm}$  [ $4.7 \text{ ft.-lbs.} \pm 0.2 \text{ ft.-lbs.}$ ]

Once the transmitter is mounted, the transmitter housing can be rotated to the desired position. See Figure 4

On insulated tanks, remove enough insulation to accommodate the mounting sleeve.




Figure 8

## 1.5 High Temperature Transmitter Mounting

You can mount the high temperature transmitter directly to the process flange connection or the process piping. See Figure 9

To mount a flange mounted transmitter model, bolt the transmitter's flange to the flange on the wall of the tank or process pipe.

It is the End User's responsibility to provide a flange gasket and mounting hardware that are suitable for the transmitter's service condition.

Once the transmitter is mounted, the transmitter housing can be rotated to the desired position. See Figure 4

On insulated tanks, remove enough insulation to accommodate the mounting sleeve.




Figure 9

## 1.6 Remote Seal Mounting

Mount the transmitter at a remote distance determined by length of capillary tubing.

NOTE: The combination of tank vacuum and high pressure capillary head effect should not exceed 9 psi (300 mm Hg) absolute.

On insulated tanks, remove enough insulation to accommodate the mounting sleeve.

Figure 10 Example – Typical Remote Seal Transmitter installation.

NOTE: For Sanitary 3-A installations, only mount the transmitter outside of the Non-Product Contact area where incidental contact with the process material is unlikely, use a minimum capillary length of 1.5m (5ft.)

| If Transmitter Model Number is.... | Then connect remote seal on....   |
|------------------------------------|---|
| STR93D or STR12D                   | high pressure (HP) side of transmitter to lower flange mounting on tank wall for <b>variable</b> head H1. |
| STR13D                             | low pressure (LP) side of transmitter to lower flange mounting on tank wall for <b>variable</b> head H1.  |

|                  |  |
|------------------|--|
| STR93D or STR12D | low pressure (LP) side of transmitter to upper flange mounting on tank wall for <b>fixed or constant</b> head H2.  |
| STR13D           | high pressure (HP) side of transmitter to upper flange mounting on tank wall for <b>fixed or constant</b> head H2. |

It is the End User's responsibility to provide a flange gasket and mounting hardware that are suitable for the transmitter's service condition




Figure 10

## 1.7 Conduit Entry Plugs and Adapters

| Honeywell Part No. | Description  | Material                                 | Environmental Rating | Ambient Limits                      | Hazardous Location Certification  |
|--------------------|--|--|----------------------|-------------------------------------|---|
| 30679588-501       | 1/2 NPT Conduit Entry Plug                               | Zinc Plated Carbon Steel                 | Type 4X, IP 66-68*   | -40°C to +93°C*<br>-40°F to +199°F* | None  |
| 30749366-501       | M20 Male to 1/2 NPT Female Certified Conduit Adapter     | 316 Stainless Steel<br>(Silicone O-Ring) | Type 4X, IP 66-68    | -50°C to +150°C<br>-58°F to +302°F  | CSA CI I, Div 1,<br>Gp ABCD<br>ATEX Ex II 2 GD;<br>Ex d IIC<br>IECEX Ex d IIC |
| 50000547-501       | M20 Certified Conduit Plug                               | 316 Stainless Steel<br>(Silicone O-Ring) | Type 4X, IP 66-68    | -50°C to +150°C<br>-58°F to +302°F  | CSA CI I, Div 1,<br>Gp ABCD<br>ATEX Ex II 2 GD;<br>Ex d IIC<br>IECEX Ex d IIC |
| 50000682-501       | 1/2 NPT Male to 3/4 NPT Female Certified Conduit Adapter | 316 Stainless Steel                      | Type 4X, IP 66-68    | -50°C to +150°C<br>-58°F to +302°F  | CSA CI I, Div 1,<br>Gp ABCD<br>ATEX Ex II 2 GD;<br>Ex d IIC<br>IECEX Ex d IIC |
| 50021832-502       | 1/2 NPT Certified Conduit Plug                           | Zinc Plated Carbon Steel                 | Type 4X, IP 66-68    | -50°C to +150°C<br>-58°F to +302°F  | CSA CI I, Div 1,<br>Gp ABCD<br>ATEX Ex II 2 GD;<br>Ex d IIC<br>IECEX Ex d IIC |
| 50021832-501       | 1/2 NPT Certified Conduit Plug                           | 316 Stainless Steel                      | Type 4X, IP 66-68    | -50°C to +150°C<br>-58°F to +302°F  | CSA CI I, Div 1,<br>Gp ABCD<br>ATEX Ex II 2 GD;<br>Ex d IIC<br>IECEX Ex d IIC |
| 51202409-501       | 1/2 NPT Male to M20 Female Certified Conduit Adapter     | 316 Stainless Steel                      | Type 4X, IP 66-68    | -50°C to +150°C<br>-58°F to +302°F  | CSA CI I, Div 1,<br>Gp ABCD<br>ATEX Ex II 2 GD;<br>Ex d IIC<br>IECEX Ex d IIC |

\* Honeywell Specified

### Procedures

It is the User/Installer's responsibility to install the ST 3000 Wireless Transmitters in accordance with national and local code requirements. Conduit entry plugs and adapters shall be suitable for the environment, shall be certified for the hazardous location when required and acceptable to the authority having jurisdiction for the plant.

Use the following procedures for installation.

Conduit Entry Plugs see Table 1 & Figure 11


Conduit Adapters see Table 2 & Figure 11

**Table 1 – Conduit entry plug installation**

| Step                   | Action  |             |          |        |  |                   |                 |       |          |                        |                 |       |          |
|------------------------|---|-------------|----------|--------|--|-------------------|-----------------|-------|----------|------------------------|-----------------|-------|----------|
| 1                      | Remove the protective plastic cap from the threaded conduit entry(s).   |             |          |        |  |                   |                 |       |          |                        |                 |       |          |
| 2                      | To ensure the environmental ingress protection rating on tapered (NPT), a non-hardening thread sealant may be used.   |             |          |        |  |                   |                 |       |          |                        |                 |       |          |
| 3                      | Thread the appropriate size conduit plug (M20 or 1/2" NPT) into the conduit entry opening. Do not install conduit entry plugs in conduit entry openings if adapters or reducers will be used.   |             |          |        |  |                   |                 |       |          |                        |                 |       |          |
| 4                      | Tighten plugs according to the following table. <table border="1" style="margin-left: 20px;"> <thead> <tr> <th>Description</th> <th>Tool</th> <th colspan="2">Torque</th> </tr> </thead> <tbody> <tr> <td>M20 Conduit Entry</td> <td>10mm Hex Wrench</td> <td>32 Nm</td> <td>24 Lb-ft</td> </tr> <tr> <td>1/2" NPT Conduit Entry</td> <td>10mm Hex Wrench</td> <td>32 Nm</td> <td>24 Lb-ft</td> </tr> </tbody> </table> | Description | Tool     | Torque |  | M20 Conduit Entry | 10mm Hex Wrench | 32 Nm | 24 Lb-ft | 1/2" NPT Conduit Entry | 10mm Hex Wrench | 32 Nm | 24 Lb-ft |
| Description            | Tool  | Torque      |          |        |  |                   |                 |       |          |                        |                 |       |          |
| M20 Conduit Entry      | 10mm Hex Wrench   | 32 Nm       | 24 Lb-ft |        |  |                   |                 |       |          |                        |                 |       |          |
| 1/2" NPT Conduit Entry | 10mm Hex Wrench   | 32 Nm       | 24 Lb-ft |        |  |                   |                 |       |          |                        |                 |       |          |

**Table 2 – Conduit adapter installation**

| Step                   | Action  |             |          |        |  |                        |                       |       |          |                        |               |       |          |
|------------------------|---|-------------|----------|--------|--|------------------------|-----------------------|-------|----------|------------------------|---------------|-------|----------|
| 1                      | Remove the protective plastic cap from the threaded conduit entry.  |             |          |        |  |                        |                       |       |          |                        |               |       |          |
| 2                      | To ensure the environmental ingress rating on tapered threads (NPT), a non-hardening thread sealant may be used.  |             |          |        |  |                        |                       |       |          |                        |               |       |          |
| 3                      | Thread the appropriate size adapter (M20 or 1/2 NPT) into the conduit entry opening   |             |          |        |  |                        |                       |       |          |                        |               |       |          |
| 4                      | Tighten adapters according to the following table. <table border="1" style="margin-left: 20px;"> <thead> <tr> <th>Description</th> <th>Tool</th> <th colspan="2">Torque</th> </tr> </thead> <tbody> <tr> <td>M20 to 1/2 NPT Adapter</td> <td>15/16" or 24mm Wrench</td> <td>32 Nm</td> <td>24 Lb-ft</td> </tr> <tr> <td>1/2 to 3/4 NPT Adapter</td> <td>1 1/4" Wrench</td> <td>32 Nm</td> <td>24 Lb-ft</td> </tr> </tbody> </table> | Description | Tool     | Torque |  | M20 to 1/2 NPT Adapter | 15/16" or 24mm Wrench | 32 Nm | 24 Lb-ft | 1/2 to 3/4 NPT Adapter | 1 1/4" Wrench | 32 Nm | 24 Lb-ft |
| Description            | Tool  | Torque      |          |        |  |                        |                       |       |          |                        |               |       |          |
| M20 to 1/2 NPT Adapter | 15/16" or 24mm Wrench   | 32 Nm       | 24 Lb-ft |        |  |                        |                       |       |          |                        |               |       |          |
| 1/2 to 3/4 NPT Adapter | 1 1/4" Wrench   | 32 Nm       | 24 Lb-ft |        |  |                        |                       |       |          |                        |               |       |          |



**Figure 11 Electronic Housing Conduit Entries**

**Note.** No plugs come installed in the ST 3000 housings. All housings come with temporary plastic dust protectors (red) installed and are not certified for use in any installation.

---

## 2 Trim the Transmitter

### 2.1 Procedure to Trim the Transmitter

For a transmitter with a small differential pressure span, you must ensure that the transmitter is vertical when mounting it. You do this by leveling the transmitter side-to-side and front-to-back. See Figure 5 for suggestions on how to level the transmitter using a spirit balance. You must also zero the transmitter by following the steps in this table.

| Step | Action  |
|------|---|
| 1    | Attach the transmitter to the mounting bracket but do not completely tighten the mounting bolts   |
| 2    | Connect a tube between the input connections in the high pressure (HP) and low pressure (LP) heads to eliminate the affects of any surrounding air currents.  |
| 3    | Connect 24 Vdc power to the transmitter and connect a digital voltmeter or SFC to read the transmitter's output or connect a voltmeter across the 250 ohm resistor, if desired.   |
| 4    | Use applicable communicator to establish communications with the transmitter. For DE transmitter use SFC, SCT, or MCT. For Hart, use MCT or other Hart Communicator with applicable Honeywell DD's. For Fieldbus, use NI FBUS tools with applicable Honeywell DD's. |
| 5    | While reading the transmitter's output on a communication tool or a voltmeter, position the transmitter so the output reading is at or near zero, then completely tighten the mounting bolts.   |
| 6    | Do an input zero correct function using the communication tool. This corrects the transmitter for any minor error that may occur after the mounting bolts are tightened.  |
| 7    | Remove the tube from between the input connections, the power, and the digital voltmeter or communication tool.   |

## 3 Set the Jumpers


### 3.1 Changing Default Failsafe Direction

Transmitters are shipped with a default failsafe direction of upscale. This means that the transmitter's output will be driven upscale (maximum output) when the transmitter detects a critical status.

You can change the direction from upscale to downscale (minimum output) by cutting jumper W1 on the printed wiring assembly. If your transmitter is operating in the analog mode, an upscale failsafe action will drive the transmitter's output to greater than 21 mA or a downscale action will drive its output to less than 3.8 mA.

If your transmitter is operating in the DE mode an upscale failsafe action will cause the transmitter to generate a "+ infinity" digital signal, or a downscale failsafe action will cause it to generate a "- infinity" digital signal. The STIMV IOP module interprets either signal as "not a number" and initiates its own configured failsafe action for the control system. The STDC initiates the failsafe mode configured through the transmitter when either signal is generated.

NOTE: The failsafe direction display that you can access through the SFC only shows the state of the failsafe jumper in the transmitter as it correlates to analog transmitter operation. The failsafe action of the digital control system may be configured to operate differently than indicated by the state of the jumper in the transmitter.

| Step | Action  |
|------|---|
|      |  <b>ATTENTION:</b> Electrostatic Discharge (ESD) hazards. Observe precautions for handling electrostatic sensitive devices   |
| 1    | With transmitter on bench and no power applied. Loosen end-cap lock and unscrew end cap from electronics side of transmitter housing.   |
| 2    | If applicable, unsnap Local Smart Meter from PWA mounting bracket and unplug cable from connector on back of meter assembly. Loosen two retaining screws and carefully pull mounting bracket and PWA from housing. Using retaining clip remove flex-tape connector from PWA. Remove 2-wire power connector from PWA, and then remove PWA and mounting bracket assembly. |
| 3    | With component side of PWA facing you, locate failsafe jumper W1 and cut it in half with small wire cutter such as dykes. See Figure 10. This changes failsafe action from upscale to downscale.  |
| 4    | Reverse applicable previous steps to replace PWA.   |
| 5    | Turn ON transmitter power.  |






Figure 12



### 3.2 Optional Write Protect Jumper

The ST 3000 Pressure Transmitter (DE or HART) is now being shipped with a newly designed printed wiring assembly (PWA) that allows user access to the optional write protect jumper without removing the PWA. This version of the PWA is functionally identical to the previous version, with the same performance and specifications. The new version PWA differs only in location of the optional write protect jumper and the associated bracket and hardware.

Do not remove the PWA as described in Section 3.1 Changing Default Failsafe Direction. Instead, follow the following steps.

|  | <b>ATTENTION:</b> Electrostatic Discharge (ESD) hazards. Observe precautions for handling electrostatic sensitive devices.  |
|---|---|
|  | <b>WARNING! PERSONAL INJURY:</b> Risk of electrical shock. Disconnect power before proceeding. HAZARDOUS LIVE voltages greater than 30 Vrms, 42.4 Vpeak, or 60 VDC may be accessible. Failure to comply with these instructions could result in death or serious injury |
| Step  | Action  |
| 1   | Place transmitter on bench. Remove power. Loosen end-cap lock and unscrew end-cap from electronics side of transmitter housing  |
| 2   | If applicable, unsnap local smart meter from PWA mounting bracket.  |
| 3   | Find the write protect jumper shown in Figure 11 below. Position the jumper for read-only or read/write.  |
| 4   | Reverse applicable previous steps to install smart meter and end-cap.   |
| 5   | Re-connect transmitter power.   |




Figure 13

## 4 Connect the Wiring and Power Up

### 4.1 Summary

The transmitter is designed to operate in a two-wire power/current loop with loop resistance and power supply voltage within the operating range shown in Figure 14.

Loop wiring is connected to the transmitter by simply attaching the positive (+) and negative (-) loop wires to the positive (+) and negative (-) SIGNAL screw terminals on the terminal block in the transmitter's electronics housing shown in the table in Section 4.2.

Each transmitter includes an internal ground terminal to connect the transmitter to earth ground. A ground terminal can be optionally added to the outside of the electronics housing. While it is not necessary to ground the transmitter for proper operation, we suggest that you do so to minimize the possible effects of "noise" on the output signal and provide additional protection against lightning and static discharge damage.




Figure 14

21012

## 4.2 Wiring Connections

This procedure shows the steps for connecting power to the transmitter.



For loop wiring and external wiring diagrams, refer to the installation drawings presented in the Transmitter Manual.

Detailed drawings are provided for transmitter installation in non-intrinsically safe areas and for intrinsically safe loops in hazardous area locations.

### ATTENTION

All wiring must comply with local codes, regulations, and ordinances.



If you will be using the transmitter in a hazardous area, be sure to review the hazardous location reference data included in Appendix B of the transmitter manual before operating the transmitter.

| Step | Action   |
|------|--|
| 1    | Loosen end-cap lock using a 1.5 mm allen wrench and remove end-cap cover from terminal block end of transmitter housing.   |
| 2    | Feed loop power leads through one of conduit entrances on either side of transmitter housing. Plug whichever entrance you do not use.<br><b>ATTENTION</b> The transmitter accepts up to 16 AWG wire.                         |
| 3    | Observing polarity, connect positive loop power lead to SIGNAL + terminal and negative loop power lead to SIGNAL - terminal.<br><b>EXAMPLE - CONNECTING LOOP POWER TO TRANSMITTER.</b>                                       |
|      | <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p>3-screw terminal block</p> </div> <div style="text-align: center;"> <p>5-screw terminal block (option LP)</p> </div> </div> |
| 4    | Replace end-cap, and tighten end-cap lock.   |

## 4.3 Lightning Protection

When your transmitter is equipped with optional lightning protection, you must connect a wire from the transmitter to ground as shown in Figure 15 to make the protection effective. We recommend that you use a size 8 (American Wire Gage) or (8.37mm<sup>2</sup>) bare or green covered wire.






Figure 15

## 4.4 Additional Considerations for Wiring SMV 3000 Transmitter




**Figure 16 SMV 3000 Transmitter Terminal Block**

Connect RTD leads to the TC terminals 1, 2, 3, and 4 as appropriate for the given probe type.



**Figure 17 RTD Input Wiring Connections.**

Connect thermocouple leads to terminals 1 (-) and 3 (+), observing polarity.



**Figure 18 Thermocouple Input Wiring Connections.**

## 5 Certifications

### 5.1 Product Certifications

#### 5.1.1 Approved Manufacturing Locations

Honeywell Process Solutions  
512 Virginia Drive  
Fort Washington, PA 19034

Honeywell (Tianjin) Limited  
66 BaiHe Road, Tianjin Economic-  
Technological Development Area  
Tianjin, 300457, P.R. China

Honeywell Automation India Limited  
56 & 57 Hadapsar Industrial Estate  
Pune 411 013, India

#### 5.1.2 European Directive Information

The EC Declarations of Conformity for all applicable directives for this product can be found on the Honeywell website at [www.honeywell.com/imc](http://www.honeywell.com/imc). A hard copy may be obtained by contacting your local Honeywell sales office.

##### **European Pressure Equipment Directive (PED) 97/23/EC**

The ST 3000 pressure transmitters are in conformity with the essential requirements of the PED. A formal statement from TÜV Industry Service Group of TÜV America, Inc., a division of TÜV Süddeutschland, a Notified Body regarding the Pressure Equipment Directive, is available upon request.

##### **Electromagnetic Compatibility (EMC) 89/336/EEC**

All ST 3000 Pressure Transmitters  
EN 50081-1: 1992; EN 50082-2: 1995;  
EN 61326: 1997 / A1: 1998 – Industrial



## 5.2 Hazardous Location Certifications

### 5.2.1 FM™ Approvals (USA)

|                                  | Type of Protection   | Comm. Option                  | Field Parameters   | Temp. Codes                  |
|----------------------------------|--|-------------------------------|--|------------------------------|
| <b>FM Approvals<sup>SM</sup></b> | <b>Explosionproof:</b><br>Class I, Division 1, Groups A, B, C, D locations<br><b>Dust Ignition Proof:</b><br>Class II, III, Division 1, Groups E, F, G locations, Enclosure Type 4X                                    | All                           | All  | T5 Ta = 93°C                 |
|                                  | <b>Intrinsically Safe:</b><br><br>Class I, II, III, Division 1, Groups A, B, C, D, E, F, G locations, Enclosure Type 4X  | 4-20 mA / DE                  | Vmax = 42.4V<br>Imax = 225mA<br>Ci = 4.2nF<br>Li = *<br>Pi = 1.2W  | T4 Ta = 93°C                 |
|                                  |  | 4-20 mA /                     | Vmax = 30V<br>Imax = 225mA<br>Ci = 4.2nF<br>Li = *<br>Pi = 1.2W    | T4 Ta = 93°C                 |
|                                  | <b>Intrinsically Safe:</b><br><br>Class I, II, III, Division 1, Groups A, B, C, D, E, F, G locations;<br><br>Class 1, Zone 0, AEx ia Group IIC, Enclosure Type 4X / IP 66/67   | Fieldbus – Entity (Not FISCO) | Vmax = 32V<br>Imax = 120mA<br>Ci = 4.2nF<br>Li = 0<br>Pi = 0.84W   | T4 Ta = 40°C<br>T3 Ta = 93°C |
|                                  |  | Fieldbus – Entity (Not FISCO) | Vmax = 24V<br>Imax = 250mA<br>Ci = 4.2nF<br>Li = 0<br>Pi = 1.2W    | T4 Ta = 40°C<br>T3 Ta = 93°C |
|                                  |  | FISCO                         | Vmax = 17.5V<br>Imax = 380mA<br>Ci = 4.2nF<br>Li = 0<br>Pi = 5.32W | T4 Ta = 40°C<br>T3 Ta = 93°C |
|                                  | <b>Nonincendive:</b><br><br>Class I, Division 2, Groups A, B, C, D locations, Enclosure Type 4X  | 4-20 mA / DE                  | Vmax = 42.4V<br>Imax = 225mA<br>Ci = 4.2nF<br>Li = *<br>Pi = 1.2W  | T4 Ta = 93°C                 |
|                                  |  | 4-20 mA / HART                | Vmax = 30V<br>Imax = 225mA<br>Ci = 4.2nF<br>Li = *<br>Pi = 1.2W    | T4 Ta = 93°C                 |
|                                  | <b>Nonincendive:</b><br><br>Class I, Division 2, Groups A, B, C, D;<br><br>Suitable for:<br>Class II, Division 2, Groups F&G;<br>Class III, Division 2;<br>Class I, Zone 2, Group IIC,<br>Enclosure Type 4X / IP 66/67 | Fieldbus – Entity (Not FNICO) | Vmax = 32V<br>Imax = 120mA<br>Ci = 4.2nF<br>Li = 0<br>Pi = 0.84W   | T4 Ta = 40°C<br>T3 Ta = 93°C |
|                                  |  | Fieldbus – Entity (Not FNICO) | Vmax = 24V<br>Imax = 250mA<br>Ci = 4.2nF<br>Li = 0<br>Pi = 1.2W    | T4 Ta = 40°C<br>T3 Ta = 93°C |
|                                  |  | FNICO                         | Vmax = 32V<br>Ci = 4.2nF<br>Li = 0                                 | T4 Ta = 40°C<br>T3 Ta = 93°C |

Li = 0 except Li = 150µH when Option ME, Analog Meter, is selected.

FM Approvals<sup>SM</sup> is a service mark of FM Global

## 5.2.2 Canadian Standards Association (CSA)

|   | Type of Protection  | Comm. Option   | Field Parameters  | Temp. Codes                  |  |
|---|---|--|---|------------------------------|--|
| <b>Canadian Standards Association (CSA)</b> | <b>Explosion Proof:</b> Class I, Division 1, Groups B, C, D locations<br><b>Dust Ignition Proof:</b> Class II, III, Division 1, Groups E, F, G locations, Enclosure Type 4X | All  | All   | T4 Ta = 93°C                 |  |
|   | <b>Intrinsically Safe:</b><br><br>Class I, II, III, Division 1, Groups A, B, C, D, E, F, G locations, Enclosure Type 4X   | 4-20 mA / DE   | Vmax = 42V<br>Imax = 225mA<br>Ci = 4.2nF<br>Li = *<br>Pi = 1.2W   | T4 Ta = 93°C                 |  |
|   |   | 4-20 mA / HART   | Vmax = 42V<br>Imax = 225mA<br>Ci = 4.2nF<br>Li = *<br>Pi = 1.2W   | T4 Ta = 93°C                 |  |
|   |   | Fieldbus – Entity (Not FISCO)  | Vmax = 24V<br>Imax = 250mA<br>Ci = 4.2nF<br>Li = 0<br>Pi = 1.2W   | T4 Ta = 40°C<br>T3 Ta = 93°C |  |
|   | <b>Nonincendive:</b><br><br>Class I, Division 2, Groups A, B, C, D locations, Enclosure Type 4X   | 4-20 mA / DE   | Vmax = 42.4V<br>Imax = 225mA<br>Ci = 4.2nF<br>Li = *<br>Pi = 1.2W | T4 Ta = 93°C                 |  |
|   |   | 4-20 mA / HART   | Vmax = 30V<br>Imax = 225mA<br>Ci = 4.2nF<br>Li = *<br>Pi = 1.2W   | T4 Ta = 93°C                 |  |
|   |   | Fieldbus – Entity (Not FNICO)  | Vmax = 24V<br>Imax = 250mA<br>Ci = 4.2nF<br>Li = 0<br>Pi = 1.2W   | T4 Ta = 40°C<br>T3 Ta = 93°C |  |
|   | <b>Canadian Registration Number (CRN):</b>  | All ST 3000 models except STG19L, STG99L, STG170, STG180, STA17L and STA97L have been registered in all provinces and territories in Canada and are marked CRN: 0F8914.5C. |   |                              |  |

### 5.2.3 IECEx International Electrotechnical Commission (LCIE)

|   | Type of Protection  | Comm. Option            | Field Parameters  | Temp. Codes   |
|---|---|-------------------------|---|---|
| <b>IECEx<br/>International<br/>Electrotechnical<br/>Commission<br/>(LCIE)</b> | <b>Flameproof, Zone 1:</b><br>Ex d IIC, Enclosure IP 66/67            | All                     | All   | T5 Ta = -50 to 93°C<br>T6 Ta = -50 to 78°C                        |
|   | <b>Intrinsically Safe, Zone 0/1:</b><br>Ex ia IIC, Enclosure IP 66/67 | 4-20 mA / DE            | U <sub>i</sub> = 30V<br>I <sub>i</sub> = 100mA<br>C <sub>i</sub> = 4.2nF<br>L <sub>i</sub> = *<br>P <sub>i</sub> = 1.2W | T4 Ta = -50 to 93°C<br>T5 Ta = -50 to 85°C<br>T6 Ta = -50 to 70°C |
|   |   | 4-20 mA / HART          | U <sub>i</sub> = 30V<br>I <sub>i</sub> = 100mA<br>C <sub>i</sub> = 4.2nF<br>L <sub>i</sub> = *<br>P <sub>i</sub> = 1.2W | T4 Ta = -50 to 93°C<br>T5 Ta = -50 to 63°C<br>T6 Ta = -50 to 48°C |
|   |   | Fieldbus<br>(Not FISCO) | U <sub>i</sub> = 24V<br>I <sub>i</sub> = 250mA<br>C <sub>i</sub> = 4.2nF<br>L <sub>i</sub> = 0<br>P <sub>i</sub> = 1.2W | T3 Ta = -50 to 93°C<br>T4 Ta = -50 to 40°C                        |

- L<sub>i</sub> = 0 except L<sub>i</sub> = 150µH when Option ME, Analog Meter, is selected.

### 5.2.4 SAEx (South Africa)

|                                | Type of Protection  | Comm. Option            | Field Parameters  | Temp. Codes   |
|--------------------------------|---|-------------------------|---|---|
| <b>SAEx<br/>(South Africa)</b> | <b>Flameproof, Zone 1:</b><br>Ex d IIC, Enclosure IP 66/67  | All                     | All   | T5 Ta = -50 to 93°C<br>T6 Ta = -50 to 78°C                        |
|                                | <b>Intrinsically Safe, Zone 0/1:</b><br>Ex ia IIC, Enclosure IP 66/67   | 4-20 mA / DE            | U <sub>i</sub> = 30V<br>I <sub>i</sub> = 100mA<br>C <sub>i</sub> = 4.2nF<br>L <sub>i</sub> = *<br>P <sub>i</sub> = 1.2W | T4 Ta = -50 to 93°C<br>T5 Ta = -50 to 85°C<br>T6 Ta = -50 to 70°C |
|                                |   | 4-20 mA / HART          | U <sub>i</sub> = 30V<br>I <sub>i</sub> = 100mA<br>C <sub>i</sub> = 4.2nF<br>L <sub>i</sub> = *<br>P <sub>i</sub> = 1.2W | T4 Ta = -50 to 93°C<br>T5 Ta = -50 to 63°C<br>T6 Ta = -50 to 48°C |
|                                |   | Fieldbus<br>(Not FISCO) | U <sub>i</sub> = 24V<br>I <sub>i</sub> = 250mA<br>C <sub>i</sub> = 4.2nF<br>L <sub>i</sub> = 0<br>P <sub>i</sub> = 1.2W | T3 Ta = -50 to 93°C<br>T4 Ta = -50 to 40°C                        |
|                                | <b>Multiple Marking:</b><br><b>Flameproof, Zone 1:</b><br>Ex d IIC, Enclosure IP 66/67<br><br><b>Intrinsically Safe, Zone 0/1:</b><br>Ex ia IIC, Enclosure IP 66/67<br><br><b>NOTE.</b> The user must determine the type of protection required for installation of the equipment. The user shall then check the box [√] adjacent to the type of protection used on the equipment certification nameplate. Once a type of protection has been checked on the nameplate, subsequently the equipment shall not be reinstalled using any of the other certification types. | 4-20 mA / DE            | U <sub>i</sub> = 30V<br>I <sub>i</sub> = 100mA<br>C <sub>i</sub> = 4.2nF<br>L <sub>i</sub> = *<br>P <sub>i</sub> = 1.2W | T4 Ta = -50 to 93°C<br>T5 Ta = -50 to 85°C<br>T6 Ta = -50 to 70°C |
|                                |   | 4-20 mA / HART          | U <sub>i</sub> = 30V<br>I <sub>i</sub> = 100mA<br>C <sub>i</sub> = 4.2nF<br>L <sub>i</sub> = *<br>P <sub>i</sub> = 1.2W | T4 Ta = -50 to 93°C<br>T5 Ta = -50 to 63°C<br>T6 Ta = -50 to 48°C |
|                                |   | Fieldbus<br>(Not FISCO) | U <sub>i</sub> = 24V<br>I <sub>i</sub> = 250mA<br>C <sub>i</sub> = 4.2nF<br>L <sub>i</sub> = 0<br>P <sub>i</sub> = 1.2W | T3 Ta = -50 to 93°C<br>T4 Ta = -50 to 40°C                        |



## 5.2.5 INMETRO (CERTU SP Brazil)

|   | Type of Protection   | Comm. Option            | Field Parameters  | Temp. Codes   |
|---|--|-------------------------|---|---|
| <b>INMETRO<br/>(CERTUSP)<br/>Brazil</b> | <b>Flameproof, Zone 1:</b><br>BR-Ex d IIC<br>Enclosure IP 66/67            | All                     | All   | T5 Ta = -50 to 93°C<br>T6 Ta = -50 to 78°C                        |
|   | <b>Intrinsically Safe, Zone 0/1:</b><br>BR-Ex ia IIC<br>Enclosure IP 66/67 | 4-20 mA / DE            | U <sub>i</sub> = 30V<br>I <sub>i</sub> = 100mA<br>C <sub>i</sub> = 4.2nF<br>L <sub>i</sub> = *<br>P <sub>i</sub> = 1.2W | T4 Ta = -50 to 93°C<br>T5 Ta = -50 to 85°C<br>T6 Ta = -50 to 70°C |
|   |  | 4-20 mA / HART          | U <sub>i</sub> = 30V<br>I <sub>i</sub> = 100mA<br>C <sub>i</sub> = 4.2nF<br>L <sub>i</sub> = *<br>P <sub>i</sub> = 1.2W | T4 Ta = -50 to 93°C<br>T5 Ta = -50 to 63°C<br>T6 Ta = -50 to 48°C |
|   |  | Fieldbus<br>(Not FISCO) | U <sub>i</sub> = 24V<br>I <sub>i</sub> = 250mA<br>C <sub>i</sub> = 4.2nF<br>L <sub>i</sub> = 0<br>P <sub>i</sub> = 1.2W | T3 Ta = -50 to 93°C<br>T4 Ta = -50 to 40°C                        |

\* L<sub>i</sub> = 0 except L<sub>i</sub> = 150µH when Option ME, Analog Meter, is selected.

## 5.2.6 ATEX Certification (LCIE)

|                | Type of Protection   | Comm. Option                  | Field Parameters  | Temp. Codes  |
|----------------|--|-------------------------------|---|--|
| ATEX<br>(LCIE) | <b>Flameproof, Zone 0:</b><br>⊕ II 1 D, Ex tD<br>Enclosure IP 66/67  | All                           | All   | A20 IP6X T95°C Ta = 93°C or T80°C Ta = 78°C  |
|                | <b>Flameproof, Zone 1:</b><br>⊕ II 2 GD, Ex d IIC, Ex tD<br>Enclosure IP 66/67   | All                           | All   | T5 Ta = -50 to +93°C<br>T6 Ta = -50 to +78°C,<br>A21 IP6X T95°C Ta = 93°C or T80°C Ta = 78°C |
|                | <b>Intrinsically Safe, Zone 0/1:</b><br><br>⊕ II 1 G, Ex ia IIC,<br>Enclosure IP 66/67   | 4-20 mA / DE                  | Ui = 30V<br>Ii = 100mA<br>Ci = 4.2nF<br>Li = *<br>Pi = 1.2W | T4 Ta = -50 to 93°C<br>T5 Ta = -50 to 85°C<br>T6 Ta = -50 to 70°C                            |
|                |  | 4-20 mA / HART                | Ui = 30V<br>Ii = 100mA<br>Ci = 4.2nF<br>Li = *<br>Pi = 1.2W | T4 Ta = -50 to 93°C<br>T5 Ta = -50 to 63°C<br>T6 Ta = -50 to 48°C                            |
|                |  | Fieldbus<br>(Not FISCO)       | Ui = 24V<br>Ii = 250mA<br>Ci = 4.2nF<br>Li = 0<br>Pi = 1.2W | T3 Ta = -50 to 93°C<br>T4 Ta = -50 to 40°C   |
|                | <b>Non-Sparking, Zone 2:</b><br><br>⊕ II 3 G, Ex nA IIC (Honeywell),<br>Enclosure IP 66/67   | 4-20 mA / DE                  | Ui = 30V<br>Ii = 100mA<br>Ci = 4.2nF<br>Li = *<br>Pi = 1.2W | T4 Ta = -50 to 93°C<br>T5 Ta = -50 to 85°C<br>T6 Ta = -50 to 70°C                            |
|                |  | 4-20 mA / HART                | Ui = 30V<br>Ii = 100mA<br>Ci = 4.2nF<br>Li = *<br>Pi = 1.2W | T4 Ta = -50 to 93°C<br>T5 Ta = -50 to 63°C<br>T6 Ta = -50 to 48°C                            |
|                |  | Fieldbus<br>(Not FNICO)       | Ui = 24V<br>Ii = 250mA<br>Ci = 4.2nF<br>Li = 0<br>Pi = 1.2W | T3 Ta = -50 to 93°C<br>T4 Ta = -50 to 40°C   |
|                | <b>Multiple Marking:</b><br><br><b>Flameproof, Zone 1:</b><br>⊕ II 2 G, Ex d IIC<br><br><b>Intrinsically Safe, Zone 0/1:</b><br>⊕ II 1 G, Ex ia IIC<br><br><b>Non-Sparking, Zone 2:</b><br>⊕ II 3 G, Ex nA IIC<br><br><b>NOTE:</b> The user must determine the type of protection required for installation of the equipment. The user shall then check the box [ √ ] adjacent to the type of protection used on the equipment certification nameplate. Once a type of protection has been checked on the nameplate, subsequently the equipment shall not be reinstalled using any of the other certification types. | 4-20 mA / DE                  | Ui = 30V<br>Ii = 100mA<br>Ci = 4.2nF<br>Li = *<br>Pi = 1.2W | T4 Ta = -50 to 93°C<br>T5 Ta = -50 to 85°C<br>T6 Ta = -50 to 70°C                            |
|                |  | 4-20 mA / HART                | Ui = 30V<br>Ii = 100mA<br>Ci = 4.2nF<br>Li = *<br>Pi = 1.2W | T4 Ta = -50 to 93°C<br>T5 Ta = -50 to 63°C<br>T6 Ta = -50 to 48°C                            |
|                |  | Fieldbus<br>(Not FISCO/FNICO) | Ui = 24V<br>Ii = 250mA<br>Ci = 4.2nF<br>Li = 0<br>Pi = 1.2W | T3 Ta = -50 to 93°C<br>T4 Ta = -50 to 40°C   |
|                |  |                               |   |  |

\* Li = 0 except Li = 150µH when Option ME, Analog Meter, is selected.

## 5.2.7 Pressure Equipment Directive (PED)

|   |   |
|---|---|
| <b>European<br/>Pressure<br/>Equipment<br/>Directive (PED)<br/>(97/23/EC)</b> | <p>The ST 3000 Smart Pressure Transmitters are in conformity with the essential requirements of the Pressure Equipment Directive.</p> <p>Honeywell ST 3000 Smart Pressure Transmitters are designed and manufactured in accordance with the applicable portions of Annex I, Essential Safety Requirements, and sound engineering practices. These transmitters have no pressurized internal volume, or have a pressurized internal volume rated less than 200 bar (2,900 psig), and/or have a maximum volume of less than 0.1 liter (Article 3, 1.1.(a) first indent, Group 1 fluids). Therefore, these transmitters are not subject to the essential requirements of the directive 97/23/EC (PED, Annex I) and shall not have the CE mark applied.</p> <p>For transmitters rated &gt; 200 bar (2,900 psig) &lt; 1,000 bar (14,500 psig) Honeywell maintains a technical file in accordance with Annex III, Module A, (internal production control) when the CE mark is required. Transmitter Attachments: Diaphragm Seals, Process Flanges and Manifolds comply with Sound Engineering Practice.</p> |
|   | <p><b>NOTE:</b> Pressure transmitters that are part of safety equipment for the protection of piping (systems) or vessel(s) from exceeding allowable pressure limits, (equipment with safety functions in accordance with Pressure Equipment Directive 97/23/EC article 1, 2.1.3), require separate examination.</p> <p>A formal statement from TÜV Industry Service Group of TÜV America, Inc., a division of TÜV Süddeutschland, a Notified Body regarding the Pressure Equipment Directive, can be found at <a href="http://www.honeywell.com">www.honeywell.com</a>. A hard copy may be obtained by contacting a Honeywell representative.</p>  |

## 5.2.8 Other Certifications

|   |   |
|---|---|
| <b>CE Mark</b>                          | <p><b><i>Electro Magnetic Compatibility (EMC) (2004/108/EC)</i></b><br/>           All Models: EN 50081-1: 1992; EN 50082-2:1995; EN 61326-1:1997 + A1, A2, and A3 – Industrial Locations</p> |
| <b>Dual Seal Certification</b>          | <p>Dual Seal Certification based on ANSI/NFPA 70-202 and ANSI/ISA 12.27.01 requirements without the use of additional seal protection elements.</p>   |
| <b>Approved Manufacturing Locations</b> | <p>Honeywell Process Solutions - York, PA USA<br/>           Honeywell (Tianjin) Limited – Tianjin, P.R. China<br/>           Honeywell Automation India Ltd. – Pune 411013 India</p>         |

Foundation™ Fieldbus is a trademark of the Fieldbus Foundation.

HART® is a registered trademark of HART Communications Foundation.

Hastelloy® C-276 is a registered trademark of Haynes International.

Monel® 400 is a registered trademark of Special Metals Corporation.

ST 3000® and Experion® are registered trademarks of Honeywell International Inc.

Viton® is a registered trademark of DuPont

Teflon® is a registered trademark of DuPont.

DC® 200 is a registered trademark of Dow Corning.

FM Approvals<sup>SM</sup> is a service mark of FM Global





## Sales and Service

For application assistance, current specifications, pricing, or name of the nearest Authorized Distributor, contact one of the offices below.

### ASIA PACIFIC

Control Products  
Asia Pacific Headquarters  
Phone: +(65) 6355-2828  
Fax: +(65) 6445-3033

### Asia Pacific Global Technical Support

Field Instruments  
Phone: +65 6580 3156  
Fax: +65 6445-3033  
Process Instruments  
Phone: (603) 76950 4777  
Fax: (603) 7958 8922

Australia  
Honeywell Limited  
Phone: +(61) 7-3846 1255  
FAX: +(61) 7-3840 6481  
Toll Free 1300-36-39-36  
Toll Free Fax:  
1300-36-04-70

China – PRC - Beijing  
Honeywell China Inc.  
Phone: +(86-10) 8458-3280  
Fax: +(86-10) 8458-4650

China – PRC - Shanghai  
Honeywell China Inc.  
Phone: (86-21) 5257-4568  
Fax: (86-21) 6237-2826

China – PRC - Chengdu  
Honeywell China Inc.  
Phone: +(86-28) 8678-6348  
Fax: +(86-28) 8678-7061

China – PRC - Xi'an  
Honeywell China Ltd -  
Xi'an.  
Phone: +(86-29) 8833-7490  
Fax: +(86-29) 8833-7489

China – PRC - Shenzhen-  
Honeywell China Inc.  
Phone: +(86) 755-2518-  
1226  
Fax: +(86) 755-2518-1221

Indonesia  
PT Honeywell Indonesia  
Phone: +(62) 21-535-8833  
FAX: +(62) 21-5367 1008

India Automation India  
Ltd.  
Honeywell Ltd.  
Phone: +(91) 5603-9400  
Fax: +(91) 5603-9600

Japan  
Honeywell Inc.  
Phone: +(81) 3 6730 7150  
Fax: +(81) 3 6730 7228

Malaysia  
Honeywell Engineering  
Sdn Bhd  
Phone: +(60-3) 7950-4776  
Fax: +(60-3) 7958-8922

New Zealand  
Honeywell Limited  
Phone: +(64-9) 623-5052  
Fax: +(64-9) 623-5060  
Toll Free (0800) 202-088

Philippines  
Honeywell Systems  
(Philippines) Inc.  
Phone: +(63-2) 633-2830-31/  
636 1661-62  
Fax: +(63-2) 638-4013

Singapore  
Honeywell Pte Ltd.  
Phone: +(65) 6580 3278  
Fax: +(65) 6445-3033

South Korea  
Honeywell Korea Co Ltd  
Phone: +(822) 799 6315  
Fax: +(822) 792 9015

Thailand  
Honeywell Systems  
(Thailand) Ltd.  
Phone: +(662) 693-3099  
FAX: +(662) 693-3089

Taiwan R.O.C.  
Honeywell Taiwan Ltd.  
Phone: +(886-2) 2245-1000  
FAX: +(886-2) 2245-3241

SE Asia Countries  
see Honeywell Pte Ltd  
(Singapore)  
for: Pakistan, Cambodia,  
Guam, Laos, Myanmar,  
Vietnam, East Timor

SE Asia Countries  
see Honeywell Automation  
India Ltd for:  
Bangladesh  
Nepal  
Sri Lanka

### EUROPE

Austria  
Honeywell Austria GmbH  
Phone: +43 (316)400123  
FAX: +43 (316)40017

Belgium  
Honeywell SA/NV  
Phone: +32 (0) 2 728 24 07  
FAX: +32 (0) 2 728 22 45

Bulgaria  
Honeywell EOOD  
Phone: +(359) 2 40 20 900  
FAX: +(359) 2 40 20 990

Czech Republic  
Honeywell spol. s.r.o.  
Phone: +420 242 442 232  
FAX: +420 242 442 131

Denmark  
Honeywell A/S  
Phone: +(45) 39 55 55 55  
FAX: +(45) 39 55 55 58

Finland  
Honeywell OY  
Phone: +358 (0)20752 2753  
FAX: +358 (0) 20752 2751

France  
Honeywell SA  
Phone: +33 (0)1 60198075  
FAX: +33 (0)1 60198201

Germany  
Honeywell AG  
Phone: +49 (69)8064-299  
FAX: +49 (69)806497336

Hungary  
Honeywell Kft.  
Phone: +36-1-451 4300  
FAX: +36-1-451 4343

Italy  
Honeywell S.p.A.  
Phone: +390292146307  
FAX: +39 0292146377

The Netherlands  
Honeywell B.V.  
Phone: +31 (0) 20 5656200  
FAX: +31 (0) 20 5656210

Norway  
Honeywell A/S  
Phone: (45) 39 55 55 55

Poland  
Honeywell Sp. zo.o  
Phone: +48-22-6060900  
FAX: +48-22-6060901

Portugal  
Honeywell Portugal Lda  
Phone: +351 21 424 5000  
FAX: +351 21 424 50 99

Romania  
Honeywell Bucharest  
Phone: +40 (0) 21 2316437  
FAX: +40 (0) 21 2316439

Russian Federation (RF),  
ZAO "Honeywell"  
Phone: +7 (095) 796 98 00  
FAX: +7 (495) 797 99 64

Slovak Republic  
Honeywell s.r.o.  
Phone: +421-2-58247 410  
FAX: +421-2-58247 415

Spain  
Honeywell S.A.  
Phone: +34 (0)91313 61 00  
FAX: +34 (0)91313 61 30

Sweden  
Honeywell AB  
Phone: +(46) 8 775 55 00  
FAX: +(46) 8 775 56 00

Switzerland  
Honeywell AG  
Phone: +41 18552448  
FAX: +(41) 1 855 24 45

Turkey  
Honeywell Turkey A.S.  
Phone: +90 216 578 71 00  
FAX: +90 216 575 66 35

Ukraine  
Honeywell  
Tel: +380-44-201 44 74  
Fax: +380-44-201-44-75

United Kingdom  
Honeywell Control Systems  
Ltd.  
Phone: +44 (0)1344 655251  
FAX: +44 (0) 1344 655554

MIDDLE EAST  
Abu Dhabi U A E  
Middle East Headquarters  
Honeywell Middle East Ltd.  
Phone: +971 2 4041246  
FAX: +971 2 4432536

Sultanate of Oman  
Honeywell & Co Oman LLC  
Phone: +968 24 701153/  
Ext.33  
FAX +968 24 787351

Saudia Arabia  
Honeywell Turki Arabia Ltd  
Jubail Office  
Phone: +966-3-341-0140  
Fax: +966-3-341-0216  
Honeywell - ATCO  
Dammam Office  
Phone: 0096638304584  
Fax: 0096638338059

Kuwait  
Honeywell Kuwait KSC  
Phone: +965 242 1327 to 30  
Fax: +965 242 8315  
And  
Phone: +965 326  
2934/1821 Fax: +965 326  
1714

### AFRICA

Mediterranean & African  
Distributors  
Honeywell SpA  
Phone: +39 (02) 250 10  
604  
FAX: +39 (02) 250 10 659

South Africa (Republic of)  
and sub saharan  
Honeywell Southern  
Africa  
Honeywell S.A. Pty. Ltd.  
Phone: +27 11 6958000  
FAX +27 118051504

### NORTH AMERICA

Canada  
Honeywell LTD  
Phone: 1-800-737-3360  
FAX: 1-800-565-4130

USA  
Honeywell Process  
Solutions,  
Phone: 1-800-343-0228  
FAX: 1-717-771-8251  
Email: [sc-cp-  
appssales@  
honeywell.com](mailto:sc-cp-appssales@honeywell.com)

### LATIN AMERICA

Argentina  
Honeywell S.A.I.C.  
Phone: +(54-11) 4383-3637  
FAX: +(54-11) 4325-6470

Brazil  
Honeywell do Brasil & Cia  
Phone: +(55-11) 7266-1900  
FAX: +(55-11) 7266-1905

Chile  
Honeywell Chile, S.A.  
Phone: +(56-2) 233-0688  
FAX: +(56-2) 231-6679

Mexico  
Honeywell S.A. de C.V.  
Phone: +(52) 55 5259-1966  
FAX: +(52) 55 5570-2985

Puerto Rico  
Honeywell Inc.  
Phone: +(809) 792-7075  
FAX: +(809) 792-0053

Trinidad  
Honeywell Inc.  
Phone: +(868) 624-3964  
FAX: +(868) 624-3969

Venezuela  
Honeywell CA  
Phone: +(58-2) 238-0211  
FAX: +(58-2) 238-3391

# Honeywell

## Honeywell Process Solutions

Honeywell  
512 Virginia Drive  
Fort Washington, PA 19034  
[www.honeywell.com/ps](http://www.honeywell.com/ps)

34-ST-25-24

July 2011

©2011 Honeywell International Inc.