

TyrePal

www.tyrepal.co.uk

Tyre Pressure Monitoring System with compact sensors TC215B

User Manual




CONTENTS

1. SYSTEM COMPONENTS	2
1.1 Monitor and accessories.....	2
1.2 Sensors	2
1.3 Optional components.....	2
1.4 Monitor layout and controls.....	3
1.5 Screen icons	3
2. IMPORTANT SAFETY NOTES	3
3. BEFORE INSTALLATION.....	4
3.1 Wheel balancing.....	4
3.2 Battery charging.....	4
3.4 Sensors and wheel positions	4
4. INSTALLATION.....	5
4.1 Install and register the sensors	5
4.2 Lock the sensors	7
4.3 Check for leaks	7
4.4 Set units and alert levels.....	8
4.5 Install the monitor.....	9
4.6 Connect the power	9
5. OPERATION	10
5.1 Sleep mode.....	10
5.2 Alerts.....	10
5.3 Backlight.....	11
5.4 Connecting and disconnecting a trailer.....	11
5.5 Replacing sensor batteries	12
6. TESTING THE SETUP.....	12
7. SMART RELAY (OPTIONAL EQUIPMENT).....	13
7.1 Operation as a signal repeater	13
8. TROUBLESHOOTING AND ADDITIONAL INFORMATION.....	13
9. SPARES, SERVICE AND WARRANTY.....	13
10. SPECIFICATION SUMMARY	14

1. SYSTEM COMPONENTS

1.1 Monitor and accessories



1.2 Sensors


The system is supplied with compact sensors that can be used for tyre pressures up to 99psi. The monitor is compatible with different types of TyrePal TCS sensors for higher pressures. If different sensors are used, the operation of the monitor may not be exactly as described in this manual.

The sensors have integral locking screws which can be used to prevent casual theft.


The box may also contain some spare O-rings that can be used as replacement seals when the sensor batteries are replaced.

1.3 Optional components

The system may be supplied with optional parts such as a Smart Relay. This is used to extend the range of the sensor signals and can also store trailer settings to simplify exchanging trailers in a fleet.



1.4 Monitor layout and controls



1.5 Screen icons

Tyre position icon



Monitor battery icon  (fully charged)  (requires charging)

Sensor low battery icon



2. IMPORTANT SAFETY NOTES

The TyrePal system can help you maintain tyre pressures for safety, fuel economy, tyre life and environmental impact.

It is your responsibility to ensure that it is suitable for your particular vehicle and that it is working correctly and properly maintained. Check the sensors and valve stems regularly, as some road salts can cause corrosion.

The system does not replace the need to carry out regular checks on the condition and wear of the tyres.

Keep the small parts and especially the batteries out of the reach of children. If a battery is swallowed, consult a doctor. Do not hold a battery with metallic tweezers as it will cause a short circuit and may lead to burning or explosion of the battery.

3. BEFORE INSTALLATION

Before installing the system, ensure that it is suitable for your vehicle.

- Check that the operating pressure of your tyres is within the range of the system. i.e. 0-6.8 bar (0-99psi).
- Check that tyre valve stems are in good condition before fitting the sensors. We do not recommend using the system with aluminium valve stems.
- Do not fit sensors to tyres that have been treated with internal tyre sealant. The sealant may damage the sensor or impair its action.
- To avoid danger of damage to the sensors, check that sensor valve caps will remain within the outside profile of the tyres when fitted.

If the distance from the rear wheels to the monitor is greater than about 7 metres, we recommend the use of a TyrePal Smart Relay to increase the range of the sensors and improve the stability of the system.

3.1 Wheel balancing


The weight of the sensors is within the tolerance achieved for wheel balancing, so there is usually no need for the wheels to be rebalanced after installing the system. If vibration is felt when driving at speed after fitting the system, the wheels must be rebalanced.

3.2 Battery charging

The monitor is powered from an internal rechargeable battery that may need to be charged before first use. A full charge will last for about 30 hours at two hours driving per day. It can be charged from the vehicle 12-24V supply using the supplied cigarette lighter lead.

3.4 Sensors and wheel positions

Sensors are interchangeable and can be registered to any of the 22 possible wheel positions. Once sensors are registered, the display only shows data from the registered positions. We recommend that you label each sensor to identify its position and record the positions here:



4. INSTALLATION

4.1 Install and register the sensors

The following procedure registers the sensors as they are installed.

1. In standby mode, press and hold the **CODE** button for 3 seconds. Release it after the beep to enter coding mode. A flashing tyre icon is displayed. If no sensor is registered to this position, the letters FFF FFF are shown. If a sensor is already registered, the sensor ID is shown.
2. Press the **+** or **-** button to select the desired tyre position.
3. Screw the sensor onto the tyre valve. As it senses the air pressure, the sensor sends its ID code to the monitor. The monitor beeps and stores the tyre position with that sensor ID. If it does not register within a few seconds, unscrew the sensor and try again.
4. Press **+** or **-** buttons to select the other tyres and repeat for all the tyres that are to be monitored.
5. When all sensors are registered, press and hold the **CODE** button to exit.

If you need to delete a setting, use the **+** or **-** buttons to select the tyre position then press and hold the **SET** button for three seconds. A double beep confirms the ID has been deleted.

Note: If a sensor is coded twice to the same monitor, the previous setting will be deleted automatically.



4.2 Lock the sensors

For added security, use the locking screw in the sensor can be tightened onto the valve stem using the hex key, but do not over tighten. If it is difficult to reach, take the sensor off and insert the locking screw into a different hole.

Keep the hex key in a safe place as it is needed to remove the sensor.

4.3 Test for leaks



When the sensors have been installed, test for leaks by brushing a little detergent and water on the valve stems. If bubbles appear, release the locking screw and re-tighten the sensor.



Hex key

4.4 Set units of pressure and alert levels

Pressure units can be set to display in psi or bar, and temperature in °C or °F. Pressure alerts are set individually for each of the three axles on the towing vehicle (tractor) while the trailer settings apply to all axles on the trailer. The temperature alert level applies to all tyres and cannot be set below 70°C.

1. In standby mode, press and hold the **SET** button for 3 seconds. Release after the beep. Press the **SET** button repeatedly to scroll through the different settings and press the **+** or **-** buttons to adjust the setting as follows:
2. **Pressure units:** while the PSI or BAR icon is flashing, press the **+** or **-** button to select the desired units. Then press **SET** to move on to set temperature units.The diagram shows a control panel with two large digital displays. The left display shows 'PSI' with a small circle around it and a line pointing to it. The right display is blank. Below the displays are several buttons. A label 'Flash' points to the 'PSI' icon. A battery icon is in the bottom right corner.
3. **Temperature units:** while the °C or °F is flashing, press the **+** or **-** buttons to select and press **SET** again to move on to set the high pressure alert level for the first axle.The diagram shows the control panel with the left display showing '35 PSI' and the right display showing '25 °C'. A label 'Flash' points to the '35' value. Below the displays are several buttons. A label 'FAST LEAKAGE' is positioned between the buttons. A battery icon is in the bottom right corner.
4. **First axle pressure alert levels:** Press **+** or **-** to adjust the high pressure setting, then press **SET** to move on to set the low pressure alert for this axle.

Red Light Flash — ●

Note that the system will not allow the high pressure alert to be less than the low pressure alert level. The factory set low pressure level is set to 30psi, so if you want the high pressure alert level below 30psi, you must set the low pressure alert levels first, then cycle through again to set the high pressure alerts.

5. Continue to cycle through high and low pressure settings for the three axles on the tractor unit and all three axles on the trailer.
6. **High temperature alert for all wheels:** Press **+** or **-** to adjust the setting as required. The factory setting of 70°C is a minimum and is suitable for most applications.
7. Press and hold the **SET** button for three seconds to save the settings and exit the settings mode. If no action is taken for 1 minute, the system will return to standby mode without making any changes.

The alert levels can be adjusted at any time using this procedure, for example if different pressures are required when not towing a trailer. The new settings take immediate effect.

4.5 Install the monitor

Various fixing options are available for the monitor. Make sure it does not obstruct the driver's view when installed.

Windscreen mount:

Clip the monitor to the holder, moisten the suction pad and press it to the windscreen. Lower the lever to secure the pad to the windscreen.



To remove it, lift the lever to break the suction, or unclip the monitor from the holder.

Free standing:

Fit the monitor stand in the holes in the back of the monitor and position it where it can be seen. Note that the stand is a tight fit in the holes.

Screw mount:

The monitor mount can be permanently fixed to the vehicle with the bracket. To use the screw mounting option, dismantle the suction holder and re-assemble it with the metal bracket in place of the suction cup.



Click the monitor into position. If required the monitor can be removed by unclipping it from the mount.

4.6 Connect the power

Connect the monitor to the vehicle power supply (12V or 24V) via the power adapter to charge the battery. A full charge will last for about 30 hours at two hours driving per day.

5. Operation

In normal operation the monitor continuously scrolls through and displays the pressure and temperature of the tyres one by one. You can manually scroll through to any particular tyre by using the + or - buttons. The system is accurate to 0.1bar (1.5psi), so a difference of one or two psi between the tyres can safely be ignored.

The sensors check the pressure and temperature every eight seconds while the vehicle is moving. If the pressure is falling, data is transmitted to the monitor immediately, but if the pressure is steady, data is transmitted only every five minutes. This is to reduce power consumption and extend the life of the sensor batteries.

5.1 Sleep mode

The monitor has a built in motion sensor that shuts it down into a sleep mode after about ten minutes of no movement so it does not normally need to be turned off. Any vibration such as opening the vehicle door wakes it up again. If the vehicle is to be unused for some time, we recommend turning the monitor off to prevent battery drain.


The sensors supplied with this model also have a sleep mode, and when the vehicle has been stationary for several minutes, they stop transmitting to save battery power. If the monitor is awake at this time, it will continue to display the latest received data for a period of time and then show a blank for tyre positions where no data has been received. Please note that it may take a few minutes for the monitor to receive signals from all the sensors when it first wakes up.

If a sensor battery is low, or if a signal is not received from a sensor for a period of 60 minutes, an alert is issued.

5.2 Alerts

If there is a leak or if any tyre is outside the pre-defined values, it gives an alert:

- An audible alarm
- A flashing red light
- A flashing tyre icon that identifies the tyre
- A description of the problem



Red Light Flash —●

Press any button to switch the alarm off. The red light will continue to flash until the problem is corrected.


The following messages may appear

HIGH PRESSURE, LOW PRESSURE, HIGH TEMP, FAST LEAKAGE

The **FAST LEAKAGE** alert is a serious situation that could rapidly affect the stability of the vehicle. If this alert appears, pull over and investigate immediately.

The **HIGH TEMPERATURE** alert shows that the tyre is overheating.

If not corrected, this can cause permanent damage to the sidewall of the tyre and will potentially lead to a blowout or a fire.



Red Light Flash — ●

Sensor battery alert:



When a sensor battery needs replacing, a low sensor battery icon is shown, and the appropriate tyre icon flashes.

Monitor battery alert:

When fully charged, the monitor battery will operate for 60 hours (30 hours per day at 2 hours driving). When it needs charging, the monitor battery icon changes from full to part full. Connect the monitor to the vehicle power supply and the icon becomes animated while charging.



Fully charged



Requires charging

5.3 Backlight

The backlight turns on automatically when it gets dark if the vehicle is in motion. It turns off when it is light or when the monitor is in sleep mode. Press any button to turn the backlight on manually. To turn it off, press and hold the + button for 3 seconds.

5.4 Connecting and disconnecting a trailer

When the trailer is not connected to the vehicle, press the **LINK** and – buttons at the same time. Trailer monitoring stops and the trailer tyre icons are removed from the display. When the trailer is reconnected, press **LINK** and + buttons to display the trailer.


If you drive away from the trailer without unlinking the monitor, it may continue to show the last measured trailer tyre data for a period of time. After about 60 minutes it will stop displaying data for the trailer tyres and will give a short beep each time the trailer tyre position is accessed.

5.5 Replacing sensor batteries



When the sensor low battery icon is showing and a corresponding tyre icon is flashing, the sensor battery needs to be replaced. The battery is a CR1632 lithium cell, which is available from TyrePal Ltd.

1. Take the sensor off the tyre and use the hex key to completely remove the locking screw.
2. Use the sensor tools to remove the battery cover from the sensor and expose the battery.
3. Replace the CR1632 battery making sure the positive + side is upwards and that it goes inside the metal cage, not on top of it.
4. Check that the waterproof rubber seal is in position and replace the battery cover, using the sensor tool to replace the cover.



6. TESTING THE SETUP

To test the system, position the monitor in the driver's cab and unscrew the furthest sensor. The system should produce an alert for that tyre position. Tighten the sensor and the alert should stop.


If the alert is not given, the sensor may be out of range. The sensors have a transmission range of about 20 metres in open air, but in practice, screening by the vehicle chassis and bodywork reduce the working distance to about 7 metres. This can be increased by using the optional Smart Relay.

7. SMART RELAY (OPTIONAL EQUIPMENT)

The Smart Relay can either be used as a signal repeater to boost sensor signals from a single trailer, or in a fleet application, it can simplify exchanging trailers by storing the trailer settings. In this case, one is fitted to each trailer.

For rigid vehicles like motorhomes and buses, position the Smart Relay near the back of the vehicle. For caravans and trailers, position it near the front of the trailer, and with the antenna clear of metallic parts.

Fix it in place with screws through the lugs and connect it to the vehicle power supply (12 to 24V) with the red wire to + positive, and the black to - negative. The cable has an in-line 2A fuse.



7.1 Operation as a signal repeater

The Relay requires no programming to operate as a signal repeater. The red light stays on while power is connected and flashes while data is being transmitted or received.

8. TROUBLESHOOTING AND ADDITIONAL INFORMATION

Additional information about the system, including troubleshooting and advice on managing tyre pressures is provided on the TyrePal web site, www.tyrepal.co.uk, where it is regularly updated.

9. SPARES, SERVICE AND WARRANTY

Spare parts including batteries and replacement sensors are available to purchase from the TyrePal web site.

Please register your guarantee by completing details on our web site.

The system is warranted to be free from manufacturing defects and is guaranteed for a period of twelve months from date of purchase. There are no user-serviceable parts inside the monitor and if internal parts have been tampered with, the warranty may be void. The warranty does not affect your statutory rights.

8. SPECIFICATION SUMMARY

Specification is subject to change without notice.

Monitor

Dimensions	115 x 73 x 27mm, weight 132g.
Power	Powered by internal lithium battery recharged from vehicle power supply. Automatically shuts down when not in use and reactivates as vehicle is used. Charger input 12 to 24V dc.
Display	Clear LCD screen with automatic backlight. View size 80 x 40mm. Continuously cycles through all wheel positions and displays pressure and temperature for each tyre. Additional detail is displayed as required.
Alerts	Bright red flashing LED, plus audible alarm. Audible alarm can be silenced by pressing any button. Distinct alerts are given for the following conditions: <ul style="list-style-type: none">Fast leakage (puncture etc)Pressure below user-set thresholdPressure above user-set thresholdTemperature above user-set threshold (potential blowout) Warnings are also given if the sensor signal is lost, if a sensor battery is low or when the monitor battery needs recharging.
Units	User selected. Pressure: Bar or psi, Temperature: °C or °F

Sensors

Dimensions	Dimensions: 20.5 x 20.5mm (length x diameter). When fitted, they extend approx. 12mm beyond the length of the tyre valve. Weight 9g.
Power	Replaceable CR1632 cell, expected life up to 2 years
Pressure	0 to 6.8 bar ± 0.1 bar (0 to 99psi ± 1.5 psi)
Temperature	-40°C to 80°C ± 3 °C
Transmission	433.92MHz, power <10dBm
Range	Typically >7m in vehicle when screened by bodywork etc. Range can be extended with a Smart Relay.

TyrePal Limited,

Unit 2 Glen Industrial Estate, Essendine, Stamford, PE9 4LE. United Kingdom
Tel: +44 (0)1780 755490 e-mail: enquiries@tyrepal.co.uk www.tyrepal.co.uk

© TyrePal Ltd 2013

TC215B 20130831