

User Manual

IP68 Waterproof Indicator

GW



© Excell Precision Limited 2015. All rights reserved Worldwide.

The information contained herein is the property of Excell Precision Limited and is supplied without liability for errors or omissions. No part may be reproduced or used except as authorised by contract or other written permission. The copyright and the foregoing restriction on reproduction and use extend to all media in which the information may be embodied.



Table of Contents

SPECIAL NOTICE 2

BEFORE USING THE SCALE 3

INSTRUCTIONS FOR USE 3

PREPARING TO USE THE SCALE 3

CHAPTER 1 INTRODUCTION 5

 1-1 Product Features..... 5

 1-2 Specifications 5

 1-3 Product Appearance..... 6

 1-4 Display Description 7

 1-5 Power Supply 7

 1-6 Keypad Function 8

 1-7 Self-Test Mode 10

 1-8 Error Messages..... 11

 1-9 Weight Units..... 11

CHAPTER 2 CONFIGURATIONS..... 12

 2-1 General Function Setting 0 | Fnc 13

 2-1-1 Auto Backlight Function Setting Fnc 01 14

 2-1-2 Auto Power-off Timer Setting Fnc 02 15

 2-1-3 HI/LO/OK Settings Fnc 03 16

 2-1-4 Hold Function Settings Fnc 06 17

 2-1-5 Auto Unit Weight Averaging Setting Fnc 07 19

 2-1-6 Foot Switch Settings Fnc 11 (Option)..... 19

 2-1-7 [F] Key Function Settings Fnc 12 20

 2-2 RS232 Serial Interface Settings 03 r5 1 21

 2-2-1 Baud Rate Settings r5 1 01 22

 2-2-2 Communication Protocol Settings r5 1 02 23

 2-2-3 Output Format Settings r5 1 03 24

 2-2-4 Continuous Transmission Settings r5 1 04 27

 2-2-5 Selection of the Continuous Transmission Rate r5 1 05 28

 2-2-6 Auto Transmission at Zero r5 1 06 29

 2-2-7 Reset Auto Transmission r5 1 07 30

 2-2-8 Output Condition Settings r5 1 08 31

 2-2-9 RS232 6/7 Digits Setting r5 1 09 32

 2-2-10 RTC Adjustment r5 1 10 33

 2-2-11 Y/M/D Print Layout Selection r5 1 11 33

 2-2-12 RS485 ID Input (Option) r5 1 12 34

 2-2-13 Line Feed Input r5 1 13 34

CHAPTER 3 WIRELESS CONNECTION INSTRUCTION..... 35

APPENDIX 1 ASCII CODE TABLE 45

APPENDIX 2 7-SEGMENT DISPLAY CHARACTERS 46

APPENDIX 3 WIRING INSTRUCTIONS..... 47



Special Notice


While installing the load cell, power cord hookup or replacing a new rechargeable battery, the indicator housing must be opened. It must be done by a technician assigned by your electronic indicator provider to avoid affecting the waterproof ability of this indicator. Before opening the housing, make sure the indicator is dry, if there is any liquid on it, please wipe it with a clean cloth.

How to Install the Housing


After installing the load cell, power cord hookup or replacing a new rechargeable battery, the housing must be screwed by the assigned order as shown below. Screw lightly first, then screw them tight using a 6 kgf-cm torsion.

P.s. Please use a torsion-adjustable screw driver.

Screwing order:



How to Install U-Bracket



**M8 Recommended
SCREWS ARE NOT INCLUDED.**



Thank you for purchasing EXCELL WEIGHING INDICATOR, to help use the product properly, operate smoothly, and extend its life cycle, please read this manual carefully.


Before Using the Scale

In order to use this scale correctly, we suggest that you read this manual carefully.

Instructions for Use

1. The load placed on the weigh pan must NOT exceed the maximum weighing capacity of the scale.
2. Protect the scale from high temperatures.
3. Avoid objects impacting with the scale. Do not drop loads onto the scale or subject the weigh pan to any strong shock loads.

Preparing to Use the Scale

1. Locate the scale on a firm level surface free from vibrations for accurate weight readings.
2. Adjust the four levelling feet (if fitted) to set the scale pan level.
3. Avoid operating the scale in direct sunlight or drafts of any kind.
4. If possible avoid connecting the scale to ac power outlet sockets which are adjacent to other appliances to minimise the possibility of interference affecting the performance of the scale.
5. Remove any weight that might be on the weigh pan before the scale is switched on and avoid leaving weight on the pan for long periods of time.
6. All goods weighed should be placed in the centre of the weigh pan for accurate weighing. The overall dimensions of the goods being weighed should not exceed the dimension of the weigh pan.
7. Once the scale has been powered on, it will go through an LCD display test and it is ready for use when the display shows zero.
8. The scale requires 15~20 minutes warm up before operation to ensure best accuracy.
9. Please note when the  symbol keeps flashing on the screen, the batteries need to be recharged.
10. Introduction of Storage Battery




Due to the storage battery adopt the advanced free-maintaining technique, customers need not to replenish electrolyte.

The scale should be recharged every 3 months to prevent failure of the internal rechargeable battery.

1. The battery should be charged for 8~10 hours.
2. The temperature of battery should below 45°C.

Maintaining

1. Please do not discharge with over-current when using the battery. Please charge the battery after discharging current.
2. Please take down the battery when the scale is not used for a long time or break the connection of cathode.
3. Do not short the battery terminals to check whether there is current. Please check whether the connection point is firm to guarantee good connection.
4. The battery should be replaced by specialized person. **No reverse-battery or the product will be damaged.**
 - a) Anode of battery should be connected with Anode of product battery (usually red cable)
 - b) Cathode of battery should be connected with Cathode of product battery (usually brown cable or black cable)
 - c) See the picture following



Brown cable(or black cable) connected with Anode of battery

Red cable connected with Cathode of battery



Safety warnings

1. The electrolyte of battery is caustic which causes metal, cotton, etc to corrode.
2. The hydrogen will be resolved when using or charging the battery and it will cause explosion when approaches fire.



No burning



Caution Corrosion



Warning explosion



Children faraway



Chapter 1 Introduction

1-1 Product Features

- Extra-large and wide LCD display (175 x 70mm) 6 digits with 55mm height
- COOL WHITE LED backlight
- RS-232+RTC(Real Time Clock) interface
- IP 68: mist-proof, waterproof and dustproof
- Up to 1/15,000 display resolution
- Unit switch key for Kilogram (kg) and pound (lb), etc.
- Full range tare, Pre-tare, Auto zero tracking, Sampling counting, Gross/Net Indication
- Hold function, Check mode Lo / Hi / OK, Auto average unit weight, Animal scale function
- Low power indication and auto power off
- U shape stand or Sleeve connecting stand selectable.

Options


- Wireless for distance 100M available (SPP mode supported)
- Convenient foot switch for Zero, or Tare, or Print
- RS-232 / RS-485 data-transfer interface

1-2 Specifications


- **Operating temperature:** -10°C ~ 40°C
- **Power Source:** DC 6V / 4Ah rechargeable battery
- **Dimensions:** 238 x 156 x 90mm (W x H x D)
- **Display:** LCD, 6 Digits, 55 mm (Height), COOL LIGHT LED backlight




1-3 Product Appearance



[Standard]




[Option]





1-4 Display Description



HI	Upper limit
OK	Value between HI and LO
LO	Lower limit
kg	Unit "kilogram"
lb	Unit "pound"
t	hk tael
Pcs	Counting mode indication
→0←	Zero point indication
Net	Net weight indication
	Low Power indication

"▼" indications description	
▼ 1	(STABLE) stable indication
▼ 2	(GROSS) gross weight indication
▼ 3	() unit weight insufficient indication
▼ 4	(PT) pre-tare indication
▼ 5	(Hold) weight hold indication
▼ 6	"GN"、"dwt"、"carat"、"M+" unit indication
▼ 7	"oz" or "viss" unit indication (set as needed), or no unit indication

1-5 Power Supply

Power Supply Selection

- ① 230Vac ±15%, 50/60Hz, 10W (plugged-in)
- ② 6V / 4Ah rechargeable battery

Power Consumption

Approximately DC 31 mA (Indicator + Load Cell)
 Approximately DC 65 mA (Indicator + Load Cell + Display backlight)
 Approximately DC 80 mA (Indicator + Load Cell + Wireless 100M)
 Approximately DC 65 mA (Indicator + Load Cell + Wireless 10M)

Charging Voltage

DC 10V/1A

Low Battery Warning

Please note when the () symbol keeps flashing on the display, the internal battery should be recharged.

- ☞ The scale will turn off automatically after a few hours when the low battery warning symbol shows up. The scale must be fully charged, before operating again.
- ☞ When the battery status indication is full, the power is about 6.1V; Each block is about 0.2V; When the battery warning symbol shows up, the power is about 5.4V.



To clear totalization data, press M+ key to let display shows up totalization numbers, then press the **M+|PRINT** key again, to clear totalization data. RS232 will print out totalization numbers, total weight, etc.

P.s. Weight must return to net zero if to perform clear function.

F KEY

Function key (In **F** r **C** | **2**, select **F** key as “MC” or “HR”)

Foot Switch Mode

This function is optional. Use **F** r **C** | **1** to select **TARE|PT** key as “ZERO” or “PRINT” key

If “PRINT” key is set (r **5** | **03** = 10/11), all totalization data will be printed out, and totalization will be cleared.

If it is Brazil version and foot switch is set as Print function, it has totalization function and print function.

Simple Counting Mode

Use **UNIT** key to switch unit to Pcs, to go into simple counting mode.

1. Use **NET|GROSS** key to select a sample number from “10, 20, 50, 100, or 200”. Display will show **10**, **20**, **50**, **100**, **200** in an sequential order by pressing **NET|GROSS** key.

2. Select a sampling number, and put appropriate weight on platter, and press **UNIT** key.

Display will show “- - - - -”. The scale will go into counting mode after weight is stable, and display will show the sample number.

Unit weight insufficient ($\frac{5}{Pcs}$): Sample unit weight is **less** than 0.2d or total sample weight is **less** than 20d (d=division)

While sampling, if there is insufficient sample or unit weight insufficient indication “▼”, the scale is still usable, but there may be slight inaccuracy.


After Power-off, the scale automatically memorizes the sampling number, and it is available when “Pcs” unit is selected next time.

If the setting is “automatic average unit weight”, if the object on platter > the previous sampling number more than 5 pcs, and also < less than 100% the previous sampling number, the scale will execute unit weight calibration automatically.



1-7 Self-Test Mode

When power is off, hold **NET|GROSS** key and press **ON|OFF** key, Wait till display shows **01 AdC** to enter "Self-Test Mode".



01 AdC INTERNAL VALUE MODE (must hook up full-bridge Load Cell to test)

- ① Press **TARE|PT** key to enter, and the display shows internal value
- ② Please check the internal value is within normal range is 0 ~ 400000 (no load)
- ③ Check whether the backlight is on
- ④ Press **ZERO** key to back to the last screen, the display shows **01 AdC**

02 KEY KEYPAD TEST MODE

- ① Press **TARE|PT** key to enter, display shows **KEY 06**
Keypad's internal code: **TARE|PT** key = 06, **UNIT** key= 05, **F** key = 02
NET|GROSS key=04
- ② Press **ZERO** key to back to the last screen , the display shows **02 KEY**

03 Ver FIRMWARE VERSION DISPLAY MODE

- ① Press **TARE|PT** key to enter , display shows the firmware version **02005** ,
- ② Press **TARE|PT** key again, the display shows maintenance number **158** for 2 seconds
- ③ Press **ZERO** key to back to the last screen, display shows **03 Ver**

00 Esc BACK TO THE LAST SCREEN

Press **TARE|PT** key to exit self-test mode, the scale will re-power on automatically.



1-8 Error Messages

- E0 ⇒ The EEPROM is not working correctly.
The EEPROM is not set yet, or the circuit on PCB is broken.
- E1 ⇒ Zero is higher than the zero range when switching the indicator on.
- E2 ⇒ Zero is lower than the zero range when switching the indicator on.
- E4 ⇒ A/D value is unstable.
- OL ⇒ The weight of the object is over 9 divisions of the maximum capacity .
- OL ⇒ The weight of the object is under -1/6 maximum capacity.
- OF ⇒ ADIC value is over the maximum range.
- E10 ⇒ The scale is not in level status.
(Only available with level detector equipped)

1-9 Weight Units

kg	1 g = 0.001 kg
g	1 g = 1 g
lb	1 g = 0.002204623 lb
lb/oz	1 g = 0.03527396 oz
oz	1 g = 0.03527396 oz
GN	1 g = 15.432358 GN
dwt	1 g = 0.6430149 dwt
ct	1 g = 5 ct
hk.tael	1 g = 0.02645546 Hk.catty
viss	1kg = 0.612245 viss




Chapter 2 Configurations

Configuration Workflow

In the weighing mode, press **NET|GROSS** key and **ZERO** keys at the same time to enter the configuration mode.

The LCD shows **01 Fnc**.

Overall workflow of the Advanced Function setting mode:




- 01 Fnc ⇒ General Function Setting Mode
- 02 EC ⇒ Reserved
- 03 r51 ⇒ RS232 Bi-direction Function Setting
- 00 ESC ⇒ Exit the Advanced Function Setting Mode

Refer to the following sections for the detailed operation procedures of each function setting.



2-1 General Function Setting 01 Fnc

Workflow of the General Function setting:




Fnc 00	⇒ Return to the Advanced Function Setting Mode Menu
Fnc 01	⇒ Automatic Backlight Function Settings
Fnc 02	⇒ Automatic Power-off Timer Settings
Fnc 03	⇒ Hi/Lo/OK Settings
Fnc 04	⇒ Reserved
Fnc 05	⇒ Reserved
Fnc 06	⇒ Hold Function Settings
Fnc 07	⇒ Auto Unit Weight Averaging Setting
Fnc 08	⇒ Reserved
Fnc 09	⇒ Reserved
Fnc 10	⇒ Reserved
Fnc 11	⇒ Foot switch on/off settings (Option)
Fnc 12	⇒ F key function settings
Fnc 13	⇒ Reserved



2-1-1 Auto Backlight Function Setting F_nC 0 1

Select F_nC 0 1 in the general function setting mode 0 1 F_nC to change the backlight function setting.



- ZERO** key ⇒ Upward key (0~9 digit entry)
- UNIT** key ⇒ Downward key (0~9 digit entry)
- TARE|PT** key ⇒ Move cursor rightward
- NET|GROSS** key ⇒ Move cursor leftward


Auto backlight function

When the weight is over 10d, the display backlight will be on. After the weight is stable for 10 seconds or when the scale returns to zero, the display backlight switches off.



2-1-2 Auto Power-off Timer Setting F_nC 02

Select F_nC 02 in the general function setting mode 0 | F_nC to change the automatic power-off timer setting.



- ZERO** key ⇒ Upward key (0~9 digit entry)
- UNIT** key ⇒ Downward key (0~9 digit entry)
- TARE|PT** key ⇒ Move cursor rightward
- NET|GROSS** key ⇒ Move cursor leftward

Auto power-off function


When the weight on weigh pan is less than 10d or keeps idle for the set time, the scale will automatically switch off.



2-1-3 HI/LO/OK Settings F_nC 03

Select F_nC 03 in the general function setting mode 0 | F_nC to set the HI/LO/OK function.

☞ When the high limit and low limit are both set as “0”, the Hi/Lo/OK function is disabled.




- ZERO** key ⇒ Upward key (0~9 digit entry)
- UNIT** key ⇒ Downward key (0~9 digit entry)
- TARE|PT** key ⇒ Move cursor rightward
- NET|GROSS** key ⇒ Move cursor leftward



2-1-4 Hold Function Settings F_nC 06

For OIML or NTEP approval models, F_nC 06 setting cannot be changed, and hold=0




ZERO key ⇒ Upward key (0~9 digit entry)
UNIT key ⇒ Downward key (0~9 digit entry)
TARE|PT key ⇒ Move cursor rightward
NET|GROSS key ⇒ Move cursor leftward

hold 0 = Hold function disabled
hold 1 = “Peak hold” mode
 The scale keeps displaying the maximum weight when the weight is continually changing. Press any key to exit this mode.
hold 2 = “Stable hold 1” mode
 When the weight is stable, the LCD shows the current weight value. Press any key to exit this mode.
hold 3 = “Stable hold 2” mode
 When the weight is stable, the LCD shows the current weight value. When the weight returns to zero (<10d), the hold mode is cancelled automatically.
hold 4 = “Animal scale hold” mode
 When the scale returns back to zero, the display shows “ - - - - - ”. After the animal or object is on the platter and the scale becomes stable, the display shows the weight value and hold. Then when the animal or object is off the platter, the display shows “ - - - - - ” (or the weight is less than 10e) and the hold function is off. If the scale is hardly stable when the animal is on the platter, the scale shows the average weight in 10 seconds and holds the status.




Hold Function Setting (Animal scale) hold 4



[ZERO] key ⇒ Upward key (0~9 digit entry)
[UNIT] key ⇒ Downward key (0~9 digit entry)
[TARE|PT] key ⇒ Move cursor rightward
[NET|GROSS] key ⇒ Move cursor leftward



2-1-5 Auto Unit Weight Averaging Setting F_nC 07




Auto unit weight averaging setting
LCD displays the last parameter setting

Auto unit weight averaging setting
Use **ZERO** or **UNIT** keys to key in the parameters

- Default setting = 0
- 0 ⇒ Auto unit weight averaging
- 1 ⇒ Non auto unit weight averaging

- ZERO** key ⇒ Upward key (0~9 digit entry)
- UNIT** key ⇒ Downward key (0~9 digit entry)
- TARE|PT** key ⇒ Move cursor rightward
- NET|GROSS** key ⇒ Move cursor leftward

2-1-6 Foot Switch Settings F_nC 11 (Option)



Foot switch on "ZERO" function
Display shows parameter from the previous setup


Foot switch on "TARE" function

Foot switch on "PRINT" function
RS232 print out data sent from pressing **M+** key
If it is Brazil version and r5104 = r_PLUB, the format is r5103 format and it has totalization function.

- ZERO** key ⇒ Upward key (0~9 digit entry)
- UNIT** key ⇒ Downward key (0~9 digit entry)
- TARE|PT** key ⇒ Move cursor rightward
- NET|GROSS** key ⇒ Move cursor leftward




2-1-7 **F** Key Function Settings F_nC 12





2-2 RS232 Serial Interface Settings 03 r5 1




- r5 1 00 ⇒ Exit the RS232 Serial Interface Setting Mode
- r5 1 01 ⇒ Baud Rate Settings
- r5 1 02 ⇒ Communication Protocol Settings
- r5 1 03 ⇒ Output Format Settings
- r5 1 04 ⇒ Transmission method setup
- r5 1 05 ⇒ The Selection of Continuous Transmission Rate
- r5 1 06 ⇒ Auto Transmission at Zero
- r5 1 07 ⇒ Reset of Auto Transmission
- r5 1 08 ⇒ Output Condition Settings
- r5 1 09 ⇒ RS232 6/7 digits setting
- r5 1 10 ⇒ RTC adjustment
- r5 1 11 ⇒ Y/M/D Print Format Selection
- r5 1 12 ⇒ RS485 ID Input (Option)
- r5 1 13 ⇒ Line Feed Input



2-2-1 Baud Rate Settings r 5 | 0 |


Select r 5 | 0 | in the RS232 serial interface setting mode 03 r 5 | to set the Baud Rate.





2-2-2 Communication Protocol Settings r5 1 02

Select r5 1 02 in the RS232 serial interface setting mode 03 r5 1 to set the Communication Protocol.




- ZERO** key ⇒ Upward key (0~9 digit entry)
- UNIT** key ⇒ Downward key (0~9 digit entry)
- TARE|PT** key ⇒ Move cursor rightward
- NET|GROSS** key ⇒ Move cursor leftward



2-2-3 Output Format Settings r 5 | 03

Select r 5 | 03 in the RS232 serial interface setting mode 03 r 5 | to set the Output Format.



RS232 output format setting
 LCD shows the last setting.
 ➤ Default setting: F - n 0

RS232 output format setting
 Use **ZERO** or **UNIT** keys to select the output format:

- F - n 0 = Same data as the scale
- F - n 1 = Gross weight
- F - n 2 = Net weight
- F - n 3 = Same data as the scale in simple format
- F - n 4 = Same gross data as the scale in simple format
- F - n 5 = Same net data as the scale in simple format
- F - n 6 = Hi/Lo/OK status + Same data as the scale in simple format
- F - n 7 = Hi/Lo/OK status + Simple gross weight
- F - n 8 = Hi/Lo/OK status + Simple net weight
- F - n 9 = Tare value
- F - n 10 = **M+** Transmission 1 note 1
- F - n 11 = **M+** Transmission 2 note 2
- F - n 12 = Brazil printing format note 3
- F - n 13 = Brazil printing format note 4
- F - n 14 = Brazil printing format note 5

📄 Format 12.13.14 are only for Brazil
 Format 10.11 are not available on counting mode

ZERO key ⇒ Upward key (0~9 digit entry)
UNIT key ⇒ Downward key (0~9 digit entry)
TARE|PT key ⇒ Move cursor rightward
NET|GROSS key ⇒ Move cursor leftward



For example:

tare 0.2kg, net weight 1key, press M+

FR"IRWT3000"

?

1,200

0,200

1,000

1,000

1

30/05/00

00:54:12

001,000000,200001,000000001

P1,1

Note5:

If it is not Brazil version, it only can print under continuous transmission.

If it is Brazil version, under decimal units mode, $F_n \square 11 = P_n$ net and $r \square 1 \square 4 = \bar{r}_n$ P_{net}, it can print out. It is not available on counting mode.

Transformat as followed:

S,GGG .GGG ,TTT .TTT,NNN.NNN

S = 0:stable 1: unstable

G = gross weight

T = tare + pre-tare

N = net weight

For example:

tare 1 kg, net weight 0.2key, gross weight 1.2 kg , stable, then show as followed:

0,001.200,001.000,000.200


Take off the weight then show as followed:

0,000.000,001.000,-01.000



2-2-4 Continuous Transmission Settings r5 | 04

Select r5 | 04 in the RS232 serial interface setting mode 03 r5 | to set the Continuous Transmission status.




ZERO key ⇒ Upward key (0~9 digit entry)
UNIT key ⇒ Downward key (0~9 digit entry)
TARE|PT key ⇒ Move cursor rightward
NET|GROSS key ⇒ Move cursor leftward



2-2-5 Selection of the Continuous Transmission Rate r 5 1 0 5

Select r 5 1 0 5 in the RS232 serial interface setting mode 0 3 r 5 1 to set the Continuous Transmission Rate.




- ZERO** key ⇒ Upward key (0~9 digit entry)
- UNIT** key ⇒ Downward key (0~9 digit entry)
- TARE|PT** key ⇒ Move cursor rightward
- NET|GROSS** key ⇒ Move cursor leftward



2-2-6 Auto Transmission at Zero r 5 | 0 6

Select r 5 | 0 6 in the RS232 serial interface setting mode 0 3 r 5 | to set the Auto Transmission at Zero.




☞ When the value of "Auto transmission at zero" set as 0 - b 0 0, the "Auto transmission at zero" function is not available. Because when the scale is at zero and keeping stable, the data are keeping transmitted, and that would be the same as "Continuous Transmission".



2-2-7 Reset Auto Transmission $r\bar{5} | 0\bar{7}$

Select $r\bar{5} | 0\bar{7}$ in the RS232 serial interface setting mode $0\bar{3} | r\bar{5} |$ to Reset Auto Transmission.



☰ When the value of "Auto transmission at zero" set as $0-b\ 00$, the "Auto transmission at zero" function is not available. Because when the scale is at zero and keeping stable, the data are keeping transmitted, and that would be the same as "Continuous Transmission".



2-2-8 Output Condition Settings r 5 1 0 8

Select r 5 1 0 8 in the RS232 serial interface setting mode 0 3 r 5 1 to Reset of Auto Transmission.

r 5 1 0 8

Press **TARE|PT** key

Stb-P

Output condition settings
The LCD shows the last setting.

➤ Default setting: Stb-P

Use **ZERO** or **UNIT** keys to select the desired setting

ALL-P

Output condition settings

Use **ZERO** or **UNIT** keys to select the desired setting:

ALL-P = All output

Stb-P = Stable output

(No output when OL or unstable)

Press **TARE|PT** key

r 5 1 0 8

StoL-P = Stable output

(OL included)

Key in the parameter "00"

r 5 1 0 0

Press **TARE|PT** key to exit RS232 2-way serial interface settings

0 3 r 5 1

ZERO key ⇒ Upward key (0~9 digit entry)

UNIT key ⇒ Downward key (0~9 digit entry)


TARE|PT key ⇒ Move cursor rightward

NET|GROSS key ⇒ Move cursor leftward



2-2-9 RS232 6/7 Digits Setting r5 1 09




Select r5 1 09 in the RS232 serial interface setting mode 03 r5 1 to Reset of Auto Transmission.




- ZERO** key ⇒ Upward key (0~9 digit entry)
- UNIT** key ⇒ Downward key (0~9 digit entry)
- TARE|PT** key ⇒ Move cursor rightward
- NET|GROSS** key ⇒ Move cursor leftward





2-2-10 RTC Adjustment

Select  in the RS232 serial interface setting mode   to reset of Auto Transmission.



2-2-11 Y/M/D Print Layout Selection


Select  in the RS232 serial interface setting mode   to reset of Auto Transmission.






2-2-12 RS485 ID Input (Option) r5 | 12

Select r5 | 12 in the RS232 serial interface setting mode 03 r5 | to reset of Auto Transmission.



2-2-13 Line Feed Input r5 | 13


Line feed would be available only when r5 | 03 was set as 10 or 11.






Chapter 3 Wireless Connection Instruction

Step 1: Connect to your device

1. Enable Wireless on your computer. Right-click on the  icon of the bottom-right corner on taskbar, highlight **“New Connection”** and left click.



Due to the different bluetooth supplier software could be installed, the setting dialogs shown below are just for reference.

2. Check **“My device is set up and ready to be found”** in the dialogue box.






3. If the device is ready, the device names **Device-C1** or **C2** will be found. Double-click on Device-C1 or Device-C2.



4. Circle “**Let me choose my own passkey**”, input the passkey “111111” and click “**Next >**” button






5. Device is added so far. Please disconnect COM port and click “**Finish.**”



Step 2: Connection test


To test the connection, use **HyperTerminal** recommended in Windows XP

1. go “**START**” → “**All programs**” → “**Accessories**” → “**Communications**” → “**HyperTerminal**”





2. Key in a name and select icon, then press “OK.”




3. After select the COM port referred by step 1 point 5 and click “OK.”






4. Click “File” → “Properties”




5. Select “settings” from the menu, and click “ASCII setup” on the bottom of the box.





6. Check “**S**end line ends with line feeds” and “**E**cho typed characters locally” and click “**OK**”.



7. Key in commands such **RW**, **MZ**, and **RG** in the main screen to test...



☒ Command Mode

On RS485 command mode, the format is as following,

1. If RS485's ID setting is 0(RS1 12), and the command is the same as regular RS232.
2. A. If RS485's ID setting is not 0(assume 99), "@ID" has to be added in front of every command. If you wish to command a zero-return, the complete command is @99MZY, then press "ENTER" key

B. If there is an error on entered command, letter "E" will show up + "Unidentified Command"

e.g. @99MZZ

The response message is => 99E1MZZ

3. RS485 responses only to machines of identified ID code

Command Format A

Host	Command
Slave	Command

MZ	Zero	SO	Command mode
MT	Tare	UA	Switch to the first unit
MG	Gross weight	UB	Switch to the second unit
MN	Net weight	UC	Switch to the third unit
CT	Clear TARE value	UD	Switch to the forth unit
SC	Continuous transmission	UE	Switch to the fifth unit
SA	Auto transmission	UF	Switch to the sixth unit
%	Stop continuous transmission and enter the command mode		

Note: UA ~ UF settings are depended on the model of the scale

Command Format B

Host	Command
Slave	Data

RW	Read current weight	RH	Read Gross (simple)
RG	Read Gross weight	RI	Read Net (simple)
RN	Read Net weight	RJ	Read comparison situation + current display of weight (simple)
RT	Read TARE	RK	Read comparison situation + Gross (simple)
RB	Read current display of weight (simple)	RL	Read comparison situation + Net (simple)

- Note:**
- a. add % before the command to read continuously
 - b. add # before the command to transmit a stable value

RJ,RK,RL Command Description

If RL command entered, and

if weight is higher than HI (FNC 03 setting), and if the current weight is 10 kg, the following will be displayed: "100+ 10.000"

If weight is higher than HI (FNC 03 setting), and if the current weight is 0.5 kg, the following will be displayed: "001+ 0.500"

If weight is between HI and LOW, and if the current weight is 1 kg, the following will be displayed: 010+ 1.000



Output data format

1. 7 places (first decimal place not included)

Weight format

Gross	S	T	,	G	S	,	+	0	1	2	3	4	5	6	7	SP	SP	o	z	CR	LF
Net	S	T	,	N	T	,	+	1	.	2	3	.	4	5	6	t	l	.	g		
Tare	S	T	,	T	R	,	+	0	1	2	.	3	4	5	6	SP	SP	k	g		
Plus OL	O	L	,	G	S	,	+	SP	SP	SP	SP	SP	SP	SP	SP	SP	SP	SP	SP		
Minus OL	O	L	,	G	S	,	-	SP	SP	SP	SP	SP	SP	SP	SP	SP	SP	SP	SP		
Unstable	U	S	,	G	S	,	+	0	1	2	3	4	.	5	6	SP	SP	l	b		

Simple format

G/N	+	1	.	2	3	.	4	5	6	CR	LF
G/N	+	0	1	2	3	4	5	.	6		
G/N	+	0	1	2	.	3	4	5	6		
Plus OL	+	SP	SP	SP	SP	SP	SP	SP	SP		
Minus OL	-	SP	SP	SP	SP	SP	SP	SP	SP		

Comparison status + Simple format

Byte0	Byte1	Byte2	+/-	1	.	2	3	.	4	5	6	CR	LF
-------	-------	-------	-----	---	---	---	---	---	---	---	---	----	----

Byte0 : HI 30H/31H

Byte1 : OK 30H/31H

Byte2 : LO 30H/31H

2. 6 places (first decimal place not included)

Weight format

Gross	S	T	,	G	S	,	+	1	2	3	4	5	6	7	SP	SP	o	z	CR	LF
Net	S	T	,	N	T	,	+	.	2	3	.	4	5	6	t	l	.	g		
Tare	S	T	,	T	R	,	+	1	2	.	3	4	5	6	SP	SP	k	g		
Plus OL	O	L	,	G	S	,	+	SP	SP	SP	SP	SP	SP	SP	SP	SP	SP	SP		
Minus OL	O	L	,	G	S	,	-	SP	SP	SP	SP	SP	SP	SP	SP	SP	SP	SP		
Unstable	U	S	,	G	S	,	+	1	2	3	4	.	5	6	SP	SP	l	b		

Simple format

G/N	+	.	2	3	.	4	5	6	CR	LF
G/N	+	1	2	3	4	5	.	6		
G/N	+	1	2	.	3	4	5	6		
Plus OL	+	SP	SP	SP	SP	SP	SP	SP		
Minus OL	-	SP	SP	SP	SP	SP	SP	SP		

Comparison status + simple format

Byte0	Byte1	Byte2	+/-	.	2	3	.	4	5	6	CR	LF
-------	-------	-------	-----	---	---	---	---	---	---	---	----	----




Byte0 : HI 30H/31H

Byte1 : OK 30H/31H

Byte2 : LO 30H/31H



Serial Data Transfer/Receive Format



Note:

S : Start bit

STOP: Stop bit

P : Parity bit



Appendix 1 ASCII Code Table

Symbol	ASC II Code	Symbol	ASC II Code	Symbol	ASC II Code
A	41H	a	61H	0	30H
B	42H	b	62H	1	31H
C	43H	c	63H	2	32H
D	44H	d	64H	3	33H
E	45H	e	65H	4	34H
F	46H	f	66H	5	35H
G	47H	g	67H	6	36H
H	48H	h	68H	7	37H
I	49H	i	69H	8	38H
J	4AH	j	6AH	9	39H
K	4BH	k	6BH	↵	0DH
L	4CH	l	6CH		
M	4DH	m	6DH		
N	4EH	n	6EH		
O	4FH	o	6FH		
P	50H	p	70H		
Q	51H	q	71H		
R	52H	r	72H		
S	53H	s	73H		
T	54H	t	74H		
U	55H	u	75H		
V	56H	v	76H		
W	57H	w	77H		
X	58H	x	78H		
Y	59H	y	79H		
Z	5AH	z	7AH		



Appendix 2 7-Segment Display Characters


Digit	7 segment letter	Alphabet	7 segment letter	Alphabet	7 segment letter
0		A		N	
1		B		O	
2		C		P	
3		D		Q	
4		E		R	
5		F		S	
6		G		T	
7		H		U	
8		I		V	
9		J		W	
		K		X	
		L		Y	
		M		Z	




Appendix 3 Wiring Instructions

Load cell wiring method

- (1) As shown below, when a load cell is connected with a 4PIN cable, SEN+ and SEN- can be unconnected. J11 and J12 on PCB must be tin-soldered in short circuit.






- (2) If Load Cell is 6PIN, please wire as the following diagram:








RS232 wiring instruction




To connect RS232, please open the housing, RS232's PIN connectors locate on the bottom-right corner of the main board. The most common connection method is using 9PIN and 25PIN, as shown below:




PC	PIN	Function	Female 9 PINS	Function	GW
	2	Transmit Data		SG	
	3	Receive Data		RxD	
	5	Signal Ground		TxD	

Printer	PIN	Function	Male 25 PINS	Function	GW
	2	Receive Data		SG	
	3	Transmit Data		RxD	
	7	Signal Ground		TxD	

RS485 wiring instruction

To connect RS485, please make J17, J18 short and J15, J16 open on main board.

PC	PIN	Function	Female 9 PINS	Function	GW
	2	Transmit Data		SG	
	3	Receive Data		DA	
	5	Signal Ground		DB	

Printer	PIN	Function	Male 25 PINS	Function	GW
	2	Receive Data		SG	
	3	Transmit Data		DA	
	7	Signal Ground		DB	

To use other connection methods, please identify the signal and following the above principles. After it is finished, please install the housing by the instruction in the *SPECIAL NOTICE*.