

# Hydro MPC

Service instructions





# English (GB) Service instructions

Original service instructions.

## CONTENTS

	Page
<b>1. Symbols used in this document</b>	3
<b>2. Identification</b>	3
2.1 Nameplate	3
2.2 Nameplate, IO 351	4
2.3 Nameplate, CU 352	4
2.4 Configuration file label	5
<b>3. Technical data</b>	<b>5</b>
3.1 Pressures	5
3.2 Temperatures	5
3.3 Relative air humidity	5
3.4 Sound pressure level	5
<b>4. CU 352 and IO 351</b>	<b>6</b>
4.1 Functions of terminals, CU 352	6
4.2 Functions of terminals, IO 351A and IO 351B	7
<b>5. Fault correction tools</b>	<b>26</b>
5.1 MPC/CU 352 indicator lights and alarm relay	26
5.2 MPC display	26
5.3 R100 and Grundfos GO Remote	30
<b>6. Factory configuration of Hydro MPC</b>	<b>30</b>
6.1 Necessary equipment	30
6.2 Factory configuration of Hydro MPC	30
<b>7. Danfoss frequency converters</b>	<b>37</b>
<b>8. CUE</b>	<b>37</b>
<b>9. MGE</b>	<b>37</b>
<b>10. Disposal</b>	<b>37</b>

### Warning

Prior to service work, read these service instructions carefully. Installation and service work must comply with local regulations and accepted codes of good practice.

Observe the safety instructions in the installation and operating instructions for the product.

## 1. Symbols used in this document



### Warning

If these safety instructions are not observed, it may result in personal injury.

**Note**

Notes or instructions that make the job easier and ensure safe operation.


## 2. Identification

This section shows the nameplate, the type key and the codes that can appear in the variant code.

**Note**

As codes can be combined, a code position may contain more than one code (letter).

### 2.1 Nameplate



TM03 1741 3105

Fig. 1 Nameplate, booster system

### Pos. Description

1	Type designation
2	Model
3	Serial number
4	Supply voltage
5	Maximum operating pressure [bar]
6	Liquid temperature [°C]
7	Maximum flow rate [m³/h]
8	Minimum head [m]
9	Number of mains-operated pumps
10	Motor power [kW] for mains-operated pumps
11	Rated voltage [V] for mains-operated pumps
12	Number of pumps with frequency converter
13	Motor power [kW] for pumps with frequency converter
14	Rated voltage [V] for pumps with frequency converter
15	Number of pilot pumps
16	Motor power [kW] for pilot pump
17	Rated voltage [V] for pilot pump
18	Order number
19-24	Options
25	Enclosure class
26	Weight [kg]
27	CE mark
28	Country of origin

**Type key****Example**

Hydro MPC -E /G /NS 3 CRIE 5-8 \* 3 x 380-415 V, 50/60 Hz, N, PE

**Type range****Control variants**

- E: Pumps with integrated frequency converter (0.37 - 22 kW)
- E: Pumps connected to a Grundfos CUE frequency converter (30 kW and up), one per pump
- F: Pumps connected to one Grundfos CUE frequency converter
- S: Mains-operated pumps (start/stop)

**Manifold material**

Stainless steel

/G: Galvanised steel

/OM: Other materials



**Suction manifold**

With suction manifold

/NS: Without suction manifold

**Number of pumps with integrated frequency converter and pump type****Number of mains-operated pumps and pump type****Supply voltage, frequency**


\* Code for custom-built solution.

**2.2 Nameplate, IO 351****Fig. 2** Nameplate, IO 351A**Fig. 3** Nameplate, IO 351B**Pos. Description**

1	Type designation
2	Product and version numbers
3	Permissible supply voltage, frequency and maximum power consumption
4	Production code (year, week)
5	Serial number

**Type key**

Code	Meaning	IO	3	5	1	B
IO	Input-output module					
35	Controller series					
1	Model number					
A	For pumps with fixed speed					
	For pumps with fixed speed and pumps in F-systems					
B	controlled by external frequency converters or the CUE, or as input-output module					

**2.3 Nameplate, CU 352****Fig. 4** Nameplate, CU 352**Pos. Description**

1	Type designation
2	Product and version numbers
3	Serial number
4	Production code (year, week)
5	Rated voltage, frequency and power


**Type key**

Code	Meaning	CU	3	5	2	O
CU	Control unit					
35	Controller series					
2	Model number					
O	For panel mounting					

## 2.4 Configuration file label

The configuration file label shows the configuration file numbers programmed in the CU 352.

See section 6. *Factory configuration of Hydro MPC*.



TM03 1742 3105

**Fig. 5 Configuration file label**

Pos.	Description
1	Control MPC - GSC file
2	Control MPC options - GSC files
3	Hydro MPC - GSC file
4	Hydro MPC options - GSC files
5	Pump data - GSC files
6	Pilot pump data - GSC files
7	Service contact information - GSC files

**Note** A GSC (Grundfos Standard Configuration) file is a configuration data file.

## 3. Technical data

### 3.1 Pressures

#### Inlet pressure

Hydro MPC booster systems can operate with a positive inlet pressure (precharged pressure system) or with a negative inlet pressure (vacuum at the suction manifold).

We recommend to calculate the inlet pressure in these cases:

- Water is drawn through long pipes.
- Water is drawn from depths.
- Inlet conditions are poor.

*In this manual, the term "inlet pressure" is defined as the pressure/vacuum which can be measured immediately before the booster system.*

To avoid cavitation, make sure that there is a minimum inlet pressure on the suction side of the booster system. The minimum inlet pressure in bar can be calculated as follows:

$$p_s > H_v + \rho \times g \times 10^{-5} \times NPSH + H_s - P_b$$

$p_s$  = The required minimum inlet pressure in bar read from a pressure gauge on the suction side of the booster system.

$H_v$  = Vapour pressure of the pumped liquid in bar.

$\rho$  = Density of the pumped liquid in kg/m<sup>3</sup>.

$g$  = Gravitational acceleration in m/s<sup>2</sup>.

NPSH = Net Positive Suction Head in metres head.

NPSH can be read from the NPSH curve at the maximum performance at which the pump will run. See installation and operating instructions for CR, CRI, CRN.

$H_s$  = Safety margin = minimum 0.1 bar.

$P_b$  = Barometric pressure in bar.  
Normal barometric pressure is 1.013 bar.

#### Maximum inlet pressure

See the CR, CRI, CRN installation and operating instructions (96462123) delivered together with this booster system.

#### Operating pressure

As standard, the maximum operating pressure is 16 bar.

Hydro MPC booster systems with a maximum operating pressure higher than 16 bar are available on request.

### 3.2 Temperatures

Liquid temperature: 0 °C to +60 °C.

Ambient temperature: 0 °C to +40 °C.

### 3.3 Relative air humidity

Maximum relative air humidity: 95 %.

### 3.4 Sound pressure level

For sound pressure level, see the installation and operating instructions for the CR pumps.

The sound pressure level for a number of pumps can be calculated as follows:

$$L_{max.} = L_{pump} + (n - 1) \times 3$$


$L_{max.}$  = Maximum sound pressure level

$L_{pump}$  = Sound pressure level of one pump

$n$  = Number of pumps

## 4. CU 352 and IO 351

### 4.1 Functions of terminals, CU 352



**Fig. 6** Functions of terminals, CU 352

#### Hydro MPC default settings

Pos.	Default settings
1	External start/stop
2	Water shortage, pressure/level switch
3	Discharge pressure
4	Inlet pressure (disabled if no sensor is connected)
5	Configurable analog input (disabled if no sensor is connected)
6	PC Tool connection, TTL
7	Ethernet connection
8	PC Tool connection, USB
9	Optional CIM card

## 4.2 Functions of terminals, IO 351A and IO 351B

### 4.2.1 IO 351A




TM04 0220 5107

**Fig. 7** Terminal groups

The module can be divided into these groups:

Group 1:	Connection of power supply
Group 2:	Digital outputs 1-3
Groups 3A, 3C:	Digital inputs GENIbus
Group 4A:	Inputs for PTC sensor or thermal switch

### 4.2.2 IO 351B



TM03 2110 3705

**Fig. 8** Terminal groups

The module can be divided into these groups:

Group 1:	Connection of power supply
Group 2:	Digital outputs 1-3
	Digital inputs
Groups 3A, 3B, 3C:	Analog inputs and outputs GENIbus
Groups 4A, 4B:	Inputs for PTC sensor or thermal switch
Group 5:	Digital outputs 4-7

### 4.2.3 Overview of inputs and outputs of modules

Type	Pump module A	Pump module B	IO module B
Analog input	Not used	Not used	2
Analog output	-	3	Not used
Digital input	3	9	9
PTC input	3	6	Not used
Digital output	3	7	7

The table below shows the modules and the GENIbus number of the individual system types.

System type and number of pumps	Module required in addition to the CU 352	GENIbus number
E	-	-
ES up to four pumps	A	31
ES five or six pumps	B	31
ED up to five pumps	A	31
ED six pumps	B	31
EDF up to six pumps	B	31
EF up to three pumps	B	31
EF four to six pumps	B + B	31 + 32
F up to three pumps	B	31
F four to six pumps	B + B	31 + 32
S up to three pumps	A	31
S four to six pumps	B	31
	General module	41
	Operating light module	41
	General module + operating light module	41 + 42

## 4.2.4 System type and IO module variants

System type	Maximum number of pumps	Controller/module	GENIbus address		Pump number					
			Module	E-pump	1	2	3	4	5	6
E	6	CU 352		1-6	E <sup>1</sup>	E <sup>1</sup>	E <sup>1</sup>	E <sup>1</sup>	E <sup>1</sup>	E <sup>1</sup>
	4	CU 352	-	1	E <sup>1</sup>	-	-	-	-	-
	ES	IO 351A	31	-	-	S <sup>2</sup>	S <sup>2</sup>	S <sup>2</sup>	-	-
	6	CU 352	-	1	E <sup>1</sup>	-	-	-	-	-
ED	5	IO 351B	31	-	-	S <sup>2</sup>	S <sup>2</sup>	S <sup>2</sup>	S <sup>2</sup>	S <sup>2</sup>
	6	CU 352	-	1-2	E <sup>1</sup>	E <sup>1</sup>	-	-	-	-
	EDF	IO 351A	31	-	-	S <sup>2</sup>	S <sup>2</sup>	S <sup>2</sup>	S <sup>2</sup>	-
	6	IO 351B	31	-	-	-	-	-	-	-
EF	6	CU 352	-	-	-	-	-	-	-	-
	EF	IO 351B	31	-	EF <sup>3</sup>	EF <sup>3</sup>	EF <sup>3</sup>	-	-	-
	6	IO 351B	32	-	-	-	-	EF <sup>3</sup>	EF <sup>3</sup>	EF <sup>3</sup>
	EF	IO 351B	32	-	F/S <sup>4</sup>	F/S <sup>4</sup>	F/S <sup>4</sup>	-	-	-
F	6	CU 352	-	-	-	-	-	-	-	-
	F	IO 351B	31	-	-	-	-	-	-	-
	6	IO 351B	32	-	-	-	-	F/S <sup>4</sup>	F/S <sup>4</sup>	F/S <sup>4</sup>
	F	IO 351A	31	-	S <sup>2</sup>	S <sup>2</sup>	S <sup>2</sup>	-	-	-
S	3	CU 352	-	-	-	-	-	-	-	-
	S	IO 351A	31	-	S <sup>2</sup>	S <sup>2</sup>	S <sup>2</sup>	-	-	-
	6	CU 352	-	-	-	-	-	-	-	-
	S	IO 351B	31	-	S <sup>2</sup>	S <sup>2</sup>	S <sup>2</sup>	S <sup>2</sup>	S <sup>2</sup>	S <sup>2</sup>
<b>Accessory</b>			IO 351B	41 <sup>5</sup>						
All			2 x IO 351B	41, 42 <sup>6</sup>	-	Data exchange, for instance to a PLC				

<sup>1</sup> E = 0.37 to 22 kW are E-pumps with integrated frequency converter.

30 to 55 kW are variable-speed pumps controlled by Grundfos CUE frequency converters.

<sup>2</sup> S = Mains-operated pump.

<sup>3</sup> EF = Variable-speed pump controlled by an external frequency converter (not CUE).

<sup>4</sup> F/S = Mains-operated pump or variable-speed pump controlled via a common frequency converter.

<sup>5</sup> Interface module or operating module.

<sup>6</sup> Interface module and operating module.

#### 4.2.5 Internal and external connections

This section shows the internal and external connections.  
The section is split up according to the various system types.

Abbreviations used:

DI: Digital input

DO: Digital output

AO: Analog output

AI: Analog input




C: Common.

#### E systems, CU 352

Group	Terminal	Designation	Data	Diagram
1	L	Connection to phase conductor		CU 352 L-L N-N ⊕-PE
	N	Connection to neutral conductor	1 x 100-240 VAC ± 10 %, 50/60 Hz	
	PE	Connection to protective earth		
2	A1	RS-485 A		CU 352 IO 351 A1 - A Y1 - Y B1 - B — - —
	Y1	RS-485 GND	GENIbus (Fix the screen with a cable clamp.)	
	B1	RS-485 B		
	—	Functional earth		
3			Connection to external fieldbus. See installation and operating instructions for the CIM module.	
4	0 V			External stop
	+12 VDC	Connection to battery	Backup battery	
5	10	DI1		Water shortage
	11	GND		
	12	DI2	Digital input	
	13	GND		
	14	DI3		
All terminals (except mains terminals) must only be connected to voltages not exceeding 16 V <sub>rms</sub> and 22.6 V <sub>peak</sub> or 35 VDC.				
Ethernet RJ45				
6			External computing devices connected to the Ethernet connection must comply with the standards IEC 60950 and UL 60950.	
7		GENIbus	Service connection	
	47	+24 V	Supply to sensor. Short-circuit-protected 30 mA	Pressure sensor
	50	+24 V	Supply to sensor. Short-circuit-protected 30 mA	
	51	AI1	Input for analog signal, 0/4-20 mA or 0-10 V	
	53	+24 V	Supply to sensor. Short-circuit-protected 30 mA	
	54	AI2	Input for analog signal, 0/4-20 mA or 0-10 V	
	57	AI3		
	58	GND*		
All terminals (except mains terminals) must only be connected to voltages not exceeding 16 V <sub>rms</sub> and 22.6 V <sub>peak</sub> or 35 VDC.				
* GND is separated from other earth connections.				
9		USB port	USB 2.0, type B	
10	70		C	70 71 72 73 74 75
	71	Relay 1	NO	
	72		NC	
	73		C	
	74	Relay 2	NO	
	75		NC	



## ES systems, IO 351, GENIbus number 31

Group	Terminal	Designation	Data	Diagram for standard configuration
1	L	Phase conductor		
	L		1 x 100-240 VAC ± 10 %, 50/60 Hz	
	N	Neutral conductor		
	N			
2	PE			
	76	DO1, 2, 3 C		
	76	DO1, 2, 3 C		
	77	DO1 NO	Relay contact, NO	
2	79	DO2 NO	Maximum load: 240 VAC, 2 A Minimum load: 5 VDC, 10 mA	
	81	DO3 NO		
	10	DI1		
3A	12	DI2		
	14	DI3	Digital input	
	15	GND	The terminals must only be connected to voltages of maximum 16 V <sub>rms</sub> and 22.6 V <sub>peak</sub> or 35 VDC. Fit jumpers instead of the external stops for which the controller is designed.	
3A	53	+24 V	Supply to sensor. Max. 50 mA	
	55	GND		
	57	AI1		
	60	AI2	Input for analog signal, 0/4-20 mA or 0-10 V	
3C	A	RS-485 A		
	A	RS-485 A		
	Y	RS-485 GND*		
	Y	RS-485 GND*	GENIbus (internal) (Fix the screen with a cable clamp.)	
3C	B	RS-485 B		
	B	RS-485 B		
		Functional earth		
			* GND is separated from other earth connections.	
4A	30	PTC1		
	32	PTC2	Input for PTC sensor or thermal switch	
	34	PTC3		
	35	GND, PTC	Fit jumpers if no PTC sensor or thermal switch is connected.	
4A			The terminals must only be connected to voltages of maximum 16 V <sub>rms</sub> and 22.6 V <sub>peak</sub> or 35 VDC.	

Group	Terminal	Designation	Data	Diagram for standard configuration
3B	16	DI4	Digital input	
	17	GND		
	18	AO4	Analog output, 0-10 V	
	20	DI5	Digital input	
	21	GND		Cannot be used.
	22	AO5	Analog output, 0-10 V	
	24	DI6	Digital input	
	25	GND		
	26	AO6	Analog output	
	42	DI7		
4B	44	DI8	Digital input	
	46	DI9		
	47	GND		
	Fit jumpers instead of the external stops for which the controller is designed.			
5	36	PTC4		
	38	PTC5	Input for PTC sensor or thermal switch	
	40	PTC6		
	41	GND, PTC		
Fit jumpers if no PTC sensor or thermal switch is connected.				
The terminals must only be connected to voltages of maximum 16 V <sub>rms</sub> and 22.6 V <sub>peak</sub> or 35 VDC.				
5	82	DO4 NO		
	83	DO4 C		
	83	DO4 C		
	84	DO5 NO		
	85	DO5 C	Relay contact, NO	
	85	DO5 C	Maximum load: 240 VAC, 2 A	
	86	DO6 NO	Minimum load: 5 VDC, 10 mA	
	87	DO6 C		
	87	DO6 C		
	88	DO7 NO		
	89	DO7 C		

## ED systems, IO 351, GENibus number 31

Group	Terminal	Designation	Data	Diagram for standard configuration	
1	L	Phase conductor			
	L		1 x 100-240 VAC ± 10 %, 50/60 Hz		
	N	Neutral conductor			
	N				
2	PE				
	PE				
2	76	DO1, 2, 3 C			
	76	DO1, 2, 3 C			
	77	DO1 NO	Relay contact, NO		
	79	DO2 NO	Maximum load: 240 VAC, 2 A Minimum load: 5 VDC, 10 mA		
	81	DO3 NO			
3A	10	DI1			
	12	DI2			
	14	DI3	Digital input		
	15	GND			
	The terminals must only be connected to voltages of maximum 16 V <sub>rms</sub> and 22.6 V <sub>peak</sub> or 35 VDC.				
Fit jumpers instead of the external stops for which the controller is designed.					
3A	53	+24 V	Supply to sensor. Max. 50 mA		
	55	GND			
	57	AI1			
	60	AI2	Input for analog signal, 0/4-20 mA or 0-10 V		
	The terminals must only be connected to voltages of maximum 16 V <sub>rms</sub> and 22.6 V <sub>peak</sub> or 35 VDC.				
3C	A	RS-485 A			
	A	RS-485 A			
	Y	RS-485 GND*			
	Y	RS-485 GND*	GENibus (internal) (Fix the screen with a cable clamp.)		
	B	RS-485 B			
B	RS-485 B				
Functional earth					
* GND is separated from other earth connections.					
4A	30	PTC1			
	32	PTC2	Input for PTC sensor or thermal switch		
	34	PTC3			
	35	GND, PTC			
	Fit jumpers if no PTC sensor or thermal switch is connected.				
The terminals must only be connected to voltages of maximum 16 V <sub>rms</sub> and 22.6 V <sub>peak</sub> or 35 VDC.					

Group	Terminal	Designation	Data	Diagram for standard configuration
3B	16	DI4	Digital input	
	17	GND		
	18	AO4	Analog output, 0-10 V	
	20	DI5	Digital input	
	21	GND		Cannot be used.
	22	AO5	Analog output, 0-10 V	
	24	DI6	Digital input	
	25	GND		
	26	AO6	Analog output	
	42	DI7		
	44	DI8	Digital input	 The diagram shows terminals 42, 44, 46, and 47 connected to a common external stop point labeled 'External stop, P6'.
	46	DI9		
	47	GND		
Fit jumpers instead of the external stops for which the controller is designed.				
4B	36	PTC4		
	38	PTC5	Input for PTC sensor or thermal switch	 The diagram shows terminal 36 connected to a PTC sensor or thermal switch, and terminal 41 connected to ground (GND) through a PTC component labeled 'PTC, P6'.
	40	PTC6		
	41	GND, PTC		
Fit jumpers if no PTC sensor or thermal switch is connected.				
The terminals must only be connected to voltages of maximum 16 V <sub>rms</sub> and 22.6 V <sub>peak</sub> or 35 VDC.				
5	82	DO4 NO		
	83	DO4 C		
	83	DO4 C		
	84	DO5 NO		
	85	DO5 C	Relay contact, NO	
	85	DO5 C	Maximum load: 240 VAC, 2 A	
	86	DO6 NO	Minimum load: 5 VDC, 10 mA	
	87	DO6 C		
	87	DO6 C		
	88	DO7 NO		
	89	DO7 C		

## EDF systems, IO 351, GENIbus number 31

Group	Terminal	Designation	Data	Diagram for standard configuration
1	L L N N  L L	Phase conductor Neutral conductor  PE	1 x 100-240 VAC ± 10 %, 50/60 Hz	IO 351 L-L N-N ⊕-PE
2	76 76 77 79 81	DO1, 2, 3 C DO1, 2, 3 C DO1 NO DO2 NO DO3 NO	Relay contact, NO Maximum load: 240 VAC, 2 A Minimum load: 5 VDC, 10 mA	IO 351 76 ← Common 76 ← Common 77 → P4, on/off, mains 79 → P5, on/off, mains 81 → P6, on/off, mains
3A	10 12 14 15	DI1 DI2 DI3 GND	Digital input	IO 351 10 External stop, P1 12 External stop, P2 14 External stop, P3 15 Common, GND
			The terminals must only be connected to voltages of maximum 16 V <sub>rms</sub> and 22.6 V <sub>peak</sub> or 35 VDC.	
			Fit jumpers instead of the external stops for which the controller is designed.	
3A	53 55 57 60	+24 V GND AI1 AI2	Supply to sensor. Max. 50 mA Input for analog signal, 0/4-20 mA or 0-10 V	IO 351 53 55 57 60 } Cannot be used.
			The terminals must only be connected to voltages of maximum 16 V <sub>rms</sub> and 22.6 V <sub>peak</sub> or 35 VDC.	
3C	A A Y Y B B  L	RS-485 A RS-485 A RS-485 GND* RS-485 GND* RS-485 B RS-485 B  Functional earth	GENIbus (internal) (Fix the screen with a cable clamp.)	IO 351 CU 352 A A1 Y Y1 B B1 L L
			* GND is separated from other earth connections.	
4A	30 32 34 35	PTC1 PTC2 PTC3 GND, PTC	Input for PTC sensor or thermal switch	IO 351 30 PTC, P1 32 PTC, P2 34 PTC, P3 35 GND, PTC
			Fit jumpers if no PTC sensor or thermal switch is connected.	
			The terminals must only be connected to voltages of maximum 16 V <sub>rms</sub> and 22.6 V <sub>peak</sub> or 35 VDC.	

Group	Terminal	Designation	Data	Diagram for standard configuration
3B	16	DI4	Digital input	IO 351 16 → VFD1, ready 17 ← VFD1, GND 18 ↗ VFD1, speed 20 → VFD2, ready 21 ← VFD2, GND 22 ↗ VFD2, speed 23 24 25 26
	17	GND		
	18	AO4	Analog output, 0-10 V	
	20	DI5	Digital input	
	21	GND		
	22	AO5	Analog output, 0-10 V	
	24	DI6	Digital input	
	25	GND		
	26	AO6	Analog output	
	42	DI7		
4B	44	DI8	Digital input	42 → External stop, P4 44 → External stop, P5 46 → External stop, P6 47 ← Common, GND
	46	DI9		
	47	GND		
	Fit jumpers instead of the external stops for which the controller is designed.			
4B	36	PTC4		IO 351 36 → PTC, P4
	38	PTC5	Input for PTC sensor or thermal switch	38 → PTC, P5
	40	PTC6		40 → PTC, P6
	41	GND, PTC		41 ← GND, PTC
Fit jumpers if no PTC sensor or thermal switch is connected.				
The terminals must only be connected to voltages of maximum 16 V <sub>rms</sub> and 22.6 V <sub>peak</sub> or 35 VDC.				
5	82	DO4 NO		IO 351 ✓ - 82 → VFD1, start 83 ← Common ✓ - 84 → VFD2, start 85 ← Common ✓ - 86 → P3, on/off, mains 87 ← Common ✓ - 88 89
	83	DO4 C		
	83	DO4 C		
	84	DO5 NO		
	85	DO5 C	Relay contact, NO	
	85	DO5 C	Maximum load: 240 VAC, 2 A	
	86	DO6 NO	Minimum load: 5 VDC, 10 mA	
	87	DO6 C		
	87	DO6 C		
	88	DO7 NO		
	89	DO7 C		

Group	Terminal	Designation	Data	Diagram for standard configuration
1	L L N N  PE PE	Phase conductor Neutral conductor	1 x 100-240 VAC ± 10 %, 50/60 Hz	IO 351 L-L N-N ⊕-PE
2	76 76 77 79 81	DO1, 2, 3 C DO1, 2, 3 C DO1 NO DO2 NO DO3 NO	Relay contact, NO Maximum load: 240 VAC, 2 A Minimum load: 5 VDC, 10 mA	IO 351 76 76 77 79 81 } Cannot be used.
3A	10 12 14 15	DI1 DI2 DI3 GND	Digital input	IO 351 10 External stop, P1 12 External stop, P2 14 External stop, P3 15 Common, GND
3A	53 55 57 60	+24 V GND AI1 AI2	Supply to sensor. Max. 50 mA Input for analog signal, 0/4-20 mA or 0-10 V	IO 351 53 55 57 60 } Cannot be used.
3C	A A Y Y B B  Functional earth	RS-485 A RS-485 A RS-485 GND* RS-485 GND* RS-485 B RS-485 B  Functional earth	GENIbus (internal) (Fix the screen with a cable clamp.)	IO 351 CU 352 A A1 Y Y1 B B1 ⊕ ⊕
4A	30 32 34 35	PTC1 PTC2 PTC3 GND, PTC	Input for PTC sensor or thermal switch	IO 351 30 PTC, P1 32 PTC, P2 34 PTC, P3 35 GND, PTC
			Fit jumpers if no PTC sensor or thermal switch is connected.	
			The terminals must only be connected to voltages of maximum 16 V <sub>rms</sub> and 22.6 V <sub>peak</sub> or 35 VDC.	

Group	Terminal	Designation	Data	Diagram for standard configuration
3B	16	DI4	Digital input	IO 351 16 → VFD1, ready 17 ← VFD1, GND 18 ↗ VFD1, speed 20 → VFD2, ready 21 ← VFD2, GND 22 ↗ VFD2, speed 23 → VFD3, ready 24 ← VFD3, GND 25 ↗ VFD3, speed 26
	17	GND		
	18	AO4	Analog output, 0-10 V	
	20	DI5	Digital input	
	21	GND		
	22	AO5	Analog output, 0-10 V	
	24	DI6	Digital input	42
	25	GND		44
	26	AO6	Analog output	46
	42	DI7		47
4B	44	DI8	Digital input	
	46	DI9		
	47	GND		
	36	PTC4		IO 351 36
	38	PTC5	Input for PTC sensor or thermal switch	38
5	40	PTC6		40
	41	GND, PTC		41
Fit jumpers if no PTC sensor or thermal switch is connected.				
The terminals must only be connected to voltages of maximum 16 V <sub>rms</sub> and 22.6 V <sub>peak</sub> or 35 VDC.				
5	82	DO4 NO		IO 351 ✓ -82 → VFD1, start 83 ← Common 83
	83	DO4 C		✓ -84 → VFD2, start 85 ← Common 85
	83	DO4 C		✓ -86 → VFD3, start 87 ← Common 87
	84	DO5 NO		✓ -88 89
	85	DO5 C	Relay contact, NO	
	85	DO5 C	Maximum load: 240 VAC, 2 A	
	86	DO6 NO	Minimum load: 5 VDC, 10 mA	
	87	DO6 C		
	87	DO6 C		
	88	DO7 NO		
	89	DO7 C		

Group	Terminal	Designation	Data	Diagram for standard configuration
1	L L N N $\perp$ $\perp$	Phase conductor Neutral conductor PE	1 x 100-240 VAC $\pm 10\%$ , 50/60 Hz	IO 351 L-L N-N $\perp$ -PE
2	76 76 77 79 81	DO1, 2, 3 C DO1, 2, 3 C DO1 NO DO2 NO DO3 NO	Relay contact, NO Maximum load: 240 VAC, 2 A Minimum load: 5 VDC, 10 mA	IO 351 76 76 77 79 81 Cannot be used.
3A	10 12 14 15	DI1 DI2 DI3 GND	Digital input The terminals must only be connected to voltages of maximum 16 V <sub>rms</sub> and 22.6 V <sub>peak</sub> or 35 VDC. Fit jumpers instead of the external stops for which the controller is designed.	IO 351 10 12 14 15 External stop, P4 External stop, P5 External stop, P6 Common, GND
3A	53 55 57 60	+24 V GND AI1 AI2	Supply to sensor. Max. 50 mA Input for analog signal, 0/4-20 mA or 0-10 V	IO 351 53 55 57 6 Cannot be used.
3C	A A Y Y B B $\perp$	RS-485 A RS-485 A RS-485 GND* RS-485 GND* RS-485 B RS-485 B Functional earth	GENIbus (internal) (Fix the screen with a cable clamp.)	IO 351 CU 352 A Y B $\perp$ A1 Y1 B1 $\perp$
4A	30 32 34 35	PTC1 PTC2 PTC3 GND, PTC	Input for PTC sensor or thermal switch Fit jumpers if no PTC sensor or thermal switch is connected.	IO 351 30 32 34 35 PTC, P4 PTC, P5 PTC, P6 GND, PTC
			The terminals must only be connected to voltages of maximum 16 V <sub>rms</sub> and 22.6 V <sub>peak</sub> or 35 VDC.	

Group	Terminal	Designation	Data	Diagram for standard configuration
3B	16	DI4	Digital input	IO 351 16 → VFD4, ready 17 ← VFD4, GND 18 ↗ VFD4, speed 20 → VFD5, ready 21 ← VFD5, GND 22 ↗ VFD5, speed 23 → VFD6, ready 24 ← VFD6, GND 25 ↗ VFD6, speed 26
	17	GND		
	18	AO4	Analog output, 0-10 V	
	20	DI5	Digital input	
	21	GND		
	22	AO5	Analog output, 0-10 V	
	24	DI6	Digital input	42
	25	GND		44
	26	AO6	Analog output	46
	42	DI7		47
4B	44	DI8	Digital input	
	46	DI9		
	47	GND		
	36	PTC4		IO 351 36
	38	PTC5	Input for PTC sensor or thermal switch	38
5	40	PTC6		40
	41	GND, PTC	Fit jumpers if no PTC sensor or thermal switch is connected.	41
The terminals must only be connected to voltages of maximum 16 V <sub>rms</sub> and 22.6 V <sub>peak</sub> or 35 VDC.				
5	82	DO4 NO		IO 351 - 82 → VFD4, start - 83 ← Common - 83
	83	DO4 C		- 84 → VFD5, start - 85 ← Common - 85
	83	DO4 C		- 86 → VFD6, start - 87 ← Common - 87
	84	DO5 NO		- 88 - 89
	85	DO5 C	Relay contact, NO	
	85	DO5 C	Maximum load: 240 VAC, 2 A	
	86	DO6 NO	Minimum load: 5 VDC, 10 mA	
	87	DO6 C		
	87	DO6 C		
	88	DO7 NO		
	89	DO7 C		

## F systems, module B1, IO 351, GENibus number 31

Group	Terminal	Designation	Data	Diagram for standard configuration
1	L L N N  PE PE	Phase conductor Neutral conductor	1 x 100-240 VAC ± 10 %, 50/60 Hz	IO 351 L-L N-N ⊕-PE
2	76 76 77 79 81	DO1, 2, 3 C DO1, 2, 3 C DO1 NO DO2 NO DO3 NO	Relay contact, NO Maximum load: 240 VAC, 2 A Minimum load: 5 VDC, 10 mA	IO 351 76      76      Common 77      79      → P1, on/off, mains 79      81      → P2, on/off, mains 81      → P3, on/off, mains
3A	10 12 14 15	DI1 DI2 DI3 GND	Digital input	IO 351 10      External stop, P1 12      External stop, P2 14      External stop, P3 15      Common, GND
			The terminals must only be connected to voltages of maximum 16 V <sub>rms</sub> and 22.6 V <sub>peak</sub> or 35 VDC.	
			Fit jumpers instead of the external stops for which the controller is designed.	
3A	53 55 57 60	+24 V GND AI1 AI2	Supply to sensor. Max. 50 mA Input for analog signal, 0/4-20 mA or 0-10 V	IO 351 53 55 57      60      } Cannot be used.
			The terminals must only be connected to voltages of maximum 16 V <sub>rms</sub> and 22.6 V <sub>peak</sub> or 35 VDC.	
3C	A A Y Y B B  Functional earth	RS-485 A RS-485 A RS-485 GND* RS-485 GND* RS-485 B RS-485 B  Functional earth	GENibus (internal) (Fix the screen with a cable clamp.)	IO 351 CU 352 A      A1 Y      Y1 B      B1 ⊕-PE
			* GND is separated from other earth connections.	
4A	30 32 34 35	PTC1 PTC2 PTC3 GND, PTC	Input for PTC sensor or thermal switch	IO 351 30      PTC, P1 32      PTC, P2 34      PTC, P3 35      GND, PTC
			Fit jumpers if no PTC sensor or thermal switch is connected.	
			The terminals must only be connected to voltages of maximum 16 V <sub>rms</sub> and 22.6 V <sub>peak</sub> or 35 VDC.	

Group	Terminal	Designation	Data	Diagram for standard configuration
3B	16	DI4	Digital input	IO 351 16
	17	GND		17
	18	AO4	Analog output, 0-10 V	18
	20	DI5	Digital input	20
	21	GND		21
	22	AO5	Analog output, 0-10 V	22
	24	DI6	Digital input	23
	25	GND		24
	26	AO6	Analog output	25
	42	DI7		26
4B	44	DI8	Digital input	42 → VFD, ready 44
	46	DI9		46
	47	GND		47 → VFD, GND
	Fit jumpers instead of the external stops for which the controller is designed.			
5	36	PTC4		IO 351 36
	38	PTC5	Input for PTC sensor or thermal switch	38
	40	PTC6		40
	41	GND, PTC		4
Fit jumpers if no PTC sensor or thermal switch is connected.				
The terminals must only be connected to voltages of maximum 16 V <sub>rms</sub> and 22.6 V <sub>peak</sub> or 35 VDC.				
5	82	DO4 NO		IO 351 - 82 → P1, on/off, VFD
	83	DO4 C		- 83 ← Common
	83	DO4 C		- 83
	84	DO5 NO		- 84 → P2, on/off, VFD
	85	DO5 C	Relay contact, NO	- 85 ← Common
	85	DO5 C	Maximum load: 240 VAC, 2 A	- 85
	86	DO6 NO	Minimum load: 5 VDC, 10 mA	- 86 → P3, on/off, VFD
	87	DO6 C		- 87 ← Common
	87	DO6 C		- 87
	88	DO7 NO		- 88 → VFD, start
	89	DO7 C		- 89 ← Common

## F systems, module B2, IO 351, GENIbus number 32

Group	Terminal	Designation	Data	Diagram for standard configuration
1	L L N N  PE PE	Phase conductor Neutral conductor	1 x 100-240 VAC ± 10 %, 50/60 Hz	IO 351 L-L N-N ⊕-PE
2	76 76 77 79 81	DO1, 2, 3 C DO1, 2, 3 C DO1 NO DO2 NO DO3 NO	Relay contact, NO Maximum load: 240 VAC, 2 A Minimum load: 5 VDC, 10 mA	IO 351 76 - 76 ← Common 77 → P4, on/off, mains 79 → P5, on/off, mains 81 → P6, on/off, mains
3A	10 12 14 15	DI1 DI2 DI3 GND	Digital input	IO 351 10 External stop, P4 12 External stop, P5 14 External stop, P6 15 Common, GND
			The terminals must only be connected to voltages of maximum 16 V <sub>rms</sub> and 22.6 V <sub>peak</sub> or 35 VDC.	
			Fit jumpers instead of the external stops for which the controller is designed.	
3A	53 55 57 60	+24 V GND AI1 AI2	Supply to sensor. Max. 50 mA Input for analog signal, 0/4-20 mA or 0-10 V	IO 351 53 55 57 60 } Cannot be used.
			The terminals must only be connected to voltages of maximum 16 V <sub>rms</sub> and 22.6 V <sub>peak</sub> or 35 VDC.	
3C	A A Y Y B B  Functional earth	RS-485 A RS-485 A RS-485 GND* RS-485 GND* RS-485 B RS-485 B  Functional earth	GENIbus (internal) (Fix the screen with a cable clamp.)	IO 351 CU 352 A A1 Y Y1 B B1 ⊕ ⊕
			* GND is separated from other earth connections.	
4A	30 32 34 35	PTC1 PTC2 PTC3 GND, PTC	Input for PTC sensor or thermal switch	IO 351 30 PTC, P4 32 PTC, P5 34 PTC, P6 35 GND, PTC
			Fit jumpers if no PTC sensor or thermal switch is connected.	
			The terminals must only be connected to voltages of maximum 16 V <sub>rms</sub> and 22.6 V <sub>peak</sub> or 35 VDC.	

Group	Terminal	Designation	Data	Diagram for standard configuration
3B	16	DI4	Digital input	IO 351 16
	17	GND		17
	18	AO4	Analog output, 0-10 V	18
	20	DI5	Digital input	20
	21	GND		21
	22	AO5	Analog output, 0-10 V	22
	24	DI6	Digital input	23
	25	GND		24
	26	AO6	Analog output	25
	42	DI7		26
4B	44	DI8	Digital input	42
	46	DI9		44
	47	GND		46
	36	PTC4		47
	38	PTC5	Input for PTC sensor or thermal switch	IO 351 36
4B	40	PTC6		38
	41	GND, PTC		40
	Fit jumpers if no PTC sensor or thermal switch is connected.			41
The terminals must only be connected to voltages of maximum 16 V <sub>rms</sub> and 22.6 V <sub>peak</sub> or 35 VDC.				
5	82	DO4 NO		IO 351 - 82 → P4, on/off, VFD
	83	DO4 C		- 83 ← Common
	83	DO4 C		- 83
	84	DO5 NO		✓ - 84 → P5, on/off, VFD
	85	DO5 C	Relay contact, NO	- 85 ← Common
	85	DO5 C	Maximum load: 240 VAC, 2 A	- 85
	86	DO6 NO	Minimum load: 5 VDC, 10 mA	✓ - 86 → P6, on/off, VFD
	87	DO6 C		- 87 ← Common
	87	DO6 C		- 87
	88	DO7 NO		✓ - 88
	89	DO7 C		- 89

## S systems, IO 351, GENIbus number 31

Group	Terminal	Designation	Data	Diagram for standard configuration	
1	L	Phase conductor			
	L		1 x 100-240 VAC ± 10 %, 50/60 Hz		
	N	Neutral conductor			
	N				
2	PE				
	PE				
2	76	DO1, 2, 3 C			
	76	DO1, 2, 3 C			
	77	DO1 NO	Relay contact, NO		
	79	DO2 NO	Maximum load: 240 VAC, 2 A Minimum load: 5 VDC, 10 mA		
	81	DO3 NO			
3A	10	DI1			
	12	DI2			
	14	DI3	Digital input		
	15	GND			
	The terminals must only be connected to voltages of maximum 16 V <sub>rms</sub> and 22.6 V <sub>peak</sub> or 35 VDC.				
Fit jumpers instead of the external stops for which the controller is designed.					
3A	53	+24 V	Supply to sensor. Max. 50 mA		
	55	GND			
	57	AI1			
	60	AI2	Input for analog signal, 0/4-20 mA or 0-10 V		
	The terminals must only be connected to voltages of maximum 16 V <sub>rms</sub> and 22.6 V <sub>peak</sub> or 35 VDC.				
3C	A	RS-485 A			
	A	RS-485 A			
	Y	RS-485 GND*			
	Y	RS-485 GND*	GENIbus (internal) (Fix the screen with a cable clamp.)		
	B	RS-485 B			
	B	RS-485 B			
	Functional earth				
* GND is separated from other earth connections.					
4A	30	PTC1			
	32	PTC2	Input for PTC sensor or thermal switch		
	34	PTC3			
	35	GND, PTC			
	Fit jumpers if no PTC sensor or thermal switch is connected.				
The terminals must only be connected to voltages of maximum 16 V <sub>rms</sub> and 22.6 V <sub>peak</sub> or 35 VDC.					

Group	Terminal	Designation	Data	Diagram for standard configuration
3B	16	DI4	Digital input	IO 351 16
	17	GND		17
	18	AO4	Analog output, 0-10 V	18
	20	DI5	Digital input	20
	21	GND		21
	22	AO5	Analog output, 0-10 V	22
	24	DI6	Digital input	23
	25	GND		24
	26	AO6	Analog output	25
	42	DI7		26
4B	44	DI8	Digital input	42 External stop, P4 44 External stop, P5 46 External stop, P6 47 Common, GND
	46	DI9		
	47	GND		
	Fit jumpers instead of the external stops for which the controller is designed.			
4B	36	PTC4		IO 351 36
	38	PTC5	Input for PTC sensor or thermal switch	38 PTC, P4
	40	PTC6		40 PTC, P5
	41	GND, PTC		41 PTC, P6 GND, PTC
Fit jumpers if no PTC sensor or thermal switch is connected.				
The terminals must only be connected to voltages of maximum 16 V <sub>rms</sub> and 22.6 V <sub>peak</sub> or 35 VDC.				
5	82	DO4 NO		IO 351 -82 → P4, on/off
	83	DO4 C		-83 ← Common
	83	DO4 C		83
	84	DO5 NO		✓ -84 → P5, on/off
	85	DO5 C	Relay contact, NO	85 ← Common
	85	DO5 C	Maximum load: 240 VAC, 2 A	85
	86	DO6 NO	Minimum load: 5 VDC, 10 mA	✓ -86 → P6, on/off
	87	DO6 C		87 ← Common
	87	DO6 C		87
	88	DO7 NO		✓ -88
	89	DO7 C		-89

#### 4.2.6 CU 352 and IO 351 installation and operating instructions

See WinCAPS or WebCAPS > Service > Hydro MPC > CU 352 or IO 351 > Installation and operating instructions.

## 5. Fault correction tools

### 5.1 MPC/CU 352 indicator lights and alarm relay

See WinCAPS or WebCAPS > Service > Hydro MPC > CU 352 or IO 351 > Installation and operating instructions.

### 5.2 MPC display

#### 5.2.1 Status

The display shown below is the status display. This display is shown when the Hydro MPC is switched on, and it appears if the buttons of the control panel remain untouched for 15 minutes.




Fig. 9 Status menu

#### Description

No settings can be made in this menu.

The actual value (process value, PV) of the control parameter, usually the discharge pressure, is shown in the upper right corner (G) together with the selected setpoint (SP) (H).

The upper half of the display (A) shows a graphic illustration of the pump system. The selected measuring parameters are shown with sensor symbol and actual value.

The lower display half (B) shows the following:

- the most recent active alarm, if any, and the fault cause with the fault code in brackets
- system status with actual operating mode and control source
- pump status with actual operating mode.

**If a fault has occurred, the warning symbol ! or alarm symbol X will be shown in the line (C) together with the cause and fault code, for instance "Overtemperature (64)".**

If the fault is related to one of the pumps, the symbol ! or X will also be shown in front of the status line (D) of the pump in question. At the same time, the pump status indicator (E) will change colour to either yellow or red as described in the table below. The symbol ! or X will be shown to the right in the top line of the display (F). As long as a fault is present, this symbol will be shown in the top line of all displays.

**Note**

#### Description of pump status

Pump status indicator	Description
Rotating, green	Pump running.
Permanently green	Pump ready (not running).
Rotating, yellow	Warning. Pump running.
Permanently yellow	Warning. Pump ready (not running).
Permanently red	Alarm. Pump stopped.

For further details on an alarm, go to the "Alarm" menu in the top bar. The "3. Alarm" display gives access to the following status displays.

- Actual alarms
- Alarm log
- Service contact information.

#### Alarm log

The alarm log can store up to 24 warnings and alarms.




Fig. 10 Alarm log

#### Description

Here warnings and alarms are shown.

For every warning or alarm, the following will be shown:

- Whether it is a warning ! or an alarm X.
- Where the fault occurred. System, Pump 1, Pump 2, etc.
- In case of input-related faults, the input will be shown.
- The cause of the fault and the alarm code in brackets, for instance "Water shortage (214)".
- When the fault occurred: Date and time.
- When the fault disappeared: Date and time. If the fault still exists, date and time will be shown as -- --.
- The most recent warning/alarm is shown at the top of the display.

### 5.2.2 Passwords

Passwords can be set to prevent unauthorised change of settings in the menus "Operation" and "Settings".

See the Hydro MPC installation and operating instructions.

Both passwords are disabled. If a password is enabled, the factory setting is "1234".

#### Service passwords

If a customer password is set and not available for a Grundfos service engineer, the booster system can be unlocked by using the Grundfos service code "6814". Please protect this code and avoid unauthorised use of the code.

### 5.2.3 Alarm list

Check all active alarm codes before starting the fault correction.

MPC alarm indication Protocol description	Alarm code	Associated device and device number	Description/cause	Remedy	Reset type <sup>1</sup>	Alarm/warning Action type <sup>2</sup>
Phase failure, pump	2	Pump 1-6	-	Check that all three mains phases are within a 15 V band.	Auto	Warning
Too many restarts	7	Pump 1-6	HSD = hardware shut-down. There has been a fault, and the permissible number of restarts for the fault type has been exceeded. • Fault in mains supply. • Terminal box defective.	Restore mains supply. Replace terminal box.	Auto	Warning
Undervoltage, pump	40	Pump 1-6	Mains voltage is too low at start.	Bring voltage back to prescribed level.	Auto	Warning
Undervoltage, pump	42	Pump 1-6	Faulty mains supply at the time of cutting in the terminal box.	Restore correct mains supply.	Auto	Warning
Undervoltage, pump	73	Pump 1-6	• Fall in mains supply. • Mains supply failure while motor is running.	Restore correct mains supply.	Auto	Warning
Overvoltage, pump	32	Pump 1-6	Mains voltage is too high at start.	Bring voltage back to prescribed level.	Auto	Warning
Overload, associated device	48	Pump 1-6	Heavy overload has caused software shutdown (SSD).	Check and possibly reduce the load.	Auto	Warning
Overload, associated device	50	Pump 1-6	MPF = motor protection function. The built-in motor protection has detected a sustained overload (MPF 60 sec. limit).	Check and possibly reduce load or improve cooling.	Auto	Warning
Overload, associated device	51	Pump 1-6	Heavy overload ( $I_{max}$ . very high). Pump blocked at start.	Deblock the pump.	Auto	Warning
Overload, associated device	54	Pump 1-6	The built-in motor protection has detected a transitory overload (MPF 3 sec. limit).	Check and possibly reduce load or improve cooling.	Auto	Warning
Too high motor temperature	65, 70	Pump 1-6	PTC sensor in the motor has signalled overtemperature.	Check and possibly reduce load or improve cooling.	Auto	Warning
Too high motor temperature	67	Pump 1-6	The terminal box has indicated overtemperature.	Check and possibly reduce load or improve cooling. Temperature during operation can be read via PC Tool E-products.	Auto	Warning
Other fault, associated device	76	Pump 1-6	Internal communication fault has occurred in the pump.	Try to reset the fault: 1. Switch off the power supply. 2. Wait until all diodes are out. 3. Switch on the power supply.  If this does not remedy the fault, replace the terminal box.	Auto	Warning
Limit 1 exceeded	190	Measured parameter	The measured parameter has exceeded the limit set.	Remove the cause of the fault.	Man/ auto	Alarm/warning Stop/unchanged
Limit 2 exceeded	191	Measured parameter	The measured parameter has exceeded the limit set.	Remove the cause of the fault.	Man/ auto	Alarm/warning Stop/unchanged

MPC alarm indication Protocol description	Alarm code	Associated device and device number	Description/cause	Remedy	Reset type <sup>1</sup>	Alarm/warning	
						Action type <sup>2</sup>	Action type <sup>2</sup>
Pressure relief	219	System	The monitored pressure could not be reduced sufficiently.	Reduce the pressure to below the limit.	Auto	Warning	Unchanged
Pressure build-up fault	215	System	The pressure set cannot be reached within the configured time.	Check limit and pipes.	Man/ auto	Alarm/warning	Stop/unchanged
Pumps outside duty range	208	System	The pump is running outside the defined range.	Check the system.	Man/ auto	Warning	Unchanged
Pilot pump fault	216	Pilot pump	Pilot pump fault.	Check wires. Check the pump.	Auto	Warning	
Water shortage Water shortage*	206		The precharge pressure (or the level in the feed tank) is below its programmable warning limit.		Man/ auto	Warning	Unchanged
Water shortage Water shortage*	214		The precharge pressure (or the level in the feed tank) is below its programmable alarm limit.  The pressure switch detects water shortage.	Check the actual pressure and the corresponding settings.  Check the sensor/switch, wiring and input according to the wiring diagram.  Check the sensor/switch.	Man/ auto	Alarm  Stop  Warning  Unchanged	
Pressure high Pressure above maximum pressure*	210		The operating pressure is above the programmable high-pressure alarm limit.		Man/ auto	Alarm  Fast stop (overrides min. seq. time)	
Pressure low Pressure below min. pressure*	211	Booster system	The operating pressure is below the programmable low-pressure alarm limit.		Man/ auto	Alarm/warning  Stop/unchanged	
Alarm, all pumps Alarm, all pumps*	203		All pumps set to Auto have stopped due to a pump alarm.	Fault-find according to the alarm message/code: 1. System. 2. Pumps installed. Use fault-finding for the pump.	Auto	Alarm  Stop	
External fault External fault*	003		The digital input set to "External fault" has been or is still closed.	The fault reading can be reset with the R100 when the digital input is no longer closed.  Reset by pressing [+] or [-].	Man/ auto	Alarm/warning  Stop/unchanged	
Dissimilar sensor signals Dissimilar sensor signals*	204	Primary sensor and/or redundant sensor	Primary feedback sensor value (pressure) is inconsistent with redundant feedback sensor value.	Check the wiring and input according to the wiring diagram.  Check the sensor output according to the value measured.	Auto	Warning  Unchanged	
Fault, primary sensor Closed-loop feedback sensor signal fault*	089	Primary sensor	A fault in the sensor assigned to the feedback control has been detected.	Check the wiring and input according to the wiring diagram.  Check the sensor output according to the value measured.	Auto	Alarm  Stop	
Fault, sensor General (measurement) sensor signal fault*	088	CU 352 IO 351B as IO module	Fault in the settings of the sensor assigned to the controller.	Check the settings of the primary sensor.			
			The signal, for instance 4 to 20 mA, from one of the analog sensors is outside the selected signal range.	Check the wiring and input according to the wiring diagram.  Check the sensor output according to the value measured.	Auto	Warning  Unchanged	

MPC alarm indication Protocol description	Alarm code	Associated device and device number	Description/cause	Remedy	Reset type <sup>1</sup>	Alarm/warning Action type <sup>2</sup>
Internal fault, CU 352 Real-time clock out of order*	157		The real-time clock in the CU 352 is out of order.	Replace the CU 352.		Warning
Fault, Ethernet Ethernet: No address from DHCP server*	231		No address from DHCP server.	Communication fault. Contact the system integrator.		
Fault, Ethernet Ethernet: Auto-disabled due to misuse*	232	CU 352	Auto-disabled due to misuse.		Auto	Unchanged
FLASH parameter verification error FLASH parameter verification error*	083		Verification error in the CU 352 FLASH memory.	Replace the CU 352.		
Other fault, associated device	83		Setting data not correct.	Other fault, associated device.		Warning
IO 351 internal fault Hardware fault, type 2*	080	IO 351	Hardware fault in the IO 351A. Hardware fault in the IO 351B.	See "Actual alarms", and identify the faulty IO 351 module from the alarm message. Replace the module.	Auto	Warning Unchanged
VFD not ready VFD not ready*	213	Pump 1-6 CU 352	The VFD signal relay does not release the VFD for operation.	Check for VFD alarm. Check the wiring and input according to the wiring diagram.	Auto	Warning Unchanged
Communication fault Pump communication fault*	010	Pump 1-6 IO 351	No GENibus communication with a device connected to the CU 352.	See "Actual alarms", and identify the faulty device from the alarm message. 1. Check the power supply. 2. Check the GENibus cable connection. 3. Check that the GENibus number of the device is correct, using the R100.	Auto	Warning Unchanged
Device alarms	From device	Pump 1-6	The device is in alarm condition.	See "Actual alarms" and identify the faulty device from the alarm message. Fault-find according to the service instructions for the device.	Auto	Warning Unchanged

<sup>1</sup> Reset either of these types:

- "Auto acknowledgement" (automatic).

- "Auto acknowledgement" or "Manual acknowledgement" (automatic/manual).

<sup>2</sup> System goes to operating mode "Stop" (no delay (< 0.5 s) between pump disconnections).

\* Protocol description.

## 5.3 R100 and Grundfos GO Remote

The R100 or the Grundfos Go Remote can be used for setting the addresses of the IO 351 modules and for reading out settings. The general-purpose IO module inputs and outputs are set up via the CU 352 or with a PC Tool connected via the CU 352.

### 5.3.1 PC Tool E-products

The Grundfos PC Tool E-products, version 11.00.01 or later, supports the Hydro MPC and the components included. A detailed PC Tool Help assistant is available in the tool program, and a user manual in PDF format can be printed from the tool. The tool can be connected to the CU 352 of the Hydro MPC booster system and communicate with IO modules and E-pumps. The "Network list" of the tool shows the units which are capable of communicating with the application in question.

The tool supports these functions:

### 5.3.2 Network list

This is a list of all GENIbus products connected to the network. Clicking [Network list] in the toolbar allows you to toggle between the network list expanded and collapsed.

### 5.3.3 Monitor

This function gives an overview and details of the operating status of the product.

### Output

If the expected output function does not take place according to the graphical presentation, it may be due to the following faults:

- Defective component connected to the output. Check the component according to the wiring diagram.
- The output from the IO module does not function according to the graphical presentation. Check the physical output.

### Input

If the expected input function does not take place according to the graphical presentation, it may be due to the following faults:

- The input signal is not as shown in the graphical presentation. Check that the signal is OK on the input terminal.
- The input of the IO module is defective. Replace the IO module.
- The CU 352 is defective.

### 5.3.4 Standard configuration

The standard configuration function allows you to select the appropriate standard configuration file for the product and send the file to the product.

It is possible to import a Grundfos Standard Configuration (GSC) file library via Tools > Update configuration files.

From factory, the Hydro MPC booster system is configured/programmed for the application.

If an IO module is replaced, the new module will automatically be configured from the CU 352 when the booster system is restarted. Remember to give the new module the correct GENIbus address by means of the R100.

If replaced, a CU 352 must be configured to the application in question. Follow the instructions in the "HELP assistant".

Standard configuration files are included in the tool when it is installed for the first time.

Subsequently, it is the user's responsibility to download the current version of the "Standard configuration file library". See section 5.3.7 Updating configuration files.

### 5.3.5 Custom configuration

The custom configuration function enables you to change selected standard configuration settings to a custom configuration.

Custom configuration should be considered as an expert tool to be used for changing/adjusting standard data.

### 5.3.6 Data logging

Data logging of all data takes place continuously. In the net list, you can select the data to be visible. When the PC Tool is shut down, you will be asked whether you want to save your data log.

### 5.3.7 Updating configuration files

You can import an updated library of the standard configuration files from Tools > Update configuration files. If the selected library is the same as or older than the one already installed, a warning allows you to either skip the update or proceed to overwrite the existing library. "Update GSC Files" opens a dialogue, allowing you to browse for the zipped GSC files library.

*If your computer is connected to a Grundfos network, the dialogue offers an automatic update. When you select the automatic update, the PC Tool will find the updated GSC library on the Grundfos network. Accordingly, you need not browse for the library.*

## 6. Factory configuration of Hydro MPC

### 6.1 Necessary equipment

The following equipment is required:

1. R100 or Grundfos GO Remote, SW version 14, Nov. 01, 2005 or later.
2. PC Tool E-Products, version 11.00.01 or later.

### 6.2 Factory configuration of Hydro MPC

The configuration consists of these steps:

- 6.2.1 Setting the GENIbus number in IO 351 modules, if any
- 6.2.2 Configuration of the CU 352
- 6.2.3 Configuration of external frequency converters, if any
- 6.2.4 Step-by-step configuration of E-pump(s), if any.

#### 6.2.1 Setting the GENIbus number in IO 351 modules, if any

Depending on the Control MPC system type and Control MPC options, the control panel is equipped with none or up to four IO 351A/B modules.

The modules present will have the designation numbers A1, A2, A01 or A03.


The units must have a GENIbus number according to the table below.

Module with designation	Address of module	Control MPC option GSC file to download
IO 351B interface	41	98272072
IO interface	42	98272073
Operating lights	41	98272076
Interface and operating lights	41 + 42	98272077
Pressure relief	41	98272079
Interface and pressure relief	41 + 42	98272081

To assign GENIbus numbers to the IO 351 module(s), if any, proceed as follows:

1. Switch on the power supply to the Control MPC.
  2. Switch on the R100 or Grundfos GO Remote and point it at the IR window of the first IO 351 to make contact with this module.

**If there is more than one IO 351, move close to the IR window to make sure that only one module is communicating with the R100 or Grundfos GO Remote at a time.**




**Fig. 11** IR window of the IO 351

- For R100 remote control, go to the first display in the installation menu "Number, IO 351". Set the address of the module according to the table in section 6.2.1 *Setting the GENIbus number in IO 351 modules, if any*.



**Fig. 12** Installation menu, "Number, IO 351"

- For Grundfos GO Remote, go to the "NUMBER" display under Settings. Set the address of the module according to the table in section 6.2.1 *Setting the GENIbus number in IO 351 modules, if any.*



**Fig. 13** Grundfos GO Remote

- Send the number to the unit by pressing [OK] on the R100 or Grundfos GO Remote.
  - Switch off the R100 or Grundfos GO Remote.
  - Repeat steps 2 to 5 for each IO 351 module.

### **6.2.2 Configuration of the CU 352**

To make the system work properly, the CU 352 in the Control MPC must be configured with a number of GSC files (Grundfos Standard Configuration files).

- Control MPC requires a "Control MPC GSC file" which includes information about the system type in question (E, ES, ED, etc.) and the number of main pumps in the system.
  - Control MPC based on one or two IO 351B modules with the designation numbers A01 and A03 requires a "Control MPC options - GSC file".
  - Hydro MPC requires a Hydro MPC GSC file describing the discharge pressure, sensor range and dry-running protection type.
  - Hydro MPC fitted with a redundant primary sensor requires a "Hydro MPC options - GSC file".
  - Hydro MPC requires a "Pump data GSC file" describing the performance curve of the pump in question.  
If a pilot pump is connected, a file describing the performance curve of the pilot pump in question must be loaded.

Note the right order of configuration:

1. Control MPC
  2. Control MPC options
  3. Hydro MPC
  4. Hydro MPC options
  5. Pump data
  6. Pilot pump data, if any
  7. Service contact information, if any.

## Configuration of Control MPC

**Example:** Hydro MPC-ES with three pumps CRIE 5-8.

Control MPC has two options, "Interface I/O module" and "Operating lights module".

Hydro MPC has one option, "Redundant sensor, 16 bar".

The printed label of GSC files will look like this:


**Fig. 14** Example of a printed label of GSC files

**After each GSC file download (if no further configurations are to be made), restart the CU 352 by clicking [Restart] in the right bottom of the PC Tool.**

*When you click [Restart], the CU 352 will initialise. This procedure takes about 25 seconds.*

## Step-by-step configuration of Control MPC

- Set all automatic circuit breakers covering the pumps to off.
- Connect the PC Tool to the service connection (TTL port) or USB connection on the CU 352.



TM05 4754 2512

**Fig. 15** Service connection (TTL)

TM05 4753 2512

**Fig. 16** USB connection

- Switch on the power supply to the Control MPC.
- Start the PC Tool E-products.
- When communication has been established, the PC Tool "Network list" will display the icons for the CU 352 and the IO 351 module(s), if any.
- Select the CU 352 in the "Network list".
- Select the PC Tool function "Standard configuration". [F6].
- Select "Application" in "Search by".

**Standard configuration**

Search by

- Number
- Application**
- My Files

Application search

Applications

- 1. Control MPC
- 2. Control MPC options
- 3. Hydro MPC
- 4. Hydro MPC options
- 5. Pump data MPC
- 6. Pilot pump data
- 7. Service contact information
- Basic Multi Pump Controller

**Search Now**

TM05 4440 2312

- Click the required application.

**Standard configuration**

Search by

- Number
- Application**
- My Files

Application search

1. Control MPC

Number of pumps: **2 pumps**

System type: **ES**

Save selection

**Search Now**

TM05 4441 2312

- From the drop-down menus, select the configuration of the current application.

- When the selection has been made, click [Search Now] and the configuration file will appear.

**Configuration files**

Configuration No.	Number of pumps	System type	Description	Modified
96307031	2 pumps	ES	SW,MPC,Control/ES/2/No/No	2008-04-02 11:58

Found: 1

**Compare** **Restart** **Send...**

TM05 4442 2312

- A configuration file is now available as a result of the previous selections. In the "Configuration files" field, details on the configuration files can be found. Make sure that these details are correct and apply to the system.
- Select the file from the "Configuration files" field and click [Send].

**Standard configuration**

Search by

- Number**
- Application
- My Files

Number search

Configuration No.

1. Control MPC	3. Hydro MPC	GRUNDFOS
6307031		X
2. C-MPC Options	4. H-MPC Options	5. Pump Data

CONFIGURATION STEPS - PLEASE FOLLOW THE NUMBERS 96586126

**Send configuration file with original numbers on product label.**

**Search Now**

TM05 4466 2312

- Select "Number" in "Search by".
- Check that the selected configuration file number is now shown in the label under "1. Control MPC". This indicates that the CU 352 has received and stored the GSC file.

Follow the procedure described above to find and send the configuration files for the remaining applications:

- Control MPC options
- Hydro MPC
- Hydro MPC options
- Pump data
- Pilot pump data, if available
- Service contact information, if available.

If no further configurations are to be made, restart the CU 352 by clicking [Restart] in the right bottom of the PC Tool.

### 6.2.3 Configuration of external frequency converters, if any

The manufacturer's factory settings of the external frequency converter(s) used in Hydro MPC F, EF and EDF must be changed to the Grundfos settings before the MPC is ready for test.

To configure the external frequency converter:

1. Switch on the power supply to the frequency converter(s) by means of the automatic circuit breaker.
2. For each frequency converter, make the settings as described in the table below.

#### VLT 2800

Press [QUICK MENU] + [+] to access all parameters.

Parameter	Factory setting			Grundfos setting		
	Function	Value or number in display of VLT		Function	Value or number in display of VLT	
		Value	Number of function		Value	Number of function
001	Language	English	[0]	Language	_2	-
101	Torque characteristic	Constant torque	[1]	Torque characteristic	Variable torque low	[2]
					Variable torque medium	[3]
102	Motor power	-	-	Motor power	_3	-
103	Motor voltage	230/400 V	-	Motor voltage	_3	-
104	Motor frequency	50 Hz		Motor frequency	_3	-
105	Motor current		-	Motor current	_3	-
106	Rated motor speed		-	Rated motor speed	_3	-
128	Thermal motor protection	No protection <sup>1</sup>	[0]	Thermal motor protection	Thermistor trip, LC filter connected <sup>1</sup>	[2]
					No thermal protection, LC filter not connected <sup>1</sup>	[0]
136	Slip compensation	100 %	-	Slip compensation	0 %	-
202	Output frequency high limit	132 Hz	-	Output frequency high limit	_4	-
205	Maximum reference	50 Hz	-	Maximum reference	_4	-
207	Ramp-up time 1	3 sec.	-	Ramp-up time 1	1 sec.	-
208	Ramp-down time 1	3 sec.	-	Ramp-down time 1	1 sec.	-
303	Digital input 19	Reversing	[9]	Digital input 19	Thermistor, LC filter connected <sup>1</sup>	[25]
					No function, LC filter not connected <sup>1</sup>	[0]
405	Reset function	Manual reset	[0]	Reset function	Auto reset x 10	[10]
412	Variable switching frequency	Without LC filter	[2]	Variable switching frequency	LC filter connected	[3]
					Without LC filter	[2]

<sup>1</sup> Thermistor function used for thermal protection of LC filter.

<sup>2</sup> For information about languages available, see relevant documentation.

<sup>3</sup> Use data from the Hydro MPC booster system.

<sup>4</sup> 51 Hz for a 50 Hz supply and 61 Hz for a 60 Hz supply.

#### Factory settings of VLT 2800

To recall the factory settings of all parameters, follow the procedure below:

1. Disconnect the power supply.
2. Press and hold [QUICK MENU] + [+] + [CHANGE DATA] and reconnect the power supply.
3. All parameters are now reset to the factory setting, except the fault log.

**VLT 6000**

Press [EXTEND MENU] to access all parameters.

Parameter	Factory setting			Grundfos setting		
	Function	Value or number in display of VLT		Function	Value or number in display of VLT	
		Value	Number of function		Value	Number of function
001	Language	-	-	Language	- <sup>2</sup>	-
102	Motor power	-	-	Motor power	- <sup>3</sup>	-
103	Motor voltage	-	-	Motor voltage	- <sup>3</sup>	-
104	Frequency	50 Hz		Frequency	- <sup>3</sup>	-
105	Motor current	-	-	Motor current	- <sup>3</sup>	-
106	Rated motor speed	-	-	Rated motor speed	- <sup>3</sup>	-
117	ETR trip1	-	4	Thermistor trip, LC filter connected <sup>1</sup>	-	2
				No thermal protection, LC filter not connected <sup>1</sup>	-	0
202	Maximum frequency	50 Hz	-	Maximum frequency	- <sup>4</sup>	-
205	Maximum reference frequency	50 Hz	-	Maximum reference frequency	- <sup>4</sup>	-
206	Ramp-up time	-	-	Ramp-up time	1 sec.	-
207	Ramp-down time	-	-	Ramp-down time	1 sec.	-
303	Reverse	-	1	No function	-	0
323	Alarm	-	8	Ready	-	1
400	Manual reset	-	0	Auto reset x 10	-	6
408	ASFM, adjustable switching frequency modulation	-	0	LC filter connected	-	2
				LC filter not connected	-	0

<sup>1</sup> Thermistor function used for thermal protection of LC/RFI filter.<sup>2</sup> For information about languages available, see relevant documentation.<sup>3</sup> Use data from the Hydro MPC booster system.<sup>4</sup> 51 Hz for a 50 Hz supply and 61 Hz for a 60 Hz supply.**Factory settings of VLT 6000**

To recall the factory settings of all parameters, follow one of the procedures below:

**Procedure 1**

1. Set parameter 620 to (3).
2. Disconnect the power supply.
3. Reconnect the power supply.
4. All parameters are now reset to the factory setting, except the fault log.

**Procedure 2**

1. Disconnect the power supply.
2. Press and hold [DISPLAY MODE] + [CHANGE DATA] + [OK] and reconnect the power supply.
3. All parameters are now reset to the factory setting, except the fault log.

**VLT FC 100**

Press [EXTEND MENU] to access all parameters.

Parameter	Factory setting			Grundfos setting		
	Function	Value or number in display of VLT		Function	Value or number in display of VLT	
		Value	Number of function		Value	Number of function
001	Language	English	[0]	Language	-2	-
002	Motor speed unit	RPM	[0]	Motor speed unit	Hz	[1]
120	Motor power	-	-	Motor power	-3	-
122	Motor voltage	-	-	Motor voltage	-3	-
123	Motor frequency	50 Hz	-	Motor frequency	-3	-
124	Motor current	-	-	Motor current	-3	-
125	Rated motor speed	1460 RPM	-	Rated motor speed	-3	-
190	Motor thermal protection	ETR trip 1	[4]	Thermistor trip, LC filter connected <sup>1</sup>	Thermistor trip	[2]
				No thermal protection, LC filter not connected <sup>1</sup>	No protection	[0]
419	Maximum output frequency	100 Hz		Maximum output frequency	51 Hz	-
303	Maximum reference	50 Hz		Maximum reference	-4	-
341	Ramp 1 ramp-up time	-	-	Ramp 1 ramp-up time	1 sec.	-
342	Ramp 1 ramp-down time	-	-	Ramp 1 ramp-down time	1 sec.	-
511	Digital input 19	Reversing	[10]	No operation	-	[0]
540	Relay 1	Alarm	[9]	Relay 1	Drive ready	[2]
	Relay 2	Running	[5]	Relay 2	Control ready	[1]
1420	Reset mode	Manual reset	[0]	Auto reset x 10	-	[10]
1401	Switching frequency	4.0 Hz	[6]	Switching frequency	5.0 Hz	[7]
					-	

<sup>1</sup> Thermistor function used for thermal protection of LC/RFI filter.

2 For information about languages available, see relevant documentation.

3 Use data from the Hydro MPC booster system.

4 51 Hz for a 50 Hz supply and 61 Hz for a 60 Hz supply.

**Factory setting of VLT FC 100**

To recall the factory settings of all parameters, follow one of the procedures below:

**Procedure 1**

1. Set parameter 14-22.
2. Press [OK].
3. Select "Initialisation" (for NLCP select "2").
4. Press [OK].
5. Disconnect the power supply.
6. Reconnect the power supply.
7. All parameters are now reset to the factory setting, expect RFI 1, protocol, address, baud rate, minimum response delay, maximum response delay, maximum inter.char delay, operating data, historic log and fault log.

**Procedure 2**

1. Disconnect the power supply.
2. Press and hold [STATUS] + [MAIN MENU] + [OK] and reconnect the power supply.
3. All parameters are now reset to the factory setting, expect the number of operating hours, power-ons and overtemperature and overvoltage faults.

#### 6.2.4 Step-by-step configuration of E-pump(s), if any

Before the Hydro MPC system is ready for test, the E-pumps have to be set.

- Switch on the power supply to the E-pumps by means of the automatic circuit breaker.
- Set the GENIbus number to the same number as that of the pump using the R100 or Grundfos GO Remote.

(Number = 1 for pump No 1, etc. Pilot pumps are set to GENIbus number 10.)

**Note** Number the pumps from left to right, always starting with the E-pumps.




Fig. 17 Pumps numbered from left to right

If a PC with PC Tool E-products is already connected via the service connection on the back of the CU 352, start at step 4. If not, start from step 1.

1. Connect your PC with PC Tool to the service connection on the back of the CU 352.
2. Start the PC Tool E-products.
3. When communication has been established, the PC Tool "Network list" will display the icons for the pumps installed.
4. Select the pump you want to configure from the "Network list".
5. Select the PC Tool function "Standard configuration".
6. Go to section "Search by" and select "Number".
7. Find the relevant GSC file number from the table below.
8. Enter the GSC file number in the "Configuration No" field and click [Search Now].
9. Select the file from the field "Configuration files" and click [Send].
10. Repeat steps 4 to 9 for each E-pump.

#### GSC file number

Application	GSC file number
MGE 1Ph HM2MKII (model C)	95139670
MGE 3Ph HM3MKII (model D)	95139671
MGE 3Ph HMLarge (model F)	95139672
MGE 3Ph HM3MK11 (model G)	97913788
MGE 1Ph/3Ph Saver (model H/I)*	98428069
MGE 1Ph/3Ph Saver (model H/I)**	98428068

\* For MPC-E 50/60 Hz and MPC-ED / MPC-ES 60 Hz.

\*\* For MPC-ED / MPC-ES 50 Hz.

#### Configuration of the CUE(s), if any

The manufacturer's factory settings of the CUE used in Control MPC must be changed to the Control MPC settings before it is ready to test.

To configure the CUE:

1. Switch off the power supply to the CUE(s) by means of the automatic circuit breaker.
  2. Connect the PC Tool to the GENIbus terminals of the CUE which you want to configure.
  3. Switch on the power supply to the CUE.
  4. Start the PC Tool E-products.
  5. When communication has been established, the PC Tool "Network list" will display the icon for the CUE.
  6. Select the CUE in the "Network list".
  7. Select the PC Tool function "Custom configuration".
  8. Go to section "GENIbus", and set the unit number to the same number as that of the CUE.
- (Number = 1 for CUE No 1, etc. Pilot pumps are set to 10.)
- Note:** Steps 7 and 8 are not necessary for the CUE in Hydro MPC-F.
9. Go to section "General", select "Pump Family" and enter motor data. See fig. 7.
- Note:** Motor data are to be read from the motor nameplate.




Fig. 18 "Custom configuration" (general)

10. Select the PC Tool function "Standard configuration".
11. Go to section "Search by" and select "Number".
12. Enter the GCS file number "96890456" in the "Configuration No" field and click [Search Now].
13. Select the file from the "Configuration files" field and click [Send].
14. Switch on the power supply to the next CUE with the main switch, and repeat steps 6 to 13 for each CUE.

## **7. Danfoss frequency converters**

For further documentation on Danfoss frequency converters, see the manual supplied with the frequency converter, or download it from <http://www.danfoss.com>.

## **8. CUE**

Service instructions, see WebCAPS.

Service instructions, extended, see GTI.

## **9. MGE**

Service instructions, see WebCAPS.

Service instructions, extended, see GTI.

## **10. Disposal**

This product or parts of it must be disposed of in an environmentally sound way:

1. Use the public or private waste collection service.
2. If this is not possible, contact the nearest Grundfos company or service workshop.

---

Subject to alterations.



## **Argentina**

Bombas GRUNDFOS de Argentina S.A.  
Ruta Panamericana, ramal Campana Centro Industrial Garín - Esq. Haendel y Mozart  
AR-1619 Garín Pcia. de Buenos Aires  
Pcia. de Buenos Aires  
Phone: +54-3327 414 444  
Telefax: +54-3327 45 3190

## **Australia**

GRUNDFOS Pumps Pty. Ltd.  
P.O. Box 2040  
Regency Park  
South Australia 5942  
Phone: +61-8-8461-4611  
Telefax: +61-8-8340 0155

## **Austria**

GRUNDFOS Pumpen Vertrieb Ges.m.b.H.  
Grundfosstraße 2  
A-5082 Grödig/Salzburg  
Tel.: +43-6246-883-0  
Telefax: +43-6246-883-30

## **Belgium**

N.V. GRUNDFOS Bellux S.A.  
Boomsesteenweg 81-83  
B-2630 Aartselaar  
Tél.: +32-3-870 7300  
Télécopie: +32-3-870 7301  
**Belarus**  
Представительство ГРУНДФОС в Минске  
220125, Минск  
ул. Шафферянская, 11, оф. 56  
Тел.: +7 (375 17) 286 39 72, 286 39 73  
Факс: +7 (375 17) 286 39 71  
E-mail: minsk@grundfos.com

## **Bosnia/Herzegovina**

GRUNDFOS Sarajevo  
Trg Heroja 16,  
BiH-71000 Sarajevo  
Phone: +387 33 713 290  
Telefax: +387 33 659 079  
e-mail: grundfos@bih.net.ba

## **Brazil**

BOMBAS GRUNDFOS DO BRASIL  
Av. Humberto de Alencar Castelo Branco, 630  
CEP 09850 - 300  
São Bernardo do Campo - SP  
Phone: +55-11 4393 5533  
Telefax: +55-11 4343 5015

## **Bulgaria**

Grundfos Bulgaria EOOD  
Slatina District  
Iztochna Tangenta street no. 100  
BG - 1592 Sofia  
Tel. +359 2 49 22 200  
Fax. +359 2 49 22 201  
email: bulgaria@grundfos.bg

## **Canada**

GRUNDFOS Canada Inc.  
2941 Brighton Road  
Oakville, Ontario  
L6H 6C9  
Phone: +1-905 829 9533  
Telefax: +1-905 829 9512

## **China**

GRUNDFOS Pumps (Shanghai) Co. Ltd.  
50/F Maxdo Center No. 8 XingYi Rd.  
Hongqiao development Zone  
Shanghai 200336  
PRC  
Phone: +86 21 612 252 22  
Telefax: +86 21 612 253 33

## **Croatia**

GRUNDFOS CROATIA d.o.o.  
Cebini 37, Buzin  
HR-10010 Zagreb  
Phone: +385 1 6595 400  
Telefax: +385 1 6595 499  
www.grundfos.hr

## **Czech Republic**

GRUNDFOS s.r.o.  
Čajkovského 21  
779 00 Olomouc  
Phone: +420-585-716 111  
Telefax: +420-585-716 299

## **Denmark**

GRUNDFOS DK A/S  
Martin Bachs Vej 3  
DK-8850 Bjerringbro  
Tlf.: +45-87 50 50 50  
Telefax: +45-87 50 51 51  
E-mail: info\_GDK@grundfos.com  
www.grundfos.com/DK

## **Estonia**

GRUNDFOS Pumps Eesti OÜ  
Peterburi tee 92G  
11415 Tallinn  
Tel: + 372 606 1690  
Fax: + 372 606 1691

## **Finland**

OY GRUNDFOS Pumpum AB  
Mestarintie 11  
FIN-01730 Vantaa  
Phone: +358-(0)207 889 900  
Telefax: +358-(0)207 889 550

## **France**

Pompes GRUNDFOS Distribution S.A.  
Parc d'Activités de Chesnes  
57, rue de Malacombe  
F-38290 St. Quentin Fallavier (Lyon)  
Tél.: +33-4 74 82 15 15  
Télécopie: +33-4 74 94 10 51

## **Germany**

GRUNDFOS GMBH  
Schlüterstr. 33  
40699 Erkrath  
Tel.: +49-(0) 211 929 69-0  
Telefax: +49-(0) 211 929 69-3799  
e-mail: infosoftware@grundfos.de  
Service in Deutschland:  
e-mail: kundendienst@grundfos.de

## **Belarus**

be think innovate

---

98394087 0513

ECM: 1114870

[www.grundfos.com](http://www.grundfos.com)

**GRUNDFOS** 

© Copyright Grundfos Holding A/S

The name Grundfos, the Grundfos logo, and be think innovate are registered trademarks owned by Grundfos Holding A/S or Grundfos A/S, Denmark. All rights reserved worldwide.