



# Easy CON Media Converter

User Manual  
(Translation of Original docu)  
Document Version 1.2

**© 2015 GOEPEL electronic GmbH. All rights reserved.**

The software described in this manual as well as the manual itself are supplied under license and may be used or copied only in accordance with the terms of the license.  
The customer may make one copy of the software for safety purposes.

The contents of the manual is subject to change without prior notice and is supplied for information only.

The hardware and software might be modified also without prior notice due to technical progress.

In case of inaccuracies or errors appearing in this manual, GOEPEL electronic GmbH assumes no liability or responsibility.

Without the prior written permission of GOEPEL electronic GmbH, no part of this documentation may be transmitted, reproduced or stored in a retrieval system in any form or by any means as well as translated into other languages (except as permitted by the license).

GOEPEL electronic GmbH is neither liable for direct damages nor consequential damages from the company's product applications.

Printed: 22.09.2015

All product and company names appearing in this manual are trade names or registered trade names of their respective owners.

**Issue: September 2015**

**1 CONCEPT OF THE DEVICE.....1-1**

**2 USE OF THE DEVICE .....2-1**

2.1 SPECIFICATIONS AND CONNECTIONS .....2-1

    2.1.1 *Technical Data* .....2-1

    2.1.2 *Connection*.....2-2

    2.1.3 *Liability and Warranty Limitation*.....2-2

2.2 INTERFACES .....2-3

    2.2.1 *Node 1*.....2-3

    2.2.2 *Node 2*.....2-3

    2.2.3 *Status LEDs*.....2-5

2.3 FIRST STEPS .....2-6

**3 ACCESSORIES.....3-1**



# 1 Concept of the Device

The **Easy CON** device from **GOPEL electronics** connects automotive Ethernet networks using one pair **BroadR-Reach** Ethernet as physical-layer to standard LAN networks with 10Base-T/ 100Base-Tx physical-layer. The device comes with RJ45 connectors on both links. This allows the use of shielded standard low-cost high-quality cables (CAT5 or CAT6) for the test-setup. For easy connection to the ECU cabling harness, an adapter cable with 9-Pol. D-Sub connector is included.

The **Easy CON** Media Converter can be operated as **BroadR-Reach** Master or Slave. Selection is easily done via a switch on the device's rear plate (not visible in the following figure).



*Figure 1-1:  
Easy CON*



## 2 Use of the Device

### 2.1 Specifications and Connections

#### 2.1.1 Technical Data

##### Easy CON Media Converter

- ◆ Baud rate: 10 MBit/s, 100 MBit/s (full duplex)
- ◆ Forward Delay BroadR Reach to 100Tx: 940 ns
- ◆ Forward Delay 100Tx to BroadR Reach: 280 ns
- ◆ DC Supply voltage: 4.75 V...5.25 V according to USB Specification (micro-USB socket)
- ◆ DC Input power: 2 W
- ◆ Operating temperature: -40 °C...+80 °C
- ◆ Protection: IP 20
- ◆ Dimensions: 24 mm x 63.6 mm x 80 mm (H x W x D)
- ◆ Weight: 112 g

##### Power supply

- ◆ Cable length: 1 m
- ◆ Output connector: micro USB
- ◆ AC Input voltage: 90 V...264 V
- ◆ AC Input current: max. 250 mA
- ◆ DC Output voltage: 5 V
- ◆ DC Output current: max. 1000 mA
- ◆ Plug type: Euro
- ◆ Power rating: 5 W
- ◆ Ripple and Noise: 200 mV Pk-Pk
- ◆ Efficiency: 74 %
- ◆ Type: Switch mode
- ◆ Class: 2
- ◆ Weight: 80 g
- ◆ Input plug type: EU, US, UK, SAA (Interchangeable Mains Connectors included)
- ◆ Safety Approval: IEC60950-1, UL/cUL60950-1 (LPS)



*Figure 2-1:  
Power supply*

### 2.1.2 Connection

**Node 1** ("Ethernet" socket) must be connected to a 10Base-T/100Base-Tx Fast Ethernet device. This can be an Ethernet Switch or another Ethernet card (e.g. PC). Most Ethernet cards will support 10Base-T/100Base-Tx Baud rate, otherwise use an Ethernet Switch to connect to 1000Base-Tx networks.

Use CAT5 or CAT6 patch cables. The use of crossover cables is not required: The **Easy CON** device has an integrated Auto-crossover Switch, detects the required connection type and configures the connection appropriately.

**Node 2** ("BroadR-Reach" socket) must be connected to a **BroadR-Reach** Ethernet device. Use CAT5 or CAT6 patch cables or the provided D-Sub 9-pol. Adapter.

Please note: **BroadR-Reach** Ethernet devices can be either link master or link slave.

If the connecting device is a link master, then the **Easy CON** device must be configured as slave. If the connecting device is a link slave, then the **Easy CON** device must be configured as master. Use the Master/ Slave sliding switch at the rear plate near the **BroadR-Reach** socket for this.

Please connect the micro USB connector to the **Easy CON** device and plug the enclosed power-supply into a wall-outlet.

### 2.1.3 Liability and Warranty Limitation

The **Easy CON** media converter is not intended and has not been designed and tested for use in a safety relevant application. Do not use the device for any safety relevant system or sub-system inside a vehicle.

Using such a device inside a vehicle to control vehicle main functions can be dangerous and cause the whole vehicle to malfunction.

In no event shall **GOPEL electronics** be liable for any direct, indirect, incidental, special, exemplary, or consequential damages (including, but not limited to procurement of substitute goods or services; loss of use, data, or profits; business interruption; injury or possible loss of life) arising in any way resulting from the use of the **Easy CON** media converter device.



## 2.2 Interfaces

- 2.2.1 Node 1 „Ethernet“ socket  
Physical layer: 10Base-T/ 100Base-Tx Fast Ethernet  
Auto-crossover MDI-X  
Connector type: R45 socket with Status LEDs

Pin	10/100 BaseTx
1	Tx+
2	Tx-
3	Rx+
4	not connected
5	not connected
6	Rx-
7	not connected
8	not connected

- 2.2.2 Node 2 Physical layer: BroadR-Reach one pair Ethernet  
Connector type: R45 socket with Status LEDs

Pin	BroadR-Reach
1	TRx+
2	TRx-
3	not connected
4	not connected
5	not connected
6	not connected
7	not connected
8	not connected

Adapter cable RJ45 to D-Sub 9-poles included in delivery  
(CAT6 Patch cable truncated to D-Sub 9-poles TRx+ (Pin 4)  
and TRx- (Pin 5), Shield (Pin 3), plastic cover

Pin-out D-Sub Adapter cable

D-Sub (plug)		RJ45	
Pin	BroadR-Reach	Pin	BroadR-Reach
1	not connected	1	TRx+
2	not connected	2	TRx-
3	Shield	3	not connected
4	TRx+	4	not connected
5	TRx-	5	not connected
6	not connected	6	not connected
7	not connected	7	not connected
8	not connected	8	not connected
9	not connected		

### 2.2.3 Status LEDs

**Easy CON** provides some information regarding the device operating status and the status of the two links.

The individual **Status LED** at the front side indicates the following states:

- ◆ **YELLOW** constant on: Device initialization (after RESET)
- ◆ **GREEN** alternating: **BroadR-Reach Link** search
- ◆ **GREEN** constant on: **Broad-R Reach Link/ no 10BaseT/100BaseTx Link** stable
- ◆ **BLUE** constant on: **Broad-R Reach Link/ 10BaseT/100BaseTx Link** stable
- ◆ **RED** alternating: Operational malfunction
- ◆ **RED** constant on: Hardware malfunction

#### **10BaseT/100BaseTx Phy Status LEDs** (socket near power supply)

10BaseT/100BaseTx Phy Status LED 1 (left)

- ◆ **GREEN** constant on: **10BaseT/100BaseTx Link** stable
- ◆ **GREEN** alternating: Link activity – carrier found

10BaseT/100BaseTx Phy Status LED 2 (right)

- ◆ **YELLOW** constant on: Link speed 100 Mbps
- ◆ **OFF**: Link speed 10 Mbps

#### **BroadR-Reach Phy Status LEDs** (socket near sliding switch)

BroadR-Reach Phy Status LED 1 (left)

- ◆ **YELLOW** constant on: **Broad R Reach Link** stable

BroadR-Reach Phy Status LED 2 (right)

- ◆ **GREEN** alternating: Link activity

## 2.3 First Steps

1. Connect your **Easy CON** device via the supplied USB cable with the supplied Wall Power Supply
2. Set the Sliding switch at the **Easy CON** to **Master** or **Slave** according to the application
3. Plug in the **Network cable** and **BroadR-Reach Adaptor** according to the inscription of the casting
4. In the case the Status-LED shines **blue**, a stable **BroadR-Reach** connection as well as a stable **Network**-connection have been established



You may download this documentation also under [www.goepel.com/automotive-test-solutions/easycon-brr](http://www.goepel.com/automotive-test-solutions/easycon-brr).

## 3 Accessories

As accessory for Easy CON the following devices are delivered:

- ◆ 1 Wall Power Supply (Figure 2-1)
- ◆ 1 Adapter cable RJ45 to D-Sub 9-poles



---

**A**

Accessories .....3-1  
Adapter cable .....2-4

---

**C**

Concept of the device .....1-1  
Conectons .....2-2

---

**E**

Easy CON  
Technical data .....2-1

---

**F**

First steps .....2-6

---

**I**

Interfaces .....2-3

---

**L**

LEDs.....2-5

---

**W**

Wall power supply .....3-1