



# Contents

◆ <b>PREPARATION</b>	
■ Safety Precautions .....	3
■ Name of Each Part .....	8
■ Remote Control – Buttons and Display .....	10
■ Inserting the Remote Control Batteries .....	11
■ Getting Started .....	12
◆ <b>OPERATION</b>	
■ Selecting Auto Mode .....	13
■ Selecting Cool Mode .....	14
■ Selecting Heat Mode .....	15
■ Selecting Dry Mode .....	16
■ Selecting Fan Mode .....	17
■ Selecting Good Sleep Mode .....	18
■ Selecting the Turbo Function .....	20
■ Adjusting the Airflow Direction Vertically .....	21
■ Adjusting the Airflow Direction Horizontally.....	21
■ Setting the On Timer .....	22
■ Setting the Off Timer .....	23
■ Operating Your Air Conditioner Without the Remote Control .....	24
◆ <b>RECOMMENDATIONS FOR USE</b>	
■ Cleaning Your Air Conditioner .....	25
■ Cleaning Deodorizing and Bio filter(Optional) .....	25
■ Temperature and Humidity Ranges .....	26
■ Operating Recommendations .....	26
■ Solving Common Problems .....	27
■ Periodical Checks .....	28
■ Protections enabled by the Unit control system .....	29



## **Correct Disposal of This Product (Waste Electrical & Electronic Equipment)**

### ***(Applicable in the European Union and other European countries with separate collection systems)***

This marking shown on the product or its literature, indicates that it should not be disposed with other household waste at the end of its working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of waste and recycle it responsibly to promote the sustainable reuse of material resources.

Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract.

This product should not be mixed with other commercial waste for disposal.

Register your product at [www.samsung.com/global/register](http://www.samsung.com/global/register)

## Safety Precautions

*The following safety precautions are provided to protect the users' safety and prevent property damage. Make sure to read the followings and use the air conditioner properly.*

- ▶ Keep this user's manual together with the installation manual in a handy place so that you can find it whenever you need to see it after reading this manual thoroughly.



### WARNING

- This indicates the possibility of serious injury or death.




### CAUTION

- This indicates the possibility of serious injury or damage to environments when operated incorrectly.


### WHEN INSTALLING



- ▶ Do not install the unit in a place where it is exposed to inflammable gas leakage.



- ▶ Do not install the outdoor unit where there's the risk of dropping such as on high outer wall or outside of the terrace.



- ▶ Do not connect the ground to a gas pipe, water pipe, lightning rod or telephone earth.



- ▶ Contact the service center if the air conditioner is under water.



- ▶ The installation must be carried out by a licensed installer or qualified personnel when installing the unit for the first time or reinstalling it.


### REGARDING POWER SOURCE



- ▶ Do not pull the electric wire or touch the power plug with the wet hands.



- ▶ Install the switch and circuit breaker only for air conditioner.



- ▶ Use the rated current fuse.



- ▶ Do not bend the electric wire by force or weigh down the air conditioner not to be out of order.



- ▶ Use the power source with separate wiring only for air conditioner.




- ▶ If the power plug is damaged, replace it by the manufacturer or qualified personnel to avoid the risk.




## WARNING

### DURING OPERATION




- ▶ Do not attempt to repair, move, modify or reinstall the unit on your own. Make sure that these installations are carried out by qualified personnel to avoid electric shock or fire.




- ▶ Do not place any obstacles in front of the unit. Make sure that the unit is correctly ventilated at all times: Do not place clothing or other materials over it.




- ▶ Do not insert anything between the air outlet blades because the inner fan may be damaged and could cause injury. Keep children away from the unit.



- ▶ When using a wireless remote control, the distance should not be more than 7 meters from the air conditioner. (If applicable)




- ▶ The manufacturer declines any liability for damage resulting from modifications or errors in the electrical or hydraulic connections.




- ▶ Failure to observe the installation instruction, or use of the unit under conditions other than those indicated in the table 'Operating limit' of the unit installation manual, will immediately invalidate the unit warranty.



- ▶ Never spill any kind of liquid into the unit. Should this happen, unplug or main switch off the unit and contact an authorized service center.



- ▶ If the wireless remote control is not used for a long time, remove the batteries. (If applicable)



- ▶ Do not connect the electric heater to the air conditioner or repair it with your discretion.




- ▶ Do not place any materials so that children cannot step on it.




## WARNING

### DISPOSING THE UNIT



- Before throwing out the device, it is necessary to pull back the battery cells and get rid of them safely for recycling reasons.



- When you need to dispose of the unit, consult your dealer. If pipes are removed incorrectly, refrigerant may blow out and come into contact with your skin, causing injury. Releasing refrigerant into the atmosphere also damages the environments.




- Please recycle or dispose of the packaging material for this product in an environmentally responsible manner.




## CAUTION


### WHEN INSTALLING



- Install the air conditioner avoiding direct sunlight or heater, especially water.



- Install the outdoor unit so as to let the discharged air out properly. Avoid a place that may disturb your neighbor by noise.



- Install the drain hose to let the water run safely and correctly.



## CAUTION

### REGARDING POWER SOURCE



- ▶ Disconnect the circuit breaker when you don't use the air conditioner for a long time to save energy.




- ▶ Contact the service center or manufacturer if you want to repair the air conditioner.




- ▶ Contact the service center after turning off the air conditioner if strange noise is heard, burning smell or smoke blow.


### DURING OPERATION



- ▶ Do not open the front grille during operation.



- ▶ Do not use the air conditioner for a long time in a closed room or in a place where there's a baby or an old person.




- ▶ Avoid cold and hot air reaching to person, pet or a plant directly for a long time.



- ▶ Do not step on the air conditioner or put heavy object on it.




- ▶ Avoid the water from getting into the air conditioner.




- ▶ Do not drink the water from the air conditioner.

# **CAUTION**


## **DURING OPERATION**



- ▶ Do not touch the pipes connected to the air conditioner.




- ▶ Do not use the air conditioner to maintain the machine, food, pet, plant or cosmetics.




- ▶ Do not give excessive shock to the air conditioner.

## **OTHERS**



- ▶ Be sure that the air filter not to be exposed to direct sunlight.




- ▶ Turn off the air conditioner and if the fan stops to operate, clean the air conditioner.



- ▶ Clean the air filter every 2 weeks.



- ▶ Be sure to insert the air filter.



- ▶ The appliance is not intended for use by young children or infirm persons without supervision: Young children should be supervised to ensure that they do not play with the appliance.




- ▶ Do not clean the air conditioner by spraying water directly or with benzene, thinner or alcohol.




- ▶ Dispose of the packaging material in accordance with the local requirements.



- ▶ The maximum input power & current is measured according to the IEC standard and the input power & current is measured according to the ISO standard.



- ▶ The surface of the heat exchanger is sharp, so be careful of it when cleaning.





- ▶ All of the manufacturing and packaging materials used for your new appliance are compatible with the environment and can be recycled.

## Name of Each Part

The design and shape can be changed according to the model.


### Indoor Unit



**MH\*\*\*FN\*A Series**


**Outdoor Unit**

MH050FXCA2A




**Outdoor Unit**

MH080FXCA4A



## Remote Control - Buttons and Display



### Note

- ◆ Each mode indicator shows the current setting and the battery life.
- ◆ You can check the battery life by pressing the <sup>Battery</sup> button.
- ◆ The number of the battery life indicator means the remaining battery life. Replace the batteries when only one battery life indicator remains.

## Inserting the Remote Control Batteries


**You must insert or replace the remote control batteries when:**

- ◆ **You purchase the air conditioner**
- ◆ **The remote control does not work correctly**


**Note**

- ◆ Use two AAA, LR03 1.5V batteries.
- ◆ Do not use old batteries or different kinds of batteries together.
- ◆ Batteries may be completely discharged after 12 months, even if they have not actually been used.

- 1** Remove the battery cover in the rear of the remote control by pushing it with your thumb.



- 2** Insert two batteries, respecting the polarities as indicated by the + and - symbols.






- 3** Close the cover by sliding it back in its place.

# Getting Started

*The User's Manual provides you with valuable information about your air conditioner. In order to take full advantage of the air conditioner's features, please read this manual carefully before using.*

*You have already seen the basic description of the unit on pages from 8 to 10. Starting with the next page, you will find a series of step-by-step procedures for each function available.*

*The illustrations in the step-by-step procedures use three different symbols:*

		
<b>PRESS</b>	<b>PUSH</b>	<b>HOLD DOWN</b>

# Selecting Auto Mode

*You can select the Auto mode if you want to cool or heat your room automatically. You can adjust the temperature and the fan speed in this mode.*

- 1 If necessary, press the  button.


**Result:**

- ◆ The operation indicator on the indoor unit lights up.
- ◆ The air conditioner starts up in the mode you selected last.
- ◆ The indoor unit beeps.






- 2 Press the  button on the remote control until  is displayed.

**Result:**



- ◆ The indoor unit beeps each time you press the  button.
- ◆ The air conditioner runs in the Auto mode.
- ◆ The Auto mode cools or heats the room depending on the set temperature.
- ◆ The air conditioner changes the Cool or Heat mode automatically depending on the current temperature during operation.

*Note* You can change modes at any time.



- 3 Press the  |  button to adjust the temperature until the required temperature is displayed.

You can set the temperature between 61°F(16°C) and 86°F(30°C).

**Result:** Each time you press the  |  button:

- The temperature is adjusted by 1°F
- The indoor unit beeps



- 4 To control the airflow direction, refer to page 21.

## Selecting Cool Mode


**You can select the Cool mode if you want to cool your room.  
You can adjust the temperature and the fan speed when cooling.**





- 1 If necessary, press the  button.


Result:

- ◆ The operation indicator on the indoor unit lights up.
- ◆ The air conditioner starts up in the mode you selected last.
- ◆ The indoor unit beeps.



- 2 Press the  button on the remote control until  is displayed.



Result:

- ◆ The indoor unit beeps each time you press the  button.
- ◆ The air conditioner runs in the Cool mode.

Note



You can change modes at any time.




- 3 Press the  |  button to adjust the temperature until the required temperature is displayed.









You can set the temperature between 61°F(16°C) and 86°F(30°C).

Result:

- ◆ Each time you press the  |  button:
  - The temperature is adjusted by 1°F
  - The indoor unit beeps
- ◆ If the room temperature is higher than the selected temperature, the air conditioner starts cooling.
- ◆ If the room temperature reaches the set temperature, the air conditioner stops cooling, but the fan operates consistently.



- 4 Press the  button to select the fan speed until the required setting is displayed.

-  Automatic (rotated :  →  →  )
-  Low
-  Medium
-  High
-  Maximum

Result:

Each time you press the  button, the indoor unit beeps.

- 5 To control the airflow direction, refer to page 21.

## Selecting Heat Mode

**You can select the Heat mode if you want to heat your room.  
You can adjust the temperature and the fan speed when heating.**


- 1 If necessary, press the  button.

**Result:**



- ◆ The operation indicator on the indoor unit lights up.
- ◆ The air conditioner starts up in the mode you selected last.
- ◆ The indoor unit beeps.

- 2 Press the  button on the remote control until  is displayed.

**Result:**



- ◆ The indoor unit beeps each time you press the  button.
- ◆ The air conditioner runs in the Heat mode.


**Note** You can change modes at any time.





- 3 Press the  |  button to adjust the temperature until the required temperature is displayed.


You can set the temperature between 61°F(16°C) and 86°F(30°C).


**Result:**


- ◆ Each time you press the  |  button:
  - The temperature is adjusted by 1°F
  - The indoor unit beeps
- ◆ If the room temperature reaches 9°F higher than the set temperature, the air conditioner stops heating, but the fan operates consistently.
- ◆ If the room temperature reaches 5°F lower than the set temperature, the air conditioner starts heating again.


- 4 Press the  button to select the fan speed until the required setting is displayed.

 Automatic (rotated :  →  → )


 Low

 Medium


 High

 Maximum

**Result:**


- ◆ Each time you press the  button, the indoor unit beeps.
- ◆ For the first 3~5 minutes, the fan may not operate to prevent the cool air from running out of the indoor unit. It helps to warm the air in your room sufficiently.

- 5 To control the airflow direction, refer to page 21.



## Selecting Dry Mode


**You can select the Dry mode if you want to dehumidify your room.  
You can adjust the temperature in this mode.**



- 1 If necessary, press the  button.


**Result:**

- ◆ The operation indicator on the indoor unit lights up.
- ◆ The air conditioner starts up in the mode you selected last.
- ◆ The indoor unit beeps.





- 2 Press the  button on the remote control until  is displayed.

**Result:**

- ◆ The indoor unit beeps each time you press the  button.
- ◆ The air conditioner runs in the Dry mode.



*Note* You can change modes at any time.



- 3 Press the  |  button to adjust the temperature until the required temperature is displayed.

You can set the temperature between 61°F(16°C) and 86°F(30°C).

**Result:**

- ◆ Each time you press the  |  button:
  - The temperature is adjusted by 1°F
  - The indoor unit beeps
- ◆ The air conditioner starts dehumidifying and the fan speed is adjusted automatically.

- 4 To control the airflow direction, refer to page 21.


## Selecting Fan Mode

**You can select the Fan mode if you want to ventilate your room.  
It helps to refresh the air in your room. You can adjust the fan speed in this mode.**

- 1 If necessary, press the  button.


**Result:**

- ◆ The operation indicator on the indoor unit lights up.
- ◆ The air conditioner starts up in the mode you selected last.
- ◆ The indoor unit beeps.





- 2 Press the  button on the remote control until  is displayed.



**Result:**


- ◆ The indoor unit beeps each time you press the  button.
- ◆ The air conditioner runs in the Fan mode.
- ◆ The temperature is set automatically.

**Note** You can change modes at any time.



- 3 Press the  button to select the fan speed until the required setting is displayed.

	Low
	Medium
	High


**Result:** Each time you press the  button, the indoor unit beeps.



- 4 To control the airflow direction, refer to page 21.

## Selecting Good Sleep Mode


**Good Sleep mode helps users to fall asleep well after going to bed whether being too hot to sleep or being awakened by coldness. The Good Sleep mode can be selected only when the air conditioner is switched on in cool/heat mode.**






- 1 If necessary, press the  button.


**Result:**

- ◆ The operation indicator on the indoor unit lights up.
- ◆ The air conditioner starts up in the mode you selected last.
- ◆ The indoor unit beeps.



- 2 Press the  button to select  or  mode.



**Result:**



- ◆ The indoor unit beeps each time you press the  button.
- ◆ The air conditioner runs in cool or heat mode.





- 3 Press the  button until the  indicator appears on the remote control.

- In the case of adjusting time

- ◆ Press the  button to adjust desired operation time from 1 to 12 hours. Good Sleep mode will automatically stop after the set time.
- ◆ Press the  button.



**Result:** In the case of adjusting the extra time for Good Sleep mode, you should press the  button within 10 seconds. If you do not press the  button within 10 seconds, Good Sleep mode will automatically stop in 8-hour operation.



- 4 Press the  |  button to adjust the temperature until the required temperature is displayed.

You can set the temperature between 61°F(16°C) and 86°F(30°C).

**Result:**

- ◆ Each time you press the  |  button:
  - The temperature is adjusted by 1°F
  - The indoor unit beeps

## Temperature changes in good' sleep mode

To prevent excessive cooling/heating during sleep, the **good' sleep** mode automatically modifies the temperature setting in accordance with the time setting. Temperature and air current change according to the three stages; Falling asleep, Sound sleep, and Waking up from **good' sleep** mode, and then the air conditioner will automatically turn off when the set time has elapsed.

Three stage **good' sleep** prevents you from having difficulty sleeping on extremely hot/cold nights.

① **Falling asleep** : Eases you into sleep by dropping the temperature.


② **Sound sleep** : Relaxes your body and raises your temperature slightly.

③ **Waking up from good' sleep mode** :


Allows you to wake up to comfortable crisp air making you feel refreshed and energized.

- Set the Off timer in **good' sleep** mode for more than 5 hours. Sleep may be disturbed if the **good' sleep** mode is set for too short or too long a time because the temperature changes are set to an 8-hour cycle.
- If the **good' sleep** mode is set for less than 4 hours, the operation will stop at the set time. If the **good' sleep** mode is set for over 5 hours, the last hour will run in Waking Up stage before shutting off.
- Recommended set temperature is between 77°F~81°F for cooling and 69.8°F~73.4°F for heating.

### Cool mode



### Heat mode



## Selecting the Turbo Function

***You can select the Turbo Function if you want to cool or heat your room in the fastest way. After the 30 - minute operation with the maximum setting, it returns to the previous setting.***



- 1 If necessary, press the  button.


Result:

- ◆ The operation indicator on the indoor unit lights up.
- ◆ The air conditioner starts up in the mode you selected last.
- ◆ The indoor unit beeps.

- 2 Press the  button.

Result:

- ◆ The temperature and fan settings are adjusted automatically.
- ◆ The air conditioner cools or heats the room as quickly as possible.
- ◆ After 30 minutes, the air conditioner is reset automatically to the previous setting.
- ◆ You can select the Turbo function in the Auto, Cool and Heat mode. If you select this function in the Dry or Fan mode, the mode changes to the Auto mode.


- 3 Press the  button again to stop the Turbo Function before the end of the 30-minute period.

Result: The air conditioner is reset automatically to the previous setting.


- 4 To control the airflow direction, refer to page 21.

## Adjusting the Airflow Direction Vertically

**You can adjust the airflow direction vertically. The outer airflow blade moves up and down to increase the efficiency of the cooling or heating operation.**

- 1 Press the  button until the required direction is set.

**Result:** The outer blade is adjusted vertically.

- 2 Press the  button to move the blade up and down automatically during operation.

- 3 Press the  button again to stop the blade moving up and down.

*Note*

**If you turn the air conditioner...**

**Then the blade...**

off

is closed completely.

on


set to the default position.






## Adjusting the Airflow Direction Horizontally

**You can adjust airflow direction horizontally manually. The inner blades with small fins move the air in the desired direction.**

- 1 Adjust the inner blades by moving them left or right.
  - ◆ Make sure do not touch the inner blades during operation. It may cause injury on your fingers.



## Setting the On Timer



**You can set the On Timer to turn on the air conditioner automatically at the appointed time. You can set the time from 1 hour to 24 hours.**

- 1 Press the **ON** button until the required time is displayed to set the On Timer. You can set the time between 1 hour and 24 hours.

- 2 Press the **Set/Cancel** button to complete the setting.

**Result:**

- ◆ The remaining time is displayed.
- ◆ The timer indicator stops blinking.
- ◆ The selected mode and the temperature on the display disappear after 10 seconds.
- ◆ The air conditioner turns on automatically at the appointed time and the On Timer setting disappears.

- 3 Press the **Mode** button until the desired mode is displayed at the top of the remote control to select the mode in advance.

**Result:** The air conditioner operates in the selected mode when it is turned on.

### Note

If you don't use the remote control after setting the On Timer, it turns off automatically after 25 hours.

## To Cancel the On Timer


Press the **Set/Cancel** button to cancel the On Timer.

### Note


If you press the **Set/Cancel** button, both the On Timer and the Off Timer are canceled.

# Setting the Off Timer

**You can set the Off Timer to turn off the air conditioner automatically at the appointed time. You can set the time from 1 hour to 24 hours.**

- 1 Press the  button until the required time is displayed to set the Off Timer. You can set the time between 1 hour and 24 hours.










- 2 Press the  button to complete the setting.


**Result:**

- ◆ The remaining time is displayed.
- ◆ The timer indicator stops blinking.
- ◆ The air conditioner turns off automatically at the appointed time and the Off Timer setting disappears.


**Example** If you would like to turn the air conditioner on after 2 hours and to operate it for 2 hours:


1. Press the  button until '2 Hr' is displayed.
2. Press the  button.
3. Press the  button until '4 Hr' is displayed.
4. Press the  button.

**Note** You can check or change the mode and/or the temperature by pressing the  button or the  |  button after setting the Off Timer.




## To Cancel the Off Timer

Press the  button to cancel the Off Timer.

**Note** If you press the  button, both the On Timer and the Off Timer are canceled.



## Operating Your Air Conditioner Without the Remote Control



***Your air conditioner can be operated directly from the indoor unit if the remote control is lost or broken.***

- 1 To switch the air conditioner on, press the ON/OFF switch on the right side of the indoor unit.

**Result:**

- ◆ The OPERATION indicator on the indoor unit comes on.
- ◆ The indoor unit beeps.
- ◆ The air conditioner starts up in the most suitable mode for the room temperature. The mode may change from cooling into heating, from heating into cooling depending on the current temperature during operation:

**Room Temperature    Operating Mode**

Less than 75.2°F      Heat

75.2°F or above      Cool

- 2 To switch the air conditioner off, press the ON/OFF switch again.

**Note** Even if the air conditioner has been switched on via the ON/OFF switch, operations can still be controlled using the remote control as usual.




## Cleaning Your Air Conditioner

**To get the best possible use out of your air conditioner, you must clean it regularly to remove the dust that accumulates on the air filter.**

**IMPORTANT** Before cleaning your air conditioner, ensure that you have switched off the breaker used for the unit.

- 1 Open the upper front grille by pulling the lower right and left tabs of the grille.
- 2 Pull air filters out of each tab of the grille.
- 3 Remove all dust on the air filters with a vacuum cleaner or brush.
- 4 When you finished, insert air filters by fixing it to each tab of the grille.
- 5 To close the front grille, fix it to hooks and push down the lower right and left tabs of the grille.
- 6 Clean the front grille with a damp cloth and mild detergent (do NOT use benzene, solvents or other chemicals).

**Note** If you have not used the air conditioner for a long period of time, set the fan going for three to four hours to dry the inside of the air conditioner thoroughly.




## Cleaning Deodorizing and Bio filter (Option)

**To remove minute dust particles and odors, deodorizing and Bio filter are installed in the air conditioner. You should clean the filters every 3 months.**

- 1 Open the upper front grille by pulling the lower right and left tabs of the grille.
- 2 Pull out the deodorizing and Bio filter.
- 3 Wash the filters with clean water, then dry them in the shade.
- 4 Insert the filters into the original position.

**Note** You can change the position of filters with each other.

- 5 Close the front grille.



## Temperature and Humidity Ranges

*The table below indicates the temperature and humidity ranges the air conditioner can be operated within. Refer to the table for efficient use.*

MODE	OPERATING CONDITIONS	IF OUT OF CONDITIONS
COOL	Indoor temp: 60.8°F~89.6°F	- A safety device will stop continuously the system functioning; - Condensation may occur on the indoor unit with risk to have either water blow off or drops on the floor;
	Indoor humidity: below 80%	
	Outdoor temp: 23°F~109.4°F	
HEAT	Indoor temp: below 80.6°F	- A safety device will stop continuously the system functioning;
	Outdoor temp: 59°F~75.2°F	
DRY	Indoor temp: 60.8°F~89.6°F	- A safety device will stop continuously the system functioning; - Condensation may occur on the indoor unit with risk to have either water blow off or drops on the floor;
	Indoor humidity: below 80%	
	Outdoor temp: 23°F~109.4°F	
POWER SUPPLY	Single phase rated voltage minimum and maximum limit	208V-230V~60Hz 187V min.253V max.

※ **Any damage occurs out of condition specified cannot be covered by product warranty.**  
**If the system works continuously outside of conditions, its performance and reliability will be compromised.**




## Operating Recommendations

*Here are a few recommendations that you should follow when using your air conditioner.*

Topic	Recommendation
Heating performances	The heat pump function of the air conditioner absorbs heat from outside air and brings it indoors. As the temperature of the outside air drops, the heating performance of air conditioner will decrease. If you find that the room is not warm enough, using an additional heating appliance is recommended.
Warm air circulation	The air conditioner circulates warm air to heat your room. It will take some time to warm the air in your room entirely after the air conditioner turns on. Therefore, turn the air conditioner on in advance.
Frost	When outdoor temperature is low but humidity is high, frost may form on the outdoor unit at Heat mode. ◆ The heating operation stops. ◆ The defrost mode will be triggered automatically for 3 to 14 minutes. No intervention is required ; after about 7 minutes, the air conditioner operates again normally.
High indoor and outdoor temperatures	If both indoor and outdoor temperatures are high and the air conditioner is running at HEAT mode, the outdoor unit's fan and compressor may stop at times. This is normal; simply wait until the air conditioner switches on again.
Power failure	If a power failure occurs while the air conditioner is operating, the unit will be switched off. When the power returns, the air conditioner starts up again automatically.
Protection mechanism	When the air conditioner is started immediately after being plugged in or stopped, the normal operation starts up after 3 minutes for the reason of protection.
Cooling operation	The indoor unit may not get the selected fan speed such as Medium and Low under cooling operation at very low outdoor temperatures for the protection of the indoor unit from ice or frost. During Low fan speed operation, cooling performance will be reduced. If the room does not be cooled down when using Low fan speed operation, please adjust the indoor unit's fan speed.

# Solving Common Problems

**Before contacting the after-sales service, perform the following simple checks.**  
**They may save you the time and expense of an unnecessary call.**

Problem	Explanation/Solution
The air conditioner does not operate at all.	<ul style="list-style-type: none"> <li>◆ Check if power is on and operate the air conditioner again.</li> <li>◆ Check if the circuit breaker is switched off.</li> <li>◆ Check if Off Timer is set.</li> </ul>
The temperature is not adjusted.	<ul style="list-style-type: none"> <li>◆ Check if you selected the Fan mode.</li> </ul>
The air conditioner does not operate in the HEAT mode.	<ul style="list-style-type: none"> <li>◆ Check if the air conditioner is cooling only model.</li> <li>◆ Check if the remote control is for cooling only model.</li> </ul>
The cool(warm) air does not come out from the air conditioner.	<ul style="list-style-type: none"> <li>◆ Check if set temperature higher(lower) than current temperature.</li> <li>◆ Check if you selected the Fan mode. Select the Cool, Heat, Auto or Dry mode.</li> <li>◆ Check if the air filter is blocked by dirt. Clean the air filter regularly.</li> <li>◆ Check if there is cover on the outdoor unit or any obstacle. Remove the cover or obstacle.</li> <li>◆ Check if you installed the air conditioner under direct sunlight.</li> <li>◆ The window or door may be opened.</li> <li>◆ Check if you turn on the air conditioner just now. It takes about 3 minutes to cool or heat the room.</li> <li>◆ Check if the drain pipe is too long.</li> </ul>
The fan speed is not adjusted.	<ul style="list-style-type: none"> <li>◆ In Dry mode, the fan speed is selected automatically.</li> </ul>
The remote control does not operate.	<ul style="list-style-type: none"> <li>◆ Check if the battery is discharged. Replace the battery.</li> <li>◆ Check if the remote control sensor is blocked.</li> <li>◆ Check if the air conditioner is placed near strong light.</li> </ul>
The Timer is not set.	<ul style="list-style-type: none"> <li>◆ Check if you pressed the  button after selecting time.</li> </ul>
Odor is permeated in the room during operation.	<ul style="list-style-type: none"> <li>◆ Check if you use the air conditioner in smoky area or there is a smell. Ventilate the room or select the Fan mode for 1~2 hours.</li> </ul>
The indoor unit indicator flashes.	<ul style="list-style-type: none"> <li>◆ Press the  button to turn on the air conditioner again. Switch the circuit breaker off and switch on it again.</li> </ul>
Strange sound is heard from the air conditioner.	<ul style="list-style-type: none"> <li>◆ The sound is heard when the refrigerant gas flow is changed depending on the use of the air conditioner.</li> <li>◆ When you press the  button, noise may be heard that the air conditioner sense the airflow blade.</li> </ul>
Water drops from the outdoor unit connection part.	<ul style="list-style-type: none"> <li>◆ Water may form due to the difference of the temperature.</li> </ul>

## AUTO- DIAGNOSTIC FUNCTION

**This air conditioner has an auto-diagnostic function in case a failure will happen.**  
**Occurring error, the Lamp is blink.**

**Before contacting customer call center green number, please ask to installer to make a double check of installation unless there's a full evidence of SAMSUNG product problem.**

## Periodical Checks

Type	Description	Monthly	Every 4 months	Once a year
Indoor unit	Clean the air filter	● (1)		
	Clean the condensate drain pan (2)			●
	Thoroughly clean the heat exchanger (2)			●
	Clean the condensate drain pipe (2)		●	
	Replace the remote control batteries			●
Outdoor unit	Clean the heat exchanger on the outside of the unit (2)		●	
	Clean the heat exchanger on the inside of the unit (2)			●
	Clean the electric components with jets of air (2)			●
	Verify that all the electric components are firmly tightened (2)			●
	Clean the fan (2)			●
	Verify that all the fan assembly is firmly tightened (2)			●
	Clean the condensate drain pan (2)			●

✱ The checks and maintenance operations described are essential to guarantee the efficiency of the air conditioner. The frequency of these operations varies according to the characteristics of the area, the amount of dust, etc.

(1) The described operations should be performed more frequently if the area of installation is very dusty.

(2) These operations must always be performed by qualified personnel. For more detailed information, see the Installation Manual.

## Protections enabled by the Unit control system

Type of protection	Description	Operation	When it enables
Protection against cold air	The internal fan is off	Heating on heat pump	During operation
Defrost cycle	The internal fan is off	Heating on heat pump	During operation
Anti-frost protection of internal battery	The compressor is off	Cooling During operation	
Delayed start of compressor	The start of the compressor is delayed.	Cooling or heating on heat pump	At start-up or during the selection of the operating mode

### CAUTION

*If the air conditioner is operating in heat pump mode, it performs several defrost cycles in order to remove the frost that may have deposited on the outdoor unit (at low temperatures). In this case, the internal fan is switched off automatically and restarted only after the defrost cycle is completed.*



**ELECTRONICS**

**If you have any comments or questions regarding Samsung products,  
contact the SAMSUNG customer care center.**

Samsung Electronics America, Inc.

1-800-SAMSUNG (7267864)

[www.samsung.com](http://www.samsung.com)



# USER'S MANUAL

Free Joint

MH\*\*\*FNCA Series

ENGLISH

ESPAÑOL

FRANÇAIS

## Free Joint Multi Air Conditioner (Cooling and Heating)

INVERTER

