

KINO-TORSION(M)TM

USER MANUAL



Schneider OPTICS

CONTENTS

Welcome	Page 1
Inside the Box	Page 2
Attachment of Lens to Kino-Torsion(M) TM Mechanism	Page 3
Electrical Connections	Page 4
Attachment of Kino-Torsion(M) TM to Chief Ceiling Mount	Page 5
Adjusting the Anamorphic Image	Page 6
About Schneider	Back Cover

WELCOME

Congratulations on your purchase of a Schneider Optics, Inc. Kino-Torsion(M)TM anamorphic system. This system is composed of the finest optical and mechanical components available. The Cine-Digital Anamorphic lens is of commercial grade and should last indefinitely provided that it is used within reasonable parameters of temperature and shock. The mechanical assemblies within the Kino-Torsion(M)TM lens mover are designed for the demanding duty cycle of a professional screening room.

Installation by a qualified professional is recommended for best results.

INSIDE THE BOX

The following items are included in the Schneider Optics Kino-Torsion(M)TM packaging:

- A. Kino-Torsion(M)TM Motorized Lens Mechanism
- B. Power Supply (12-volt output, 110-240-volt input)
- C. 3 Power Cord Types (US, UK, EU)
- D. 12-Volt Trigger Cable (3.5mm Phono Type, Mono, 3M, Male-Male)

Note: A Cine-Digitar Anamorphic lens is required to use the Kino-Torsion(M)TM and must be purchased seperately.



ATTACHMENT OF LENS TO KINO-TORSION(M)TM MECHANISM

Tools Needed:

1. Allen Wrench: 1/16", 1/8"
2. Ball End Allen Wrench: 4mm
(Important for Mounting Bolts)

Assembly Instructions:

1. Remove Kino-Torsion(M)TM mechanism and Cine Digital anamorphic lens, if purchased together, from packaging. Inspect all components for damage that may have occurred during shipping.
2. Insert lens into the frame of the Kino-Torsion(M)TM. See *Illustration #1*
3. Align the lens, rotating it until the flat sides of the inner bezel are vertical. See *Illustration #2*
4. Tighten the thumb screw to lock lens in place. See *Illustration #1*



Illustration #1 - Rear View of Kino-Torsion(M)TM with Lens Installed



Illustration #2 -Front View of Kino-Torsion(M)TM

ELECTRICAL CONNECTIONS




Illustration #3 -Electrical Connection Area




Illustration #4 -Detail of Electrical Connection Area

1. Select the appropriate power cord (US, UK, EU) for your location, and connect the power supply to the Kino-Torsion(M)™ and electrical outlet. A green LED should go on if power is working correctly. A flashing LED indicates that power is not correct. See *Illustration #4*.

2. When the Kino-Torsion(M)™ receives 12 volts through this connector, the lens moves out of the projector view. When the voltage is zero, the lens moves back into projector view. A 12-volt trigger must be supplied by a programmable 12-volt source on the projector, video scaler, or home theater control system. A 3 meter trigger cable is provided.

3. Test Kino-Torsion(M)™ by triggering unit and observe motion. Trigger <ON> should move lens away. Trigger <OFF> restores original position.

4. As an alternative or local testing, the Kino-Torsion(M)™ can also be controlled via simple contact closure without a 12-volt trigger. Use a wire to connect terminal 1 to 2. This will move lens out of the projector view when connected, similar to using the 12-volt trigger.

5. To gain access to the terminal block, the motor cover needs to be removed. Unscrew the motor cover screws with 1/16" allen wrench, and carefully pull back cover. See *Illustration #3*.

ATTACHMENT OF KINO-TORSION(M)TM TO CHIEF CEILING MOUNT




Illustration #5 - Detail of Chief PAN-2 Lens Support



Illustration #6 - Schneider Kino-Torsion(M)TM PAN-2 Bracket




Illustration #7 - Chief Mount

Accessories Needed:

1. Chief MFG, CMS Column, or 1.5" NPT pipe of suitable Length. (Chief CMSTTM)
2. Chief MFG, RPA LCD/DLP Universal Ceiling Mount. (Chief RPATM)
3. Chief MFG, SLBU/SLMU Universal Interface Bracket, or custom interface bracket (not shown) for your specific projector.
4. Chief MFG, PAN-2 Panamorph Lens Support. (Chief PAN-2TM)
5. Schneider Optics, Kino-Torsion(M) / PAN-2 Bracket (#54-018712).

Assembly Instructions:

1. Install the Chief CMSTTM Column and Chief RPATM Universal Ceiling Mount as instructed in Chief manual.
2. Attach the Chief PAN-2TM lens support to Chief RPATM Universal Ceiling Mount as instructed in Chief manual.
3. Replace the 90-degree adapter supplied with the Chief PAN-2 lens support with the Schneider PAN-2 bracket. See *Illustration #5*.
4. Mount projector interface bracket (universal/custom) to the projector. Then place entire assembly into the Chief RPATM Universal Ceiling Mount.
5. Mount the Kino-Torsion(M)TM onto the Schneider PAN-2 bracket with the mating holes. Use a 5/32" ball end allen wrench to tighten the two 10-32 mounting bolts. Adjust knobs to align the vertical position of the lens if needed. See *Illustration #7*.
6. Mount safety lanyard to projector mount securely for safety.

"RPA" and "PAN-2" are trademarks of Chief Manufacturing.

ADJUSTING THE ANAMORPHIC IMAGE

1. If focusing projector for the first time, use the 12-volt trigger controller to take the lens out of the light path of the projector. Follow projector manufacture instructions for setting up image.

2. <Important> Use the adjustments on the Chief RPA™ Universal Ceiling Mount as much as possible to center image. Projector image adjustments should be centered as much as possible for proper alignment to the anamorphic.

3. Deploy the anamorphic lens into the projector light path using the controller (Trigger OFF), checking to assure that no part of the lens or cradle contacts any part of the projector. Observe image using the projector test grid pattern.

4. If you see vertical “vignette” distortion on top or bottom, adjust the height of the anamorphic lens. Use either the vertical adjustments on the Kino-Torsion(M)™ or the knurled knobs on the Chief Mount.

5. If you see left or right side “vignette” distortion, shift horizontally by adjusting the knurled knobs on the Chief Mount.

6. If you see “trapezoidal”, “barrel”, or “pin-cushion” distortion, adjust the pitch on the Kino-Torsion(M).™

7. If you see “parallelogram” distortion and stretched corners, adjust lens rotation (roll). See *Illustration #2*.

8. If the image requires focusing, loosen the lens focus knob on the Schneider Anamorphic lens to adjust.




Illustration #8 - Detail of Chief Mount



Illustration #9 - Front Detail

ABOUT SCHNEIDER

Schneider Optics is the U.S. subsidiary of the world-renowned German optical manufacturer, Schneider-Kreuznach. Schneider has been producing the highest quality optics on the market for over 90 years, offering solutions for large-format photography, photo enlarging, motion picture projection, optical filtration, and industrial applications. In 2000, Schneider Optics acquired Century Precision Optics, adding its over 50 years experience manufacturing superior attachments for film and video.

Schneider Optics has offices in Hauppauge, NY and Van Nuys, CA and a network of hundreds of dealers around the globe, ready to assist you with any of your imaging needs.

Joseph Schneider founded the company in 1913 in Bad Kreuznach, Germany. Since that time the Schneider factory has been constantly modernized, always remaining state-of-the-art.

The factory is fully compliant with ISO 9001 standards. Its U.S. subsidiary, Schneider Optics, was founded in 1972.

Century Optics first opened its doors in North Hollywood, CA in 1948, and quickly gained a reputation for expert lens repair, custom modification and intelligent innovation. In the early 80's Century began creating what has become the most extensive array of ultra-high quality video lens accessories available anywhere.

Separately the two companies were leaders in their respective spheres of the optical world—both having been awarded Technical Achievement Awards from the Academy of Motion Picture Arts and Sciences (Schneider in 2005, 2001, 1978 and 1976; Century in 1992). Together they are the ultimate solution to all your optical needs.



Schneider Cinema Projection Lens technology has won four Technical Achievement Awards from the Academy of Motion Picture Arts and Sciences

Schneider OPTICS

Schneider Optics, Inc.
7701 Haskell Avenue
Van Nuys, CA 91406
Phone: +1 818 766-3715 • +1 800 228-1254
Fax: 818 505-9865
Email: info@schneideroptics.com
www.schneideroptics.com

 **Schneider**
KREUZNACH

Jos. Schneider Optische Werke GmbH
Business Unit: Cinema
Ringstr. 132 • D-55543 Bad Kreuznach
Phone: ++49-(0)671-60 12 82
Fax: ++49-(0)671-60 11 08
Email: kino@schneiderkreuznach.com
www.schneiderkreuznach.com