



SERIAL BUS DEVICENET™ ADAPTERS

RPSSCDM12A, RPSSCDM18PA

User Manual 601

Important User Information

Solid state equipment has operational characteristics differing from those of electromechanical equipment. *Safety Guidelines for the Application, Installation and Maintenance of Solid State Controls (Form #A10325)* (available online at www.rosscontrols.com/rosslit. htm), describes some important differences between solid state equipment and hard-wired electromechanical devices. Because of these differences, and also because of the wide variety of uses for solid state equipment, all persons responsible for applying this equipment must satisfy themselves that each intended application of this equipment is acceptable.

In no event will ROSS CONTROLS[®] be responsible or liable for indirect or consequential damages to persons or property resulting from the use or application of this equipment.

The examples and diagrams in this manual are included solely for illustrative purposes. Because of the many variables and requirements associated with any particular installation, ROSS CONTROLS cannot assume responsibility or liability for actual use based on the examples and diagrams.

No patent liability is assumed by ROSS CONTROLS with respect to use of information, circuits, equipment, or software described in this manual.

Reproduction of the contents of this manual, in whole or in part, without written permission of ROSS CONTROLS is prohibited.

Throughout this manual we use notes to make you aware of safety considerations.

	Identifies information about practices or circumstances that can cause an explosion in a hazardous environment, which may lead to personal injury or death, property damage, or economic loss.
IMPORTANT	Identifies information that is critical for successful application and understanding of the product.
	Identifies information about practices or circumstances that can lead to personal injury or death, property damage, or economic loss. Attentions help you: • Identify a Hazard • Avoid a Hazard • Recognize the Consequence
SHOCK HAZARD	Labels may be located on or inside the equipment to alert people that dangerous voltage may be present.
BURN HAZARD	Labels may be located on or inside the equipment to alert people that surfaces may be dangerous temperatures.

ATTENTION



Environment and Enclosure

This equipment is intended for use in overvoltage Category II applications (as defined in IEC publication 60664-1), at altitudes up to 2000 meters without derating. This equipment is considered Group 1, Class A industrial equipment according to IEC/CISPR Publication 11. Without appropriate precautions, there may be potential difficulties ensuring electromagnetic compatibility in other environments due to conducted as well as radiated disturbance. This equipment is supplied as "enclosed" equipment. It should not require additional system enclosure when used in locations consistent with the enclosure type ratings stated in the Specifications section of this publication. Subsequent sections of this publication may contain additional information regarding specific enclosure type ratings, beyond what this product provides, that are required to comply with certain product safety certifications.

NOTE: See NEMA Standards publication 250 and IEC publication 60529, as applicable, for explanations of the degrees of protection provided by different types of enclosures. Also, see the appropriate sections in this publication, as well as the publication A10324 ("Industrial Automation Wiring and Grounding Guidelines"), for additional installation requirements pertaining to this equipment.

Preventing Electrostatic Discharge

This equipment is sensitive to electrostatic discharge, which can cause internal damage and affect normal operation. Follow these guidelines when you handle this equipment:

- Touch a grounded object to discharge potential static.
- Wear an approved grounding wrist strap.
- Do not touch connectors or pins on component boards.
- Do not touch circuit components inside the equipment.
- If available, use a static-safe workstation.
- When not in use, store the equipment in appropriate staticsafe packaging.

Purpose of This Manual

This manual describes how to install, configure, and operate your Serial Bus DeviceNet[™] Adapters, catalog numbers RPSSCDM12A and RPSSCDM18PA.

See the Following Sections:	Page:
Who Should Use This Manual	P-1
What the Manual Contains	P-2
Related Terms	P-3
Related Products and Documentation	P-4
Guidelines for Using Your Adapter	P-4
Conventions Used in This Manual	P-4

IMPORTANT

In this manual, we use Serial Bus DeviceNet adapters to refer to all the DeviceNet[™] adapter modules (RPSSCDM12A and RPSSCDM18PA). We use the specific catalog number (e.g., RPSSCDM12A) to refer to a specific module.

In the rest of this manual (except Chapter 4), we refer to the Serial Bus I/O DeviceNet[™] adapters as the adapters.

In Chapter 4, we refer to the Serial Bus I/O DeviceNet adapter as the scanner because the chapter describes how to configure the adapter on the subnet.

Who Should Use This Manual

You must be able to use RSNetWorx for DeviceNet[™] software, or a similar configuration software, to configure your adapter.

In this manual, we assume you know how to configure an adapter. If you do not, refer to your software user manuals, or online help, before attempting to use these adapters.

We also assume you are familiar with the Serial Bus I/O product line, including other serial bus interfaces, I/O modules, and power supplies. If you are not familiar with these components, you can read the Serial Bus I/O documents listed in the Related Products and Documentation section.



What the Manual Contains

This manual contains the following sections:







Interflore		
storing an questionion to the basinable.	and a state of the	
Including Advances - IP-Soldmann, IP-S	Allineats	
Canal II Canty	Sector and a sector fraction fraction of the last of t	lare solution solution 1.128. National Splana sumption resumption for such XS speaks sumiar and to such at the metadox consumer is the Socialities anapper
	Santy Part I is bains 1 and Rantysiana nament namba Rangesian Preser Gagely	n. 1. antarokal keyensi 1.36 win a PODSERA Restatione The POSSERA nan supply up to an additional 1.56 of
	Margin Philippine mail	like out he want to see it the
	6 m. m.	Printing Generic Registerants
	Annual	322
	ACHEE INTERNAL	2.00
	0/16/54	2.04
	EPIGANANAN ERIT Tabaia	2 mil
	Advice Sectors 24.	2.04
	PPERSONAL PROPERTY AND INC.	1.14
Deviate Connervation has	1254 Mills Fullet Hastmath	
	Well and prior maximum	
Including Prove Spacifications		
New York	Mill Case 3 a fater from	R. Of Low Maps District (20), pp. Num an affer a pre-totage, March a Present Compose they affer along a District and present annual first res. A Dr. page (2011).
	Participand to come	what is provided with
CERCONIA PARTY	ACCESS SUPPORT	1.1.1
in a francisk og Kontrakter	france on the second	
In cashed Price Party Information	2010/05/1-05/1 2010/01/1 #1	TO FA TANDAR
Press Benefic Spanifications		
road happy	MC Dealt a fater firm	n on one where sharps provide provide the set of a set of a set of the set of
	sever papels to preservice .	adopter A. S.R.H. supply represent accessed May prop. 60 AV years
	for some series and is come	whether any state of the second state of the second state of the
ing a strategy fielding	anvoc.	
In a Canadana Patentino	Table and To prove the	
Inviati Current	46 maximum for time	
Annual Carety	On Residual & Color, TO.	1276220
Fact Site Pour Registrants, Maimer	20201-201-2020	\$ 405.7A
	time a title airt mannan	ital
Calural Qualifications		
E industry	 partial plane state partial plane state 	
	I purched Painting states	
	1 peer typen Press Price	TRACT DIRECT.



Appendix B - Default Data Maps

Listing of the default data maps for Serial Bus I/O modules



Related Terms

This manual uses the following terms:

Term	Definition
Adapter	The adapter interfaces between DeviceNet devices and Serial Bus I/O modules. Serial Bus I/O DeviceNet adapters include the RPSSCDM12A and RPSSCDM18PA.
Auto Catalog Replace	The Serial Bus I/O DeviceNet adapter supports the swapping of two identical modules connected to the adapter. That is, if a RPSSN8M8A is in slot 3 and another RPSSN8M8A is in slot 7, the two modules can be removed from the Serial Bus system and the slot 3 module placed into slot 7, and vice-versa. When Automatic Device Replacement (ADR) is active, the swapped modules will be reconfigured to match the previous module in their new slot. When ADR is not active, the configuration parameters will not be modified, the swapped modules must have identical configuration and values for their EDS file parameters.
Auto Device Replacement (ADR)	This refers to the ADR feature of a ControlLogix System on DeviceNet. With ADR active, any device on the DeviceNet link may be removed and replaced with an out-of-the-box checkmark compliant DeviceNet device. The ADR feature will result in downloading the values of the configuration parameters of the EDS file of the removed device to the new device.
Auto Start Mode	A feature that lets the Serial Bus I/O system get "up any of the EDS parameters for the PointBus™ or Serial Bus I/O modules. Using Auto Start Mode will result in a scan list within the adapter that stores the modules identity information.
Autobaud	A feature in devices (e.g., Serial Bus I/O modules) on the DeviceNet network that causes them to listen to communications on the network and set their own baudrate to match the network rate.
Backplane	The PointBus that consists of Serial Bus I/O modules connected to the Serial Bus DeviceNet adapter.
Baudrate	Rate of communications between devices on the DeviceNet network. Backplane baudrate is used for the RPSSCMD12A and RPSSCDM18PA.
Change of State (COS)	DeviceNet communications method in which the adapter sends data based on detection of any changed value within the input data. Data is independently received based on a change of state from the sender. Data in both directions can be acknowledged or unacknowledged depending on the run-time configuration of the system.
Commissioning	The period in time associated with post startup activities. Commissioning implies that the system has been validated and all configuration parameters are correct, all modules are in good operating condition, and the adapter scanlist is complete.
ControlFlash™	Utility software you can use to update the adapter's firmware with the most current boot and application code.

Term	Definition
Cyclic	DeviceNet communications method in which the adapter sends data cyclically based on a configured time value. Data is independently received cyclically from the sender. Data in both directions can be acknowledged or unacknowledged depending on the run time configuration of the system.
MACID	Media Access Control Identifier (DeviceNet network address).
Master	A DeviceNet network device (e.g., Rockwell Automation 1771-SDN) that initiates communication with DeviceNet slave devices (e.g., Serial Bus I/O modules) to retrieve data. The master only receives unprompted data when the slave is enabled for COS and there is a change in the device's operating state.
Offline	State of the adapter when it is not powered or maintaining normal communication exchanges with other DeviceNet devices.
Online	State of the adapter when it is powered and maintaining normal communication exchanges with other DeviceNet devices.
PointBus	The Serial Bus I/O backplane PointBus maintains all DeviceNet network protocol, but also offers configuration capabilities.
Polled	DeviceNet communications method in which a module sends data in response to received data.
Primary Network	The primary DeviceNet network is defined as the DeviceNet link that provides the direct connection between the Serial Bus DeviceNet adapter and a DeviceNet scanner.
RSNetWorx for DeviceNet	Configuration software for the adapter and Subnet modules.
Scanlist	The list of Subnet modules connected to the adapter. When ADR is active, the scanlist stores the configured values of each of the Subnet modules' configurable parameters. When ADR is not active, the scanlist stores only the module identity information.
Scanner	Operating state of the Serial Bus DeviceNet adapter when it retrieves I/O data from Subnet modules.
Slave	A DeviceNet network device that cannot initiate communication (except when configured with COS enabled) but responds to a DeviceNet master device.
Strobe	Adapter sends data in response to the strobe command. The single bit allocated to the adapter in the strobe message is not used. If the configured size of the input data (sent from the adapter) is greater than 8 bytes, the strobe connection establishment will fail. In this case, the input size must be reconfigured to 8 bytes or less.



Related Products and Documentation

The following table lists related Serial Bus I/O products and documentation:

Description	Model Number	Publication
Serial Bus 32 Point Valve Driver Installation Instructions	RPSSV32A	A10312
Serial Bus DeviceNet Adapters Installation Instructions	RPSSCDM12A, RPSSCDM18PA	A10313
Serial Bus PROFIBUS Adapter Installation Instructions	RPSSCPBA	A10314
Serial Bus ControlNet Adapter Installation Instructions	RPSSCCNA	A10315
Serial Bus EtherNet/IP Adapter Installation Instructions	RPSSCENA	A10316
Serial Bus I/O 24VDC Expansion Power Supply Installation Instructions	RPSSSE24A	A10317
Serial Bus 24VDC Input Modules Installation Instructions	RPSSN8, RPSSP8	A10318
Serial Bus 24VDC Output Modules Installation Instructions	RPSST8	A10319
Serial Bus Relay Output Modules Installation Instructions	RPSSTR4M12A	A10320
Serial Bus 24VDC Analog Input Modules Installation Instructions	RPSSNA	A10321
Serial Bus 24VDC Analog Output Modules Installation Instructions	RPSSTA	A10322
Serial Bus RS232 ASCII Module Installation Instructions	RPSSS23A	A10323
Industrial Automation Wiring and Grounding Installation Instructions	N/A	A10324
Safety Guidelines for the Application, Installation and Maintenance of Solid State Control	N/A	A10325

If you need more information on these products, contact your local distributor, integrator or sales office for assistance.

Guidelines for Using Your Adapter

Remember the following operational guidelines when using your Serial Bus DeviceNet adapter.

- Do not leave spaces in the I/O. Instead, install all Serial Bus I/O modules adjacent to each other.
- Populate every position on the mounting base.
- Serial Bus does not support removal and insertion under power (RIUP). When an I/O module is removed, the IP67 seal is broken and the backplane bus is interrupted.

Conventions Used In This Manual

The following conventions are used throughout this manual:

- Bullet lists (such as this one) provide information, not procedural steps
- Numbered lists provide sequential steps
- Text written like this identifies screen, menu, toolbar names, field names, buttons, and check boxes on screens
- A menu item in this format File>Save identifies the submenu item after the caret (>) that is accessed from the main menu (name before the caret)
- Pictures of symbols and/or screens represent the actual symbols you see or the screens you use

Table of Contents i

	Chapter 1	
Install the Serial Bus	Mount the Adapter and I/O Base	1-1
DeviceNet Adapters	Set the Node Address	
	Wire the DeviceNet Adapters RPSSCDM12A RPSSCDM18PA DeviceNet Auxiliary Power	
	Chapter Summary and What's Next	1-2
	Chapter 2	
What Is the Serial Bus	Use the Adapter	2-1
DeviceNet Adapter?	Set Subnet/Backplane Baudrate	2-2
	Set Subnet/Backplane I/O Module Addresses	
	Configure the Primary DeviceNet Network	
	Remove and Reinsert Modules on the Backplane	2-2
	Understand the DeviceNet Network and Subnet	2-3
	DeviceNet Network	2-3
	Backplane/Subnet Network	2-3
	Adapter Features	2-4
	Communicate Through the Adapter	
	Map the Data	
	Overview of the Communication Process	
	Communicate With I/O Medules	
	Use Diagnostic Tables	
	Chapter Summary and What's Next	2-12

Chapter 3

Why Use Auto Start Mode?	3-2
What Does Auto Start Mode Do?	3-2
How Is I/O Data Mapped Using Auto Start Mode?	3-2
Requirement To Using Auto Start Mode	3-2
Install the I/O Module	3-3
Remove the Module From the Mounting Base	3-3
Use RSNetWorx for DeviceNet	3-4
Begin Auto Start Mode	3-5
Use Custom Configuration	3-6
Chapter Summary and What's Next	3-6



Use Auto Start Mode

	Chapter 4	
Configure the DeviceNet	Configuration Overview	
Scanner Subnet	Add the Scanner To Your Network	
	Add I/O Modules To Your Network	
	Set the Scanner's Parameters	
	Go On Line	
	Chapter Summary and What's Next	4-6

Chapter 5

Add the Serial Bus DeviceNet	Configuration Overview	5-1
Adapter to the DeviceNet	Add the Adapter to Your Network	5-1
Scanner's Scanlist	Set the Adapter's Parameters	5-2
	Go On Line	5-4
	Chapter Summary	5-4

Chapter 6)
-----------	---

Troubleshoot the Serial Bus	Use the Status Indicators	6-1
DeviceNet Adapter	Guidelines for Using Your Adapter	6-2
	Chapter Summary	6-2

Appendix A

Specifications

Default Data Maps

Appendix B

RPSSN8 Sink Input Module	B-1
RPSSP8 Source Input Module	B-1
RPSST8 Electronically Protected Output Module	B-2
RPSSTR4 Relay Sink/Source Output Module	B-2
RPSSNAC Analog Current Input Module	B-2
RPSSNAV Analog Input Module	B-3
RPSSTAC Analog Current Output Module	.B-3
RPSSTAV Analog Output Module	B-4
RPSSS23A ASCII Module	B-4
RPSSV32A 32 Point Valve Driver Module	B-4

Install the Serial Bus DeviceNet Adapters

This chapter describes how to install and wire your adapter.

See the Following Sections:	Page:
Mount the Adapter and I/O Base	1-1
Set the Node Address	1-1
Wire the DeviceNet Adapters	1-2
Chapter Summary and What's Next	1-2

Mount the Adapter and I/O Base

To mount the Serial Bus adapter on a wall or panel, use the screw holes provided in the adapter.

A mounting illustration for the Serial Bus adapter with I/O bases is shown below.

Install the Mounting Base as Follows:

- 1. Lay out the required points as shown in the drilling dimension drawing.
- 2. Drill the necessary holes for #8 (M4) machine or self-tapping screws.
- 3. Mount the adapter and I/O bases using #8 (M4) screws.
- 4. Ground the system using the ground lug connection in the I/O base. (The ground lug connection is also a mounting hole.)



may vary. Refer to Bulletin A10309 for additional information.

Set the Node Address

Valid node addresses are 00 through 63.

Set the node address using either the rotary switches, RSNetWorx for DeviceNet[™], DeviceNetManager[™], or another software configuration tool. Setting the switches at any number from **64** through **99** lets the software have address control.

Each module is shipped with the switches set for node address **63**. Remove the caps on the front of the module to access the switches (refer to the X10 and X1 on the front of the module). The two switches are:

- X10 (most significant digit) left side of module
- X1 (least significant digit) right side of module

This example shows the node address set at 63.





To reset the node address, use a small blade screwdriver to rotate the switches. Line up the small notch on the switch with the number setting you wish to use and then cycle power.

The rotary switches are read periodically. If the switches have been changed since the last time they were read and they no longer match the on line address, a minor fault will occur, which is indicated by a flashing red Adapter Status LED. Settings of 64 through 99 cause the module to use the **last valid node address stored internally**. For example, the last setting internally was 40. If a change is made to 68, and then you power up, the address will default to 40.

The module is equipped with AutoBaud detect. AutoBaud lets the module read the settings already in use on your DeviceNet network and automatically adjusts to follow those settings.

Wire the DeviceNet Adapters

Following are wiring instructions for the DeviceNet Adapters.

RPSSCDM12A

Male In Connector



(view into connector) Pin 1 - Drain Pin 2 - +V Pin 3 - -V Pin 4 - CAN_High Pin 5 - CAN_Low

Female Out Connector



RPSSCDM18PA



(view into connector) Pin 1 - Drain Pin 2 - +V Pin 3 - -V Pin 4 - CAN_High Pin 5 - CAN_Low

Female Out Connector



DeviceNet Auxiliary Power

Male In Connector



- (view into connector) Pin 1 - User Power + Pin 2 - Adapter Power +
- Pin 3 Adapter Power -
- Pin 4 User Power -

ATTENTION



Make sure all connectors and caps are securely tightened to properly seal the connections against leaks and maintain IP67 requirements.

Chapter Summary and What's Next

In this chapter, you learned how to install and wire your DeviceNet adapter. Move to Chapter 2 to learn about the Serial Bus DeviceNet adapters.

What Is the Serial Bus DeviceNet Adapter?

This chapter describes the Serial Bus I/O DeviceNet adapter, including descriptions of the adapter's features and functionality.

See the Following Sections:	Page:
Use the Adapter	2-1
Understand the DeviceNet Network and Subnet	2-3
Adapter Features	2-4
Communicate Through the Adapter	2-8
Communicate With I/O Modules	2-10
Use Diagnostic Tables	2-11
Chapter Summary and What's Next	2-12

Use the Adapter

The adapter resides on the primary $\ensuremath{\mathsf{DeviceNet}}$ network and the Subnet simultaneously.

IMPORTANT

The PointBus maintains all DeviceNet network protocol, but also offers configuration capabilities.

The adapter interfaces between DeviceNet devices and Serial Bus I/O modules. The graphic below shows the adapter on the DeviceNet network and PointBus.



After you have installed your adapter into a Serial Bus I/O system, you must perform the following tasks:

- 1. Set Subnet/Backplane Baudrate
- 2. Set Subnet/Backplane I/O Module Addresses
- 3. Configure the Subnet I/O
- 4. Configure the Primary DeviceNet Network

The steps mentioned above are explained briefly here, and then in greater detail throughout this manual. You must complete the steps for the adapter to work with DeviceNet masters (e.g. Rockwell Automation 1756-DNB) on the primary network and Subnet modules.



1. Set Subnet/Backplane Baudrate

The adapter and Subnet/Backplane modules must use the same baudrate to communicate with each other. Use one or both of the following to set a Subnet/Backplane baudrate.

- Enable or disable the Backplane Autobaud feature for Serial Bus I/O modules. Serial Bus I/O modules have Autobaud enabled as the default See page 2-5.
- Set the adapter baudrate for the Subnet. The default for the RPSSCDM12A and RPSSCDM18PA is 1Mbaud.

You set the backplane baudrate for the RPSSCDM12A and RPSSCDM18PA.

2. Set Subnet/Backplane I/O Module Addresses

Once the adapter and Serial Bus I/O modules are communicating at the same rate on the backplane, you must make sure all modules use a valid MACID.

Set the Auto Address feature for Serial Bus I/O modules - See page 2-5.

3. Configure the Subnet I/O

In the first two steps, you set a consistent communication rate and made sure each module uses valid addresses for communication. Next you must configure the PointBus (e.g., set scan list).

You can configure the PointBus using one of two methods:

- · Auto Start Mode (ASM) or
- Manually For more information on configuring the PointBus, see Chapter 3 for ASM or see Chapter 4 for manual configuration.

4. Configure the Primary DeviceNet Network

Finally, you must configure the adapter for communication with a master (e.g., Rockwell Automation 1756-DNB).

For more information on configuring the DeviceNet network, see Chapter 5, Add the Serial Bus DeviceNet Adapter to the DeviceNet Scanner's Scanlist.

You must understand all of the adapter's features to effectively use it in your Serial Bus I/O system. Keep these four steps in mind as you read this manual:

- 1. Set Subnet/Backplane Baudrate
- 2. Set Subnet/Backplane I/O Module Addresses
- 3. Configure the Subnet I/O
- 4. Configure the Primary DeviceNet Network

Remove and Reinsert Modules on the Backplane

Removal and Insertion Under Power (RIUP) is not recommended in a Serial Bus System because of the following reasons.

- · Removing a module breaks the IP67 seal.
- Removing a module breaks the backplane bus. Modules to the right of the removed module will be 'lost' to the adapter. Also, the terminating resistor will be removed, causing system uncertainty.
- Inserting a module under power may cause the adjacent module to reset due to the addition of a large capacitive load on the power bus.

IMPORTANT

If the module is removed while it is under power, all the modules to the right of the removed module will disconnect from the PointBus and field power until the module is reinstalled.

If you must remove and reinsert modules, we recommend the following:

- Do not move I/O modules to different locations on the mounting base after they have been installed and configured.
- If adjacent modules (i.e., 2 or more) are removed from the backplane, replace all of them before attempting to operate the Serial Bus I/O system. Input data will hold last state until all previously removed modules are replaced.
 - If adjacent modules are removed and all but one is returned, the adapter cannot verify the location of the returned modules. For example, if modules are removed from nodes 3 and 4 and only the module from node 4 is returned, the adapter cannot verify the location. In this case, the adapter alerts you via a flashing red PointBus status LED that it cannot verify the presence of modules in the affected locations. I/O data will not be exchanged with this node until both modules have been reinserted.
 - If modules of different types are removed and returned to the wrong locations, the adapter identifies the returned modules and alerts you (via RSNetWorx for DeviceNet) that the error has occurred and must be corrected.
 - If modules of the same type are removed and returned to the wrong locations, the adapter identifies the returned modules, updates their MACIDs, and continues operation.

IMPORTANT

The removal and return scenario exists whether the system is under power or not. If the system is under power, the scenario arises immediately. If the system is not under power, the scenario arises in the next power cycle.Also, the example above shows removal of two adjacent modules. The scenario described exists anytime 2 or more adjacent modules are removed and all are not returned.

IMPORTANT

Care must be taken when replacing backplane I/O modules. Each I/O module stores its configuration parameters in internal non-volatile memory. You must either enable ADR for all modules or manually configure each module in a non-manufacturing environment when the module is being replaced or placed on the network for the first time. Failure to do so could result in inadvertent control attributed to different configuration settings.

Understand the DeviceNet Network and Subnet

DeviceNet Network

Your adapter serves as a slave to DeviceNet masters. The adapter receives data from, and returns data to, the master through the following I/O connections:

- Change of State (COS)
- Cyclic
- Polled
- Strobe

Backplane / Subnet Network

On the Backplane/Subnet, your adapter acts as a scanner and is the master of the Subnet modules. The adapter performs the following functions:

- Exchanges I/O data with devices on the Backplane/Subnet
- Collects I/O data from the Backplane/Subnet and sends it to devices on the DeviceNet network (e.g., scanners or controllers)
- Supplies power to the backplane I/O modules (See Appendix A for power supply rules regarding I/O modules power requirements.)

Data Collection

The adapter collects I/O data from up to 63 modules via the Backplane/Subnet. The I/O modules appear on the primary DeviceNet network as a single node, though, and require only one DeviceNet node address.

IMPORTANT

If Automatic Device Replacement (ADR) is enabled on the adapter, you can only connect up to 62 modules via the Subnet.

For more information on ADR, see page 2-6.

Module Power

The adapter supplies 5V logic power to Serial Bus I/O modules by converting 24VDC field power to PointBus 5V power.

You can connect up to 63 I/O modules to each adapter and you can power the backplane I/O modules from the adapter (with a maximum of 10A of field power). You may use the integrated, isolated 24VDC expansion power unit (RPSSSE24A) to power additional I/O modules, as shown below.



For more information on the RPSSSE24A expansion power unit, see the Serial Bus I/O 24VDC Expansion Power Supply Installation Instructions, publication A10317.



Adapter Features

Your adapter uses the following features on both the DeviceNet network and the PointBus:

- Self-Test
- Field Upgradable Firmware
- Fully Configurable Software
- Connections
- Baudrates

Self-Test

When power is applied to the adapter, the adapter performs a selftest. The adapter tests various internal and programmatic memories and checks the status indicators (LEDs).

Field Upgradable Firmware

You can update the adapter's firmware with the ControlFlash Utility software. This feature lets you always use the most current firmware.

Fully Software Configurable

The adapter is fully software configurable using RSNetWorx for DeviceNet. You must configure the adapter to be used with a DeviceNet master (e.g. 1756-DNB) and separately to be used with Subnet devices.

For more information on how to configure your adapter to use with a DeviceNet master, see Chapter 5, Add the Serial Bus DeviceNet Adapter to the DeviceNet Scanner's Scanlist.

For more information on how to configure your adapter to use with Subnet modules, see Chapter 4, Configure the DeviceNet Scanner Subnet.

Connections

Your adapter supports the following connections on both the primary DeviceNet network and Subnet:

- I/O connections:
 - Polled
 - Strobe
 - Cyclic
 - COS
- Explicit connections

You can use I/O mapping to determine the data contained in each connection.

The adapter supports Master/Slave connection types on the DeviceNet network. On the Subnet, the adapter functions as a scanner device, exchanging data with I/O modules.

Baudrates

Choose baudrates for the adapter in the RSNetWorx for DeviceNet software. The adapter supports these rates:

- 125Kbaud
- 250Kbaud
- 500Kbaud
- Autobaud The adapter detects the primary DeviceNet network baudrate and automatically sets its own baudrate to match the network.
- For the RPSSCDM12A and RPSSCDM18PA, the PointBus can be configured to operate at 1Mbaud (1000Kbaud).

Auto Start Mode

Auto Start Mode lets you easily get your adapter installed and operating. In this mode, the adapter's configurable features operate as they were most recently configured. For example, if Autobaud on DeviceNet was enabled in the adapter's last configuration, it will be enabled when Auto Start Mode is used.

For a more detailed explanation of how to use Auto Start Mode, see Chapter 3.

Auto Catalog Replace

Auto Catalog Replace corrects errors that might occur when backplane modules of the same type are removed and replaced in the wrong location. If modules of the same type are removed and returned to the wrong locations, the adapter identifies the returned modules, updates their MAC IDs, and continues operation.

IMPORTANT

If modules of different types are removed and returned to the wrong locations, the adapter identifies the returned modules and alerts you (via RSNetWorx for DeviceNet, the Node Status Table, and the Faulted Node Table) that the error has occurred and must be corrected.

Backplane (RPSSCDM12A and RPSSCDM18PA) Baudrate

EDS parameter Backplane Baudrate is accessible from the primary DeviceNet and sets a specific baudrate for all backplane I/O modules.

Set this parameter in RSNetWorx for DeviceNet to one of the following baudrates:

- 125 Kbaud
- 250 Kbaud
- 500 Kbaud
- 1 Mbaud (available for both Serial Bus DeviceNet adapters)

When you download this parameter, the adapter sends a command to reset all present I/O modules on the backplane to the new baudrate. If additional modules are connected to the adapter, you must download the Backplane/Subnet Baudrate to make sure the new modules use the same rate as the others. The baudrate may not take effect until power is recycled or the I/O modules are reset.

IMPORTANT

Changes to the Backplane Baudrate parameter only take effect if they are downloaded on an individual basis. (For example, if you change the Backplane Baudrate and download the changes with additional changes to other features, the Backplane Baudrate remains at the previous setting.)

Also, this parameter should be set to 'Do Nothing' when you download all parameters, or when Automatic Device Replacement is enabled for the adapter.

If you want to set an I/O module to use a specific baudrate (i.e., 125, 250, 500), you must first disable Backplane Autobaud for that module.

Backplane Baudrate performs the following functions:

- Sets the adapter's Subnet baudrate
- Sends a message to all connected backplane I/O modules. If an I/O module is set to autobaud, it receives the message, but ignores the new baudrate.

Backplane Autobaud

The adapter itself never autobauds on the Subnet. Backplane Autobaud automatically enables or disables Autobaud for all I/O modules currently attached to the backplane. The adapter does not set a specific rate though (as with Backplane Baudrate).

If you enable Backplane Autobaud in the adapter or the EDS parameter access that you set from the primary DeviceNet, the adapter only enables the Autobaud in all backplane I/O modules. When the modules listen to communications on the DeviceNet network, they detect the rate of communication and automatically set their own baudrates to match the network rate.

The module does not automatically detect the backplane baudrate until power is cycled or the module is reset.

TIP

Autobaud, when enabled, is useful if you swap Serial Bus I/O modules between networks that are operating at different baudrates.

Enable Backplane Baudrate in RSNetWorx for DeviceNet.

IMPORTANT

Changes to the Backplane Autobaud parameter only take effect if they are downloaded on an individual basis. (For example, if you enable the Backplane Autobaud setting and download the change with additional changes to other features, the Backplane Baudrate remains disabled.)

This parameter should be set to 'Do Nothing' when you download all parameters, or when Automatic Device Replacement is enabled for the adapter.

If you want to set an I/O module to use a specific baudrate (i.e., 125, 250, 500), you must first disable Autobaud for that module.

Auto Address

The EDS parameter Auto Address is available from the primary DeviceNet and lets the user sequentially order the node addresses of backplane I/O modules. This parameter is not a mode, but occurs on a single occurrence only. The node address selected is assigned to the module closest to the adapter. The next closest module is assigned the next numerically higher value. The numbering pattern continues for all connected backplane I/O modules.

Enable this parameter in the RSNetWorx for DeviceNet software.

IMPORTANT

Changes to the Auto Address parameter only take effect if they are downloaded on an individual basis. (For example, if you enable the Auto Address and download the changes with additional changes to other features, the node addresses of the I/O modules remains disabled.)

This parameter should be set to 'Do Nothing' when you download all parameters, or when Automatic Device Replacement is enabled for the adapter.

Physical List Acquire Status

The adapter maintains a physical list that indicates the order of the node addresses of all Serial Bus I/O modules present on the backplane. Physical List Acquire Status shows the status of this physical list acquire process.

The adapter requires that each backplane I/O module has a MACID greater than that of its neighbor to its immediate left. The list is created when power is applied to the adapter and each time a module is inserted on the backplane.

The valid values are:

- Idle
- Busy
- Auto Start Mode



Cycling Node Status

Using the Cycling Node Status parameter, you can easily determine the status of any Serial Bus I/O modules with which the adapter is experiencing problems. A corresponding text string appears, including the MAC ID, and a description of the status code reported in the Node Status Table. For more information on the Node Status Table, see page 2-11.

For the connection sizes mentioned below, the I/O connection sizes on DeviceNet are dependent on the scanlist configuration on the backplane.

Poll/COS Connection Consume Size

Poll/COS Connection Consume Size shows the size (number of data bytes) consumed by the poll/COS (Instance 2) I/O connection on the primary DeviceNet.

Poll Connection Produce Size

Poll Connection Produce Size shows the size (number of data bytes) produced by the polled (Instance 2) I/O connection on the primary DeviceNet.

COS/Cyclic Connection Produce Size

COS Produce Size shows the size (number of data bytes) produced by the Change of State I/O connection on the primary DeviceNet.

Strobe Connection Produce Size

The Strobe Produce Size shows the size (number of data bytes) produced by the Strobe I/O connection on the primary DeviceNet.

Cycling I/O Mapping

Cycling I/O Mapping is an EDS parameter, accessible from the primary DeviceNet, that shows you how data is mapped in the adapter's scanlist. The data, as shown below, is listed in order of active modules in the scanlist.

PSSCDM12A Serial Bus DeviceNet Ad	lapter-1 🕮
General Device Bridging Parameters VOD	Ma BOSPIe
Select the parameter that you want to action using the toolbox.	configure and initials an
Firm G G M 1	中國的國家
ID - R Parameter	Current Value
 Autobaucion Devantes: 	mand
2 Set Bodgiare Baubate	1 Houd
0 Set Bodiplane Autobasel	Do Nothing
4 AutoAddeas Badglare M	Bo Nething
 Auto Stat Node 	to texting
6 R Physical Access Status	Dif
7 R Pol/005-Cervertise Cers	3
8 / Pol Connection Produce See	2
9 fl COS Connection Produce	12
10 R Stobe Connection Produc	1
11 R Cycling tode Status	to Problems Detected
12 /B Cycling UO Magaing	12 0002/0402/7,3C804
*1	×
OK Dent	Auto Hela

The data format is NN OBBB:b-BBB:b,IDBBB:b-BBB:b, where:

- NN = node number
- O or I = data type (output or input)
- BBB = byte number
- b = bit number
- D = DeviceNet connection (C [COS/cyclic], S [strobe], or P [poll])

IMPORTANT

If an I/O module's data has multiple mappings, you must use RSNetWorx for DeviceNet to browse to the backplane to view the mappings.

Automatic Device Replacement

With Automatic Device Replacement (ADR), the adapter automatically configures a new replacement module.

IMPORTANT

The replacement module must match the original module (i.e., same vendor I.D., device type, product code, major and minor revision) for ADR to work. The parameters that must match are those selected in the electronic keying portion of the scanlist. You determine the level of electronic keying.

The backplane configuration parameters (e.g., Auto Address) should be set to 'Do Nothing'.

The adapter is capable of holding approximately 64K of configuration data for Serial Bus I/O modules connected to it. The adapter sends configuration data to an I/O module each time connections are created with that module (i.e., power cycle or module insertion to backplane).

You can exchange an old module for a new one if the following conditions are met:

- ADR is enabled in the adapter.
- The new module matches the old one (i.e., electronic keying).
- The new module is inserted in the proper location (only for modules using the backplane).

If the conditions listed above are met, the new module's MACID is changed to the appropriate value, if necessary, and the configuration information is subsequently downloaded to the module.

Physical Ordering

When power is applied, or when an I/O module is inserted, the adapter detects the backplane I/O modules' order, based on MACID. With Physical Ordering, the adapter detects if any Serial Bus I/O modules connected to it are out of order. If this condition is detected, the adapter changes the MACIDs of any new modules.

IMPORTANT

If any backplane I/O modules are missing when power is applied, none of the backplane modules enter run mode.

The adapter's MACID is always 0 on Subnet. The MACIDs of each attached backplane I/O module must be sequentially ordered (i.e., each module's MACID is greater than the left adjacent module).

Interscan Delay (ISD)

Interscan Delay is the time delay between consecutive I/O scans of polled devices. The default setting is 10ms. The ISD=4ms for Auto Start Mode. You can change this parameter in the **Module** window of the scanner in the RSNetWorx for DeviceNet software.

The scanner uses this period of time to perform non-time-critical communications on the DeviceNet network, such as communicating with RSNetWorx for DeviceNet software. Setting this parameter to a very low value increases the latency for non-time-critical scanner operations, including the time required to respond to RSLinx software and configuration functions. Setting this parameter to a very large value reduces the freshness of the I/O data being collected by the scanner and is not advisable.

Foreground to Background Poll Ratio

Foreground to Background Poll Ratio is the ratio of foreground to background polls. You can set this parameter in the **Module** window of the scanner in RSNetWorx for DeviceNet software.

Devices can be polled on every I/O scan (foreground), or they can be polled less frequently (background). Whether a particular device will be polled in the foreground or in the background is determined by its **Poll Rate** parameter on the **Edit I/O Parameters** dialog box, which is accessed from the **Scanlist** property page.

The poll ratio sets the frequency of poll I/O messages to a device in relation to the number of I/O scans. For example, if the poll ratio is set to 5, the scanner will poll the selected devices once every six I/O scans. We recommend that you use a poll ratio of 1.

Expected Packet Rate

Expected Packet Rate is the rate at which the packets will be expected to be received by the scanner. You set this parameter in the **Module** window (from the **Advanced** button) of the scanner in RSNetWorx for DeviceNet software.

IMPORTANT

We recommend that you do **not** change the Expected Packet Rate unless you are instructed to do so by a Rockwell Automation technical support representative.

Transmit Retries

Transmit Retries are the maximum number of times that the scanner will attempt to send an I/O message to a device before it times out and generates an error message. You set this parameter in the **Module** window (from the **Advanced** button) of the scanner in RSNetWorx for DeviceNet software.

IMPORTANT

We recommend that you do **not** change the Transmit Retries unless you are instructed to do so by a Rockwell Automation technical support representative.



Communicate Through the Adapter

As described previously in this manual, the adapter resides on the DeviceNet network and the PointBus simultaneously. The adapter's functions are as follows:

- DeviceNet adapter serves as a slave device that exchanges I/O data with another DeviceNet scanner device (e.g., 1771-SDN) via DeviceNet messages
- PointBus adapter serves as master for up to 63 I/O modules, using DeviceNet messages to consume from or produce data to each module.

IMPORTANT

If Automatic Device Replacement (ADR) is enabled on the adapter, you can only connect up to 62 modules via the PointBus.

For more information on ADR, see page 2-6.

Map the Data

Your adapter must store data temporarily before transferring it between devices. You must map data to your adapter's memory before transferring it.

For a detailed description of the mapping process, see page 2-9.

Overview of the Communication Process

In a typical configuration, the adapter acts as an interface between a DeviceNet scanner (e.g., Rockwell Automation 1756-DNB) and Serial Bus I/O modules. The following example graphic shows information transferred from a 1756-DNB to Serial Bus I/O modules.

IMPORTANT

Although information is exchanged between the Logix5555 and 1756-DNB, this diagram (nor this chapter) is not designed to explain such an exchange.

Four data transfers are shown in the diagram, including:

- 1. Scanner to adapter
- 2. Adapter to I/O modules
- 3. I/O modules to adapter
- 4. Adapter to scanner

Because the adapter simultaneously resides on the DeviceNet network and on PointBus, it serves as a slave to the processor (i.e., steps 1 and 4) and a master to the I/O modules (i.e., steps 2 and 3).

The four data transfers are not necessarily sequential. Transfers 2 and 3 typically occur more frequently than transfers 1 and 4.



The computers and PCMCIA card shown in the diagram are required to configure the processor, adapter, and I/O modules.

Although the PCMCIA card is used in this example, you can use other communications cards, such as PCID and KFD cards.

Key Points About Scanner to Adapter Transfer (Step 1)

- 1. Scanner initiates transfer
- 2. Scanner uses DeviceNet I/O messaging to write data to adapter. Data may contain:
- device output data
- configuration data

Key Points About Adapter to Output Module Transfer (Step 2)

- 1. Adapter initiates transfer
- 2. Adapter produces data for I/O module to consume. Data may contain:
- device output data
- · configuration data
- Key Points About Input Module to Adapter Transfer (**Step 3**) Adapter consumes data I/O module has produced. Data may contain:
 - device input data
 - status data
- Key Points About Adapter to Scanner Transfer (Step 4) SDN consumes I/O data produced by adapter. Data may contain:
 - · device input data
 - status data

Image Table Mapping

Your adapter receives data from:

•master devices (e.g., scanners) - output data is then passed to Serial Bus I/O modules

•input modules - input data is passed to the scanner

The adapter must map the data it receives to its internal memory before passing it to the appropriate device. The I/O map for a module is divided into:

•read bytes - input and status bytes

•write bytes - output and configuration bytes

The data is mapped by 3 buffers for input data (each representing an I/O connection on the primary DeviceNet) and 1 buffer for output data (representing data sent for Poll or COS connections on the primary DeviceNet).

The number of read bytes or write bytes can be 2 or more. The length of each I/O module's read bytes and write bytes vary in size depending on module complexity. Each I/O module supports at least 1 input byte or 1 output byte. Status and configuration are optional, depending on the module.

The following graphic shows how the adapter maps information.





See the I/O Status Word Bit Definitions table for definitions of the first 2 bytes of each I/O message produced by the adapter on DeviceNet.

Byte	Bit	Operating Mode	Operating Mode Description
0	0	0 = Run mode 1 = Idle mode	Run - The adapter maps output data to each module on PointBus.
0	1	1 = Device failure (at least one device failed)	Idle - Output data with zero length is sent to I/O modules. Device Failure - One or more of the
0	2	1 = Communication failure	devices in the scanlist has failed to communicate with the adapter.
0	3	1 = Duplicate node address failure	Communications Failure - The adapter has entered the BUSOFF
0	4	Reserved	state on the Subnet. Another
0	5	Reserved	Subnet device is configured with the wrong baud rate
0	6	Reserved	
0	7	Reserved	Duplicate Node Address Failure -
1	0	Reserved	same address (0) as the scanner
1	1	Reserved	on the Subnet and the adapter has
1	2	Reserved	talled its Dup_MAC_ID test.
1	3	Reserved	
1	4	Reserved	
1	5	Reserved	
1	6	Reserved	
1	7	Reserved	

I/O Status Word Bit Definitions

The first 2 bytes of output data on the DeviceNet network that are sent to the adapter are reserved as a command word. No bits have been defined.

Communicate With I/O Modules

The adapter module supports multiple communication choices. These choices all use the default I/O structure previously described. The adapter's master (e.g., 1756-DNB) makes the actual communication choice. The choices are:

- Polled Adapter sends data in response to received data.
- Strobe Adapter sends data in response to the strobe command. The single bit allocated to the adapter in the strobe message is not used. If the configured size of the input data (sent from the adapter) is greater than 8 bytes, the strobe connection establishment will fail. In this case, the input size must be reconfigured to 8 bytes or less (only 6 bytes are I/O data because the first 2 bytes are the status word).
- Change of State Adapter sends data based on detection of any changed value within the input data. Data is independently received based on change of state from the sender. Data in both directions can be acknowledged or unacknowledged depending on the run time configuration of the system.
- Cyclic Adapter sends data cyclically based on a configured time value. Data is independently received cyclically from the sender. Data in both directions can be acknowledged or unacknowledged depending on the run time configuration of the system.

The adapter uses these messages to solicit data from or deliver data to each device. Data received from the devices (i.e., input data) is organized by the adapter and retransmitted to the master. Data received from the master (i.e., output data) is organized in the adapter and sent on to the I/O modules.

Use Diagnostic Tables

The adapter maintains three diagnostic tables to manage the flow of data between a processor and a network's devices. You can access the table over DeviceNet through the Scan Config Object (Class Code 0x90), Instance 1, via the following read-only attributes:

- Faulted Node Table (Attribute 0xA) In this 8-byte table, each bit represents a node on the backplane. For example, bit 0 in byte 0 represents MACID 0 (the adapter), while bit 0 in byte 1 represents MACID 8 and so on. If a bit is set, a corresponding non-zero status value can be read from the Node State Table described below.
- Idle Node Table (Attribute 0xB) In this 8-byte table, each bit also represents a node on the backplane, as with the Faulted Node Table. If a bit is set in the Idle Node Table, the corresponding node is in the scanlist and currently in idle mode.
- Node Status Table (Attribute 0xC) This 64 byte table contains a status code for each possible MACID on the backplane. Non-zero values are accompanied with the respective bit in the Faulted Node Table being set.

See the table Node Status Table Numeric Code Definitions for an explanation of the text messages associated with the Node Status Table.

Numeric Code:	Text Message:	Definition:	Take this action:
70	DupMAC Failure	Adapter failed Duplicate Node Address check.	An I/O module has a MACID of zero. Change the module's address.
71	Scanner Cfg Error	Illegal data in the scan list table.	Reconfigure the scan list table and remove any illegal data.
72	Comm Failure	Slave device stopped communicating.	Inspect the I/O modules and verify connections.
73	Wrong Device Type	Device's identity information does not match electronic key in scan list table entry.	Verify that the correct device is at this node number. Make sure that the device matches the desired electronic key (vendor, product code, product type).
74	Port Overrun Error	Data overrun on port detected.	Modify your configuration and check for invalid data. Check network communication traffic.
75	Network Failure	Communication has ceased on the backplane.	Inspect the I/O modules and verify connections.
76	No Msg for Scanner	No direct network traffic for scanner detected.	No action. The scanner hears other network communication.
77	Wrong Data Size	Data size expected by the device does not match scan list entry.	Reconfigure your module for correct transmit and receive data sizes.
78	No Such Device	Slave device in scan list table does not exist.	Add the device to the network, or delete scan list entry for that device.
79	Transmit Failure	Adapter has failed to transmit a message.	Make sure that other modules exist on the backplane.
80	In Idle Mode	Adapter is in IDLE mode.	No action necessary. If you want the adapter to run, put it in RUN mode.

Node Status Table Numeric Code Definitions



Numeric Code:	Text Message:	Definition:	Take this action:
82	Fragmentation Error	Error detected in sequence of fragmented I/O messages from device.	Check scan list table entry for slave device to make sure that input and output data lengths are correct. Check slave device configuration.
83	Slave Init Error	Slave device is returning error responses when scanner attempts to communicate with it.	Check accuracy of scan list table entry. Check slave device configuration. Slave device might be in another master's scan list. Reboot slave device.
84	Not Yet Initialized	Adapter is initializing the DeviceNet channel.	No action.
85	Rcv Buffer Overflow	Data size is larger than 255 bytes.	Configure the device for a smaller data size.
86	Device Went Idle	Device is producing zero length data (idle state) while channel is in Run Mode.	Check device configuration and slave node status.
89	ADR Failed	Failure occurred when downloading ADR data to the I/O module.	Reconfigure the ADR download data for the I/O module.
91	Port Bus Off	Bus-off condition detected on communications port. Scanner is detecting communications errors.	Check DeviceNet connections and physical media integrity. Check system for failed slave devices or other possible sources of network interference.
92	Port Power Off	No network power detected on communications port.	Provide network power. Make sure that scanner drop cable is providing network power to adapter communications port.

Node Status Table Numeric Code Definitions

A user program can monitor the Device Failure Bit in the I/O message(s) received from the adapter. When it has determined the bit set, you can read the Faulted Node Table and Node Status Table, using the Explicit Message Program Control Feature of the scanner device, to determine the module experiencing problems and the nature of those problems.

Chapter Summary and What's Next

In this chapter you learned about the Serial Bus DeviceNet adapters. Move to Chapter 3 to learn about using Auto Start Mode.

Use Auto Start Mode

This chapter describes how to use the Auto Start Mode with your Serial Bus I/O DeviceNet adapters.

See the Following Sections:	Page:
Why Use Auto Start Mode?	3-2
Install the I/O Module	3-3
Use RSNetWorx for DeviceNet	3-4
Begin Auto Start Mode	3-5
Use Custom Configuration	3-6
Chapter Summary and What's Next	3-6

This chapter assumes you already have a Serial Bus system mounted. There are five simple steps to the Auto Start Mode:

1. Install the I/O Module



2. Wire the DeviceNet Adapters

3. Install the I/O Module







4. Use RSNetWorx for DeviceNet





5. Begin Auto Start Mode





Why Use Auto Start Mode?

Auto Start Mode offers you a quick and easy method of getting your Serial Bus I/O system 'up and running'. If your Serial Bus I/O application can use default configuration, you should use Auto Start Mode to easily begin operations.

Once your adapter is:

- Installed
- Connected to the system's I/O modules
- Online (in RSNetWorx for DeviceNet)

you only need to choose the Auto Start Mode option in the adapter's **Parameters** window in the RSNetWorx for DeviceNet software and the adapter begins working with a default configuration.

IMPORTANT

Although Auto Start Mode allows your adapter to operate with a default configuration, you can write a custom configuration after operation has begun.

For more information on how to write custom configuration for your adapter on DeviceNet, see Chapter 5, Add the Serial Bus DeviceNet Adapter to the DeviceNet Scanner's Scanlist.

What Does Auto Start Mode Do?

When using Auto Start Mode, the adapter:

- 1. Sets all modules on the backplane to Auto Baud
- 2. Reads the Subnet module's identity information
- 3. Sets backplane modules' addresses sequentially
- 4. Generates a scanlist for the Subnet
- 5. Maps I/O data, based on byte, word, double-word, or fixed boundaries

When this sequence of events is completed, the Serial Bus I/O modules connected to the adapter are ready to accept connections from a scanner.

How Is I/O Data Mapped Using Auto Start Mode?

In Auto Start Mode, you can map I/O data in the adapter's memory in one of the following ways:

- Byte Boundaries
- Word Boundaries
- Double Word Boundaries
- Fixed Boundaries

Byte Boundaries

Each node's I/O data is mapped in the adapter's memory at the next available byte. This option works best in applications that use Allen-Bradley PLCs and SLCs.

Word Boundaries

Each node's I/O data is mapped in the adapter's memory at the next available word. This option works best in applications that use Allen-Bradley PLCs and SLCs.

Double Word Boundaries

Each node's I/O data is mapped in the adapter's memory at the next available double word. This option works best in applications that use Allen-Bradley Logix products.

Fixed Boundaries

The map to the fixed location is based on the node address. Mapping size ranges from 1 to 32 and is set using an EDS parameter. The mapping for a node with address 1 begins on byte 2. The formula for mapping is: 2+((N-1)(mapsize)), where N = node address.

Keep the following in mind when using fixed boundaries:

- · You specify fixed map size using EDS parameters
- Data is mapped after status/channel words in I/O image, beginning with byte 2
- No data area is reserved for MACID 0 (the adapter)

Requirement To Using Auto Start Mode

Your Serial Bus DeviceNet adapter must be free of I/O connections on DeviceNet when you use Auto Start Mode. If you attempt to use Auto Start Mode after another scanner device has established I/O connections with the adapter, your attempt to use Auto Start Mode will be rejected. When the adapter is configuring itself in Auto Start Mode, no other device can establish I/O connections to the adapter.

Install the I/O Module

To install the module:

- 1. Using a bladed screwdriver, rotate the keyswitch on the mounting base clockwise until the correct number for the I/O module aligns with the notch in the base. (See the individual Serial Bus I/O module installation instructions for this number.)
- 2. Position the module vertically above the mounting base. The module will bridge two bases.



3. Push the module down until it engages the latching mechanism. You will hear a clicking sound when the module is properly engaged.

The locking mechanism will lock the module to the base.

Remove the Module From the Mounting Base

To remove the module from the mounting base:

- 1. Put a flat blade screwdriver into the slot of the orange latching mechanism.
- 2. Push the screwdriver toward the I/O module to disengage the latch. The module will lift up off the base.
- 3. Pull the module off of the base.

For more information on installing and wiring the multiple Serial Bus I/O modules, see the installation instructions for each catalog number.



3-4 Use Auto Start Mode

Use RSNetWorx for DeviceNet

You must use the RSNetWorx for DeviceNet software to configure your adapter.

Follow the steps below to use Auto Start Mode.

1. Go online in the software.

IMPORTANT

Auto Start Mode is only available when RSNetWorx for DeviceNet is online.

- A. Click on the Network pull-down menu.
 B. Choose Online.
- **2.** Once you are online, browse for the primary network (e.g., You can use Single Pass Browse).
 - A. Click on the Network pull-down menu.
 - B. Choose a Browse type.



3. Click OK to synchronize your offline and online configuration.

RShetWe	re for DeviceNet
٩	Britore the activerse allows younts carring are unline devices, you must uplead or diversional device information. When the uplead or diversional question is completed, your offline tankquation will be synchronized with the unline entropyle.
	Note: You can uplied or download device information on either a restrict-volle or individual device base.

The adapter appears on the screen.

4. Double click on the adapter icon.

In Od She Month Davis Superior Date and	100
きほうにほうねか ぜんらしてい ひっかん 罰請	
Inclusion III III III III III III III III III I	2
C Transportentiem Interface C Transportentiem Interface C Transportentiem Interface C Transportentiem Interface C Transportentiem C Transportentiem	
	1

You can either:

- · Upload configuration from the device to update the software
- Download configuration from the software to the device
- 5. Click **Yes** to upload configuration from the device.



Begin Auto Start Mode

After you upload the configuration from the device to the software, begin Auto Start Mode (ASM).

- 1. Double click on the adapter icon to open the adapter properties window.
- 2. Click on the Parameters tab.
- 3. Click on the right side of the Auto Start Mode line so that a menu appears.



4. Download the Auto Start Mode value. Make sure you only download this single value, as shown below.



After 30-40 seconds, the adapter begins operations and uses the configuration most recently applied. During the Auto Start Mode process, the **Physical List Acquire Status** field displays the words: **Auto Start Mode**, but after the download is complete the field displays the word **Idle**.

- · Check for solid red indicators on all modules
- Verify that all non-backplane modules have the proper baudrate (or have autobaud enabled)
- Check that MACIDs are set to proper values

Check scanlist

- browse to Subnet and view scanlist, or look at mapping text

- Make sure the scanlist was saved (if not, investigate why?)

After ASM has completed (that is, **Physical List Acquire Status** field is **Idle**), verify that the operation was successful and that each I/O module was added to the adapter's scanlist. The PointBus Status LED should be solid green. This indicates only that the adapter is able to establish I/O connections with each module in its scanlist, not that each module on the Subnet was successfully added to its scanlist.

To verify the presence of each module in the adapter's scanlist, perform one of the following checks:

- Each I/O module's NET LED should be solid green. If the device has neither LED, use one of the following methods.
 - By browsing to the Subnet and uploading the adapter's scanlist using RSNetWorx for DeviceNet and verifying that the device is found in the scanlist.
 - By repeatedly uploading the EDS parameter Cycling I/O Mapping to verify that a mapping for the concerned module exists. See page 2-6 for more information about this parameter.

If one of the following is observed, it is likely that one of the Subnet modules has been addressed incorrectly or is configured to communicate at the wrong baud rate.

- The adapter's PointBus Status LED is solid or blinking red
- An I/O module's NET LED is solid red
- · It appears that the adapter has not saved a scanlist

Use the following procedures to attempt to remedy a problem:

 Verify that each backplane module is configured to autobaud. The adapter's EDS parameter Set Backplane Autobaud can be used to set each module's autobaud parameter. It is necessary to cycle a module's power before the autobaud parameter change takes effect. In rare situations, it may be necessary to download the parameter and cycle power several times before each backplane module's autobaud parameter has been changed.

Note that if the adapter is configured to autobaud on the primary DeviceNet network, network traffic on the primary network is required before the backplane modules will attempt to communicate. For this reason, it is sometimes helpful to have RSLinx continuously browsing the primary network while attempting the ASM process and verification.

When it is believed that each non-backplane module is correctly configured and that each backplane module is able to communicate on the Subnet, the ASM process can be attempted again.

After successfully configuring your adapter with the Auto Start Mode feature, the adapter must still be added to the primary DeviceNet network scanner's scanlist. See Chapter 5 for more information.



Use Custom Configuration

The Auto Start Mode is recommended to quickly and easily get your Serial Bus I/O system 'up and running'. But this mode does not prevent you from changing the adapter's default configuration after system operation has begun.

For more information on how to write custom configuration for your adapter on DeviceNet, see Chapter 4, Configure the DeviceNet Scanner Subnet and Chapter 5, Add the Serial Bus DeviceNet Adapter to the DeviceNet Scanner's Scanlist.

IMPORTANT

The adapter's ADR configuration for the Subnet modules is reset when you run Auto Start Mode.

Chapter Summary and What's Next

Auto Start Mode was discussed in this chapter. Move on to Chapter 4, Configure the DeviceNet Scanner Subnet or to Chapter 5, Add the Serial Bus DeviceNet Adapter to the DeviceNet Scanner's Scanlist.

Configure the DeviceNet Scanner Subnet

This chapter describes how to custom configure your scanner for use with Serial Bus I/O modules.

See the Following Sections:	Page:
Configuration Overview	4-1
Add the Scanner to Your Network	4-1
Add I/O Modules to Your Network	4-1
Set the Scanner's Parameters	4-2
Go On Line	4-6
Chapter Summary and What's Next	4-6

Your adapter works on two networks simultaneously and must be configured for each separately. This chapter explains configuration of the scanner for use with Serial Bus I/O modules.

For information on how to configure the adapter for use on the DeviceNet Network, see Chapter 5, Adding the DeviceNet Adapters to the DeviceNet Scanner's Scanlist.

Configuration Overview

You must use the RSNetWorx for DeviceNet software to configure your scanner. You can configure the scanner while it is:

- On Line
- Off Line

This chapter shows configuration in the offline mode. Configuration screens appear the same in both modes. Note that some screen options are unavailable in offline mode. The only difference is that if you make changes off line, you must take the scanner on line before the configuration changes take effect.

IMPORTANT

Throughout most of this manual, we refer to the Serial Bus I/O DeviceNet adapter as the adapter. The adapter also communicates with Subnet modules as a scanner. In this chapter only, the adapter is referred to as a scanner.

You must follow these steps during configuration:

- 1. Add the scanner to your network
- 2. Add I/O modules to your network
- **3.** Set the scanner's parameters
- 4. Go on line

Add the Scanner To Your Network

- Follow these steps:
- 1. Start RSNetWorx for DeviceNet.
- 2. Add the scanner as shown below.



Add I/O Modules To Your Network

After you add the scanner, you must add the modules connected to the scanner on the Subnet. In the offline mode, I/O modules must be added individually. Follow these steps:

1. Add modules as shown below.

1.	Expand Vendor → Parker Hannifin Corp. to display the list of I/O modules.	2.	Double Click the I/O module you want to add to the network.	- r t	FIP: You can also click and drag the module name onto he network.	c
	numer Alexandra Internet				593	3





Set the Scanner's Parameters

1. Configure the scanner as shown below.

After adding the scanner to the network, you must configure it for use with I/O modules.

IMPORTANT

This chapter shows configuration in the off line mode. Changes set in this mode do not take effect until the scanner goes on line. For more information on how to go on line, see page 4-6.



A window will open with a series of tabs along the top. Each tab opens to a window that provides options to write configuration for your scanner. These windows are shown on the following pages.

General window	PSSCDW12A Scanner
	Output ADR Summary General Device Bridging Module Scareful Input
Type the scanner's — name here.	PSSC0H12A Scanner Nane: 38806031838080203
Type a description — here (optional).	Description:
The scanner's address must = 0.	Addess 0
This window also shows the scanner's	Device Identity [Philusey] Vendo: Parlver Hermitin Cosp. [4] Type: Communication:Adapter [12]
These fields are read only.	Device: PSSEDH124.Scenner[256] Catelog: PSSEDH124 Revision: 2.008 (III III)
Click OK to accept the Parameters.	OK Cancel Apply Help

IMPORTANT

Configuration changes made in offline mode do not take effect until the scanner goes on line. For more information on how the scanner goes on line, see page 4-6.

Device Bridging window



For more information on the need to maintain two configuration files in the same adapter and the simultaneous presence of the adapter on two networks (i.e., DeviceNet as a slave and PointBus as a master), see page 4-1.

Use Clear Association to remove previously established configuration file associations that no longer apply to your scanner.



method (e.g., Polled) and make other appropriate I/O parameter changes on

this screen.

Configure the DeviceNet Scanner Subnet

4-3

Dupa Size - Eyter defeatured. Put Rate Restore I/O Spec

Click OK when finished.







Following are the remaining configuration windows.



for this window, but are here to maintain consistency among the windows.

This completes the configuration options. Your scanner must go on line for configuration changes to take effect.



Go On Line

After you set configuration parameters, your scanner must go on line to accept the configuration changes. Follow these steps:

1. Use the Network pulldown to go on line.



The software prompts you to save your configuration changes.

sere charges or eare	uth upper price out the state	1963 5	
If you do not save, all	changes to the netw	ork wide configurat	ion will be disc
Yes	1 00	Cancel	
	If you do not save, al	If you do not save, all changes to the network	If you do not save, all changes to the network wide configurat

2. Choose your scanner's network and apply the changes, as shown below.

	Erewie for setwork
	Select a communications path to the decised network.
	R Address Trong
Select the DeviceNet — network subnetwork.	1754-0169,0, 1754-0469,0 005.40.20 1754-0169,0, 1754-0469,0 005.40.20 1784-0169,0, 1754-0469,0 045.20 Dadgiare, 1755-01754-0469,0 101,0 1754-0554,0 1754-05534,1755-01124-04605 1,1754-0554,0, 0755-055,0 1754-05534,1755-01124-04605 1,1754-0569,0 0 1,1754-0569,0 0 1,1754-0569,0 0 1,1754-0569,0 0 1,1754-0569,0 0 1,1754-0569,0 0 1,1754-0569,0 0
This selection accesses the PointBus to configure the adapter on the DeviceNet network.	Concentration of the second seco
Click OK to apply the —— data to your scanner.	OK Cascal Hep

Chapter Summary and What's Next

In this chapter, you learned how to configure the scanner. Move to Chapter 5 to learn how to add the Serial Bus DeviceNet adapter to the DeviceNet scanner's scanlist.

Add the Serial Bus DeviceNet Adapter to the DeviceNet Scanners Scanlist

This chapter describes how to custom configure your adapter for use with DeviceNet devices.

See the Following Sections:	Page:
Configuration Overview	5-1
Add the Adapter to Your Network	5-1
Set the Adapter's Parameters	5-2
Go On Line	5-4
Chapter Summary	5-4

Your adapter works on two networks simultaneously and must be configured for each separately, which means that you will have two separate RSNetWorx for DeviceNet software files.

This chapter explains configuration of the adapter for use on the primary DeviceNet network. For information on how to configure the adapter for use on the Subnet, see Chapter 4, Configure the DeviceNet Scanner Subnet.

Configuration Overview

You must use the RSNetWorx for DeviceNet software to configure your adapter. You can configure the adapter while it is:

- On line
- Off line

This chapter shows configuration in the offline mode. Configuration screens appear the same in both modes. Note that some screen options are unavailable in offline mode. The only difference is that if you make changes off line, you must take the adapter on line before the configuration changes take effect.

You must follow these steps during configuration:

- 1. Add the adapter to your network
- 2. Set the adapter's parameters
- **3.** Add the DeviceNet adapter's scanlist (see the Quick Start, Appendix B)
- 4. Go on line

Add the Adapter to Your Network

Follow these steps:

- 1. Start the RSNetWorx for DeviceNet software.
- 2. Add the adapter as shown below.
- 1. Expand the list of Communication Adapters.

2. To add the adapter, you can double click on the adapter, or click and drag the adapter name onto the network.

the state of the second s		1.2.2
2. Barbery		80
Control of the second sec		
	a contribute (Senter) was before and a 1 hands (c)	
Rear Lab. Law		
-		Ma



Set the Adapter's Parameters

After adding the adapter to the network, you must configure it for use with master DeviceNet devices.

IMPORTANT

This chapter shows configuration in the offline mode. Changes set in this mode do not take effect immediately. For configuration changes to take place, you must:

· go on line with your adapter

1. Configure the adapter as shown below.

· download the new configuration to your adapter

For more information on how to go on line, see page 5-4.



You see a window with a series of tabs. Each tab opens to a window that provides options to write configuration for your adapter. The tabs are shown on the following pages.

General window	SSCDM12A Adapter
	General Device Bridging Parameters 1/0 Data EDS File
Type the scanner's - name here.	PSSCEHT2A-Adapter Name J2800023140855725
Type a description - here (optional).	Description
Set the desired address. This address	Address: 0
address switch on the adapter.	Vendor: Parker Hawville Cop. [4] Type: Communication Adapter [12] Device: PSSCD#138. Adapter [259]
This screen shows the adapter's device identity.	Catalog PSSCDH12A Rentator 2.000 (#)
These fields are read only	OK Cascel Apply Help

Device Bridging

the adapter on two

networks (i.e., DeviceNet

master), see page 5-1.

as a slave and Subnet as a



remove previously established configuration file associations that no longer apply to your adapter.

Parameters window

Restore all parameter default values.

For a description of a specific parameter, — highlight the parameter below and click here.

Any parameter with a lock shown before it cannot be changed.

The values correspondto the I/O connection sizes from the **I/O Data** window. They can be uploaded from an adapter with a downloaded scanlist.

		of the parameter field you want to config in using the lookat	ue and edute as
ofa	Teon Decel		Current Value
,	L	Autobaud on Devicaties:	Ended
neter	2	Set Backplane Dauch etc.	De Nothing
	3	Set Backplane Autobaud	Do Nothing
re.		Auto-Address Backplane Modules	Do Nothing
		Auto Start Pitele	Dulkollung
n a —	4.1	R Preside Acquire Status	IDAE
it	7	8 Pol/COS Comedian Consume Size	2
	4.4	8 Foll-Connection Produce Size	1
J.		COS Connection Produce Size	1
	11	8 Stabe Connection Produce See	2
ond —	11 /	R Cycling Node Status	Mode Status
n	12 /	E Cycling DC Magang	UC Majoing
Data be	1		×

IMPORTANT

The following configuration parameters:

- Auto Start Mode
- Set Backplane Baudrate
- Set Backplane Autobaud
- AutoAddress Backplane Modules

should only be used when on line and should be set to **Do Nothing** when **Download All Parameters** is selected or when saving to a scanner's ADR data.

S

The following screens show how to change the other parameters.

AutoAddress

	S. Pacaneter	Current Halue	
1	Autobiaud on/DeviceMet	Drabled	1
2.	Set Exclptone Baudrate	Excelect	
3	Set Enciplane Autobaud	Disabled	

Enable or disable autoaddress.

Backplane Autobaud

Gar	18	Parameter	Curvers Value	
-1		Autobaud on DeviceMet	Enabled	1
2.		Set Backplane Daubrate	125 thead	- 3
3		Set Boriplane Autobaut	Do Nething	-
4		AutoAddress Badiplane H	Du Nothing	
5.		Auto Start Mede	Enable Astobaud	
6	.8	Phys List Acquire Solice	Duable Autobaud	

Configure backplane modules to autobaud.

Auto Start Mode

t git		12 G 14	· + Martin 第二曲
-	19	Parameter	Current Haller
1		Autobaudion SeviceNet	Enabled
2		Set Earlplane Boudrate	Ou Nothing
3		Tel Exciptore Autobaul	Do Matilang
+		Autoeddress Baciplane PL.,	Do Netting
5		Auto Start Mode	Do Nothing
6		Phys List Acquire Status	Do Nothing
7	.8	Phil/005 Convection Corp	Plap Data To Eyte Boundaries
18.	.8	Phil Connection Produce See	Phip Data To Word Boundaries
٠		COS Consection Produce	Plap Data To Diviord Boundarie
30		Stroke Connection Produc	2
11		Cycling Node Status	Node Status
12		Cycling 3/0 Mapping	1/0 Pleasing

Backplane Baudrate

	1.8	For unvotor	Current lieka	
1		Autobaud on DeviceNet	Evabled	- 19
2		Set Sociale e Baschote	125 Khoud	-
1		Set Badghare Autobaut	Co Nething	-
. 4		AutoActivess Baciglane M	125 (baud	
		Auto Start Phote	250 sheud	
	- 8	Provide Accure Status	500 Kba.d	
	. 4	PuBCOS Convertain-Cons	L PEAL	

Set the backplane baudrate.

AutoAddress Backplane Modules

1	10	Forumeter	Carrent liske	
1		Autobaud on DeviceMet	tratied	- 5
1		Set Badglare Bauckste	125 (baul	- 04
.1		Set Budghme Autobaut	Do Nothing	19
4		AutoAddress Sucipiane H	De Niching	6
5		Auto Start Plote	Co Mething	
	. 4	Presidit Acquire Status	1	-
7	. 6	PulliCOS Connection Cons	2	
		Pol Correction Produce Size	3	
	. 4	COS Camedon Proban	4	

Choose the autoaddress.



The following screens show the remaining configuration windows.



Troubleshoot the Serial Bus DeviceNet Adapter

This chapter describes how to troubleshoot your adapter.

See the Following Sections:	Page:
Use the Status Indicators	6-1
Guidelines for Using Your Adapter	6-2
Chapter Summary	6-2

Indication	Probable Cause
DeviceNet Status	
Off	 Device is not on line: Device attempting to Autobaud Device has not completed dup_MAC-id test Device not powered - check module status indicator
Flashing Green	Device is on line but has no connections in the established state
Green	Device is on line and has connections in the established state
Flashing Red	One or more I/O connections in timed-out state
Red	Critical link failure - failed communication device. Device detected error that prevents it from communicating on the network. (Possible duplicate MAC ID or baud rate mismatch).

Use the Status Indicators

You can use the status indicators to troubleshoot your adapter. The following graphic shows the adapter's status indicators.



Use the table below to troubleshoot your adapter.

Indication	Probable Cause
Adapter Status	
Off	No power applied to device
Green	Device operating normally
Flashing Red	Recoverable fault
Red	Unrecoverable fault - may require device replacement
Flashing Red/Green	Device is in self-test

Indication	Probable Cause
PointBus Status	
Off	 Device is not on line: Device has not completed dup_MAC-id test Device not powered - check module status indicator
Flashing Green	Device is on line but has no connections in the established state
Green	Device is on line and has connections in the established state
Flashing Red	One or more I/O connections in timed-out state
Red	Critical link failure - failed communication device. Device detected error that prevents it from communicating on the network. (Possible duplicate MAC ID or baud rate mismatch).
Flashing Red/Green	Communication faulted device - the device has detected a network access error and is in communication faulted state. Device has received and accepted an Identity Communication Faulted Request - long protocol message.

Indication	Probable Cause				
System Power					
Off	Not active - Field power is off or dc-dc converter problem.				
Green	System power on - dc-dc converter active (5V).				

Indication	Probable Cause				
Adapter Power					
Off	Not active - Field power is off.				
Green	System power on, 24V present.				



Guidelines for Using Your Adapter

Remember the following operational guidelines when using your Serial Bus DeviceNet adapter.

- Do not leave spaces in the I/O. Instead, install all Serial Bus I/O modules adjacent to each other.
- Populate every position on the mounting base.
- Do not add new I/O modules to the end of the Serial Bus I/O system while the system is under power.
- · Use labels with the I/O modules.
- Do not move I/O modules to different locations on the mounting base after they have been installed and configured.
- If adjacent modules (i.e., 2 or more) are removed, replace all of them to operate the Serial Bus I/O system. Input data will hold last state until all previously removed modules are replaced.

Chapter Summary

In this chapter you learned how to troubleshoot your adapter.

Specifications Following are specifications for the DeviceNet adapters.

DeviceNet Adapters - RPSSCDM12A, RPSSCDM18PA							
Expansion I/O Capacity	 DeviceNet adapter backplane current output = 1.0A maximum. See the list below for backplane current consumption for each I/O catalog number and the current consumption for each of the modules connected to the DeviceNet adapter Verify that it is below 1.0A. Backplane current can be extended beyond 1.0A with a RPSSSE24A Backplane Extension Power Supply. The RPSSSE24A can supply up to an additional 1.3A of backplane current. Multiple RPSSSE24A modules can be used to reach the maximum of 63 modules. 						
	Cat. No. RPSSN8xxx RPSSP8xxx RPSST84M12A RPSSNACM12A RPSSNAVM12A RPSSTACM12A RPSSTACM12A RPSSTACM12A RPSSSV22A	PointBus Current Requirements 75 mA 75 mA 90 mA 75 mA 75 mA 75 mA 75 mA 75 mA 75 mA 75 mA 75 mA					
DeviceNet Communication Rate	125K bit/s (500m maximum) 250K bit/s (250m maximum) 500K bit/s (100m maximum)	75 mA					
DeviceNet Power Specifications	· · · · · · · · ·						
Power Supply	Note: In order to comply with CE Low Voltage Directives (LVD), you must use either a NEC Class 2, a Safety Extra Low Voltage (SELV) or a Protected Extra Low Voltage (PELV) power supply to power this adapter. A SELV supply cannot exceed 30V rms, 42.4V peak or 60VDC under normal conditions and under single fault conditions. A PELV supply has						
Input Voltage Bating	24VDC nominal						
DeviceNet Input Voltage Bange	11-25VDC DeviceNet specificat	tion					
Input Overvoltage Protection	Beverse polarity protected						
DeviceNet Power Requirements	24VDC (+4% = 25VDC) @ 30 r	mA maximum					
Power Supply Specifications							
Power Supply	Note: In order to comply with C NEC Class 2, a Safety Extra Lo power supply to power this ada or 60VDC under normal conditi the same rating and is connected	E Low Voltage Directives (LVD), you must use either a w Voltage (SELV) or a Protected Extra Low Voltage (PELV) pter. A SELV supply cannot exceed 30V rms, 42.4V peak ons and under single fault conditions. A PELV supply has ed to protected earth.					
Input Voltage Rating	24VDC 10-28.8VDC range						
Input Overvoltage Protection	Reverse polarity protected						
Inrush Current	6A maximum for 10ms						
PointBus Output Current	1A maximum @ 5VDC <u>+</u> 5% (4.	75-5.25)					
Field Side Power Requirements, Maximum	24VDC (+20% = 28.8VDC) @ 4	400 mA					
Interruption	Output voltage will stay within s 10ms at 10V with maximum loa	pecifications when input drops out for d					
General Specifications							
LED Indicators	1 green/red Adapter status 1 green/red DeviceNet status 1 green/red PointBus status 1 green System Power (PointBu 1 green Adapter Power (24V fro	us 5V power) om field supply)					



General Specifications (continued)							
Bewer Concumption Movimum							
Power Consumption, Maximum	8.1W @ 28.8VDC						
Power Dissipation, Maximum							
Thermal Dissipation, Maximum	9.5 BTU/hr. @ 28.8VDC						
Isolation Voltage	50V rms						
(continuous-voltage withstand rating)	lested at 1250VAC rms for 60s						
Field Power Bus							
Nominal Voltage	24VDU 10.28 8V/DC range						
Supply Voltage							
Dimensions Inches (Millimeters)	4 41H x 2 83W x 2 56D (112H x 72W x 65D)						
Operating Temperature	1.4.111 X 2.00W X 2.30D (11211 X 72W X 03D)						
	IEC 60068-2-2 (Test Rd, Operating Cold),						
	IEC 60068-2-14 (Test Nb, Operating Thermal Shock):						
	20 to 60°C (68 to 140°F)						
Storage Temperature	IEC 60068-2-1 (Test Ab, Un-packaged Non-operating Cold),						
	IEC 60068-2-2 (Test Bb, Un-packaged Non-operating Dry Heat),						
	-40 to 85°C (-40 to 185°F)						
Relative Humidity	IEC 60068-2-30 (Test Db, Un-packaged Non-operating Damp Heat):						
	5-95% non-condensing						
Shock	IEC60068-2-27 (Test Ea, Unpackaged Shock):						
	Operating 30g						
	Non-operating 50g						
Vibration	IEC60068-2-6 (lest Fc, Operating):						
	IEC 61000-4-2: 6kV contact discharges						
	8kV air discharges						
Badiated BE Immunity	IFC 61000-4-3						
	10V/m with 1kHz sine-wave 80%AM from 30MHz to 2000MHz						
	10V/m with 200Hz 50% Pulse 100%AM at 900Mhz						
	10V/m with 200Hz 50% Pulse 100%AM at 1890Mhz						
EFT/B Immunity	IEC 61000-4-4:						
	±4kV at 5kHz on power ports						
	±3kV at 5kHz on signal ports						
Surge Transient Immunity							
	± 1 kV line-line(DM) and ± 2 kV line-earth(CM) on power ports						
	1000-4-0.						
Emissions							
	Group 1 Class A						
Enclosure Type Bating	Meets IP65/66/67 (when marked)						
Mounting Base Screw Torque	#8 screw 7.5 in the in Aluminum 16 in the in Steel						
Wiring Category	1 - on power ports						
Winnig Category	1 - on communications ports						
Weight Imperial (Metric)							
Certifications: (when product is marked)	c-III -us, III Listed Industrial Control Equipment, certified for LIS and Canada						
Certifications. (when product is marked)	CE European Union 80/336/EEC EMC Directive, compliant with:						
	European onion 69/330/EEC ENC Directive, compliant with.						
	EN 50082-2: Industrial Immunity						
	EN 61326; Meas./Control/Lab., Industrial Requirements						
	EN 61000-6-2; Industrial Immunity						
	C-Tick Australian Radiocommunications Act, compliant with:						
	AS/NZS CISPR 11; Industrial Emissions						
	ODVA ODVA conformance tested to DeviceNet specifications						

1. Use this Conductor Category information for planning conductor routing. Refer to Publication A10324, "Industrial Automation Wiring and Grounding Guidelines".

Default Data Maps

I/O messages are sent to (consumed) and received from (produced) the Serial Bus I/O modules. These messages are mapped into the processor's memory. This appendix lists the default data maps for 1738 Serial Bus I/O modules.

For the Default Data Map of:	See Page:
RPSSN8 Sink Input Module	B-1
RPSSP8 Source Input Module	B-1
RPSST8 Electronically Protected Output Module	B-2
RPSSTR4 Relay Sink / Source Output Module	B-2
RPSSNAC Analog Current Input Module	B-2
RPSSNAV Analog Voltage Input Module	B-3
RPSSTAC Analog Current Output Module	B-3
RPSSTAV Analog Voltage Output Module	B-4
RPSSS23A ASCII Module	B-4
RPSSV32A 32 Point Valve Driver Module	B-4

RPSSN8 Sink Input Module

Message size: 1 Byte

	7	6	5	4	3	2	1	0
Produces (scanner Rx)	Ch7	Ch6	Ch5	Ch4	Ch3	Ch2	Ch1	Ch0
Consumes (scanner Tx)	No consumed data							
Where: Ch0 = input channel 0, Ch1 = input channel 1, Ch2 = input channel 2, Ch3 = input channel 3, Ch4 = input channel 4, Ch5 = input channel 5, Ch6 = input channel 6, Ch7 = input channel 7; 0 = OFF, 1 = ON								

RPSSP8 Source Input Module

Message size: 1 Byte

	7	6	5	4	3	2	1	0
Produces (scanner Rx)	Ch7	Ch6	Ch5	Ch4	Ch3	Ch2	Ch1	Ch0
Consumes (scanner Tx)	No consumed data							
Where: Ch0 = input channel 0, Ch1 = input channel 1, Ch2 = input channel 2, Ch3 = input channel 3, Ch4 = input channel 4, Ch5 = input channel 5, Ch6 = input channel 6, Ch7 = input channel 7; 0 = OFF, 1 = ON								



RPSST8 Electronically Protected Output Module

Message size: 1 Byte

	7	6	5	4	3	2	1	0	
Produces (scanner Rx)	Ch7	Ch6	Ch5	Ch4	Ch3	Ch2	Ch1	Ch0	Channel Status
Where: Ch0 = output channel 0, Ch1 = output channel 1, Ch2 = output channel 2, Ch3 = output channel 3, Ch4 = output channel 4, Ch5 = output channel 5, Ch6 = output channel 6, Ch7 = output channel 7; 0 = no error, 1 = error									

Message size: 1 Byte

	7	6	5	4	3	2	1	0	
Consumes (scanner Tx)	Ch7	Ch6	Ch5	Ch4	Ch3	Ch2	Ch1	Ch0	Channel State
Where: Ch0 = output channel 0, Ch1 = output cha Ch6 = output channel 6, Ch7 = output cha	annel 1, Ch2 annel 7; 0 =	2 = output cl OFF, 1 = Ol	hannel 2, Cł N	n3 = output	channel 3, (Ch4 = outpu	t channel 4,	Ch5 = outp	out channel 5,

RPSSTR4 Relay Sink / Source Output Module

Message size: 1 Byte

	7	6	5	4	3	2	1	0	
Consumes (scanner Tx)		Not l	Jsed		Ch3	Ch2	Ch1	Ch0	Channel State
Where: Ch0 = output channel 0, Ch1 = output channel 1, Ch2 = output channel 2, Ch3 = output channel 3; 0 = OFF, 1 = ON									

RPSSNAC Analog Current Input Module

Message size: 6 Bytes

	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
Produces (scanner Rx)			Input C	hanne	el 0 Hig	Ih Byte)				Input C	Channe	el 0 Lov	w Byte		•
		Input Channel 1 High Byte									Input C	Channe	el 1 Lov	w Byte		
		Status Byte for Channel 1									Status	Byte f	or Cha	innel 0		
	OR	UR	HHA	LLA	НА	LA	СМ	CF	OR	UR	HHA	LLA	НА	LA	СМ	CF
Consumes (scanner Tx)							No	consu	med d	ata						
Where: CF = Channel Fault stat	tus; 0 = n	no error,	1 = fault													
CM = Calibration Mode;	0 = norr	mal, 1 =	calibratio	n mode												
LA = Low Alarm, 0 = no	error, 1	= fault														
HA = High Alarm; 0 = nc	o error, 1	= fault														
LLA = Low/Low Alarm; (0 = no er	ror, 1 =	fault													
HHA = High/High Alarm	; 0 = no error, 1 = fault															
UR = Underrange; 0 = r	no error,	1 = fault														
OR = Overrange; 0 = no	o error, 1	error, 1 = fault														

RPSSNAV Analog Voltage Input Module

Message size: 6 Bytes

	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
Produces (scanner Rx)		Input Channel 0 - High Byte									nput C	hanne	I 0 - Lo	w Byte	9	
		Input Channel 1 - High Byte							Input Channel 1 - Low Byte							
	Status Byte for Channel 1 Status Byte for Channel						Status Byte for Channel 1						nnel 0			
	OR	R UR HHA LLA HA LA CM CF OR UR HHA LLA HA LA							СМ	CF						
Consumes (scanner Tx)							No	consu	med d	ata						
Where: CF = Channel Fault stat	tus; 0 = n	io error,	1 = fault													
CM = Calibration Mode;	; 0 = norr	nal, 1 =	calibratio	n mode												
LA = Low Alarm, 0 = no	error, 1	= fault														
HA = High Alarm; 0 = nc	o error, 1	= fault														
LLA = Low/Low Alarm;	0 = no er	ror, 1 = 1	fault													
HHA = High/High Alarm	n; 0 = no	= no error, 1 = fault														
UR = Underrange; 0 = r	no error,	error, 1 = fault														
OR = Overrange; 0 = no	o error, 1	rror, 1 = fault														

RPSSTAC Analog Current Output Module

Message size: 4 Bytes

	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
Consumes (Tx)		C	Dutput	Chann	el 0 Hi	gh Byt	e		Output Channel 0 Low Byte						Ð	
		C	Dutput	Chann	el 1 Hi	gh Byt	e		Output Channel 1 Low Byte							

Message size: 2 Bytes

	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
Produces (Rx)		High Byte - Channel 1 Status Low Byte - Channel 0 Status								s						
		Not Used HCA LCA CM CF Not Used HCA LCA C							СМ	CF						
Where: CF = Channel Fault stat	us; 0 = n	io error,	1 = fault													
CM = Calibration Mode;	0 = norr	nal, 1 =	calibratio	n mode												
LCA = Low Clamp Alarn	n, 0 = no	error, 1	= fault													
HCA = High Clamp Alar	m; 0 = n	o error, 1	l = fault													



RPSSTAV Analog Voltage Output Module

Message size: 2 Bytes

	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
Produces (Rx)		Channel 1 Status - High Byte						Channel 0 Status - Low Byte								
		Not	Jsed		HCA	LCA	СМ	ST		Not I	Jsed		HCA	LCA	СМ	ST
Where: ST = Channel Fault stat	us; 0 = n	io error,	1 = fault													
CM = Calibration Mode;	0 = norr	mal, 1 =	calibratic	n mode												
LCA = Low Clamp Alarr	m, 0 = no	error, 1	= fault													
HCA = High Clamp Alar	rm; 0 = n	o error, [·]	I = fault													

RPSSS23A ASCII Module

Default Receive Data Assembly Format (Default Mode)

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5-23	Byte 24
Rx Transaction ID Byte	Status Byte	Reserved	Length	ASCII Data	<cr> (Terminator)</cr>

Default Transmit Data Assembly Format (Default Mode)

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5-23	Byte 24
Reserved	TX Transaction ID Byte	Reserved	Length	ASCII Data	<cr> (Terminator)</cr>

RPSSV32A 32 Point Valve Driver Module

Message Size: 1 Byte

Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Produce 0	Output							
	7	6	5	4	3	2	1	0
Produce 1	Output							
	15	14	13	12	11	10	9	8
Produce 2	Output							
	23	22	21	20	19	18	17	16
Produce 3	Output							
	31	30	29	28	27	26	25	24
Produce 4	Fault							
	28-31	24-27	20-23	16-19	12-15	8-11	4-7	0-3
Consume 0	Output							
	7	6	5	4	3	2	1	0
Consume 1	Output							
	15	14	13	12	11	10	9	8
Consume 2	Output							
	23	22	21	20	19	18	17	16
Consume 3	Output							
	31	30	29	28	27	26	25	24

Α

adapter	
adding to network5-	1
auto start5-3	3
autoaddress5-3	3
autoaddress backplane modules5-3	3
backplane autobaud5-3	3
backplane baudrate5-3	3
configuration overview5-1	1
device bridging5-2	2
going on line5-4	1
guidelines for using6-2	2
I/O data parameter5-4	1
parameters5-3	3
residence on two networks simultaneously2-1	1
setting backplane baudrate5-3	3
setting parameters5-2	2
using2-1	1
what it is?2-1	1
adapter features	
auto address2-5	5
auto catalog replace2-4	1
auto start mode2-4	1
automatic device replacement2-6	3
backplane autobaud2-5	5
backplane baudrate2-4	1
COS connection produce size2-6	3
cycling I/O mapping2-6	3
cycling node status2-6	3
expected packet rate2-7	7
field upgradable firmware2-4	1
foreground to background poll ratio2-7	7
tully software configurable2-4	1
interscan delay2-	(
multiple baudrates	+
multiple connection types2-4	ŧ
physical list acquire status) 7
	(_
poli/COS connection consume size2-6	2 4
strate connection produce size	+
transmit ratrias	נ 7
uanshill reules2-1	1
auditers	1
	+ ว
winnyI-2	- 1
audioned for manualF-	•

auto catalog replace	
of adapter when power applied	2-4
auto start	
adapter	5-3
auto start mode	
beginning	3-5
byte boundaries	3-2
double word boundaries	3-2
fixed boundaries	3-2
mapping I/O data	3-2
of adapter when power applied	2-4
requirements to using	3-2
using	3-1
what it does	3-2
why use?	3-2
word boundaries	3-2
autoaddress	2-5
adapter	5-3
enabling in RSNetWorx for DeviceNet	5-3
autoaddress backplane modules	
adapter	5-3
autobaud	. P-3, 2-4
automatic device replacement	2-6
automatic device replacement via PointBus .	2-8

В

backplane	
set I/O module address	2-2
backplane autobaud	2-5
adapter	5-3
enabling in RSNetWorx for DeviceNet	5-3
backplane baudrate	2-4
adapter	5-3
setting	2-2
setting in RSNetWorx for DeviceNet	5-3
backplane network	2-3
baudrate	P-3, 2-4
byte boundaries	3-2

С

change of state (COS)	P-3, 2-2, 2-10
collecting data on PointBus	2-3
communicate through the adapter .	2-8
communications	
communicating with I/O modules	2-10

image table mapping	2-9
mapping data	2-8
overview of the process	2-8
configuration	
adapter overview	5-1
adding adapter to network	5-1
adding I/O modules to network	4-1
adding scanner to network	4-1
configuring scanner subnet	4-1
configuring the adapter for DeviceNet	5-1
going on line	4-6, 5-4
RSNetWorx for DeviceNet	P-1, P-3
setting the adapter's parameters	5-2
setting the scanner's parameters	4-2
using EDS files	5-4
configure the primary DeviceNet network .	2-2
configure the subnet I/O	2-2
connections	
to and from the adapter	2-4
contents of manual	P-2
ControlFlash	P-3, 2-4
conventions used in manual	P-4
COS connection produce size	2-6
custom configuration	
using	3-6
cyclicP-3	3, 2-3, 2-10
cycling I/O mapping	2-6

D

data alignment
scanner setting in RSNetWorx for DeviceNet 4-4
data collection
on PointBus2-3
data maps
defaultB-1
RPSSN8B-1
RPSSNACB-2
RPSSNAVB-3
RPSSP8B-1
RPSSS23AB-4
RPSST8B-2
RPSSTACB-3
RPSSTAVB-4
RPSSTR4B-2
data tables
faulted node table2-11

idle node table	2-11
node status table	2-11
default data maps	B-1
device bridging	5-2
DeviceNet communications	
backplane autobaud	2-5
backplane baudrate	2-4
change of state	P-3, 2-3, 2-10
cyclic	P-3, 2-3, 2-10
polled	P-3, 2-3, 2-10
strobe	P-3, 2-3, 2-10
DeviceNet network	2-3
remove and reinsert modules	2-2
RSNetwork for DeviceNet	2-1
understanding	2-3
DeviceNet network, primary	
configure	2-2
diagnostic tables	2-11
documentation	
other Serial Bus I/O products	2-3, P-4
double word boundaries	

Ε

EDS Files	5-4
expansion power unit (PSSSE24A)	2-3
expected packet rate	2-7
scanner setting in RSNetWorx for DeviceNet	4-3

F

faulted node table	2-11
firmware	
upgrading in the field	2-4
fixed boundaries	3-2
foreground to background poll ratio	2-7
scanner setting in RSNetWorx for DeviceNet	4-3

G

going on line guidelines	4-6, 5-4
using the adapter	6-2
guidelines for using the adapter	P-4
guidelines for using the adapter	P-4

I

I/O data parameter	
adapter5	-4

I/O modules

installing	3-3
removing from mounting base	
I/O status word bit	2-10
idle node table	2-11
image table mapping	2-9
installing	
I/O modules	
installing the adapter	1-1
interscan delay	2-7
scanner setting in RSNetWorx for DeviceNet	4-3

Μ

map from parameters	
scanner setting in RSNetWorx for DeviceNet	4-4
mapping data	2-8
mapping I/O data	
in auto start mode	3-2
module power	2-3
mount the adapter	1-1
mount the I/O base	1-1
mounting base	
removing I/O modules	3-3

Ν

networks	2-1
DeviceNet	2-3, 2-8
PointBus	2-8
node address	
setting	1-1
node status	
cycling	2-6
node status table	2-11

0

on line	
going	

Ρ

parameters

adapter	. 5-3
foreground to background poll ratio	. 4-3
I/O data, adapter	. 5-4
map from scanner	. 4-4
scanner	. 4-2

scanner data alignment	4-4
scanner expected packet rate setting	4-3
scanner interscan delay	4-3
scanner transmit retries	4-3
setting adapter	5-2
physical list acquire status	2-5
physical ordering	2-7
PointBus	2-1
data collection	2-3
poll/COS connection consume size	2-6
polledP-3,	2-3, 2-10
power	
expansion power unit	2-3
supplying power to Serial Bus I/O modules	2-3
primary DeviceNet network	
configure	2-2
products related to adapters	P-4
products related to Serial Bus I/O products	P-4
purpose of manual	P-1

R

related documentation	P-4, 2-3
related products	P-4
related terms	P-3
remove and reinsert modules on	
DeviceNet network	2-2
removing I/O base from mounting ba	ase3-3
RSNetWorx for DeviceNet	. P-3, 3-4, 4-1, 5-1
using	3-4
RSNetWorx for DeviceNet software .	P-1

S

scanner
adding I/O modules to network4-1
adding to network4-1
configuration overview4-1
data alignment4-4
expected packet ratesetting4-3
foreground to background poll ratio4-3
going on line4-6
interscan delay4-3
setting parameters4-2
settings in RSNetWorx for DeviceNet4-4
transmit retries4-3
self-test
of adapter when power applied2-4



set backplane baudrate2-2		
set backplane I/O module address2-2		
set node address1-1		
set subnet baudrate2-2		
set subnet I/O module address2-2		
software		
Configuring scanner subnet4-1		
configuring the adapter for DeviceNet5-1		
RSNetWorx for DeviceNetP-1, P-3, 2-4, 3-4		
specificationsA-1		
status indicators6-1		
strobe P-3, 2-3, 2-10		
strobe connection produce size2-6		
subnet		
configure I/O2-2		
set I/O module address2-2		
understanding2-3		
subnet baudrate		
setting2-2		
subnet network2-3		

Т

terminal marking kits	P-4
terms defined	P-3
terms used in manual	P-3
transmit retries	
scanner setting in RSNetWorx for DeviceNet	4-3
troubleshooting	
using status indicators	6-1

U

updating adapter firmware	
using the ControlFlash utility	P-3
using diagnostic tables	2-11
using the adatpers	
guidelines	P-4

W

wire the adapters	
word boundaries	







ROSS CONTROLS® Troy, MI, U.S.A. Telephone: + 1-248-764-1800 Fax: + 1-248-764-1850 In the United States: **Customer Service: 1-800-GET ROSS** (438-7677)Technical Service: 1-888-TEK-ROSS (835-7677)

www.rosscontrols.com

ROSS UK Ltd. Birmingham, United Kingdom Telephone: + 44-121-559-4900 Fax: + 44-121-559-5309 Email: sales@rossuk.co.uk

ROSS SOUTH AMERICA Ltda. São Paulo, Brazil CEP 09725-020 Telephone: + 55-11-4335-2200 Fax: + 55-11-4335-3888 Email: vendas@ross-sulamerica.com.br

Your local ROSS distributor is:

ROSS EUROPA[®] GmbH Langen, Germany Telephone: + 49-6103-7597-0 Fax: + 49-6103-74694 Email: info@rosseuropa.com www.rosseuropa.com

ROSS ASIA® K.K. Kanagawa, Japan Telephone: + 81-427-78-7251 Fax: + 81-427-78-7256 www.rossasia.co.jp

ROSS CONTROLS (CHINA) Ltd

Shanghai, China Telephone: + 86-21-6915-7951 Fax: + 86-21-6915-7960 Email: alvinzhurong@vip.163.com

ROSS CONTROLS® INDIA Pvt. Ltd.

Chennai, India Telephone: + 91-44-2624-9040 Fax: + 91-44-2625-8730 Email: rossindia@airtelbroadband.com

DIMAFLUID s.a.s.

Saint Ouen. France Telephone: + 33-01-49-45-65-65 Fax: + 33-01-49-45-65-30 Email: dimafluid@dimafluid.com www.dimafluid.com

Products manufactured by ROSS are warranted to be free of defects in material and workmanship for a period of one year from the date of purchase. ROSS' obligation under this warranty is limited to repair or replacement of the product or refund of the purchase price paid solely at the discretion of ROSS and provided such product is returned to ROSS freight prepaid and upon examination by ROSS such product is found to be defective. This warranty shall be void in the event that product has been subject to misuse, misapplication, improper maintenance, modification or tampering. THE WARRANTY EXPRESSED ABOVE IS IN LIEU OF AND EXCLUSIVE OF ALL OTHER WARRANTIES AND ROSS EXPRESSLY DISCLAIMS ALL OTHER WARRANTIES EITHER EXPRESSED OR IMPLIED WITH RESPECT TO MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. ROSS MAKES NO WARRANTY WITH RESPECT TO ITS PRODUCTS MEETING THE PROVISIONS OF ANY GOVERNMENTAL OCCUPATIONAL SAFETY AND/OR HEALTH LAWS OR REGULATIONS. IN NO EVENT SHALL ROSS BE LIABLE TO PURCHASER, USER, THEIR EMPLOYEES OR OTHERS FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES WHICH MAY RESULT FROM A BREACH OF THE WARRANTY DESCRIBED ABOVE OR THE USE OR MISUSE OF THE PRODUCTS. NO STATEMENT OF ANY REPRESENTATIVE OR EMPLOYEE OF ROSS SHALL EXTEND THE LIABILITY OF ROSS AS SET FORTH HEREIN.