TABLE OF CONTENTS

INTRODUCTION	2
SAFETY PRECAUTIONS	2
PACKAGE CONTENTS	3
Device Overview	3
BUTTON OPERATION SUMMARY	4
BASIC OPERATION	5
REAL TIME MODE	6
ALARM TIME MODE	7
ENABLING DAILY ALARM/HOURLY CHIME	7
ALARM SETTINGS	7
CHRONOGRAPH MODE	8
STARTING/STOPPING CHRONOGRAPH	8
Recording/Recalling Lap Time	8
TIMER MODE	9
Selecting Starting Time	9
TIMER SETTINGS	9
ALTIMETER MODE	10
OPERATING ALTIMETER	10
Absolute Altitude Settings	10
RELATIVE ALTITUDE ADJUSTMENT	11
BAROMETER MODE	12
MAINTENANCE	13

Thank you for purchasing **CANYON CNS-SW6**, a multi-functional watch device with thermometer, barometer, and altimeter function. You have made an excellent choice and we hope you will enjoy all of its exciting features. To fully utilize the functions and features of **CANYON CNS-SW6**, please read through the user manual carefully before using the product, and follow all of the procedures in the manual to fully enjoy all features of the product.

Introduction

Safety Precautions


Please observe all safety precautions before using the device. Please follow all procedures outlined in this manual to properly operate the device.

- Do NOT attempt to disassemble or alter any part of the device that is not described in this guide.
- Do NOT place the device near a heat source or directly expose it to flame.
- Never place the device in vicinity of equipments generating strong electromagnetic fields. Exposure to strong magnetic fields may cause malfunctions.
- Avoid exposing the device to extreme temperatures or chemicals such as gasoline and alcohol.
- Avoid strong impacts for it will damage the device permanently.
- Store device and its accessory at a dry and well ventilated location when they are not in use.

Package Contents

Product Image	Item Name
1-04 1-04	CANYON CNS-SW6 Main Unit
	Quick Guide
	Documentation CD

Device Overview



Button Operation Summary

MODE Button

- Press to cycle through 4 functional modes.
- During Settings Mode, press to cycle through different settings.

ADJUST Button

- Press and hold to enter settings mode.
- Press to recall lap memories in Chronograph Mode.

ST./STP. Button

- Press to start/stop time counting in Chronograph and Timer Mode.
- Press to toggle between units in Sensor Modes.
- Press to select items in Setting Modes.


ALTI-BARO Button

- Press to toggle between Time-Keeping Modes and Sensor Modes.
- Press to increase values at Settings Mode.
- Press to record lap memories in Chronograph Mode.
- Press and hold to reset lap memories in Chronograph Mode.
- Press to select timer preset value in Timer Mode.

LIGHT Button


• Press to turn on back light for 3 seconds

Basic Operation




CANYON CNS-SW6 is a multi-functional watch device that contains 4 functional modes including Real Time Mode, Alarm Time Mode, Chronograph Mode, and Timer Mode and 2 sensor modes including Altimeter Mode and Barometer Mode. Press **MODE** to cycle through 4 functional modes and **ALTI-BARO** to toggle between Real Time Mode and Sensor Modes.

Time and Date Settings



- Press and hold ADJUST for 2 seconds to enter Settings Mode.
- Press ST./STP. to cycle through different digits and settings. Press
 ALTI-BARO to adjust values and switch between time formats.
- Press ADJUST to save modified settings and exit Settings Mode.


Enabling Daily Alarm/Hourly Chime



Alarm Time Mode

- Upon entering, Alarm Time Mode indicator ALM will be displayed at the side of screen.
- Press **ST**./**STP**. to switch between daily alarm1 and daily alarm2 display.
- Press ALTI-BARO to switch daily alarms on/off and hourly chimes at daily alarm1 or daily alarm2 display. A daily alarm indicator •))) and/or hourly chime indicator **+** will be displayed on the screen when switched on.

Alarm Settings




start/stop Alarm Time Setting Sequence

hour

minute


- Press and hold ADJUST for 2 seconds at Alarm1/2 display to enter Settings Mode.
- Press ST./STP. to shift through different digits and press ALTI-BARO to adjust values.
- Press ADJUST to save modified settings and exit Settings Mode.




Starting/Stopping Chronograph

- Upon entering, the Chronograph
 Mode indicator CHR will be
 displayed at the side of screen.
- The device measures elapsed time and lap times.
- Press ST./STP. to start counting.
 Press the button again to stop counting and the elapsed time will be displayed on the screen. Press the button the third time to resume counting.
- Press and hold ALTI-BARO for 2 seconds to reset counter.

Recording/Recalling Lap Time





To recall the Lap Time


- Press ALTI-BARO while counting to display current lap time and press the button again to display current counting.
- Up to 10 lap times can be recorded.
- Press ADJUST to review recorded lap times when chronograph is stopped.
- Press and hold ALTI-BARO for 2 seconds to reset counter.

Selecting Starting Time



Timer Setting 1 Sequence


- Upon entering, the Timer Mode indicator TMR will be displayed at the side of screen.
- Press ALTI-BARO to select 1 of 4 preset starting time value and user preset starting time value.
- Press ST./STP. to start count down.
 The residual time will be displayed on the screen.
- Press ST./STP. to stop timer during count down. Press the button again to resume countdown.
- Press ALTI-BARO to reset countdown timer to target time.




- Press and hold ADJUST for 2 seconds to adjust user preset starting time value.
- Press ST./STP. to shift through different digits and press
 ALTI-BARO to adjust values.
- Press ADJUST to save modified settings and exit Settings Mode.

Timer Settings

Operating Altimeter






- Press ALTI-BARO at Real Time Mode to cycle through Altimeter Mode and Barometer Mode.
- The current temperature/altitude/ time is displayed at the top/ middle/bottom row of device screen.

NOTE:

To obtain more accurate readings, please keep the device away from body which will minimize effect of body heat.

 Press ST./STP. to switch between measurement units including altitude units meter(m)/feet(ft) and temperature units (°C)/ (°F).



Absolute Altitude Settings


 Absolute altitude is the difference between current altitude and sea level (assuming that air pressure at sea level is 1013.21mbar)

NOTE:

A precise altitude indication such as sea level (0m) or an altitude sign pole is required before calibration.


- Press and hold ADJUST for 2 seconds to adjust altitude.
- Press ST./STP. to shift through different digits and press
 ALTI-BARO to adjust values.
- Press ADJUST to save modified settings and exit Settings Mode.


Relative Altitude Adjustment



- Relative altitude is the difference between current altitude and the altitude of a specific altitude level.
- Press and hold ADJUST for 2 seconds to adjust altitude.
- Press ST./STP. to shift through different digits and press
 ALTI-BARO to adjust values to "zero".
- Press ADJUST to save modified settings and exit Settings Mode.
- To switch back to Altimeter with absolute altitude measurement, please refer to previous section to adjust altitude values.

Barometer Mode





Unit Selection Sequence


- Press ALTI-BARO at Real Time Mode to cycle through Altimeter Mode and Barometer Mode.
- The current temperature/pressure/ time is displayed at the top/ middle/bottom row of device screen.

NOTE:

To obtain more accurate readings, please keep the device away from body which will minimize effect of body heat.

 Press ST./STP. to switch between measurement units including pressure units mb/hPa / inHg and temperature units (°C)/ (°F).

Maintenance



 It is recommended to replace a new battery (CR-2032) when the low battery indicator appears on the screen display.