




# GS Series AC Drive Ethernet Interface User Manual



**BLANK  
PAGE**

# ⚡ WARNING ⚡

Thank you for purchasing automation equipment from Automationdirect.com®, doing business as AutomationDirect. We want your new automation equipment to operate safely. Anyone who installs or uses this equipment should read this publication (and any other relevant publications) before installing or operating the equipment.

To minimize the risk of potential safety problems, you should follow all applicable local and national codes that regulate the installation and operation of your equipment. These codes vary from area to area and usually change with time. It is your responsibility to determine which codes should be followed, and to verify that the equipment, installation, and operation is in compliance with the latest revision of these codes.

At a minimum, you should follow all applicable sections of the National Fire Code, National Electrical Code, and the codes of the National Electrical Manufacturer's Association (NEMA). There may be local regulatory or government offices that can also help determine which codes and standards are necessary for safe installation and operation.

Equipment damage or serious injury to personnel can result from the failure to follow all applicable codes and standards. We do not guarantee the products described in this publication are suitable for your particular application, nor do we assume any responsibility for your product design, installation, or operation.

Our products are not fault-tolerant and are not designed, manufactured or intended for use or resale as on-line control equipment in hazardous environments requiring fail-safe performance, such as in the operation of nuclear facilities, aircraft navigation or communication systems, air traffic control, direct life support machines, or weapons systems, in which the failure of the product could lead directly to death, personal injury, or severe physical or environmental damage ("High Risk Activities"). AutomationDirect specifically disclaims any expressed or implied warranty of fitness for High Risk Activities.

For additional warranty and safety information, see the Terms and Conditions section of our catalog. If you have any questions concerning the installation or operation of this equipment, or if you need additional information, please call us at 770-844-4200.

This publication is based on information that was available at the time it was printed. At AutomationDirect we constantly strive to improve our products and services, so we reserve the right to make changes to the products and/or publications at any time without notice and without any obligation. This publication may also discuss features that may not be available in certain revisions of the product.

## Trademarks

This publication may contain references to products produced and/or offered by other companies. The product and company names may be trademarked and are the sole property of their respective owners. AutomationDirect disclaims any proprietary interest in the marks and names of others.

**Copyright 2002, 2010, 2011, Automationdirect.com® Incorporated  
All Rights Reserved**

No part of this manual shall be copied, reproduced, or transmitted in any way without the prior, written consent of Automationdirect.com® Incorporated. AutomationDirect retains the exclusive rights to all information included in this document.

# ⚡ AVERTISSEMENT ⚡

Nous vous remercions d'avoir acheté l'équipement d'automatisation de Automationdirect.com®, en faisant des affaires comme AutomationDirect. Nous tenons à ce que votre nouvel équipement d'automatisation fonctionne en toute sécurité. Toute personne qui installe ou utilise cet équipement doit lire la présente publication (et toutes les autres publications pertinentes) avant de l'installer ou de l'utiliser.

Afin de réduire au minimum le risque d'éventuels problèmes de sécurité, vous devez respecter tous les codes locaux et nationaux applicables régissant l'installation et le fonctionnement de votre équipement. Ces codes diffèrent d'une région à l'autre et, habituellement, évoluent au fil du temps. Il vous incombe de déterminer les codes à respecter et de vous assurer que l'équipement, l'installation et le fonctionnement sont conformes aux exigences de la version la plus récente de ces codes.

Vous devez, à tout le moins, respecter toutes les sections applicables du Code national de prévention des incendies, du Code national de l'électricité et des codes de la National Electrical Manufacturer's Association (NEMA). Des organismes de réglementation ou des services gouvernementaux locaux peuvent également vous aider à déterminer les codes ainsi que les normes à respecter pour assurer une installation et un fonctionnement sûrs.

L'omission de respecter la totalité des codes et des normes applicables peut entraîner des dommages à l'équipement ou causer de graves blessures au personnel. Nous ne garantissons pas que les produits décrits dans cette publication conviennent à votre application particulière et nous n'assumons aucune responsabilité à l'égard de la conception, de l'installation ou du fonctionnement de votre produit.

Nos produits ne sont pas insensibles aux défaillances et ne sont ni conçus ni fabriqués pour l'utilisation ou la revente en tant qu'équipement de commande en ligne dans des environnements dangereux nécessitant une sécurité absolue, par exemple, l'exploitation d'installations nucléaires, les systèmes de navigation aérienne ou de communication, le contrôle de la circulation aérienne, les équipements de survie ou les systèmes d'armes, pour lesquels la défaillance du produit peut provoquer la mort, des blessures corporelles ou de graves dommages matériels ou environnementaux («activités à risque élevé»). La société AutomationDirect nie toute garantie expresse ou implicite d'aptitude à l'emploi en ce qui a trait aux activités à risque élevé.

Pour des renseignements additionnels touchant la garantie et la sécurité, veuillez consulter la section Modalités et conditions de notre documentation. Si vous avez des questions au sujet de l'installation ou du fonctionnement de cet équipement, ou encore si vous avez besoin de renseignements supplémentaires, n'hésitez pas à nous téléphoner au 770-844-4200.

Cette publication s'appuie sur l'information qui était disponible au moment de l'impression. À la société AutomationDirect, nous nous efforçons constamment d'améliorer nos produits et services. C'est pourquoi nous nous réservons le droit d'apporter des modifications aux produits ou aux publications en tout temps, sans préavis ni quelque obligation que ce soit. La présente publication peut aussi porter sur des caractéristiques susceptibles de ne pas être offertes dans certaines versions révisées du produit.

## Marques de commerce

La présente publication peut contenir des références à des produits fabriqués ou offerts par d'autres entreprises. Les désignations des produits et des entreprises peuvent être des marques de commerce et appartiennent exclusivement à leurs propriétaires respectifs. AutomationDirect nie tout intérêt dans les autres marques et désignations.

**Copyright 2002, 2010, 2011, Automationdirect.com® Incorporated  
Tous droits réservés**

Nulle partie de ce manuel ne doit être copiée, reproduite ou transmise de quelque façon que ce soit sans le consentement préalable écrit de la société Automationdirect.com® Incorporated. AutomationDirect conserve les droits exclusifs à l'égard de tous les renseignements contenus dans le présent document.



# GS SERIES AC DRIVE ETHERNET INTERFACE USER MANUAL

Please include the Manual Number and the Manual Issue, both shown below, when communicating with Technical Support regarding this publication.

**Manual Number:** GS-EDRV-M-WO  
**Issue:** Third Edition, Revision A  
**Issue Date:** 12/2011

Publication History		
Issue	Date	Description of Changes
First Edition	8/02/02	Original
1st Ed, Rev A	3/14/03	Added Input WORD functions
1st Ed, Rev B	8/12/05	Website publication only; Corrected Output Word Map & Warnings
Second Edition	02/2010	Revised "Reading/Writing From/To the Drive" & "Input/Output Word Map" sections
Third Edition	05/2011	Added GS-EDRV100 product information and specifications.
3rd Ed, Rev A	12/2011	User manual name change to "GS-EDRV-M-WO" (added "-WO") GS series AC drive connection parameter settings

**BLANK  
PAGE**

# GS-EDRV(100) USER MANUAL



# CONTENTS

---

Manual Overview . . . . .	2
Overview of this Publication . . . . .	2
Who Should Read This Manual . . . . .	2
Supplemental Publications . . . . .	2
Technical Support . . . . .	2
Special Symbols . . . . .	2
GS-EDRV Overview . . . . .	3
Package Contents . . . . .	4
GS-EDRV Board Layout . . . . .	5
Power Terminals . . . . .	5
Communication Ports . . . . .	6
DIP Switches . . . . .	6
LED Indicators . . . . .	6
Setting the GS-EDRV Address . . . . .	7
Setting Module ID with DIP Switches . . . . .	7
Setting TCP/IP Address with NetEdit . . . . .	8
GS-EDRV Network Connections . . . . .	9
GS-EDRV100 Overview . . . . .	10
Package Contents . . . . .	11
GS-EDRV100 Layout . . . . .	12
Power Terminals . . . . .	12
Communication Ports . . . . .	12
DIP Switches . . . . .	13
LED Indicators . . . . .	13
Setting the GS-EDRV100 Address . . . . .	14
Setting Module ID with DIP Switches . . . . .	14
Setting TCP/IP Address with NetEdit . . . . .	15

# GS-EDRV(100) USER MANUAL



# CONTENTS

---

GS-EDRV100 Network Connections .....	16
GS-EDRV(100) to GS Series AC Drive Connection .....	17
Setting the GS Series AC Drive Parameters .....	17
GS-EDRV(100) to ERM Module Connection .....	18
Reserved PLC Memory for the GS-EDRV(100) .....	18
Reading/Writing From/To the Drive .....	19
Input/Output Word Map .....	19
Examples – I/O Word Mapping .....	22
Built-in Web Server .....	24
Troubleshooting – H24-ERM-M .....	24
Refer to Ethernet Remote Master User Manual H24-ERM-M .....	24
Application Example: Modbus TCP/IP .....	25



**BLANK  
PAGE**

## Manual Overview

### Overview of this Publication

The GS AC Drive Ethernet Interface User Manual describes the installation, configuration, and operation of GS AC Drive Ethernet Interface cards.

### Who Should Read This Manual

This manual contains important information for those who will install, maintain, and/or operate any GS Series AC Drive Ethernet Interface card.

### Supplemental Publications

The **Ethernet Remote Master Module Manual** (H24-ERM-M) is available from **AutomationDirect** and may be useful for your application.

### Technical Support

**By Telephone: 770-844-4200**

(Mon.-Fri., 9:00 a.m.-6:00 p.m. E.T.)

**On the Web: [www.automationdirect.com](http://www.automationdirect.com)**

Our technical support group is glad to work with you in answering your questions. If you cannot find the solution to your particular application, or, if for any reason you need additional technical assistance, please call technical support at **770-844-4200**. We are available weekdays from 9:00 a.m. to 6:00 p.m. Eastern Time.

We also encourage you to visit our web site where you can find technical and non-technical information about our products and our company. Visit us at **[www.automationdirect.com](http://www.automationdirect.com)**.

### Special Symbols



---

*When you see the “notepad” icon in the left-hand margin, the paragraph to its immediate right will be a special note.*

---



---

**When you see the “exclamation mark” icon in the left-hand margin, the paragraph to its immediate right will be a WARNING. This information could prevent injury, loss of property, or even death (in extreme cases).**

---

## GS-EDRV Overview

The GS-EDRV provides a low-cost, high-performance 10BaseT Ethernet link between a control system and a GS Series AC Drive. The control system can be any of the following:

- DL205 CPU, DL405 CPU, or a WinPLC, with the appropriate Ethernet Remote Master module (H2-ERM or H4-ERM).
- A Productivity3000 CPU using the onboard Ethernet port.
- A PC running Entivity's ThinknDo software, a PC using a custom device driver that was developed using our Ethernet SDK, or a PC running **KEPDirect** EBC or OPC Server.
- Any independent I/O controller with a Modbus TCP/IP driver.

The GS-EDRV mounts on DIN rail and utilizes cable connections and, if needed, Ethernet switches or hubs to communicate to the AC drive.

The functions of the interface are as follows:

- process input signals from the AC drive.
- format these signals to conform to the Ethernet standard.
- transmit converted signals to the control system.
- receive and translate output signals from the control system.
- sends the output signals to the drive.

The control function is NOT performed by the interface. The control function is performed by one of the control systems mentioned above. The I/O mapping function is performed by an H2(4)-ERM module (purchased separately). The H2(4)-ERM module is configured with the ERM Workbench Utility which is part of the **DirectSOFT** PLC programming software.


### Package Contents

After receiving the GS-EDRV, please check for the following:

- Make sure that the part number indicated on the package corresponds with the part number of your order.
- Make sure that the package includes a GS AC Drive Ethernet Interface card (GS-EDRV), one piece of **SNAPTRACK™**, two DIN mounting clips, and one serial connection cable.
- Inspect the contents to insure they were not damaged during shipment.



# GS-EDRV Board Layout



## Power Terminals

Power for the GS-EDRV is connected directly to the card using a nominal 24VDC supply (+24VDC, -0VDC). The GNDC terminal is for a chassis or system Ground.

## Input Voltage

18–33 VDC with a 24VDC nominal supply

## Input Current

90–135 mA

### Communication Ports

Two comm ports are provided to make the connection from a GS Series AC drive (Serial port) to an Ethernet device or network (Ethernet port).

### DIP Switches

The DIP Switches are used to set the Module ID for the GS-EDRV card.

### LED Indicators

#### STATUS Indicator

The green STATUS LED is steady ON when the GS-EDRV is connected to a GS Series AC drive and communication has been established.

#### LINK

The green LINK LED is steady ON when the GS-EDRV is correctly connected to an active device on the network. The LINK LED verifies that the proper cables are connected, and the card is functioning correctly. If a mismatch with the 10BaseT connections occurs this LED will not be illuminated.

#### ACTIVE

The green ACTIVE LED flashes to indicate that the card sees data travelling on the network. If any network device is sending or receiving data, the ACTIVE LED will be illuminated. In idle mode (no network traffic) this LED is OFF. During heavy communication loads this LED will be steady ON.

#### ERROR Indicator

If the GS-EDRV's red Error (ERROR) indicator is flashing or steady ON, a fatal error has occurred. The error may be in the card itself, or a network problem may be causing this symptom. The ERROR indication can be caused by a faulty ground, an electrical spike or other types of electrical disturbances. Cycle power to the system to attempt clearing the error.

#### RTS

The green RTS LED indicates the GS-EDRV is ready to send information to the AC drive.

#### TXD

The green TXD LED flashes to indicate that the card sees data traveling to the AC drive. During heavy communication loads, this LED will be steady ON.

#### RXD

The green RXD LED flashes to indicate that the card sees data traveling from the AC drive. During heavy communication loads this LED will be steady ON.

## Setting the GS-EDRV Address

Each GS-EDRV must have an identification (ID) or address in order to be recognized on the network, and each ID must be unique.



**WARNING:** Duplicate IDs on the same network will cause unpredictable results and must be avoided.

### Setting Module ID with DIP Switches


You can use the DIP switch to set the ID to a number from one to sixty-three. Do not use ID "0" for communication.

If the DIP switch is set to a number greater than 0, the software tools are disabled from setting the ID. Again, the software tools will only allow changes to the ID if the DIP switch setting is 0 (zero, all switches OFF).



The DIP switch settings are read only at power-up. You must cycle power if you change the DIP switches.

The GS-EDRV contains eight individual DIP switches, but only six of these are active. You will find that the switches on the printed circuit board are labeled 0 (zero) through 7. The numbers on the printed circuit board indicate the power of 2 represented by each individual switch. For example, switch 0 represents  $2^0$  (or 1), switch 1 is  $2^1$  (or 2), switch 2 is  $2^2$  (or 4), and so on.




The ID equals the sum of the binary values of the slide switches set in the ON position. For example, if you set slide switches 1, 2, and 3 to the ON position, the ID will be 14. This is found by adding  $8+4+2=14$ . The maximum value you can set on the DIP switch is  $32+16+8+4+2+1=63$ . This is achieved by setting switches 0 through 5 to the ON position.


## Setting TCP/IP Address with NetEdit

NetEdit is a free utility that can be used to configure the GS-EDRV's IP address. This utility is included with the DirectSOFT software or it can be downloaded from <http://support.automationdirect.com/downloads.html>.

Connect your PC to the Ethernet network that the GS-EDRV is currently on and open the NetEdit utility. If it is not already selected, select the TCP/IP tab as seen below.




Double click on the desired GS-EDRV. A "General Settings" popup will display allowing you to configure the IP address of the module you have selected.



Press the OK button to write the new configuration to the GS-EDRV.




# GS-EDRV Network Connections



## 10Base-T Connections

The GS-EDRV Ethernet port has an eight-pin modular jack that accepts RJ45 connector plugs. UTP (Unshielded Twisted-Pair) cable is rated according to its data-carrying ability (bandwidth) and is given a "category" number. We strongly recommend using a category 5 cable for all Ethernet 10Base-T connections. For convenient and reliable networking, we recommend that you purchase commercially manufactured cables (cables with connectors already attached).

To connect an GS-EDRV (or PC) to a hub, switch, or repeater, use a patch cable (sometimes called a straight-through cable). The cable used to connect a PC or an H2(4)-ERM directly to an GS-EDRV or to connect two hubs is referred to as a crossover cable.



This diagram illustrates the standard wire positions in the RJ45 connector. We recommend all Ethernet 10BaseT cables to be Category 5, UTP cable.

# GS-EDRV100 Overview

The GS-EDRV100 provides a low cost, high-performance 10/100Mbps Ethernet link between a control system and a GS Series AC Drive. The control system can be any of the following:

- DL205 CPU, DL405 CPU, or a WinPLC, with the appropriate Ethernet Remote Master module (H2-ERM or H4-ERM).
- A Productivity3000 CPU using the onboard Ethernet port.
- A PC running Entivity's ThinknDo software, a PC using a custom device driver that was developed using our Ethernet SDK, or a PC running KEP **Direct** EBC or OPC Server.
- Any independent I/O controller with a Modbus TCP/IP driver.

The GS-EDRV100 has an encapsulated compact DIN rail mounted design allowing for minimal space requirements. With the appropriate cable connections and, if needed, Ethernet switches or hubs, the GS-EDRV100 will allow you to communicate with your AC drive over qualified Ethernet networks.

The functions of the interface are as follows:

- process input signals from the AC drive.
- format these signals to conform to the Ethernet standard.
- transmit converted signals to the control system.
- receive and translate output signals from the control system.
- sends the output signals to the drive.

The control function is NOT performed by the interface. The control function is performed by one of the control systems mentioned above. The I/O mapping function is performed by an H2(4)-ERM module (purchased separately). The H2(4)-ERM module is configured with the ERM Workbench Utility which is part of the **DirectSOFT** PLC programming software.


### Package Contents

After receiving the GS-EDRV100, please check for the following:

- Make sure that the part number indicated on the package corresponds with the part number of your order.
- Make sure that the package includes a GS AC Drive Ethernet Interface card (GS-EDRV100), one DIN rail mounting clip, one 3-wire terminal block, and one serial connection cable (2ft in length).
- Inspect the contents to insure they were not damaged during shipment.



## GS-EDRV100 Layout



**Power Terminals**  
(Class 2 power recommended)  
Positive connection (+) or +10-36VDC  
Negative connection (-) or 0VDC  
Chassis or system Ground connection

### Power Terminals

Power for the GS-EDRV100 is connected directly to the card using a 10-36VDC power supply (a Class 2 power supply is recommended). The Chassis terminal is for a chassis or system Ground.

### Input Current and Voltage Ratings

220mA@10VDC, 70mA@24VDC, or 50mA@36VDC.

### Communication Ports

Two comm ports are provided to make the connection from a GS Series AC drive (Serial port) to an Ethernet device or network (Ethernet port).

## DIP Switches

The DIP Switches are used to set the Module ID for the GS-EDRV100 card.

## LED Indicators

### STA

The STA or STATUS LED is steady ON when the GS-EDRV100 is connected to a GS Series AC drive and communication has been established.

### SPD

The SPD or SPEED LED is used to represent the Ethernet speed. The LED will be ON when the Ethernet speed is 100Mbps and OFF when the speed is 10Mbps.

### TXD

The TXD or TRANSMIT DATA LED flashes to indicate that the GS-EDRV100 is sending data through the serial port to the AC drive.

### ERR

If the GS-EDRV100's ERR (ERROR) indicator is ON, a critical error has occurred. The error may be in the card itself, or a network problem may be causing this symptom. The ERROR indication can be caused by a faulty ground, an electrical spike or other types of electrical disturbances. Cycle power to the system to attempt clearing the error. The ERROR LED will also flash (once per second) when a firmware update is in progress.

### LK/A

The LK/A or LINK GOOD/ACTIVITY LED flashes to indicate that the card sees data traveling on the Ethernet network. If any network device is sending or receiving data, the LK/A LED will be flashing. During heavy communication loads, this indicator will be steady ON. If the LED is OFF, then a problem with the Ethernet connection has been detected.

### RXD

The RXD or RECEIVE DATA LED flashes to indicate that the GS-EDRV100 is receiving data through the serial port from the AC drive.

## Setting the GS-EDRV100 Address

Each GS-EDRV100 must have an identification (ID) or address in order to be recognized on the network, and each ID must be unique.



**WARNING:** Duplicate IDs on the same network will cause unpredictable results and must be avoided.

### Setting Module ID with DIP Switches


You can use the DIP switch to set the ID to a number from one to sixty-three. Do not use ID "0" for communication.

**If the DIP switch is set to a number greater than 0, the software tools are disabled from setting the ID. Again, the software tools will only allow changes to the ID if the DIP switch setting is 0 (zero, all switches OFF).**



*The DIP switch settings are read only at power-up. You must cycle power if you change the DIP switches.*

The GS-EDRV100 contains eight individual DIP switches, but only six of these are active. You will find that the switches on the printed circuit board are labeled 0 (zero) through 7. The numbers on the printed circuit board indicate the power of 2 represented by each individual switch. For example, switch 0 represents  $2^0$  (or 1), switch 1 is  $2^1$  (or 2), switch 2 is  $2^2$  (or 4), and so on.




The ID equals the sum of the binary values of the slide switches set in the ON position. For example, if you set slide switches 1, 2, and 3 to the ON position, the ID will be 14. This is found by adding  $8+4+2=14$ . The maximum value you can set on the DIP switch is  $32+16+8+4+2+1=63$ . This is achieved by setting switches 0 through 5 to the ON position.


## Setting TCP/IP Address with NetEdit

NetEdit is a free utility that can be used to configure the GS-EDRV100's IP address. This utility is included with the DirectSOFT software or it can be downloaded from <http://support.automationdirect.com/downloads.html>.

Connect your PC to the Ethernet network that the GS-EDRV100 is currently on and open the NetEdit utility. If it is not already selected, select the TCP/IP tab as seen below.



Double click on the desired GS-EDRV100. A "General Settings" popup will display allowing you to configure the IP address of the module you have selected.



Press the OK button to write the new configuration to the GS-EDRV100.


## GS-EDRV100 Network Connections



### 10/100Mbps Connections

The GS-EDRV100 Ethernet port has an eight-pin modular jack that accepts RJ45 connector plugs. UTP (Unshielded Twisted-Pair) cable is rated according to its data-carrying ability (bandwidth) and is given a “category” number. We strongly recommend using a category 5 cable for all Ethernet 10/100Mbps connections. For convenient and reliable networking, we recommend that you purchase commercially manufactured cables (cables with connectors already attached).

To connect an GS-EDRV100 (or PC) to a hub, switch, or repeater, use a patch cable (sometimes called a straight-through cable). The cable used to connect a PC or an H2(4)-ERM directly to an GS-EDRV100 or to connect two hubs is referred to as a crossover cable.



This diagram illustrates the standard wire positions in the RJ45 connector. We recommend all Ethernet 10/100Mbps cables to be Category 5, UTP cable.




## GS-EDRV(100) to GS Series AC Drive Connection

A serial connection cable (2ft. in length) is provided with the GS-EDRV(100) to make an RS-485 connection with a GS Series AC Drive.



When using the **GS2 Series AC Drive**, DIP Switch 2 and 3 (SW2 and SW3) on the drive must be set to RS485.



Switches SW2 and SW3 on the drive must be set to RS485 for an RS-485 connection (GS2 Series Only).

### Setting the GS Series AC Drive Parameters

The following parameters need to be set in the GS Series AC Drive in order to operate properly with the GS-EDRV(100) interface card.

P3.00: 03 or 04 – Operation Determined by RS232C/RS485 interface. Keypad STOP is enabled (03) or disabled (04).

P4.00: 05 – Frequency determined by RS232/RS485 communication interface

P9.00: 01 – Must be set to 1 in order for the EDRV to communicate to the GS drive

**NOTE:**

*P9.01 will be automatically changed to a value of 2 (19200 baud) by the EDRV, and it cannot be changed to anything else.*

*P9.02 will be automatically changed to a value of 5 (Modbus RTU mode <8 data bits, odd parity, 1 stop bit>) by the EDRV, and it cannot be changed to anything else*



The previous list of parameter settings is the minimum required to communicate with a GS Series AC Drive through a GS-EDRV(100) interface card. There may be other parameters that need to be set to meet the needs of your application.

## GS-EDRV(100) to ERM Module Connection

The GS-EDRV(100) interface card can be added to any H2(4)-ERM module using the ERM Workbench Utility. For more details on selecting and configuring slaves for the ERM module, see CHAPTER 4 of the H24-ERM-M.

### Reserved PLC Memory for the GS-EDRV(100)

Once the GS-EDRV(100) is added the ERM module, 16 WORD inputs and 11 WORD outputs are mapped back to the PLC. The assigned PLC addresses are shown in the ERM Workbench Utility.

The screenshot shows the ERM Workbench Utility interface. At the top, it displays 'ERM Module [00 E0 62 20 0F 9E] - ERM Workbench'. The configuration area includes: Ethernet Remote Master: H2-ERM, Ethernet Address: 00 E0 62 20 0F 9E, IP: 192.168. 26.101, Module ID: 101. CPU Interface: PLC, CPU: 260, Last ERM Error: no error, PLC Mode: Program. A 'Slave Status' grid shows slave 1 selected. A table at the bottom lists I/O modules and their PLC addresses. Annotations with arrows point to the V2000-V2015 range (16 Input WORDS) and V2100-V2112 range (11 Output WORDS).

I/O Module	I/O Points	PLC Start	PLC End	V-Map	Notes
<reserved>	Slave Status Bits	X300	X317	V40414	
	ERM Status Word	X320	X337	V40415	
	Disable Slave Comm...	Y300	Y317	V40514	
Slave 1	GS-EDRV				Ethernet Address[00 E0 62 40 00 11] on IPX;
Slave 1/Slot 0	4 Word Input	V2000	V2003		16-bit Binary; ← 16 Input WORDS
Slave 1/Slot 1	10 Word Input	V2004	V2015		16-bit Binary;
Slave 1/Slot 2	2 Word Input	V2016	V2017		16-bit Binary;
Slave 1/Slot 3	4 Word Output	V2100	V2103		16-bit Binary; ← 11 Output WORDS
Slave 1/Slot 4	5 Word Output	V2104	V2110		16-bit Binary;
Slave 1/Slot 5	2 Word Output	V2111	V2112		16-bit Binary;

## Reading/Writing From/To the Drive



---

*The control function is NOT performed by the interface. The control function is performed by the control system. The I/O mapping function is performed by an H2(4)-ERM module (purchased separately). The H2(4)-ERM module is configured with the ERM Workbench Utility which is part of the DirectSOFT PLC programming software.*

---

### Input/Output Word Map

The Input and Output WORDS for the GS-EDRV(100) are mapped to specific parameters and functions in the GS Series AC Drives. The Word Map tables on the following pages show the Input and Output WORDS and their functions.

### Using the Input/Output Words

Output Words 10 and 11 are used in conjunction with Input Words 15 and 16 to Read/Write AC drive parameters that are not mapped to other Input and Output Words. By using Output Words 10 and 11 with Input Words 14 and 15, you have the ability to read/write most AC drive parameters.



---

*P9.29 is the only Communication Parameter (P9.xx range) that can be written to using the Read/Write Input/Output Words (IW 15 & 16; OW 10 & 11). However, these Input/Output Words can be used to read values from all of the drive Communication Parameters (P9.xx range).*

---

Input Word Map

Input WORD Map																								
Input Word	Parameter Reference	Function																						
1	N/A	Present Output Frequency																						
2	N/A	Present Output Current																						
3	Drive P9.29 & EDRV Comm Fault Bit	Bit 0 = Drive Serial Comm External Fault bit (P9.29) Bit 1 = EDRV internal EDRV-to-Drive Comm Fault bit  00 = 0: no EDRV-to-drive comm fault; no manual comm ext fault 01 = 1: no EDRV-to-drive comm fault; manual comm ext fault triggered 10 = 2: EDRV-to-drive comm fault; no manual comm ext fault 11 = 3: EDRV-to-drive comm fault; manual comm ext fault triggered																						
4	P6.31	P6.31 = Status Monitor 1 – Error Codes from AC Drive.  <table border="0"> <tr> <td>00: No fault occurred</td> <td>11: Hardware Protection Failure (HPF)</td> </tr> <tr> <td>01: Over-current(oc)</td> <td>12: Over-current during accel (OCA)</td> </tr> <tr> <td>02: Over-voltage(ov)</td> <td>13: Over-current during decel (Ocd)</td> </tr> <tr> <td>03: Overheat (oH)</td> <td>14: Over-current during steady state (Ocd)</td> </tr> <tr> <td>04: Overload (oL)</td> <td>15: Ground fault or fuse failure (GFF)</td> </tr> <tr> <td>05: Overload 1 (oL1)</td> <td>16: Low voltage (Lv)</td> </tr> <tr> <td>06: Overload 2 (oL2)</td> <td>17: Input power 3-phase loss</td> </tr> <tr> <td>07: External Fault (EF)</td> <td>18: External Base-Block (bb)</td> </tr> <tr> <td>08: CPU failure 1 (CF1)</td> <td>19: Auto adjust accel/decel failure (cFA)</td> </tr> <tr> <td>09: CPU failure 2 (CF2)</td> <td>20: Software protection code (codE)</td> </tr> <tr> <td>10: CPU failure 3 (CF3)</td> <td></td> </tr> </table>	00: No fault occurred	11: Hardware Protection Failure (HPF)	01: Over-current(oc)	12: Over-current during accel (OCA)	02: Over-voltage(ov)	13: Over-current during decel (Ocd)	03: Overheat (oH)	14: Over-current during steady state (Ocd)	04: Overload (oL)	15: Ground fault or fuse failure (GFF)	05: Overload 1 (oL1)	16: Low voltage (Lv)	06: Overload 2 (oL2)	17: Input power 3-phase loss	07: External Fault (EF)	18: External Base-Block (bb)	08: CPU failure 1 (CF1)	19: Auto adjust accel/decel failure (cFA)	09: CPU failure 2 (CF2)	20: Software protection code (codE)	10: CPU failure 3 (CF3)	
00: No fault occurred	11: Hardware Protection Failure (HPF)																							
01: Over-current(oc)	12: Over-current during accel (OCA)																							
02: Over-voltage(ov)	13: Over-current during decel (Ocd)																							
03: Overheat (oH)	14: Over-current during steady state (Ocd)																							
04: Overload (oL)	15: Ground fault or fuse failure (GFF)																							
05: Overload 1 (oL1)	16: Low voltage (Lv)																							
06: Overload 2 (oL2)	17: Input power 3-phase loss																							
07: External Fault (EF)	18: External Base-Block (bb)																							
08: CPU failure 1 (CF1)	19: Auto adjust accel/decel failure (cFA)																							
09: CPU failure 2 (CF2)	20: Software protection code (codE)																							
10: CPU failure 3 (CF3)																								
5	P9.16	Block Transfer Parameter 6 – User defined read value																						
6	P9.17	Block Transfer Parameter 7 – User defined read value																						
7	P9.18	Block Transfer Parameter 8 – User defined read value																						
8	P9.19	Block Transfer Parameter 9 – User defined read value																						
9	P9.20	Block Transfer Parameter 10 – User defined read value																						
10	P9.21	Block Transfer Parameter 11 – User defined read value																						
11	P9.22	Block Transfer Parameter 12 – User defined read value																						
12	P9.23	Block Transfer Parameter 13 – User defined read value																						
13	P9.24	Block Transfer Parameter 14 – User defined read value																						
14	P9.25	Block Transfer Parameter 15 – User defined read value																						

*Table continued next page.*

Input Word Map (continued)

Input WORD Map (continued)																		
Input Word	Parameter Reference	Function																
15	Read/Write Response	<p>Response to a read/write request (Output Word 10)</p> <p>Bit: 00-07 = Memory Reference                      08-11 = Memory type number (i.e. 0 to A for P0 to P10)                      12-13 = Operation (works in conjunction with bit 15):                      0=NOP, 9=Read accomplished, A=Write accomplished                      Bit 12 set indicates a read operation.                      Bit 13 set indicates a write operation.                      Bit 15 set indicates the read or write op was accomplished.                      Check bit 14 and Input Word 16 to see if an error occurred.</p> <p>14 = Error status:                      If set, an error has occurred. Error Code is stored in Word 16.</p> <p>15 = Read/Write Status:                      If set, the read or write operation was successful.</p>																
16	Read Request Value	<p>If Input Word 15 is a Read response, the value is stored here.                      If Input Word 15 is an Error response, the error code is stored here.</p> <p>Error Codes:</p> <table border="0"> <tr> <td>0x8010</td> <td>HEIE_INVALID_REQUEST</td> </tr> <tr> <td>0x8090</td> <td>HEIE_NOT_INITIALIZED</td> </tr> <tr> <td>0x8096</td> <td>HEIE_INVALID_OPERATION</td> </tr> <tr> <td>0x006F</td> <td>HEIE_INVALID_TYPE</td> </tr> <tr> <td>0x0091</td> <td>HEIE_INVALID_MODE</td> </tr> <tr> <td>0x008C</td> <td>HEIE_INVALID_ADDRESS</td> </tr> <tr> <td>0x0085</td> <td>HEIE_RANGE_ERROR</td> </tr> <tr> <td>0x006D</td> <td>HEIE_SIZE_ERROR</td> </tr> </table>	0x8010	HEIE_INVALID_REQUEST	0x8090	HEIE_NOT_INITIALIZED	0x8096	HEIE_INVALID_OPERATION	0x006F	HEIE_INVALID_TYPE	0x0091	HEIE_INVALID_MODE	0x008C	HEIE_INVALID_ADDRESS	0x0085	HEIE_RANGE_ERROR	0x006D	HEIE_SIZE_ERROR
0x8010	HEIE_INVALID_REQUEST																	
0x8090	HEIE_NOT_INITIALIZED																	
0x8096	HEIE_INVALID_OPERATION																	
0x006F	HEIE_INVALID_TYPE																	
0x0091	HEIE_INVALID_MODE																	
0x008C	HEIE_INVALID_ADDRESS																	
0x0085	HEIE_RANGE_ERROR																	
0x006D	HEIE_SIZE_ERROR																	

Output Word Map

Output WORD Map		
Output Word	Parameter Reference	Function
1	P9.27	RUN Command
2	P9.26	RS-485 Speed Reference
3	P9.28	Direction Command (0 = Forward; 1 = Reverse)
4	P9.30	Serial Comm Fault Reset (0 = no action; 1 = Reset Fault)
5	P9.11	Block Transfer Parameter 1 – user defined write value
6	P9.12	Block Transfer Parameter 2 – user defined write value
7	P9.13	Block Transfer Parameter 3 – user defined write value
8	P9.14	Block Transfer Parameter 4 – user defined write value
9	P9.15	Block Transfer Parameter 5 – user defined write value
10	Read/Write Request	<p>Bit: 00-07 = Memory Reference                      08-11 = Memory type number (i.e. 0 to A for P0 to P10)                      12-13 = Operation: 00=NOP, 01=Read, 10=Write, 11=Undefined                      14 = Undefined for request</p>
11	Write Request Value	If Output Word 10 is a Write request, the value to be written is placed here.

### Examples – I/O Word Mapping

1) Read P9.29 (Serial Comm External Fault):

Write value 0x191D into Output Word 10, and the parameter address 0x991D will come back into Input Word 15. The value read from P9.29 will be stored in Input Word 16.

OW 10: Read Request: Read from drive parameter 9.29																
	n/a		operation		parameter group #				parameter memory reference #							
Bit #	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Binary #	0	n/a	0	1	1	0	0	1	0	0	0	1	1	1	0	1
Hex #	0	n/a	1		9				1			D				
Decimal #	0	n/a	1		9				29							
Meaning	n/a	n/a	read		parameter 9.29											

IW 15: Read Response: Read from drive parameter 9.29																
	status	error	operation		parameter group #				parameter memory reference #							
Bit #	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Binary #	1	0	0	1	1	0	0	1	0	0	0	1	1	1	0	1
Hex #	9				9				1			D				
Decimal #	9				9				29							
Meaning	successful		read		parameter 9.29											

2) Write to P9.29 (Serial Comm External Fault):

Write value 0x291D into Output Word 10, and the parameter address 0xA91D will come back into Input Word 15. The value in Output Word 11 will be written to drive P9.29.

OW 10: Write Request: Write to drive parameter 9.29																
	n/a		operation		parameter group #				parameter memory reference #							
Bit #	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Binary #	0	n/a	1	0	1	0	0	1	0	0	0	1	1	1	0	1
Hex #	0	n/a	2		9				1			D				
Decimal #	0	n/a	2		9				29							
Meaning	n/a	n/a	write		parameter 9.29											

IW 15: Write Response: Write to drive parameter 9.29																
	status	error	operation		parameter group #				parameter memory reference #							
Bit #	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Binary #	1	0	1	0	1	0	0	1	0	0	0	1	1	1	0	1
Hex #	A				9				1			D				
Decimal #	10				9				29							
Meaning	successful		write		parameter 9.29											

**Examples – I/O Word Mapping (continued)**

3) Read P0.00 (Motor Nameplate Voltage):

Write value 0x1000 into Output Word 10, and the parameter address 0x9000 will come back into Input Word 15. The value read from P0.00 will be stored in Input Word 16.

OW 10: Read Request: Read from drive parameter 0.00																
	n/a		operation		parameter group #				parameter memory reference #							
Bit #	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Binary #	0	n/a	0	1	0	0	0	0	0	0	0	0	0	0	0	0
Hex #	0	n/a	1		0				0				0			
Decimal #	0	n/a	1		0				0							
Meaning	n/a	n/a	read		parameter 0.00											


IW 15: Read Response: Read from drive parameter 0.00																
	status	error	operation		parameter group #				parameter memory reference #							
Bit #	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Binary #	1	0	0	1	0	0	0	0	0	0	0	0	0	0	0	0
Hex #	9				0				0				0			
Decimal #	9				0				0							
Meaning	successful		read		parameter 0.00											

## Built-in Web Server

The GS-EDRV(100) interface card has a built-in Web Server that allows you to access AC drive data with your favorite Web browser. In order to access the internal Web Server, you must first assign an IP address to the GS-EDRV(100) card. The IP address can be assigned by using the NetEdit utility. You can then access the GS-EDRV(100) card by typing the IP address into your Web browser.

### Example

If the IP address of your GS-EDRV100 is 192.168.36.2, just enter **http://192.168.36.2** into the address field of your browser and press the **Enter** key.



The browser will then access the built-in Web Server as seen below. The available parameter groups are shown with links to the parameter options.

### EDrive-100 by [Automation Direct.com](http://AutomationDirect.com)

Module ID:	<a href="#">6 (0x6)</a>
Module Name:	<a href="#">New GS-EDRV100</a>
Module Description:	<a href="#">New GS-EDRV100 on Station1, Drive 6.</a>
Ethernet Address:	00 E0 62 40 48 00
IP Setup:	<a href="#">Address: 192.168.36.2 Subnet: 255.255.0.0 Gateway: 192.168.36.201(Supplied by DHCP)</a>
Booter Version:	5.0.76
OS Version:	5.0.198
Comm Link:	<a href="#">Searching for drive.</a>
P0:	<a href="#">Monitoring parms</a>
P1:	<a href="#">Ramps parms</a>
P2:	<a href="#">Velts/Hertz parms</a>
P3:	<a href="#">Digital parms</a>
P4:	<a href="#">Analog parms</a>
P5:	<a href="#">Presets parms</a>
P6:	<a href="#">Protection parms</a>
P7:	<a href="#">PID parms</a>
P8:	<a href="#">Display parms</a>
P9:	<a href="#">Comm parms</a>
P10:	<a href="#">Encoder Feedback parms</a>
Firmware Updates:	<a href="#">Hosttron.com</a>

## Troubleshooting – H24-ERM-M

### Refer to Ethernet Remote Master User Manual H24-ERM-M

Troubleshooting help for the ERM module and its slaves is available in CHAPTER 6 of the Ethernet Remote Master User Manual (H24-ERM-M).




## Application Example: Modbus TCP/IP


This application example shows how to use a GS-EDRV(100) to access a GS1, GS2 or a DURApulse drive's parameters for monitoring and control via the Modbus TCP/IP protocol.

Equipment and software used in example:


- Two DURApulse Drives
- Two GS-EDRV100 Ethernet interface modules
- A Stride Ethernet switch (SE-SW5U-ST)
- A standard network PC with a Modbus TCP/IP driver installed
- ModScan software (available for download from Win-Tech at <http://www.win-tech.com/html/demos.htm>). or any other Modbus TCP/IP interfacing software



To monitor drive parameters using ModScan, set up the connection parameters as follows:



Once a connection to the interface has been established, select the drive parameters that you wish to monitor. See the table below for drive parameters and their modbus addresses.




If you wish to write a value to the drive from this page, double click the address you wish to change and a Write Register window will appear. Enter the new value and select Update.

Modbus Addresses		
Read/Write	Hex	Modbus
Speed reference	091AH	42331
Run command	091BH	42332
Direction	091CH	42333
External fault	091DH	42334
Fault reset	091EH	42335
Jog	091FH	42336
Status	2101H	48450
Frequency command	2102H	48451
Output frequency	2103H	48452
Output current	2104H	48453
DC bus voltage	2105H	48454
Output voltage	1206H	48455
Motor RPM	2107H	48456
Scale frequency (low)	2108H	48457
Scale frequency (high)	2109H	48458
Percent load	210BH	48460
Firmware version	2110H	48465


ModScan gives you the ability to build custom interface forms (like the one below) that can be used to display and control GS/DURApulse drive parameters.

Custom Form			
GS3-43PO	Default	New	Comments
P0.00	480	460	Motor nameplate voltage setting
P0.01	5	4.8	Motor nameplate amps setting
P0.02	60	60	Motor base frequency
P0.03	1750	1725	Motor base RPM
P0.04	1750	1725	Motor maximum RPM
P1.00	0	1	Coast to stop
P1.01	10	20	Acceleration time
P2.00	0	2	Volts/hertz set to fans and pumps
P3.00	0	3	RS485 operation control enabled
P4.00	0	5	RS485 speed reference control
P8.00	0	3	RPM display
P9.00	1	X (1)	Communication address (dependent on drive 1-8)
P9.01	1	1	9600 baud rate
P9.02	0	5	Modbus RTU 8 data bits, odd parity, 1 stop bit


To build a new form, select **File>Custom Form>Create** and a blank form will open. With your mouse, select an area of the form and a Custom Display menu will appear as seen below.



Select an object (text, charts, shapes or data) from the menu and ModScan will load the selection into the form. When creating data objects, such as Register and Discrete variables, selecting the Write Enabled checkbox (as seen on following page) will allow the user to write values out to the drive from this form.



Once a read/write data object is created, double click on the object and a Write Modbus Variable popup will appear allowing the user to enter a new value for the selected parameter.



Enter the new value and select OK to write the new value to the drive.

BLANK  
PAGE

**BLANK  
PAGE**

