

DENSO ROBOT

Vertical articulated

VS-G SERIES

GENERAL INFORMATION ABOUT ROBOT

Copyright © DENSO WAVE INCORPORATED, 2005-2010

All rights reserved. No part of this publication may be reproduced in any form or by any means without permission in writing from the publisher.

Specifications are subject to change without prior notice.

All products and company names mentioned are trademarks or registered trademarks of their respective holders.

Preface

Thank you for purchasing this high-speed, high-accuracy assembly robot.

Before operating your robot, read this manual carefully to safely get the maximum benefit from your robot in your assembling operations.

Robot series and/or models covered by this manual

Series	Model	
	Floor-mount	Overhead-mount
Small-sized, vertical articulated VS-G (Models configured with RC7M controller)	VS-6556G VS-6577G	Same as left.

NOTE 1: Model names listed above apply to the models of robot systems. The model names of robot units are followed by M. If the robot system model is VS-6556G, for example, the robot unit model is VS-6556GM.

Important

To ensure operator safety, be sure to read the precautions and instructions in "SAFETY PRECAUTIONS".

How the documentation set is organized

The documentation set consists of the following books. If you are unfamiliar with this robot and option(s), please read all books and understand them fully before operating your robot and option(s).

GENERAL INFORMATION ABOUT ROBOT - this book -

Provides the packing list of the robot and outlines of the robot system, robot unit, and robot controller.

INSTALLATION & MAINTENANCE GUIDE

Provides instructions for installing the robot components and customizing your robot, and maintenance & inspection procedures.

STARTUP HANDBOOK

Introduces you to the DENSO robot system and guides you through connecting the robot unit and controller with each other, running the robot with the teach pendant, and making and verifying a program. This manual is a comprehensive guide to starting up your robot system.

SETTING-UP MANUAL

Describes how to set up or teach your robot with the teach pendant or mini-pendant.

For the panel designer functions, refer to the Panel Designer User's Manual (SUPPLEMENT).

WINCAPSIII GUIDE

Provides instructions on how to use the programming support tool WINCAPSIII which runs on the PC connected to the robot controller for developing and managing programs.

PROGRAMMER'S MANUAL I, Program Design and Commands

Describes the PAC programming language, program development, and command specifications in PAC. This manual consists of two parts; Part 1 provides the basic programming knowledge, and Part 2, details of individual commands.

PROGRAMMER'S MANUAL II, PAC Library

Describes the program libraries that come with WINCAPSIII as standard.

RC7M CONTROLLER MANUAL

Provides the specifications, installation and maintenance of the RC7M controller. It also describes interfacing with external devices, system- and user-input/output signals, and I/O circuits.

ERROR CODE TABLES

List error codes that will appear on the teach pendant or mini-pendant if an error occurs in the robot system. These tables also provide detailed description and recovery ways.

OPTIONS MANUAL

Describes the specifications, installation, and use of optional devices.

For the extension board "conveyer tracking board," refer to the OPTIONS MANUAL (SUPPLEMENT).

How this book is organized

This book is just one part of the robot documentation set. This book consists of SAFETY PRECAUTIONS, chapters one through five, and appendix.

SAFETY PRECAUTIONS

Defines safety terms and related symbols and provides precautions that should be observed. Be sure to read this section before operating your robot.

Chapter 1 Packing List of the Robot

Lists the standard components contained in the product package and optional components.

Chapter 2 Configuration of the Robot System

Illustrates the configuration of the robot system and describes the component names of the robot unit and controller.

Chapter 3 Specifications of the Robot Unit

Describes the specifications, motion space, robot positioning time, air piping and signal wiring, and engineering-design notes for robot hands.

Chapter 4 Specifications of the Robot Controller

Lists the specifications of the robot controller and controller setting table (SETPRM LIST).

Chapter 5 Warranty

Describes the warranty period and coverage.

Appendix How to Use the Manual Pack CD

SAFETY PRECAUTIONS

Be sure to observe all of the following safety precautions.

Strict observance of these warning and caution indications are a **MUST** for preventing accidents, which could result in bodily injury and substantial property damage. Make sure you fully understand all definitions of these terms and related symbols given below, before you proceed to the text itself.

 WARNING	Alerts you to those conditions, which could result in serious bodily injury or death if the instructions are not followed correctly.
 CAUTION	Alerts you to those conditions, which could result in minor bodily injury or substantial property damage if the instructions are not followed correctly.

Terminology and Definitions

Maximum space: Refers to the space which can be swept by the moving parts of the robot as defined by the manufacturer, plus the space which can be swept by the end-effector and the workpiece. (Quoted from the ISO 10218-1:2006.)

Restricted space: Refers to the portion of the maximum space restricted by limiting devices (i.e., mechanical stops) that establish limits which will not be exceeded. (Quoted from the ISO 10218-1:2006.)

Motion space: Refers to the portion of the restricted space to which a robot is restricted by software motion limits. The maximum distance that the robot, end-effector, and workpiece can travel after the software motion limits are set defines the boundaries of the motion space of the robot. (The "motion space" is DENSO WAVE-proprietary terminology.)

Operating space: Refers to the portion of the restricted space that is actually used while performing all motions commanded by the task program. (Quoted from the ISO 10218-1:2006.)

Task program: Refers to a set of instructions for motion and auxiliary functions that define the specific intended task of the robot system. (Quoted from the ISO 10218-1:2006.)


1. Introduction

This section provides safety precautions to be observed for the robot system.


The installation shall be made by qualified personal and should confirm to all national and local codes.

2. Warning Labels

The robot unit and controller have warning labels. These labels alert the user to the danger of the areas on which they are pasted. Be sure to observe the instructions printed on those labels.



(Example: Location of labels)

Warning label	Instructions printed on the label
 Label (1)	Risk of injury. Never enter the restricted space.
<Except HM>  Label (2)	<u>For UL-Listed robot units only</u> Risk of injury. This label alerts the user that pressing the brake release switch could drop the arm.
 Label (3)	Risk of electrical shock. Never open the controller cover when the power is on. Never touch the inside of the controller for at least 3 minutes even after turning the power off and disconnecting the power cable.
 Label (4)	Risk of injury. Be sure to perform lockout/tagout before starting servicing. Turning the power ON when a person is inside the safety fence may move the arm, causing injuries.

3. Installation Precautions

3.1 Insuring the proper installation environment

■ For standard type and cleanroom type

The standard and cleanroom types have not been designed to withstand explosions, dust-proof, nor is it splash-proof. Therefore, it should not be installed in any environment where:

- (1) there are flammable gases or liquids,
- (2) there are any shavings from metal processing or other conductive material flying about,
- (3) there are any acidic, alkaline or other corrosive material,
- (4) there is a mist,
- (5) there are any large-sized inverters, high output/high frequency transmitters, large contactors, welders, or other sources of electrical noise.

■ For dust- & splash-proof type

The dust- & splash-proof type has an IP54-equivalent structure, but it has not been designed to withstand explosions. (The HM/HS-G-W and the wrist of the VM/VS-G-W are an IP65-equivalent dust- and splash-proof structure.)

Note that the robot controller is not a dust- or splash-proof structure. Therefore, when using the robot controller in an environment exposed to mist, put it in an optional protective box.

The dust- & splash-proof type should not be installed in any environment where:

- (1) there are any flammable gases or liquids,
- (2) there are any acidic, alkaline or other corrosive material,
- (3) there are any large-sized inverters, high output/high frequency transmitters, large contactors, welders, or other sources of electrical noise,
- (4) it may likely be submerged in fluid,
- (5) there are any grinding or machining chips or shavings,
- (6) any machining oil not specified in this manual is in use, or
Note: Yushiron Oil No. 4C (non-soluble) is specified.
- (7) there is sulfuric cutting or grinding oil mist.

3.2 Service space

The robot and peripheral equipment should be installed so that sufficient service space is maintained for safe teaching, maintenance, and inspection.

**3.3 Control devices
outside the robot's
restricted space**

The robot controller, teach pendant and mini-pendant should be installed outside the robot's restricted space and in a place where you can observe all of the robot's movements and operate the robot easily.

3.4 Positioning of gauges

Pressure gauges, oil pressure gauges and other gauges should be installed in an easy-to-check location.

**3.5 Protection of electrical
wiring and
hydraulic/pneumatic
piping**

If there is any possibility of the electrical wiring or hydraulic/pneumatic piping being damaged, protect them with a cover or similar item.

3.6 Grounding resistance

The protective grounding resistance of the robot power supply should not be more than 100Ω.

**3.7 Positioning of
emergency stop
switches**

Emergency stop switches should be provided in a position where they can be reached easily should it be necessary to stop the robot immediately.


- (1) The emergency stop switches should be red.
- (2) Emergency stop switches should be designed so that they will not be released after pressed, automatically or mistakenly by any other person.
- (3) Emergency stop switches should be separate from the power switch.

**3.8 Positioning of
operating status
indicators**

Operating status indicators should be positioned in such a way where workers can easily see whether the robot is on a temporary halt or on an emergency or abnormal stop.

Note: The UL-Listed robot units have motor ON lamps on their robot arms.

3.9 Setting-up a safety fence



A safety fence should be set up so that no one can easily enter the robot's restricted space.

- (1) The fence should be constructed so that it cannot be easily moved or removed.
- (2) The fence should be constructed so that it cannot be easily damaged or deformed through external force.
- (3) Establish the exit/entrance to the fence. Construct the fence so that no one can easily get past it by climbing over the fence.
- (4) The fence should be constructed to ensure that it is not possible for hands or any other parts of the body to get through it.
- (5) Take any one of the following protections for the entrance/exit of the fence:
 - 1) Place a door, rope or chain across the entrance/exit of the fence, and fit it with an interlock that ensures the emergency stop device operates automatically if it is opened or removed.
 - 2) Post a warning notice at the entrance/exit of the fence stating "In operation--Entry forbidden" or "Work in progress--Do not operate" and ensure that workers follow these instructions at all times.

When making a test run, before setting up the fence, place an overseer in a position outside the robot's restricted space and one in which he/she can see all of the robot's movements. The overseer should prevent workers from entering the robot's restricted space and be devoted solely to that task.

3.10 Setting the robot's motion space

The area required for the robot to work is called the robot's operating space.

If the robot's motion space is greater than the operating space, it is recommended that you set a smaller motion space to prevent the robot from interfering or disrupting other equipment.

Refer to the INSTALLATION & MAINTENANCE GUIDE, Chapter 2.

3.11 No robot modification allowed

Never modify the robot unit, robot controller, teach pendant or other devices.

3.12 Cleaning of tools

If your robot uses welding guns, paint spray nozzles, or other end-effectors requiring cleaning, it is recommended that the cleaning process be carried out automatically.

3.13 Lighting

Sufficient illumination should be assured for safe robot operation.

3.14 Protection from objects thrown by the end-effector

If there is any risk of workers being injured in the event that the object being held by the end-effector is dropped or thrown by the end-effector, consider the size, weight, temperature and chemical nature of the object and take appropriate safeguards to ensure safety.

3.15 Affixing the warning label

Place the warning label packaged with the robot on the exit/entrance of the safety fence or in a position where it is easy to see.



3.16 Posting the moving directions of all axes

Post a notice showing axes names and moving directions in a visible location on the robot unit. The posted moving directions should match the actual directions.

No posting or wrong direction posting may result in bodily injuries or property damages due to incorrect operation.

4. Precautions while Robot is Running



Warning

Touching the robot while it is in operation can lead to serious injury. Please ensure the following conditions are maintained and that the cautions listed from Section 4.1 and onwards are followed when any work is being performed.



- 1) Do not enter the robot's restricted space when the robot is in operation or when the motor power is on.
- 2) As a precaution against malfunction, ensure that an emergency stop device is activated to cut the power to the robot motor upon entry into the robot's restricted space.
- 3) When it is necessary to enter the robot's restricted space to perform teaching or maintenance work while the robot is running, ensure that the steps described in Section 4.3 "Ensuring safety of workers performing jobs within the robot's restricted space" are taken.

4.1 Creation of working regulations and assuring worker adherence

When entering the robot's restricted space to perform teaching or maintenance inspections, set "working regulations" for the following items and ensure workers adhere to them.

- (1) Operating procedures required to run the robot.
- (2) Robot speed when performing teaching.
- (3) Signaling methods to be used when more than one worker is to perform work.
- (4) Steps that must be taken by the worker in the event of a malfunction, according to the contents of the malfunction.
- (5) The necessary steps for checking release and safety of the malfunction status, in order to restart the robot after robot movement has been stopped due to activation of the emergency stop device
- (6) Apart from the above, any steps below necessary to prevent danger from unexpected robot movement or malfunction of the robot.
 - 1) Display of the control panel (See Section 4.2 on the next page.)
 - 2) Assuring the safety of workers performing jobs within the robot's restricted space (See Section 4.3 on the next page.)
 - 3) Maintaining worker position and stance
Position and stance that enables the worker to confirm normal robot operation and to take immediate refuge if a malfunction occurs.

-
- 4) Implementation of measures for noise prevention
 - 5) Signaling methods for workers of related equipment
 - 6) Types of malfunctions and how to distinguish them

Please ensure "working regulations" are appropriate to the robot type, the place of installation and to the content of the work.

Be sure to consult the opinions of related workers, engineers at the equipment manufacturer and that of a labor safety consultant when creating these "working regulations".

4.2 Display of operation panel

To prevent anyone other than the worker from accessing the start switch or the changeover switch by accident during operation, display something to indicate it is in operation on the operation panel or teach pendant. Take any other steps as appropriate, such as locking the cover.

4.3 Ensuring safety of workers performing jobs within the robot's restricted space

When performing jobs within the robot's restricted space, take any of the following steps to ensure that robot operation can be stopped immediately upon a malfunction.

- (1) Ensure an overseer is placed in a position outside the robot's restricted space and one in which he/she can see all robot movements, and that he/she is devoted solely to that task.
 - ① An emergency stop device should be activated immediately upon a malfunction.
 - ② Do not permit anyone other than the worker engaged for that job to enter the robot's restricted space.
- (2) Ensure a worker within the robot's restricted space carries the portable emergency stop switch so he/she can press it (the emergency button on the teach pendant) immediately if it should be necessary to do so.

4.4 Inspections before commencing work such as teaching

Before starting work such as teaching, inspect the following items, carry out any repairs immediately upon detection of a malfunction and perform any other necessary measures.

- (1) Check for any damage to the sheath or cover of the external wiring or to the external devices.
- (2) Check that the robot is functioning normally or not (any unusual noise or vibration during operation).
- (3) Check the functioning of the emergency stop device.
- (4) Check there is no leakage of air or oil from any pipes.
- (5) Check there are no obstructive objects in or near the robot's restricted space.

4.5 Release of residual air pressure

Before disassembling or replacing pneumatic parts, first release any residual air pressure in the drive cylinder.

4.6 Precautions for test runs

Whenever possible, have the worker stay outside of the robot's restricted space when performing test runs.

4.7 Precautions for automatic operation

(1) At start-up

Stay out of the safeguarded space with a safety fence when starting the robot; in particular, take extra caution in Internal automatic operation.

Before starting the robot, check the following items as well as setting the signals to be used and perform signaling practice with all related workers.

- 1) Check that there is no one inside the safeguarded space (with a safety fence).
- 2) Check that the teach pendant and tools are in their designated places.
- 3) Check that no lamps indicating a malfunction on the robot or related equipment are lit.

(2) Check that the display lamp indicating automatic operation is lit during automatic operation.

(3) Steps to be taken when a malfunction occurs

Stop the robot's operation by activating the emergency stop device when it is necessary to enter the safeguarded space with a safety fence to perform emergency maintenance in the case of malfunction of the robots or related equipment.

Take any necessary steps such as posting a notice on the start switch to indicate work is in progress to prevent anyone from accessing the robot.

4.8 Precautions in repairs

- (1) Do not perform repairs outside of the designated range.
- (2) Under no circumstances should the interlock mechanism be removed.
- (3) When opening the robot controller's cover for battery replacement or any other reasons, always turn the robot controller power off and disconnect the power cable.
- (4) Use only spare tools specified in this manual.

5. Daily and Periodical Inspections

- (1) Be sure to perform daily and periodical inspections. Before starting jobs, always check that there is no problem with the robot and related equipment. If any problems are found, take any necessary measures to correct them.
- (2) When carrying out periodical inspections or any repairs, maintain records and keep them for at least 3 years.

6. Management of Floppy Disks

- (1) Carefully handle and store the "Initial settings" floppy disks packaged with the robot, which store special data exclusively prepared for your robot.
- (2) After finishing teaching or making any changes, always save the programs and data onto floppy disks.
Making back-ups will help you recover if data stored in the robot controller is lost due to the expired life of the back-up battery.
- (3) Write the names of each of the floppy disks used for storing task programs to prevent incorrect disks from loading into the robot controller.
- (4) Store the floppy disks where they will not be exposed to dust, humidity and magnetic field, which could corrupt the disks or data stored on them.

7. Safety Codes

The safety standards relating to robot systems are listed below.

As well as observing the safety precautions given in this manual, ensure compliance with all local and national safety and electrical codes for the installation and operation of the robot system.

Standards	Title
ANSI/RIA R15.06-1999	Industrial Robots and Robot Systems--Safety Requirements
ANSI/UL1740: 1998	Safety for Robots and Robotic Equipment
CAN/CSA Z434-03	Industrial Robots and Robot Systems--General Safety Requirements
ISO10218-1: 2006	Robots for industrial environments--Safety requirements--Part 1: Robot
NFPA 79: 2002	Electrical Standard for Industrial Machinery

8. Battery Recycling

DENSO Robot uses lithium batteries.

Discard batteries according to your local and national recycling law.



Contents

Preface	i
How the documentation set is organized	ii
How this book is organized	iii
SAFETY PRECAUTIONS	
Chapter 1 Packing List of the Robot.....	1
1.1 Standard Components	1
1.2 Optional Components.....	2
Chapter 2 Configuration of the Robot System	4
2.1 Configurators	4
2.2 Names of Robot Unit Components	5
2.2.1 Robot Unit Components and Rotation Direction	5
2.2.2 Name Plate	6
2.2.3 Warning and Caution Labels	7
2.3 Names of the Robot Controller Components	8
Chapter 3 Specifications of the Robot Unit	9
3.1 Robot Specifications	9
3.2 Outer Dimensions and Workable Space of the Robot Unit	15
3.2.1 Models Except UL-Listed Ones.....	15
3.2.2 UL-Listed Models.....	27
3.3 Robot Positioning Time.....	29
3.4 Air Piping, Signal Wiring, and Solenoid Valve Specifications.....	36
3.4.1 Air Piping and Signal Wiring.....	36
3.4.2 Instructions for Using Splash-proof Connector Sets.....	41
3.4.3 Solenoid Valve Specifications (VS-G series).....	42
3.4.4 Existing Internal Threads for Wiring and Piping	42
3.5 Precautions When Designing the End-effectors	43
3.6 Stopping Time and Distance (Angle) at an Emergency Stop	46
Chapter 4 Specifications of the Robot Controller.....	48
4.1 Specifications	48
4.2 Outer Dimensions.....	50
4.3 Controller Setting Table	51
Chapter 5 Warranty	52

Chapter 1 Packing List of the Robot

1.1 Standard Components

The components listed below are contained in the product package.

Standard Components

No.	Item	Q'ty
(1)	Robot unit	1
(2)	Robot controller	1
(3)	Power cable (5 m)	1
(4)	Motor & encoder cable (Note 1)	1
(5)	Manuals ("Manual Pack CD" and "Safety Precautions")	1 set
(6)	NetwoRC CD (containing WINCAPSIII beta version)	1
(7)	Spare fuses for robot controller	3
(8)	Initialization floppy disk (1.44 MB format) (Note 2)	1
(9)	Pendantless connector (Dummy connector) (not contained in UL-Listed robot systems)	1
(10)	Connector set for hand control signals (for CN20 and CN21)	1 set
(11)	Direction indicator label (Note 3)	1
(12)	Warning label (Note 4)	1
(13)	Spare output IC for robot controller	1
(14)	Dowel pins (internally threaded positioning pin and diamond-shaped pin)	1 set
(15)	Short sockets for robot controller	2

Note 1: Choose a motor & encoder cable from the table below. The 20-m motor & encoder cable (standard/splash-proof) is not available for controllers equipped with extended-joint options or UL-Listed robot units. The internal cable bending radius shall at least be 200 mm. Excessively bending will result in broken lead wires.

Item	Part No.
Standard cable 2 m	410141-4400
Standard cable 4 m	410141-3611
Standard cable 6 m	410141-3621
Standard cable 12 m	410141-3631
Standard cable 20 m	410141-4440
Splash-proof cable 2 m	410141-4420
Splash-proof cable 4 m	410141-3681
Splash-proof cable 6 m	410141-3691
Splash-proof cable 12 m	410141-3701
Splash-proof cable 20 m	410141-4460

Note 2: Preserve the initialization floppy disk in a safe place. The disk contains CALSET-related arm data exclusively prepared for your robot. If a memory error appears on the teach pendant due to a memory failure, use the disk to load the arm data to the robot controller. (Refer to the INSTALLATION & MAINTENANCE GUIDE, "Using the Initialization Floppy Disk.")

Note 3: After installation, attach the direction indicator label in a position on the robot unit that can be easily seen.

Note 4: Attach the warning label on the robot safety fence or other location where workers will easily notice it. If necessary, prepare a plate for attaching the seal.

When placing an order for UL-Listed robot systems, be sure to order the optional teach pendant or mini-pendant also which is essential to UL-Listed ones.

1.2 Optional Components

The table below lists the optional components.

Optional Components (1)

Classification	No.	Item		Remarks		Part No.
I/O cables	1	Standard I/O cable set		(8 m) Incl. Nos. 1-1 and 1-2.		410149-0940
				(15 m) Incl. Nos. 1-1 and 1-2.		410149-0950
	1-1	I/O cable for “Mini I/O” (68pins)		(8 m)		410141-2700
				(15 m)		410141-2710
	1-2	I/O cable for “HAND I/O”		(8 m)		410141-1740
				(15 m)		410141-1750
	2	I/O cable for “Parallel I/O board” (96 pins)		(8 m)		410141-3050
				(15 m)		410141-3060
	3	I/O cable for “SAFETY I/O” (36 pins) (Only for global type)		(8 m)		410141-3580
				(15 m)		410141-3590
Operation devices	4	Teach pendant		(4 m) With cable		410100-1570
				(8 m) With cable		410100-1580
				(12 m) With cable		410100-1590
	5	Mini-pendant kit (Incl. cable and WINCAPSIII Light)		(4 m)	Japanese indication	410109-0390
					English indication	410109-0400
				(8 m)	Japanese indication	410109-0410
					English indication	410109-0420
		(12 m)	Japanese indication	410109-0430		
	English indication			410109-0440		
	6	Pendant extension cable		(4 m)	For TP, MP	410141-3710
(8 m)				For TP, MP	410141-3720	
Programming support tool	7	WINCAPSIII		CD-ROM (common to the languages--Japanese, English, German, Korean, and Chinese)		410090-0980
Optional boards for the robot controller	8	Parallel I/O board	Shipped as installed on the controller	NPN		410010-3320
				PNP		410010-3330
			Shipped as individual boards (supply part)	NPN		410010-3340
				PNP		410010-3350
	9	DeviceNet board	Shipped as installed on the controller	For Slave station		410010-3370
				For Master station		410010-3380
				For Master & slave station		410010-3390
			Shipped as individual boards (supply part)	For Slave station		410010-3400
		For Master station		410010-3410		
		For Master & slave station		410010-3480		
	10	CC-Link board		Shipped as installed on the controller		410010-3430
				Shipped as individual boards (supply part)		410010-3440
	11	Conveyor tracking board		Shipped as installed on the controller		410010-3460
				Shipped as individual boards (supply part)		410010-3470


Optional Components (2)

Classification	No.	Item	Remarks	Part No.
Optional functions (For own optional board etc.)	12	Optional function for RS232C board Board manufacturer: CONTEC CO., LTD. Model: COM-2P(PCI)H	Shipped after integrated in the controller	410006-0260
			Added when the board is purchased as a spare part	410006-0270
	13	Optional function for S-LINK V board Board manufacturer: SUNX CO., LTD Model: SL-VPCI	Shipped after integrated in the controller	410006-0280
			Added when the board is purchased as a spare part	410006-0290
	14	Optional function for PROFIBUS-DP slave board Board manufacturer: Hilscher GmbH Model: CIF50-DPS\DENSO	Shipped after integrated in the controller	410006-0300
			Added when the board is purchased as a spare part	410006-0310
	15	EtherNet/IP function Board manufacturer: Hilscher GmbH Model: CIFX 50-RE\DENSO	Shipped after integrated in the controller	410006-0800
			Added when the board is purchased as a spare part	410006-0810
	16	Optional function for memory extension	Extension only upon controller shipment (3.25MB to 5.5 MB)	410006-0320
Optional box	17	Controller protection box		410181-0090
	18	I/O conversion box	For interchangeability with RC5 type controller	410181-0100
CD Manuals	19	Manual Pack CD	Contained in the robot package.	410002-2661
Optional manuals (Printed materials, English edition)	20	Instruction manual for VS-G, full set	Includes No. C and No. D	410009-0300
	C	Instruction manual for VS-G, basic set	Includes No. C-1 to No. C-3	410009-0200
	C-1	GENERAL INFORMATION ABOUT ROBOT	For VS-G	410002-2490
	C-2	RC7M CONTROLLER MANUAL	For RC7M controller	410002-2430
	C-3	ERROR CODE TABLES		410002-3370
	D	Instruction manual for VS-G, extension set	Includes No. D-1 to No. D-7	410009-0080
	D-1	INSTALLATION & MAINTENANCE GUIDE	For VS-G	410002-2510
	D-2	STARTUP HANDBOOK		410002-2750
	D-3	SETTING-UP MANUAL		410002-3310
	D-4	PROGRAMMER'S MANUAL (I)		410002-3330
	D-5	PROGRAMMER'S MANUAL (II)		410002-3350
	D-6	Panel Designer USER'S MANUAL		410002-6480
	D-7	OPTIONS MANUAL	For RC7M controller	410002-2650

Chapter 2 Configuration of the Robot System

2.1 Configurators

The figure below shows configurators of the typical robot system.




Configurators of the Robot System (VS-G series)

2.2 Names of Robot Unit Components


2.2.1 Robot Unit Components and Rotation Direction

The figure below shows the names of the components of the robot unit and the rotation direction of each axis.

Note: The UL-Listed robot unit has the motor ON lamps on the 2nd arm, and the brake release switch and axis selector on the base.




UL-Listed robot unit



Robot Unit Components and Rotation Direction (VS-G series)

2.2.2 Name Plate

The robot unit has a name plate pasted on the base. The serial number printed on the name plate, which is the same as that printed on the controller's name label, identifies an individual robot.




2.2.3 Warning and Caution Labels

The robot unit has warning and caution labels pasted as shown below. They alert the user to the dangers of the areas on which they are pasted. Be sure to observe the instructions printed on those labels.

Warning and Caution Labels on the Robot Unit

Location of labels




Warning and caution labels on the robot unit	Additional description
Label 1	Contact with the robot unit which is in motion can cause serious injuries. Observe the following: (1) Never enter the robot's restricted space when the robot is in motion or the motor power is on. (2) When you need to enter the robot's restricted space for recovery from robot failures, be sure to cut the power to the robot motors by activating an emergency stop device or the like.
Label 2 (on UL-Listed robot units only)	When the controller power is on, pressing the brake release switch causes the arm to fall. It is DANGEROUS. Observe the following: (1) Never press the brake release switch except in an emergency. (2) Before pressing the brake release switch, be sure to check that there is no danger of injuries or damages on equipment.
Label 3	There is a high voltage part. This label alerts the user to the dangers of electrical shocks.
Label 4	Instructions on how to hoist the robot unit.
Label 5	Cautions when performing CALSET. For details, refer to the INSTALLATION & MAINTENANCE GUIDE.

2.3 Names of the Robot Controller Components


The figure below shows the names of the robot controller components.

Note: For warning and caution labels pasted on the controller, refer to the RC7M CONTROLLER MANUAL.




SAFETY BOX
(Only for global type with safety box)


SAFETY BOARD
(Only for global type with safety board)



Rear panel (Air exhaust side)



Front panel



Air intake filters

Connectors for the VS-G series (Encoders connected via bus)

Connector No.	Marking	Name
CN1	RS-232C	Serial interface connector
CN2	USB	USB connector (2 lines)
CN3	PENDANT	Teach pendant connector
CN4	LAN	Ethernet connector
CN5	Mini I/O	I/O connector
CN6	INPUT AC	Power supply connector
CN7	MOTOR	Motor/encoder connector
CN9	HAND I/O	HAND I/O connector
CN10	SAFETY I/O	SAFETY I/O connector (Only for global type)

Names of Robot Controller Components

Chapter 3 Specifications of the Robot Unit

3.1 Robot Specifications

The following tables list the specifications of the VS-G series. For UL-Listed robot units, see (3) "VS-65**G-BW-UL."

(1) VS-6556G (configured with RC7M controller)

VS-6556G Specifications

Item		Specifications				
		Standard type	Dust- & splash-proof type	With brakes	Dust- & splash-proof type with brakes	UL-Listed type (Dust- & splash-proof type with brakes)
Model name of robot system (Note 1)		VS-6556G	VS-6556G-W	VS-6556G-B	VS-6556G-BW	VS-6556G-BW-UL
Model name of robot unit		VS-6556GM	VS-6556GM-W	VS-6556GM-B	VS-6556GM-BW	VS-6556GM-BW-UL
Overall arm length		270 (first arm) + 295 (second arm) = 565 mm				
Arm offset		J1 (swing): 75 mm, J3 (front arm): 90 mm				
Maximum motion area		R = 733 mm (end-effector mounting face) R = 653 mm (Point P: J4, J5, J6 center)				
Motion range		J1 : ±170°, J2 : +135°, -100°, J3 : +166°, -119° J4 : ±190°, J5 : ±120°, J6 : ±360°				
Maximum payload		7 kg (Note 2)				
Maximum composite speed		8200 mm/s (at the center of an end-effector mounting face)				
Position repeatability (Note 3)		In each of X, Y and Z directions: ±0.02 mm (at the center of an end-effector mounting face)				
Maximum allowable inertia moment		0.413 kgm ² for around J4 and J5, 0.063 kgm ² for around J6				
Position detection		Absolute encoder				
Drive motor and brake		AC servomotors for all joints, Brakes for joints J2 to J4		AC servomotors for all joints, Brakes for joints J2 to J6		AC servomotors for all joints, Brakes for all joints
Brake releasing		Enter a brake release command with the teach pendant or mini-pendant.				Use the brake release switch. (Note 5)
User air piping (Note 4)		7 systems (φ4x6, φ6x1), 3 solenoid valves (2-position, double solenoid) contained.				
User signal line		10 (for proximity sensor signals, etc.)				
Air source	Operating pressure	0.10~0.39MPa				
	Maximum allowable pressure	0.49MPa				
Degree of protection		IP40	IP54 (Wrist: IP65)	IP40	IP54 (Wrist: IP65)	IP54 (Wrist: IP65)
Airborne noise (A-weighted equivalent continuous sound pressure level)		80 dB or less				
Weight		Approx. 35 kg (77 lbs) (See the name plate on each model.)				

Note 1: The model name of robot set refers to the model name of a complete set including a robot unit and robot controller.

Note 2: If the payload exceeds 6 kg, the robot unit must be used with the flange facing down at ± 45 degrees from vertical.

Note 3: Position repeatability is the value at constant ambient temperature.

Note 4: Only the $\phi 4 \times 6$ air piping system may be controlled by built-in solenoid valves.

Note 5: When the controller power is ON, use the brake release switch to release the brake of the selected joint. Brake releasing with the teach pendant or mini-pendant is not possible.

(2) VS-6577G (configured with RC7M controller)

VS-6577G Specifications

Item		Specifications				
		Standard type	Dust- & splash-proof type	With brakes	Dust- & splash-proof type with brakes	UL-Listed type (Dust- & splash-proof type with brakes)
Model name of robot system (Note 1)		VS-6577G	VS-6577G-W	VS-6577G-B	VS-6577G-BW	VS-6577G-BW-UL
Model name of robot unit		VS-6577GM	VS-6577GM-W	VS-6577GM-B	VS-6577GM-BW	VS-6556GM-BW-UL
Overall arm length		365 (first arm) + 405 (second arm) = 770 mm				
Arm offset		J1 (swing): 75 mm, J3 (front arm): 90 mm				
Maximum motion area		R = 934 mm (end-effector mounting face) R = 854 mm (Point P: J4, J5, J6 center)				
Motion range		J1 : ±170°, J2 : +135°, -100°, J3 : +169°, -119° J4 : ±190°, J5 : ±120°, J6 : ±360°				
Maximum payload		7 kg (Note 2)				
Maximum composite speed		7600 mm/s (at the center of an end-effector mounting face)				
Position repeatability (Note 3)		In each of X, Y and Z directions: ±0.03 mm (at the center of an end-effector mounting face)				
Maximum allowable inertia moment		0.413 kgm ² for around J4 and J5, 0.063 kgm ² for around J6				
Position detection		Absolute encoder				
Drive motor and brake		AC servomotors for all joints, Brakes for joints J2 to J4		AC servomotors for all joints, Brakes for joints J2 to J6		AC servomotors for all joints, Brakes for all joints
Brake releasing		Enter a brake release command with the teach pendant or mini-pendant.				Use the brake release switch.(Note 5)
User air piping (Note 4)		7 systems (φ4x6, φ6x1), 3 solenoid valves (2-position, double solenoid) contained.				
User signal line		10 (for proximity sensor signals, etc.)				
Air source	Operating pressure	0.10~0.39MPa				
	Maximum allowable pressure	0.49MPa				
Degree of protection		IP40	IP54 (Wrist: IP65)	IP40	IP54 (Wrist: IP65)	IP54 (Wrist: IP65)
Airborne noise (A-weighted equivalent continuous sound pressure level)		80 dB or less				
Weight		Approx. 36 kg (80 lbs) (See the name plate on each model.)				

Note 1: The model name of robot set refers to the model name of a complete set including a robot unit and robot controller.

Note 2: If the payload exceeds 6 kg, the robot unit must be used with the flange facing down at ± 45 degrees from vertical.

Note 3: Position repeatability is the value at constant ambient temperature.

Note 4: Only the $\phi 4 \times 6$ air piping system may be controlled by built-in solenoid valves.

Note 5: When the controller power is ON, use the brake release switch to release the brake of the selected joint. Brake releasing with the teach pendant or mini-pendant is not possible.

(3) VS-6556G-P10, VS-6556G-BP10**VS-6556G-P10 & VS-6556G-BP10 Specifications**

Item		Specifications	
		Standard type	With brakes
Model name of robot set (Note 1)		VS-6556G-P10	VS-6556G-BP10
Model name of robot unit		VS-6556GM-P10	VS-6556GM-BP10
Overall arm length		270 (first arm) + 295 (second arm) = 565 mm	
Arm offset		J1 (swing): 75 mm, J3 (front arm): 90 mm	
Maximum motion area		R = 733 mm (end-effector mounting face) R = 653 mm (Point P: J4, J5, J6 center)	
Motion range		J1 : ±170°, J2 : +135°, -100°, J3 : +166°, -119° J4 : ±190°, J5 : ±120°, J6 : ±360°	
Maximum payload		7 kg (Note 2)	
Maximum composite speed		8200 mm/s (at the center of an end-effector mounting face)	
Position repeatability (Note 3)		In each of X, Y and Z directions: ±0.02 mm	
Maximum allowable inertia moment		Around J4 and J5: 0.413 kgm ² Around J6: 0.063 kgm ²	
Position detection		Absolute encoder	
Drive motor and brake		AC servomotors for all joints, Brakes for joints J2 to J4	AC servomotors for all joints, Brakes for joints J2 to J6
User air piping		6 systems (φ4x6), 3 solenoid valves (2-position, double solenoid) contained.	
User signal line		10 (for proximity sensor signals, etc.)	
Air source	Operating pressure	0.10~0.39MPa	
	Maximum allowable pressure	0.49MPa	
Weight		Approx. 35 kg (77 lbs) (See the name plate on each model.)	
Clean class for cleanroom type (FED-STD-209D)		Class 10 (0.1 μ) at point-of-use	
Note 1: The model name of robot set refers to the model name of a complete set including a robot unit and robot controller.			
Note 2: If the payload exceeds 6 kg, the robot unit must be used with the flange facing down at ±45 degrees from vertical.			
Note 3: Position repeatability is the value at constant ambient temperature.			

(4) VS-6577G-P10, VS-6577G-BP10**VS-6577G-P & VS-6577G-BP Specifications**

Item		Specifications	
		Standard type	With brakes
Model of robot system (Note 1)		VS-6577G-P10	VS-6577G-BP10
Model of robot unit		VS-6577GM-P10	VS-6577GM-BP10
Overall arm length		365 (first arm) + 405 (second arm) = 770 mm	
Arm offset		J1 (swing): 75 mm, J3 (front arm): 90 mm	
Maximum motion area		R = 934 mm (end-effector mounting face) R = 854 mm (Point P: J4, J5, J6 center)	
Motion range		J1 : ±170°, J2 : +135°, -100°, J3 : +169°, -119° J4 : ±190°, J5 : ±120°, J6 : ±360°	
Maximum payload		7 kg (Note 2)	
Maximum composite speed		7600 mm/s (at the center of an end-effector mounting face)	
Position repeatability (Note 3)		In each of X, Y and Z directions: ±0.03 mm	
Maximum allowable inertia moment		Around J4 and J5: 0.413 kgm ² Around J6: 0.063 kgm ²	
Position detection		Absolute encoder	
Drive motor and brake		AC servomotors for all joints, Brakes for joints J2 to J4	AC servomotors for all joints, Brakes for joints J2 to J6
User air piping		6 systems (φ4x6), 3 solenoid valves (2-position, double solenoid) contained.	
User signal line		10 (for proximity sensor signals, etc.)	
Air source	Operating pressure	0.10~0.39MPa	
	Maximum allowable pressure	0.49MPa	
Weight		Approx. 36 kg (80 lbs) (See the name plate on each model.)	
Clean class for cleanroom type (FED-STD-209D)		Class 10 (0.1 μ) at point-of-use	
Note 1: The model name of robot set refers to the model name of a complete set including a robot unit and robot controller.			
Note 2: If the payload exceeds 6 kg, the robot unit must be used with the flange facing down at ±45 degrees from vertical.			
Note 3: Position repeatability is the value at constant ambient temperature.			

(5) VS-6556G-P100, VS-6556G-BP100

VS-6556G-P100 & VS-6556G-BP100 Specifications

Item		Specifications	
		Standard type	With brakes
Model name of robot set (Note 1)		VS-6556G-P100	VS-6556G-BP100
Model name of robot unit		VS-6556GM-P100	VS-6556GM-BP100
Overall arm length		270 (first arm) + 295 (second arm) = 565 mm	
Arm offset		J1 (swing): 75 mm, J3 (front arm): 90 mm	
Maximum motion area		R = 733 mm (end-effector mounting face) R = 653 mm (Point P: J4, J5, J6 center)	
Motion range		J1 : ±170°, J2 : +135°, -100°, J3 : +166°, -119° J4 : ±190°, J5 : ±120°, J6 : ±360°	
Maximum payload		7 kg (Note 2)	
Maximum composite speed		8200 mm/s (at the center of an end-effector mounting face)	
Position repeatability (Note 3)		In each of X, Y and Z directions: ±0.02 mm	
Maximum allowable inertia moment		Around J4 and J5: 0.413 kgm ² Around J6: 0.063 kgm ²	
Position detection		Absolute encoder	
Drive motor and brake		AC servomotors for all joints, Brakes for joints J2 to J4	AC servomotors for all joints, Brakes for joints J2 to J6
User air piping		6 systems (φ4x6), 3 solenoid valves (2-position, double solenoid) contained.	
User signal line		10 (for proximity sensor signals, etc.)	
Air source	Operating pressure	0.10~0.39MPa	
	Maximum allowable pressure	0.49MPa	
Weight		Approx. 35 kg (77 lbs) (See the name plate on each model.)	
Clean class for cleanroom type (FED-STD-209D)		Class 100 (0.3 μ) at point-of-use	
Note 1: The model name of robot set refers to the model name of a complete set including a robot unit and robot controller.			
Note 2: If the payload exceeds 6 kg, the robot unit must be used with the flange facing down at ±45 degrees from vertical.			
Note 3: Position repeatability is the value at constant ambient temperature.			

(6) VS-6577G-P100, VS-6577G-BP100**VS-6577G-P100 & VS-6577G-BP100 Specifications**


Item		Specifications	
		Standard type	With brakes
Model of robot system (Note 1)		VS-6577G-P100	VS-6577G-BP100
Model of robot unit		VS-6577GM-P100	VS-6577GM-BP100
Overall arm length		365 (first arm) + 405 (second arm) = 770 mm	
Arm offset		J1 (swing): 75 mm, J3 (front arm): 90 mm	
Maximum motion area		R = 934 mm (end-effector mounting face) R = 854 mm (Point P: J4, J5, J6 center)	
Motion range		J1 : ±170°, J2 : +135°, -100°, J3 : +169°, -119° J4 : ±190°, J5 : ±120°, J6 : ±360°	
Maximum payload		7 kg (Note 2)	
Maximum composite speed		7600 mm/s (at the center of an end-effector mounting face)	
Position repeatability (Note 3)		In each of X, Y and Z directions: ±0.03 mm	
Maximum allowable inertia moment		Around J4 and J5: 0.413 kgm ² Around J6: 0.063 kgm ²	
Position detection		Absolute encoder	
Drive motor and brake		AC servomotors for all joints, Brakes for joints J2 to J4	AC servomotors for all joints, Brakes for joints J2 to J6
User air piping		6 systems (φ4x6), 3 solenoid valves (2-position, double solenoid) contained.	
User signal line		10 (for proximity sensor signals, etc.)	
Air source	Operating pressure	0.10~0.39MPa	
	Maximum allowable pressure	0.49MPa	
Weight		Approx. 36 kg (80 lbs) (See the name plate on each model.)	
Clean class for cleanroom type (FED-STD-209D)		Class 100 (0.3 μ) at point-of-use	
Note 1: The model name of robot set refers to the model name of a complete set including a robot unit and robot controller.			
Note 2: If the payload exceeds 6 kg, the robot unit must be used with the flange facing down at ±45 degrees from vertical.			
Note 3: Position repeatability is the value at constant ambient temperature.			

3.2 Outer Dimensions and Workable Space of the Robot Unit

The outer dimensions and workable space of the VS-G series are shown on the following pages.

3.2.1 Models Except UL-Listed Ones


(1) VS-6556G (Standard type)




Outer Dimensions and Workable Space [VS-6556G]

(2) VS-6556G-W (Dust- & splash-proof type)



Workable space
defined by point P



Detailed drawing of end-effector
mounting face (view A)





Detailed drawing of base mounting
face (Top view)





Workable space
defined by point P

Outer Dimensions and Workable Space [VS-6556G-W]


(3) VS-6556G-B (with brakes)



Outer Dimensions and Workable Space [VS-6556G-B]





Detailed drawing of base mounting face (Top view)




(4) VS-6556G-BW (Dust- & splash-proof type with brakes)

Workable space
defined by point P




Workable space
defined by point P

Detailed drawing of end-effector
mounting face (view A)




Detailed drawing of base mounting
face (Top view)




Outer Dimensions and Workable Space [VS-6556G-BW]

(5) VS-6556G-P10/P100(cleanroom type)




Outer dimensions and workable space (VS-6556G-P10/P100)


Workable space
defined by point P




Detailed drawing of end-effector mounting face (view A)




Detailed drawing of base mounting face (Top view)





(7) VS-6577G (Standard type)



Detailed drawing of end-effector mounting face (view A)



Detailed drawing of base mounting face (Top view)



Outer Dimensions and Workable Space [VS-6577G]

(8) VS-6577G-W (Dust- & splash-proof type)

Workable space
defined by point P

Top view of the VS-6577G-W robot arm. The workable space is defined by point P. Key dimensions include:

- Radius of the workable space: $R854.88$
- Radius of the arm: $R241.34$
- Distance from the center to the end effector: 222
- Angle of the workable space: 170°
- Joint J6 and J4 are indicated with dimensions $\pm 360^\circ$ and $\pm 190^\circ$.

Detailed drawing of end-effector mounting face (view A)

Detailed drawing of the end-effector mounting face (view A). Key features include:

- 4-M5 Depth 8 (P.C.D. 31.5)
- $\phi 40h8$ with tolerance $\begin{smallmatrix} 0 \\ 0.039 \end{smallmatrix}$
- $\phi 20H7$ with tolerance $\begin{smallmatrix} +0.021 \\ 0 \end{smallmatrix}$ and Depth 6
- $\phi 5H7$ with tolerance $\begin{smallmatrix} +0.012 \\ 0 \end{smallmatrix}$ and Depth 7

Detailed drawing of base mounting face (Top view)

Detailed drawing of the base mounting face (Top view). Key features include:

- 2- $\phi 6H7$ (Reference hole) with tolerance $\begin{smallmatrix} +0.012 \\ 0 \end{smallmatrix}$ and R20
- 4- $\phi 12$ Hole (for M10 screw)
- Dimensions: 184 ± 0.05 , 200 , 160 , 66 ± 0.05 , 160 , 200


Side view of the VS-6577G-W robot arm. The workable space is defined by point P. Key dimensions include:

- Radius of the workable space: $R779.88$
- Radius of the arm: $R323.35$
- Radius of the base: $R166.34$
- Radius of the end effector: $R414.88$
- Distance from the center to the end effector: 779.88
- Angle of the workable space: 170°
- Joint J2 is indicated with dimensions 105 , 465 , 120 , and 209° .
- Other dimensions: 80 , 485 , 405 , 218 , 90 , 365 , 335 , 203 , 143.26 , 337.97 , 75 .


Outer Dimensions and Workable Space [VS-6577G-W]

(9) VS-6577G-B (With brakes)



Workable space
defined by point P



Detailed drawing of end-effector
mounting face (view A)




Detailed drawing of base mounting
face (Top view)




Outer Dimensions and Workable Space [VS-6577G-B]

(10) VS-6577G-BW (Dust- & splash-proof type with brakes)



Workable space
defined by point P



Detailed drawing of end-effector
mounting face (view A)




Detailed drawing of base mounting
face (Top view)




Outer Dimensions and Workable Space [VS-6577G-BW]

(11) VS-6577G-P10/P100 (cleanroom type)



Workable space
defined by point P



Detailed drawing of end-effector
mounting face (view A)




Detailed drawing of base mounting
face (Top view)




Outer dimensions and workable space (VS-6577G-P10/P100)

(12) VS-6577G-BP10/BP100 (cleanroom type with brakes)



Workable space
defined by point P



Detailed drawing of end-effector
mounting face (view A)









Detailed drawing of base mounting
face (Top view)



Outer dimensions and workable space (VS-6577G-BP10/BP100)

3.2.2 UL-Listed Models


(1) VS-6556G-BW-UL (UL-Listed)




Outer Dimensions and Workable Space [VS-6556G-BW-UL]

(2) VS-6577G-BW-UL (UL-Listed)



Workable space
defined by point P



Detailed drawing of end-effector
mounting face (view A)



Detailed drawing of base mounting
face (Top view)



Outer Dimensions and Workable Space [VS-6577G-BW-UL]

3.3 Robot Positioning Time

VS-G series robot positioning time


1. Following figures show the positioning times used to calculate the cycle time.
2. Positioning time means the time from the start of robot operation to the arrival at the target positioning point.
3. After the robot moves to and passes the target positioning point, vibration will be dampened and the robot positioned at the target positioning point as shown in Figure below. This vibration dampening time is not considered in the graph.

Caution (1) The vibration dampening time depends on factors such as the weight of the end-effector. If the robot is to be used in such a way that it overshoots or if the vibration damping time is of great concern, test the robot carefully beforehand.

(2) If acceleration begins before residual vibration of the robot stops, an overcurrent error (code starts from ERROR6120; the first digit represents the axis number) may be displayed. In this case, take one of the following measures:


- Lower the deceleration of the preceding operation with a DECEL command to reduce residual vibration.
- Keep the robot in stand-by with a DELAY command until residual vibration stops.
- Lower acceleration with an ACCEL command.

(3) Operate the robot with the optimum load setting in accordance with the end-effector weight and workpiece weight. If not, a robot failure may result.




Vibration Dampening Time


(1) VS-6556G robot positioning time




J1 Axis [VS-6556G]




J2 Axis [VS-6556G]




J3 Axis [VS-6556G]





J4, J5 Axis [VS-6556G]




J6 Axis [VS-6556G]




CP Operation [VS-6556G]


(2) VS-6577G robot positioning time**J1 Axes [VS-6577G]****J2, J3 Axes [VS-6577G]**



J4, J5 Axes [VS-6577G]



J6 Axis [VS-6577G]



CP Operation [VS-6577G]


3.4 Air Piping, Signal Wiring, and Solenoid Valve Specifications

The VS-G series is equipped with 7 air pipes for air chuck, 10 signal lines, and 3 solenoid valves in it.

Caution: - Supply dry air filtered through an air filter (Recommended filtration rating: 5 μ m or below).
 - Before piping, blow the air tube out with dry air to clean out the inside (flushing); otherwise, any chips, cutting oil, dust or dirt remaining in the air tube may result in a damaged valve.

3.4.1 Air Piping and Signal Wiring

(1) VS-6556G(-B) / VS-6577G(-B)



Valve Symbols and Air Intake/Exhaust States
(1A and 1B are piping joint symbols.)

	Air piping joint		Solenoid valve	Valve signal	
	Air intake	Exhaust		A	B
AIR1	1A	1B	1	ON	OFF
	1B	1A	1	OFF	ON
	2A	2B	2	ON	OFF
	2B	2A	2	OFF	ON
	3A	3B	3	ON	OFF
	3B	3A	3	OFF	ON
AIR2					

CN20 Pin Assignment

For controller I/O unit, NPN type (source IN, sink OUT)

CN20 pin No.	Used for:
12	+24V
13	Solenoid 1A (solenoid valve 1)
14	Solenoid 1B (solenoid valve 1)
15	Solenoid 2A (solenoid valve 2)
16	Solenoid 2B (solenoid valve 2)
17	Solenoid 3A (solenoid valve 3)
18	Solenoid 3B (solenoid valve 3)

For controller I/O unit, PNP type (sink IN, source OUT)

CN20 pin No.	Used for:
12	0V
13	Solenoid 1A (solenoid valve 1)
14	Solenoid 1B (solenoid valve 1)
15	Solenoid 2A (solenoid valve 2)
16	Solenoid 2B (solenoid valve 2)
17	Solenoid 3A (solenoid valve 3)
18	Solenoid 3B (solenoid valve 3)


Note 1: Pins #1 to #10 on CN21 and those on CN20 are connected with each other. The allowable current per line is 1 A.

Note 2: Use the attached connector sets for CN20 and CN21.

Connector set part No.	Part No.	Model and part name	Appearance
410889-0030	410887-0170 (for CN20)	SRCN6A25-24S (round type connector) Japan Aviation Electronics Industry Ltd.	
	410877-0180 (for CN21)	JMLP1610M (L type plug connector) DDK Electronics, Inc.	

Air Piping and Signal Wiring [VS-6556G(-B) / VS-6577G(-B)]

(2) VS-6556G-(B)W / VS-6577G-(B)W



Valve Symbols and Air Intake/Exhaust States
(1A and 1B are piping joint symbols.)

Air piping joint			Valve signal		
AIR1	Air intake	Exhaust	Solenoid valve	Solenoid	
	1A	1B	1	A	B
	1A	1B	1	ON	OFF
	1B	1A	1	OFF	ON
	2A	2B	2	ON	OFF
	2B	2A	2	OFF	ON
AIR2	3A	3B	3	ON	OFF
	3B	3A	3	OFF	ON

CN20 Pin Assignment

For controller I/O unit, NPN type (source IN, sink OUT)

CN20 pin No.	Used for:
M	+24V
N	Solenoid 1A (solenoid valve 1)
P	Solenoid 1B (solenoid valve 1)
R	Solenoid 2A (solenoid valve 2)
S	Solenoid 2B (solenoid valve 2)
T	Solenoid 3A (solenoid valve 3)
U	Solenoid 3B (solenoid valve 3)

For controller I/O unit, PNP type (sink IN, source OUT)

CN20 pin No.	Used for:
M	0V
N	Solenoid 1A (solenoid valve 1)
P	Solenoid 1B (solenoid valve 1)
R	Solenoid 2A (solenoid valve 2)
S	Solenoid 2B (solenoid valve 2)
T	Solenoid 3A (solenoid valve 3)
U	Solenoid 3B (solenoid valve 3)

Note 1: Pins A to K on CN20 and pins #1 to #10 on CN21 are connected with each other as shown below. The allowable current per line is 1 A.


CN20	A	B	C	D	E	F	G	H	J	K
CN21	1	2	3	4	5	6	7	8	9	10

Note 2: Use the attached connector sets for CN20 and CN21.

Connector set part No.	Part No.	Model and part name	Appearance
410889-0010	410877-0120 (for CN20)	H/M3106A22-14S (straight plug) HIROSE ELECTRIC CO., LTD.	
	410877-0130 (for CN20)	H/MS3057-12A (cord clamp) HIROSE ELECTRIC CO., LTD.	Applicable wire diameter φ11.4 to 15.9
	410877-0140 (for CN20)	H/MS3057-12A1 (cord clamp) HIROSE ELECTRIC CO., LTD.	Applicable wire diameter φ8 to 11.6
	410877-0070 (for CN21)	EBLP1610M (L type plug connector) DDK Electronics, Inc.	

Air Piping and Signal Wiring [VS-6556G-(B)W / VS-6577G-(B)W]

(3) VS-6556G-P10(B)/VS-6577G-P10(B)



Valve Symbols Air Intake/Exhaust States
(1A and 1B are piping joint symbols.)

	Air piping joint		Valve signal		
	Air intake	Exhaust	Solenoid valve	Solenoid	
AIR 1	1A	1B	1	ON	OFF
	1B	1A	1	OFF	ON
	2A	2B	2	ON	OFF
	2B	2A	2	OFF	ON
	3A	3B	3	ON	OFF
	3B	3A	3	OFF	ON
AIR 2: Not used for cleanroom type					


Note for cleanroom type (class 10):

The cleanroom type requires ventilation inside the robot. Exhaust air from the air vent provided in the bottom of the robot base.

Recommended air inlet volume: 115 to 130 liters/min.

Recommended blower: VFC088P

(Fuji Electric Motor CO., LTD.)



CN20 Pin Assignment

For controller I/O unit, NPN type (source IN, sink OUT)

CN20 pin No.	Used for:
M	+24V
N	Solenoid 1A (solenoid valve 1)
P	Solenoid 1B (solenoid valve 1)
R	Solenoid 2A (solenoid valve 2)
S	Solenoid 2B (solenoid valve 2)
T	Solenoid 3A (solenoid valve 3)
U	Solenoid 3B (solenoid valve 3)

For controller I/O unit, PNP type (sink IN, source OUT)

CN20 pin No.	Used for:
M	0V
N	Solenoid 1A (solenoid valve 1)
P	Solenoid 1B (solenoid valve 1)
R	Solenoid 2A (solenoid valve 2)
S	Solenoid 2B (solenoid valve 2)
T	Solenoid 3A (solenoid valve 3)
U	Solenoid 3B (solenoid valve 3)

Note 1 : Pins A to K on CN20 and pins #1 to #10 on CN21 are connected with each other as shown below. The allowable current per line is 1 A.


CN20	A	B	C	D	E	F	G	H	J	K
CN21	1	2	3	4	5	6	7	8	9	10

Note 2 : Use the attached connector sets for CN20 and CN21.

Connector set part No.	Part No.	Model and part name	Appearance	
410889-0010	410877-0120 (for CN20)	H/M3106A22-14S (straight plug) (HIROSE ELECTRIC CO., LTD.)		
	410877-0130 (for CN20)	H/MS3057-12A (cord clamp) (HIROSE ELECTRIC CO., LTD.)	Applicable wire diameter φ11.4 to 15.9	
	410877-0140 (for CN20)	H/MS3057-12A1 (cord clamp) (HIROSE ELECTRIC CO., LTD.)	Applicable wire diameter φ8 to 11.6	
	410877-0070 (for CN21)	EBLP1610M (L type plug connector) (DDK Electronics, Inc.)		


Air Piping and Signal Wiring

(4) VS-6556G-P100(B)/VS-6577G-P100(B)



Valve Symbols and Air Intake/Exhaust States
(1A and 1B are piping joint symbols.)

	Air piping joint		Valve signal		
	Air intake	Exhaust	Solenoid valve	Solenoid	
				A	B
AIR1	1A	1B	1	ON	OFF
	1B	1A	1	OFF	ON
	2A	2B	2	ON	OFF
	2B	2A	2	OFF	ON
	3A	3B	3	ON	OFF
	3B	3A	3	OFF	ON
AIR2			Not used for cleanroom type		



CN20 Pin Assignment

For controller I/O unit, NPN type (source IN, sink OUT)

CN20 pin No.	Used for:
M	+24V
N	solenoid 1A (solenoid valve 1)
P	Solenoid 1B (solenoid valve 1)
R	Solenoid 2A (solenoid valve 2)
S	Solenoid 2B (solenoid valve 2)
T	Solenoid 3A (solenoid valve 3)
U	Solenoid 3B (solenoid valve 3)


For controller I/O unit, PNP type (sink IN, source OUT)

CN20 pin No.	Used for:
M	0V
N	Solenoid 1A (solenoid valve 1)
P	Solenoid 1B (solenoid valve 1)
R	Solenoid 2A (solenoid valve 2)
S	Solenoid 2B (solenoid valve 2)
T	Solenoid 3A (solenoid valve 3)
U	Solenoid 3B (solenoid valve 3)

Note 1 : Pins A to K on CN20 and pins #1 to #10 on CN21 are connected with each other as shown below. The allowable current per line is 1 A.


CN20	A	B	C	D	E	F	G	H	J	K
CN21	1	2	3	4	5	6	7	8	9	10

Note 2 : Use the attached connector sets for CN20 and CN21.

Connector set part No.	Part No.	Model and part name	Appearance	
410889-0010	410877-0120 (for CN20)	H/M3106A22-14S (straight plug) (HIROSE ELECTRIC CO., LTD.)		
	410877-0130 (for CN20)	H/MS3057-12A (cord clamp) (HIROSE ELECTRIC CO., LTD.)	Applicable wire diameter φ11.4 to 15.9	
	410877-0140 (for CN20)	H/MS3057-12A1 (cord clamp) (HIROSE ELECTRIC CO., LTD.)	Applicable wire diameter φ8 to 11.6	
	410877-0070 (for CN21)	EBLP1610M (L type plug connector) (DDK Electronics, Inc.)		

Air Piping and Signal Wiring

(3) UL-Listed models (VS-6556G-BW-UL / VS-6577G-BW-UL)



CN20 Pin Assignment
For controller I/O unit, NPN type (source IN, sink OUT)

CN20 pin No.	Used for:
M	+24V
N	Solenoid 1A (solenoid valve 1)
P	Solenoid 1B (solenoid valve 1)
R	Solenoid 2A (solenoid valve 2)
S	Solenoid 2B (solenoid valve 2)
T	Solenoid 3A (solenoid valve 3)
U	Solenoid 3B (solenoid valve 3)

For controller I/O unit, PNP type (sink IN, source OUT)

CN20 pin No.	Used for:
M	0V
N	Solenoid 1A (solenoid valve 1)
P	Solenoid 1B (solenoid valve 1)
R	Solenoid 2A (solenoid valve 2)
S	Solenoid 2B (solenoid valve 2)
T	Solenoid 3A (solenoid valve 3)
U	Solenoid 3B (solenoid valve 3)

Note 1: Pins A to K on CN20 and pins #1 to #10 on CN21 are connected with each other as shown below. The allowable current per line is 1 A.

CN20	A	B	C	D	E	F	G	H	J	K
CN21	1	2	3	4	5	6	7	8	9	10

Note 2: Use the attached connector sets for CN20 and CN21.

Connector set part No.	Part No.	Model and part name	Appearance
410889-0130	410877-0120 (for CN20)	H/M3106A22-14S (straight plug) HIROSE ELECTRIC CO., LTD.	
	410877-0130 (for CN20)	H/MS3057-12A (cord clamp) HIROSE ELECTRIC CO., LTD.	Applicable wire diameter φ11.4 to 15.9
	410877-0140 (for CN20)	H/MS3057-12A1 (cord clamp) HIROSE ELECTRIC CO., LTD.	
	410877-0620 (for CN21)	WEBLP1610M-2-D (L type plug connector) DDK Electronics, Inc.	

Air Piping and Signal Wiring [VS-6556G-BW-UL / VS-6577G-BW-UL]

3.4.2 Instructions for Using Splash-proof Connector Sets






The splash-proof connector sets for CN20 and CN21 assure the waterproof degree of as long as they are properly assembled and connected.

When using those connector sets, be sure to observe the following notes.

- (1) The degree of protection of the splash-proof robot unit, which is specified in Section 3.1 "Robot Specifications," is assured as long as the splash-proof connectors are joined with connectors CN20 and CN21 on the robot unit. If there is no connection on CN20 and CN21, the splash-proof rating is not assured.
- (2) Use a sheathed cable for a splash-proof connector. Using an unsheathed cable cannot assure the splash-proof rating.
- (3) Each connector set contains two types of cord clamps for CN20. Use the one that matches the cable diameter.
- (4) Each connector set should be assembled according to the instructions specified by the connector manufacturer.

The table below shows an assembly procedure example of a connector set for CN21. The actual assembly procedure should be in accordance with the instructions specified by the connector manufacturer.

Overview of assembly procedure example of connector set for CN21

Components of connector set for CN21	Assembly procedure example
 (For straight plug)  (For L type plug)	(1) Treatment of wire ends: Strip the wire ends of the cable (prepared by the customer). The cable diameter and the lengths "A" and "B" should be in accordance with the instructions given by the connector manufacturer.    (2) Tinning: Tin both the core wires and the connector contacts. (3) Pass the cable through the heat-shrinkable tube for splash-proof purpose (with adhesive inside, prepared by the customer) and the rubber bushing. (4) Solder the core wires onto the connector contacts to connect them each other. (5) Press the rubber bushing against the shell to fit the hood. Then cover the rubber bushing with the heat-shrinkable tube and apply heat to shrink the tube.  


3.4.3 Solenoid Valve Specifications (VS-G series)

Note: Do not cover the valve exhaust port behind the second arm.

	Item	Specifications
Valve	Switching system	2-position double
	Applicable fluid	Air
	Operating system	Pilot type
	Effective cross section (Cv value)	P→A·B : 1.116mm ² (0.062) A·B→R : 1.188mm ² (0.066)
	Lubrication	Oilless
	Operating pressure range	0.1 to 0.7 MPa (Note 1)
	Response time	15 ms or less (at 0.5 MPa)
	Maximum operating frequency	10 Hz
	Ambient temperature	-5 to 50°C (No dew condensation allowed. When dry air is used)
Solenoid	Operating voltage	24 V ±10%
	Power consumption (current)	0.5 W (21 mA)
	Surge voltage protection circuit	Zener diode

Note 1: The air source connected to the robot unit must be used within the operating pressure range from 0.10 to 0.39 MPa (specified in Chapter 3 "Specifications of the Robot Unit").

3.4.4 Existing Internal Threads for Wiring and Piping



Existing Internal Threads for Wiring and Piping (VS-G series)

3.5 Precautions When Designing the End-effectors

Design an end-effector such that it is in compliance with items (1) to (3) described below.



CAUTION

If the end-effector design precautions are not observed, the clamped parts of the robot unit may become loose, rattle or be out of position. In the worst case, the mechanical parts of the robot and robot controller may become damaged.

(1) Mass of end-effector


Design the end-effector so that the total mass of the end-effector (including workpiece) will be lighter than the maximum payload capacity of the robot. The total mass includes the wiring, piping, etc.

Maximum total mass of end-effector (including workpiece) $\leq$ Maximum payload capacity (7 kg) *¹

*¹: If the payload exceeds 6 kg, the robot unit must be used with the flange facing down at ± 45 degrees from vertical.

(2) Center of gravity position of end-effector

Design an end-effector so that the center of gravity position of the end-effector (including workpiece) is within the range shown in Figure below.



Allowable Range of Center of Gravity Position of End-effector (VS-G series)

(3) Moment of inertia around J4, J5 and J6






Design an end-effector so that its moments of inertia around J4, J5 and J6 (including workpiece) do not exceed the maximum allowable moment of inertia of the robot.

Moment of inertia around J4, J5 and J6 of end-effector (incl. mass of workpiece) ≤ Max. allowable moment of inertia

Mass of payload (kg)	Max allowable moment of inertia (kg·m ²)	
	Around J4 & J5	Around J6
~1	0.059	0.009
~2	0.118	0.018
~3	0.177	0.027
~4	0.236	0.036
~5	0.295	0.045
~6	0.354	0.054
~7	0.413	0.063

When calculating the moment of inertia around J4, J5 and J6 of the end-effector, use the formulas given in Following Table and Figure.


Moment-of-Inertia Formulas

1. Cylinder (1) (Axis of rotation = Center axis)  $I = \frac{mr^2}{2}$	4. Sphere (Axis of rotation = Center axis)  $I = \frac{2mr^2}{5}$
2. Cylinder (2) (The axis of rotation passes through the center of gravity.)  $I = \frac{m}{4} \left(r^2 + \frac{l^2}{3} \right)$	5. Center of gravity not on the axis of rotation I_g: Moment of inertia around center of gravity [kgm²]  $I = I_g + mL^2$
3. Rectangular parallelepiped (The axis of rotation passes through the center of gravity.)  $I = \frac{m}{12} (b^2 + c^2)$	I: Moment of inertia kgm² m: Mass kg r: Radius m a, b, c, l: Length m

Calculation example : When calculating the moment of inertia of a complicated shape, divide it into simple parts as much as possible for easier calculations.

As shown in the figure below, divide the end-effector into three parts (①, ②, ③).

(1) Moment of inertia around J6



Moment of inertia around J6 of (1): I_1 (from 3 and 5 in the above table)

$$I_1 = \frac{0.14}{12} (0.12^2 + 0.015^2) + 0.14 \times 0.01^2 = 1.85 \times 10^{-4} \text{ [kgm}^2\text{]}$$

Moment of inertia around J6 of (2): I_2 (from 1 and 5 in the above table)

$$I_2 = \frac{0.1 \times 0.01^2}{2} + 0.1 \times 0.04^2 = 1.65 \times 10^{-4} \text{ [kgm}^2\text{]}$$

Moment of inertia around J6 of (3): I_3 (from 1 and 5 in the above table)


$$I_3 = \frac{1.0 \times 0.02^2}{2} + 1.0 \times 0.05^2 = 2.7 \times 10^{-3} \text{ [kgm}^2\text{]}$$

Moment of inertia around J6 of entire hand: I_{J6}

$$I_{J6} = I_1 + I_2 + I_3 = 0.003 \text{ [kgm}^2\text{]}$$

(2) Moment of inertia around J4 and J5

For the end-effector shown below, the moment of inertia around J4 and J5 can be calculated according to the same formula.



Moment of inertia around J4 and J5 of (1): I_1 (from 3 and 5 in the above table)

$$I_1 = \frac{0.14}{12} (0.015^2 + 0.01^2) + 0.14 \times (0.08 + 0.005)^2 = 1.02 \times 10^{-3} \text{ [kgm}^2\text{]}$$

Moment of inertia around J4 and J5 of (2): I_2 (from 2 and 5 in the above table)

$$I_2 = \frac{0.1}{4} (0.01^2 + \frac{0.04^2}{3}) + 0.1 \times (0.08 + 0.01 + 0.02)^2 = 1.23 \times 10^{-3} \text{ [kgm}^2\text{]}$$

Moment of inertia around J4 and J5 of (3): I_3 (from 2 and 5 in the above table)

$$I_3 = \frac{1.0}{4} (0.02^2 + \frac{0.1^2}{3}) + 1.0 \times (0.08 + 0.01 + 0.05)^2 = 2.0 \times 10^{-2} \text{ [kgm}^2\text{]}$$

Moment of inertia around J4 and J5 of entire end-effector: I_{J4}, I_{J5}

$$I_{J4} = I_{J5} = I_1 + I_2 + I_3 = 2.22 \times 10^{-2} \text{ [kgm}^2\text{]}$$


End-effector Moment of Inertia Calculation Example

3.6 Stopping Time and Distance (Angle) at an Emergency Stop


Pressing the emergency stop button when the robot is in motion stops the robot. The stopping time required from activation of a stop signal and the distance (angle) for major three joints vary with the robot speed as shown in the graphs below. The measuring conditions are: Robot arm extended, 33%, 66% and 100% of the maximum payload.

Note : The acceleration differs depending upon the mass of payload setting. The graphs below show the cases where the stopping distance or stopping time comes to be the maximum.

(1) VS-6556G series




J1, J2, J3 stopping time vs. speed at an emergency stop (VS-6556G series)




J1, J2, J3 stopping distance vs. speed at an emergency stop (VS-6556G series)

(2) VS-6577G series



J1, J2, J3 stopping time vs. speed at an emergency stop (VS-6577G series)



J1, J2, J3 stopping distance vs. speed at an emergency stop (VS-6577G series)

Chapter 4

Specifications of the Robot Controller

4.1 Specifications

Table below lists the robot controller specifications.

RC7M Controller Specifications (1) (VS-G series)

Item			Specifications
Applicable robot			Small-sized, vertical articulated type (VS-G series)
Controller model			RC7M-VSG6***- **
Control system			PTP, CP 3-dimensional linear, 3-dimensional circular
No. of controllable axes			Up to six axes simultaneously
Drive system			All axes: Full-digital AC servo
Language used			DENSO robot language (conforming to SLIM)
Memory capacity			3.25 MB (equivalent to 10,000 steps, 30,000 points)
Teaching system			1) Remote teaching 2) Numerical input (MDI)
External signals (I/O)	Standard I/O	Mini I/O	Input signals: 8 user open points + 11 fixed system points Output signals: 8 user open points + 14 fixed system points Note: In global type, some fixed system points are not used.
		HAND I/O	Input signals: 8 user open points Output signals: 8 user open points
	SAFETY I/O (Only for Global type)		Input signals: 6 fixed system points Output signals: 5 fixed system points
	Parallel I/O board (Option)	2 boards	Input signals: Additional 80 user open points Output signals: Additional 96 user open points
		1 board	Input signals: Additional 40 user open points Output signals: Additional 48 user open points
	DeviceNet board (Option)	Master & slave	Input signals: 1024 points (Master) + 256 points (Slave) Output signals: 1024 points (Master) + 256 points (Slave)
		Master	Input signals: 1024 points Output signals: 1024 points
		Slave	Input signals: 256 points Output signals: 256 points
	CC-Link board (option)	Slave	Input signals: 384 points Output signals: 384 points (including remote registers RWw and RWr)
	External communication		
Extension slot			3 (For an optional board)
Self-diagnosis function			Overrun, servo error, memory error, input error, etc.
Timer function			0.02 to 10 sec. (in units of 1/60 sec.)
Error display			Error codes will be outputted on the external I/O. Error messages will be displayed in English on the teach pendant (option). Error codes will be displayed on the mini pendant (option).
Cables	Motor & encoder cable (option)		2 m, 4 m, 6 m, 12 m, 20 m (Standard / Splash-proof)
	I/O cable (option)		8 m, 15 m (For Mini I/O, HAND I/O, Optional parallel I/O) and SAFETY I/O
	Power cable		5 m

RC7M Controller Specifications (2) (VS-G series)

Item	Specifications
Environmental conditions (in operation)	Temperature: 0 to 40°C Humidity: 90% RH or less (no condensation allowed)
Power source	Three-phase, 200 VAC-15% to 230 VAC+10%, 50/60 Hz, 1.85 kVA Single-phase, 230 VAC-10% to 230 VAC+10%, 50/60 Hz, 1.85 kVA
Degree of protection	IP20
Weight	Standard type: Approx. 18 kg (40 lbs) Global type with safety board: Approx. 19 kg (42 lbs) Global type with safety box: Approx. 22 kg (49 lbs)

** WARNING**

- **DO NOT touch fins. Their hot surfaces may cause severe burns.**
- **DO NOT insert fingers or foreign objects into openings. Doing so may cause bodily injury.**
- **Before opening the controller cover and accessing the inside of the controller for maintenance, be sure to turn off the power switch, disconnect the power cable, and wait 3 minutes or more. This is for protecting you from electric shock.**
- **DO NOT connect or disconnect connectors to/from the controller while the power switch is on. Doing so may cause electric shock or controller failure.**


** CAUTION IN INSTALLATION**

- **This controller is not designed to be dust-proof, splash-proof, or explosion-proof.**
- **Read operation manuals before installation.**
- **Do not place anything on the controller.**

4.2 Outer Dimensions

Figure below shows the outer dimensions of the robot controller.

Outer Dimensions of Robot Controller (VS-G series)



Outer Dimensions of RC7M Robot Controller (Example: Global type with safety board)

4.3 Controller Setting Table

The controller setting table given in Figure below is attached to the controller. It shows the software version, the next replacement dates of the memory backup battery and encoder backup battery, etc.

コントローラ設定表／THE SETPRM LIST

①パラメータ／PARAMETER

ソフトウェアVer.
SOFTWARE Ver.

電池交換日
DATE OF RENEWING BAT.

TYPE

②サブアセンブリ／SUBASSEMBLY

IPM	SLOT5	SLOT6	
BOARD	SLOT3	SLOT4	
	SLOT1	SLOT2	

③その他変更点／OTHER MODIFICATIONS


Robot Controller	
MODEL NO.	_____
PART NO.	_____
POWER	_____
CAPACITY	_____
TYP OUTPUT	_____
WEIGHT	_____
CONDITION	_____
SERIAL NO.	_____
YEAR OF PRODUCTION	_____
DENSO WAVE INCORPORATED 4-2-12, TORANOMON MINATO-KU, TOKYO, JAPAN	

<Content THE SETPRM LIST>

SOFTWARE Ver.	The version of the main software for the controller is entered.
DATE OF RENEWING BAT.	The next replacement dates of the memory backup battery and encoder backup battery are entered.
TYPE	The model of the robot system is entered. The coding of the set model is described below:
SUBASSEMBLY	The type and position of the controller IPM board are described.

The coding of the set model (VS-G series)

VS -6 5 56 G-BW/



Chapter 5 Warranty

DENSO robots are manufactured under strict quality control. In case of failure, we warranty the robot under the following conditions:

Warranty Period

The warranty shall be effective for one year from the date of purchase.

Warranty Coverage

DENSO WAVE shall repair the robot free of charge when a failure occurs and is attributable to the design, manufacture or material of the robot within the warranty period in spite of proper use.

Items Not Covered

Failures, which arise from one of the following, shall not be covered by the warranty even if the robot is under warranty:

- (1) Failures caused by improper repair, modification, transfer or handling by you or a third party;
- (2) Failures caused by the use of a part or oil/fat other than those specified in the related manuals;
- (3) Failures caused by a fire, salt damage, earthquake, storm/flood or other acts of God;
- (4) Failures caused by the use of the robot in an environment other than the environment specified in the related manuals, such as dust and water ingress;
- (5) Failures caused by a worn-out consumable, such as a fan filter;
- (6) Failures caused by improper performance or non-performance of lubrication, maintenance or inspections stated in this owner's manual; and
- (7) Damages other than the robot repair costs.

Vertical Articulated Robot VS-G SERIES

GENERAL INFORMATION ABOUT ROBOT

First Edition	July 2005
Eighth Edition	April 2009
Ninth Edition	March 2010

DENSO WAVE INCORPORATED

3M**C

The purpose of this manual is to provide accurate information in the handling and operating of the robot. Please feel free to send your comments regarding any errors or omissions you may have found, or any suggestions you may have for generally improving the manual.

In no event will DENSO WAVE INCORPORATED be liable for any direct or indirect damages resulting from the application of the information in this manual.

