

**KW1M-R
Eco-POWER METER
User's Manual**

Cautions for Your Safety

Read the manual carefully before installing, running and maintenance for proper operation. Before using, master the knowledge of the equipment, safety information and all of other notes.

This manual uses two safety flags to indicate different levels of danger.



WARNING

A handling error could cause serious physical injury to an operator and in the worst case could even be fatal.

- Always take precautions to ensure the overall safety of your system, so that the whole system remains safe in the event of failure of this product or other external factor.
- Do not use this product in areas with inflammable gas. It could lead to an explosion.
- Exposing this product to excessive heat or open flames could cause damage to the lithium battery or other electronic parts.
- Do not use this product at a hospital and the place with the electric medical equipment (pacemakers etc.) It might influence the electric medical equipment due to the radio disturbance and it could cause an accident.



CAUTION

A handling error could cause serious physical injury to an operator or damage to the equipment.

- To prevent abnormal exothermic heat or smoke generation, use this product at the values less than the maximum of the characteristics and performance that are assured in these specifications.
- Do not dismantle or remodel the product. It could lead to abnormal exothermic heat or smoke generation.
- Do not touch the terminal while turning on electricity. It could lead to an electric shock.
- Use the external devices to function the emergency stop and interlock circuit.
- Connect the wires or connectors securely. The loose connection might cause abnormal exothermic heat or smoke generation.
- Do not allow foreign matters such as liquid, flammable materials, metals to go into the inside of the product. It might cause exothermic heat or smoke generation.
- Do not undertake construction (such as connection and disconnection) while the power supply is on.
- Do not use at secondary side circuit of inverter. It might cause exothermic heat or damage.

Copyright and trademark

- Panasonic Electric Works SUNX Co., Ltd. owns the copyright of this manual.
- We stiffly refuse the reproduction of without permission from this manual.
- Modbus Protocol is a communication protocol that the Modicon Inc. developed for PLC.
- Other company names and the product names are the trademarks or registered trademarks of each company.

Introduction

Thank you very much indeed for purchasing
“KW1M-R Eco-POWER METER”.

In this manual, we explain the usage of “KW1M-R
Eco-POWER METER” in detail.

Please use it correctly after understanding the content
enough.

Table of Contents

Chapter 1 Unit's Features and Structure	1
1.1 Features	1
1.2 Unit's Name and Model Numbers	2
1.2.1 Main unit	2
1.2.2 Option	2
1.2.3 Tool	3
1.3 Measurement items	3
Chapter 2 Parts Name and Working	4
2.1 Parts Names	4
2.2 Key's Functions	4
Chapter 3 Wiring	5
3.1 Terminal arrangement	5
3.2 Wiring Diagrams	7
3.3 How to attach the Current Transformer (CT)	8
3.4 For input connection	10
3.5 For Output connection	11
3.6 RS485 Communication	11
3.7 RS232C Communication	13
3.7.1 Connect to PC	13
3.7.2 Connect to PLC	14
Chapter 4 Settings	16
4.1 AKW1000 /AKW1000K Setting procedures	16
4.2 AKW1000 /AKW1000K Setting Mode Explanation	17
4.2.1 MODE1 (Mode for setting each parameter for wireless communication.)	17
4.2.2 MODE2 (Communication test mode)	19
4.2.3 MODE3 (Mode for setting of each parameter for serial communication)	21
4.2.4 MODE4 (Mode for setting of each parameter for optional function)	23
4.3 AKW1131 /AKW1131K Setting procedure	26
4.4 AKW1131 /AKW1131K Setting Mode Explanation	29
4.4.1 MODE1 (Mode for setting each parameter for power measurement.)	29
4.4.2 MODE2 (Mode for setting of each parameter for pulse measurement)	34
4.4.3 MODE3 (Mode for setting of each parameter for serial communication)	35
4.4.4 MODE4 (Mode for setting of each parameter for optional function)	38
Chapter 5 Various Functions	40
5.1 LOCK mode	40
5.2 Pulse output function	40
5.2.1 Output depends on integrated electric power	40
5.2.2 Instantaneous electric power alarm	40
5.2.3 Current alarm	40
5.2.4 Stand-by power alarm	40
5.2.5 Output depends on count value	40
5.3 Counter function	41
5.3.1 Operation mode	41
5.3.2 Change the Preset Value	41
5.4 Wireless functions	42
5.4.1 System configuration	42
5.4.2 Initial setting flow for wireless	44
5.4.3 Check radio wave environment	44
5.4.4 Network construction	46
5.4.5 Wired communication settings	48
5.4.6 Delimiter time of data by wired side (DTIM)	48
5.4.7 Upper communication recognition time (UTIM)	49
5.4.8 KW Network Monitor	50
5.4.9 Use as a wireless unit	51
5.4.10 Communication error flag function	52
Chapter 6 Display of each Value	53
6.1 Working of AKW1000 /AKW1000K Monitor Display	53
6.2 AKW1000 /AKW1000K Monitor display	53
6.2.1 Unit type/Group	53

6.2.2 Communication Channel.....	53
6.2.3 LQI (Field intensity with an upper wireless device).....	54
6.2.4 Calendar/Timer	54
6.3 Working of AKW1131 /AKW1131K Monitor Display.....	55
6.4 AKW1131 /AKW1131K Monitor display.....	56
6.4.1 Integrated electric power.....	56
6.4.2 Instantaneous electric power	56
6.4.3 Current	57
6.4.4 Voltage	57
6.4.5 Electricity Charge	58
6.4.6 Carbon dioxide conversion value.....	58
6.4.7 Power factor	58
6.4.8 Frequency	59
6.4.9 Hour meter	59
6.4.10 Counter	60
6.4.11 LQI (Field intensity with an upper wireless device).....	60
6.5 Other indication.....	61
6.5.1 Power On indication	61
6.5.2 Indication while communication	61
6.5.3 Indication of communication error.....	61
Chapter 7 Communication.....	62
7.1 Communication Procedures	62
7.2 Communication timing	62
7.3 MEWTOCOL Communication.....	63
7.3.1 Overview of MEWTOCOL-COM	63
7.3.2 Data Register List (MEWTOCOL) <Only AKW1131/AKW1131K>	64
7.3.3 Error Codes.....	66
7.3.4 Command.....	66
7.4 MODBUS (RTU) Communication	68
7.4.1 Overview of MODBUS (RTU)	68
7.4.2 Data Register List <Only AKW1131/AKW1131K>	71
Chapter 8 Specifications.....	73
8.1 Main unit	73
8.2 Input Specifications.....	74
8.2.1 Electric power input <only AKW1131/AKW1131K>	74
8.2.2 Pulse input <only AKW1131/AKW1131K>	75
8.3 Output Specifications.....	75
8.3.1 Pulse output (Transistor output) <only AKW1131/AKW1131K>.....	75
8.4 Communication Specifications.....	75
8.4.1 RS232C communication <only AKW1000/AKW1000K>	75
8.4.2 RS485 communication	76
8.4.3 Wireless communication	77
8.5 Calendar timer specifications.....	78
8.6 Self-diagnostic function.....	79
8.7 Power Failure Memory.....	79
8.8 Dedicated Current Transformer Specifications.....	80
Chapter 9 Mounting	81
9.1 Dimensions	81
9.1.1 Main unit.....	81
9.1.2 Dedicated CT	82
9.1.3 Antenna.....	85
9.2 How to mount to DIN rail.....	86
9.3 How to connect / replace the battery	86
9.4 Antenna.....	87
Chapter 10 Q&A	88

Cautions before using

■ Installation environment

◇Do not use the Unit in the following environments.

- Where the unit will be exposed to direct sunlight and where the ambient temperature is outside the range of -10 to 50 °C.
- Where the ambient humidity is outside the range of 30 to 85 % RH (at 20°C, non-condensing) and where condensation might occur by sudden temperature changes
- Where inflammable or corrosive gas might be produced
- Where the unit will be exposed to excessive airborne dust or metal particles
- Where the unit will be exposed to water, oil or chemicals
- Where organic solvents such as benzene, paint thinner, alcohol, or strong alkaline solutions such as ammonia or caustic soda might adhere to the product
- Where direct vibration or shock might be transmitted to the product, and where water might wet the product.
- Where high-voltage line, high-voltage device, power line, power supply device or the device with sending part such as amateur radio are existed, or large switching surge is occurred.

◇Please use the Unit according to the specifications described in this manual. Otherwise, it may malfunction or cause fire and an electric shock.

- Connect to the power supply in compliance with the rating.
- Refer to the wiring diagram to ensure proper wiring for the power supply, input and output.
- Do not perform wiring or installation with a live line. It may also lead to circuit burnout or fire by way of the secondary CT side opening.

■ Installation

- Installation and wiring must be performed by expert personnel for electrical work or electric piping.
- The power supply terminal and voltage input terminal of the main unit is common. Therefore if additional noise effects the power supply line, incorrect measurements may result.
- Eco-POWER METER is designed to be used in a control panel.
- Do not add an excess power to the display. It might break the inner liquid crystal.
- **Do not bring it close to a radio and television. It may cause poor reception.**
- **Where the place there is a broadcasting station or radio station and radio wave from there is strong, this unit may not be able to use.**
- **This unit uses 2.4GHz-width wave to transmit data, if some devices using the same frequency are existed, interference might occur and not be able to communicate.**
- In order to make the wireless performance better, pay attention to the below items.
 - Mount an antenna as high as possible.
 - Be sure to connect the antenna and the mounting direction is vertical for the ground.
 - Antenna should be keep away from metal board. If antenna is mounted inside the control board, the wireless performance will decrease.
- When it communicates between several buildings, it might not communicate due to traffic or existence of something. Mount an antenna as high as possible to reduce the influence.
- Master and slaves (repeaters) can't be connected via wire. Be sure to connect via wireless. If you connect with wire, it will display the error.

■ As to measurement

- If there is some distortion by harmonic or waveform, it may not measure correctly. Please check with the actual system before adopts it.
- This can't measure the power that flows reverse such as a regenerative electric power. If you measure a reverse power, it shows "0.00kW" and it doesn't count.
- It might not measure an instantaneous current such as an inrush current or an welding machine.
- When measuring the below loads, it might not satisfy with the accuracy guarantee.
Out of rating current, Load with low power factor,
Load with winding current, Load with ferromagnetic field
- Power factor operation is a method assuming balanced load. The error might be big when it measures unbalanced load.

■ Static electricity

- Discharge static electricity touching the grounded metal etc. when you touch the unit.
- Excessive static electricity might be generated especially in a dry place.

■ Cleaning

- Wipe dirt of the main unit with soft cloth etc. When thinner is used, the unit might deform or be discolored.

■ Power supply

- Connect a breaker to the voltage input part for safety reasons and to protect the device. The breaker that connects to the voltage input part must arrange at the position easily reached, and display shows it is the breaker of the equipment.
- Do not turn on the power supply or input until all wiring is completed.

■ Before power on

Please note the following points when turning on power at the first time.

- Confirm there are neither wiring rubbish nor especially an electrical conduction when installed.
- Confirm neither the power supply wiring, the I/O wiring nor the power-supply voltage are wrong.
- Tighten the installation screw and the terminal screw surely.
- Use an electric wire applicable to the rated current.

■ Usable countries

This product can be used in following countries.

AKW1000, AKW1131	Japan, China
AKW1000K, AKW1131K	Korea

Chapter 1 Unit's Features and Structure

KW1M-R Eco-POWER METER is the suitable size wattmeter with wireless functions for installing in a control board.

It measures electrical power, voltage, current and so on using AC voltage and AC current input.

It also works as an hour meter, which is measured power-on or power-off time.

1.1 Features

Easy setting! Adopts auto-routing system

"Auto-routing system" that it builds up wireless network automatically is adopted. And you don't need complicated terminal registration and routing setting. You can introduce with easy setting of the main unit.

In addition, it has monitor function to check the field intensity during running; therefore it is easy to maintenance.

Wireless type: 2.4GHz (1mW) conform to IEEE802.15.4

*It is not compatible with KR10 and KR20 wireless unit.

Possible to wireless communication with Eco-POWER METER series

It is possible to wireless communication by connecting devices that have MEWTOCOL or MODBUS (RTU) via RS485 such as Eco-POWER METER. For one master unit up to 99 terminal equipments (MEWTOCOL) and up to 247* terminal equipments with MODBUS (RTU) can be connected including slaves. (* Slave can connect up to 99 units including AKW1131(K) via RS485.)

In addition, Master AKW1000(K) can be used as a slave (a repeater) by setting with master/slave setting mode. Therefore, AKW1000(K) can be used as a wireless data communication device not only power measuring by Eco-POWER METER.

Small and thin size is appropriate to mount in devices or panels.

50mm of the thickness makes it to mount in lower panel. It can mount with both of screw and DIN rail.

When using attached antenna with cable, it can communicate wireless in metal case or metal panel.


(*Mount an antenna outside of the metal case.)

AC free power supply

KW1M-R is working with AC power supply (100 to 240V *1), and it can mount to panel board directly.

*1. Rated power supply of AKW1000K and AKW1131K is limited to 220V AC.

<System construction example>



1.2 Unit's Name and Model Numbers

1.2.1 Main unit

Product name		Model No.
KW1M-R Eco-POWER METER	Master	AKW1000 / AKW1000K *
	Slave	AKW1131 / AKW1131K *

* Use AKW1000, AKW1131 in Japan and China. Use AKW1000K, AKW1131K in Korea

* Rated power supply of AKW1000K and AKW1131K is limited to 220V AC.

(Master: AKW1000 / AKW1000K)

Power supply	Terminal type
100-240VAC 50/60Hz	Scret terminal • Screw Terminal(M3 + / - screw) (only for "Power supply" , "RS232C(SD,RD,SG)" tarminals) • Screw Terminal(M3.5 + / - screw)

* Master or Slave is selectable with MODE1 Master/Slave setting mode.

* AKW1000 has no electric power measurement function.

(Slave: AKW1131 / AKW1131K)

Phase and Wire system	• Single-phase two-wire • Single-phase three-wire • Three-phase three-wire • Three-phase four-wire
Power supply	100-240V AC 50/60Hz
Measured voltage input	• 400VAC • 100/200VAC
Measured current input	50A / 100A / 250A / 400A / 600A
Current transformer	Dedicated CT type
Terminal type	Screw Terminal (M3 + / - screw) and (M3.5 + / - screw) *1

*1 M3.5 +/- screws are only for "Power supply", "voltage input (P0, P1, P2, P3) terminals."

1.2.2 Option

Dedicated Current Transformer (CT) Clamp-on type

Product name	Rated primary current	Model No
Dedicated current transformer for 5A/50A	5A / 50A	AKW4801C
Dedicated current transformer for 100A	100A	AKW4802C
Dedicated current transformer for 250A	250A	AKW4803C
Dedicated current transformer for 400A	400A	AKW4804C

Dedicated Current Transformer (CT) Through type

Product name	Rated primary current	Model No
Dedicated current transformer for 50A/100A	50A / 100A	AKW4506C
Dedicated current transformer for 250A/400A	250A / 400A	AKW4507C
Dedicated current transformer for 600A	600A	AKW4508C

Others

Product name	Contents	Model No
Mounting rail	Used to fix DIN rail terminal block	AT8-DLA1
Fastening plate	Used to fix DIN rail	ATA4806
Battery (attached) *1	Required to back up memory and calendar	AFPG804
Antenna with cable	Cable length: 2m	AKW1803 *2 *3
Antenna extension cable	Cable length: 2m	AKW1804 *3
Pencil type antenna	1pc.	AKW1802 *4
RS232C cable	Dsub 9 pin female ⇔ Shielded wire triplex 3m	AKR1801
Extension cable for CT 3m	Used to extend CT	AKW4703
Extension cable for CT 5m	Used to extend CT	AKW4705

*1) This is included only with AKW1000(K).

*2) Antenna with cable (AKW1803) is included with AKW1000(K) and AKW1131(K).

*3) Antenna with cable (AKW1803) and Antenna extension cable can not be used in Korea.

*4) Pencil type antenna is included with AKW1000K, AKW1131K.

1.2.3 Tool

Product name	Contents	Remarks
KW Network Monitor	Use to check wireless network and connected terminal equipments to slave. It is possible to check field intensity at one time with network check.	Download from our website

Note) Users' registration is required to download the software.

1.3 Measurement items

Item	Unit	Data range
Integrated electric power (Active)	kWh/ MWh	0.00 to 9999.99MWh (9-digit display) 0.00 to 9999999.99kWh
Instantaneous electric power (Active)	kW	0.00 to 9999.99
Current	R-current	A
	S-current	
	T-current	
Voltage	R(RS)-voltage	V
	S(RT)-voltage	
	T(TS)-voltage	
Electricity charge *		0.00 to 999999
Conversion value	Carbon dioxide	kg-CO ₂
Power Factor		0.00 to 1.00 (Identify leading phase(－) and lagging phase) (Within the range of phase angle $\theta = -90$ to 90 degree)
Frequency	Hz	47.5 to 63.0
Hour meter	ON-time	hour
	OFF-time	
Pulse counter		0 to 999999

*Eco-POWER METER is designed chiefly to manage saving energy.


It is neither intended nor can it be legally used for billing.

Chapter 2 Parts Name and Working


2.1 Parts Names

①MODE indicator	Lighting when mode setting
②LOCK indicator	Lighting while in lock mode
③OP. output indicator	Lighting when pulse output *only AKW1131(K)
④Mode display	Display mode in setting and measurement item with 16-seg
⑤Display each value	With 7-seg •Display each measured value •Display each setting value
⑥POWER indicator TX/RX indicator	Lighting while power on Blinking while communication *not for repeater
⑦ERROR indicator	Blinking when error occurs.
⑧<MODE> key	
⑨<SET> key	
⑩<SHIFT / ▽> key	
⑪<ITEM / △> key	

<AKW1000/AKW1000K>



<AKW1131/AKW1131K>



2.2 Key's Functions

Key	Functions
<MODE>	•Use to shift setting mode
<SET>	•Use to set each value entered •Reset stand-by alarm while output the alarm (only available while output the stand-by alarm)
<SET> (continuous press 3-sec)	•All keys locked •Release lock mode while in lock mode
<SHIFT / ▽>	•To select measured value display (While monitoring) •To select setting value (While setting mode)
<ITEM / △>	•To select measured value display (While monitoring) •To select setting value (While setting mode)
<SET>+<MODE>	•To reset the measured value


Chapter 3 Wiring

3.1 Terminal arrangement

Be sure to wire correctly according to the terminal arrangement and wiring diagrams.
After completing wiring, be sure to attach the terminal cover for safety reasons.

<AKW1000/AKW1000K>

No.	Function	Screw
①	L	M3.5 + / - Screw
②	N	
③	N.C.	
④	SD	RS232C
⑤	RD	
⑥	SG	
⑦	+	M3 + / - Screw
⑧	-	
⑨	E	
⑩		N.C.
⑪		
⑫	RS	RS232C
⑬	CS	



⚠ The input voltage to each terminal is as follows.

Terminal	Phase and wire	Terminal	Input voltage
Operating power supply	Single-phase, two-wire	①-②	100-240VAC (100 - 240V~) (Line voltage)*1

*1. Rated power supply of AKW1000K and AKW1131K is limited to 220V AC.

<AKW1131/AKW1131K>

No.	Function	Screw
①	L	M3.5 + / - Screw
②	N	
③	P1	
④	P0	Measured voltage input
⑤	P2	
⑥	P3	

No.	Function	Screw
⑦	+	M3 + / - Screw
⑧	-	
⑨	E	
⑩	+	Pulse output
⑪	-	
⑫	+	Pulse input
⑬	-	


⚠ The input voltage to each terminal is as follows.

Terminal	Phase and wire	Terminal	Input voltage
Operating power supply	Single-phase, two-wire	①-②	100-240VAC (100 - 240V~) (Line voltage)*1
Measured voltage input	Single-phase, two-wire	③-④	0-440VAC (0-440V~) (Line voltage)
	Single-phase, three-wire	③-④-⑤	0-220VAC (0-220V~ :3W) (Phase voltage)
	Three-phase, three-wire	③-④-⑤	0-440VAC (0-440V 3~) (Line voltage)
	Three-phase, four-wire	③-④-⑤-⑥	0-254VAC (0-254V 3N~) (Phase voltage)


*1. Rated power supply of AKW1000K and AKW1131K is limited to 220V AC.

<M3.5 Screws>

- (1) Terminal fastening torque should be about 1.0 N·m. In case of using a crimping terminal, use it with insulating sleeve applicable to M3.5 screw.
- (2) This has no built-in power switch, circuit breaker for power supply part. To protect the device, it is necessary to install power switch and circuit breaker in the power supply circuit.
And this has no built-in power switch, circuit breaker or fuse for measured voltage input parts. Therefore it is necessary to install them in the circuit near this unit.
- (3) We recommend a wire with the cross section of 0.75 to 1.25mm² for power supply line and measured voltage input line.




(4) Shape of the terminal cover




<M3 screws>

- (1) Terminal fastening torque should be about 0.5 to 0.6 N·m. In case of using a crimping terminal, use it with insulating sleeve applicable to M3 screw.



(2) Shape of the terminal cover




3.2 Wiring Diagrams

Please connect a breaker (3 to 15A) to the voltage input part for safety reasons and to protect the device. Grounding the secondary side of VT (Voltage transformer) and CT (Current transformer) is not necessary with low-voltage circuit.

◆When measuring a load with rated input voltage (100-200V system/ 400V system)

Single-phase two-wire system


*One current transformer (CT) is required.



Do not wire ⑤ ⑥ terminals. They are connected internal.

Single-phase three-wire / Three-phase three-wire system


*Two current transformers are required.



Do not wire ⑥ terminals. They are connected internal.

Three-phase four-wire system

*Three current transformers are required.




◆When measuring a load with exceed input voltage


Voltage transformer (VT) is needed when you measure a load with over rated input voltage (440V).
Use VT, those secondary rating is 110V.

Grounding the secondary side of VT and CT is not necessary with low-voltage circuit.


Single-phase two-wire system



Single-phase, three-wire system
Three-phase, three-wire system



Three-phase, four-wire system



3.3 How to attach the Current Transformer (CT)

• One current transformer (CT) is needed to measure 1P2W system. Two CTs are needed to measure a 1P3W/3P3W system. Three CTs are needed to measure a 3P4W system. Using all CT should be the same.

• Check beforehand that the thickness of the electric wire is smaller than the through-hole of the CT.

• When connecting CT, connect the secondary side to the terminal of the main unit first, and after that wire the primary side to a load electric wire.

Incorrect order might cause an electric shock or break CT.

• The CT has polarity. Wire correctly according to the K and L marks.

Wrong direction can't measure correctly.

• When closing clamp-on type CT, check that there is no foreign materials on the divided face. And make sure it is closed securely once the wire is in place; **if not the measurement value will be not accurate.**

• When CT's cable is extended, it is possible to extend up to about 10m with the cable of AWG#22 or more cross section under the environment without noise at all. Please use the thick cable as much as possible. *Please check beforehand with the actual system in case of extending the cable.

• If there is some distortion by harmonic or waveform, it may not measure correctly. Please check with the actual system before adopting it.

• Separate the wiring (strong electric part) of the measured voltage input terminal (operating power supply terminal) from the CT cable. It may not satisfy the accuracy due to noise.

◇To connect CT with secondary side current 5A


How to connect for measuring by combination with CT (secondary side current 5A)

- (1) Select 5A at CT type setting mode (CT-T).
- (2) Set the primary current of measured CT (secondary side current 5A) at primary side current of CT setting mode (CT-1).
 < ex > If the measured CT is 400A/5A, set to "400".
- (3) Clamp the dedicated CT for 5A, which is connected to the main unit first, to secondary side of the CT (secondary side current 5A). CT direction (K→L) should be set for the commercial CT direction.


***Set the CT (secondary side current 5A) and the dedicated CT for 5A approximately 1m apart. If the two CTs are set too close each other, it may not measure accurately due to magnetic field interference.**

(Connection example)

With Ammeter etc.




Without Ammeter



3.4 For input connection

• Contact input

Use highly reliable metal plated contacts. Since the contact's bounce time leads directly to error in the count value, use contacts with as short a bounce time as possible. In general, select 30Hz for max. counting speed.



• Non-contact input (Transistor input)

Connect with an open collector. Use the transistor with the following specifications. $V_{CE0}=20V$ min. $I_C=20mA$ min. $I_{CBO}=6 \mu A$ max

Use transistors with a residual voltage of less than 1.5V when the transistor is ON.

*Short-circuit impedance should be less than $1k \Omega$.

(When the impedance is 0Ω , drain current is approx. 7mA.)



Open-circuit impedance should be more than $100k \Omega$.

• Input wiring

Please wire as short as possible by using a shielded wire or a metallic electric wire tube individually.


(Note)

Operating power supply input part and measured voltage input are not insulated to pulse input parts. So the input equipment must have the power supply transformer in which the secondary side is not grounded with the primary and secondary sides insulated, in order to prevent interference of the power supply circuit when connecting the external input circuit. Be sure not to use an auto-transformer.



3.5 For Output connection



Since the transistor output is insulated from the internal circuit by a photo-coupler, it can be used both as a NPN output and PNP (equal value) output.



- Wire up to 100m for output connection.
If it is long, it may not work correctly due to floating capacitance of wire.

3.6 RS485 Communication



- When using shielded cable for the RS485 transmission line, ground one end.
Use a class D dedicated earth for grounding. Do not share a ground with other earth lines. (Fig.1)
 - Be sure to connect with daisy chain the RS485 transmission line between each unit.
Do not use a splitter. (Fig.2)
 - With a terminal station, RS485 (E) (No.9) and RS485 (-) (No.8) should be shorted.
- *E terminal is not SG (signal ground) terminal. Do not ground shielded cable.



Recommended Cable

Use the transmission cables shown below for Eco-POWER METER RS485 communication system.

Cable	Conductor		Insulator		Cable diameter	Applicable cable
	Size	Resistance (at 20°C)	Material	Thickness		
Twisted-pair with shield	1.25 mm ² (AWG16) or more	Max.16.8 Ω /km	Polyethylene	Max. 0.5 mm	Approx. 8.5 mm	HITACHI KPEV-S 1.25 mm ² × 1P Belden Inc. 9860
	0.5 mm ² (AWG20) or more	Max.33.4 Ω /km	Polyethylene	Max. 0.5 mm	Approx. 7.8 mm	HITACHI KPEV-S 0.5 mm ² × 1P Belden Inc. 9207
VCTF	0.75 mm ² (AWG18) or more	Max.25.1 Ω /km	PVC	Max. 0.6 mm	Approx. 6.6 mm	VCTF 0.75 mm ² × 2C (JIS)

Cable	Section
Twisted-pair with shield	
VCTF	

Notes

- 1) Use shielded type twist cables.
- 2) Use only one type of the transmission cables.
- 2) Do not mix different types of the cables.
- 3) Use twist pair cables under a bad noise environment.


3.7 RS232C Communication

- When using shielded cable for the RS232C transmission line, the grounding connection should have a resistance of less than 100 ohms, and ground one end.
Do not share a ground with other earth lines. (Fig.1)
- When wiring transmission line, connect by straight connection, it can't transmit by cross connection.
- Set a flow control according to the connected device. If it sets to different, it may not communicate correctly.

3.7.1 Connect to PC


- Use a straight connection when using PC.
- As to the cable, refer to the below wiring diagram.

●Without flow control



* AKR1801 can be used as RS232C cable.
AKW1000(K) terminal block 4:SD(red), 5:RD(white), 6:SG(blue)

●With flow control



3.7.2 Connect to PLC

● Connect to Web Datalogger Unit / FPΣ control unit

In order to connect to KW1M-R master, attach FPΣ communication cassette to Web Datalogger Unit (DLU) or FPΣ control unit.

Communication cassette to use (RS232C communication type)

Name	Part No.	Model No.
FPΣ communication cassette (RS232C 1CH type)	FPG-COM1	AFPG801
FPΣ communication cassette (RS232C 2CH type)	FPG-COM2	AFPG802
FPΣ communication cassette (RS485 1CH/ RS232C 1CH type)	FPG-COM4	AFPG806


● AFPG801



AKW1000(K) terminal block

Pin No.	Signal name
4	SD
5	RD
12	RS
13	CS
6	SG

Pin name
SD
RD
RS
CS
SG



● AFPG802




Without flow control

AKW1000(K) terminal block

Pin No.	Signal name
4	SD
5	RD
12	RS
13	CS
6	SG

Pin name
S1
R1
S2
R2
SG



● AFPG806




Without flow control

AKW1000(K) terminal block

Pin No.	Signal name
4	SD
5	RD
12	RS
13	CS
6	SG

Pin name
+
-
SD
RD
SG




● Connect to FP-X control unit

In order to connect to KW1M-R master, attach communication cassette to FP-X control unit.


Communication cassette to use (RS232C communication type)

Name	Model No.
FP-X COM1 communication cassette (RS232C 1CH type)	AFPX-COM1
FP-X COM2 communication cassette (RS232C 2CH type)	AFPX-COM2
FP-X COM4 communication cassette (RS485 1CH/ RS232C 1CH type)	AFPX-COM4
FP-X COM5 communication cassette(Ethernet 1CH/ RS232C 1CH type)	AFPX-COM5


●AFPX-COM1




●AFPX-COM2



●AFPX-COM4




●AFPX-COM5



Chapter 4 Settings

4.1 AKW1000 /AKW1000K Setting procedures

- Mode 1: Mode for Wireless communication
- Mode 2: Mode for communication test
- Mode 3: Mode for Serial communication
- Mode 4: Mode for Optional function



Press <MODE> to return Monitor.

*1 Communication channel setting mode and Upper communication recognition time setting mode are only when 'MAST' is selected on Master/Slave setting mode.

*2 Communication test mode is available for the unit version 2.0 or later.

◆ Initial value list

Mode 1		Mode 2	
Item	Initial value	Item	Initial value
Master/Slave	MAST	Test select	TEST1
Group	0		
Communication channel	AUTO		
Communication style	1-N		

Mode 3		Mode 4	
Item	Initial value	Item	Initial value
Protocol	MEWTOCOL	Auto-off	0
Transmission speed	19200	Display	Group number
Transmission format	8bit-o	Initialize communication setting	OFF
Communication port	RS232C	Field intensity monitor	STOP
Delimiter time of data by wired side	10	Calendar	January 1 st , 2000 00:00
Upper communication recognition time	2		
Flow control	OFF		

4.2 AKW1000 /AKW1000K Setting Mode Explanation

■ The value with underline is initial setting among each setting value. ☆ Set before measurement.

4.2.1 MODE1 (Mode for setting each parameter for wireless communication.)

Master/Slave setting mode TYPE

Mode defines unit's type.

- Select from Master(MAST)/Slave(SLAV).
- In case using a master unit as a repeater, select Slave(SLAV).
- When changing the type, the unit will restart.

Group setting mode Gr

Mode defines group of network.

- It can be set the range of 0 to 255.

Communication channel setting mode CH

*Only when "MAST" is selected on master/slave setting mode.

Mode defines channel of network.


- It can be set from AUTO and the range of 1 to 16.
- In case selecting AUTO, it selects a vacant channel automatically and connects.
It will change channel automatically when the connection with a slave is cut for 10 minutes in the same network.

Communication style setting mode STYL

Mode defines communication style.

- Select from 1-N/1-1.
- Normally, select "1-N". As to "1-1", refer to 5.4.9 Use as wireless unit.

Mode1 Setting flow chart



4.2.2 MODE2 (Communication test mode)

Test select mode **TEST**

Mode selects TEST1 or TEST2 for communication test.

• Select from TEST1(LQI test) or TEST2(data communication test).

Test mode **TEST1 TEST2**

Mode to start the test selected.

• When "TEST1" is selected, select the station number to test and check the wave(LQI).

• When "TEST2" is selected, select the station number to display on the master.


*It can't communicate from the upper during test mode.

*LQI of AKW1000(K) (repeater) working with SLAV mode is not displayed with TEST1.

*It judges automatically according to the communication history.


*Mode2 Communication test mode is available for the unit version 2.0 or later.

Mode2 Setting flow chart



Test select mode

Press <ITEM/Δ><SHIFT/▽> to change TEST1 and TEST2.




↓ <SET>

<When "TEST1" is selected>

Press <ITEM/Δ><SHIFT/▽> to select station number to get LQI.


It is different the range of station number according to the protocol selected with mode 3.




(When "MEWTOCOL" is selected: 1 to 99)
 (When "MODBUS" is selected: 1 to 247)

↓ <SET>

After selecting the station number and press <SET>, LQI will be displayed.
 LQI is updated every 1 second.
 If it is impossible to get LQI, it will return to the monitor.



↓ <SET>



<When “TEST2” is selected>

Press <ITEM/Δ><SHIFT/▽> to select station number to get data.




(When “MEWTOCOL” is selected: 1 to 99)
 (When “MODBUS” is selected: 1 to 247)

↓ <SET>

After selecting the station number and press <SET>, item selection window will be displayed.
 If it is impossible to get any data, it will return to the monitor.

[KW1M-R, No communication history]



At the display of each item, press <SET> to display each data. If the selected number is not connected, [-----] will be displayed.

↓ <SET>

Monitor

4.2.3 MODE3 (Mode for setting of each parameter for serial communication)

Protocol setting mode **PROT**

Mode defines communication protocol of main unit via serial communication.

- Select from MEWTOCOL / MODBUS(RTU).

Transmission speed (Baud rate) setting mode **SPD**

Mode defines serial communication transmission speed. Define the transmission speed according to the master's (PLC etc.).

- Select from 19200/ 38400/ 57600/ 115200/ 1200/ 2400/ 4800/ 9600 [bps].

Transmission format setting mode **FMT**

Mode defines serial communication transmission format (Data length, Parity). Define the transmission format according to the master's (PLC etc).

- Select from 8bit-o/7bit-n/7bit-E/7bit-o/8bit-n/8bit-E.
- “n (none)” means parity is not available.
- “E (Even)” means parity is even number.
- “o (odd)” means parity is odd number.
- *With MODBUS(RTU) protocol, it works only with 8bit.

Communication port setting mode **PORT**

Mode defines communication port via serial communication.

- Select from RS232C / RS485.

Delimiter time of data by wired side setting mode **DTIM**

Mode defines vacant letter number to use for judgment completion of wired communication.

(Refer to 5.4.6)

- It can be set the range of 4 to 20. (Initial: 10)

Upper communication recognition time setting mode **UTIM**

Mode defines time to use for judgement if terminal equipment is connected by multi-dropped to RS485 port or not. (Refer to 5.4.7)

When it receives data of the same station number from RS485 port within the setting time, after that it doesn't send by wireless.

- It can be set the range of 1 to 3000 (100ms to 300s). (Initial: 2)


Flow control setting mode **FLOW**

Mode defines an existence of hardware flow control during RS232C communication.

Flow control means that it controls timing of sending data to delay or stop in order to prevent data incompleteness when a device doesn't send data due to another process.

- If flow control is executed, the other device need to support flow control.
- Select from OFF / ON. Select ON and press <SET> to execute flow control.

Mode3 Setting flow chart



Protocol setting mode
 Press <ITEM/Δ><SHIFT/▽> to change MEWTOCOL ⇔ MODBUS(RTU).

↓ <SET>

Transmission speed setting mode
 Press <ITEM/Δ><SHIFT/▽> to change 19200⇔38400⇔57600⇔115200⇔1200⇔2400⇔4800⇔9600.

↓ <SET>

Transmission format setting mode
 Press <ITEM/Δ><SHIFT/▽> to change 8bit-o ⇔ 7bit-n ⇔ 7bit-E ⇔ 7it-o ⇔ 8bit-n ⇔ 8bit-E.

↓ <SET>

Communication port setting mode
 Press <ITEM/Δ><SHIFT/▽> to change 232 ⇔ 485.

↓ <SET>

Delimiter time of data by wired side setting mode
 Set letter's number to use for judgment of completing using <ITEM/Δ><SHIFT/▽>.

(4 to 20, initial: 10)

↓ <SET>

Upper communication recognition time setting mode

Set the recognition time using <ITEM/Δ><SHIFT/▽>.




(1 to 3000, initial:2)

↓ <SET>

Flow control setting mode

Press <ITEM/Δ><SHIFT/▽> to select OFF ↔ ON.



Initial: OFF

Select "ON" and press <SET> to do flow control.

↓ <SET>

Monitor

4.2.4 MODE4 (Mode for setting of each parameter for optional function)

Auto-off setting mode OFF

Display back light turns off automatically when there is no key operation for a long time.

- Off time can be set the range of 0 to 99min.
- "0" should be set if you want to turn always light on.
- "1 to 99" should be set if you want to turn light off at setting time.
- After turns off the back light, any key operation makes it turns on.
- After turns off the back light, only power indicator turns on.

Display setting mode DISP

Mode defines display when starting unit.

- In case selecting "Master" on Master/Slave setting mode:
Select from Group number (Gr)/Channel (CH)/Calendar (CAL)
- In case selecting "Slave" on Master/Slave setting mode:
Select from Group number (Gr)/Field intensity (LQI)/Calendar (CAL)

Initialize communication setting INIT

Use to initialize the settings regard to communication (except calendar timer).

- Select OFF and press <SET>, it doesn't initialize.
 - Select ON and press <SET>, it initialize the settings regard to communication.
- *During initialization, [-----] is displayed. While [-----] is displayed, do not turn off the power supply.

Field intensity monitor RSSI

Mode to check if the communication channel that intend to use is used by another wireless device or not.

- Select from STOP / START.
- Select START and press <SET>, it start monitoring.
- At the initial, 'ALL' is displayed and it monitors all channels automatically.
- In order to fix monitoring channel, set the range of 1 to 16 CH. (Display: Left)
- It displays field intensity of selected channel. (Display: Right)
- It is good intensity to approach "0". (Display range: 0 to 70)

*It can't communicate with wireless during monitoring.

*During monitoring, stop sending data from master.

Calendar timer setting mode **CAL**

Mode defines the year, month, day and time.

- Set year -> month -> date -> hour-> minute.
- It can be set the range of 2000 Jan. 1st 00:00 to 2099 Dec. 31st 23:59.

*Do not set the false date, or it might occur a malfunction.

*Be sure to set the calendar timer because it records a happening time with an error log.

Mode4 Setting flow chart

Monitor

↓ <MODE> (MODE 4 Lighting)

↓ <SET>

Auto-off setting mode

Set auto-off time by minute using <ITEM/Δ><SHIFT/▽>.

(0 to 99)

“0” should be set to turn always light on.

“1~99” should be set to turn light off at setting time (minute).

While light off, press any key to light on.




↓ <SET>

Display setting mode

Press <ITEM/Δ><SHIFT/▽> to change display when starting.

- Master(MAST): Group number (Gr) ⇔ Channel (CH) ⇔ Calendar (CAL)
- Slave(SLAV): Group number (Gr) ⇔ Field intensity (LQI) ⇔ Calendar (CAL)




↓ <SET>

Initialize communication setting

Press <ITEM/Δ><SHIFT/▽> to change OFF/ON.

Initial: OFF Select “ON” and press <SET> and the settings are initialized.



Error log is also initialized, read out the error log by KW Network Monitor if needed.

↓ <SET>

Field intensity monitor (RSSI)

Press <ITEM/Δ><SHIFT/▽> to select STOP⇔START.

Initial: STOP
Select "START" and press <SET> to start monitoring.

After press <SET>, 'ALL' is displayed and it monitors all channels of 1 to 16CH automatically.
In order to fix monitoring channel, set channel using <ITEM/Δ><SHIFT/▽>.

↓ <SET>

Calendar timer setting mode

Set the present time using <ITEM/Δ><SHIFT/▽>, and <SET>.
(2000/1/1 00:00 to 2099/12/31 23:59)

CAL

[2009] Blinking (Set year) [01] Blinking (Set month)


[01] Blinking (Set day) [00] Blinking (Set hour) [00] Blinking (Set minute)

↓ <SET>

Monitor

4.3 AKW1131 /AKW1131K Setting procedure


Mode 1...Mode for setting each parameter for power measurement



Press <MODE> to return Monitor.

Note) Press <MODE> and <SET> at the same time, the setting will be initialized.

Mode 2...Mode for setting of each parameter for pulse measurement
 Mode 3...Mode for setting of each parameter for serial communication
 Mode 4...Mode for setting of each parameter for optional function



Press **<MODE>** to return Monitor.
 Note) Press **<MODE>** and **<SET>** at the same time, the setting will be initialized.

*1 Group setting mode, Initialize communication setting, Field intensity monitor are available only when "Wireless" is selected with Wired/Wireless setting mode.
 *2 Wired/Wireless setting mode is available only for Ver.2.2 or more.

◆ Initial value list

Mode 1		Mode 2	
Item	Initial value	Item	Initial value
Phase/Wire system	1P2W	Max. counting speed	2000
CT type	50		
Primary side current of CT	5	Prescale	1.000
Voltage range	400		
VT	1.00		
Current for time measurement	1.0	Mode 3	
Cutoff current	1.0	Item	Initial value
Unit for pulse output	0.001	Wired/Wireless	WIRELESS
Power alarm	9999.99	Protocol	MEWTOCOL
Current alarm	100.0	Station number	1
Stand-by alarm1	100.00	Transmission speed	19200
Stand-by alarm 2	0	Transmission format	8bit-o
Preset value	0	Response time	1
Electricity rate	10.00	Delimiter time of data by wired side	10
Conversion factor	0.410	Group	0

Mode 4	
Item	Initial value
Auto-off	0
Initialize communication setting	OFF
Field intensity monitor	STOP

4.4 AKW1131 /AKW1131K Setting Mode Explanation

■ The value with under line is initial setting among each setting value. ☆ Set before measurement.

4.4.1 MODE1 (Mode for setting each parameter for power measurement.)

Phase/Wire system setting mode SYST

Mode defines phase and wire system to measure.

- Select from Single-phase 2-wire / Single-phase 3-wire / Three-phase 3-wire / Three-phase 4-wire.
Select the system of the measured load.

CT type setting mode CT-T

Mode defines input current type of the dedicated CT.

- Select from the type of 5A/50A/100A/250A/400A/600A.
- When the secondary current of CT is 5A, select "5A".

Primary side current of CT setting mode CT-1

**Only when "5A" is selected on CT type setting mode.*

Mode defines primary side current when measuring by combination with existing CT, its secondary current of 5A.

It is possible to use as the second step for combination with existing CT by selecting "5A" in the CT type setting mode. In this case, it is necessary to set the primary side current.

- Primary side current of the existing CT can be set the range of 1 to 4000 (Initial 5).
- When connecting 5ACT directly and measure with 5A range, set to "5".
ex) If primary current of measured existing CT is 400A(secondary side is 5A), set to "400".

Voltage range setting mode VOLT

Mode defines voltage range of Eco-Power Meter.

- Select from 400/200.
- When it measures load of 400V system, select "400".
When it measures load of 100/200V system, select "200".

**In case measuring the load of 100/200V system with selecting "400", the resolution will be down.
Select the correct voltage range.*

VT setting mode VT

Mode defines voltage input method to the main unit, input voltage directly or uses a voltage transformer (VT) (over 440V system).

- It can be set the range of 1.00 to 99.99.
"1.00" should be set when voltage input directly without connecting VT.
"1.01 to 99.99" should be set when VT is used to input voltage.

Current for time measurement setting mode HM-A

Mode defines for time measured current. It measures ON-time and OFF-time by setting value.

- It can be set the range of 1.0% to 100.0%F.S.
ex) When 10.0 is set, the current exceeds 10.0%F.S is measured as ON-time, the current under 10.0%F.S is measured as OFF-time.
**Measured current is the current of CT1.*

Cutoff current setting mode CUTA

Mode defines load current that does not measure (Cutoff current).

Use to avoid miss-measurement by wiring or induction noise at no-load.

0.00kW is displayed for instantaneous electric power, 0.0A is displayed for current. Integrated electric power is not added.

- It can be set the range of 1.0% to 50.0%.
ex) When set to 10.0, current (=power) under 10.0%F.S is not added.

Unit for pulse output setting mode **PL-P**

Mode defines unit used for pulse output. It defines the unit of integrated electric power for 1-pulse output.

• Select from 0.001/0.01/0.1/1/10/100kWh /AL-P/AL-C/AL-S/Cnt.

When one of the “0.001/0.01/0.1/1/10/100” [kWh] is set, one pulse is output at reaching the setting value.

When “AL-P” is set, alarm is output at the time when instantaneous electric power is over the setting value.

When “AL-C” is set, alarm is output at the time when current is over the setting value.

When “AL-S” is set, alarm is output at the time when current is under the setting value and it passes the setting time.

When “Cnt” is set, it output at the time when count value reaches preset value set by preset value setting mode.

Power alarm setting mode **AL-P**

**Only when “AL-P” is selected on unit for pulse output setting mode.*

Mode defines instantaneous electric power used for alarm output.

• It is set the range of 0.00 to 9999.99kW.

Current alarm setting mode **AL-C**

**Only when “AL-C” is selected on unit for pulse output setting mode.*

Mode defines the ratio of current used for alarm output. (Ratio for the rated current)

• It is set the range of 1.0 to 100.0%.

Stand-by alarm setting mode 1 **AL-S1**

**Only when “AL-S” is selected on unit for pulse output setting mode.*

Mode defines the ratio of current used for threshold value to judge stand-by power. (Ratio for the rated current)

• It is set the range of 1.0 to 100.0%.

Stand-by alarm setting mode 2 **AL-S2**

**Only when “AL-S” is selected on unit for pulse output setting mode.*

Mode defines the time used for threshold value to judge stand-by power.

• It is set the range of 0 to 9999min.

When “0” is set, alarm is always output at the time when judging the stand-by power.

When “1 to 9999” is set, alarm is output at the time when passing the setting time with the stand-by power.

The alarm can be reset by pressing <SET> with the instantaneous electric power display. After reset the alarm, start to monitor the stand-by power again.

Preset value setting mode **Cnt**

**Only when “Cnt” is selected on unit for pulse output setting mode.*

Mode defines count value used for output.

• It is set the range of 0(0.000) to 999999(999.999).

**The range differs according to the pre-scale set by pre-scale setting mode.*

Electricity charge setting mode **RATE**

Mode defines electricity charge ratio used as a standard per 1kWh.


• It can be set the range of 0.00 to 99.99 /1kWh. (Initial 10.00)

Conversion factor setting mode **CO2**

Mode defines conversion factor of carbon dioxide used as a standard per 1kWh.

• It can be set the range of 0.000 to 9.999/1kWh. (Initial 0.410)

Mode1 Setting flow chart



Phase/Wire system setting mode

Press <ITEM/Δ><SHIFT/▽> to change Single-phase 2-wire ⇔ Single-phase 3-wire ⇔ Three-phase 3-wire ⇔ Three-phase 4-wire.

↓ <SET>

CT type setting mode

Press <ITEM/Δ><SHIFT/▽> to change 50 ⇔ 100 ⇔ 250 ⇔ 400 ⇔ 600 ⇔ 5.

↓ <SET>

Primary side current of CT setting mode *It is only when "5A" is selected on CT type setting mode.

Set primary side current of CT using <ITEM/Δ><SHIFT/▽>.

If measured CT is 100A/5A, set to 100. If 5A is measured, set to 5.

(1 to 4000, Initial 5)

↓ <SET>

Voltage range setting mode

Press <ITEM/Δ><SHIFT/▽> to change 400V ⇔ 200V.

↓ <SET>

VT ratio setting mode

Set VT ratio using <ITEM/Δ><SHIFT/▽>. If the VT is 440/110, set to "4.00".

(1.00 to 99.99)

↓ <SET>

Current for time measurement setting mode

Set ratio of current for time measurement using <ITEM/Δ> <SHIFT/▽>.
If you measure the current over 50.0%F.S, set to "50.0".

MODE

HM-A

10

(1.0 to 100.0)

↓ <SET>

Cutoff current setting mode

Set cutoff current ratio using <ITEM/Δ> <SHIFT/▽>.
If you don't measure the current under 10.0%F.S, set to "10.0".

MODE

CUTR

10

(1.0 to 50.0)

↓ <SET>

Unit for pulse output setting mode

Press <ITEM/Δ><SHIFT/▽> to change 0.001 ⇔ 0.01 ⇔ 0.1 ⇔ 1 ⇔ 10 ⇔ 100 ⇔ AL-P (Power alarm) ⇔ AL-C (Current alarm) ⇔ AL-S (Stand-by alarm) ⇔ Cnt (Count output).

MODE

PL-P

0.001

0.001

MODE

PL-P

0.01

0.01

MODE

PL-P

0.1

0.1

MODE

PL-P

1

1

MODE

PL-P

10

10

MODE

PL-P

100

100

MODE

AL-P

AL-P

AL-P

MODE

AL-C

AL-C

AL-C

MODE

AL-S

AL-S

AL-S

MODE

Cnt

Cnt

Cnt

↓ <SET>

Power alarm setting mode *It is only when "AL-P" is selected on unit for pulse output setting mode.

Set power for alarm using <ITEM/Δ><SHIFT/▽>.

MODE

AL-P

9999.99

(0.00 to 9999.99)

↓ <SET>

Current alarm setting mode *It is only when "AL-C" is selected on unit for pulse output setting mode.

Set current ratio (for the rated current) for alarm using <ITEM/Δ><SHIFT/▽>.

MODE

AL-C

1000

(1.0 to 100.0)

↓ <SET>

Stand-by alarm setting mode 1 *It is only when "AL-S" is selected on unit for pulse output setting mode.

Set a ratio (for the rated current) of current used for threshold value to judge stand-by power using <ITEM/Δ><SHIFT/▽>.

MODE

AL-S

1 1000

(1.0 to 100.0)


↓ <SET>

Stand-by alarm setting mode 2

*It is only when "AL-S" is selected on unit for pulse output setting mode.

Set a time used for threshold value to judge stand-by power using <ITEM/Δ><SHIFT/▽>.

(0 to 9999 min.)



"0": Alarm is always output at the time when judging the stand-by power.

"1 to 9999": Alarm is output at the time when passing the setting time with the stand-by power.

The alarm can be reset by pressing <SET> with the instantaneous electric power display.


After reset the alarm, start to monitor the stand-by power again.

↓ <SET>

Preset value setting mode

*It is only when "Cnt" is selected on unit for pulse output setting mode.

Set preset value to output using <ITEM/Δ><SHIFT/▽>.



(0 to 999999)

↓ <SET>

Electricity charge setting mode

Set the rate per 1kWh using <ITEM/Δ><SHIFT/▽>.



(0.00 to 99.99 Initial: 10.00)

↓ <SET>

Conversion factor setting mode

Set the conversion factor per 1kWh using <ITEM/Δ><SHIFT/▽>.



(0.000 to 9.999 Initial: 0.410)

↓ <SET>


Monitor

4.4.2 MODE2 (Mode for setting of each parameter for pulse measurement)**Max. counting speed setting mode** **Hz****Mode defines max. counting speed.**

- Select from 2000Hz(2kHz)/30Hz

Pre-scale setting mode **PSCL****Mode defines pre-scale value used for changing count value.**

- It can be set the range of 0.001 to 100.000. (Initial 1.000)
- The position of decimal point set with this mode is applied to count value and preset value.
ex) When 0.01 (Last 2-digit) is set, the decimal point of count value and preset value has 2 digit under decimal point.

Mode2 Setting flow chart

4.4.3 MODE3 (Mode for setting of each parameter for serial communication)**Wired/Wireless setting mode** **FORM**

Mode defines communication style wired or wireless.

- Select from WIRELESS / WIRED.

Protocol setting mode **PROT**

Mode defines communication protocol of main unit via serial communication (RS485).

- Select from MEWTOCOL / MODBUS(RTU).

Station number setting mode **NO**

Mode defines an individual station no. for each unit when two or more units communicate via serial communication (RS485).

- It can be set the range of 1 to 99.

Transmission speed (Baud rate) setting mode **SPD**

Mode defines serial communication (RS485) transmission speed.

Define the transmission speed according to the master's (PLC etc.).

- Select from 2400 / 4800 / 9600 / 19200 / 38400 [bps].

Transmission format setting mode **FMT**

Mode defines serial communication (RS485) transmission format (Data length, Parity).

Define the transmission format according to the master's (PLC etc.).

- Select from 8bit-o/7bit-n/7bit-E/7bit-o/8bit-n/8bit-E.

“n (none)” means parity is not available.

“E (Even)” means parity is even number.

“o (odd)” means parity is odd number.

*With MODBUS(RTU) protocol, it works only with 8bit.

Response time setting mode **RESP**

Mode defines serial communication (RS485) response time of main unit.

When command is received, it sends response after setting response time passes.

- It can be set the range of 1 to 99 ms.

Delimiter time of data by wired side setting mode **DTIM**

Mode defines vacant letter number to use for judgment completion of wired communication.

***Normally, it is not necessary to change.**

- It can be set the range of 4 to 20. (Initial: 10)

Group setting mode **GR**


*Only when “WIRELESS” is selected on Wired/Wireless setting mode.

Mode defines group of network.

- It can be set the range of 0 to 255.


- Set the group number of the master's number that is intended to communicate.

Mode3 Setting flow chart



Transmission format setting mode

Press <ITEM/Δ><SHIFT/▽> to change 8bit-o ⇔ 7bit-n ⇔ 7bit-E ⇔ 7it-o ⇔ 8bit-n ⇔ 8bit-E.



↓ <SET>

Response time setting mode

Set the response time using <ITEM/Δ><SHIFT/▽>.



↓ <SET>

Delimiter time of data by wired side setting mode

Set letter's number to use for judgment of completing using <ITEM/Δ><SHIFT/▽>.



↓ <SET>

Group setting mode

Set group number using <ITEM/Δ><SHIFT/▽>.



↓ <SET>

Monitor

4.4.4 MODE4 (Mode for setting of each parameter for optional function)

Auto-off setting mode **OFF**

Display back light turns off automatically when there is no key operation for a long time.

- Off time can be set the range of 0 to 99min.
- “0” should be set if you want to turn always light on.
- “1~99” should be set if you want to turn light off at setting time.
- After turns off the back light, any key operation makes it turns on.
- After turns off the back light, only power indicator turns on.

Initialize communication setting **INIT**

**Only when “WIRELESS” is selected on Wired/Wireless setting mode.*

Use to initialize the settings regard to communication (MODE3).

- Select OFF and press <SET>, it doesn't initialize.
- Select ON and press <SET>, it initialize the settings regard to communication.

Field intensity monitor **RSSI**

**Only when “WIRELESS” is selected on Wired/Wireless setting mode.*


Mode to check if the communication channel that intend to use is used by another wireless device or not.

- Select from STOP / START.
- Select START and press <SET>, it start monitoring.
- At the initial, ‘ALL’ is displayed and it monitors all channels automatically.
- In order to fix monitoring channel, set the range of 1 to 16 CH. (Display: Left)
- It displays field intensity of selected channel. (Display: Right)
- It is good intensity to approach “0”. (Display range: 0 to 70)

**It can't communicate with wireless during monitoring.*


**During monitoring, stop sending data from master.*

Mode4 Setting flow chart



Field intensity monitor (RSSI)

*It is only when "WIRED" is selected on Wired/Wireless setting mode.

Press <ITEM/Δ><SHIFT/▽> to select STOP⇔START.Initial: STOP

Select "START" and press <SET> to start monitoring.



After press <SET>, 'ALL' is displayed and it monitors all channels of 1 to 16CH automatically.
 In order to fix monitoring channel, set channel using <ITEM/Δ><SHIFT/▽>.

↓ <SET>

Monitor


Chapter 5 Various Functions

5.1 LOCK mode

It is the mode makes all keys unable. Use when you want to fix one of the measurement displays (For all displays). In this mode, you can not input by any keys.

When you press <SET> continuously for about 3sec., the "LOCK" indicator lights and all keys become locked (pressing them will have no effect).


Press <SET> continuously for about 3sec. again to release Lock mode. The "LOCK" indicator goes off and the lock mode is released (unlocked).



5.2 Pulse output function

Refer to the mode 1 setting for the way to set.

"OP." indicator is lighting when pulse output.



5.2.1 Output depends on integrated electric power

Set the unit for pulse output (0.001/0.01/0.1/1/10/100kWh) and pulse output (transistor output) turns on every time when integrated electric power reaches the unit. (Pulse width: about 100ms)

5.2.2 Instantaneous electric power alarm

When it exceeds the setting instantaneous electric power, pulse output (transistor output) turns on in order to notice. When it falls below, the output turns off.

5.2.3 Current alarm

When it exceeds the setting current ratio, pulse output (transistor output) turns on in order to notice. When it falls below, the output turns off.


5.2.4 Stand-by power alarm

When it detects stand-by power (current) of the measured load, pulse output (transistor output) turns on in order to notice.


Set current (C) and stand-by time (T) to judge stand-by power.

When the measured load is satisfied the setting conditions, pulse output (transistor output) turns on in order to notice.

You can reset the alarm by pressing <SET> with the instantaneous electric power display.



(Working flow chart)




5.2.5 Output depends on count value

Set the preset value and pulse output (transistor output) turns on the time when count value reaches the preset value.

5.3 Counter function

5.3.1 Operation mode

Maintain output hold count **HOLD**



- (1) Output control is maintained after count-up completion and until reset. However counting is possible despite of count-up completion.
- (2) It reverts "0" after counting up full scale, but output control is maintained. However output is OFF if count value or preset value is changed.

5.3.2 Change the Preset Value

It is possible to change the preset value even during counting. However note the following points.

◇When the pre-scale value is "1.000". (PSCL=1.000)

- (1) If the preset value is changed to the value less than the count value, counting will continue until it reaches full scale, returns to "0" and then reaches the new preset value.
- (2) If the preset value is changed to "0", it will not count up at start with "0". It counts up when the counting value comes to "0" again (after reach to full scale). However output is OFF if count value or preset value is changed.
- (3) When the count value is fixed, output is changed according to the changing of preset value as below.
 - ① If the preset value is changed to the value less than the count value or same as count value, output is ON. (Count value \geq Preset value)
 - ② If the preset value is changed to the value more than the count value, output is OFF. (Count value $<$ Preset value)

◇When the pre-scale is not "1.000". (PSCL \neq 1.000)

Even if the preset value is changed after counting to full scale, output is not changed.

5.4 Wireless functions

This is explanation about wireless functions of KW1M-R.

Start master device (PLC, DLU etc.) after completing the settings.

If starting working such as command sending during settings, it might not execute wireless communication correctly.

5.4.1 System configuration

■ 1:N topology


It is the system with 1 unit of master and several units of slaves.

In case of using repeaters, it will build up wireless network automatically. Therefore, you don't need to consider repeaters' mounting.

Mount AKW1131(K) to the place where measure an electric power and confirm the network completion by LQI mode. When it doesn't complete network or LQI is under 10, adjust the mounting place and the antenna angle. When it still doesn't complete network, confirm by KW Network Monitor.

If radio wave doesn't reach the place, mount a repeater to the no blind place between the master and the slave. Both of AKW1000(K) and AKW1131(K) can be used as a repeater.

When adding the measuring point, use AKW1131(K). When using only repeater function, use AKW1000(K).



■ 1:N topology (Multi-dropped connection with master)


It is the system with 1 unit of master and several units of slaves and several terminals connected to the master device by wire.

In this system, it doesn't communicate with wireless to the terminal equipments No.1 and No.2.

When the response speed from multi-dropped connection terminals is low, it is necessary to change the setting of "upper communication recognition time (UTIM)". (When using KR10 wireless unit. When response speed from terminal equipments is low.)

Normally it is not necessary to change initial value, 200ms. Refer to [5.4.7 Upper communication recognition time](#).

【Master: 1 unit Slave: Several units RS485 Multi-drop】




In order to use the below system, set "WIRED" with Wire/Wireless setting mode.


Notice that this can't work with wireless mode.

When you acquire the data of slaves directly, use with wired mode. If not, it might occur malfunction.


【Direct connection between master device and slave unit (AKW1131(K))】



【Parallel connection between master unit (AKW1000(K)) and slave unit (AKW1131(K))】



5.4.2 Initial setting flow for wireless



<Note> This product builds up a network automatically. When 2 or more networks are used, be sure to set group number different. It can't specify whether it build up network with which master unit if there are several master units of same group number within the same communication area.

5.4.3 Check radio wave environment

You can check if other wireless device uses the communication channel that you want to use or not.

It is convenient when examining the communication channel of KW1M-R.


Check at the all place where a master and slaves are mounted. If other wireless device uses the same frequency, it may not communicate. Power on only the units to use field intensity monitor function.

It also receives from other units' radio wave, therefore it disturbs to check vacant channels.

It monitors simply by using rough time period in this function. When you need measuring correctly, use a commercial spectrum analyzer.

■ Field intensity monitor (RSSI) procedures

1. Press <MODE> with monitor display to display "MODE 4".
(Press 3 times for AKW1000(K), 4 times for AKW1131(K))
2. Press <SET> to display Field intensity monitor (RSSI).




3. After appearing RSSI, press <ITEM/SHIFT> to change “STOP⇄”START”.

Select “START” and press <SET>. After set, “ALL” is displayed for 3 seconds and it monitors all channels (1 to 16ch) in order. The displayed value is an instantaneous value, therefore in order to examine a using channel, keep monitoring for a while and check a vacant channel.

In order to fix monitoring channel, enter channel to monitor using <ITEM/SHIFT>. When changing channel, it start monitoring the changed channel again.

*Select “STOP” and press <SET> to move next display, when you don't start monitoring.

Press <MODE> to return monitor.



After getting the result from field intensity monitor, use a channel with the RSSI value close to “0”.

When a problem such that it can't communicate wireless, it can't build up network etc is happened, confirm the surrounding radio wave environment by the field intensity monitor.

<Note>

1. Even though RSSI value is good at the time when checking by field intensity monitor before mounting, the channel might become impossible to be used because another wireless device uses the channel during running.
2. Even though RSSI value is high, it has a possibility to be able to communicate. However, it might be interference of the communication.
3. Consider the communication channel again when introduce another new wireless device.
4. When the channel is set to “AUTO”, it is possible to recover the communication if the channel is blocked by interfering wave.
5. During field intensity monitoring, it can't transmit data. After stop sending data from upper, start monitoring. It might cause malfunctions.

5.4.4 Network construction

*** In order to construct wireless network, it is necessary to set the below items.**

This product builds up network automatically by adjusting group.


【AKW1000(K)】

- Master/Slave setting mode (*1)
- Group setting mode
- Communication channel setting mode

【AKW1131(K)】

- Group setting mode

*1: AKW1000(K) works as a master or a slave. (It doesn't have measurement functions.)



■ Network construction procedures

Follow the below procedures to build up network.

1. Prepare the using units (AKW1000(K), AKW1131(K)) on the table.
(Be sure to confirm to complete settings on the table.)


AKW1000(K)	<ul style="list-style-type: none"> • Master/Slave setting * • Group setting • Communication channel setting
AKW1131(K)	<ul style="list-style-type: none"> • Group setting

2. Power on all units.
3. Set the right items.
 - Set to same group number for master and slave.
 - Select communication channel of master.

*When AKW1000(K) is set as a slave, it is not necessary to set a communication channel.
4. Confirm a completion the network construction of all units that set to same group number. When no error “ERR13 (Unidentified network error)” is displayed on slaves, the network construction is completed.
5. After checking the completion of setting, power off all units.
6. After mounting to the place where is intended to use and connecting terminal equipment, power on the master unit. Power on all slaves from a slave near to the master in order.
7. Confirm the connection by using LQI (Field intensity) of each slave. (15 or more is recommended.) If it is under 10, adjust the unit position or antenna angle. When isn't still improved, check the network by using Network Monitor and mount a repeater between the slave and the master. (Refer to 5.4.8)
8. At last, power on the master device (PLC, DLU etc.) of the network. If a master device sends data during construction of network, it may cause malfunctions.
 - *When unit is added, set the group number same as existing unit and mount the place.
 - With the added unit, check that LQI is the recommended value (15) or more.
 - *If leave LQI display during wireless communication, the communication will be unstable.
 - Shift to LQI display only when checking field intensity.


■ Communication channel (AUTO)

1. [When using fixed channel 1ch]



In case of using fixed channel 1ch, if other equipment uses the same frequency as 1ch, 1ch is blocked and it might not be able to communicate.

2. [When using channel AUTO]



In case of selecting “AUTO”, if other equipment used the same frequency as 1ch, 1ch is blocked but it select other channel with good radio wave from 2 to 16 ch and it is possible to communicate.

When it set to “AUTO”, the master will change channel at 10 minutes after it becomes unusable. Therefore, when the using channel is blocked it might not receive data for 10 minutes. If network is recovered once during changing, there is a possibility that the master doesn't change channel over 10 minutes.

If communication error happens frequently, check the radio wave environment by using field intensity monitor. At the time when it changes the channel, it will cut the network one time.

In order to check communication channel, use the field intensity monitor (RSSI) function, KW Network Monitor or a spectrum analyzer.

5.4.5 Wired communication settings

After completing wireless network constructions, set communication settings with connected devices.

It is necessary to set the communication settings between an upper device and a master, and between slaves and terminal equipments. Initial settings are 19200bps, 8bit, Odd.

*It is not necessary to communication settings of AKW1131(K), when no terminal equipment is connected to the slave (AKW1131(K)).

*When data size is larger than 256byte, set baud rate of slaves to 9600bps or more.

If the slave needs much time to wire communication, it makes timeout of master and there is a possibility not to be able to communicate.

*When data size of response is large for the command and the slaves baud rate is low, there is a possibility not to be able to communicate. Refer to "Chapter 8 Timeout period of master".

5.4.6 Delimiter time of data by wired side (DTIM)


KW1M-R Eco-POWER METER doesn't determine an end of wired data by control code such as "CR", and determine by a blank time.

At initial setting, if there is the blank time for 10 characters, it is determined as the end of wired data and it starts wireless communication.

Therefore the data with blank more than the time will be interrupted.

Moreover, if the blank time between primary data and next data is less than the time, two data are judged as one datum, and it is not likely to send correctly. (It can be set the range of 4 to 20 characters.)

Connect terminals to master with multi-drop and DTIM should be short (4 characters) when it communicates with high speed.



It determines an end of wired data with the time in below table and it starts wireless communication.

Set DTIM refer to the below table.

For example, when it communicates 19200bps and it sends one datum with 4.0ms blank, you should set DTIM 8 characters (4.6ms) or more. If you set 8 characters or less, it will determine an end of wired data within the datum and interrupt.

■ Delimiter time of data by wired side (DTIM) Reference value (Data length: 8bit, Parity: Available)

(Unit: ms)


Baud rate (bps) / Number	1200	2400	4800	9600	19200	38400	57600	115200
4	36.7	18.3	9.2	4.6	2.3	1.1	0.8	0.4
5	45.8	22.9	11.5	5.7	2.9	1.4	1.0	0.5
6	55.0	27.5	13.8	6.9	3.4	1.7	1.1	0.6
7	64.2	32.1	16.0	8.0	4.0	2.0	1.3	0.7
8	73.3	36.7	18.3	9.2	4.6	2.3	1.5	0.8
9	82.5	41.3	20.6	10.3	5.2	2.6	1.7	0.9
10	91.7	45.8	22.9	11.5	5.7	2.9	1.9	1.0
11	100.8	50.4	25.2	12.6	6.3	3.2	2.1	1.1
12	110.0	55.0	27.5	13.8	6.9	3.4	2.3	1.1
13	119.2	59.6	29.8	14.9	7.4	3.7	2.5	1.2

Baud rate (bps) / Number	1200	2400	4800	9600	19200	38400	57600	115200
14	128.3	64.2	32.1	16.0	8.0	4.0	2.7	1.3
15	137.5	68.8	34.4	17.2	8.6	4.3	2.9	1.4
16	146.7	73.3	36.7	18.3	9.2	4.6	3.1	1.5
17	155.8	77.9	39.0	19.5	9.7	4.9	3.2	1.6
18	165.0	82.5	41.3	20.6	10.3	5.2	3.4	1.7
19	174.2	87.1	43.5	21.8	10.9	5.4	3.6	1.8
20	183.3	91.7	45.8	22.9	11.5	5.7	3.8	1.9

5.4.7 Upper communication recognition time (UTIM)

Upper communication recognition means that when a master unit and terminals are multi-dropped connected to a master device, the master device recognize that terminals are connected to upper side of a master unit by the setting recognition time. It doesn't send data wireless to the recognized terminals. Therefore, it can reduce radio traffic by avoiding unnecessary wireless sending. It is available only when selecting RS485 port.

For example, When the time between command and response is 150ms, it recognizes terminals are multi-dropped connected to upper of a master by setting the upper communication recognition time to 200ms.



However in this case, if a retransmission time-out of the master device is set under 20ms, it can't send data by wireless correctly because the retransmission command is recognized as response falsely.

Set the times as this,

$$[\text{time-out of terminals connected to upper}] < [\text{UTIM}] < [\text{time-out of master device}]$$

In the below example,


Terminals connected to upper (Eco-POWER METER) communicate with master device (PLC or DLU) by wire, therefore the time between command and response is about the range of several-ms to 100ms. Master recognizes that the terminals are connected upper by wire and doesn't send data by wireless, after judging the time between command and response.

If a response returns within the setting time, it recognizes that it multi-dropped connected. With the below constructions, it is not necessary to change the initial 200ms.

When using this construction, set baud rate of master to under 57600bps.

If it communicates with high baud rate, there is a possibility not to judge delimiter of communication between master device and terminals (Station No.1 and No.2). It is necessary to consider about response times of master device and terminals.

【Example】



* It recognize the wired communication and it doesn't send data of No.1 and No.2 by wireless .

5.4.8 KW Network Monitor

KW Network Monitor is a tool to check network wireless and wired network. It is possible to set and use without this tool. You can check whether network constructions and mounted devices build up a network correctly or not. And you can read out a communication error log memorized in the main unit. Therefore it is helpful to find factors of a communication error.

■ How to install KW Network Monitor

Download "KW Network Monitor" from our website.

Install it according to the installer's procedures.

In order to start KW Network Monitor,

[Start menu] -> [All programs] -> [Panasonic-EW SUNX Control]

-> [KW Network Monitor] -> [KW Network Monitor]

■ Functions of KW Network Monitor


- Search network (connection conditions, device name, version, radio field intensity etc.)

- Read out error log of master


- *It doesn't have data collection function.

- *About each function, refer to the operation manual or help of KW Network Monitor.

<Display example of Network condition on KW Network Monitor>



<Display example of error log>



In case of the above error log, it is thought that terminal No.1 turned off at the same time of the facility turned off at night.

- *Error log is memorized with the happening order, but the latest log is on the top of list.

(Even if changing calendar timer setting, the error happening time and happening order before changing are not changed.)

5.4.9 Use as a wireless unit

KW1M-R Eco-POWER METER master unit (AKW1000(K)) can be used as a wireless unit for various data communication not only to use as a power measurement.


In case of using AKW1000(K) as a slave, set to "SLAV" on Master/Slave setting mode (MODE1).

■ 1:N topology

• Use RS232C devices and R485 devices within one network

- AKW1000(K) can be selected RS232C or RS485, RS232C/RS485 converter is not necessary.
- Set port (RS232C/RS485) of AKW1000(K) on MODE3.
- *AKW1131(K) doesn't have RS232C port.


<Example> Read out data of Eco-POWER METER or PLC to PC.



■ 1:1 topology

Use a protocol other than MEWTOCOL and MODBUS (RTU) (Only 1:1 topology)

- Only when it is set to 1:1 topology, another protocol than MEWTOCOL and MODBUS (RTU) can be used.
- In order to use 1:1 topology, set "1-1" to both of a master and a slave^(*)(AKW1000(K)) with communication style setting mode (MODE1). As to the protocol (MODE3), both of MEWTOCOL and MODBUS (RTU) can be used.
- Master and slave^(*) are one for each in the same group when using 1:1 topology.
- If there are several slaves^(*) set to 1:1 topology, it causes malfunction.
- KW Network Monitor can't be used for 1:1 topology.



Not use for a sequence of command and response

(communication only one direction of command sending)

- When setting 1:1 topology, there is no timed-out. Both of a master and a slave^(*) can start sending data. Command can be sent from both side, note that data is conflicted.
- When using to send command one direction, transmission interval of each data should be set 50ms or more^(*). If the transmission interval is short, there is a possibility of missing data. Set the transmission interval after check whether data isn't missing with the actual device. (Max. 2048byte data can be sent at one time.)

*1: In this case, set AKW1000(K) to "SLAVE (SLAV)" with "Master/Slave setting mode".

AKW1131(K) can not used for 1:1 topology.

*2: When sending 20byte date with 115200bps

5.4.10 Communication error flag function

In order to save the communication error of KW1M-R into the master unit, it judges if the communication with the connected devices works correct or not.

Refer to Chapter 7 for the communication.

- DT00500) 0:normal 1:error
- For KW1M-R, if time out error of number of times you set, occurs continuously, DT00500 will be '1'. Set the number of times for DT00501.

【Data register】

MEWTOCOL

Data register	Name	Unit	Kind of data	Range	R/W
DT00500	Communication error flag	—	Unsigned 16bit	0:normal 1:error	R
DT00501	Number of times for communication error decision	times	Unsigned 16bit	1 to 255 (initial: 10)	R/W

MODBUS

Data register (MEWTOCOL)	Name	Unit	Kind of data	Range:Hexadecimal (Range: Decimal)	MODBUS Function code
01F4H (DT00500)	Communication error flag	—	Unsigned 16bit	0H(0):normal 1H(1):error	03H
01F5H (DT00501)	Number of times for communication error decision	times	Unsigned 16bit	1H to FFH (1 to 255) (initial: 10)	03H/06H


*AKW1000(K) responses to the upper device (PLC etc.) for DT00500 to 00501(01F4H to 01F5H). It is impossible to send data to the wireless device (PLC etc.).

*Communication error flag function is available for the unit version 2.0 or later.

*You can't use this when KW1M-R master is connected by multi-drop. If you use like this, it will occur malfunctions.

Chapter 6 Display of each Value

6.1 Working of AKW1000 /AKW1000K Monitor Display





Power on the unit and it displays the item that set with Mode 4. “MAST/SLAV”, “Group” are displayed initial.

6.2 AKW1000 /AKW1000K Monitor display

6.2.1 Unit type/Group

- You can set master or slave with MODE1 Master/Slave setting mode.
- You can set group with MODE1 Group setting mode.



Sample



6.2.2 Communication Channel

- It displays only when “master (MAST)” is selected with MODE1 Master/Slave setting mode.
- You can set channel with MODE1 Channel setting mode.


Sample



6.2.3 LQI (Field intensity with an upper wireless device)

- It displays only when “slave (SLAV)” is selected with MODE1 Master/Slave setting mode.
- “0” is displayed when there is no connection with an upper wireless device.
- It is good intensity with the upper wireless device to approach “70”.
- It is recommended to mount with the value over “15”.
- When the value is under “10”, the communication will be unstable. In this case, move to near the upper wireless device or adjust the antenna’s angle and height or mount a repeater between the upper wireless devices.

Sample




LQI: 47

6.2.4 Calendar/Timer


- It displays the setting present date and time.
- Press <SHIFT/▽> to change Year-Month-Day to Time.

Sample


Year/Month/Day
(April 10, 2009)



Time
(10:45)



6.3 Working of AKW1131 /AKW1131K Monitor Display



*1,2
The display is changed according to the phase and wire system.

	Current	Voltage
1P2W system	R-current	R-voltage (P1-P0)
1P3W system	R-current T-current	R-voltage, T-voltage (P1-P0) (P2-P0)
3P3W system	R-current, S-current, T-current	RS-voltage, RT-voltage, TS-voltage (P1-P0) (P1-P2) (P2-P0)
3P4W system	R-current, S-current, T-current	R-voltage, S-voltage, T-voltage (P1-P0) (P2-P0) (P3-P0)

6.4 AKW1131 /AKW1131K Monitor display

Power on the unit and it displays the monitor.



6.4.1 Integrated electric power

It displays the integrated electric power.

Sample


Integrated active power (kWh)

Integrated active power (MWh)



Integrated electric power is measured and displayed from 0.00kWh to 9999.99MWh.


The decimal point is changed automatically.



(After reaching the full scale (99999.9kWh), the value reverts to 0.00kWh but continues to measure.)

How to reset

Hold down <SET> and press <MODE> makes integrated electric power clear.




How to display with 9-digit

Sample

Integrated electric power can be displayed with 9-digit.

Press <SHIFT/▽> and <ITEM/△> simultaneously at integrated electric power display (kWh/MWh) and integrated electric power with 9-digit is displayed.




6.4.2 Instantaneous electric power

It displays the Instantaneous electric power.


Sample

Instantaneous electric power (kW)



6.4.3 Current

- It displays the current value of the load.
- Press <SHIFT/▽> to change R-current, S-current, T-current.
- *Before start measuring, select phase and wire system according to the measured load.
When it sets wrong, it doesn't measure correctly. (Refer to the explanation of setting mode.)





- When input current exceeds 150%F.S. at each range, [- - - -] will be displayed.
 - Current measurement parts
- Eco-POWER METER measures the current as below.

System \ Display	R-A	S-A	T-A
Single-phase two-wire	R-current	(Skip)	(Skip)
Single-phase three-wire	R-current	(Skip)	T-current
Three-phase three-wire	R-current	S-current	T-current
Three-phase four-wire	R-current	S-current	T-current

6.4.4 Voltage

- It displays the voltage value of the load.
- Press <SHIFT/▽> to change voltage between R(RS)-voltage, S(RT)-voltage and T(TS)-voltage.
- *Before start measuring, select phase and wire system according to the measured load.
When it sets wrong, it doesn't measure correctly. (Refer to the explanation of setting mode.)



- When input voltage is under 5% of rating, it displays "0.0" and doesn't measure.
(“Under 5%” means the value getting from this calculation “rated voltage 200(400) x 0.05 x VT ratio”).
- When input voltage exceeds 150%F.S. at each range, [- - - -] will be displayed.

•Voltage measurement parts


Eco-POWER METER measures the voltage as below.

Display System	R-V / RS-V	S-V / RT-V	T-V / TS-V
Single-phase two-wire	R-voltage (P1-P0) (line voltage)	(Skip)	(Skip)
Single-phase three-wire	R-voltage (P1-P0) (phase voltage)	(Skip)	T-voltage (P2-P0) (phase voltage)
Three-phase three-wire	RS-voltage (P1-P0) (line voltage)	RT-voltage (P1-P2) (line voltage)	TS-voltage (P2-P0) (line voltage)
Three-phase four-wire	R-voltage (P1-P0) (phase voltage)	S-voltage (P2-P0) (phase voltage)	T-voltage(P3-P0) (phase voltage)

6.4.5 Electricity Charge

•It displays the standard electricity charge for the integrated electrical power.

Sample




*When the value exceeds '999999', [- - - - -] will be displayed.

6.4.6 Carbon dioxide conversion value

•It displays the standard conversion value for the integrated electrical power.

Sample

CO₂ conversion value (kg-CO₂)




*When the value exceeds '999999', [- - - - -] will be displayed.

6.4.7 Power factor


•It displays power factor of the load.

Sample

Lagging phase



Leading phase



•How to calculate power factor


Eco-POWER METER displays power factor by calculating as below.

Power factor operation is a method assuming balanced load. The error might be big when it measures unbalanced load.

Single-phase two-wire	$PF = \frac{\text{Instantaneous electric power}}{\text{Voltage} \times \text{Current}}$	
Single-phase three-wire Three-phase four-wire	$PF = \frac{\text{Instantaneous electric power}}{a \times \left(\text{Average of each phase V} \right) \times \left(\text{Average of each phase A} \right)}$	
	1P3W: a=2	3P4W: a=3
Three-phase three-wire	$PF = \frac{\text{Instantaneous electric power}}{\sqrt{3} \times \left(\text{Average of each phase V} \right) \times \left(\text{Average of each phase A} \right)}$	


6.4.8 Frequency

• It displays frequency.



6.4.9 Hour meter

• It displays ON-time and OFF-time of the load measured by CT1.
 • Press <SHIFT/▽> to change the load ON-time to load OFF-time.




Blinking the decimal point during measurement of ON-time.


Blinking the decimal point during measurement of OFF-time.

*When load current is under the setting current for time measurement (HM-A), it measures as OFF-time. When load current is exceeded to the setting current for time measurement (HM-A), it measures as ON-time. Current for time measurement (HM-A) is set to under cutoff current (CUTA), all current is measured as OFF-time.

*Current of CT1




*After reaching the full scale (99999.9h), the value reverts to 0.0h but continues to measure.



How to Reset ON/OFF-time


• Hold down <SET> key and press <MODE> key makes ON-time or OFF-time clear.
 (ON-time and OFF-time are reset by each.)




6.4.10 Counter

- It displays present count value (pulse input value).

Sample




Prescale: 0.01



- *After reaching the full scale (999999), the value reverts to 0 but continues to measure.

How to Reset Count value


- Hold down <SET> key and press <MODE> key makes count value clear.



6.4.11 LQI (Field intensity with an upper wireless device)

- It displays LQI.
- "0" is displayed when there is no connection with an upper wireless device.
- It is good intensity with the upper wireless device to approach "70".
- It is recommended to mount with the value over "15".
- When the value is under "10", the communication will be unstable. In this case, move to near the upper wireless device or adjust the antenna's angle and height or mount a repeater between the upper wireless devices.

Sample




LQI: 47

6.5 Other indication

6.5.1 Power On indication


Power indicator turns on when the unit powers on.

Even if the display turns off, the power indicator is lighting while the unit is powered.
(Refer to Mode 4 setting.)




6.5.2 Indication while communication

TX/RX indicator is blinking while Eco-POWER METER is under communication.



6.5.3 Indication of communication error

ERROR indicator is blinking when a communication error is happened.
In addition, error number is displayed on the unit.
Error contents are as below.




Number	Type	Error	Error conditions
1	Master/Slave	Serial communication error	Communication error at serial communication When data size is larger than sendable byte. (When data 2048 byte or more data is received with wire and so on)
13	Slave	Unidentified network error	When it can't find master or it lose master.
21	Master	Terminal registration error	When 2 or more terminals with same station number exist.
46	Master	Busy error	When another command except wireless communication is processed. For example, when flow control setting is different, when it is not connected to other device although it set flow control available.
54	Master	Time out error	When response from slave is time out.
60	Master/Slave	Unsupported protocol error	When protocol is different from the designated. When transmission speed is different.
81	Master/Slave	Wireless communication error	No slave is connected to the network.
82	Master	No connection with terminal error	When communication between master and registered slave is cut.

Chapter 7 Communication

7.1 Communication Procedures

Communication starts with command transmission from the host computer (hereafter Master) and ends with the response of AKW1131(K) or terminal equipment connected AKW1131(K) (hereafter Slave).



7.2 Communication timing

◆ The minimum access time from the master is 1 sec. (Minimum time for update the data *¹)
Eco-POWER METER may not response due to noise and so on, be sure to check that it receives the response from Eco-POWER METER.

*1: In case of the data is big or the baud rate of a slave is low, it may need more than 1 second.


◆ In order to improve the communication quality, we recommend to send the transmission again.

7.3 MEWTOCOL Communication


7.3.1 Overview of MEWTOCOL-COM

◆ Command and response functions

The computer sends commands (instructions) to Eco-POWER METER, and receives responses in return. This enables the computer and Eco-POWER METER to converse with each other, so that various kinds of information can be obtained and provided.



◆ Command and response formats



◇ Control codes

Name	Character	ASCII code	Explanation
Header	%	25H	Indicates the beginning of a message.
Command	#	23H	Indicates that the data comprises a command message.
Normal response	\$	24H	Indicates that the data comprises a normal response message.
Error response	!	21H	Indicates that the data comprises a response message when an error occurs.
Terminator	CR	0DH	Indicates the end of a message.

◇ Destination and source AD (H), (L)

Two-digit decimal 01 to 99 (ASCII codes)

Command messages contain a station number for Eco-POWER METER that receives the message. When FF (ASCII code table) is used, however, the transmission is a global transmission (sent to all stations at once).

Note) When a global transmission is sent, no response to the command message is returned.

◇ Block check code Bcc (H), (L)

Two-digit hexadecimal 00 to FF (ASCII codes)

These are codes (horizontal parity) that are used to detect errors in the transmitted data.

If "***" is entered instead of "Bcc", however, messages can be transmitted without the Bcc. In this case, the Bcc is included with the response

◇ Error code Err (H), (L)


Two-digit hexadecimal 00 to FF (ASCII codes)

These indicate the content if an error occurs.

◆ Bcc (Block Check Code)

-The Bcc is a code that carries out an error check using horizontal parity, to improve the reliability of the data being sent.

-The Bcc uses an exclusive OR from the header (%) to the final character of the text, and converts the 8-bit data into a 2-character ASCII code.



7.3.2 Data Register List (MEWTOCOL) <Only AKW1131/AKW1131K>

Data register	Name	Unit	Kind of data	Range	R/W
DT00054	Rate (CHG)	0.01	Unsigned 16bit	0 to 9999	R/W
DT00055	Conversion factor (CO2)	0.001 kg-CO ₂	Unsigned 16bit	0 to 9999	R/W
DT00060	CT type	Rated A (rms)	Unsigned 16bit	5,50,100,250,400,600	R/W
DT00061	Unit for Pulse output	—	Unsigned 32bit	1(0.001),10(0.01),100(0.1),1000(1),10000(10),100000(100)999 (Instantaneous electric power: Values of DT00064, 00065)777 (Ratio for current alarm: Value of DT00069)	R/W
DT00062				555 (Preset value for output: Values of DT00158,00159)333 (Ratio and time for Stand-by alarm: Value of DT00077,00078)	
DT00063	Primary side current value when CT 5A	1A	Unsigned 16bit	1 to 4000	R/W
DT00064	Power alarm value (Instantaneous electric power)	0.01kW	Unsigned 32bit	0 to 99999999	R/W
DT00065					
DT00066	VT ratio	0.01	Unsigned 16bit	100 to 9999	R/W
DT00067	Current threshold for time measurement	0.1%	Unsigned 16bit	1 to 1000	R/W
DT00068	Cutoff current	0.1%	Unsigned 16bit	10 to 500	R/W
DT00069	Ratio for current alarm	0.1%	Unsigned 16bit	10 to 1000	R/W
DT00070	Voltage range	—	Unsigned 16bit	1; 400V 2; 200V	R/W
DT00077	Ratio for stand-by current	0.1%	Unsigned 16bit	10 to 1000	R/W
DT00078	Time for stand-by alarm	1min.	Unsigned 16bit	0 to 9999	R/W
DT00100	Integrated electric power	0.01kWh	Unsigned 32bit	0 to 999999999	R/W
DT00101					
DT00107	R-current	0.1A	Unsigned 16bit	0 to 60000	R
DT00108	S-current	0.1A	Unsigned 16bit	0 to 60000	R
DT00109	T-current	0.1A	Unsigned 16bit	0 to 60000	R
DT00111	Power factor	0.01	Signed 16bit	-99 to 100	R
DT00112	Frequency	0.1Hz	Unsigned 16bit	0 to 1000	R
DT00150	Load ON-time	0.1h	Unsigned 32bit	0 to 999999	R/W
DT00151					
DT00152	Load OFF-time	0.1h	Unsigned 32bit	0 to 999999	R/W
DT00153					
DT00154	Pulse count value	—	Unsigned 32bit	0 to 999999	R/W
DT00155					
DT00158	Preset value	—	Unsigned 32bit	0 to 999999	R/W
DT00159					
DT00160	Prescale value	0.001	Unsigned 32bit	1 to 100000	R/W
DT00161					
DT00162	Max. counting speed	Hz	Unsigned 16bit	30, 2000	R/W
DT00163	Auto-off time	min	Unsigned 16bit	0 to 99 (0:always on)	R/W
DT00170	R(RS)-voltage	0.1V	Unsigned 32bit	0 to 99999	R
DT00171					
DT00172	S(RT)-voltage	0.1V	Unsigned 32bit	0 to 99999	R
DT00173					
DT00174	T(TS)-voltage	0.1V	Unsigned 32bit	0 to 99999	R
DT00175					
DT00176	Instantaneous electric power	0.01kW	Unsigned 32bit	0 to 99999999	R
DT00177					

Data register	Name	Unit	Kind of data	Range	R/W
DT00500	Communication error flag	—	Unsigned 16bit	0:normal 1:error	R
DT00501	Number of times for communication error decision	times	Unsigned 16bit	1 to 255 (initial: 10)	R/W

Note1) R: Read W: Write

2) Data register except specified is 0.

3) If each setting value is wrote by communication, it memories to internal EEPROM at the same time. Therefore, change setting frequently makes EEPROM's life short. Avoid to usage like this.

4) Write a data within the range when you write it.

5) AKW1000(K) responses to the upper device (PLC etc.) for DT00500 to 00501).

It is impossible to send data to the wireless device (PLC etc.).

7.3.3 Error Codes

◇Basic procedure errors

Error code	Error name	Explanation
40H	Bcc error	• A Bcc error occurred in the command data.
41H	Format error	• A command message was sent that does not fit the transmission format.
42H	No support error	• A command was sent that is not supported.
43H	Procedure error	• Delimiter with multiple frames was sent. • The response shall be multiple frames.

◇Application error

Error code	Error name	Explanation
60H	Parameter error	• The data code is not "D".
61H	Data error	• Word No. is specified without decimal. (0000F etc.) • The starting word No. is bigger than the ending word No. • Writing data has a code that is not hexadecimal.
62H	Registration error	• Too many registrations have been entered (more than 17). • "MD" command was sent when some registration has been exist. • "MG" command was sent when registration has not been entered.

◇Self-diagnostic error

Error code	Error name	Explanation
45H	Operation error	• At "WD" command, writing data is exceeded the range of data register.


7.3.4 Command

Eco-POWER METER has 5 kinds of commands.


Command name	Code	Explanation
Read data area	RD	Reads the contents of data area.
Write data to data area	WD	Writes data to a data area.
Register or Reset data monitored	MD	Registers the data to be monitored.
Monitoring start	MG	Monitors a registered data.
Read status	RT	Reads the specifications of Eco-POWER METER and error code if an error occurs.

◆[RD]: Read data area (Reads the contents of data area.)


◇Command



◇Normal response (Read successful)




◇Error response



◆[WD]: Write data area (Writes date to a data area.)




◇Command




◇Normal response (Write successful)




◆[MD]: Register or Reset data monitored (Registers the data to be monitored.) *Up to 16 points can be registered for one unit.



◆[MG]: Monitoring start (Monitors a registered data.)



◆[RT]: Read the status of Eco-POWER METER (Reads the specifications of Eco-POWER METER and error codes if an error occurs.)



*With this unit, it responses "99" for Model code1, "15" for Model code2.

7.4 MODBUS (RTU) Communication

7.4.1 Overview of MODBUS (RTU)

◆8-bit binary data in command is transmitted as it is.

Data format	Start bit	: 1 bit
	Data bit	: 8 bits *7bits is not available.
	Parity	: No parity, Even parity, Odd parity Selectable
	Stop bit	: 1 bit (Fixed)
	Error detection	: CRC-16 (Cyclic Redundancy Check)
	Data interval	: 3.5 character transmission time or more

◆Message configuration

RTU mode is configured to start after idle time processing of more than 3.5 character transmissions and end after idle time processing of more than 3.5 character transmissions.

3.5 idle characters	Slave address	Function code	Data	Error check CRC-16	3.5 idle characters
	8-bit	8-bit	* * bits	16-bit	

Master judges the transmission complete after no command for 4-characters idle time and process the command.

◇Slave address:

Slave address is an individual instrument number on the slave side and is set within the range 1 to 247 (01H to F7H). Master identifies slaves by the slave address of the requested message.

Slave informs master which slave is responding to master by placing its own address in the response message. Slave address 0 (00H, broadcast address) can identify all slaves connected. However slaves do not respond.

◇Function code: Function code is command code for the slave to undertake the following action types.

Function code	Contents
03(03H)	DT Read
06(06H)	DT 1 word write
16(10H)	DT several data write

Function code is used to discern whether the response is normal (acknowledgement) or if any error (negative acknowledgement) has occurred when slave returns response message to master.

When acknowledgement is returned, slave simply returns original function code. When negative acknowledgement is returned, MSB of original function code is set as 1 for response.

For example, when the master sends request message setting 00H to function code by mistake, slave returns 80H by setting MSB to 1, because the former is an illegal function.

For negative acknowledgement, the exception codes below are set to data of response message and returned to master in order to inform it of what kind of error has occurred.

Exception code	Contents
1(01H)	Illegal Function (Non-existent function)
3(03H)	Illegal data value (Value out of the device numbers)

note1) Even if it commands to write (06H.10H) to non-existent data address, slave response with acknowledgement. However, it doesn't write.

note2) Even if it commands to write the value out of the setting range, slave response with acknowledgement. However, it doesn't write.

◇Data: Data depends on the function code.

A request message from the master side is composed of data item, number of data and setting data.

A response message from the slave side is composed of number of bytes, data and exception code in negative acknowledgement.

◇Error check: 16-bit data to detect communication errors. Refer to the next.

◇Acknowledgement response

When command is to write 1 point, same message of command is responded.

When command is to write several points, part of command message (6 bytes) is responded.

◆Error check

After calculating CRC-16 (Cyclic Redundancy Check) from slave address to the end of data, the calculated 16-bit data is appended to the end of message in sequence from low order to high order.

<How to calculate CRC>

In CRC system, the information is divided by the polynomial series. The remainder is added to the end of the information and transmitted. The generation of polynomial series is as follows.

(Generation of polynomial series: $X^{16} + X^{15} + X^2 + 1$)

- 1) Initialize the CRC-16 data (assumed as X) (FFFFH).
- 2) Calculate exclusive OR (XOR) with the 1st data and X. This is assumed as X.
- 3) Shift X one bit to the right. This is assumed as X.
- 4) When a carry is generated as a result of the shift, XOR is calculated by X of 3) and the fixed value (A001H). This is assumed as X. If a carry is not generated, go to step 5).
- 5) Repeat steps 3) and 4) until shifting 8 times.
- 6) XOR is calculated with the next data and X. This is assumed as X.
- 7) Repeat steps 3) to 5).
- 8) Repeat steps 3) to 5) up to the last data.
- 9) Set X as CRC-16 to the end of message in sequence from low order to high order.

◆Message example

<1> Reading electricity rate (0036H) of address 1

•Command

3.5 idle characters	Slave address (01H)	Function code (03H)	Data item (0036H)	Number of data (0001H)	Error check CRC-16 (6404H)	3.5 idle characters
	1	1	2	2	2	←character number

•Response message from slave in normal status (When Rate=1000(10.00) [03E8H])

3.5 idle characters	Slave address (01H)	Function code (03H)	Number of response byte (02H)	Number of data (03E8H)	Error check CRC-16 (B8FAH)	3.5 idle characters
	1	1	1	2	2	←character number

<2> Setting electricity rate (0036H) of address 1 (When rate is set to 20.00(2000) [07D0H])

•Command

3.5 idle characters	Slave address (01H)	Function code (06H)	Data item (0036H)	Number of data (07D0H)	Error check CRC-16 (6A68H)	3.5 idle characters
	1	1	2	2	2	←character number


•Response message from slave in normal status

3.5 idle characters	Slave address (01H)	Function code (06H)	Data item (0036H)	Number of data (07D0H)	Error check CRC-16 (6A68H)	3.5 idle characters
	1	1	2	2	2	←character number


<3> Reset integrated electric power (0064H, 0065H:2-word) of address 1

(When setting to 0 [0000, 0000H])

• Command



• Response message from slave in normal status




• A response message from the slave in exception (error) status

(When number of data has been mistaken.)

Function code MSB is set to 1 for the response message in exception (error) status (90H).


The exception code 03H (Value out of the device numbers) is returned as contents of error.

<Mistaken message example (Command)>



<Response message from slave to mistaken command

(Response message in exception (error) status)>



7.4.2 Data Register List <Only AKW1131/AKW1131K>

Data item (MEWTOCOL)	Name	Unit	Kind of date	Range: Hexadecimal (Range: Decimal)	MODBUS Function code
0036H (DT00054)	Rate (CHG)	0.01	Unsigned 16bit	0H to 270FH (0 to 9999)	03H/06H/10H
0037H (DT00055)	Conversion factor (CO ₂)	0.001 kg-CO ₂	Unsigned 16bit	0H to 270FH (0 to 9999)	03H/06H/10H
003CH (DT00060)	CT type	Rated A (rms)	Unsigned 16bit	5H(5), 32H(50), 64H(100), FAH(250), 190H(400), 258H(600)	03H/06H/10H
003DH<LSB> (DT00061)	Unit for Pulse output	—	Unsigned 32bit	1H(1)<0.001>, AH(10)<0.01>, 64H(100)<0.1>, 3E8H(1000)<1>, 2710H(10000)<10>, 186A0H(100000)<100>, 3E7H(999) <Instantaneous electric power: Values of 0040H,0041H> 309H(777) <Ratio for current alarm: Values of 0045H> 22B(555) <Preset value for output: Values of 009EH,009FH> 14DH(333) <Ratio and time for stand-by alarm: Values of 004DH,00E4H>	03H/06H/10H
003EH<MSB> (DT00062)					
003FH (DT00063)	Primary side current value when CT 5A	1A	Unsigned 16bit	1H to FA0H (1 to 4000)	03H/06H/10H
0040H<LSB> (DT00064)	Power alarm value (Instantaneous active power)	0.01kW	Unsigned 32bit	0H to 5F5E0FFH (0 to 99999999)	03H/06H/10H
0041H<MSB> (DT00065)					
0042H (DT00066)	VT ratio	0.01	Unsigned 16bit	64H to 270FH (100 to 9999)	03H/06H/10H
0043H (CT00067)	Current threshold for time measurement	0.1%	Unsigned 16bit	1H to 3E8H (1 to 1000)	03H/06H/10H
0044H (DT00068)	Cutoff current	0.1%	Unsigned 16bit	AH to 1F4H (10 to 500)	03H/06H/10H
0045H (DT00069)	Current alarm value	0.1%	Unsigned 16bit	AH to 3E8H (10 to 1000)	03H/06H/10H
0046H (DT00070)	Voltage range	—	Unsigned 16bit	1H(1):400V 2H(2):200V	03H/06H/10H
004DH (DT00077)	Current ratio for stand-by alarm	0.1%	Unsigned 16bit	AH to 3E8H (10 to 1000)	03H/06H/10H
004EH (DT00078)	Time for stand-by Alarm	—	Unsigned 16bit	1H to 270FH (1 to 9999)	03H/06H/10H
0064H (DT00100)	Integrated electric Power	0.01kWh	Unsigned 16bit	0H to 3B9AC9FFH (0 to 999999999)	03H/06H/10H
0065H (DT00101)					
006BH (DT00107)	R-current	0.1A	Unsigned 16bit	0H to EA60H (0 to 60000)	03H
006CH (DT00108)	S-current	0.1A	Unsigned 16bit	0H to EA60H (0 to 60000)	03H
006DH (DT00109)	T-current	0.1A	Unsigned 16bit	0H to EA60H (0 to 60000)	03H
006FH (DT00111)	Power factor	0.01	Signed 16bit	FF9DH to 0064H (-99 to 100)	03H
0070H (DT00112)	Frequency	0.1Hz	Unsigned 16bit	0H to 3E8H (0 to 1000)	03H

Data item (MEWTOCOL)	Name	Unit	Kind of date	Range: Hexadecimal (Range: Decimal)	MODBUS Function code
0096H<LSB> (DT00150) 0097H<MSB> (DT00151)	Load ON-time	0.1h	Unsigned 32bit	0H to F423FH (0 to 999999)	03H/06H/10H
0098H<LSB> (DT00152) 0099H<MSB> (DT00153)	Load OFF-time	0.1h	Unsigned 32bit	0H to F423FH (0 to 999999)	03H/06H/10H
009AH<LSB> (DT00154) 009BH<MSB> (DT00155)	Pulse count value	—	Unsigned 32bit	0H to 5F5E0FFH (0 to 999999999)	03H/06H/10H
009EH<LSB> (DT00158) 0099H<MSB> (DT00153)	Preset value	—	Unsigned 32bit	0H to 5F5E0FFH (0 to 999999999)	03H/06H/10H
009EH<LSB> (DT00160) 009FH<MSB> (DT00161)	Prescale value	—	Unsigned 32bit	0H to 186A0H (0 to 100000)	03H/06H/10H
00A2H (DT00162)	Max. counting speed	Hz	Unsigned 16bit	1EH (30), 7D0H (2000)	03H/06H/10H
00A3H (DT00163)	Auto-off time	min	Unsigned 16bit	0H to 63H (0 to 99) (0H:always on)	03H/06H/10H
00AAH<LSB> (DT00170) 00ABH<MSB> (DT00171)	R(RS)-voltage	0.1V	Unsigned 32bit	0H to F423FH (0 to 999999)	03H
00ACH<LSB> (DT00172) 00ADH<MSB> (DT00173)	S(RT)-voltage	0.1V	Unsigned 32bit	0H to F423FH (0 to 999999)	03H
00AEH<LSB> (DT00174) 00AFH<MSB> (DT00175)	T(TS)-voltage	0.1V	Unsigned 32bit	0H to F423FH (0 to 999999)	03H
00B0H<LSB> (DT00176) 00B1H<MSB> (DT00177)	Instantaneous electric power	0.01kW	Unsigned 32bit	0H to F423FH (0 to 999999)	03H
01F4H (DT00500)	Communication error flag	—	Unsigned 16bit	0H(0):normal 1H(1):error	03H
01F5H (DT00501)	Number of times for communication error decision	times	Unsigned 16bit	1H to FFH (1 to 255)	03H/06H

<LSB>: Least Significant Byte

<MSB>: Most Significant Byte

Note1) 03H: Read 06H,10H: Write

2) Data register except specified is 0.

3) If each setting value is wrote by communiation, it memories to internal EEPROM at the same time. Therefore, change setting frequency makes EEPROM's life short. Avoid to usage like this.

4) Write a data within the range when you write it.

5) AKW1000(K) responses to the upper device (PLC etc.) for 01F4H to 01F5H(DT00500 to 00501). It is impossible to send data to the wireless device (PLC etc.).

Chapter 8 Specifications

8.1 Main unit

Rated operating voltage	100-240V AC *1		
Rated frequency	50/60Hz common		
Rated power consumption	AKW1000(K): 5VA, AKW1131(K): 8VA (240VAC at 25°C)		
Inrush current	Max. 30A (240VAC at 25°C)		
Allowable operating voltage range	85-264V AC (85% to 110% of rated operating voltage)		
Allowable momentary power-off time	10ms		
Ambient temperature	-10 to +50°C (-25°C to +70°C at storage)		
Ambient humidity	30 to 85%RH (at 20°C non-condensing)		
Breakdown voltage(initial)	Between the isolated circuits: 2000V for 1min	A)Outer edge (enclosure) – All terminals B)Between Insulated circuit <AKW1000(K)> • Operating power supply terminals – RS232C terminals • Operating power supply terminals – RS485 terminals • RS232C terminals – RS485 terminals <AKW1131(K)> *2 • Operating power supply terminals – Analog input terminals • Operating power supply terminals – Pulse input terminal • RS485 – All other terminals • Pulse output terminals – All other terminals	
Insulation resistance(initial)	Between the isolated circuits: 100MΩ or more (measured at 500V DC)		
Vibration resistance	10 to 55Hz (1cycle/min) single amplitude : 0.375mm(1h on 3 axes)		
Shock resistance	Min. 294m/s ² (5 times on 3 axes)		
Display method	LCD with backlight	Upper: Green Lower: Amber	4-digit, 16-segment, letters H: 6.5mm 6-digit, 7-segment, letters H: 7.5mm
Power failure memory method	AKW1000(K)	FROM(more than 100,000 overwrite)	Memory items: Setting value Error Log
	AKW1131(K)	EEPROM (more than 1,000,000 overwrite)	Memory items: Setting value Measuring value
Size	75 x 90 x 50 mm		
Weight	AKW1000(K): approx.160g AKW1131(K):approx.170g (Without antenna and battery)		

*1 Rated power supply of AKW1000K and AKW1131K is limited to 220V AC.

*2 Analog input terminals: No.3, No.4, No.5 and No. 6

8.2 Input Specifications

8.2.1 Electric power input <only AKW1131/AKW1131K>

Phase and wire system		Single-phase two-wire system Single-phase three-wire system (common) Three-phase three-wire system Three-phase four-wire system
Input voltage	Rating	Single-phase two-wire : 0-440V AC (Line voltage) Single-phase three-wire : 0-220V AC (Phase voltage) Three-phase three-wire : 0-440V AC (Line voltage) Three-phase four-wire : 0-254V AC (Phase voltage)
	Allowable measurement voltage	Up to 120% of rated input voltage Single-phase two-wire : 0-528V AC (Line voltage) Single-phase three-wire : 0-264V AC (Phase voltage) Three-phase three-wire : 0-528V AC (Line voltage) Three-phase four-wire : 0-300V AC (Phase voltage)
	VT ratio	1.00 to 99.99 (Set with setting mode) *Voltage transformer (VT) is required when you measure a load with voltage over 440VAC (Allowable measurement voltage). *Secondary voltage rating of VT is 110V.
Input current	Primary side rating	<Using the dedicated CT> •5A/50A/100A/250A/400A/600A (Select with setting mode) <Using a CT with the secondary side current 5A> • 1 to 4000A (Set with setting mode) *Use a CT with secondary side current of 5A when measure 600A or more.
Special functions	Cut-off current	1.0 to 50.0%F.S (Set with setting mode)
	Cut-off voltage	Below 5% of rating voltage (Rating voltage x 0.05 x VT ratio) (Fixed)
	Current threshold for hour meter	1.0 to 100.0%F.S.
Accuracy (without error in CT and VT)	Indication accuracy	Instantaneous electric power / Integrated electric power / Electricity charge / Conversion value Within $\pm (2.0 \% \text{ F.S.} + 1 \text{ digit})$ (at 20 °C, rated input, rated frequency, power factor 1) In case of 5 A CT mode, within $\pm (2.5 \% \text{ F.S.} + 1 \text{ digit})$ *Accuracy coverage: 5 to 100% of rated current
		Current Within $\pm (1.0 \% \text{ F.S.} + 1 \text{ digit})$ In case of 5 A CT mode, within $\pm (2.5 \% \text{ F.S.} + 1 \text{ digit})$ (at 20 °C rated input, rated frequency, power factor 1) *Accuracy coverage: 5 to 100 % of rated current
		Voltage Within $\pm (1.0 \% \text{ F.S.} + 1 \text{ digit})$ (at 20 °C rated input, rated frequency, power factor 1)
		Hour meter $\pm (0.01\%+1\text{digit})$ (at 20°C) Monthly accuracy: $\pm 260 \text{ sec.}$ (for your reference) 〔 In case power on start or current energizing 〕 $\pm (0.01\%+1\text{s}+1 \text{ digit})$ (at 20°C)
	Temperature characteristics	Within $\pm (1.0 \% \text{ F.S.} + 1 \text{ digit})$ In case of 5 A CT mode, within $\pm (1.5 \% \text{ F.S.} + 1 \text{ digit})$ (Range of -10 to 50 °C, rated input, power factor 1)
	Frequency characteristics	Within $\pm (1.0 \% \text{ F.S.} + 1 \text{ digit})$ In case of 5 A CT mode, within $\pm (1.5 \% \text{ F.S.} + 1 \text{ digit})$ (Frequency change $\pm 5 \%$ based on rated frequency, rated input, power factor 1)

8.2.2 Pulse input <only AKW1131/AKW1131K>

Input mode	Addition (Fixed)	
Max. counting speed	2kHz /30Hz (Select with setting mode)	
Pulse input	Min. input signal width: 0.25ms (When 2kHz selected) /16.7ms (When 30Hz selected) ON:OFF ratio = 1 : 1	
Input signal	Contact / No contact (open collector) • Impedance when shorted: Min. 1k Ω • Residual voltage when shorted: Max. 2V • Impedance when open: Min. 100k Ω	
Output mode	HOLD (Over count)	
Prescale	Decimal point	under 3-digit
	Range	0.001 to 100.000 (Set with setting mode)

8.3 Output Specifications

8.3.1 Pulse output (Transistor output) <only AKW1131/AKW1131K>

Number of output point	1 point
Insulation method	Optical coupler
Output type	Open collector
Output capacity	100mA 30V DC
Pulse width	approx. 100ms
ON state voltage drop	1.5V or less
OFF state leakage current	100 μ A or less
Pulse output unit	0.001/0.01/0.1/1/10/100kWh/Alarm(AL-P)/ Current alarm(AL-C) /Stand-by alarm (AL-S) /Counter(Cnt) (Selectable with setting mode)

* We recommend the setting of minimum unit for pulse output for measurement shown as below.

Output pulse: less than 4-pulse per 1sec.

How to calculate

(Unit for pulse output: PL-P) > (Max. measurement power [kW]) / (3600[s] × 4 [pulse/s])

Note (1) Improper unit setting may cause miss counting.

(2) If the OFF time is too short, there is a possibility of counting errors.

8.4 Communication Specifications

8.4.1 RS232C communication <only AKW1000/AKW1000K>

Interface	Conforming to RS232C	
Protocol	MEWTOCOL/MODBUS(RTU) *1	
Transmission distance	15m (max.)	
Transmission speed	115200/57600/38400/19200/9600/4800/2400/1200bps (selectable with setting mode)	
Transmission Format	Data length	8bit/7bit (selectable with setting mode)
	Parity	Not available / Odd number / Even number (selectable with setting mode)
	Stop bit	1bit (fixed)
Communication method	Half-duplex	
Synchronous system	Synchronous communication method	
Flow control	Available / Not available (selectable with setting mode) *2	
Data buffer	Max.data size send/receive at one time • MEWTOCOL: 2048 byte • MODBUS(RTU): 256 byte	

*1 For 1:1 topology of AKW1000(K), it can communicate regardless the protocol.

(Only communication between AKW1000(K) and AKW1000(K))

*2 If flow control is executed, the other device needs to support flow control.

8.4.2 RS485 communication

Interface		Conforming to RS485
Protocol		MEWTOCOL/MODBUS(RTU) *5, *6
Isolation status		Isolated with the internal circuit
Number of connected units		99 (max.) *2 *3
Transmission distance		1200m (max.) *1
Transmission speed	AKW1000(K)	115200/57600/38400/19200/9600/4800/2400/1200bps (selectable with setting mode)
	AKW1131(K)	38400/19200/9600/4800/2400bps (selectable with setting mode)
Transmission Format	Data length	8bit/7bit (selectable with setting mode) *4
	Parity	Not available / Odd number / Even number (selectable with setting mode)
	Stop bit	1bit (fixed)
Communication method		Half-duplex
Synchronous system		Synchronous communication method
Ending resistance		approx. 120 Ω (built-in)
Data buffer		Max.data size send/receive at one time • MEWOCOL: 2048 byte • MODBUS(RTU): 256 byte *7

*1 Please check with the actual devices when some commercial devices with RS485 interface are connected. The number of connected devices, transmission distance, and transmission speed may be different according to using transmission line.

*2 For RS485 converter on the computer side, we recommend SI-35 and SI-35USB.
(from LINE EYE Co., Ltd.)

*3 When using SI-35, SI-35USB or PLC from our company (which can be connected up to 99 units), up to 99 Eco-POWER METER can be connected. In case using this system with the other devices, up to 31 Eco-POWER METER can be connected.

*4 With MODBUS (RTU) protocol, it works only with 8bit.

*5 For 1:1 topology of AKW1000(K), it can communicate regardless the protocol.
(Only communication between AKW1000(K) and AKW1000(K))

*6 AKW1131(K) can't be used for data communication from RS485. It may cause malfunctions.

*7 For AKW1131(K), the maximum number of reading points are 26 (57-byte), the maximum number of writing points is 23 (55-byte).


8.4.3 Wireless communication

Wave type	Direct sequence spread spectrum (DS-SS)
Transmission distance	Approx. 100m (straight, obstacle-free distance)
Wave output	1mW
Frequency	2405 to 2480 MHz
Number of channel	16 channels (selectable vacant channel automatically by auto scan function)
Transmission speed	250kbps
Communication style	1:N topology Auto routing method (N= max.249)
Repeater function	8 repeaters (between master and slave) *1

*1 There is no setting for letting it work as repeater, confirm actual number of repeaters by KW Network Monitor.

■ Frequency

There are 16 channels of communication channel with 5MHz separation.



Communication channel	Frequency
AUTO	Auto selection from 2405 to 2480MHz
1ch	2405MHz
2ch	2410MHz
3ch	2415MHz
4ch	2420MHz
5ch	2425MHz
6ch	2430MHz
7ch	2435MHz
8ch	2440MHz
9ch	2445MHz
10ch	2450MHz
11ch	2455MHz
12ch	2460MHz
13ch	2465MHz
14ch	2470MHz
15ch	2475MHz
16ch	2480MHz


■ Timeout period of master

- At 1:N topology, when no response is sent from slave or terminal, master stops waiting for response and move to next action. The time from to start communication to move next action is named timeout period.
- Timeout period differs according to data size. Master doesn't receive serial communication until pass the timeout period. Consider timeout period by upper equipment.

Sending data size [bytes]	Time out period [seconds]	Sending data size [bytes]	Time out period [seconds]
1 to 75	3.4	1036 to 1115	10.1
76 to 155	4.1	1116 to 1195	10.6
156 to 235	4.8	1196 to 1275	11.0
236 to 315	5.3	1276 to 1355	11.5
316 to 395	6.0	1356 to 1435	11.8
396 to 475	6.4	1436 to 1515	12.3
476 to 555	7.0	1516 to 1595	12.7
556 to 635	7.4	1596 to 1675	13.0
636 to 715	7.9	1676 to 1755	13.5
716 to 795	8.4	1756 to 1835	13.9
796 to 875	8.8	1836 to 1915	14.4
876 to 955	9.3	1916 to 1995	14.7
956 to 1035	9.6	1996 to 2048	15.0

Note: Depending on conditions of data size and baud rate, it could not communicate because of master's time out.

- In case there are excess data size, such as command is 75byte and response is 2048byte.
- In case there are excess data size such as baud rate of slave's wired communication is low.



8.5 Calendar timer specifications

<only AKW1000/AKW1000(K)>

Calendar timer	Time accuracy (Monthly accuracy) ±240 seconds (at -10°C) ±70 seconds (at 25°C) ±240 seconds (at 50°C)
Backup contents by battery	Time measurement
Battery life *1	About 2 years (at 25°C) (when no power)

*1 When battery power is reduced, "BATT" is blinking. Replace battery according to the procedures. Battery life will be shorten if using this under high-temperature.

8.6 Self-diagnostic function

If an error occurs, the following indication will be given.

Indicator	Meaning	Output status	To recover
Err0	CPU error	OFF	Turn the power off and then on again.
Err1	Memory error*		EEPROM life ended. Replace the unit.

*Includes the possibility that the EEPROM's life has expired.

8.7 Power Failure Memory

<AKW1000(K)>

Every time to change each setting, each setting value is memorized to FROM and kept data before power failure. Change setting frequently makes FROM's life short. Avoid to usage like this.

<AKW1131(K)>

Eco-POWER METER memories integrated electric power and working status to internal EEPROM until when power supply is off. (Power failure guarantee)

And every time to change each setting, each setting value is memorized to internal EEPROM at the same time. Therefore, change setting frequently makes EEPROM's life short. Avoid to usage like this.

*Especially be careful if you set by communication.

8.8 Dedicated Current Transformer Specifications

● Clamp-on type

Model No	AKW4801C	AKW4802C	AKW4803C	AKW4804C
Primary side rated current	5A / 50A	100A	250A	400A
Secondary side rated Current	1.67mA / 16.7mA	33.3mA	125mA	200mA
Transform ratio	3000:1	3000:1	2000:1	2000:1
Ratio error	±2.0% F.S.			
Hole Dia (mm)	φ 10	φ 16	φ 24	φ 36
Breakdown voltage (initial)	AC1000V/1min (Between through hole and output lead wire)		AC2000V/1min (Between through hole and output lead wire)	
Insulation resistance (initial)	Min. 100MΩ (at DC500V) (Between through hole and output lead wire)			
Vibration resistance	Functional	10 to 55Hz (1 cycle/ minute) single amplitude of 0.15mm (10 min. on X,Y and Z axes)		
	Destructive	10 to 55Hz (1 cycle/ minute) single amplitude of 0.375mm (1 hrs. on X,Y and Z axes)		
Shock resistance	Functional	Min. 98m/s ² (4 times on X,Y and Z axes)		
	Destructive	Min. 294m/ s ² (5 times on X,Y and Z axes)		
Output protection level	±7.5V with clamp element		±3.0V with clamp element	
Permissible clamping frequency	Approx. 100 times			
Ambient temperature	-10 to +50°C (without frost and non-condensing)			
Storage temperature	-20 to +60°C (without frost and non-condensing)			
Ambient humidity	35 to 80%RH (at 20°C non-condensing)			
Weight (with relay cable)	Approx. 60g	Approx. 90g	Approx. 200g	Approx. 295g

● Through type

Model No	AKW4506C	AKW4507C	AKW4508C
Primary side rated current	50A / 100A	250A / 400A	600A
Secondary side rated Current	16.7mA / 33.3mA	125mA / 200mA	200mA
Transform ratio	3000:1	2000:1	3000:1
Ratio error	±1.0%F.S.		
Hole Dia (mm)	φ 17	φ 36	
Breakdown voltage (initial)	AC1000V/1min (Between through hole and output lead wire)	AC2000V/1min (Between through hole and output lead wire)	
Insulation resistance (initial)	Min. 100MΩ (at DC500V) (Between through hole and output lead wire)		
Vibration resistance	Functional	10 to 55Hz (1 cycle/ minute) single amplitude of 0.15mm (10 min. on X,Y and Z axes)	
	Destructive	10 to 55Hz (1 cycle/ minute) single amplitude of 0.375mm (1 hrs. on X,Y and Z axes)	
Shock resistance	Functional	Min. 98m/s ² (4 times on X,Y and Z axes)	
	Destructive	Min. 294m/ s ² (5 times on X,Y and Z axes)	
Output protection level	±7.5V with clamp element	±3.0V with clamp element	
Ambient temperature	-10 to +50°C (without frost and non-condensing)		
Storage temperature	-20 to +60°C (without frost and non-condensing)		
Ambient humidity	35 to 80%RH (at 20°C non-condensing)		
Weight (with relay cable)	Approx. 70g	Approx. 200g	Approx. 215g


Note Dedicated current transformers (CT) are dedicated for low voltage under 440V. They can not be used for high voltage circuit. In case measuring high voltage circuit, make a 2-step construction by combination of a commercial CT of secondary side current 5A for high voltage and the dedicated CT for 5A.

Chapter 9 Mounting


9.1 Dimensions

9.1.1 Main unit

(unit: mm)



Panel cutout




Please keep space that the finger enters for the battery exchange at the left of the main unit (about 30mm).


9.1.2 Dedicated CT

◆ For 5A/50A (AKW4801C)


(unit: mm)
(tolerance: ±1.0)



◆ For 100A (AKW4802C)




◆ For 250A (AKW4803C)




Plug housing: SLP-02V (JST Mfg.Co.,Ltd.)
 Socket contact: SSF-21T-P1.4 (JST Mfg.Co.,Ltd.)
 (Applicable connector)
 Receptacle housing: SLR-02VF (JST Mfg.Co.,Ltd.)
 Pin contact: SSM-21T-P1.4 (JST Mfg.Co.,Ltd.)

◆ For 400A (AKW4804C)




Plug housing: SLP-02V (JST Mfg.Co.,Ltd.)
 Socket contact: SSF-21T-P1.4 (JST Mfg.Co.,Ltd.)
 (Applicable connector)
 Receptacle housing: SLR-02VF (JST Mfg.Co.,Ltd.)
 Pin contact: SSM-21T-P1.4 (JST Mfg.Co.,Ltd.)


◆ For 50/100A (AKW4506C)



◆ For 250A/400A (AKW4507C), For 600A (AKW4508C)




◆ Attached trunk cable (common)



9.1.3 Antenna


(unit: mm)
(tolerance: ± 1.0)

◆ Antenna with cable(AKW1803)




*This is included to the main unit.

◆ Pencil type antenna (AKW1802)



9.2 How to mount to DIN rail


- (1) Hook "A" of main unit on the upper side of DIN rail.
- (2) Making "A" part as a support fit the bottom side of main unit to DIN rail.
- (3) It will be completely fixed to DIN rail with a "click" sound.



9.3 How to connect / replace the battery


Be sure to connect the battery included before using the unit.

- (1) Remove the battery cover.
- (2) Insert the connector and put into the case.
- (3) Put the battery cover in.



Battery life is about 2 years; we recommend exchanging battery about 2 years from the beginning of the use. When battery has abnormal or battery power is reduced, "BATT" is blinking in the lower line. Please replace the battery according to the procedures in 1 minute.

When replacing, remove connector after taking from the case.



<Note>


Please throw away the replaced battery according to the instruction of your area.
Please insulate the terminal part by tape before throwing away.

9.4 Antenna

◆ Available Antennas

Model No.	Product Name	Contents
AKW1803	Antenna with cable	1pc., cable length: 2m
AKW1802	Pencil type antenna	1pc.

*AKR2802 and AKR2803 for KR20 are not available for KW1M-R.



■ Cautions when connecting to main unit

- When connecting an antenna in the connecting part, connect surely till the end having the connector part of an antenna.

■ Cautions when mounting antennas

- Be sure to connect antenna and set it vertical direction for the ground.
- Set antenna apart from metal plate. If antenna set in a metal control panel, wireless specifications will become low. When antenna set in a metal control panel, use an antenna with cable and set an antenna part outside the panel.
- In order to fix an antenna with cable, use attached double-faced tape or magnet. However, setting point should be metal plate for using magnet.
- When wiring the antenna with cable and the extension cable, the cable bend radius should be 50mm or more. Do not bend the root of connector (about 40mm).
- The antenna with cable and the pencil type antenna are used for indoors. In case of using outdoor, take the waterproof measures such as put in a plastic case.
- The top of antenna can be bent about 90 degree. Adjust the angle according to the radio wave condition.
- Set separate the antenna of different group more than 2m. If it set near, it influences each other and communication error might be increasing.
- When using the extension cable, radio attenuation happens. Using one decreases the transmission distance of about 30%, check beforehand using it. Using for both master and slave makes the transmission distance of about a half.

Chapter 10 Q&A

■ Hardware

Q1	I'd like to measure by Eco-POWER METER. Measured load is 50 to 60A in normal operation. But the inrush current is 130 to 140 A. Which CT is selected? (100A or 250A)
A1	Select 100A CT. Stable current more than 1 second is necessary to measure. The inrush current seems to be a few ms, therefore it can't measure it. In case there is current over 1 second (inrush current), it measures it and select 250A CT.
Q2	Current and voltage are displayed. But it can't measure an electric power.
A2	<ul style="list-style-type: none"> •Do you install CT to the correct position and correct direction? CT has directions. Install CT according to the direction marked. From power supply side (K) to load side (L). •Do you wire measurement voltage input correctly? When phases of voltage and current are not matched, it can't measure correctly. Please check the wiring.
Q3	How long can I extend CT cable?
A3	You can extend up to about 10 m with cable of AWG#22 or more. We can't guarantee the specifications if you extend more than 10m.
Q4	How do you guarantee the accuracy of measurement with low current range?
A4	Up to 5% for CT rating. In case of CT50A, for an electric power with current 2.5A or more, the accuracy is $\pm 2.0\%$. (For PF=1)
Q5	"BATT" is displayed.
A5	It is notice to reduce battery. Do you connect battery attached? If the battery is connected, it is time to replace. Replace to new battery.
Q6	Keys operation doesn't work.
A6	Isn't it in LOCK mode? When "LOCK" indicator is displayed, it set to the lock mode. Press <SET> continuously to release the lock mode.

■ Coping processed wham errors about communication

Error contents	Causes and coping processes
Unidentified network error (Err13) is displayed regularly.	<ul style="list-style-type: none"> • Is group number of the master same as group number of the slave? • Is the distance between the master and the slave too far? • At the time power on, it happens until it finds the master.
Data communication is impossible. (Err1)	<ul style="list-style-type: none"> • Do you transmit data with size suitable for the protocol? MEWTOCOL: 2048 byte max. MODBUS (RTU): 256byte max. When set to 1:1 topology, it transmits up to 2048byte. • Is the communication setting of the main unit same as the setting of the connected terminals? • Don't you transmit other protocol data than MEWTOCOL and MODBUS (RTU)? If you transmit other protocol, set 1:1 topology.
Even if the communication setting is correct, Err1 is displayed.	Data might be collided because the time-out of upper device is shorter than the time-out of master's. Refer to Chapter 8 "■ Timeout period of master", and set the time-out of upper device longer than master's.
Wireless communication is impossible.	<ul style="list-style-type: none"> • Is the communication setting of the master same as the setting of the slave? 1:1 or 1: N It is necessary to set as same. *AKW1131(K) is fixed "1: N". • Isn't an unidentified network error (Err13) happened? The distance to the master is too far. Group number is different.
TX/RX indicator (Green) isn't blinking when sending data.	<ul style="list-style-type: none"> • Do you wire correctly? (RD, SD, +, -) • Is flow control setting same as the setting of connected device? The connected device may not support flow control. Set the main unit flow control setting to off. • Is the setting of RS232C/RS485 same?
"Err81" is displayed when sending data.	There is no slave within the communication area of the master. Mount a repeater (AKW1000(K) or AKW1131(K)) between the using slave and the master.
Communication is cut during RSSI monitor.	It is impossible to RSSI monitoring and data transmission at the same time. It takes several seconds to return normal working from RSSI monitoring.
Data at night can't be received.	<ul style="list-style-type: none"> Don't you use any other wireless communication device or a device generated noise at night? Don't you turn off the power of the slave or terminals? <p>Read out error log of the master and check whether any other device is used and the slave is power off and so on at the time of happening error.</p> <p>*Refer to Main unit error log list for error log contents.</p>

■ Main unit error log list

The contents of display on the main unit are as below.

You can read out error log memorized in the main unit by using "KW Network Monitor".

Reading out error log shows the happening time of error.

Number	Type	Error	Error conditions
1	Master/Slave	Serial communication error	Communication error at serial communication When data size is larger than sendable byte. (When data over 2048 byte is received with wire and so on)
13	Slave	Unidentified network error	When it can't find master or it lose master. It always happens until find a master when power on.
21	Master	Terminal registration error	When 2 or more terminals with same station number exist. Check if 2 or more units have the same station number or not.
46	Master	Busy error	When another command except wireless communication is processed. Concretely, when flow control setting is different, when it is not connected to other device although it set flow control available.
54	Master	Time out error	When response from slave is time-out. <ul style="list-style-type: none"> • Command from upper device is different. • No radio wave to a slave • Data size is large.
60	Master/Slave	Unsupported protocol error	When protocol is different from the designated. When transmission speed is different. Check the protocol and baud rate.
81	Master/Slave	Wireless communication error	No slave is connected to the network.
82	Master	No connection with terminal error	When communication between master and registered slave is cut. Check if the terminals power on.

*The time when errors happen is memorized at the main unit's calendar timer.

Set the calendar timer at initial settings.

*In order to delete error log, initialize the communication settings of the main unit.

In this case, notice that the communication settings are also initialized.

Revision History

Issue Date	Manual no.	Content of revision
May, 2010	ARCT1F498E	First edition
March, 2012	ARCT1F498E-1	[Add functions] Wired/Wirelss setting function 600A CT input Add through type CT [Improve spec.] Improve the accuracy

Please contact

Panasonic Electric Works SUNX Co., Ltd.

■ Head office: 2431-1 Ushiyama-cho, Kasugai-shi, Aichi, 486-0901, Japan

■ Telephone: +81-568-33-7861

■ Facsimile: +81-568-33-8591

panasonic.co.jp/id/pidsx/global

All Rights Reserved © 2012 COPYRIGHT Panasonic Electric Works SUNX Co., Ltd.