

GW Professional Weighing Scale

User Manual



**SNOWREX INTERNATIONAL
CO., LTD.**

SRGW 20100415

Table of Contents

| | |
|--|----------|
| Table of Contents | 1 |
| Specifications | 2 |
| Basic specification..... | 2 |
| Series specification(EC TYPE/OIML APPROVED)..... | 2 |
| Series specification(NON-APPROVED)..... | 2 |
| Display and keypad | 3 |
| LCD Display..... | 3 |
| Keypad..... | 4 |
| Using the weighing scale..... | 6 |
| Counting function..... | 6 |
| Percentage function..... | 6 |
| Operation of M+ | 6 |
| Operation of MR | 6 |
| Alarm function | 7 |
| Settings and Calibration | 8 |
| General Settings (CAL 1)..... | 8 |
| Print Settings (CAL 2)..... | 9 |
| Calibration Procedure (CAL 3) | 11 |
| Linearity Calibration Procedure (CAL 4) | 12 |
| RS232C Connection: DB-09 (Male)..... | 13 |
| Bi-directional RS232C Setting..... | 13 |

Specifications

Basic specification

| | |
|------------------------------|---|
| Display Digit | LCD, height 17mm, 6/6(Parameter/WEIGHT) |
| Pan Size(mm) | 280 x 200 (WxL) |
| Dimensions(mm) | 280x300x110(WxLxH) |
| Net Weight(kg) | 3.6kg |
| Operating Temperature | 0° C to +40° C |
| Relative Humidity | Less than 85% |
| Power | DC9V / 500mA, AC adapter; Built in 6V Rechargeable Battery |
| Interface | RS-232C (optional) |

Series specification(EC TYPE/OIML APPROVED)


| Model | GW-6D | GW-15D | GW-30D |
|---|--------------|---------------|---------------|
| Max₁ / Max₂= | 3kg / 6kg | 6kg / 15kg | 15kg / 30kg |
| Min₁ / Min₂= | 20g / 3kg | 40g / 6kg | 100g / 15kg |
| e₁ / e₂= | 1g / 2g | 2g / 5g | 5g / 10g |
| Accuracy | 1/3000(Dual) | 1/3000(Dual) | 1/3000(Dual) |

Series specification(NON-APPROVED)

| Model | GW-3H | GW-6H | GW-15H | GW-30H |
|----------------------|--------------|--------------|---------------|---------------|
| Max. Capacity | 3kg | 6kg | 15kg | 30kg |
| d = | 0.1g | 0.2g | 0.5g | 1g |
| Accuracy | 1/30000 | 1/30000 | 1/30000 | 1/30000 |


Display and keypad

LCD Display



| | |
|------------|--|
| | Numerical display to display weight, ID number |
| | Indicates the weight is stable. |
| | Indicates the weight is at zero. |
| MR | Indicates the total weights in memory |
| M+ | Indicates the accumulation weights in memory. |
| G.W | When ▼ is shown above the G.W. indicator, the Gross Weight is displayed. |
| NET | When ▼ is shown above the NET. indicator, the Net Weight is displayed. |
| T.W | When ▼ is shown above the T.W. indicator, the Tare Weight is displayed. |
| Hi | When the weight is over the weight upper bound, ► is flashing next to the Hi indicator. |
| Go | When the weight is between the weight upper bound and lower bound, ► is flashing next to the Go indicator. |
| Lo | When the weight is under the weight lower bound, ► is flashing next to the Lo indicator. |
| | ▼ is shown above the when in counting mode. |
| | ▼ is shown above the when in percentage mode. |
| kg & lb | Indicate the unit of weight |

Keypad



| Key Icons | Keypad | Descriptions |
|-----------|---------------------|---|
| | Zero key | Press to absorb trivial weight on the pan and set the scale to zero. |
| | Tare key | Press to perform tare operation. |
| & | Number setting keys | Press “+1” key to increase number and press “shift” to shift the digit. |
| | Clear key | Press to clear the input data. |
| | M+ key | Press to accumulate piece counting and weighing results. |
| | MR key | Press to recall total number of accumulation and total weighing. |
| | Alarm key | Press to set alarm for weight upper and lower bound. |
| | Backlight key | Press to set backlight on or off. |
| | Function key | Press to toggle among weighing, percentage and counting modes. |
| | Sampling key | Press to set up sample quantity. |
| | Percentage key | Press to set up percentage of the given sample. |
| | Print key | Press to print the weight data. |

| | | |
|---|--------------------|---|
|  | Unit key | Press to switch between kg and lb. |
|  | ID key | Press to enter the ID mode. Use the numeric keypad to enter the user's ID number. |
|  | Gross/Net/Tare key | Press to toggle among Gross Weight, Net Weight, and Tare Weight on the display. |

Using the weighing scale

Counting function

1. Put certain pieces of objects on to the scale pan.
2. In weighing mode, press , and then use  &  keys to set the piece counts.
3. Press  to confirm.
4. Now you are ready to perform parts counting for the specific samples.

Percentage function

1. Put certain pieces of objects on to the scale pan.
2. Press  and then use  &  keys to enter the percentage of the sample,
3. Press  to confirm.
4. Place objects of desired piece counts on the weighing pan. The percentage of the objects will be calculated automatically.

Operation of M+

1. When there is a load on the weighing pan, press  and after a beep sound, the ► indicator let to **M+** icon will light up on the LCD, indicating a data has been recorded.
2. Clear the load and put another load on the weighing pan. When the scale become stable, press  to record another load weight

- *After each recording, if the load on the weighing pan is not cleared, pressing  will result in the beep and the scale won't be able to record the next weighing result.*
- *The stored memory can memorize up to 180 weighing results.*

Operation of MR

1. In weighing mode, press  to display the accumulated weighing result. The LCD display will show the total number of accumulation and the total weight alternatively. For instance, if you added two weighing results and the total weight add up to 4.0 kg. The scale will show **tot.002**, and **4.000** kg

2. Press  to exit the MR mode without clearing the data in memory.

Alarm function

1. Press  key to set the upper bound of the weight. The **Hi** is showing in the left window.
2. Set up the weight upper bound with the  &  keys. Press  to confirm to save your Hi setting. And then move to Lo setting.
3. The **Lo** is showing in the left window. Press the  &  keys to set the lower bound of the weight.
4. Press  to confirm to save your Lo setting. And then back to weighing mode.

Note:

- *While the weight exceeds the upper bound of Weight Upper Bound, or lower than the Weight Lower Bound, or between the lower and upper bound and is not zero, the scale may beep for warning.*

You may change the beep settings in CAL 1 menu.

Settings and Calibration

1. Press and hold any key while turning the scale ON. **CAL 1** is shown on the LCD display.

2. Press  key to toggle among the **CAL 1**, **CAL 2**, **CAL 3**, and **CAL 4** menus.

3. Select **CAL 1**, press  to enter General Settings menu.

4. Select **CAL 2**, press  to enter the Print Settings menu

6. Select **CAL 3**, press  to enter Calibration procedure.

7. Select **CAL 4**, press  to enter Linearity Calibration procedure.

Note: To perform CAL 3 and CAL 4 calibration, you must remove the JP3 jumper from the PCB first.

Put the JP3 back after calibration is complete.

General Settings (CAL 1)

In the General Settings menu, press  to toggle among the options, and  to confirm.

1. Aut.oFF– Auto Off Setting

| Display | Descriptions |
|----------------|---|
| A.oFF 0 | Disable auto shutdown function. |
| A.oFF 1 | If there is no operation, the scale will shut down in 5 minutes. |
| A.oFF 2 | If there is no operation, the scale will shut down in 10 minutes. |
| A.oFF 3 | If there is no operation, the scale will shut down in 20 minutes. |
| A.oFF 4 | If there is no operation, the scale will shut down in 30 minutes. |

2. Pcnt.dP – Percentage decimal Setting

| Display | Descriptions |
|---------------------|--------------|
| Pcnt.dP 0.0 | 100.0 %. |
| Pcnt.dP 0.00 | 100.00 % |

3. bbH - Hi Beep Setting

| Display | Explanation |
|---------------|--|
| bbH_ 0 | Disable Hi alarm sound. |
| bbH_ 1 | Set Hi alarm sound as continual short beeps. |
| bbH_ 2 | Set Hi alarm sound as continual long beeps. |

4. bbS - Go Beep Setting

| Display | Explanation |
|---------|--|
| bbG_0 | Disable Hi alarm sound. |
| bbG_1 | Set Hi alarm sound as continual short beeps. |
| bbG_2 | Set Hi alarm sound as continual long beeps. |

5. bbL – Lo Beep Setting

| Display | Explanation |
|---------|--|
| bbL_0 | Disable Hi alarm sound. |
| bbL_1 | Set Hi alarm sound as continual short beeps. |
| bbL_2 | Set Hi alarm sound as continual long beeps. |

Print Settings (CAL 2)

Press  to toggle among the options. Use the numeric keys to input data and press  to save your settings.

1. Print Settings

| Display | Descriptions |
|---------|---|
| Pr.dEFA | Set the print format to default settings. |
| Pr.LP50 | Set the print format to LP-50 printer. |

2. Printout setting

| Display | Descriptions |
|-----------|---|
| P. PrESS | Press M+ to print single weighing result. Press C in MR mode to print accumulated weighing result and total accumulation. |
| P. StAb.1 | Print weighing result (Net wt, Pc. wt, Pc. count) when the scale is stable and weight > 0. * Pressing M+ and MR do not print. |
| P. StAb.2 | Print Net wt when the scale is stable and weight > 0. * Pressing M+ and MR do not print. |
| P. ALL.1 | Press M+ to print single weighing result. Press C in MR mode to print accumulated weighing result and total accumulation. Print weighing result (Net wt, Pc. wt, Pc. count) when the scale is stable and weight > 0. |

| | |
|-----------------|--|
| P. ALL.2 | Press M+ to print single weighing result. Press C in MR mode to print accumulated weighing result and total accumulation. Print Net wt when the scale is stable and weight > 0. |
| P.Count | Continuous printing weight data. Usually used for sending weight data to PC. |
| P. oFF | Print function disabled. |

3. Baud Rate

| Display | Descriptions |
|----------------|---------------------------|
| br2400 | Set the baud rate to 2400 |
| br4800 | Set the baud rate to 4800 |
| br9600 | Set the baud rate to 9600 |

4. Parity Setting

| Display | Descriptions |
|------------------|-------------------------|
| PA. 7-E-1 | Set the parity to 7-E-1 |
| PA. 7-o-1 | Set the parity to 7-o-1 |
| PA. 7-n-2 | Set the parity to 7-n-2 |
| PA. 8-n-1 | Set the parity to 8-n-1 |
| PA. 8-E-1 | Set the parity to 8-E-1 |
| PA. 8-o-1 | Set the parity to 8-o-1 |

Calibration Procedure (CAL 3)

Please remove the JP3 jumper before you start the calibration process.

In Calibration menu, press  to toggle among the menu options. And press  to confirm.

1. SEL maximum capacity

| Display | Descriptions |
|-------------|--------------------------------|
| LoAd 06d | Set maximum capacity as 6 kg. |
| LoAd 15d | Set maximum capacity as 15 kg. |
| LoAd 30d | Set maximum capacity as 30 kg. |

2. A0

| Display | Descriptions |
|-----------|--------------------------------------|
| A0 0(off) | Zero tracking function is disabled. |
| A0 1(on) | Zero tracking function is activated. |

3. Zero Point Calibration

| Display | Descriptions |
|---------------|---|
| Pnt. 0 XXXXXX | The right window shows AD Value of Zero weight. Wait until the AD value becomes stable, press  to confirm. |

4. Setup calibration weight

| Display | Descriptions |
|--------------------|--|
| Pnt. CAL XXXXXX | Put 1/3 or 2/3 or 3/3 of full load on the weighing pan. The right window shows AD Value of the load. Wait until the AD value becomes stable, press  to confirm. |
| Display | Descriptions |
| Pnt. CAL 1/2/30000 | The right window will cycle display the 1/3,2/3,3/3 of full load. When the weight displayed equal to the load weight, press  to confirm. The window will show “done”. |

Remove the load from the weighing pan, and the scale will restart and the calibration is done.

Linearity Calibration Procedure (CAL 4)

Note: This section can only be operated by engineers.

Please have the jumper JP3 switch OFF before you start the calibration process.

In Calibration menu, press  to toggle among the menu options. And press  to confirm.

1. Zero Point Calibration

| Display | Descriptions |
|---------|---|
| Pnt 0 | The AD Value is then displayed in the right window. |

Make sure the weighing pan is empty. Wait until the AD value becomes stable, press  to proceed.

2. Calibration by 1/3 of the maximum capacity

| Display | Descriptions |
|---------|---|
| Pnt 1 | The AD Value of 1/3 of the full load is then displayed. |

Put on poise of the 1/3 weight by the maximum capacity. Wait until the AD value becomes stable, press  to proceed.

3. Calibration by 2/3 of the maximum capacity

| Display | Descriptions |
|---------|---|
| Pnt 2 | The AD Value of 2/3 of the full load is then displayed. |

Put on poise of the 2/3 weight by the maximum capacity. Wait until the AD value becomes stable, press  to proceed.

4. Calibration by the maximum capacity

| Display | Descriptions |
|---------|--|
| Pnt 3 | The AD Value of the full load is then displayed. |

Put on poise of full capacity of the scale. Wait until the AD value becomes stable, press . The linearity calibration is complete.

RS232C Connection: DB-09 (Male)

Pin setup: 2 (TXD) 3 (RXD) 5 (GND) others (NC)

Bi-directional RS232C Setting

This section is applicable only for models with RS-232C module.

OUTPUT FORMAT

| | | | | | | | | | | | | | |
|-----|------|----------------|----------------|----------------|----------------|----------------|----------------|----------------|-------|----------------|----------------|----|----|
| STA | SIGN | W ₆ | W ₅ | W ₄ | W ₃ | W ₂ | W ₁ | W ₀ | SPACE | U ₁ | U ₀ | CR | LF |
|-----|------|----------------|----------------|----------------|----------------|----------------|----------------|----------------|-------|----------------|----------------|----|----|

| | |
|----------------------------------|--|
| STA | 'U' (55h) indicates it's an unstable weight. 'S' (53h) indicates it's a stable weight. |
| SIGN | '-' (2Dh) means it's a negative weight. ' ' (20h) space char indicates it's a positive or zero weight. |
| W ₆ ...W ₀ | Weight data, decimal point included. |
| SPACE | 20h |
| U ₁ , U ₀ | 'k' (6Bh) 'g' (67h) indicates that the unit is kilogram. 'l' (6Ch) 'b' (62h) indicates that the unit is lb. |
| CR | 0Dh |
| LF | 0Ah |

Command:

| COMMAND | Actions | Response |
|-------------|---------|--|
| <ENQ> (05h) | | the weight string (not available when the print format is set to OFF or PRESS.) |