

# POSITIONServo



S950

## Model 940 PROGRAMMING MANUAL

**Copyright ©2005 by AC Technology Corporation.**

All rights reserved. No part of this manual may be reproduced or transmitted in any form without written permission from AC Technology Corporation. The information and technical data in this manual are subject to change without notice. AC Tech makes no warranty of any kind with respect to this material, including, but not limited to, the implied warranties of its merchantability and fitness for a given purpose. AC Tech assumes no responsibility for any errors that may appear in this manual and makes no commitment to update or to keep current the information in this manual.

MotionView®, Positionservo®, and all related indicia are either registered trademarks or trademarks of Lenze AG in the United States and other countries.

This document printed in the United States of America

# Table of Contents

|                                                            |    |
|------------------------------------------------------------|----|
| 1. Getting Started .....                                   | 5  |
| 1.1 Introduction .....                                     | 5  |
| 1.2 Getting started with the PositionServo Model 940 ..... | 6  |
| 1.3 Programming flow overview .....                        | 7  |
| 1.4 MotionView / MotionView Studio .....                   | 8  |
| 1.5 Programming Basics .....                               | 10 |
| 1.6 Using advanced debugging features .....                | 17 |
| 1.7 Inputs and Outputs .....                               | 17 |
| 1.8 Events .....                                           | 22 |
| 1.9 Variables and Define statement .....                   | 24 |
| 1.10 IF/ELSE statements .....                              | 25 |
| 1.11 Motion .....                                          | 25 |
| 1.12 Subroutines and Loops .....                           | 30 |
| 2. Programming .....                                       | 31 |
| 2.1 Introduction .....                                     | 31 |
| 2.2 Variables .....                                        | 33 |
| 2.3 Arithmetic's .....                                     | 34 |
| 2.4 Logical expressions and operators .....                | 34 |
| 2.5 Bit wise operators .....                               | 34 |
| 2.6 Boolean Operators .....                                | 35 |
| 2.7 Comparison operators .....                             | 35 |
| 2.9 System Variables and Flags .....                       | 35 |
| 2.10 System Variables storage organization .....           | 36 |
| 2.11 System Variables and Flags Summary .....              | 36 |
| 2.12 Control structures .....                              | 37 |
| 2.13 Scanned Event Statements .....                        | 40 |
| 2.13 Motion .....                                          | 41 |
| 2.14 System Status Register (DSTATUS register) .....       | 47 |
| 2.15 Fault Codes (DFAULTS register) .....                  | 48 |
| 2.16 Limitations and restrictions .....                    | 49 |
| 3. Language Reference .....                                | 50 |
| Appendix A. Complete list of variables .....               | 67 |

## Safety Information

All safety information given in these Operating Instruction have the same layout:



**Signal Word!** (Characterizes the severity of the danger)

Note (describes the danger and informs on how to proceed)

| Icon                                                                              |                                         | Signal Words    |                                                                                                                                                    |
|-----------------------------------------------------------------------------------|-----------------------------------------|-----------------|----------------------------------------------------------------------------------------------------------------------------------------------------|
|  | Warning of hazardous electrical voltage | <b>DANGER!</b>  | Warns of <b>impending danger</b> .<br>Consequences if disregarded:<br>Death or severe injuries.                                                    |
|  | Warning of a general danger             | <b>WARNING!</b> | Warns of <b>potential, very hazardous situations</b> .<br>Consequences if disregarded:<br>Death or severe injuries.                                |
|  | Warning of damage to equipment          | <b>STOP!</b>    | Warns of <b>potential damage to material and equipment</b> .<br>Consequences if disregarded:<br>Damage to the controller/drive or its environment. |
|  | Information                             | <b>Note</b>     | Designates a general, useful note.<br>If you observe it, handling the controller/drive system is made easier.                                      |

# 1. Getting Started

## 1.1 Introduction

### Definitions

**Model 940 PositionServo:** The Model 940 is a Programmable Digital Drive/Motion Controller, which can be configured as a stand alone Programmable Motion Controller, or as a high performance Torque and Velocity Drive for Centralized Control Systems.

**MotionView:** MotionView is a universal Communication and Configuration Software utilized by the 94 and 940 drives. It has an automatic self-configuration mechanism that recognizes what drive it is connected to and configures the tool set accordingly. The MotionView platform is divided up into three sections or windows, the "Parameter Tree Window", the "Parameter View Window" and the "Message Window". Refer to Section 1.3 for more detail.

**SimpleMotion Programming Language (SML):** SML is the programming software utilized by MotionView. The SML software provides a very flexible development environment for creating solutions to motion applications. The software allows you to, create complex and intelligent motion moves, process I/O, perform complex logic decision making, do program branching, utilize timed event processes, as well as a number of other functions found in PLC's and high end motion controllers.

**User Program (or Indexer Program):** This is the SML program, developed by the user to describe the programmatic behavior of the 940 drive. The User Program can be stored in a text file on your PC or in the 940's memory. The User Program needs to be compiled (translated) into binary form before the 940 can execute it with the aid of the MotionView Studio tools.

**MotionView Studio:** MotionView Studio is a part of the MotionView software platform. It is a tool suite containing all the software tools needed to program and debug a PositionServo. These tools include a, full-screen text editor, program compiler, status and monitor utility, online oscilloscope and a debugger function that allows the user to step through the program during program development.



### WARNING!

- Hazard of unexpected motor starting! When using the MotionView software, or otherwise operating the PositionServo 940 drive over RS-232/485 or Ethernet, the motor may start unexpectedly, which may result in damage to equipment and/or injury to personnel. Make sure the equipment is free to operate in this manner, and that all guards and covers are in place to protect personnel.
- Hazard of electrical shock! Circuit potentials are at 115 VAC or 230 VAC above earth ground. Avoid direct contact with the printed circuit board or with circuit elements to prevent the risk of serious injury or fatality. Disconnect incoming power and wait 60 seconds before servicing drive. Capacitors retain charge after power is removed.

## 1.2 Getting started with the PositionServo Model 940

Before the PositionServo 940 can execute a motion program it has to be properly installed and configured. First time users are encouraged to read through the appropriate sections in this manual for the best configuration of the 940's programmable features and parameters. They are also encouraged to reference the PositionServo User's Manual for the proper hardware installation.

The PositionServo 940 drive has a number of features and parameters which can be programmed via the MotionView Software. Below is a list of programmable features and parameters specific for operation under program control. They are listed in the order they appear in the 'Parameter Tree Window' in MotionView. Please refer to Position Servo Model 940 User's Manual for details on parameters not covered below.

### Parameters

- **Autoboot - Enable / Disable**

If this option is Enabled the drive will start executing the user program stored in the drives flash memory at Power Up. If there is not a valid program existing in the flash memory, then the program must be started manually via MotionView or a Host Interface.



#### **DANGER!**

Hazard of unexpected motor starting! When using the MotionView software, or otherwise operating the PositionServo 940 drive over RS-232/485 or Ethernet, the motor may start unexpectedly, which may result in damage to equipment and/or injury to personnel. Make sure the equipment is free to operate in this manner, and that all guards and covers are in place to protect personnel.

- **Group ID**

The Group ID feature allows you to group 940 drives together via an Ethernet network. When used with the SEND and SENDTO command, drives in the same group can share and updated variables. Group ID Numbers can be set between 0 and 32767. See statements SEND and SENDTO for further explanations.

### Communication

- **IP Setup** - Displays properties and settings for Ethernet communication port (IP Address).

### Digital I/O

- **Inputs**

- The 940 has 12 Digital Inputs. The inputs are grouped into three set of four, [A1 - A4 ], [B1 - B4], and [C1 - C4]. Each group shares its own common, [Acom, Bcom, and Ccom].
- Inputs can be assigned individual debounce times via MotionView. Debounce times can be set between 0 and 1000ms. (1ms = 0.001 Sec)
- Inputs can be, monitored via the user program, monitored via a host interface, and / or be assigned Special Purpose Functions. Refer to Section 1.6 for more detail.

- **Outputs**

- The 940 has 5 Digital Outputs. One output is dedicated and will only come on when the drive is Enabled and is in the RUN mode. Outputs 1 - 4 can be either, activated via the user program, activated via a host interface, or be assigned a Special Purpose Function. Refer to Section 1.6 for more detail.

### Indexer Program


When the Indexer program file is selected from the node tree, the Parameter View Window displays the drives user program. This area can now be used to enter, edit and debug the user program. Also additional programming features will be displayed in the menu and toolbar. Refer to Section 1.3 for more detail.

### 1.3 Programming flow overview

MotionView utilizes a basic like programming structure referred to as SimpleMotion programming Language (SML). SML is a quick and easy way to create powerful motion applications.


With SML you describe your system logistics, motion, I/O processing and user interaction, programmatically i.e. creating the program. The program structure includes a full set of arithmetic and logical operator programming statements, which allow the user to command motion, process I/O and control program flow.

Before the 940 drive can execute the users program the program first needs to be compiled (translated) into binary machine code, and downloaded to the drive. Compiling the program is done by selecting the “Compile” button from the toolbar. You can also compile and download the program at the same time by selecting the “Compile and Load” button from the toolbar. Once downloaded, the compiled program is stored both in the 940’s memory as well as in the internal flash memory. The figure below summarizes program preparation process.



S801


## 1.4 MotionView / MotionView Studio



S802

MotionView is the universal programming software used to communicate and configure the 94 and 940 drives. The MotionView platform is segmented into three windows. The first window is the **"Parameter Tree Window"**. This window is used much like Windows Explorer. The various parameters for the drive are represented here as folders or files. Once the desired parameter file is selected, all of the corresponding information for that parameter will appear in the second window, the **"Parameter View Window"**. The user can then enable, disable or edit drive features or parameters. The third window is the **"Message Window"**. This window is located at the bottom of the screen and will display any and all communication status and errors.

### MotionView Studio




S803

### Motionview Studio Screen layout

MotionView Studio is part of the MotionView universal program and provides a tool suite used to enter, compile, load and debug the user program. To view and develop the user program the, "Indexer Program" file, must be selected from the Parameter Tree Window. Once this file is selected the User program will be displayed in the "Parameter View Window" and the Studio's tool set will become available. This will allow the user to edit, compile and debug the User Program. The displayed Program is the current program stored in the drive. When Motion View starts, it always loads the current program text from the 940's memory. This action is always performed regardless of program run state. PositionServo supports incremental quadrature encoder or resolver feedback devices. A second encoder can also be supported during position and velocity modes.



## Studio tool suite Menu & Toolbar Options



### Studio tool suite Menu

When developing or editing a program, additional Menu options tabs become available. The additional options tabs are Indexer and Edit. These tabs are only available when you are in the programming area (Parameter View Window). These options are used to, load, compile, save and debug the program. The following are examples on how to utilize these option tabs.

Please note that to utilize these features you must select "Indexer program" from the node tree. This will expand the menu options. You then have to click your mouse anywhere in the Parameter View Window to activate Menu Tabs.

#### Load User program from the PC to MotionView

- Select "**Indexer**" from the pull down menu.
- Select "**Import program from file**" from the drop down menu and select desired program.

This procedure loads the program from file to the editor window. It doesn't load the program to the 940 drive's memory.

#### Compile program and load to 940 drive

- Select "**Indexer**" from the pull down menu.
- Select "**Compile and send to drive**" from the drop down menu.

To check syntax errors without loading the program to drive select "**Compile**" from the "**Indexer**" menu. If the compiler finds any syntax error, compilation stops and program will not be loaded to drive's memory. Errors are reported in bottom portion of the screen in Message Window.

#### Save User program from MotionView to PC .

- Select "**Indexer**" from the pull down menu.
- Select "**Export program to file**" from the drop down menu.

The program will default to saving the program in the MotionView "**User Data**" file.

#### Run User program in drive.

- Select "**Indexer**" from the pull down menu.
- Select "**Run**" from the drop down menu.

If the program is already running then you might need to **Restart** or **Stop** the program first.

#### Execute Program Step through the User program.

- Select "**Indexer**" from the pull down menu.
- Select "**Step in / Step over**" from the drop down menu.

The 940 will execute the program one step at a time. The current program statement will be highlighted. If the program is running it will have to be either stopped or restarted.

#### Set Breakpoint(s) in the program

- Select the point in the program where you would like the program to stop.
- Select "**Indexer**" from the pull down menu.
- Select "**Toggle breakpoint**" from the drop down menu.

A convenient way to debug a User program is to insert breakpoints at critical junctions throughout the program. These breakpoints are marked by red dots and stop the drive from executing the program but do not disable the drive and the position variables. Once the program has stopped the user can continue to run the program, step through the program or restart the program.

#### Stop program execution

- Select "**Indexer**" from the pull down menu.
- Select "**Stop**" from the drop down menu.

The program will stop after completing the current statement. You can resume the program by selecting Run. Please note that the STOP button doesn't stop or disable the motion it only stops the execution of the program code.

### Restart Program execution


- Select “**Indexer**” from the pull down menu.
- Select “**Restart**” from the drop down menu.

The program will be reset and the drive will be disabled. All the position variables will no longer be valid.

### Studio tool suite Toolbar Options

When developing a User program, the MotionView Studio Toolbar becomes available. The toolbar supplies shortcuts to most of the options found in the **Indexer** Menu Option Tab. The toolbar is only available when you are in the programming area

(Parameter View Window). These options are used to, load, compile, save and debug the program.



S805

**MotionView Studio toolbar Icons**

## 1.5 Programming Basics

The User program consists of commands which when executed will not only initiate motion moves but also process the drives I/O and make decisions based on drive parameters. Before motion can be initiated certain Drive and I/O Parameters must be configured. To configure these parameters perform the following procedure.

**Parameter setup** - Select “**Parameter**” from Parameter Tree Window and set the following parameters.

#### Set the Drive mode to Position.

- Select “**Drive mode**” from the Parameter View Window.
- Select “**Position**” from the pull down menu.

#### Set the Reference mode to Internal.

- Select “**Reference**” from the Parameter View Window.
- Select “**Internal**” from the pull down menu.

#### Set the Enable Switch Function to Inhibit.

- Select “**Enable Switch Function**” from the Parameter View Window.
- Select “**Inhibit**” from the menu.

### I/O Configuration

Input A3 is the Inhibit/Enable special purpose input. (See section 1.6 for more information). Before executing a program input A3 must be activated to enable the drive and take it out of Inhibit mode. Note: If the drive starts to execute the user program and comes to an “Enable” command and input 3A is not made then the following fault will occur “F\_36”, (“Drive Disable”).

### Basic Motion Program


Select “**Indexer program**” from the Parameter Tree. The Parameter View Window will display the current User Program stored in the 940 drive. Note that if there is no valid program in the 940’s memory the program area will be empty.

Clear any existing program and replace it with the following Program:

```
UNITS=1
ACCEL = 5
DECEL = 5
MAXV = 10
ENABLE
MOVED 10
MOVEDISTANCE -10
END
```



After the text has been entered into the program area, select the “Compile and load” icon from the toolbar. After compilation is done, the following message should appear:



S806

Click “OK” to dismiss the “Compilation error” dialog box. The cause of the Compilation error will be displayed in the Message Window, located at the bottom of your screen. MotionView will also highlight the program line where the error occurred.


```
UNITS=1
ACCEL = 5
DECEL = 5
MAXV = 10 ;
ENABLE
MOVED 10 ;
MOVEDISTANCE -10
END
```

The problem in this example is that “**MOVEDISTANCE**” is not a valid command. Change the text “**MOVEDISTANCE**” to “**MOVED**”.

```
UNITS=1
ACCEL = 5
DECEL = 5
ENABLE
MOVED 10
MOVED -10
END
```



After editing the program, select the “Compile and load” icon from the toolbar. After compilation is done, the following message box should appear.



S807

The program has now been compiled and loaded to the drives memory and is ready to run. Click “OK” to dismiss the dialog box.



To **Run** the program, select the “**Go**” icon from the toolbar. The drive will start to execute the User Program. The motor will spin 10 revolutions in the CCW direction and then 10 revolutions in the CW direction. After the all the code has been executed the program will stop and the drive will stay enabled.



To **Restart** the program, select the “**Restart**” icon from the toolbar. This will disable the drive and reset the program to execute from the start. Note that the program does not run itself automatically. To run the program again, either select the “**Run**” icon from the toolbar or select “**Run**” from the “**Indexer**” pull down menu.

## Program Layout

When developing a program it is important to structure the program. It is recommended that the program be divided up into the following 7 sections:

- Header:** The header defines the title of the program, who wrote the program and description of what the program does. It may also include a date and rev number.
- I/O List:** The I/O list defines what the inputs and outputs of the drive are being use for. For example input A1 might be used as a Start Switch.
- Init & Set Var:** Initialize and Set Variables defines the drives settings and system variables. For example here is where acceleration, deceleration and max speed, are set.
- Events:** An Event is a small program that runs independently of the main program. This section is used to define the Event.
- Main Pgm:** The Main Program is the area where the process of the drive is defined.
- Sub-Routines:** This is the area where any and all sub-routines should reside. These routines will be called out from the Main Program with a GO SUB command.
- Fault Handler:** This is the area where the Fault Handler code resides. If a Fault handler is utilized this code will be executed when the drive generates a fault.

The following is an example of a Pick and Place program divided up into the above segments.

```
***** HEADER *****
;Title:      Pick and Place example program
;Author:     Lenze / AC Technology
;Description: This is a sample program showing a simple sequence that
;            picks up a part moves to a set position and drops the part
;***** I/O List *****
;   Input A1   -   not used
;   Input A2   -   not used
;   Input A3   -   Enable Input
;   Input A4   -   not used
;   Input B1   -   not used
;   Input B2   -   not used
;   Input B3   -   not used
;   Input B4   -   not used
;   Input C1   -   not used
;   Input C2   -   not used
;   Input C3   -   not used
;   Input C4   -   not used
;   Output 1   -   Pick Arm
;   Output 2   -   Gripper
;   Output 3   -   not used
;   Output 4   -   not used
;***** Initialize and Set Variables *****
UNITS = 1
ACCEL = 75
DECEL =75
MAXV = 10
;V1 =
;V2 =
```

```

;***** Events *****
;Set Events handling here
;***** Main Program *****
PROGRAM_START:
ENABLE
MOVED 10           ;Move to Pick position
OUT1 = 1           ;Turn on output 1 on to extend Pick arm
WAIT TIME 500      ;Delay 1/2 sec to extend arm
OUT2 = 1           ;Turn on output 2 to Engage gripper
WAIT TIME 500      ;Delay 1/2 sec to Pick part
OUT1 = 0           ;Turn off output 1 to Retract Pick arm
MOVED -10          ;Move to Place position
OUT1 = 1           ;Turn on output 1 on to extend Pick arm
WAIT TIME 500      ;Delay 1/2 sec to extend arm
OUT2 = 0           ;Turn off output 1 to Disengage gripper
WAIT TIME 500      ;Delay 1/2 sec to Place part
OUT1 = 0           ;Retract Pick arm
GOTO PROGRAM_START
END
;***** Sub-Routines *****
Enter Sub-Routine code here
;***** Fault Handler Routine *****
; Enter Fault Handler code here
ON FAULT
ENDFAULT


```

### Saving Configuration File to PC -

The “Configuration File” consists of all the parameter setting for the drive, as well as the User Program. Once you are done setting up the drives parameters and have written your User Program you can save these setting to your computer. To save the settings select “**Save configuration As**” from the **Node** pull down menu. Then simply assign your program a name, (Basic Motion), and click Save. The configuration file has a “dcf” extension and will default to save the file to the “User Data” file in MotionView.


### Loading Configuration File to the Drive -

There are times when it is desired to import (or export) the program source to another drive. Other times the program was prepared off-line. In both of these scenarios the program, or configuration file, needs to be loaded from the PC to the drive. To load the configuration file to the drive, select “**Load configuration file to drive**” from the **Node** pull down menu. Then simply select the program you want to load and click Open. MotionView will first compile the selected program. Once compiled the following message box should appear.



S807

Click “OK” to dismiss this dialog box. MotionView will then load the selected file to the drive and display the following message box when done.




S808

Click “OK” to dismiss the dialog box.

## Create a new Configuration File -

There are times when you are not connected to the drive and would like to develop a new application. This may be accomplished by loading a virtual drive. To create a new configuration file, select “**New configuration file**” from the **Node** pull down menu. The following message box should appear.



Select the desired drive and click “OK”. This will load a virtual drive onto the Parameter Tree. From here you can set all your parameter setting as well as create your User Program. When done you can use the above “**Saving Configuration File to PC**” procedure to save your work. Later you can continue to work on your program offline by selecting “**Open configuration file**” from the **Node** pull down menu.

## Motion source (Reference)

The 940 can be set up to operate in one of three modes: Torque, Velocity, or Position. The drive must be given a command before it can initiate any motion. The source for commanding this motion is referred to as the “Reference”. With the 940 you have two ways of commanding motion, or two types of References. When the drives command signal is from an external source, for example a PLC or Motion Controller, it is referred to as an External Reference. When the drive is being given its command from the User program or through one of the system variables it is referred to as an Internal Reference. (See table below)

| Mode     | “Reference” parameter setting                                                      |                                                  |
|----------|------------------------------------------------------------------------------------|--------------------------------------------------|
|          | External                                                                           | Internal                                         |
| Torque   | Analog input AIN1                                                                  | System variable “IREF”                           |
| Velocity | Analog input AIN1                                                                  | System variable “IREF”                           |
| Position | MA/MB pulse train inputs + User Program/Interface<br>(Trajectory generator output) | User Program/Interface<br>(Trajectory generator) |

## Units

All motion statements in the drive work with User units. The statement on the first line of the test program, UNITS=1, sets the relationship between User units and motor revolutions. It simply answers the question: “How many User units are there in one motor shaft revolution?” If this statement is omitted from the program, the motor will operate with encoder counts as User units.

## Time base

Time base is always in seconds i.e. all time-related values are set in USER UNITS/SEC.

## Enable/Disable/Inhibit drive

### Set Enable switch function to Run.

The 940 drive can be configured to receive its command reference from an external source and not utilize the internal User Program for its motion moves. Essentially acting like a 94 drive. When the “Enable switch function” parameter is set to Run, and the Input 3A is made, the drive will be Enabled. Likewise, toggling input 3A to the off state will Disabled the drive.

- Select “**Parameter**” from the Parameter Tree Window.
- Select “**Enable switch function**” from the Parameter View Window.
- Select “**Run**” from the popup menu.

### Set Enable switch function to Inhibit.

In the above example the decision on when to enable and disable the drive is determined by an external device, PLC or Motion controller. The 940's User Program allows the programmer to take that decision and incorporate it into the drives program. By default the drive will execute the User Program whether the drive is enabled or disabled, however if a motion statement is executed while the drive is disabled, a fault will occur. When the **"Enable switch function"** parameter is set to **Inhibit**, and Input 3A is on, the drive will default to the disabled state and remain there until the ENABLE statement is executed by the User Program.

- Select **"Parameter"** from the Parameter Tree Window.
- Select **"Enable switch function"** from the Parameter View Window.
- Select **"Inhibit"** from the popup menu.

### Faults

When a fault condition has been detected by the drive, the following events occur:

- If a program is executing the user code, the code execution is stopped. If a fault handler routine was defined, its code starts executing. (See below for details on Fault Handler). If there is no fault handler
  - user program is terminated
- Fault code will be written in DFAULTS register and will be available to user's program. See list of fault codes in section 2.15
- Dedicated "Ready" output will turn OFF.
- Any output with assigned special function "fault" will turn ON
- Any output with assigned special function "ready/enabled" will turn OFF
- Enable LED located on drive's front panel will turn OFF:
- Display will display F\_XX where XX is fault code number.

Clearing Fault condition can be done one of the following ways:



- Select the **"Restart"** icon from the toolbar.
- Executing the **RESUME** statement at the end of the Fault Handler routine (see Fault Handler Example ).
- Send "Reset" command over the Host Interface.
- Cycle power (hard reset).

### Fault Handler

The Fault Handler is a section of code that executes when the drive generates a fault. This allows the program to recover from a fault rather than just disabling the drive. Exiting the Fault Handler Code is done by executing either a **"REST"** or **"RESUME"** statements.

### Without Fault Handler

To simulate a fault, restart the Pick and Place example program. While the program is running disconnect the encoder feedback connector from the drive. This will cause the drive to generate a Feedback Error (F\_Fb) and put the drive into a Fault Mode. While the drive is in Fault Mode, the outputs will remain in there current state, (any output on will remain on), program execution will stop, and any motion moves will be terminated. In this example the Pick and Place arm may not be in a desired location when the program goes into the fault mode.

## With Fault Handler

Add the subroutine below to the “Pick and Place” program and restart the program. While the program is running disconnect the encoder feedback again. This will generate a Feedback Error, (F\_Fb). At this point the Fault Routine will take over and process the outputs to get the machine into a safe state.

```
;***** Sub-Routines *****; Enter
Sub-Routine code here
;***** Fault Handler Routine *****
ON FAULT          ;statement starts fault handler
  OUT2 = 0         ;Output 1 off to Disengage gripper.
                  ;This will drop the part in the gripper
WAIT TIME 1000    ;Delay 1 sec to allow the part to clear the gripper
  OUT1 = 0         ;Retract Pick arm to make sure it is up and out of the way
RESUME PROGRAM_START ;program restarts from label PROGRAM_START
ENDFAULT          ;fault handler MUST end with this statement
```



### Note

The following statements can not be used in Fault Handler Code:

- ENABLE
- WAIT UNTIL
- MOVE
- MOVED
- MOVEP
- MOVEDR
- MOVEPR
- MDV
- MOTION SUSPEND
- MOTION RESUME
- GOTO, GOSUB
- JUMP
- ENABLE
- GEAR ON/OFF
- VELOCITY ON/OFF

See section 2.1 for additional details and the Language Reference section for the statement “ON FAULT/ENDFAULT”.



## 1.6 Using advanced debugging features



Select the **“Restart”** icon from the toolbar to restart the program from the beginning.



Select either the **Step into** icon



or **Step over** icons

from the toolbar to execute the program statements one line at a time.



By selecting the **“Insert/Remove breakpoints”** icon from the toolbar the user can insert Breakpoints throughout the program. The drive will execute the program line by line until it comes to one of the breakpoints. At this point the program will stop, allowing the user to evaluate program variables, check program branching or just check code execution.



To continue code processing you can either Step through the program using the above procedure or you can select the **“Go”** icon from the toolbar.



To open the **Variable Debug Window**, select the **“Debug View”** icon from the toolbar. The Debug Window allows you to view the drives system and user variable as well as I/O status.



Use the left arrow key to add variables.




Use the right arrow key to remove variables.



Use the **“Refresh”** key to refresh variable values.

Note that variable values are refreshed manually when you click on the **“Refresh”** button or automatically when the program stops, when a single step is completed or when a breakpoint is encountered.



S810

## 1.7 Inputs and Outputs

### Analog Input and Output

- The 940 has two analog inputs. These analog inputs are utilized by the dive as System Variables and are labeled **“AIN1”** and **“AIN2”**. Their value can be directly accessed, (read), by the User Program or via a Host Interface. This value can range from -10 to +10 which correlates to  $\pm 10$  volts.
- The 940 has one analog output. This analog output is utilized by the dive as System Variable and is labeled **“AOUT”**. It can be directly accessed, written to, by the User Program or via a Host Interface. Its value can range from -10 to +10 which correlates to  $\pm 10$  volts.



#### Note

If an analog output is assigned any special function from MotionView, writing to AOUT from the User Program will not change its value.

If an analog output is set to “Not assign” then it can be controlled by writing to the AOUT variable.

## Digital Inputs

- The 940 has twelve digital inputs. These digital inputs are utilized by the drive for decision making in the User Program. Some examples would be travel limit switches, proximity sensors, push buttons and hand shaking with other devices.
- Each input can be assigned an individual debounce times via MotionView. From the **Parameter Tree** select "IO". Then select the "Digital Input" folder. The debounce times will be displayed in the **Parameter View Window**. Debounce times can be set between 0 and 1000 ms (1ms = 0.001 Sec).
- The twelve inputs are separated into three groups: A, B and C. Each group has four inputs and share one common per group: Acom, Bcom and Ccom. The inputs are labeled individually as **IN\_A1 - IN\_A4, IN\_B1 - IN\_B4 and IN\_C1 - IN\_C4**.
- In addition to monitoring each input individually the status of all twelve inputs can be represented as one binary number. Every input has its bit number range from 0 to 11 in the INPUTS System variable. Each input allocates 1 bit in the INPUTS variable. See table below:

| Input Name | System Variable<br>INPUTS bit # |
|------------|---------------------------------|
| A1         | 0                               |
| A2         | 1                               |
| A3         | 2                               |
| A4         | 3                               |
| B1         | 4                               |
| B2         | 5                               |
| B3         | 6                               |
| B4         | 7                               |
| C1         | 8                               |
| C2         | 9                               |
| C3         | 10                              |
| C4         | 11                              |

- Some inputs can have additional special functionality, (Travel Limit switch, Enable input, and Registration input). Configuration of these inputs is done from MotionView. Input functionality is summarized in the table below and in the following sections. The status of the current state of the drives inputs are available to the programmer through dedicated System Flags or as bits of the System Variable INPUTS. The table below summarizes the inputs:

| Function             | Special function          |
|----------------------|---------------------------|
| Input A1             | CW limit switch           |
| Input A2             | CCW limit switch          |
| Input A3             | Inhibit/Enable input      |
| Input A4             |                           |
| Common for A section |                           |
| Input B1             |                           |
| Input B2             |                           |
| Input B3             |                           |
| Input B4             |                           |
| Common for B section |                           |
| Input C1             |                           |
| Input C2             |                           |
| Input C3             | Registration sensor input |
| Input C4             |                           |
| Common for C section |                           |

## Read Digital Inputs

Below, the Pick and Place example program has been modified to utilize the “WAIT UNTIL” inputs statements in place of the “WAIT TIME” statements. **IN\_A4** is used as a proximity sensors to detect when the pick and place arm is extended and when it is retracted. When the arm is extended **IN\_A4** will be in an ON state and will equal “1”. When the arm is retracted, **IN\_A4** will be in an OFF state and will equal “0”.

```
;***** Main Program *****
ENABLE
PROGRAM_START:
WAIT UNTIL IN_A4==0      ;Make sure Arm retracted
MOVED 10                ;Move to Pick position
OUT1 = 1                 ;Turn on output 1 on to extend Pick arm
WAIT UNTIL IN_A4 == 1    ; Arm extend
OUT2 = 1                 ;Turn on output 2 to Engage gripper
WAIT TIME 1000           ;Delay 1 sec to Pick part
OUT1 = 0                 ;Turn off output 1 to Retract Pick arm
WAIT UNTIL IN_A4==0      ;Make sure Arm retracted
MOVED -10                ;Move to Place position
OUT1 = 1                 ;Turn on output 1 on to extend Pick arm
WAIT UNTIL IN_A4 == 1    ; Arm extend
OUT2 = 0                 ;Turn off output 1 to Disengage gripper
WAIT TIME 1000           ;Delay 1 sec to Place part
OUT1 = 0                 ;Retract Pick arm
WAIT UNTIL IN_A4 == 0    ; Arm retracted
GOTO PROGRAM_START
END
```

Once you have made the above modifications, export the program to file and save it as “Pick and Place with I/O”, then compile, download and test the program.

## ASSIGN & INDEX - Using inputs to generate predefined indexes

“INDEX” is a variable on the drive that can be configured to represent a certain group of inputs as a binary number. “ASSIGN” is the command that configures what inputs are utilized and how we want to configure them.

Below the Pick and Place program has been modified to utilize this “INDEX” function. The previous example program simply picked up a part and moved it to a place location. For demonstration purposes we will add seven different end, or place locations. These locations will be referred to as Bins. What Bin the part is placed in will be determined by the state of three inputs, B1, B2 and B3.

|       |   |                               |
|-------|---|-------------------------------|
| Bin 1 | - | Input B1 is made              |
| Bin 2 | - | Input B2 is made              |
| Bin 3 | - | Inputs B1 and B2 are made     |
| Bin 4 | - | Input B3 is made              |
| Bin 5 | - | Inputs B1 and B3 are made     |
| Bin 6 | - | Inputs B2 and B3 are made     |
| Bin 7 | - | Inputs B1, B2 and B3 are made |

The “ASSIGN” command is used to assign the individual input to a bit in the “INDEX” variable. ASSIGN INPUT <input name> AS BIT <bit #>

```
;***** Initialize and Set Variables *****
ASSIGN INPUT IN_B1 AS BIT 0 ;Assign the Variable INDEX to equal 1 when IN_B1 is made
ASSIGN INPUT IN_B2 AS BIT 1 ;Assign the Variable INDEX to equal 2 when IN_B2 is made
ASSIGN INPUT IN_B3 AS BIT 2 ;Assign the Variable INDEX to equal 4 when IN_B4 is made
```

| Bin Location | Input state                   | INDEX Value |
|--------------|-------------------------------|-------------|
| Bin 1        | Input B1 is made              | 1           |
| Bin 2        | Input B2 is made              | 2           |
| Bin 3        | Inputs B1 and B2 are made     | 3           |
| Bin 4        | Input B3 is made              | 4           |
| Bin 5        | Inputs B1 and B3 are made     | 5           |
| Bin 6        | Inputs B2 and B3 are made     | 6           |
| Bin 7        | Inputs B1, B2 and B3 are made | 7           |

Below the Main program has been modified to change the end place position based on the value of the “INDEX” variable.

```
;***** Main Program *****
ENABLE
PROGRAM_START:
WAIT UNTIL IN_A4==0      ;Make sure Arm retracted
MOVEP 0                  ;Move to (ABS) to Pick position
OUT1 = 1                  ;Turn on output 1 on to extend Pick arm
WAIT UNTIL IN_A4 == 1    ; Arm extend
OUT2 = 1                  ;Turn on output 2 to Engage gripper
WAIT TIME 1000           ;Delay 1 sec to Pick part
OUT1 = 0                  ;Turn off output 1 to Retract Pick arm
WAIT UNTIL IN_A4==0      ;Make sure Arm retracted

IF INDEX == 1             ;In this area we use the If statement to
GOTO BIN_1                ;check and see what state ininputs B1, B2 & B3
ENDIF                     ;are in.
IF INDEX == 2             ; INDEX = 1 when input B1 is made
GOTO BIN_2                ; INDEX = 2 when input B2 is made
ENDIF                     ; INDEX = 3 when input B1 & B2 are made.
                           ; INDEX = 4 when input B3 is made
                           ; INDEX = 5 when input B1 & B3 are made.
                           ; INDEX = 6 when input B2 & B3 are made.
IF INDEX == 7             ; INDEX = 7 when input B1, B2 & B3 are made
GOTO BIN_7                ;We can now direct the program to one of seven
ENDIF                     ;locations based on three inputs.

BIN_1:                    ;Set up for Bin 1
MOVEP 10                  ;Move to Bin 1 location
GOTO PLACE_PART           ;Jump to place part routine
BIN_2:                    ;Set up for Bin 2
MOVEP 20                  ;Move to Bin 2 location
GOTO PLACE_PART           ;Jump to place part routine
BIN_7:                    ;Set up for Bin 7
MOVEP 70                  ;Move to Bin 7 location
GOTO PLACE_PART           ;Jump to place part routine
PLACE_PART:
OUT1 = 1                  ;Turn on output 1 on to extend Pick arm
WAIT UNTIL IN_A4 == 1     ; Arm extend
OUT2 = 0                  ;Turn off output 1 to Disengage gripper
WAIT TIME 1000           ;Delay 1 sec to Place part
OUT1 = 0                  ;Retract Pick arm
WAIT UNTIL IN_A4 == 0     ; Arm retracted
GOTO PROGRAM_START
END
```



#### Note

Note: Any on the 12 inputs can be assigned as a bit position within INDEX variable. Only bits 0 through 7 can be used with the INDEX variable. Bits 8-31 are not used and always set to 0. Unassigned bits in the INDEX variable are set to 0.

|                      |    |   |    |    |   |   |   |   |
|----------------------|----|---|----|----|---|---|---|---|
| BITS 8-31 (not used) | A1 | 0 | A2 | A4 | 0 | 0 | 0 | 0 |
|----------------------|----|---|----|----|---|---|---|---|

## Limit switch input functions


Inputs A1 and A2 can be configured as special purpose inputs. They are configured from the **Digital I/O** folder in MotionView and can be set to one of following three settings.

- The **"Not assigned"** setting designates the inputs as general purpose inputs which can be utilized by the User Program.
- The **"Fault"** setting will configure A1 and A2 as Hard Limit Switches. When either input is made the drive will be disabled, the motor will hard stop, and a the drive will generate a fault.
- The **"Stop and fault"** setting will configure A1 and A2 as End of Travel limit switches. When either input is made the drive will initiate a rapid stop before disabling the drive and generating a Fault. The speed of the deceleration will be set by the value stored in the **"QDECEL"** System Variable.



### Note

The "Stop and Fault" function is available in Position mode when the parameter Reference is set to Internal, i.e. when the motion command is derived from the User Program. In all other cases the Stop and Fault will function acts the same as the Fault function.




S811

To set this parameter select the **"IO"** folder from the Parameter Tree. Then select the **"Digital IO"** folder. From the Parameter View Window select **"Hard limit switch action"**.

## Digital Outputs Control

- The 940 has 5 Digital Outputs. The “RDY” or READY output is dedicated and will only come on when the drive is Enabled and in the **RUN** mode. The remaining outputs are labeled individually as **OUT1 - OUT4**.
- Outputs can be configured as Special Purpose Outputs. If an output is configured as a **Special Purpose Outputs** it will activate when the state assigned to it becomes true. For example if an output is assigned the function “**Zero speed**”, the assigned output will come on when the motor is not in motion. To configure an output as a Special Purpose Output, select the “**IO**” folder from the Parameter Tree. Then select the “**Digital IO**” folder. From the Parameter View Window, select the “**Output function**” parameter you wish to set



S812

- Outputs not configured as Special Purpose Outputs can be activated either, via the User Program, or from a host interface. If an output is assigned as a Special Purpose Output neither the user program nor the host interface can override its status.
- The Systems Variable “**OUTPUTS**” is a read/write variable which allows the User Program, or host interface, to monitor and set the status of all four outputs as one binary number. Each output allocates 1 bit in the OUTPUTS variable. For example if you set this variable equal to 15 in the User Program, (OUTPUTS = 15), then all 4 outputs will be turned on.
- The examples below summarize the output functions and corresponding System Flags. To set the output write to its flag any non 0 value (TRUE). To clear the output, write to its flag a 0 value (FALSE). You also can use flags in an expression. If an expression evaluates to TRUE then the output will be turned ON. Otherwise, it will be turned OFF.

```
OUT1 = 1           ;turn OUT1 ON
OUT2 = 10          ;any value but 0 turns output ON
OUT3 = 0           ;turn OUT3 OFF
OUT2 = APOS>3 && APOS<10 ;ON when position within window, otherwise OFF
```

## 1.8 Events

### Scanned Events

A Scanned Event is a small program that runs independently of the main program. SCANNED EVENTS are very useful when it is necessary to trigger an action, (handle I/O), while the motor is in motion. In the following example the Event “**SPRAY\_GUNS\_ON**” will be setup to turn Output 3 on when the servo’s position becomes greater than 25. (Note: the event will trigger only at the instant the servo position becomes greater than 25. It will not continue to execute while the position is greater than 25).

```
;***** EVENT SETUP *****
EVENT SPRAY_GUNS_ON      APOS>25
OUT3=1
ENDEVENT
```

```
;*****
```

The Event code should be entered in the EVENT SETUP section of the program. To SETUP an Event, the “**EVENT**” command must be entered. This is followed by the Event Name “**SPRAY\_GUNS\_ON**” and the triggering mechanism, “**APOS>25**”. The next step is to enter in the “statements” or “code”. This is the sequence of programming events you wish to occur once the event is triggered. In our case we will turn output 3 on, “**OUT3=1**”. To end the Event setup the “**ENDEVENT**” command must be entered.

Events can be activated, (Turned On), and deactivated, (Turned Off), throughout the program. To turn ON an Event, the “**EVENT**” command is entered, followed by the Event Name “**SPRAY\_GUNS\_ON**”. This is trailed by the desired state of the Event, “**ON**” or “**OFF**”.

```
;*****
EVENT SPRAY_GUNS_ON      ON
;*****
```

To learn more about Scanned Events refer to Section 2.13.

Two Scanned Events have been added to the Pick and Place program (shown below). These Events will be used to trigger a spray gun on and off. The Event will trigger after the part has been picked up and is passing in front of the spray guns (POS 25). Once the part is in position, output 3 is turn on activating the spray guns. When the part has passed by the spray guns, (POS 75), output 3 is turned off, deactivating the spray guns.

```
;***** Events *****
EVENT  SPRAY_GUNS_ON    APOS>25
OUT3=1
ENDEVENT

EVENT  SPRAY_GUNS_OFF   APOS>75
OUT3=0
ENDEVENT
;***** Main Program *****
PROGRAM_START:
ENABLE
EVENT  SPRAY_GUNS_ON    ON
EVENT  SPRAY_GUNS_OFF   ON
WAIT UNTIL IN_A4==0      ;Make sure Arm retracted
MOVEP 0                  ;Move to Pick position
OUT1 = 1                  ;Turn on output 1 on to extend Pick arm
WAIT UNTIL IN_A4 == 1    ;Arm extend
OUT2 = 1                  ;Turn on output 2 to Engage gripper
WAIT TIME 1000           ;Delay 1 sec to Pick part
OUT1 = 0                  ;Turn off output 1 to Retract Pick arm
WAIT UNTIL IN_A4==0      ;Make sure Arm retracted
MOVEP 100                ;Move to Place position
OUT1 = 1                  ;Turn on output 1 on to extend Pick arm
WAIT UNTIL IN_A4 == 1    ;Arm extend
OUT2 = 0                  ;Turn off output 1 to Disengage gripper
WAIT TIME 1000           ;Delay 1 sec to Place part
OUT1 = 0                  ;Retract Pick arm
WAIT UNTIL IN_A4 == 0    ; Arm retracted
GOTO PROGRAM_START
END
```

## 1.9 Variables and Define statement

Variables are resources in the drive. Some of these variables are read / write and some are read only. Certain variables are used to set the operating parameters of the drive, for example (ACCEL, DECEL, or MAXV). Other variables can be used to determine the status of the drive, (AIN, INPUTS, or APOS). Variables can also be used as system registers. These system registers can be local to the drive, (V1- V31), or network variables (N1 - N31). In the example below we set the trigger position for the EVENT “**SPRAY\_GUNS\_ON**” to be equal to “V1”, and the trigger position for EVENT “**SPRAY\_GUNS\_OFF**” to be equal to “V2”.

The DEFINE command is used to assign a name to the state of a drive variable, (Output\_ON = 1, Output\_OFF = 0). You can also assign a set number a name, (MIN = 25, MAX = 75). In the example below we assign the name “Output\_On” to equal the value “1”, and “Output\_Off” to equal the value “0”.

Defining and setting variables should be done in the “**Initialize and set Variables**” section of the program.

```
;***** Initialize and Set Variables *****
UNITS = 1
ACCEL = 5
DECEL = 5
MAXV = 10
V1 = 25 ;Set Variable V1 equal to 25
V2 = 75 ;Set Variable V2 equal to 75
DEFINE Output_On 1 ;Define Name for output On
DEFINE Output_Off 0 ;Define Name for output Off
;***** EVENTS *****
EVENT SPRAY_GUNS_ON APOS > V1 ;Event will trigger as position passes 25 in pos dir.
OUT3= Output_On ;Turn on the spray guns (out 3 on)
ENDEVENT ;End event

EVENT SPRAY_GUNS_OFF APOS > V2 ;Event will trigger as position passes 75 in neg dir.
OUT3= Output_Off ;Turn off the spray guns (out 3 off)
ENDEVENT ;End even

;***** Main Program *****
PROGRAM_START:
ENABLE
EVENT SPRAY_GUNS_ON ON ;Enable the Event
EVENT SPRAY_GUNS_OFF ON ;Enable the Event
WAIT UNTIL IN_A4==0 ;Ensure Arm is retracted before running the program
MOVEP 0 ;Move to position 0 to pick part
OUT1 = Output_On ;Turn on output 1 to extend Pick arm
WAIT UNTIL IN_A4 == 1 ;Check input to make sure Arm is extended
OUT2 = Output_On ;Turn on output 2 to Engage gripper
WAIT TIME 1000 ;Delay 1 sec to Pick part
OUT1 = Output_Off ;Turn off output 1 to Retract Pick arm
WAIT UNTIL IN_A4==0 ;Check input to make sure Arm is retracted
MOVED 100 ;Move to Place position
OUT1 = Output_On ;Turn on output 1 to extend Pick arm
WAIT UNTIL IN_A4 == 1 ;Check input to make sure Arm is extended
OUT2 = Output_Off ;Turn off output 1 to Disengage gripper
WAIT TIME 1000 ;Delay 1 sec to Place part
OUT1 = Output_Off ;Retract Pick arm
WAIT UNTIL IN_A4 == 0 ;Check input to make sure Arm is retracted
GOTO PROGRAM_START
END
```



## 1.10 IF/ELSE statements

IF/ELSE statement allows you to execute one or more statements conditionally. You can use IF or IF/ELSE construct:

### Single IF example:

This example increments a counter, Variable “V1”, until the Variable, “V1”, is greater than 10.

Again:

```
V1=V1+1
IF V1>10
V1=0
ENDIF
GOTO Again
```

END


### IF/ELSE example:

This example checks the value of Variable V1, If V1 is greater than 3 then V2 is set to 1. If V1 is not greater than 3 then V2 is set to 0.

```
IF V1>3
V2=1
ELSE
V2=0
ENDIF
```

Whether you are using an IF or IF/ELSE statement the construct must end with ENDIF keyword.

## 1.11 Motion



S813

### 940 position and velocity regulator's diagram

The “**Position Command**”, as shown in the regulator's diagram above, is produced by a **Trajectory Generator**. The Trajectory Generator processes the motion commands produced by the User's program to calculate the position increment or decrement, also referred to as the “index” value, for every servo loop. This calculated target (or theoretical) position is then supplied to the **Regulator** input.


The main purpose of the **Regulator** is to set the motors position to match the target position created by the Trajectory Generator. This is done by comparing the input from the Trajectory Generator with the position feedback from the encoder, to control the torque and velocity of the motor. Of course there will always be some error in the position following. Such error is referred to as “Position Error” and is expressed as follows:

$$\text{Position Error} = \text{Target Position} - \text{Actual Position}$$

When the Position Error exceeds a certain threshold value “Position Error Excess”, fault (F\_Fb) will be generated. You can set the allowable Position Error limit and Position Error Time, (how long is the delay before the fault is generated). These parameters can only be set by using MotionView software. (From the Node Tree - Limits folder/Position Limits)

### Motion Modes

There are three modes of operation for the 940, Torque, Velocity and Position. Torque and Velocity moves are generally used when the command reference is from an external device, (Ain). Position mode is used when the command comes from the drives User Program, or from an external device, encoder or a step and direction pulse. Setting the drives mode is done from the “**Parameter**” folder in MotionView. To command motion from the User Program the drive must be configured to Position Mode. Even though the drive is setup in position mode Velocity mode can be turned on and off from the User Program. Executing the VELOCITY ON statement is used to activate this mode where as VELOCITY OFF will deactivate this mode. This mode is used for special case indexing moves. Velocity mode is the mode when the target position is constantly advanced with a rate set in the VEL system variable. Gear mode is the mode when the target position reference is fed from MA/MB inputs scaled by the Gear Ratio (gear ratio set by statement Gear Ratio). The diagram below shows the Reference arrangements for the different modes of operation.




S814

Reference arrangement diagram

### Point To Point Moves location

The 940 supports two types of moves, absolute and incremental. The statement MOVEP (Move to Position) is used to make an absolute move. When executing an absolute move the motor is instructed to move to a known position. The move to this known position is always referenced from the motor's “home” or “zero” location. For example, the statement (MOVEP 0), will cause the motor to move to its zero, or home, position, regardless of where the motor is located at the beginning of the move. The statement MOVED (Move Distance) makes incremental, (or relative), moves from its current position. For example, (MOVED 10), will cause the motor to index 10 user units forward from its current location.

MOVEP and MOVED statements generate what is called a trapezoidal point to point motion profile. A Trapezoidal move is when the motor accelerates, using the current acceleration setting, (ACCEL), to a default top speed, (MAXV), it then maintains that speed for a period of time before decelerating to the end position using the deceleration setting, (DECEL). If the distance to be moved is fairly small, a triangular move profile will be used. A triangular move is a move that starts to accelerate toward the Max Velocity setting but has to decelerate before ever achieving the max velocity in order to reach the desired end point.




S815

### Segment moves

MOVED and MOVEP commands are simple and useful, but if the required move profile is more complex than a simple trapezoid move, then a MDV or segment move can be used.

The profile shown below is divided up into 8 segments or 8 MDV moves. A MDV move, (Move Distance Velocity), has two arguments. The first argument is the distance moved in that segment. This distance is referenced from the motors current position and is in User Units. The second argument is the desired target velocity for the end of the segment move. That is the velocity the motor will be at once the motor is in position.



S816

| Segment Number | Distance moved during segment | Velocity at the end of segment |
|----------------|-------------------------------|--------------------------------|
| 1              | 3                             | 56                             |
| 2              | 3                             | 12                             |
| 3              | 4                             | 16                             |
| 4              | 2                             | 57                             |
| 5              | 2.5                           | 57                             |
| 6              | 3                             | 11                             |
| 7              | 5                             | 20                             |
| 8              | 5                             | 0                              |
| -              | -                             | -                              |
|                |                               |                                |

Below is the User program for the above example. Please note that the last segment move must have a “0” for the end velocity, (MDV 5 , 0). If this procedure is not followed a F\_24 Fault, (Motion Queue Underflow), will be triggered.

```
;Segment moves
LOOP:
WAIT UNTIL IN_A4==0      ;Wait until input A4 is off before starting the move
MDV 3 , 56      ;Move 3 units accelerating to 56 User Units per sec
MDV 3 , 12      ;Move 3 units decelerating to 12 User Units per sec
MDV 4 , 16      ;Move 4 units accelerating to 16 User Units per sec
MDV 2 , 57      ;Move 2 units accelerating to 57 User Units per sec
MDV 2.5 , 57    ;Move 2.5 units maintaining 57 User Units per sec
MDV 3 , 11      ;Move 3 units decelerating to 11 User Units per sec
MDV 5 , 20      ;Move 5 units accelerating to 20 User Units per sec
MDV 5 , 0       ;Move 5 units decelerating to 0 User Units per sec
WAIT UNTIL IN_A4==1      ;Wait until input A4 is on before looping
GOTO LOOP
END
```




#### Note

- When a MDV move is executed, the segment moves are stored to a Motion Queue. If the program loops on itself then the queue will become full and a F\_23 Fault, (Motion Queue Overflow), will occur.
- Because the MDV moves utilize a Motion Queue the **Step into [ ]** or **Step over [ ]** debug features will not work.

### Registration

Both Absolute and Incremental moves can be used for registration moves. The statements associated with these moves are MOVEPR and MOVEDR. These statements have two arguments. The first argument specifies the commanded move distance or position. The second argument specifies the move made after the registration input is seen. If the registration move is an absolute move, (MOVEPR 10,30), then the second argument, “30”, will simply define the position to move to once the registration input is made. If the registration move is an incremental move, (MOVEDR 10,30), then the second argument will be the distance to move from the point the registration input is seen.




S817

### S-Curve Acceleration

Very often it is important for a move profile to be as smooth as possible. This could be to minimize the wear on a machine, or it could be that a smooth profile is critical to the successful completion of an operation. To perform smooth motion profiles, the 940 supports S-curve acceleration.

With normal straight line acceleration, the axis is accelerated to the target velocity in a linear fashion. With S-curve acceleration, the motor accelerates slowly at the first, then twice as fast as the middle straight line area, and then slowly stops accelerating as it reaches the target velocity. With straight line acceleration, the acceleration changes are abrupt at the beginning of the acceleration and again once the motor reaches the target velocity. With S-curve acceleration the acceleration gradually builds to the peak value then gradually decreases to no acceleration. The disadvantage with S-curve acceleration is that for the same acceleration distance the peak acceleration is twice that of straight line acceleration, which often requires twice the peak torque. Note that the axis will arrive at the target position at the same time regardless which type of acceleration method is used.



S818

To use S-curve acceleration in MOVED, MOVEP or MDV statement requires only the additional „S” at the end of the statement.

#### Examples:

```
MOVED 10 , S
MOVEP 10 , S
MDV 10,20,S
MDV 10,0,S
```

#### Motion Queue

The 940 drive executes the User Program one statement at a time. When a move statement, (MOVED or MOVEP), is executed the move profile is stored to the Motion Queue. The program will, by default, wait, or hang, on that statement until the Motion Queue has executed the move. Once the move is completed the next statement in the program will be executed. This effectively will suspend the program until the motion is complete.

A standard move, (MOVED or MOVEP) is only followed by one argument. This argument references the distance or position to move the motor to. By adding the second argument „C”, (MOVEP 0,C) or (MOVED 100,C), the drive is allowed to CONTINUE executing the user program during the move. At this point multiple move profiles can be stored to the queue. The Motion Queue can hold up to 32 profiles. Like the EVENT command, the Continue „C” argument is very useful when it is necessary to trigger an action, (handle I/O), while the motor is in motion. Below the Pick and Place Example Program has been modified to utilize the Continue, „C”, argument.

```
;***** Main Program *****
PROGRAM_START:
ENABLE
WAIT UNTIL IN_A4==0 ;Make sure Arm is retracted before starting the program
MOVEP 0 ;Move to position 0 to pick part
OUT1 = 1 ;Turn on output 1 to extend Pick arm
WAIT UNTIL IN_A4 == 1 ;Check input to make sure Arm is extended
OUT2 = 1 ;Turn on output 2 to Engage gripper
WAIT TIME 1000 ;Delay 1 sec to Pick part
OUT1 = 0 ;Turn off output 1 to Retract Pick arm
WAIT UNTIL IN_A4==0 ;Check input to make sure Arm is retracted
MOVED 100,C ;Move to Place position and continue code execution
WAIT UNTIL APOS >25 ;Wait until pos is greater than 25
OUT3 = 1 ;Turn on output 3 to spray part
WAIT UNTIL APOS >=75 ;Wait until pos is greater than or equal to 75
OUT3 = 0 ;Turn off output 3 to shut off spray guns
WAIT UNTIL APOS >=95 ;Wait until move is almost done before extending arm
OUT1 = 1 ;Turn on output 1 to extend Pick arm
WAIT UNTIL IN_A4 == 1 ;Check input to make sure Arm is extended
OUT2 = 0 ;Turn off output 1 to Disengage gripper
WAIT TIME 1000 ;Delay 1 sec to Place part
OUT1 = 0 ;Retract Pick arm
WAIT UNTIL IN_A4 == 0 ;Check input to make sure Arm is retracted
GOTO PROGRAM_START
END
```

When the “C” argument is added to the standard MOVED and MOVEP statements, the generated motion profile is treated like a MDV move. With a MDV move the execution of the program is never suspended.

The generated motion profiles are stored directly to the Motion Queue and are then executed one by one. If the MOVED and MOVEP statements don't have the “C” modifier then the motion profiles generated by these statements go to the motion stack and the program is suspended until each profile has been executed.

## 1.12 Subroutines and Loops

### Subroutines

Often it is necessary to repeat a series of steps in several places in a program. Subroutines can be useful in such situations. The syntax of a subroutine is simple. Subroutines must be placed after the main program, (after the END statement), and must start with the subname: label (where subname is the name of subroutine), and must end with a statement RETURN.

Note that there can be more than one RETURN statement in a subroutine. Subroutines are called using the GOSUB statement.

### Loops

SML language supports WHILE/ENDWHILE block statement which can be used to create repetition loops. Note that IF-GOTO statements can also be used to create loops.

The following example illustrates calling subroutines as well as how to implement looping by utilizing WHILE / ENDWHILE statements.

```
;***** Initialize and Set Variables *****
UNITS = 1
ACCEL = 15
DECEL = 15
MAXV = 100
APOS = 0
DEFINE LOOPCOUNT V1
DEFINE LOOPS 10
DEFINE DIST V2
DEFINE REPETITIONS V3
REPETITIONS = 0

;***** Main Program *****
PROGRAM_START:
ENABLE
MAINLOOP:
    LOOPCOUNT=LOOPS ;Set up the loopcount to loop 10 times
    DIST=10 ;Set distance to 10
    WHILE LOOPCOUNT ;Loop while loopcount is greater than zero
        DIST=DIST/2 ;decrease dist by 1/2
        GOSUB MDS ;Call to subroutine
        WAIT TIME 100 ;Delay executes after returned from the subroutine
        LOOPCOUNT=LOOPCOUNT-1 ;decrement loop counter
    ENDWHILE
    REPETITIONS=REPETITIONS+1 ;outer loop
    IF REPETITIONS < 5
GOTO MAINLOOP
    ENDIF
END

;***** Sub-Routines *****
MDS:
    V4=dist/3
    MDV V4,10
    MDV V4,10
    MDV V4,0
RETURN
```

## 2. Programming

### 2.1 Introduction

One of the most important aspects of programming is developing a structure for the program. Before you begin to write a program, you should develop a plan for that program. What tasks must be performed? In what order do they need to be performed? What things can be done to make the program easy to understand and to be maintained by others? Are there any procedures that are repetitive?

Most programs are not a simple linear list of instructions where every instruction is executed in exactly the same order each time the program runs. Programs need to do different things in response to external events and operator input. SML contains, program control structure instructions and scanned event functions that may be used to control the flow of execution in an application program.

Control structure instructions are the instructions that cause the program to change the path of execution. Scanned events are instructions that execute at the same time as the main body of the application program.

#### Program Structure

**Header - Enter in program description and title information**

```
;***** HEADER *****
;Title:          Pick and Place example program
;Author:         Lenze / AC Technology
;Description:    This is a sample program showing a simple sequence that
;               picks up a part moves to a set position and drops the part
```

**I/O List - Define what I/O will be used**

```
;***** I/O List *****
;   Input A1   -   not used
;   Input A2   -   not used
;   Input A3   -   Enable Input
;   Input A4   -   not used
;   Input B1   -   not used
;   Input B2   -   not used
;   Input B3   -   not used
;   Input B4   -   not used
;   Input C1   -   not used
;   Input C2   -   not used
;   Input C3   -   not used
;   Input C4   -   not used
;
;   Output 1   -   Pick Arm
;   Output 2   -   Gripper
;   Output 3   -   not used
;   Output 4   -   not used
```

**Initialize and Set Variables - Define and assign Variables values**

```
;***** Initialize and Set Variables *****
UNITS = 1
ACCEL = 75
DECEL =75
MAXV = 10
;V1 =
;V2 =
DEFINE Output_on 1
DEFINE Output_off 0
```

### **Events - Define Event name, Trigger and pgm**

```
;***** Events *****
EVENT SPRAY_GUNS_ON      APOS > V1 ;Event will trigger as position passes 25 in pos dir.
OUT3= Output_On          ;Turn on the spray guns (out 3 on)
ENDEVENT                 ;End event
EVENT SPRAY_GUNS_OFF     APOS > V2 ;Event will trigger as position passes 75 in neg dir.
OUT3= Output_Off         ;Turn off the spray guns (out 3 off)
ENDEVENT                 ;End even
```

### **Main Program - Define the motion and I/O handling of the machine**

```
;***** Main Program *****
PROGRAM_START:
ENABLE
EVENT SPRAY_GUNS_ON ON   ;Enable the Event
EVENT SPRAY_GUNS_OFF ON  ;Enable the Event
WAIT UNTIL IN_A4==0      ;Make sure Arm is retracted before starting the program
MOVEP 0                  ;Move to position 0 to pick part
OUT1 = Output_On         ;Turn on output 1 to extend Pick arm
WAIT UNTIL IN_A4 == 1    ;Check input to make sure Arm is extended
OUT2 = Output_On         ;Turn on output 2 to Engage gripper
WAIT TIME 1000           ;Delay 1 sec to Pick part
OUT1 = Output_Off        ;Turn off output 1 to Retract Pick arm
WAIT UNTIL IN_A4==0      ;Check input to make sure Arm is retracted
MOVED 100                ;Move to Place position
OUT1 = Output_On         ;Turn on output 1 to extend Pick arm
WAIT UNTIL IN_A4 == 1    ;Check input to make sure Arm is extended
OUT2 = Output_Off        ;Turn off output 1 to Disengage gripper
WAIT TIME 1000           ;Delay 1 sec to Place part
OUT1 = Output_Off        ;Retract Pick arm
WAIT UNTIL IN_A4 == 0    ;Check input to make sure Arm is retracted
GOTO PROGRAM_START
END
```

### **Sub-Routine - Any and all Sub-Routine code should reside here**

```
;***** Sub-Routines *****
;      Enter Sub-Routine code here
```

### **Fault Handler - Define what the program should do when a fault is detected**

```
;***** Fault Handler Routine *****
;      Enter Fault Handler code here
ON FAULT
ENDFAULT
```

The **header section** of the program contains description information, program name, version number, description of process and programmers name.

The **I/O List section** of the program contains a listing of all the I/O on the drive.

The **Initialize and Set Variables section** of the program defines the names for the user variables and constants used in the program.

The **Events section** contains all scanned events. Remember to execute the **EVENT <eventname> ON** statement in main program to enable the events. Please note that not all of the SML statements are executable from within the EVENT body. For more detail reference “EVENT” and “ENDEVENT”, in section three of the manual, (LANGUAGE REFERENCE). The GOTO statement is one of the statements that can not be executed from within the Event Body. However the JUMP statement can be used to jump to code in the main program body. This technique allows the program flow to change based on the execution of an Event. For more detail reference “JUMP”, in section three of the manual, (LANGUAGE REFERENCE).

The **main program** body of the program contains the main part of the program, which can include all motion and math statements, labels, I/O commands and subroutine calls. The main body has to be finished with an END statement.



Subroutines are routines that are called from the main body of the program. When a subroutine is called, (GOSUB), the programs execution is transferred from the main program to the subroutine called. It will then process the subroutine until a RETURN statement occurs. Once a RETURN statement is executed, the programs execution will return back to the main program to the line of code immediately following the GOSUB statement.

**Fault handler** is a section of code that is executed when the drive detects a fault. This section of code begins with the "ON FAULT" statement and ends with an "ENDFAULT" statement. When a fault occurs, the normal program flow is interrupted, motion is stopped, the drive is disabled, Event scanning is stopped and the statements in the Fault Handler are executed, until the program exits the fault handler. The Fault handler can be exited in three ways:

- The "RESUME" statement will cause the program to end the Fault Handler routine and resume the execution of the main program. The location called out in the "RESUME" command will determine where the program will commence.
- The "RESET" statement will cause the program to end the Fault Handler routine and reset the main program to its first statement.
- The "ENDFAULT" statement will cause the user program to be terminated.

Keep in mind that while the Fault Handler is being executed Events are not being processed and detection of additional faults is not possible. Because of this, the Fault Handler code should be kept as short as possible. If extensive code must be written to process the fault, then this code should be placed in the main program and the "RESUME" statement should be utilized. Note, not all of SML statements can be utilized by the Fault Handler. For more details reference "ON FAULT/ENDFAULT", in section three of the manual, (LANGUAGE REFERENCE).

**Comments** are allowed in any section of the program and are preceded by a semicolon. They may occur on the same line as an instruction or on a line by themselves. Any text following a semicolon on a line will be ignored by the compiler.

## 2.2 Variables

All SimpleServo variables have ordinal numbers. Any variable can be accessed by that number from the User's program or from a Host Interface. In addition to numbers some of the variables have predefined names and can be accessed by that name from the User's program.

The following syntax is used when accessing variables by there ordinal number:

```
@102 = 20      ; set variable #102 to 20
@23=@100       ; copy value of variable #100 to variable #23
```

There are two types of variables in 940 Drive - **User Variables** and **System Variables**.

**User variables** are a fixed set of variables that the programmer can use to store data and perform arithmetic manipulations. All variables are of a single type, (see below). Single type variables facility, (type less variables), relieve the programmer of the task of remembering to apply conversion rules between types, thus greatly simplifying programming.

### User variables

- |               |                                                                                                                                                                                                                                                                                            |
|---------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>V0-V3</b>  | User defined variables. Variables can hold any numeric value including logic (Boolean 0 - FALSE and non 0 - TRUE) values. They can be used in any valid arithmetic or logical expressions.                                                                                                 |
| <b>N0-N31</b> | User defined network variables. Variables can hold any numeric value including logic (Boolean 0 - FALSE and non 0 - TRUE) values. They can be used in any valid arithmetic or logical expressions. Variables can be shared across Ethernet network with use of statements SEND and SENDTO. |

Since SML is a type less language, there is no special type for Boolean type variables (variables that can be only 0 or 1). Regular variables are used to facilitate Boolean variables. Assigning a variable a "FALSE" state is done by setting it equal to "0". Assigning a variable a "TRUE" state is done by assigning it any value other than "0".

In addition to the user variables, system variables are also supported.

System variables are dedicated variables that contain particular values. For example, **APOS** variable holds actual position of the motor shaft. For more details reference in Section 2.9.

## Scope

SML variables are available system wide. Each of the variables can be read and set from any user program, subroutine or Host Language Command at any time. There is no provision to protect a variable from change. This is referred as global scope.

## Volatility

All variables are volatile i.e. they don't maintained their values after power is removed. After power up the value of all of the variables are set to 0. Loading or resetting the program doesn't change variables values.

## Flags, Resolution and Accuracy

As mentioned before you can use any variable as a flag in a logical expression and as a condition in a conditional expression. Flags are often used to indicate that some event has occurred, logic state of an input has changed or that the program has executed to a particular point. Variables with non '0' values are evaluated as "TRUE" and variables with a "0" values are evaluated as "FALSE".

Variables are stored internally as 4 bytes (double word) for integer portion and 4 bytes (double word) for fractional portion. This way every variable in the system is stored as 64 bit in 32.32 fixed point format. Maximum number can be represented by this format is +/- 2,147,483,648. Variable resolution in this format is 2.3E-10.

## 2.3 Arithmetic's

Four arithmetic functions are supported. Constants as well as User and System variables can be part of the arithmetic expressions.

Examples.

```
V1 = V1+V2           ;Add two user variables
V1 = V1-1            ;Subtract constant from variable
V2 = V1+APOS         ;Add User and System (actual position) variables
APOS = 20            ;Set System variable
V5 = V1*(V2+V3*5/2+1) ;Complicated expression
```

| Operator       | Symbol |
|----------------|--------|
| Addition       | +      |
| Subtraction    | -      |
| Multiplication | *      |
| Division       | /      |
|                |        |

Result overflow for "\*" and "/" operations will cause Arithmetic overflow fault # 19. Result overflow/underflow for "+" and "-" operations does not cause arithmetic fault.

## 2.4 Logical expressions and operators

Bit wise, Boolean, and comparison operators are considered as Logical Operators. Simply put they are the operators which operate on logical values of the operands. There are two possible values for logical operand: TRUE and FALSE. Any value contained in a User variable, System variable or flag is treated as TRUE or FALSE with these types of the operators. If variable value equal "0" it is considered FALSE. All the other values (non 0) including negative numbers are considered TRUE.

## 2.5 Bit wise operators

The following bit wise operators are supported

| Operator | Symbol |
|----------|--------|
| AND      | &      |
| OR       |        |
| XOR      | ^      |
| NOT      | !      |

Both User or System variables can be used with these operators.

Examples:

```
V1 = V2 & 0xF           ;clear all bits but lowest 4
IF (INPUTS & 0x3)       ;check inputs 0 and 1
V1 = V1 | 0xFF          ;set lowest 8 bits
V1 = INPUTS ^ 0xF       ;invert inputs 0-3
V1 = !IN_A1             ;invert input 0
```

## 2.6 Boolean Operators

These operators are used in logical expressions.

| Operator | Symbol |
|----------|--------|
| AND      | &&     |
| OR       |        |
| NOT      | !      |

Examples:

```
IF APOS >2 && APOS <6 || APOS >10 && APOS <20
    . {statements if true}
ENDIF
```

The above example check if APOS (actual position) is within one of two windows; 2 to 6 units or 10 to 20 units. In other words:

If (APOS is more than 2 AND less than 6)  
OR  
If (APOS is more than 10 AND less then 20)  
THEN evaluate to TRUE. Otherwise it is FALSE”

## 2.7 Comparison operators

Following operators are supported:

| Operator      | Symbol |
|---------------|--------|
| More          | >      |
| Less          | <      |
| Equal or more | >=     |
| Equal or less | =<     |
| Not Equal     | <>     |
| Equal         | ==     |

Examples:

```
IF APOS <=10
IF APOS > 20
IF APOS ==5
IF V1<2 && V2 <>4
```

## 2.9 System Variables and Flags

System variables are variables that have a predefined meaning. They give the programmer / user access to certain drive parameters. Most of these variables can be set from MotionView. In most cases the value of these variables can be read and set in your program or via a Host Interface. Variables are either read only, write only or read and write. Read only variables can only be read and can't be set. For example, INPUT = 5, is an illegal action because you can not set an input.

System Flags are System Variables that can only have values of 0 or 1. For example, IN\_A1 is the system flag that reflects the state of digital input1. Since inputs can only be ON or OFF, then the value of IN\_A1 can only be 0 or 1.

## 2.10 System Variables storage organization

All system variables are located in drive's RAM memory and therefore are volatile. However values for some of these system variables are also stored in EPM. When a system variable is changed from MotionView its value changed in both RAM and EPM. When a system variable is changed from the user's program its value is changed in RAM only.

Host interface have the function to change the value in both the EPM and in memory so the user has a choice to change variable in RAM and EPM or in RAM only.

## 2.11 System Variables and Flags Summary

A full list of system variables is shown in Appendix "A". Every aspect of the 940 can be controlled by the manipulation of the values stored in the System Variables. All System Variables start with a "VAR\_" followed by the variable name. Alternatively System Variables can be addressed as an @NUMBER where the number is the variable Index. Most frequently used variables also have alternative names shown below. Variables can be Read-Only (R) or Read/Write (R/W) types. System Flags are always Read Only (R).

Flags don't have Index number assigned to them. They are the product of a BIT mask applied to a particular system variable by drive and are available to user only from the User's program.

| Index | Variable   | Access | Variable Description                                                            | Units                       |
|-------|------------|--------|---------------------------------------------------------------------------------|-----------------------------|
| 186   | UNITS      | R/W    | User Units scale. <sup>(1)</sup>                                                | UserUnits/Rev               |
| 215   | APOS       | R/W    | Actual motor position                                                           | User Units                  |
| 214   | TPOS       | R      | Theoretical/commanded position                                                  | User Units                  |
| 217   | TV         | R      | Commanded velocity in                                                           | User Units/Sec              |
| 213   | RPOS       | R      | Registration position. Valid when system flag F_REGISTRATION set                | User Units                  |
| 218   | TA         | R      | Commanded acceleration                                                          |                             |
| 184   | INPOSLIM   | R/W    | Maximum deviation of position for INPOSITION Flag to remain set                 | User Units                  |
| 180   | MAXV       | R/W    | Maximum velocity for motion commands                                            | User Units/Sec              |
| 181   | ACCEL      | R/W    | Acceleration for motion commands                                                | User Units/Sec <sup>2</sup> |
| 182   | DECEL      | R/W    | Deceleration for motion commands                                                | User Units/Sec <sup>2</sup> |
| 183   | QDECEL     |        | Quick Deceleration for STOP MOTION QUICK statement                              | User Units/Sec <sup>2</sup> |
| 185   | VEL        | R/W    | Set Velocity when in velocity mode                                              | User Units/Sec              |
| 46    | PGAIN_P    | R/W    | Position loop P-gain                                                            | -                           |
| 47    | PGAIN_I    | R/W    | Position loop I-gain                                                            | -                           |
| 48    | PGAIN_D    | R/W    | Position loop D-gain                                                            | -                           |
|       | PGAIN_VFF  | R/W    | Position loop VFF (velocity feed forward) gain                                  | -                           |
| 49    | PGAIN_ILIM | R/W    | Position loop I gain limit                                                      | -                           |
| 44    | VGAIN_P    | R/W    | Velocity loop P-gain                                                            | -                           |
| 45    | VGAIN_I    | R/W    | Velocity loop I-gain                                                            | -                           |
| 65    | INPUTS     | R      | Digital Inputs states. The first 12 bits correspond to the 12 drive inputs      | -                           |
| 66    | OUTPUTS    | R/W    | Digital outputs. First 5 bits represents outputs From #0 to #4                  | -                           |
|       | INDEX      | R/W    | Lower 8 bits are used. See ASSIGN statement for details.                        | -                           |
| 188   | PHCUR      | R      | Motor phase current                                                             | A(mpere)                    |
| 54    | DSTATUS    | R      | Status flags register                                                           | -                           |
|       | DFAULTS    | R      | Fault code register                                                             | -                           |
| 71    | AIN        | R      | Analog input. Scaled in volts.<br>Range form -10 to +10                         | V(olt)                      |
| 88    | AOUT       | R/W    | Analog output value in Volts.<br>Valid range from -10 to +10 (V) <sup>(2)</sup> | V(olt)                      |

(1) When a "0", (Zero), value is assigned to the variable "UNITS", then "USER UNITS" is set to QUAD ENCODER COUNTS. This is the default setting at the start of the program before UNITS=<value> is executed.

(2) Any value outside +/- 10 range assigned to AOUT will be automatically trimmed to that range

Any value outside +/- 10 range assigned to AOUT will be automatically trimmed to that range.

Example:

AOUT=100 , AOUT will be assigned value of 10.

V0=236

VOUT=V0, VOUT will be assigned 10 and V0 will be unchanged.

### System Flags

|                              |   |                                                                                                                                                                                     |
|------------------------------|---|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| IN_A1-4, IN_B1-4, IN_C1-4    | R | Digital inputs . TRUE if input active, FALSE otherwise                                                                                                                              |
| OUT1, OUT2, OUT3, OUT4, OUT5 | W | Digital outputs OUTPUT1- OUTPUT5                                                                                                                                                    |
| F_ICONTROL OFF               | R | Interface Control Status (ON/OFF) #27 in DSTATUS register                                                                                                                           |
| F_IN_POSITION                | R | TRUE when Actual Position (APOS) is within limits set by INPOSLIM variable and motion completed                                                                                     |
| F_ENABLED                    | R | Set when drive is enabled                                                                                                                                                           |
| F_EVENTS OFF                 | R | Events Disabled Status (ON/OFF) #30 in DSTATUS register                                                                                                                             |
| F_MCOMPLETE                  | R | Set when motion is completed and there is no motion commands waiting in the Motion Queue                                                                                            |
| F_MQUEUE_FULL                | R | Motion Queue full                                                                                                                                                                   |
| F_MQUEUE_EMPTY               | R | Motion Queue empty                                                                                                                                                                  |
| F_FAULT                      | R | Set if any fault detected                                                                                                                                                           |
| F_ARITHMETIC_FLT             | R | Arithmetic fault                                                                                                                                                                    |
| F_REGISTRATION               | R | Set when registration mark was detected. Content RPOS variable is valid when this flag is active. Flag resets by any registration moves MOVEPR,MOVEDR or by command REGISTRATION ON |
| F_MSUSPENDED                 | R | Set if motion suspended by statement MOTION SUSPEND                                                                                                                                 |

Flag logic is shown below :

If

```
TPOS-INPOSLIM < APOS < TPOS+INPOSLIM  && F_MCOMPLETE && F_MQUEUE_EMPTY
F_IN_POSITION = TRUE
```

Else

```
F_IN_POSITION = FALSE
```

End If

For VELOCITY and GEAR mode F\_MCOMPLETE and F\_MQUEUE\_EMPTY flags are ignored and assumed TRUE.

## 2.12 Control structures

Control structures allow you to control the flow of your program's execution. Most of the power and utility of any programming language comes from its ability to change statement order with structure and loops.

### DO/UNTIL structures


This statement is used to execute a block of code one time and then continue executing that block until a condition becomes true (satisfied). The difference between DO/UNTIL and WHILE statements is that the DO/UNTIL instruction tests the condition after the block is executed so the conditional statements are always executed at least one time. The syntax for DO/UNTIL statement is:

```
DO
    ...statements
UNTIL <condition>
```

The following flowchart and code segment illustrate the use of the DO/UNTIL statement.

... statements

```
DO
    MOVED 3
    WAIT TIME 2000
UNTIL IN_A3
...statements
```



s819

## WHILE Structure

This statement is used if you want a block of code to execute while a condition is true.

The syntax for the WHILE instruction is:


```
WHILE <condition>
```

...statements

ENDWHILE

...statements

```
WHILE IN_A3
    MOVED 3
    WAIT TIME 2000
ENDWHILE
```



s820

...statements

## Subroutines

A subroutine is a group of SML statements that is located at the end of the main body of the program. It starts with a label which is used by the GOSUB statement to call the subroutine and ends with a RETURN statement. The subroutine is executed by using the GOSUB statement in the main body of the program. Subroutines can not be called from EVENT or FAULT handlers.

When a GOSUB statement is executed, execution is transferred to the first line of the subroutine. The subroutine is then executed until a RETURN statement is met. When the RETURN statement is executed, the programs execution returns to the program line, in the main program, following the GOSUB statement. Subroutines may have more then one RETURN statement in its body.

Subroutines may be nested for up to 16 times. Only the remaining body of the program may contain a GOSUB statement. Refer to Part 3 Language Reference for more detailed information on the GOSUB and RETURN statements. The following flowchart and code segment illustrate the use of subroutines.

```
...statements
GOSUB CalcMotionParam
MOVED V1
OUT2=1
...statements
END
;Subs usually located after END
;statement of main program
;
CalcMotionParam:
V1 = (V3*2)/V4
RETURN
```

## IF Structure

The "IF" statement is used to execute an instruction or block of instructions one time if a condition is true. The simplified syntax for IF is:


```
IF condition
    ...statement(s)
ENDIF
```

The following flowchart and code segment illustrate the use of the IF statement.

...statements

```
IF IN_A2
    OUT2 = 1
    MOVED 3
ENDIF
```

..statements



## IF/ELSE Structure

The IF/ELSE statement is used to execute a statement or a block of statements one time if a condition is true and a different statement or block of statements if condition is false.

The simplified syntax for the IF/ELSE statement is:


```
IF <condition>
    ...statement(s)
ELSE
    ...statement(s)
ENDIF
```

The following flowchart and code segment illustrate the use of the IF/ELSE instruction.

...statements

```
IF IN_A2
    OUT2=1
    MOVED 3
ELSE
    OUT2=0
    MOVED 5
ENDIF
```

..statements



## WAIT Statement

The WAIT statement is used to suspend program execution until or while a condition is true. The simplified syntax for this statement is:

```
WAIT UNTIL <condition>
WAIT WHILE <condition>
WAIT TIME <time>
WAIT MOTION COMPLETE
```

## GOTO/Label

The GOTO statement can be used to transfer program execution to a new point marked by a label. This statement is often used as the action of an IF statement. The destination label may be above or below the GOTO statement in the application program.

Labels may be any alphanumeric string 64 characters in length beginning with a letter and followed by a colon ":".

```
GOTO TestInputs
    ...statements
TestInputs:
    ...statements
IF (IN_A1) GOTO TestInputs
```

## Program Structure Instruction Summary

The following table contains a summary of instructions that relate to program branching.

| Name           | Description                                          |
|----------------|------------------------------------------------------|
| GOTO           | Call a subroutine                                    |
| DO/UNTIL       | Do once and keep doing until conditions becomes true |
| IF and IF/ELSE | Execute if condition is true                         |
| RETURN         | Return from subroutine                               |
| WAIT           | Wait fixed time or until condition is true           |
| WHILE          | Execute while a condition is true                    |

## 2.13 Scanned Event Statements

A Scanned Event is a small program that runs independently of the main program. SCANNED EVENTS are very useful when it is necessary to trigger an action, (handle I/O), while the motor is in motion. When setting up Events, the first step is to define both the action that will trigger the event, as well as the sequence of statements to be executed once the event has been triggered. Events are scanned every 256µS. Before an Event can be scanned however it must first be enabled. Events can be enabled or disabled from the user program, from another event or from itself (see explanations below). Once the Event is defined and enabled, the Event will be constantly scanned until the trigger condition is met, this scan rate is independent of the main programs timing. Once the trigger condition is met the Event statements will be executed simultaneously with the user program.

Scanned events are used to record events and perform actions independent of the main body of the program. For example, if you want output 3 to come ON when the position is greater then 4 inches, or if you need to turn an output 4 ON whenever input 2 and 3 are ON, you may use the following scanned event statements.

```
EVENT      PositionIndicator APOS > 4
           OUT3=1
ENDEVENT

EVENT      Inputs3and4          IN_A4 & IN_B1
           OUT4=1
ENDEVENT
...statements
```

Scanned events may also be used with a timer to perform an action on the periodic time basis.

The program statements contained in the action portion of the scanned event can be any legal program statement except: Subroutine calls (GOSUB), DO/WHILE, WHILE, WAIT, GOTO and also motion commands: MOVED,MOVEP,MDV,STOP, MOTION SUSPEND/RESUME.

### EVENT <name> INPUT <inputname>

This scanned event statement is used to execute a block of code every time a specified input <inputname> changes its state from low->hi. If it is desired to trigger when changing from hi->low then an exclamation point symbol, (!), should be placed in front of the <inputname>, (!IN\_A4).



### EVENT <name> TIME <timeout>

This scanned event statement is used to execute a block of code with a repetition rate specified by the <timeout> argument.

### EVENT <name> expression

This scanned event statement is used to execute a block of code when the expression evaluates to true.

### EVENT <name> ON/OFF

This statement is used to enable/disable scanned event. Statement can be used within event's block of code.

### Scanned Event Statements Summary

The following table contains a summary of instructions that relate to scanned events. Refer to Part 3 "Language Reference" for more detailed information.

| Name                           | Description                                  |
|--------------------------------|----------------------------------------------|
| EVENT <name> ON/OFF            | enable / disable event                       |
| EVENT <name> INPUT <inputname> | Scanned event on input <#>                   |
| EVENT <name> TIME <value>      | Periodic event with <value> repetition rate. |
| EVENT <name> expression        | Scanned event on expression = true           |

## 2.13 Motion

### Moves Overview

The position command that cause motion to be generated comes from the profile generator or profiler for short. The profile generator is used by the MOVE, MOVED, MOVEP, MOVEPR, MOVEDR and MDV statements. MOVE commands generate motion in a positive or negative direction, while or until certain conditions are met. For example you can specify a motion while a specific input remains ON (or OFF). MOVEP generates a move to specific absolute position. MOVED generates incremental distance moves i.e. move some distance from its current position. MOVEPR and MOVEDR are registration moves. MDV commands are used to generate complicated profiles. Profiles generated by these commands are put into the motion stack which is 32 levels deep. By default when one of these statements, (except MDV), is executed, the execution of the main User Program is suspends until the generated motion is done. Motion requests generated by a MDV statement or MOVE statements with the "C" modifier don't suspend the program. They are merely put into the motion stack and executed by profiler in the order they where loaded. The Motion Stack can hold up to 32 moves. The SML language allows the programmer to load moves into the stack and continue on with the program. It is the responsibility of the programmer to check the motion stack to make sure there is room available before loading new moves. This is done by checking the appropriate flag in the System status register.

### Incremental (MOVED) and Absolute (MOVEP) Motion

MOVED and MOVEP statements are used to create incremental and absolute moves respectively. The motion that results from these commands is by default a trapezoidal velocity move or S-curved velocity move if the "S" modifier is used with the statement,

For example:


```
MOVEP 10          ;will result in a trapezoidal move
```

But

```
MOVEP 10,S        ;will result in S-curved move
```

IN the above example, (MOVEP 10), the length of the move is determined by the argument following the MOVEP command, (10). This argument can be a number, a variable or any valid arithmetic expression. The top velocity of the move is determined by setting the system variable MAXV. The acceleration and deceleration are determined by setting the system variables ACCEL and DECEL respectively.

If values for velocity, acceleration and deceleration, for a specified distance, are such that there is not enough time to accelerate to specified velocity, the motion profile will result in triangular or double S profile. (see picture below):



S823

```
ACCEL = 200
DECEL = 200
MAXV = 20
MOVED 4 ;Move 1
MOVED 2 ;Move 2
MOVED 4 , S ;Move 3
MOVED 2 , S ;Move 4
```

All four of the moves shown above have the same Acceleration, Deceleration and Max Velocity values. Moves 1 and 3 have a larger value for the move distance than Moves 2 and 4 have. In Moves 1 and 3 the distance is long enough to allow the motor to accelerate to the profiled max velocity and maintain that velocity before decelerating down to a stop. In Moves 2 and 4 the distance is so small that while the motor is accelerating towards the profiled Max Velocity it has to Decelerate to a stop before it can ever obtain the profiled Max Velocity.

### Incremental (MOVED) motion

Incremental motion is defined as a move of some distance from the current position. Move four revolutions from the current position is an example of an incremental move.

MOVED is the statement used to create incremental moves. The simplified syntax is:

MOVED <+/-distance>

+/- sign will tell the motor shaft what direction to move.

### Absolute (MOVEP) move

Absolute motion is defined as a motion to some fixed position from the current position. The fixed position is defined as a position relative to a fixed zero point. The zero point for a system is established during the homing cycle, typically performed immediately after power-up.

During a homing cycle, the motor will make incremental moves while checking for a physical input, index mark, or both.

### Registration (MOVEDR MOVEPR) moves

MOVEPR and MOVEDR are used to move to position or distance respectively just like MOVEP and MOVED. The difference is that while the statements are being executed they are looking for a registration signal or registration input. If during the motion a registration signal is detected then a new end position is generated. If the move is a MOVEDR then the drive will increment the distance called out in the registration statement. This increment will be referenced from the position the registration input was seen. If the move is a MOVEPR then the new position will be the absolute position called out in the registration statement.

Example:

```
MOVEDR 5, 1 ;Statement move a distance of 5 user units or registration position +  
           ;1 user units if registration input is activated during motion.
```

There are two exceptions from this behavior.

Exception one:

The move will not be modified to "Registration position +displacement" if the registration was detected while system was decelerating to complete the motion.

Exception two:

Once the registration input is seen, there must be enough room for the motor to decelerate to a stop using the profiled Decel Value. If the new registration move is larger than the distance need to come to a stop then the motor will overshoot the new registration position.

### Segment moves

In addition to the simple moves that can be generated by MOVED and MOVEP statements, complex profiles can be generated using segment moves. A segment move represents one portion of a complete move. A complete move is constructed out of two or more segments, starting and ending at zero velocity.


## MDV Segments

Segments are created using a sequence of MDV statements. The simplified syntax for the **MDV (Move Distance with Velocity)** statement is:

MDV <distance>,<velocity>

The <distance> is the length of the segment move. The <velocity> is the final velocity for the segment move. The starting velocity is either zero or the final velocity of the previous segment. The final segment in a complete move must have a velocity of zero. If the final segment has a final velocity anything other than zero, a motion stack under run fault will occur.

The profile shown below can be broken up to 8 MDV moves. The first segment would define the distance between point 1 and point 2 and the velocity at point 2. So, if the distance between point 1 and 2 was 3 units and the velocity at point 2 was 56 RPM, the command would be: MDV 3 , 56. The second segment would give the distance between point 2 and 3 and the velocity at point 3, and so on. Any profile can be programmed using MDV moves.



S823

The following table represents the graph show above.

| Segment Number | Distance moved during segment | Velocity at the end of segment |
|----------------|-------------------------------|--------------------------------|
| 1              | 3                             | 56                             |
| 2              | 3                             | 12                             |
| 3              | 4                             | 16                             |
| 4              | 2                             | 57                             |
| 5              | 2.5                           | 57                             |
| 6              | 3                             | 11                             |
| 7              | 5                             | 20                             |
| 8              | 5                             | 0                              |
| -              | -                             | -                              |

;Segment moves

```
MDV 3 , 56
MDV 3 , 12
MDV 4 , 16
MDV 2 , 57
MDV 2.5 , 57
MDV 3 , 11
MDV 5 , 20
MDV 5 , 0
END
```

The following equation can be used to calculate the acceleration that results from segment move.

$$\text{Accel} = (V_f^2 - V_0^2) / 2 \cdot D$$

V<sub>f</sub> - Final velocity  
V<sub>0</sub> - Starting velocity  
D - Distance

### S-curve Acceleration

Instead of using a linear acceleration, the motion created using segment moves (MDV statements) can use S-curve acceleration. The syntax for MDV move with S-curve acceleration is:

MDV <distance>,<velocity>,S

Segment moves using S-curve acceleration will take the same amount of time as linear acceleration segment moves. S-curve acceleration is useful because it is much smoother at the beginning and end of the segment, however, the peak acceleration of the segment will be twice as high as the acceleration used in the linear acceleration segment.

### Motion SUSPEND/RESUME.

At times it is necessary to control the motion by preloading the motion stack with motion profiles. Then, based on the User Program, execute those motion profiles at some predetermined instance. The statement "MOTION SUSPEND" will suspend motion until the statement "MOTION RESUME" is executed. While motion is suspended, any motion statement executed by the User Program will be loaded into the motion stack. When the "MOTION RESUME" statement is executed the preloaded motion profiles will be executed in the order that they were loaded.

Example:

```
MOTION SUSPEND
MDV 10,2          ;placed in stack
MDV 20,2          ;placed in stack
MDV 2,0           ;placed in stack
MOVED 3,C         ;must use ",C" modifier. Otherwise program will hang.
MOTION RESUME
```

Caution should be taken when using MOVED,MOVEP and MOVE statements. If any of the MOVE instructions are written without the "C" modifier the program will hang, or lock up. The "MOTION SUSPEND" command effectively halts all execution of motion. As the program executes the "MDV" and "MOVED" statements those move profiles are loaded into the motion stack. If the final "MOVED" is missing the "C" modifier then the User Program will wait until that move profile is complete before continuing on. But because motion has been suspended the move will never be complete and the program will hang here indefinitely.

### Conditional moves (MOVE WHILE/UNTIL)

The statements "MOVE UNTIL <expression>" and "MOVE WHILE <expression>" will both start their motion profiles based on their acceleration and max velocity profile settings. The "MOVE UNTIL <expression>" statement will continue the move until the <expression> becomes true. The "MOVE WHILE <expression>" will also continue its move while it's <expression> is true. Expression can be any valid arithmetic or logical expressions or their combination.

Examples:

```
MOVE WHILE APOS<20          ;Move while the position is less than 20, then
                             ;stop with current deceleration rate.
MOVE UNTIL APOS>V1          ;Move positive until the position is greater than
                             ;the value in variable V1
MOVE BACK UNTIL APOS<V1     ;Move negative until the position is less than the
                             ;value in variable V!
MOVE WHILE IN_A1            ;Move positive while input A1 is activated.
MOVE WHILE !IN_A1          ;Move positive while input A1 is not activated.
                             ;The exclamation mark (!) in front of IN_A1 inverts
                             ;(or negates) the value of IN_A1.
```

This last example is a convenient way to find a sensor or switch.

## Motion Queue and statements execution while in motion


By default when the program executes a MOVE, MOVED or MOVEP statement it waits until the motion is complete before going on to the next statement. This effectively will suspend the program until the requested motion is done. Note that "EVENTS" are not suspended however and keep on executing in parallel with the User Program. Like the EVENT command, the Continue "C" argument is very useful when it is necessary to trigger an action, (handle I/O), while the motor is in motion. Below is an example of the Continue "C" argument.

;This program monitors I/O in parallel with motion:

```
START:
    MOVED 100,C           ;start moving max 100 revs
WHILE F_MCOMPLETE=0      ;while moving
IF IN_A2 == 1            ;if sensor detected
    OUT1=1               ;turn ON output for
    WAIT TIME 500        ;500 mS
    OUT1=0               ;turn output OFF
    WAIT TIME 500        ;wait 500 ms
ENDIF
ENDWHILE
    MOVED -100           ;Return back
    WAIT TIME 1000       ;wait time
    GOTO START           ;and start all over
END
```

This program starts a motion of 100 revs. While the motor is in motion input A2 is monitored. If Input A2 is made, during the move, then output 1 is turned on for 500mS and then turned off. The program will continue to loop in the WHILE statement, monitoring input A2, until the move is completed. If input 2 remains ON, or made, during the move, then Output 1 will continue to toggle On and Off every 500 mS until the move is complete. If input A2 is only made while the motion passes by a sensor wired to the input then output 1 will only stay on for 500 mS. By adding the "Continue" argument "C" to the MOVE statement the program is able to monitor the input while executing the motion profile. Without this modifier the program would be suspended until all motion is done making it impossible to look for the input during the move. After the motor has traveled the full distance it then returns back to its initial position and the process repeats. This program could be used for a simple paint mechanism which turns ON a paint spray as soon as the parts edge (or part guide) crosses the sensor(s).

The diagram below illustrates the structure and operation of the Motion Queue. All moves are loaded into the Motion Queue before they are executed. If the move is a standard move, "MOVEP 10" or "MOVED 10", then the move will be loaded into the queue and the execution of the User Program will be suspended until the move is completed. If the move has the continue argument, "MOVEP 10,C" or "MOVED 10,C", or if it is a "MDV" move then the moves will be loaded into Motion Queue and executed simultaneously with the User Program.



S825

The Motion Queue can hold 32 motion profiles. The System Status Register's indicate the state of Motion Queue. If the Flag is set then the queue is full. If the possibility of overflow exists, the programmer should check this flag before executing any MOVE statements, especially in programs where MOVE statements are executed in lopped fashion. Attempts to execute a motion statement while the Motion Queue is full will result in fault #23. MDV statements don't have the "C" option and therefore the program is never suspended by these statements. If last MDV statement in the Queue doesn't specify a 0 velocity Motion, a Stack Underflow fault #24 will occur.

The "MOTION SUSPEND" and "MOTION RESUME" statements can be utilized to help manage the User Program and the Motion Queue. If the motion profiles loaded into the queue aren't managed correctly the Motion Queue can become overloaded which will cause the drive to fault.

## 2.14 System Status Register (DSTATUS register)

System Status Register, (DSTATUS), is a Read Only register. Its bits indicate the various states of the 940's subsystems. Some of the flags are available as System Flag Variables and summarized in the table below:

| Bit in register | Description                                                                                                                                                               |
|-----------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 0               | Set when drive enabled                                                                                                                                                    |
| 1               | Set if DSP subsystem at any fault                                                                                                                                         |
| 2               | Set if drive has a valid program                                                                                                                                          |
| 3               | Set if byte-code or system or DSP at any fault                                                                                                                            |
| 4               | Set if drive has a valid source code                                                                                                                                      |
| 5               | Set if motion completed and target position is within specified limits                                                                                                    |
| 6               | Set when scope is triggered and data collected                                                                                                                            |
| 7               | Set if motion stack is full                                                                                                                                               |
| 8               | Set if motion stack is empty                                                                                                                                              |
| 9               | Set if byte-code halted                                                                                                                                                   |
| 10              | Set if byte-code is running                                                                                                                                               |
| 11              | Set if byte-code is set to run in step mode                                                                                                                               |
| 12              | Set if byte-code is reached the end of program                                                                                                                            |
| 13              | Set if current limit is reached                                                                                                                                           |
| 14              | Set if byte-code at fault                                                                                                                                                 |
| 15              | Set if no valid motor selected                                                                                                                                            |
| 16              | Set if byte-code at arithmetic fault                                                                                                                                      |
| 17              | Set if byte-code at user fault                                                                                                                                            |
| 18              | Set if DSP initialization completed                                                                                                                                       |
| 19              | Set if registration has been triggered                                                                                                                                    |
| 20              | Set if registration variable was updated from DSP after last trigger                                                                                                      |
| 21              | Set if motion module at fault                                                                                                                                             |
| 22              | Set if motion suspended                                                                                                                                                   |
| 23              | Set if program requested to suspend motion                                                                                                                                |
| 24              | Set if system waits completion of motion                                                                                                                                  |
| 25              | Set if motion command completed and motion Queue is empty                                                                                                                 |
| 26              | Set if byte-code task requested reset                                                                                                                                     |
| 27              | If set interface control is disabled. This flag is set/clear by ICONTROL ON/OFF statement.                                                                                |
| 28              | Set if positive limit switch reached                                                                                                                                      |
| 29              | Set if negative limit switch reached                                                                                                                                      |
| 30              | Events disabled. All events disabled when this flag is set. After executing EVENTS ON all events previously enabled by EVENT EventName ON statements become enabled again |

## 2.15 Fault Codes (DFAULTS register)

Faults in the drive are recorded in a special variable called the "DFAULTS" register or "Fault Register". Specific flags are also set in the System Status Register.

Whenever a fault has occurred in the drive a record of that fault will be recorded in a special system variable called the Fault Register, (DFAULTS). In addition, specific flags in the System Status Register will be set helping to indicate what class of fault the current fault belongs to. Below is a table that summarizes the possible fault codes. Note: Codes from 1 to 16 are reserved for DSP subsystem errors. Codes above that range are generated by various systems of the 940.

| Fault ID | Associated flags in status register | Description                                                                                          |
|----------|-------------------------------------|------------------------------------------------------------------------------------------------------|
| 1        | 1, 3                                | Over voltage                                                                                         |
| 2        | 1, 3                                | Invalid hall sensors code                                                                            |
| 3        | 1, 3                                | Over current                                                                                         |
| 4        | 1, 3                                | Over temperature                                                                                     |
| 5        | 1, 3                                | Reserved                                                                                             |
| 6        | 1, 3                                | Over speed. (Over speed limit set by motor capability in motor file)                                 |
| 7        | 1, 3                                | Position error excess.                                                                               |
| 8        | 1, 3                                | Attempt to enable while motor data array invalid or motor was not selected.                          |
| 9        | 1,3                                 | Motor over temperature switch activated                                                              |
| 10       | 1,3                                 | Sub processor error                                                                                  |
| 11-13    | -                                   | Reserved                                                                                             |
| 14       | 1,3                                 | Under voltage                                                                                        |
| 15       | 1,3                                 | Hardware current trip protection                                                                     |
| 16       | -                                   | Reserved                                                                                             |
| 17       | 3                                   | Unrecoverable error.                                                                                 |
| 18       | 16                                  | Division by zero                                                                                     |
| 19       | 16                                  | Arithmetic overflow                                                                                  |
| 20       | 3                                   | Subroutine stack overflow. Exceeded 16 levels subroutines stack depth.                               |
| 21       | 3                                   | Subroutine stack underflow. Executing RETURN statement without preceding call to subroutine.         |
| 22       | 3                                   | Variable evaluation stack overflow. Expression too complicated for compiler to process.              |
| 23       | 21                                  | Motion Queue overflow. 32 levels depth exceeded                                                      |
| 24       | 21                                  | Motion Queue underflow. Last queued MDV statement has non 0 target velocity                          |
| 25       | 3                                   | Unknown opcode. Byte code interpreter error                                                          |
| 26       | 3                                   | Unknown byte code. Byte code interpreter error                                                       |
| 27       | 21                                  | Drive disabled. Attempt to execute motion while drive is disabled.                                   |
| 28       | 16, 21                              | Accel too high. Motion statement parameters calculate an Accel value above the system capability.    |
| 29       | 16, 21                              | Accel too low. Motion statement parameters calculate an Accel value below the system capability.     |
| 30       | 16, 21                              | Velocity too high. Motion statement parameters calculate a velocity above the system capability.     |
| 31       | 16, 21                              | Velocity too low. Motion statement parameters calculate a velocity below the system capability.      |
| 32       | 3,21                                | Positive limit switch engaged                                                                        |
| 33       | 3,21                                | Negative limit switch engaged                                                                        |
| 34       | 3,21                                | Attempt at positive motion with engaged positive limit switch                                        |
| 35       | 3,21                                | Attempt at negative motion with engaged negative limit switch                                        |
| 36       | 3                                   | Hardware disable (enable input not active when attempting to enable drive from program or interface) |
| 37       | 3                                   | Undervoltage                                                                                         |
| 38       | 3                                   | EPM loss                                                                                             |
| 39       | 3,21                                | Positive soft limit reached                                                                          |
| 40       | 3,21                                | Negative soft limit reached                                                                          |
| 41       | 3                                   | Attempt to use variable with unknown ID from user program                                            |



## 2.16 Limitations and restrictions

### Communication Interfaces usage restrictions

Simultaneous connection to the RS232 and RS485 ports is allowed for the purpose of retransmitting (conversion) between interfaces.

Usage of either the RS232 or RS485 simultaneously with Ethernet may lead to unpredictable behavior since the drive will attempt to perform commands from both interfaces concurrently.

### Motion parameters limitation

Due to finite precision in the calculations there are some restrictions for acceleration/deceleration and max velocity for a move. If you receive arithmetic faults during your programs execution it is likely due to these limitations. Min/Max values are expressed in counts or counts/sample, where sample - position loop sample interval and equal 256uS.

| Parameter               | MIN           | MAX          | Units                      |
|-------------------------|---------------|--------------|----------------------------|
| Accel / Decel           | $65/(2^{32})$ | 512          | counts/sample <sup>2</sup> |
| MaxV (maximum velocity) | 0             | 2048         | counts/sample              |
| Max move distance       | 0             | $\pm 2^{31}$ | counts                     |

### Stacks and queues depth limitations

Motion Queue 32

Subroutines Stack 32

Number of events 32

### 3. Language Reference

#### Format

Each statement, system variable or operand is documented using the format shown below. If there is no information in one of the fields the label is still shown.

| KEYWORD           | Long Name                                                                                                                                                                                                                | Type |
|-------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------|
| <b>Purpose</b>    |                                                                                                                                                                                                                          |      |
| <b>Syntax</b>     | KEYWORD=value<br>Variable=KEYWORD<br>Arguments                                                                                                                                                                           |      |
| <b>Remarks</b>    |                                                                                                                                                                                                                          |      |
| <b>See Also</b>   |                                                                                                                                                                                                                          |      |
| <b>Example</b>    |                                                                                                                                                                                                                          |      |
| <b>KEYWORD:</b>   | The KEYWORD is the name of the statement, system variable or system flag as it would appear in a program.                                                                                                                |      |
| <b>Long Name:</b> | The long name is an interpretation of the keyword. For example: MOVEP is the keyword and Move to Position would be a long name. The long name is provided only as an aid to the reader and may not be used in a program. |      |
| <b>Type:</b>      | This field identifies what type of statement or system variable the keyword is.                                                                                                                                          |      |
| <b>Purpose:</b>   | Purpose of the keyword.                                                                                                                                                                                                  |      |
| <b>Syntax:</b>    | This field shows proper usage of the keyword. Optional arguments will be contained within square brackets [ ]. Arguments will be written in italics.                                                                     |      |
| <b>Arguments:</b> | The data that is supplied with a statement that modifies the behavior of the statement. For example, MOVED=100. MOVED is the statement and 100 is the argument.                                                          |      |
| <b>Remarks:</b>   | The remark field contains additional information about the usage of the statement or system variable.                                                                                                                    |      |
| <b>See Also:</b>  | This field contains a list of statements or system variables that are related to the purpose of the keyword.                                                                                                             |      |
| <b>Example:</b>   | The example field contains a code segment that illustrates the usage of the keyword                                                                                                                                      |      |
| <b>Reference</b>  |                                                                                                                                                                                                                          |      |

| ASSIGN            | Assign Input As Index Bit                                                                                                                                                                        | Statement |
|-------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|
| <b>Purpose</b>    | Assign keyword causes specific input to act as a particular bit of system variable INDEX. After such assignments changes in input state will cause changes in particular bit input is assign to. |           |
| <b>Syntax</b>     | ASSIGN INPUT <input name> AS BIT <bit #>                                                                                                                                                         |           |
| <b>Input name</b> | Input name (IN_A1..IN_A2 etc.)<br>Bit# INDEX variable bit number from 0 to 7                                                                                                                     |           |
| <b>Remarks</b>    |                                                                                                                                                                                                  |           |
| <b>See Also</b>   |                                                                                                                                                                                                  |           |
| <b>Example:</b>   | <pre>ASSIGN INPUT IN_B4 AS BIT 0 ;index bit 0 state matches state of input B4</pre>                                                                                                              |           |

| DEFINE          | Define name                                                                                                                                                                                                                      | Pseudo-statement |
|-----------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------|
| <b>Purpose</b>  | DEFINE is used to define symbolic names for variables and constants for programming convenience. It is a pseudo-statement i.e. it is not executable.<br>DEFINE can be used also to substitute a symbolic string.                 |                  |
| <b>Syntax</b>   | DEFINE <name> <string><br>name      any symbolic string<br>string     any symbolic string                                                                                                                                        |                  |
| <b>Remarks:</b> | DEFINE must be located before any executable statement                                                                                                                                                                           |                  |
| <b>See Also</b> |                                                                                                                                                                                                                                  |                  |
| <b>Example:</b> | <pre> DEFINE  Five      5 DEFINE  Three     3 DEFINE  Result    V1 DEFINE  SUMM Five + Three  ProgramStart: Result = Five + Three           ;Is same as V1 = 5+3 Result = SUMM                  ;same result as above End </pre> |                  |

| DISABLE         | Turns servo OFF                                                                                                                                                                                                                                                                                                     | Statement |
|-----------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|
| <b>Purpose</b>  | DISABLE turns the power to the motor OFF and disables the servo.                                                                                                                                                                                                                                                    |           |
| <b>Syntax</b>   | DISABLE                                                                                                                                                                                                                                                                                                             |           |
| <b>Remarks</b>  | Once the DISABLE statement is executed, power to the drive is turned off and the motor can move freely. APOS will continue to display the current position of the motor. Even though TPOS will be updated to the value of APOS once the ENABLE statement is executed, it is recommended that the motor be re-homed. |           |
| <b>See Also</b> | ENABLE                                                                                                                                                                                                                                                                                                              |           |
| <b>Example:</b> | <pre> DISABLE </pre>                                                                                                                                                                                                                                                                                                |           |

| DO UNTIL        | Do/Until                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | Statement |
|-----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|
| <b>Purpose</b>  | DO <statement(s)> UNTIL <condition> executes the statement(s) between the DO and the UNTIL repeatedly until the <condition> specified becomes TRUE.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |           |
| <b>Syntax</b>   | DO <statement(s)> UNTIL <condition><br><statement(s)> any valid statement(s)<br><condition>    The condition to be tested.<br><br>The condition may be a comparison, an input being TRUE or FALSE (H or L) system flag or a variable used as a flag (if 0 - false, else - true ). Comparisons compare the values of two operands and determine if the condition is TRUE or FALSE. A comparison may be greater (>), less than (<), less than or equal (<=), or greater than or equal to (>=). The operands of a comparison may be user variable, system variables, analog input values, or constants.<br><br>IN_A1                ;an input is evaluated to true if active<br>V1                 ;user variable. True when non 0, false when 0<br>INPOSITION       ;System flag<br>V1 > V2            ;user variable comparison<br>V1 > APOS          ;comparison user and system variables<br>APOS < 8.4        ;compare system variable to constant |           |
| <b>Remarks</b>  | Unlike the WHILE statement, the loop body will always be executed at least once because the DO/UNTIL statement tests the <condition> AFTER the loop body is executed.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |           |
| <b>See Also</b> | WHILE, IF                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |           |
| <b>Example:</b> | <pre> DO MOVED V1            ;Keep looping through the Do Move statements UNTIL IN_B4            ;Until the input is made WHILE IN_A2            ;IN_A2 is activated (TRUE) </pre>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |           |

| ENABLE          | Enables servo                                     | Statement |
|-----------------|---------------------------------------------------|-----------|
| <b>Purpose</b>  | Turns power to the motor on and enables the servo |           |
| <b>Syntax</b>   | ENABLE                                            |           |
| <b>Remarks</b>  |                                                   |           |
| <b>See Also</b> | DISABLE                                           |           |
| <b>Example:</b> | ENABLE ;servo turns on after this statement       |           |

| END             | END program                                                               | Statement |
|-----------------|---------------------------------------------------------------------------|-----------|
| <b>Purpose</b>  | This statement is used to terminate (finish) user program and its events. |           |
| <b>Syntax</b>   | END                                                                       |           |
| <b>Remarks</b>  | END can be used anywhere in program                                       |           |
| <b>See Also</b> | DISABLE                                                                   |           |
| <b>Example:</b> | ENABLE ;servo turns on after this statement                               |           |

| EVENT          | Starts Event handler                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | Statement |
|----------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|
| <b>Purpose</b> | EVENT keyword creates scanned event handler.<br>Statement also sets one of 4 types of events possible.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |           |
| <b>Syntax</b>  | <ol style="list-style-type: none"> <li>1. EVENT &lt;name&gt; INPUT &lt;inputname&gt;<br/>Or</li> <li>2. EVENT &lt;name&gt; INPUT !&lt;inputname&gt;<br/>Or</li> <li>3. EVENT &lt;name&gt; TIME &lt;period &gt;<br/>Or</li> <li>4. EVENT &lt;name&gt; &lt;expression&gt; <ul style="list-style-type: none"> <li>name any valid alphanumeric string</li> <li>inputname any valid input "IN_A1 - IN_C4"</li> <li>period any integer number. Expressed in ms</li> <li>expression any arithmetic or logical expression</li> </ul> </li> </ol> <p>The following statements can not be used within event's handler:<br/> MOVE,MOVED,MOVEP,MOVEDR,MOVEPR,MDV<br/> MOTION SUSPEND<br/> MOTION RESUME<br/> STOP MOTION<br/> DO UNTIL<br/> GOTO<br/> GOSUB<br/> HALT<br/> VELOCITY ON/OFF<br/> WAIT<br/> WHILE</p> <p>While GOTO or GOSUB are restricted, a special JUMP statement can be used for program flow change from within event handler. See JUMP statement description in Language Reference section.</p> |           |

#### Remarks

For syntax 1 and 2:

The Event will occur when the input with the <name/number> transition from L to H, for syntax 1 and from H to L for syntax 2.

For syntax 3:

The Event will occur when the specified , <period>, period of time has expired. This event can be used as periodic event to check for some conditions.

For syntax 4

The Event will occur when the expression, <expression>, evaluates to be true. The expression can be any valid arithmetic or logical expression or combination of the two. This event can be used when implementing soft limit switches or when changing the program flow based on some conditions. Any variable, (user and system), or constants can be used in the expression.

**See Also** ENDEVENT, EVENT ON, EVENT OFF

**Example:**

```

V0=0
V1=0
EVENT InEvent IN_A1
  V0 = V0+1          ;count
ENDEVENT
EVENT period  TIME 1000 ;1000 ms = 1Sec
V3=V0-V1          ;new count - old count = number of pulses per second
V0=V1             ;save as old count
;-----
EVENT InEvent ON
EVENT period ON
{program statements}
END

```

| ENDEVENT        | END of Event handler                        | Statement |
|-----------------|---------------------------------------------|-----------|
| <b>Purpose</b>  | Indicates end of the event handler          |           |
| <b>Syntax</b>   | ENDEVENT                                    |           |
| <b>Remarks</b>  |                                             |           |
| <b>See Also</b> | EVENT, EVENT ON, EVENT OFF                  |           |
| <b>Example:</b> | EVENT InputRise IN_B4<br>V0=V+1<br>ENDEVENT |           |

| EVENT ON/OFF    | Turn events on or off                                            | Statement |
|-----------------|------------------------------------------------------------------|-----------|
| <b>Purpose</b>  | turns events created by EVENT handler statement ON or OFF        |           |
| <b>Syntax</b>   | EVENT <name> ON<br>EVENT <name> OFF<br><name> Event handler name |           |
| <b>Remarks</b>  |                                                                  |           |
| <b>See Also</b> | EVENT                                                            |           |
| <b>Example:</b> |                                                                  |           |
|                 | EVENT InputRise ON                                               |           |
|                 | EVENT InputRise OFF                                              |           |

| EVENT ON/OFF    | Globally Enables/disables events                                                                                                                                                                                                                | Statement |
|-----------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|
| <b>Purpose</b>  | Enables/Disables events execution previously enabled by EVENT Eventname ON statement. This is a global ON/OFF control. Effects flag #30 in DSTATUS register - F_EVENTSOFF. After executing EVENTS ON individual event's on/off states restored. |           |
| <b>Syntax</b>   | EVENTS ON      Restores execution of previously enabled events.<br>EVENTS OFF      Disables all execution of all events                                                                                                                         |           |
| <b>Remarks</b>  | Events are globally enabled after reset and controlled by individual Event Eventname ON statements.                                                                                                                                             |           |
| <b>See Also</b> | EVENT ON/OFF                                                                                                                                                                                                                                    |           |

**Example:**

```

*****
EVENT SKIPOUT IN_B4      ;check for rising edge of input B4
JUMP TOGGLE              ;redirect code execution to TOGGLE
ENDEVENT                 ;end the event

EVENT OVERSHOOT IN_B3    ;check for rising edge of input B3
JUMP SHUTDOWN            ;redirect code execution to SHUTDOWN
ENDEVENT                 ;end the event
*****

EVENT SKIPOUT ON
EVENT OVERSHOOT ON
*****

.....User code.....

EVENTS OFF                ;turns off all events

.....User code.....

EVENTS ON                 ;turns on any event previously activated

```

| FAULT           | User generated fault                                                                                                                                                                                                                                               | Statement                                                                                                     |
|-----------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>  | Allows the user program to set a custom system fault. This is useful when the custom program needs a standard fault process for custom conditions like data supplied by interface out of range etc. Custom fault numbers must be in region of 128 to 240 (decimal) |                                                                                                               |
| <b>Syntax</b>   | FAULT FaultNumber                                                                                                                                                                                                                                                  | Sets system fault.<br>Faultnumber - constant in range 128-240<br>Variables are not allowed in this statement. |
| <b>Remarks</b>  | Custom fault will be processed as any regular fault. There will be a record in the fault log.                                                                                                                                                                      |                                                                                                               |
| <b>See Also</b> | ON FAULT                                                                                                                                                                                                                                                           |                                                                                                               |

**Example:**

```

FAULT 200                ;Sets fault #200

V0=200

FAULT V0                  ;Not valid. Variables are not allowed here

```

| GOTO            | Go To                                                              | Statement |
|-----------------|--------------------------------------------------------------------|-----------|
| <b>Purpose</b>  | Transfer program execution to the instruction following the label. |           |
| <b>Syntax</b>   | GOTO <label>                                                       |           |
| <b>Remarks</b>  |                                                                    |           |
| <b>See Also</b> | GOSUB, JUMP                                                        |           |

**Example:**

```

GOTO Label2
{Statements...}

Label2:  {Statements...}

```

| <b>GOSUB</b>    | <b>Go To subroutine</b>                                                      | <b>Statement</b> |
|-----------------|------------------------------------------------------------------------------|------------------|
| <b>Purpose</b>  | GOSUB transfers control to <subname> subroutine.                             |                  |
| <b>Syntax</b>   | GOSUB <subname>                                                              |                  |
|                 | <subname>      a valid subroutine name                                       |                  |
| <b>Remarks</b>  | After return from subroutine program resumes from next statement after GOSUB |                  |
| <b>See Also</b> | GOTO, JUMP, RETURN                                                           |                  |

**Example:**

```

DO
GOSUB  CALCMOVE
MOVED   V1
WHILE  1
END

SUB      CALCMOVE
      V1= (V2+V3) / 2
RETURN

```

| <b>HALT</b>     | <b>Halt the program execution</b>                                                                                                                                                       | <b>Statement</b> |
|-----------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------|
| <b>Purpose</b>  | Used to halt main program execution. Events are not halted by the HALT statement. Execution will be resumed by the RESET statement or by executing the JUMP to code from EVENT handler. |                  |
| <b>Syntax</b>   | HALT                                                                                                                                                                                    |                  |
| <b>Remarks</b>  | This statement is convenient when writing event driven programs.                                                                                                                        |                  |
| <b>See Also</b> | RESET                                                                                                                                                                                   |                  |

**Example:**

```

{Statements...}
HALT

```

| <b>JUMP</b>     | <b>Jump to label from Event handler</b>                                                                                                                                                                                                                                                                                                                                                                                                      | <b>Statement</b>                   |
|-----------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------|
| <b>Purpose</b>  | This is a special purpose statement to be used only in the Event Handler code. When the EVENT is triggered and this statement is processed, execution of the user's program is transferred to the <label> argument called out in the "JUMP" statement. This statement is particularly useful when there is a need for program's flow to change based on some event(s).<br>Transfer program execution to the instruction following the label. |                                    |
| <b>Syntax</b>   | JUMP <label>                                                                                                                                                                                                                                                                                                                                                                                                                                 | <label> is any valid program label |
| <b>Remarks</b>  | Can be used in EVENT handler only.                                                                                                                                                                                                                                                                                                                                                                                                           |                                    |
| <b>See Also</b> | EVENT                                                                                                                                                                                                                                                                                                                                                                                                                                        |                                    |

**Example:**

```

    {Statements...}
EVENT ExternalFault INPUT IN_A3    ;activate Event when IN_A3 goes high
    JUMP ExecuteStop                ;redirect program execution to <ExeecuteStop>
ENDEVENT

    {statements...}
StartMotion:
    EVENT ExternalFault ON
    ENABLE
    MOVED 20
    MOVED -100
    {statements}
END

ExecuteStop:
    STOP MOTION                    ;Motion stopped here
    DISABLE                        ;drive disabled
    GOTO StartMotion

```



| ICONTROL<br>ON/OFF | Enables interface control                                                                                                                                                                                                                                                                                                                                                                                                           | Statement                                               |
|--------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------|
| <b>Purpose</b>     | Enables/Disables interface control. Effects flag #27 in DSTATUS register F_ICONTROLOFF.<br>All interface motion commands and commands changing any outputs will be disabled. See Host interface commands manual for details. This command is useful when the program is processing critical states (like limit switches for example) and can't be disturbed by the interface (usually asynchronous body to the program state/event) |                                                         |
| <b>Syntax</b>      | ICONTROL ON<br>ICONTROL OFF                                                                                                                                                                                                                                                                                                                                                                                                         | Enables Interface control<br>Disables interface control |
| <b>Remarks</b>     | After reset interface control is enabled by default.                                                                                                                                                                                                                                                                                                                                                                                |                                                         |

#### See Also

#### Example:

```

EVENT LimitSwitch IN_A1      ;limit switch event
  Jump LimitSwitchHandler    ;jump to process limit switch
ENDEVENT

V0=0
EVENT LimitSwitch ON
Again:
HALT                          ;system controlled by interface

LimitSwitchHandler:
  EVENTS OFF                  ;turn off all events
  ICONTROL OFF                ;disable interface control
  STOP MOTION QUICK
  DISABLE                     ;optional DISABLE
  V0=1                        ;indicate fault condition to the interface
  ICONTROL ON
  EVENTS ON
  GOTO AGAIN

```

| IF              | If/Then/Else                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               | Statement |
|-----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|
| <b>Purpose</b>  | The IF statement tests for a condition and then executes the specific action(s) between the IF and ENDIF statements if the condition is satisfied. If the condition is false, no action is taken and the instructions following the ENDIF statement are executed. Optionally, using the ELSE statement, a second action(s) may be specified to be executed if the condition is false.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |           |
| <b>Syntax</b>   | <pre> IF &lt;condition&gt; {statements 1}  ELSE {statements 2}  ENDIF </pre> <p>The, &lt;condition&gt;, is the condition to be tested. This condition may be a comparison, an input being TRUE or FALSE (H or L), system flag or a variable used as a flag (if 0 - false, else - true ).</p> <p>Comparisons compare the values of two operands and determine if the condition is TRUE or FALSE. A comparison may be greater (&gt;), less than (&lt;), less than or equal (&lt;=), or greater than or equal to (&gt;=). The operands of a comparison may be a user variable, system variables, analog input values, or constants.</p> <pre> IN_A1           ;an input is evaluated to true if active V1              ;user variable. True when non 0, false when 0 INPOSITION      ;system flag V1 &gt; V2         ;user variable comparison V1 &gt; APOS       ;comparison user and system variables APOS &lt; 8.4      ;compare system variable to constant {Statements 1}  ;statements will be performed if condition is TRUE {Statements 2}  ;statements will be performed if condition is FALSE </pre> |           |
| <b>Remarks</b>  | Only {Statements 1} or {Statements 2} will be performed. It is impossible for both to take place.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |           |
| <b>See Also</b> | WHILE, DO                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |           |

**Example:**

```

IF APOS > 4
    V0=2
;-----
ELSE
    V0=0
ENDIF
;-----
If V1 <> V2 && V3>V4
    V2=9
ENDIF

```

| MOVE           | Move                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                | Statement |
|----------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|
| <b>Purpose</b> | MOVE UNTIL performs motion until condition becomes TRUE. MOVE WHILE performs motion while conditions stays TRUE. The statement suspends the programs execution until the motion is completed, unless the statement is used with C modifier.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |           |
| <b>Syntax</b>  | MOVE [BACK] UNTIL <condition> [,C]<br>MOVE [BACK] WHILE <condition> [,C]<br><br>BACK            Changes direction of the move.<br><br>C (optional)    C[ontinue] - modifier allows the program to continue while motion is being performed. If a second motion profile is executed while the first profile is still in motion, the second profile will be loaded into the Motion Stack. The Motion Stack is 32 entries deep. The programmer should check the "F_MQUEUE_FULL" system flag to make sure that there is available space in the queue. If the queue becomes full, or overflows, then the drive will generate a fault.<br><br><condition>    The condition to be tested. The condition may be a comparison, an input being TRUE or FALSE (H or L) system flag or a variable is used as flag (if 0 - false, else - true ). |           |

**Remarks**

**See Also**    MOVEP, MOVED, MOVEPR, MOVEDR, MDV, MOTION SUSPEND, MOTION RESUME

**Example:**

```
{Statements...}
MOVE UNTIL V0<3
MOVE BACK UNTIL V0>4
MOVE WHILE V0<3
MOVE BACK WHILE V0>4
MOVE WHILE V0<3,C
```

| MOVED          | Move Distance                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | Statement |
|----------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|
| <b>Purpose</b> | MOVED performs incremental motion (distance) specified in User Units. The commanded distance can range from -231 to 231. This statement will suspend the programs execution until the motion is completed, unless the statement is used with the "C" modifier. If the "S" modifier is used then S-curve accel is performed during the move.                                                                                                                                                                                                                                                                                          |           |
| <b>Syntax</b>  | C[ontinue]    MOVED <distance>[,S] [,C]<br><br>The "C" argument is an optional modifier which allows the program to continue executing while the motion profile is being executed. If the drive is in the process of executing a previous motion profile the new motion profile will be loaded into the Motion Stack. The Motion Stack is 32 entries deep. The programmer should check the "F_MQUEUE_FULL" system flag to make sure that there is available space in the queue. If the queue becomes full, or overflows, then the drive will generate a fault.<br><br>S[-curve]    optional modifier specifies S-curve acceleration. |           |

**See Also**    MOVE, MOVEP, MOVEPR, MOVEDR, MDV, MOTION SUSPEND, MOTION RESUME

**Example:**

```
{Statements...}
MOVED 3                    ;moves 3 user units forward
MOVED BACK 3              ;moves 3 user units backward
{Statements...}
```

| <b>MOVEP</b>    | <b>Move to Position</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               | <b>Statement</b> |
|-----------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------|
| <b>Purpose</b>  | MOVEP performs motion to a specified absolute position in User Units. The commanded range for an Absolute move is from -231 to 231. This statement will suspend the programs execution until the motion is completed, unless the statement is used with the "C" modifier. If the "S" modifier is used then S-curve accel is performed during the move.                                                                                                                                                                                                                                                                                |                  |
| <b>Syntax</b>   | MOVEP <absolute position>[,S] [,C]<br>C[ontinue]    The "C" argument is an optional modifier which allows the program to continue executing while the motion profile is being executed. If the drive is in the process of executing a previous motion profile the new motion profile will be loaded into the Motion Stack. The Motion Stack is 32 entries deep. The programmer should check the "F_MQUEUE_FULL" system flag to make sure that there is available space in the queue. If the queue becomes full, or overflows, then the drive will generate a fault.<br>S[-curve]    optional modifier specifies S-curve acceleration. |                  |
| <b>See Also</b> | MOVE, MOVEP, MOVEPR, MOVEDR, MDV, MOTION SUSPEND, MOTION RESUME                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |                  |

**Example:**

```
{Statements...}
MOVEP 3           ;moves to 3 user units absolute position
{Statements...}
```

| <b>MOVEDR</b>   | <b>Registered Distance Move</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            | <b>Statement</b> |
|-----------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------|
| <b>Purpose</b>  | MOVEDR performs incremental motion, specified in User Units. If during the move the registration input becomes activated (goes high) then the current position is recorded, and the displacement value (the second argument in the MOVEPR statement) is added to this position to form a new target position. The end of the move is then altered to this new target position. This statement suspends execution of the program until the move is completed, unless the statement is used with the "C" modifier.                                                                           |                  |
| <b>Syntax</b>   | MOVEDR <distance>,<displacement> [,C]<br>C[ontinue]    The "C" argument is an optional modifier which allows the program to continue executing the User Program while a motion profile is being processed. If a new motion profile is requested while the drive is processing a move the new motion profile will be loaded into the Motion Stack. The Motion Stack is 32 entries deep. The programmer should check the "F_MQUEUE_FULL" system flag to make sure that there is available space in the queue. If the queue becomes full, or overflows, then the drive will generate a fault. |                  |
| <b>See Also</b> | MOVE, MOVEP, MOVEPR, MOVED, MDV, MOTION SUSPEND, MOTION RESUME                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |                  |

**Example:**

```
{Statements...}
MOVEDR 3, 2
{Statements...}
```

This example moves the motor 3 user units and checks for the registration input. If registration isn't detected then the move is completed. If registration is detected, the registration position is recorded and a displacement value of 2 is added to the recorded registration position to calculate the new end position.

| MOVEPR          | Registered Distance Move                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | Statement |
|-----------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|
| <b>Purpose</b>  | MOVEPR performs absolute position moves specified in User Units. If during a move the registration input becomes activated, goes high, then the end position of the move is altered to a new target position. The new position is a generated from the second argument in the MOVEPR statement, (displacement). This statement suspends the execution of the program until the move is completed, unless the statement is used with C modifier.                                                                                                                                           |           |
| <b>Syntax</b>   | MOVEPR <distance>,<displacement> [,C]<br>C[ontinue]    The “C” argument is an optional modifier which allows the program to continue executing the User Program while a motion profile is being processed. If a new motion profile is requested while the drive is processing a move the new motion profile will be loaded into the Motion Stack. The Motion Stack is 32 entries deep. The programmer should check the “F_QUEUE_FULL” system flag to make sure that there is available space in the queue. If the queue becomes full, or overflows, then the drive will generate a fault. |           |
| <b>See Also</b> | MOVE, MOVEP, MOVEPR, MOVED, MDV, MOTION SUSPEND, MOTION RESUME                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |           |
| <b>Example:</b> | This example moves the motor to the absolute position of 3 user units while checking for the registration input.<br>{Statements...}<br>MOVEPR 3, 2    If registration isn't detected then the move is completed .<br>{Statements...}    If registration is detected then the end of the move is changed to a new absolute target position of 2 user units.                                                                                                                                                                                                                                |           |

| MDV             | Segment Move                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       | Statement |
|-----------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|
| <b>Purpose</b>  | MDV defines incremental motion segment by specifying distance and final velocity (for each segment) in User Units. Acceleration (or deceleration) is calculated automatically based on these two parameters. This technique allows complicated moves to be created that consist of many segments. Each MDV move starts and ends with a velocity of 0. Based on this a MDV move must have at least two segments. The MDV statement doesn't suspend execution of the main program. Each segment is loaded into the Motion Queue immediately. If the last segment in the Motion Queue doesn't have a final velocity of 0 the drive will generate a “Motion Queue Empty” fault #24. If the “S” modifier is used in the statement then the velocity acceleration/deceleration will be S-curved as opposed to be linear. |           |
| <b>Syntax</b>   | MDV            <[-]segment distance>,<segment final velocity> [,S]<br>S[-curve]    optional    modifier specifies S-curve acceleration.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |           |
| <b>See Also</b> | MOVE, MOVEP, MOVEPR, MOVED, MDV, MOTION SUSPEND, MOTION RESUME                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |           |
| <b>Example:</b> | {Statements...}<br>MDV 5, 10            ;Move 5 user units and accelerate to a velocity of 10<br>MDV 10,10           ;Move 10 user units and maintain a velocity of 10<br>MDV 10,5            ;Move 10 user units and decelerate to velocity of 5<br>MDV 5,;0            ;Move 5 user units and decelerate to velocity 0.<br>;The last MDV must have a final velocity of 0.<br>{Statements...}                                                                                                                                                                                                                                                                                                                                                                                                                     |           |

| <b>MOTION SUSPEND</b> | <b>Suspend</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            | <b>Statement</b> |
|-----------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------|
| <b>Purpose</b>        | <p>This statement is used to temporarily suspend motion without flashing the Motion Queues contents. If this statement is executed while a motion profile is being processed then the motion will not be suspended until after the completion of the move. If executing a series of MDV segment moves, motion will not be suspended until after the all MDV segment have been processed. If the Motion Queue is empty then any subsequent motion statement will be loaded into the queue and will remain there until the "Motion Resume" statement is executed. Any motion statements without the "C" modifier (except MDV statements) will lock-up the User Program.</p> <p>To illustrate this program lock-up, reference the following program:</p> <pre> ;Program locked-up after MOVE statement executed ...{statements} MOTION SUSPEND    ;Motion is put on hold, or suspended MOVE 20           ;Motion profile is loaded into the Motion Queue                   ;and the program is suspended until the move is                   ;completed. ...{statements}   ;These statements never get executed because                   ;the drive is waiting for completion of the                   ;above move which will never get processed                   ;because motion is suspended. MOTION RESUME      ;Like the above statements this command will never                   ;get executed and the program will be LOCKED-UP. </pre> <p>You can only unlock this situation by a reset or by the execution the MOTION RESUME command from a Host Interface.</p> |                  |
| <b>Syntax</b>         | MOTION SUSPEND                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |                  |
| <b>Remarks</b>        | Performing any MOVEx commands without "C" modifier will lock-up the user program. You will be able to unlock it only by performing Reset or Host Interface command "Motion Resume"                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |                  |
| <b>See Also</b>       | MOVE, MOVEP, MOVEDR, MOVED, MOVEPR ,MDV, MOTION RESUME                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |                  |

**Example:**

```

...{statements}
MOTION SUSPEND    ;Motion will be suspended after current motion
                  ;command is finished.
...{statements}

```

| <b>MOTION RESUME</b> | <b>Resume</b>                                                                                                                             | <b>Statement</b> |
|----------------------|-------------------------------------------------------------------------------------------------------------------------------------------|------------------|
| <b>Purpose</b>       | Statement resumes motion previously suspended by MOTION SUSPEND. If motion was not previously suspended, this has no effect on operation. |                  |
| <b>Syntax</b>        | MOTION RESUME                                                                                                                             |                  |
| <b>See Also</b>      | MOVE, MOVEP, MOVEDR, MOVED, MOVEPR ,MDV, MOTION RESUME                                                                                    |                  |

**Example:**

```

...{statements}
MOTION RESUME    ;Motion is resumed from current command in  motion Queue (if any)
...{statements}

```

| ON FAULT/<br>ENDFAULT | Resume                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | Statement |
|-----------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|
| <b>Purpose</b>        | <p>This statement starts the Fault Handler section of the User Program. The Fault Handler is a piece of code which is executed when a fault occurs in the drive. The Fault Handler program must begin with the "ON FAULT" statement and end with the "ENDFAULT" statement. If a Fault Handler routine is not defined then the User Program will be terminated anytime the drive detects a fault. Subsequently, if a Fault Handler is defined, and a fault is detected, the drive will be disabled, all scanned events will be disabled, and the Fault Handler routine will be executed. The RESUME and RESET statements can be used to redirect the program execution from the Fault Handler back to the main program. If these statements are not utilized then the program will terminate once the ENDFault statement is executed.</p> <p>The following statements can't be used in fault handler:<br/> MOVE, MOVED, MOVEP, MOVEDR, MOVEPR, MDV, MOTION SUSPEND, MOTION RESUME,<br/> GOTO, GOSUB, JUMP, ENABLE, GEAR ON/OFF, and VELOCITY ON/OFF</p> |           |
| <b>Syntax</b>         | <pre>ON FAULT {...statements} ENDFAULT</pre>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |           |
| <b>See Also</b>       | RESUME, RESET                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |           |

**Example:**

```

...{statements}                ;User program
FaultRecovery:                 ;Recovery procedure
...{statements}

END

ON FAULT                        ;Once fault occurs program is directed here
...{statements}                ;Any code to deal with fault
RESUME FaultRecovery           ;Execution of RESUME ends Fault Handler and directs
                               ;execution back to User Program. If RESUME is omitted
                               ;the program will terminate here

ENDFAULT                       ;Fault routine must end with a ENDFault statement

```

| REGISTRATION ON | Registration On                                                                                                                                                                                                                                                                                                                                                                                          | Statement                                                      |
|-----------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------|
| <b>Purpose</b>  | <p>This statement arms the registration input, (input IN_C3). When the registration input is activated, the Flag Variable "F_REGISTRATION" is set and the current position is captured and stored to the "RPOS" System Variable. Both of these variables are available to the User Program for decision making purposes. The "REGISTRATION ON" statement will also resets the "F_REGISTRATION" flag.</p> |                                                                |
| <b>Syntax</b>   | REGISTRATION ON                                                                                                                                                                                                                                                                                                                                                                                          | Flag "F_REGISTRATION" is reset and registration input is armed |
| <b>See Also</b> | MOVEDR, MOVEPR                                                                                                                                                                                                                                                                                                                                                                                           |                                                                |

**Example:**

```

; Moves until input is activated and then come back to the sensor position.
...{statements}

REGISTRATION ON                ;Arm registration input
MOVE UNTIL IN_C3              ;Move until input is activated, (sensor hit)
MOVEP RPOS                    ;Absolute move to the position of the sensor
...{statements}

```

| RESUME          | Resume                                                                                                                                                                                                                                                                                    | Statement                                           |
|-----------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------|
| <b>Purpose</b>  | This statement redirects the code execution from the Fault Handler routine back to in the User Program. The specific line in the User Program to be directed to is called out in the argument <label> in the "RESUME" statement. This statement is only allowed in fault handler routine. |                                                     |
| <b>Syntax</b>   | RESUME <label>                                                                                                                                                                                                                                                                            | <label> Label address in User Program to be sent to |
| <b>See Also</b> | ON FAULT                                                                                                                                                                                                                                                                                  |                                                     |

**Example:**

```

...{statements}
FaultRecovery:
...{statements}
END
ON FAULT                ;Once fault occurs program is directed here
...{statements}         ;Any code to deal with fault
RESUME FaultRecovery    ;Execution of RESUME ends Fault Handler and directs
                        ;execution back to the "FaultRecovery" label in the User
                        ;Program.
                        ;If RESUME is omitted the program will terminate here.
ENDFAULT                ;Fault routine must end with a ENDFault statement

```

| RETURN          | Return from subroutine                                                                                                                                                                                                                                                   | Statement |
|-----------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|
| <b>Purpose</b>  | This statement will return the code execution back from a subroutine to the point in the program from where the subroutine was called. If this statement is executed without a previous call to subroutine, (GOSUB), fault #21 "Subroutine stack underflow" will result. |           |
| <b>Syntax</b>   | RETURN                                                                                                                                                                                                                                                                   |           |
| <b>See Also</b> | GOTO, GOSUB                                                                                                                                                                                                                                                              |           |

**Example:**

```

...{statements}...
GOSUB MySub             ;Program jumps to Subroutine "MySub"
MOVED 10                ;Move to be executed once the Subroutine has executed
                        ;the RETURN statement.
...{statements}
END                      ;main program end
MySub:                  ;Subroutine called out from User Program
...{statements}         ;Code to be executed in subroutine
RETURN                  ;Returns execution to the line of code under the "GOSUB"
                        ;command, (MOVED 10 statement).

```



| SEND/SEND TO | Send network variable(s) value                                                                                                                                                                                                                                                                                                                                                                                                                                                                       | Statement |                                                                       |
|--------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|-----------------------------------------------------------------------|
| Purpose      | This statement is used to share the value of Network Variables between drives on an Ethernet network. Network Variables are variables N0 through N31. The variables to be sent out, or synchronized with, are called out in the “SEND” statement. For example, “SEND [N5]” will take the current value of variable N5 and load it into the N5 variable of every drive on the network. The SENDTO statement only update network variables of the drives with the same group ID listed in the command. |           |                                                                       |
| Syntax       | SEND [ Na,Nb, Nx-Ny],                                                                                                                                                                                                                                                                                                                                                                                                                                                                                | a,b,x,y   | Any number from 0 to 31                                               |
|              | SENDTO GroupID [Na,Nb, Nx-Ny]                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | GroupID   | GroupID of the drives who’s variables will be affected (synchronized) |
| See Also     | Network variables                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |           |                                                                       |

**Example:**

```

...{statements}...
N1=12           ;Set N1 equal to 12
SEND [N1]       ;Set the N1 variable to 12 in every drive in the Network.
SEND [N5-N10]   ;Sets the N5 through N10 variable in all drives on the Network.
N20=25         ;Set N20 equal to 25
SENDTO 2 [N20]  ;Set the N20 variable to 25 only in drives with GroupID = 2.
...{statements}
END             ;End main program

```

| STOP MOTION |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |                                      |
|-------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------|
| [Quick]     | Stop Motion                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            | Statement                            |
| Purpose     | This statement is used to stop all motion. When the “STOP MOTION” statement is executed all motion profiles stored in the Motion Queue are cleared, and motion will immediately be stopped via the deceleration parameter set in the “DCEL” variable. If the “QUICK” modifier is used then the deceleration value will come from the “QDECEL” variable. The main use for this command is to control an emergency stops or when the End Of Travel sensor is detected. Note that the current position will not be lost after this statement is executed. |                                      |
| Syntax      | STOP MOTION                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            | Stops using DECEL deceleration rate  |
|             | STOP MOTION QUICK                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      | Stops using QDECEL deceleration rate |
| See Also    | MOTION SUSPEND                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |                                      |

**Example:**

```

...{statements}...
DECEL = 100
QDECEL = 10000
...{statements}
STOP MOTION QUICK

```

| <b>VELOCITY ON/OFF</b> | <b>Velocity Mode</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | <b>Statement</b> |
|------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------|
| <b>Purpose</b>         | The VELOCITY ON statement enables velocity mode in the drive. The VELOCITY OFF statement disables velocity mode and returns drive to its default mode. (Default mode is Positioning). The velocity value for this mode is set by setting the System Variable "VEL". All position related variables are valid in this mode.                                                                                                                                                                                                                                                                                                                                       |                  |
| <b>Syntax</b>          | VELOCITY ON<br>VELOCITY OFF                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |                  |
| <b>Remarks</b>         | <p>The "VELOCITY ON" statement is considered one of the motion related commands. It has to be implemented when the drive is enabled. If the "VELOCITY ON" statement is executed while the drive is disabled, fault # 27-"Drive disabled" will occur.</p> <p>Execution of any motion related profiles while the drive is in Velocity mode will be loaded into the Motion Queue. When the "VELOCITY OFF" statement is executed the drive defaults back to Position mode and immediately begins to execute the motion profiles stored in the Motion Queue. Please note that the "VEL" variable can be set on the fly, allowing dynamic control of the velocity.</p> |                  |

#### See Also

#### Example:

```

VEL=0           ;Set velocity to 0
VELOCITY ON     ;Turn on Velocity Mode
VEL = 10        ;Set velocity
...{statements}
VELOCITY OFF    ;Turn off Velocity Mode

```

| <b>WAIT</b>     | <b>Wait</b>                                                                                                                                                                     | <b>Statement</b>                                 |
|-----------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------|
| <b>Purpose</b>  | This statement suspend the execution of the program until some condition(s) is(are) met. Conditions include Expressions TRUE or FALSE, Preset TIME expiration, MOTION COMPLETE. |                                                  |
| <b>Syntax</b>   | WAIT UNTIL <expression>                                                                                                                                                         | wait until expression becomes TRUE               |
|                 | WAIT WHILE <expression>                                                                                                                                                         | wait while expression is TRUE                    |
|                 | WAIT TIME <time delay>                                                                                                                                                          | wait until <time delay> in mS is ;expired        |
|                 | WAIT MOTION COMPLETE                                                                                                                                                            | wait until last motion in Motion Queue completes |
| <b>Remarks</b>  |                                                                                                                                                                                 |                                                  |
| <b>See Also</b> | DSTATUS System Variable, User Variables and Flags section                                                                                                                       |                                                  |

#### Example:

```

WAIT UNTIL (APOS>2 && APOS<3) ;Wait until Apos is > 2 and <3
WAIT WHILE (APOS <2 && APOS>1) ;Wait while Apos is <2 and >1
WAIT TIME 1000                 ;Wait 1 Sec (1 Sec=1000mS)
MDV 20, 20                     ;Start MDV moves
MDV 20,0                       ;Start MDV moves
WAIT MOTION COMPLETE           ;Waits until motion is done

```

| <b>WHILE/ENDWHILE</b> | <b>While</b>                                                                                                                        | <b>Statement</b> |
|-----------------------|-------------------------------------------------------------------------------------------------------------------------------------|------------------|
| <b>Purpose</b>        | The WHILE <expression> executes statement(s) between keywords WHILE and ENDWHILE repeatedly while the expression evaluates to TRUE. |                  |
| <b>Syntax</b>         | WHILE <expression><br>{statement(s)}...<br>ENDWHILE                                                                                 |                  |
| <b>Remarks</b>        | WHILE block of statements has to end with ENDWHILE keyword.                                                                         |                  |
| <b>See Also</b>       | DO/UNTIL                                                                                                                            |                  |

#### Example:

```

WHILE APOS<3 ;Execute the statements until Apos is <3
{statement(s)}..
ENDWHILE

```

## Appendix A. Complete list of variables.

A complete list of 940 accessible variables is given in the table below. These variables can be accessed from the User's Program or any supported interface protocol like RPC over Ethernet, PPP over RS232 or MODBUS-RTU over RS485 port.

Any variable can be accessed by its name from the user's program or by Index value using syntax:

@<VARINDEX> , where <VARINDEX> variable index from the table.

Any interface variable can be accessed by its index value.

The column "**Format**" gives native format of the variable:

W: 32 bit integer

F: float (real)

When setting a variable via an external device the value can be addressed as floating or integer. The value will automatically adjusted to fit it's given form.

The column "**EPM**" shows if a variable has a non-volatile storage space in the EPM memory. The User's Program uses a RAM (volatile) copy of the variables stored on the EPM. The EMP's values are not affected by changing the variables in the User's program. Interface functions however could change both volatile and non-volatile copy of the variable. If the host interface request a change to the EPM (non-volatile) value, this change is done both in the User Programs RAM memory as well as in the EPM. When the User's program reads a variable it always reads from the RAM (volatile) copy of the variable. Interface functions have choice of reading from the RAM (volatile) or from the EPM (non-volatile) copy of the variable. At power up all RAM copies of the variables are initialized with the EPM values.

The column "**Access**" shows if a variable is R-read only, W-write only, or R/W - read/write. Writing to a R-only variable or reading from a W-only variable won't work

The column "Units" shows units of the variable. Units unique to this manual that are used for motion are:

UU - user units

EC - encoder counts

S - seconds

PPS - pulses per sample. Sample time is 255us - servo loop rate

PPSS - pulses per sample per sample. Sample time is 255us - servo loop rate

| Index | Name                   | Format | EPM | Access | Description                                        | Units |
|-------|------------------------|--------|-----|--------|----------------------------------------------------|-------|
| 1     | VAR_IDSTRING           |        | N   | R      | Drive's identification string                      |       |
| 2     | VAR_NAME               |        | Y   | R/W    | Drive's symbolic name                              |       |
| 10    | VAR_M_ID               |        | Y   | R      | Motor ID                                           |       |
| 11    | VAR_M_MODEL            |        | Y   | R      | Motor model                                        |       |
| 12    | VAR_M_VENDOR           |        | Y   | R      | Motor vendor                                       |       |
| 13    | VAR_M_ESET             |        | Y   | R      | Reserved                                           |       |
| 14    | VAR_M_HALLCODE         |        | Y   | R      | Hallcode index                                     |       |
| 15    | VAR_M_HOFFSET          |        | Y   | R      | Reserved                                           |       |
| 16    | VAR_M_ZOFFSET          |        | Y   | R      | Reserved                                           |       |
| 17    | VAR_M_ICTRL            |        | Y   | R      | Reserved                                           |       |
| 18    | VAR_M_JM               |        | Y   | R      | Motor Jm                                           |       |
| 19    | VAR_M_KE               |        | Y   | R      | Motor Ke                                           |       |
| 20    | VAR_M_KT               |        | Y   | R      | Motor Kt                                           |       |
| 21    | VAR_M_LS               |        | Y   | R      | Motor Ls                                           |       |
| 22    | VAR_M_RS               |        | Y   | R      | Motor Rs                                           |       |
| 23    | VAR_M_MAXCURRENT       |        | Y   | R      | Motor's max current(RMS)                           |       |
| 24    | VAR_M_MAXVELOCITY      |        | Y   | R      | Motor's max velocity                               |       |
| 25    | VAR_M_NPOLES           |        | Y   | R      | Motor's poles number                               |       |
| 26    | VAR_M_ENCODER          |        | Y   | R      | Encoder resolution                                 |       |
| 27    | VAR_M_TERMVOLTAGE      |        | Y   | R      | Nominal Motor's terminal voltage                   |       |
| 28    | VAR_M_FEEDBACK         |        | Y   | R      | Feedback type                                      |       |
| 29    | VAR_ENABLE_SWITCH_TYPE | W      | Y   | R/W    | Enable switch function<br>0-inhibit only<br>1- Run | Bit   |
| 30    | VAR_CURRENTLIMIT       | F      | Y   | R/W    | Current limit                                      | [A]mp |

| Index | Name                    | Format | EPM | Access | Description                                                                                                                                                   | Units |
|-------|-------------------------|--------|-----|--------|---------------------------------------------------------------------------------------------------------------------------------------------------------------|-------|
| 31    | VAR_PEAKCURRENTLIMIT16  | F      | Y   | R/W    | Peak current limit for 16kHz operation                                                                                                                        | [A]mp |
| 32    | VAR_PEAKCURRENTLIMIT    | F      | Y   | R/W    | Peak current limit for 8kHz operation                                                                                                                         | [A]mp |
| 33    | VAR_PWMFREQUENCY        | W      | Y   | R/W    | PWM frequency selection                                                                                                                                       |       |
| 34    | VAR_DRIVEMODE           | W      | Y   | R/W    | Drive mode selection<br>0-torque<br>1-velocity<br>2-position                                                                                                  |       |
| 35    | VAR_CURRENT_SCALE       | F      | Y   | R/W    | Analog input #1 current reference scale in A/V                                                                                                                | A/V   |
| 36    | VAR_VELOCITY_SCALE      | F      | Y   | R/W    | Analog input #1 velocity reference scale in RPM/V                                                                                                             | RPM/V |
| 37    | VAR_REFERENCE           | W      | Y   | R/W    | Reference selection:<br>1 - internal source<br>0 - external                                                                                                   |       |
| 38    | VAR_STEPINPUTTYPE       | W      | Y   | R/W    | Selects how position reference inputs operating:<br>1 - Quadrature inputs (A/B)<br>0 - Step & Direction type                                                  |       |
| 39    | VAR_MOTORTHERMALPROTECT | W      | Y   | R/W    | Motor thermal protection function:<br>0 - disabled<br>1 - enabled                                                                                             |       |
| 40    | VAR_MOTORPTCRESISTANCE  | F      | Y   | R/W    | Motor thermal protection PTC cut-off resistance in Ohms                                                                                                       | [Ohm] |
| 41    | VAR_SECONDENCODER       | W      | Y   | R/W    | Second encoder:<br>0 - Disabled<br>1 - Enabled                                                                                                                |       |
| 42    | VAR_REGENDUTY           | W      | Y   | R/W    | Regen circuit PWM duty cycle in %<br>Range: 0-100%                                                                                                            | %     |
| 43    | VAR_ENCODERREPEATSRC    | W      | Y   | R/W    | Selects source for repeat buffers:<br>0 - Encoder connected to P4 terminal<br>1 - Feedback module<br>(if available on particular module)                      |       |
| 44    | VAR_VP_GAIN             | W      | Y   | R/W    | Velocity loop Proportional gain<br>Range: 0 - 32767                                                                                                           |       |
| 45    | VAR_VI_GAIN             | W      | Y   | R/W    | Velocity loop Integral gain<br>Range: 0 - 16383                                                                                                               |       |
| 46    | VAR_PP_GAIN             | W      | Y   | R/W    | Position loop Proportional gain<br>Range: 0 - 32767                                                                                                           |       |
| 47    | VAR_PI_GAIN             | W      | Y   | R/W    | Position loop Integral gain<br>Range: 0 - 16383                                                                                                               |       |
| 48    | VAR_PD_GAIN             | W      | Y   | R/W    | Position loop Differential gain<br>Range: 0 - 32767                                                                                                           |       |
| 49    | VAR_PI_LIMIT            | W      | Y   | R/W    | Position loop integral gain limit<br>Range: 0 - 20000                                                                                                         |       |
| 51    | VAR_VREG_WINDOW         | W      | Y   | R/W    | Gains scaling coefficient<br>Range: -5 - +4                                                                                                                   |       |
| 52    | VAR_ENABLE              | W      | N   | W      | Software Enable/Disable<br>0 - disable<br>1 - enable                                                                                                          |       |
| 53    | VAR_RESET               | W      | N   | W      | Drive's reset (cold boot)<br>0 - no action<br>1 - reset drive                                                                                                 |       |
| 54    | VAR_STATUS              | W      | N   | R      | Drive's status register                                                                                                                                       |       |
| 55    | VAR_BCF_SIZE            | W      | Y   | R      | User's program Byte-code size                                                                                                                                 | Bytes |
| 56    | VAR_AUTOBOOT            | W      | Y   | R/W    | User's program autostart flag.<br>0 - program has to be started manually<br>(MotionView or interface)<br>1 - program started automatically after drive booted |       |

| Index | Name                   | Format | EPM | Access | Description                                                                                                                                                                                                                      | Units   |
|-------|------------------------|--------|-----|--------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|
| 57    | VAR_GROUPID            | W      | Y   | R/W    | Network group ID<br>Range: 1 - 32767                                                                                                                                                                                             |         |
| 58    | VAR_VLIMIT_ZEROSPEED   | F      | Y   | R/W    | Zero Speed value<br>Range: 0 - 100                                                                                                                                                                                               | Rpm     |
| 59    | VAR_VLIMIT_SPEEDWND    | F      | Y   | R/W    | Speed window<br>Range: 10 - 10000                                                                                                                                                                                                | Rpm     |
| 60    | VAR_VLIMIT_ATSPEED     | F      | Y   | R/W    | Target speed for velocity window<br>Range: -10000 - +10000                                                                                                                                                                       | Rpm     |
| 61    | VAR_PLIMIT_POSEERROR   | W      | Y   | R/W    | Position error<br>Range: 1 - 32767                                                                                                                                                                                               | EC      |
| 62    | VAR_PLIMIT_ERRORTIME   | F      | Y   | R/W    | Position error time (time which position error has to remain to set-off position error fault)<br>Range: 0.25 - 8000                                                                                                              | mS      |
| 63    | VAR_PLIMIT_SEPOSEERROR | W      | Y   | R/W    | Second encoder Position error<br>Range: 1 - 32767                                                                                                                                                                                | EC      |
| 64    | VAR_PLIMIT_SEERRORTIME | F      | Y   | R/W    | Second encoder Position error time (time which position error has to remain to set-off position error fault)<br>Range: 0.25 - 8000                                                                                               | mS      |
| 65    | VAR_INPUTS             | W      | N   | R      | Digital inputs states. A1 occupies Bit 0, A2- Bit 1 ... C4 - bit 11.                                                                                                                                                             |         |
| 66    | VAR_OUTPUTS            | W      | N   | W      | Digital outputs states. Writing to this variables sets/resets digital outputs, except outputs which has been assigned special function.<br>Output 1 Bit0<br>Output 2 Bit 1<br>Output 3 Bit 2<br>Output 4 Bit 3<br>Output 5 Bit 4 |         |
| 67    | VAR_IP_ADDRESS         | W      | Y   | R/W    | Ethernet IP address. IP address changes at next boot up. 32 bit value                                                                                                                                                            |         |
| 68    | VAR_IP_MASK            | W      | Y   | R/W    | Ethernet IP NetMask. Mask changes at next boot up. 32 bit value                                                                                                                                                                  |         |
| 69    | VAR_IP_GATEWAY         | W      | Y   | R/W    | Ethernet Gateway IP address. Address changes at next boot up. 32 bit value                                                                                                                                                       |         |
| 70    | VAR_IP_DHCP            | W      | Y   | R/W    | Use DHCP<br>0-manual<br>1- use DHCP service                                                                                                                                                                                      |         |
| 71    | VAR_AIN1               | F      | N   | R      | Analog Input AIN1 current value                                                                                                                                                                                                  | [V]olt  |
| 72    | VAR_AIN2               | F      | N   | R      | Analog Input AIN2 current value                                                                                                                                                                                                  | [V]olt  |
| 73    | VAR_BUSVOLTAGE         | F      | N   | R      | Bus voltage                                                                                                                                                                                                                      | [V]olt  |
| 74    | VAR_HTEMP              | F      | N   | R      | Heatsink temperature<br>Returns: 0 - for temperatures < 40C and actual heat sink temperature for temperatures >40 C                                                                                                              | [c]     |
| 75    | VAR_ENABLE_ACCELDECCEL |        | Y   | R/W    | Enable Accel/Decel function for velocity mode<br>0 - disable<br>1 - enable                                                                                                                                                       |         |
| 76    | VAR_ACCEL_LIMIT        | F      | Y   | R/W    | Accel value for velocity mode<br>Range: 0.1 - 5000000                                                                                                                                                                            | Rpm*Sec |
| 77    | VAR_DECEL_LIMIT        | F      | Y   | R/W    | Decel value for velocity mode<br>Range: 0.1 - 5000000                                                                                                                                                                            | Rpm*Sec |
| 78    | VAR_FAULT_RESET        | W      | Y   | R/W    | Reset fault configuration:<br>1 - on deactivation of Enable/Inhibit input (A3)<br>0 - on activation of Enable/Inhibit input (A3)                                                                                                 |         |
| 79    | VAR_M2SRATIO_MASTER    | W      | Y   | R/W    | Master to system ratio.<br>Master counts range: -32767 - +32767                                                                                                                                                                  | EC      |
| 80    | VAR_M2SRATIO_SYSTEM    | W      | Y   | R/W    | Master to system ratio.<br>System counts range: 1 - 32767                                                                                                                                                                        | EC      |

| Index | Name                | Format | EPM | Access | Description                                                                                                                                                                                                                                         | Units  |
|-------|---------------------|--------|-----|--------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------|
| 81    | VAR_S2PRATIO_SECOND | W      | Y   | R/W    | Secondary encoder to prime encoder ratio.<br>Second counts range: -32767 - +32767                                                                                                                                                                   |        |
| 82    | VAR_S2PRATIO_PRIME  | W      | Y   | R/W    | Secondary encoder to prime encoder ratio.<br>Prime counts range: 1 - 32767                                                                                                                                                                          |        |
| 83    | VAR_EXSTATUS        | W      | N   | R      | Extended status. Lower word copy of DSP status flags.                                                                                                                                                                                               |        |
| 84    | VAR_HLS_MODE        | W      | Y   | R/W    | Hardware limit switches.<br>0 - not used<br>1 - stop and fault<br>2 - fault                                                                                                                                                                         |        |
| 85    | VAR_AOUT_FUNCTION   | W      | Y   | R/W    | Analog output function range: 0 - 8<br>0 - Not assigned<br>1 - Phase Current (RMS)<br>2 - Phase Current (Peak Value)<br>3 - Motor Velocity<br>4 - Phase Current R<br>5 - Phase Current S<br>6 - Phase Current T<br>7 - Iq current<br>8 - Id current |        |
| 86    | VAR_AOUT_VELSCALE   | F      | Y   | R/W    | Analog output scale for velocity quantities.<br>Range: 0.1 - 5                                                                                                                                                                                      | mV/Rpm |
| 87    | VAR_AOUT_CURSCALE   | F      | Y   | R/W    | Analog output scale for current related quantities. Range: 0.1 - 10                                                                                                                                                                                 | V/A    |
| 88    | VAR_AOUT            | F      | N   | W      | Analog output value.(Used if VAR #84 is set to 0 - no function) Range: 0 - 10                                                                                                                                                                       | V      |
| 89    | VAR_AIN1_DEADBAND   | F      | Y   | R/W    | Analog input #1 dead-band. Applied when used as current or velocity reference.<br>Range: 0 - 50                                                                                                                                                     | mV     |
| 90    | VAR_AIN1_OFFSET     |        | Y   | R/W    | Analog input #1 offset. Applied when used as current/velocity reference<br>Range: -1000 - +1000                                                                                                                                                     | mV     |
| 91    | VAR_SUSPEND_MOTION  | W      | N   | R/W    | Suspend motion. Suspends motion produced by trajectory generator. Current move will be completed before motion is suspended.<br>0 - motion enabled<br>1 - motion disabled                                                                           |        |
| 92    | VAR_MOVEP           | W      | N   | W      | Target position for absolute move. Writing value executes Move to position as per MOVEP statement using current values of acceleration, deceleration and max velocity.                                                                              |        |
| 93    | VAR_MOVED           | W      | N   | W      | Incremental position. Writing value <>0 executes Incremental move as per MOVED statement using current values of acceleration, deceleration and max velocity.                                                                                       |        |
| 94    | VAR_MDV_DISTANCE    | F      | N   | W      | Distance for MDV move                                                                                                                                                                                                                               | UU     |
| 95    | VAR_MDV_VELOCITY    | F      | N   | W      | Velocity for MDV move. Writing to this variable executes MDV move with Distance value last written to variable #94                                                                                                                                  | UU     |
| 96    | VAR_MOVE_PWI1       | W      | N   | W      | Writing value executes Move in positive direction while input true (active). Value specifies input #                                                                                                                                                |        |
| 97    | VAR_MOVE_PWI0       | W      | N   | W      | Writing value executes Move in positive direction while input false (not active). Value specifies input #                                                                                                                                           |        |
| 98    | VAR_MOVE_NWI1       | F      | N   | W      | Writing value executes Move negative direction while input true (active). Value specifies input #                                                                                                                                                   |        |
| 99    | VAR_MOVE_NWI0       | F      | N   | W      | Writing value executes Move negative direction while input false (not active). Value specifies input #                                                                                                                                              |        |

| Index | Name    | Format | EPM | Access | Description                                            | Units |
|-------|---------|--------|-----|--------|--------------------------------------------------------|-------|
| 100   | VAR_V0  | F      | N   | R/W    | User variable<br>General purpose user defined variable |       |
| 101   | VAR_V1  | F      | N   | R/W    | User variable<br>General purpose user defined variable |       |
| 102   | VAR_V2  | F      | N   | R/W    | User variable<br>General purpose user defined variable |       |
| 103   | VAR_V3  | F      | N   | R/W    | User variable<br>General purpose user defined variable |       |
| 104   | VAR_V4  | F      | N   | R/W    | User variable<br>General purpose user defined variable |       |
| 105   | VAR_V5  | F      | N   | R/W    | User variable<br>General purpose user defined variable |       |
| 106   | VAR_V6  | F      | N   | R/W    | User variable<br>General purpose user defined variable |       |
| 107   | VAR_V7  | F      | N   | R/W    | User variable<br>General purpose user defined variable |       |
| 108   | VAR_V8  | F      | N   | R/W    | User variable<br>General purpose user defined variable |       |
|       |         |        |     |        |                                                        |       |
| 109   | VAR_V9  | F      | N   | R/W    | User variable<br>General purpose user defined variable |       |
| 110   | VAR_V10 | F      | N   | R/W    | User variable<br>General purpose user defined variable |       |
| 111   | VAR_V11 | F      | N   | R/W    | User variable<br>General purpose user defined variable |       |
| 112   | VAR_V12 | F      | N   | R/W    | User variable<br>General purpose user defined variable |       |
| 113   | VAR_V13 | F      | N   | R/W    | User variable<br>General purpose user defined variable |       |
| 114   | VAR_V14 | F      | N   | R/W    | User variable<br>General purpose user defined variable |       |
| 115   | VAR_V15 | F      | N   | R/W    | User variable<br>General purpose user defined variable |       |
| 116   | VAR_V16 | F      | N   | R/W    | User variable<br>General purpose user defined variable |       |
| 117   | VAR_V17 | F      | N   | R/W    | User variable<br>General purpose user defined variable |       |
| 118   | VAR_V18 | F      | N   | R/W    | User variable<br>General purpose user defined variable |       |
| 119   | VAR_V19 | F      | N   | R/W    | User variable<br>General purpose user defined variable |       |
| 120   | VAR_V20 | F      | N   | R/W    | User variable<br>General purpose user defined variable |       |
| 121   | VAR_V21 | F      | N   | R/W    | User variable<br>General purpose user defined variable |       |
| 122   | VAR_V22 | F      | N   | R/W    | User variable<br>General purpose user defined variable |       |
| 123   | VAR_V23 | F      | N   | R/W    | User variable<br>General purpose user defined variable |       |
| 124   | VAR_V24 | F      | N   | R/W    | User variable<br>General purpose user defined variable |       |
| 125   | VAR_V25 | F      | N   | R/W    | User variable<br>General purpose user defined variable |       |
| 126   | VAR_V26 | F      | N   | R/W    | User variable<br>General purpose user defined variable |       |
| 127   | VAR_V27 | F      | N   | R/W    | User variable<br>General purpose user defined variable |       |



| Index | Name                    | Format | EPM | Access | Description                                                                                                  | Units       |
|-------|-------------------------|--------|-----|--------|--------------------------------------------------------------------------------------------------------------|-------------|
| 128   | VAR_V28                 | F      | N   | R/W    | User variable<br>General purpose user defined variable                                                       |             |
| 129   | VAR_V29                 | F      | N   | R/W    | User variable<br>General purpose user defined variable                                                       |             |
| 130   | VAR_V30                 | F      | N   | R/W    | User variable<br>General purpose user defined variable                                                       |             |
| 131   | VAR_V31                 | F      | N   | R/W    | User variable<br>General purpose user defined variable                                                       |             |
| 132   | VAR_MOVEDR_DISTANCE     | F      | N   |        | Registered move distance. Incremental motion as per MOVEDR statement                                         | UU          |
| 133   | VAR_MOVEDR_DISPLACEMENT | F      | N   |        | Registered move displacement<br>Writing to this variable executes the move MOVEDR using value set by #132    | UU          |
| 134   | VAR_MOVEPR_DISTANCE     |        | N   | W      | Registered move distance. Absolute motion as per MOVEPR statement                                            | UU          |
| 135   | VAR_MOVEPR_DISPLACEMENT | F      | N   | W      | Registered move displacement<br>Writing to this variable makes the move MOVEPR using value set by #134       | UU          |
| 136   | VAR_STOP_MOTION         | W      | N   | W      | Stops motion:<br>1 - stops motion<br>0 - no action                                                           |             |
| 137   | VAR_START_PROGRAM       | W      | N   | W      | Starts user program<br>1 - starts program<br>0 - no action                                                   |             |
| 138   | VAR_VEL_MODE_ON         | W      | N   | W      | Turns on "profile" velocity. (Acts as statement VELOCITY ON)<br>0 - normal operation<br>1 - velocity mode on |             |
| 139   | VAR_IREF                | F      | N   | R/W    | Internal reference for Current or Velocity mode.<br>In Velocity mode:<br>In Current mode                     | RPS<br>Amps |
| 140   | VAR_NV0                 | F      | N   | R/W    | User defined Network variable.<br>Variable can be shared across Ethernet network.                            |             |
| 141   | VAR_NV1                 | F      | N   | R/W    | User defined Network variable.<br>Variable can be shared across Ethernet network.                            |             |
| 142   | VAR_NV2                 | F      | N   | R/W    | User defined Network variable.<br>Variable can be shared across Ethernet network.                            |             |
| 143   | VAR_NV3                 | F      | N   | R/W    | User defined Network variable.<br>Variable can be shared across Ethernet network.                            |             |
| 144   | VAR_NV4                 | F      | N   | R/W    | User defined Network variable.<br>Variable can be shared across Ethernet network.                            |             |
| 145   | VAR_NV5                 | F      | N   | R/W    | User defined Network variable.<br>Variable can be shared across Ethernet network.                            |             |
| 146   | VAR_NV6                 | F      | N   | R/W    | User defined Network variable.<br>Variable can be shared across Ethernet network.                            |             |
| 147   | VAR_NV7                 | F      | N   | R/W    | User defined Network variable.<br>Variable can be shared across Ethernet network.                            |             |
| 148   | VAR_NV8                 | F      | N   | R/W    | User defined Network variable.<br>Variable can be shared across Ethernet network.                            |             |
| 149   | VAR_NV9                 | F      | N   | R/W    | User defined Network variable.<br>Variable can be shared across Ethernet network.                            |             |
| 150   | VAR_NV10                | F      | N   | R/W    | User defined Network variable.<br>Variable can be shared across Ethernet network.                            |             |
| 151   | VAR_NV11                | F      | N   | R/W    | User defined Network variable.<br>Variable can be shared across Ethernet network.                            |             |
| 152   | VAR_NV12                | F      | N   | R/W    | User defined Network variable.<br>Variable can be shared across Ethernet network.                            |             |



| Index | Name                | Format | EPM | Access | Description                                                                                                           | Units |
|-------|---------------------|--------|-----|--------|-----------------------------------------------------------------------------------------------------------------------|-------|
| 153   | VAR_NV13            | F      | N   | R/W    | User defined Network variable.<br>Variable can be shared across Ethernet network.                                     |       |
| 154   | VAR_NV14            | F      | N   | R/W    | User defined Network variable.<br>Variable can be shared across Ethernet network.                                     |       |
| 155   | VAR_NV15            | F      | N   | R/W    | User defined Network variable.<br>Variable can be shared across Ethernet network.                                     |       |
| 156   | VAR_NV16            | F      | N   | R/W    | User defined Network variable.<br>Variable can be shared across Ethernet network.                                     |       |
| 157   | VAR_NV17            | F      | N   | R/W    | User defined Network variable.<br>Variable can be shared across Ethernet network.                                     |       |
| 158   | VAR_NV18            | F      | N   | R/W    | User defined Network variable.<br>Variable can be shared across Ethernet network.                                     |       |
| 159   | VAR_NV19            | F      | N   | R/W    | User defined Network variable.<br>Variable can be shared across Ethernet network.                                     |       |
| 160   | VAR_NV20            | F      | N   | R/W    | User defined Network variable.<br>Variable can be shared across Ethernet network.                                     |       |
| 161   | VAR_NV21            | F      | N   | R/W    | User defined Network variable.<br>Variable can be shared across Ethernet network.                                     |       |
| 162   | VAR_NV22            | F      | N   | R/W    | User defined Network variable.<br>Variable can be shared across Ethernet network.                                     |       |
| 163   | VAR_NV23            | F      | N   | R/W    | User defined Network variable.<br>Variable can be shared across Ethernet network.                                     |       |
| 164   | VAR_NV24            | F      | N   | R/W    | User defined Network variable.<br>Variable can be shared across Ethernet network.                                     |       |
| 165   | VAR_NV25            | F      | N   | R/W    | User defined Network variable.<br>Variable can be shared across Ethernet network.                                     |       |
| 166   | VAR_NV26            | F      | N   | R/W    | User defined Network variable.<br>Variable can be shared across Ethernet network.                                     |       |
| 167   | VAR_NV27            | F      | N   | R/W    | User defined Network variable.<br>Variable can be shared across Ethernet network.                                     |       |
| 168   | VAR_NV28            | F      | N   | R/W    | User defined Network variable.<br>Variable can be shared across Ethernet network.                                     |       |
| 169   | VAR_NV29            | F      | N   | R/W    | User defined Network variable.<br>Variable can be shared across Ethernet network.                                     |       |
| 170   | VAR_NV30            | F      | N   | R/W    | User defined Network variable.<br>Variable can be shared across Ethernet network.                                     |       |
| 171   | VAR_NV31            | F      | N   | R/W    | User defined Network variable.<br>Variable can be shared across Ethernet network.                                     |       |
| 172   | VAR_SERIAL_ADDRESS  | W      | Y   | R/W    | RS485 drive ID. Range: 0 - 31                                                                                         |       |
| 173   | VAR_MODBUS_BAUDRATE | W      | Y   | R/W    | Baud rate index for ModBus operations:<br>1 - 4800<br>2 - 9600<br>3 - 19200<br>4 - 38400<br>5 - 57600<br>6 - 115200   |       |
| 174   | VAR_MODBUS_DELAY    | W      | Y   | R/W    | ModBus reply delay in mS<br>Range: 0 - 1000                                                                           | mS    |
| 139   | VAR_RS485_CONFIG    | W      | Y   | R/W    | Rs485 configuration:<br>0 - normal IP over PPP<br>1 - ModBus                                                          |       |
| 176   | VAR_PPP_BAUDRATE    | W      | Y   | R/W    | RS232/485 (normal mode) baud rate index.<br>1 - 4800<br>2 - 9600<br>3 - 19200<br>4 - 38400<br>5 - 57600<br>6 - 115200 |       |

| Index | Name                   | Format | EPM | Access | Description                                                                                                                                                                                                                                                      | Units             |
|-------|------------------------|--------|-----|--------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------|
| 177   | VAR_MOVEPS             | F      | N   | W      | Same as variable #92 but using S-curve acceleration/deceleration                                                                                                                                                                                                 |                   |
| 178   | VAR_MOVEDS             | F      | N   | W      | Same as variable #93 but using S-curve acceleration/deceleration                                                                                                                                                                                                 |                   |
| 179   | VAR_MDVS_VELOCITY      |        | N   | W      | Velocity value for MDV move. Writing to this variable puts MDV segment to motion stack subsequently causing motion to be executed (unless motion is suspended by #91). Distance is taken from #94 variable which must be written prior writing to this variable. | UU                |
| 180   | VAR_MAXVEL             | F      | N   | R/W    | Max velocity for motion profile                                                                                                                                                                                                                                  | UU/S              |
| 181   | VAR_ACCEL              | F      | N   | R/W    | Accel value for indexing                                                                                                                                                                                                                                         | UU/S <sup>2</sup> |
| 182   | VAR_DECEL              | F      | N   | R/W    | Decel value for indexing                                                                                                                                                                                                                                         | UU/S <sup>2</sup> |
| 183   | VAR_QDECEL             | F      | N   | R/W    | Quick decel value                                                                                                                                                                                                                                                | UU/S <sup>2</sup> |
| 184   | VAR_INPOSLIM           | W      | N   | R/W    | "In position" limit                                                                                                                                                                                                                                              | UU                |
| 185   | VAR_VEL                | F      | N   | R/W    | Velocity reference for "Profiled" velocity                                                                                                                                                                                                                       | UU/S              |
| 186   | VAR_UNITS              | F      | Y   | R/W    | User units                                                                                                                                                                                                                                                       |                   |
| 187   | VAR_MECounter          | W      | N   | R/W    | A/B inputs reference counter value                                                                                                                                                                                                                               | Count             |
| 188   | VAR_PHCUR              | F      | N   | R      | Phase current                                                                                                                                                                                                                                                    | A                 |
| 189   | VAR_POS_PULSES         | W      | N   | R/W    | Target position in encoder pulses                                                                                                                                                                                                                                | EC                |
| 190   | VAR_APOS_PULSES        | W      | N   | R/W    | Actual position in encoder pulses                                                                                                                                                                                                                                | EC                |
| 191   | VAR_POSErrOR_PULSES    | W      | N   | R      | Position error in encoder pulses                                                                                                                                                                                                                                 | EC                |
| 192   | VAR_CURRENT_VEL_PPS    | F      | N   | R      | Current velocity in PPS (pulses per sample)                                                                                                                                                                                                                      | PPS               |
| 193   | VAR_CURRENT_ACCEL_PPSS | F      | N   | R      | Current acceleration (demanded value) value                                                                                                                                                                                                                      | PPSS              |
| 194   | VAR_IN0_DEBOUNCE       | W      | Y   | R/W    | Input de-bounce time in mS<br>Range: 0 - 1000                                                                                                                                                                                                                    | mS                |
| 195   | VAR_IN1_DEBOUNCE       | W      | Y   | R/W    | Input de-bounce time in mS<br>Range: 0 - 1000                                                                                                                                                                                                                    | mS                |
| 196   | VAR_IN2_DEBOUNCE       | W      | Y   | R/W    | Input de-bounce time in mS<br>Range: 0 - 1000                                                                                                                                                                                                                    | mS                |
| 197   | VAR_IN3_DEBOUNCE       | W      | Y   | R/W    | Input de-bounce time in mS<br>Range: 0 - 1000                                                                                                                                                                                                                    | mS                |
| 198   | VAR_IN4_DEBOUNCE       | W      | Y   | R/W    | Input de-bounce time in mS<br>Range: 0 - 1000                                                                                                                                                                                                                    | mS                |
| 199   | VAR_IN5_DEBOUNCE       | W      | Y   | R/W    | Input de-bounce time in mS<br>Range: 0 - 1000                                                                                                                                                                                                                    | mS                |
| 200   | VAR_IN6_DEBOUNCE       | W      | Y   | R/W    | Input de-bounce time in mS<br>Range: 0 - 1000                                                                                                                                                                                                                    | mS                |
| 201   | VAR_IN7_DEBOUNCE       | W      | Y   | R/W    | Input de-bounce time in mS<br>Range: 0 - 1000                                                                                                                                                                                                                    | mS                |
| 202   | VAR_IN8_DEBOUNCE       | W      | Y   | R/W    | Input de-bounce time in mS<br>Range: 0 - 1000                                                                                                                                                                                                                    | mS                |
| 203   | VAR_IN9_DEBOUNCE       | W      | Y   | R/W    | Input de-bounce time in mS<br>Range: 0 - 1000                                                                                                                                                                                                                    | mS                |
| 204   | VAR_IN10_DEBOUNCE      | W      | Y   | R/W    | Input de-bounce time in mS<br>Range: 0 - 1000                                                                                                                                                                                                                    | mS                |
| 205   | VAR_IN11_DEBOUNCE      | W      | Y   | R/W    | Input de-bounce time in mS<br>Range: 0 - 1000                                                                                                                                                                                                                    | mS                |
| 206   | VAR_OUT0_FUNCTION      | W      | Y   | R/W    | Output function index                                                                                                                                                                                                                                            |                   |
| 207   | VAR_OUT1_FUNCTION      | W      | Y   | R/W    | Output function index                                                                                                                                                                                                                                            |                   |
| 208   | VAR_OUT2_FUNCTION      | W      | Y   | R/W    | Output function index                                                                                                                                                                                                                                            |                   |
| 209   | VAR_OUT3_FUNCTION      | W      | Y   | R/W    | Output function index                                                                                                                                                                                                                                            |                   |
| 210   | VAR_HALLCODE           | W      | N   | R      | Current hall code<br>Bit 0 - Hall 1<br>Bit 1 - Hall 2<br>Bit 2 - Hall 3                                                                                                                                                                                          |                   |
| 211   | VAR_ENCODER            | W      | N   | R      | Primary encoder current value                                                                                                                                                                                                                                    | EC                |

| Index | Name               | Format | EPM | Access | Description                                                                                                                                                                                                                                                        | Units             |
|-------|--------------------|--------|-----|--------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------|
| 212   | VAR_RPOS_PULSES    | W      | N   | R      | Registration position                                                                                                                                                                                                                                              | EC                |
| 213   | VAR_RPOS           | F      | N   | R      | Registration position                                                                                                                                                                                                                                              | UU                |
| 214   | VAR_POS            | F      | N   | R/W    | Target position                                                                                                                                                                                                                                                    | UU                |
| 215   | VAR_APOS           | F      | N   | R/W    | Actual position                                                                                                                                                                                                                                                    | UU                |
| 216   | VAR_POSEERROR      | W      | N   | R      | Position error                                                                                                                                                                                                                                                     | EC                |
| 217   | VAR_CURRENT_VEL    | F      | N   | R      | Current velocity (demanded value)                                                                                                                                                                                                                                  | UU/S              |
| 218   | VAR_CURRENT_ACCEL  | F      | N   | R      | Current acceleration (demanded value)                                                                                                                                                                                                                              | UU/S <sup>2</sup> |
| 219   | VAR_TPOS_ADVANCE   | W      | N   | W      | Target position advance. Every write to this variable adds value to the Target position summing point. Value gets added once per write. This variable useful when loop is driven by Master encoder signals and trying to correct phase. Value is in encoder counts | EC                |
| 220   | VAR_IOINDEX        | W      | N   | R/W    | Same as INDEX variable in user's program. See "INDEX" in Language Reference section Of this manual.                                                                                                                                                                |                   |
| 221   | VAR_PSLIMIT_PULSES | W      | Y   | R/W    | Positive Software limit switch value in Encoder counts                                                                                                                                                                                                             | EC                |
| 222   | VAR_NSLIMIT_PULSES | W      | Y   | R/W    | Negative Software limit switch value in Encoder counts                                                                                                                                                                                                             | EC                |
| 223   | VAR_SLS_MODE       | W      | Y   | R/W    | Soft limit switch action code:<br>0 - no action<br>1- Fault.<br>2- Stop and fault (When loop is driven by trajectory generator only. With all the other sources same action as 1) --                                                                               |                   |
| 224   | VAR_PSLIMIT        | F      | Y   | R/W    | Same as var 221 but value in User Units                                                                                                                                                                                                                            | UU                |
| 225   | VAR_NSLIMIT        | F      | Y   | R/W    | Same as var 222 but value in User Units                                                                                                                                                                                                                            | UU                |

**AC Technology Corporation**

member of the Lenze Group

630 Douglas Street

Uxbridge, MA 01569

Telephone: (508) 278-9100

Facsimile: (508) 278-7873