Panasonic®

PROGRAMMABLE CONTROLLER FP7 Positioning Unit User's Manual

Safety Precautions

Observe the following notices to ensure personal safety or to prevent accidents. To ensure that you use this product correctly, read this User's Manual thoroughly before use. Make sure that you fully understand the product and information on safety. This manual uses two safety flags to indicate different levels of danger.

WARNING

If critical situations that could lead to user's death or serious injury is assumed by mishandling of the product.

-Always take precautions to ensure the overall safety of your system, so that the whole system remains safe in the event of failure of this product or other external factor. -Do not use this product in areas with inflammable gas. It could lead to an explosion.

-Exposing this product to excessive heat or open flames could cause damage to the lithium battery or other electronic parts.

CAUTION

If critical situations that could lead to user's injury or only property damage is assumed by mishandling of the product.

-To prevent excessive exothermic heat or smoke generation, use this product at the values less than the maximum of the characteristics and performance that are assured in these specifications.

-Do not dismantle or remodel the product. It could cause excessive exothermic heat or smoke generation.

-Do not touch the terminal while turning on electricity. It could lead to an electric shock.

-Use the external devices to function the emergency stop and interlock circuit.

-Connect the wires or connectors securely.

The loose connection could cause excessive exothermic heat or smoke generation.

-Do not allow foreign matters such as liquid, flammable materials, metals to go into the inside of the product. It could cause excessive exothermic heat or smoke generation.

-Do not undertake construction (such as connection and disconnection) while the power supply is on. It could lead to an electric shock.

Copyright / Trademarks

-This manual and its contents are copyrighted.

-You may not copy this manual, in whole or part, without written consent of Panasonic Industrial Devices SUNX Co., Ltd.

-Windows is a registered trademark of Microsoft Corporation in the United States and other countries.

-All other company names and product names are trademarks or registered trademarks of their respective owners.

PLC_ORG

Introduction

Thank you for buying a Panasonic product. Before you use the product, please carefully read the installation instructions and the users manual, and understand their contents in detail to use the product properly.

Types of Manual

- There are different types of users manual for the FP7 series, as listed below. Please refer to a relevant manual for the unit and purpose of your use.
- The manuals can be downloaded on our website.

U	nit name or purpose of use	Manual name	Manual code
F	P7 Power Supply Unit	EP7 CPU Unit Lloore Manual (Hardware)	
F	P7 CPU Unit	FF7 CF0 Onit Osers Manual (Hardware)	
	Instructions for Built-in COM Port FP7 Extension (Communication) Cassette	FP7 CPU Unit Users Manual (COM Port Communication)	WUME- FP7COM
	Instructions for Built-in LAN Port	FP7 CPU Unit Users Manual (LAN Port Communication)	WUME-FP7LAN
F	P7 Digital Input/Output Unit	ital Input/Output Unit FP7 Digital Input/Output Unit Users Manual	
F	P7 Analog Input Unit	Input Unit FP7 Analog Input Unit Users Manual	
F	P7 Analog Output Unit	FP7 Analog Output Unit Users Manual	WUME-FP7AOH
F	P7 Positioning Unit	ositioning Unit FP7 Positioning Unit Users Manual	
Р	HLS System	System PHLS System Users Manual	
P F	rogramming Software PWIN GR7	FPWIN GR7 Introduction Guidance	WUME-FPWINGR7

Table of Contents

1.	Fun	ctions of Unit and Restrictions on Combinations 1-1
	1.1	Functions of Positioning Unit1-21.1.1Functions of Unit1-21.1.2Unit Type1-3
	1.2	Restrictions on Combinations of Units1-4
2.	Nan	nes and Functions of Parts 2-1
	2.1	Names and Functions of Parts2-2
	2.2	Operating Status LEDs2-3
3.	Wir	ing 3-1
	3.1	Connection over Wire-pressed Terminal Cable
		3.1.1 Specifications of Wire-pressed Terminal Cable
		3.1.2 Assembly of Connector for Wire-pressed Terminal Cable
	3.2	I/O Specifications and Terminal Wiring
		3.2.1 I/O Specifications
	3.3	Supply of Power to Drive Internal Circuit
		3.3.1 Line Driver Output
		3.3.2 Transistor Output
	3.4	Connecting Pulse Instruction Signal Input3-9
		3.4.1 Line Driver Output Type
		3.4.2 Transistor Output Type
	3.5	Connecting Deviation Counter Clear Output Signal

	3.6	Connecting Servo On Output Signal 3-11
	3.7	Connecting Home Input/Near Home Input Signal
	3.8	Connecting Pulse Input3-143.8.1Line Driver Type3.8.2Transistor Open Collector Type3.8.3Transistor Resistance Pull-up Type3-14
	3.9	Wiring Cautions
4.	Pow 4.1	ver On/Off and Check Items
	4.2	Before Turning On the Power
	4.3	Procedure for Turning On the Power4-54.3.1Procedure for Turning On the Power4-54.3.2Procedure for Turning Off the Power4-6
	4.4	Check with Power Turned On4-74.4.1Check Items After Turning Power On4-74.4.2Check on External Safety Circuit4-84.4.3Check on Safety Circuit with Positioning Unit4-84.4.4Operation Checks on Near Home Switch and Home Switch4-94.4.5Checking Rotating and Moving Directions and Moving Distance4-10
5.	Unit	Allocation and Parameter Settings5-1

5-2	Unit Allocation		5.1
5-2	I/O Map Registration	5.1.1	
5-3	Check on I/O Allocation Information	5.1.2	

0.Z	Axis A	Ilocation for Use	5-5
	5.2.1	Settings in Configurator PM7	5-5
5.3	Param	neter Settings	5-7
	5.3.1	Parameter Settings in Configurator PM7	5-7
	5.3.2	Parameter Setting Items	5-8
5.4	Synch	ronous Parameter/Cam Pattern Settings	5-10
	5.4.1	Synchronous Parameter Settings	5-10
	5.4.2	Cam Pattern Settings	5-11
5.5	Creatin	ng Positioning Data Table	5-12
	5.5.1	Construction of Positioning Data Table	5-12
	5.5.2	Table No. Positioning Start	5-13
	5.5.3	Operation Patterns and Tables	5-14
5.6	Saving	g Parameters	5-15
	5.6.1	Save/Load Configuration	5-15
	5.6.2	Export and Import	5-15
_	-		
Tra	nsfer	to Unit and Commissioning	6-1
Tra	nsfer t	to Unit and Commissioning	6-1
Tra	Check	to Unit and Commissioning	6-1
Tra 6.1	Check 6.1.1	to Unit and Commissioning	6-1 6-2 6-2
Tra 6.1	Ster 1 Check 6.1.1 6.1.2	to Unit and Commissioning on Setting Contents Check on Parameter Data Comparison of Parameter Information	6-1 6-2 6-2
Tra 6.1 6.2	Check 6.1.1 6.1.2 Transf	to Unit and Commissioning	6-1 6-2 6-2 6-4
Tra 6.1 6.2	Check 6.1.1 6.1.2 Transf 6.2.1	to Unit and Commissioning on Setting Contents Check on Parameter Data Comparison of Parameter Information fer of Parameters Writing Parameters to Unit	6-1 6-2 6-2 6-4 6-4
Tra 6.1 6.2 6.3	nsfer f Check 6.1.1 6.1.2 Transf 6.2.1 Monito	to Unit and Commissioning on Setting Contents Check on Parameter Data Comparison of Parameter Information fer of Parameters Writing Parameters to Unit Dring on Configurator PM7	6-1 6-2 6-2 6-4 6-4 6-5
Tra 6.1 6.2 6.3	nsfer f Check 6.1.1 6.1.2 Transf 6.2.1 Monito 6.3.1	to Unit and Commissioning	6-1 6-2 6-2 6-4 6-4 6-5 6-5
Tra 6.1 6.2 6.3	nsfer 1 Check 6.1.1 6.1.2 Transf 6.2.1 Monito 6.3.1 6.3.2	to Unit and Commissioning	6-1 6-2 6-2 6-4 6-4 6-5 6-5 6-5
Tra 6.1 6.2 6.3	nsfer 1 Check 6.1.1 6.1.2 Transf 6.2.1 Monito 6.3.1 6.3.2 Tool O	to Unit and Commissioning	6-1 6-2 6-2 6-4 6-4 6-5 6-5 6-5
Tra 6.1 6.2 6.3	nsfer 1 Check 6.1.1 6.1.2 Transf 6.2.1 Monito 6.3.1 6.3.2 Tool O 6.4.1	to Unit and Commissioning	6-1 6-2 6-2 6-2 6-5 6-5 6-5 6-7 6-7
Tra 6.1 6.2 6.3 6.4	nsfer 1 Check 6.1.1 6.1.2 Transf 6.2.1 Monito 6.3.1 6.3.2 Tool O 6.4.1 6.4.2	to Unit and Commissioning	6-1 6-2 6-2 6-4 6-4 6-5 6-5 6-5 6-7 6-7 6-9
Tra 6.1 6.2 6.3	nsfer 1 Check 6.1.1 6.1.2 Transf 6.2.1 Monito 6.3.1 6.3.2 Tool O 6.4.1 6.4.2 6.4.3	to Unit and Commissioning	6-1 6-2 6-2 6-4 6-4 6-5 6-5 6-5 6-7 6-7 6-9 6-11

6.

6.4.5 To	ool Operation - Teaching	6-15
----------	--------------------------	------

7. Automatic Operation (Positioning Control)......7-1

	7.1	Basic	Operation	7-2
		7.1.1	Positioning Control Patterns	7-2
		7.1.2	Setting and Operation of E-Point Control	7-4
		7.1.3	Setting and Operation of P-Point Control	7-5
		7.1.4	Setting and Operation of P-Point Control	7-6
		7.1.5	Setting and Operation of J-point Control	7-7
		7.1.6	Sample Program (E-Point, P-Point, and C-Point Control)	7-9
		7.1.7	Sample Program (J-point Control)	7-9
		7.1.8	Programming Precautions	7-10
	7.2	Interp	polation Control	7-11
		7.2.1	Types of Interpolation Control	7-11
		7.2.2	Setting and Operation of 2-Axis Linear Interpolation	7-14
		7.2.3	Setting and Operation of 2-Axis Circular Interpolation	7-16
		7.2.4	Setting and Operation of 3-Axis Linear Interpolation	7-19
		7.2.5	Setting and Operation of Three-Axis Linear Interpolation	7-21
		7.2.6	Sample Program (Interpolation Control)	7-23
	7.3	Settin	ng and Operation of Positioning Repeat Function	7-24
8.	Aut	omati	ic Operation (Synchronous Control)	8-1

8.1	Synch	ronous Control	8-2
	8.1.1	Outline of Synchronous Control	.8-2
8.2	Settin	gs for Master and Slave Axes	8-3
	8.2.1	Selection of Master Axis and Settings	.8-3
	8.2.2	Selection of Slave Axes and Settings	.8-4
	8.2.3	Enabling/Disabling Synchronous Control	. 8-5
8.3	Electr	onic Gear Function	8-7
	8.3.1	Outline of Electronic Gear Function	.8-7

		8.3.2	Types and Contents of Setting Parameters	8-8
		8.3.3	Gear Ratio Changes while in Operation	8-9
	8.4	Electr	onic Clutch Function	8-11
		8.4.1	Electronic Clutch Function	8-11
		8.4.2	Types and Contents of Setting Parameters	8-12
		8.4.3	Trigger Types for Electronic Clutch	8-13
		8.4.4	Engagement Methods of Electronic Clutch	8-14
	8.5	Electr	onic Cam Function	8-15
		8.5.1	Outline of Electronic Cam Function	8-15
		8.5.2	Types and Contents of Setting Parameters	8-16
		8.5.3	Cam Pattern Setting Method	8-17
9.	Man	ual C	Dperation (JOG Operation)	
	9.1	Settin	g and Operation of JOG Operation	9-2
	9.2	Chan	ging the Speed During JOG Operation	9-4
10.	Mar	nual (Operation (Home Return)	10-1
10.	Mar	nual (Operation (Home Return)	10-1
10.	Mar 10.1	n ual (Patter	Operation (Home Return)	10-1
10.	Mar 10.1 10.2	nual (Patter Settin	Operation (Home Return) rn of Home Return g and Operation of Home Return	10-1 10-2 10-5
10.	Mar 10.1 10.2	nual (Patter Settin	Operation (Home Return) rn of Home Return g and Operation of Home Return	10-1 10-2 10-5
10.	Mai 10.1 10.2 Mai	nual (Patter Settin	Operation (Home Return) rn of Home Return g and Operation of Home Return Operation (Pulser Operation)	10-1 10-2 10-5 11-1
10. 11.	Mar 10.1 10.2 Mar	Patter Settin	Operation (Home Return) rn of Home Return g and Operation of Home Return Operation (Pulser Operation)	10-1 10-2 10-5 11-1
10. 11.	Mar 10.1 10.2 Mar 11.1	nual (Patter Settin nual (Settin	Operation (Home Return) rn of Home Return. rg and Operation of Home Return. Operation (Pulser Operation) rg and Operation of Pulser Operation	10-1 10-2 10-5 11-1
10.	Mar 10.1 10.2 Mar 11.1	nual (Patter Settin nual (Settin	Operation (Home Return) rn of Home Return rg and Operation of Home Return Operation (Pulser Operation) rg and Operation of Pulser Operation	10-1
10. 11. 12.	Mai 10.1 10.2 Mai 11.1	nual (Patter Settin nual (Settin p fun	Operation (Home Return) rn of Home Return rg and Operation of Home Return Operation (Pulser Operation) rg and Operation of Pulser Operation rg and Operation of Pulser Operation	10-1
10. 11. 12.	Mar 10.1 10.2 Mar 11.1 Sto	nual (Patter Settin nual (Settin p fun	Operation (Home Return) rn of Home Return g and Operation of Home Return Operation (Pulser Operation) g and Operation of Pulser Operation ng and Operation of Pulser Operation	10-1
10. 11. 12.	Mai 10.1 10.2 Mai 11.1 Sto 12.1	nual (Patter Settin nual (Settin p fun Settin	Operation (Home Return) rn of Home Return g and Operation of Home Return Operation (Pulser Operation) g and Operation of Pulser Operation g and Operation of Pulser Operation g and Operation of Stop Functions	
10. 11. 12.	Mai 10.1 10.2 Mai 11.1 Sto 12.1 12.2	nual (Patter Settin nual (Settin p fun Settin Settin	Operation (Home Return) rn of Home Return g and Operation of Home Return Operation (Pulser Operation) g and Operation of Pulser Operation g and Operation of Pulser Operation g and Operation of Stop Functions gs and Operations of Stop Functions gs and Operations of Pause Functions	

13.	Sup	plementary Functions13-1
	13.1	Dwell Time
	13.2	Software Limit
	13.3	Auxiliary Output Code and Auxiliary Output Contact
	13.4	Current Value Update
	13.5	Coordinate Origin
	13.6	Pulse Input13-9
		13.6.1 Pulse Input Types13-9
		13.6.2 Monitoring Pulse Input Values
		13.6.3 Pulser Input Function
		13.6.4 Feedback Pulse Function
		13.6.5 High-speed Counter Function
	13.7	Startup speed 13-17
14.	Pro	gramming Cautions14-1
14.	Pro	gramming Cautions
14.	Pro	gramming Cautions
14.	Pro 9	gramming Cautions14-1Programming Cautions14-214.1.1 Turning Off Power Supply Clears Contents of Unit Memory14-214.1.2 Not Going to Other Operation from Current Operation14-2
14.	Pro 14.1	gramming Cautions14-1Programming Cautions14-214.1.1 Turning Off Power Supply Clears Contents of Unit Memory14-214.1.2 Not Going to Other Operation from Current Operation14-214.1.3 Operation with the PLC Set to PROG. Mode from RUN Mode14-2
14.	Pro 14.1	gramming Cautions14-1Programming Cautions14-214.1.1 Turning Off Power Supply Clears Contents of Unit Memory14-214.1.2 Not Going to Other Operation from Current Operation14-214.1.3 Operation with the PLC Set to PROG. Mode from RUN Mode14-214.1.4 Types of Positioning Data Setting Areas14-3
14.	Pro 14.1 Errc	gramming Cautions14-1Programming Cautions14-214.1.1 Turning Off Power Supply Clears Contents of Unit Memory14-214.1.2 Not Going to Other Operation from Current Operation14-214.1.3 Operation with the PLC Set to PROG. Mode from RUN Mode14-214.1.4 Types of Positioning Data Setting Areas14-3Ors and Warnings15-1
14.	Pro 14.1 Errc 15.1	gramming Cautions14-1Programming Cautions14-214.1.1 Turning Off Power Supply Clears Contents of Unit Memory14-214.1.2 Not Going to Other Operation from Current Operation14-214.1.3 Operation with the PLC Set to PROG. Mode from RUN Mode14-214.1.4 Types of Positioning Data Setting Areas14-3Ors and Warnings15-1About Errors and Warnings15-2
14.	Pro 14.1 Errc 15.1	gramming Cautions14-1Programming Cautions14-214.1.1 Turning Off Power Supply Clears Contents of Unit Memory14-214.1.2 Not Going to Other Operation from Current Operation14-214.1.3 Operation with the PLC Set to PROG. Mode from RUN Mode14-214.1.4 Types of Positioning Data Setting Areas14-3Ors and Warnings15-1About Errors and Warnings15-215.1.1 Errors and Warnings15-2
14.	Pro 14.1 Errc 15.1	gramming Cautions14-1Programming Cautions14-214.1.1 Turning Off Power Supply Clears Contents of Unit Memory14-214.1.2 Not Going to Other Operation from Current Operation14-214.1.3 Operation with the PLC Set to PROG. Mode from RUN Mode14-214.1.4 Types of Positioning Data Setting Areas14-3Ors and Warnings15-1About Errors and Warnings15-215.1.1 Errors and Warnings15-215.1.2 Check and Clearing with Configurator PM715-2
14.	Pro 14.1 Errc 15.1	gramming Cautions14-1Programming Cautions14-214.1.1 Turning Off Power Supply Clears Contents of Unit Memory14-214.1.2 Not Going to Other Operation from Current Operation14-214.1.3 Operation with the PLC Set to PROG. Mode from RUN Mode14-214.1.4 Types of Positioning Data Setting Areas14-3Ors and Warnings15-1About Errors and Warnings15-215.1.1 Errors and Warnings15-215.1.2 Check and Clearing with Configurator PM715-215.1.3 Check and Clearing with User Program15-3

	15.2	Changes in Recovery from Errors15 15.2.1 Outline	-5 5-5
	15.3	Error Code Table	-6
		15.3.1 System Error (from 1000H)15	5-6
		15.3.2 Axis operation error (from 3000H)15	5-7
		15.3.3 Set Value Error (from 4000H)15	5-9
	15.4	List of Warning Codes	14
		15.4.1 Unit Warning (from B000H)15-	14
16.	Tro	ubleshooting16-	-1
	16.1	What to Do If an Error Occurs16	-2
		16.1.1 Motor is not Rotating or Operating (Pulse Output A and B LEDs are Flashing or Lit)	6-2
		16.1.2 Motor is not Rotating or Operating (Pulse Output A and B LEDs off)16	6-2
		16.1.3 Reversed Rotation or Movement Direction16	6-3
17.	Spe	cifications 17-	-1
17.	Spe 17.1	cifications	-1
17.	Spe 17.1	Specifications	- 1 7-2
17.	Spe 17.1	Specifications	- 1 7-2 7-2
17.	Spe 17.1 17.2	Specifications 17 Specifications 17 17.1.1 General Specifications 17 17.1.2 Performance Specifications 17 I/O Number Allocation 17	- 1 7-2 7-2 7-3
17.	Spe 17.1 17.2 17.3	cifications 17 Specifications 17 17.1.1 General Specifications 17 17.1.2 Performance Specifications 17 I/O Number Allocation 17 Entire Configuration of Memory Unit Area 17-'	-1 7-2 7-3 7-6
17.	Spe 17.1 17.2 17.3 17.4	cifications 17 Specifications 17 17.1.1 General Specifications 17 17.1.2 Performance Specifications 17 I/O Number Allocation 17 Entire Configuration of Memory Unit Area 17-' Details of Common Area in Unit Memory 17-'	-1 7-2 7-2 7-3 7-6 115
17.	Spe 17.1 17.2 17.3 17.4	cifications 17 Specifications 17 17.1.1 General Specifications 17 17.1.2 Performance Specifications 17 I/O Number Allocation 17 I/O Number Allocation 17 Entire Configuration of Memory Unit Area 17-7 Details of Common Area in Unit Memory 17-7 17.4.1 Common Area Configuration 17-7	-1 7-2 7-2 7-3 7-6 115 116
17.	Spe 17.1 17.2 17.3 17.4	Specifications17-Specifications1717.1.1 General Specifications1717.1.2 Performance Specifications1717.1.2 Performance Specifications17I/O Number Allocation17Entire Configuration of Memory Unit Area17-Details of Common Area in Unit Memory17-17.4.1 Common Area Configuration17-17.4.2 Setting Parameter Control Area17-	-1 7-2 7-2 7-6 115 116 116
17.	Spe 17.1 17.2 17.3 17.4	Specifications17-Specifications1717.1.1 General Specifications1717.1.2 Performance Specifications17I/O Number Allocation17I/O Number Allocation17Entire Configuration of Memory Unit Area17-7Details of Common Area in Unit Memory17-717.4.1 Common Area Configuration17-717.4.2 Setting Parameter Control Area17-717.4.3 Operating Speed Factor Area17-7	-1 7-2 7-2 7-3 7-6 115 116 116 117 117
17.	Spe 17.1 17.2 17.3 17.4	Specifications17-Specifications1717.1.1 General Specifications1717.1.2 Performance Specifications17I/O Number Allocation17I/O Number Allocation17Entire Configuration of Memory Unit Area17-Details of Common Area in Unit Memory17-17.4.1 Common Area Configuration17-17.4.2 Setting Parameter Control Area17-17.4.3 Operating Speed Factor Area17-17.4.4 Axis Group Setting Area17-	-1 7-2 7-3 7-6 15 16 16 17 17
17.	Spe 17.1 17.2 17.3 17.4	Pecifications17-Specifications1717.1.1 General Specifications1717.1.2 Performance Specifications1717.1.2 Performance Specifications17I/O Number Allocation17Entire Configuration of Memory Unit Area17-Details of Common Area in Unit Memory17-17.4.1 Common Area Configuration17-17.4.2 Setting Parameter Control Area17-17.4.3 Operating Speed Factor Area17-17.4.4 Axis Group Setting Area17-17.4.5 Current Value Update Data Area17-	-1 7-2 7-2 7-3 7-6 115 116 117 117 117
17.	Spe 17.1 17.2 17.3 17.4	Specifications17Specifications1717.1.1 General Specifications1717.1.2 Performance Specifications1717.1.2 Performance Specifications17I/O Number Allocation17Entire Configuration of Memory Unit Area17-7Details of Common Area in Unit Memory17-717.4.1 Common Area Configuration17-717.4.2 Setting Parameter Control Area17-717.4.3 Operating Speed Factor Area17-717.4.4 Axis Group Setting Area17-717.4.5 Current Value Update Data Area17-717.4.6 Positioning Control Starting Table Number Setting Area17-7	-1 7-2 7-3 7-6 115 116 117 117 117 120

		17.4.8 Error Annunciation & Clear Area17-22
		17.4.9 Warning Annunciation & Clear Area17-25
		17.4.10 Pulse Count Control Area17-28
		17.4.11 Synchronous Control Monitor Area
		17.4.12 System Operation Setting Area17-31
	17.5	Details of Each Axis Information Area in Unit Memory 17-32
		17.5.1 Each Axis Information & Monitor Area17-32
		17.5.2 Each Axis Information & Monitor Area
	17.6	Details of Each Axis Setting Area in Unit Memory 17-36
		17.6.1 Configuration of Each Axis Setting Area17-36
		17.6.2 Parameter Setting Area17-37
		17.6.3 Positioning Data Setting Areas17-49
	17.7	Unit Memory Synchronous Control Setting Area 17-68
		17.7.1 Synchronous Control Setting Area17-68
		17.7.2 Detailed Information on Synchronous Control Setting Area
	17.8	Dimensions 17-71
18.	San	nple program18-1
	18.1	Basic Configuration and Contact Allocations of Sample Programs 18-2
	18.2	Sample program

- - 18.2.2 When Setting Positioning Data in Extended Area by Programming 18-7
 - 18.2.3 When Setting Positioning Data in Standard Area by Programming......18-9

T Functions of Unit and Restrictions on Combinations

1.1 Functions of Positioning Unit

1.1.1 Functions of Unit

The positioning unit can perform positioning control when it is used in combination with a stepping motor or servomotor equipped with a driver of pulse string input type.

Positioning control with stepping motor



Positioning control with servomotor



■ Transistor output (open collector) type and line driver output type available

Two types are available—a line driver output type for high-speed control and a transistor output type for a motor equipped with a driver that connects only to open collector output (e.g., a stepping motor). If either type is applicable to your application, the use of the unit with line driver output is recommended.

Setting in configuration menu

The dedicated software Configurator PM7 is available, which allows ease of creating a variety of parameters and positioning tables required for positioning control.

Note) The Configurator PM7 will start by pressing [Set details] button in the I/O map of the configuration menu of the FPWIN GR7.

Interpolation control

The 2-axis linear interpolation, 2-axis circular interpolation, 3-axis linear interpolation, and 3axis spiral interpolation control can be performed.

Synchronous control

The unit supports synchronous control using an electronic gear, electronic clutch, and electronic cam. The unit can perform synchronous control with an actual or virtual axis as a master axis.

1.1.2 Unit Type

Product type

Туре	Product no.
2-axis transistor	AFP7PP02T
2-axis line driver	AFP7PP02L
4-axis transistor	AFP7PP04T
4-axis line driver	AFP7PP04L

1.2 Restrictions on Combinations of Units

When the system is configured, take the other units being used into consideration and use a power supply unit with a sufficient capacity.

Current consumption

Туре	Product no.	Current consumption
2-axis transistor	AFP7PP02T	120 mA
2-axis line driver	AFP7PP02L	120 mA
4-axis transistor	AFP7PP04T	120 mA
4-axis line driver	AFP7PP04L	120 mA

2 Names and Functions of Parts

2.1 Names and Functions of Parts



(1) Operation monitor LEDs

Displays the operating status of two axes.

(2) Operating monitor switch (AFP7PP04T and AFP7PP04L only)

Toggles between the operating status display of 1st and 2nd axes and that of the 3rd and 4th axes.

(3) User I/F connector (1st axis and 2nd axis)

A connector for a motor driver and external interface.

(4) User I/F connector (3rd axis and 4th axis) (AFP7PP04T and AFP7PP04L only)

A connector for a motor driver and external interface.

2.2 Operating Status LEDs

The LEDs display the operating status of two axes at a time. If the unit is of 4-axis type, use the switch to toggle between the operating status display of the 1st and 2nd axes and that of the 3rd and 4-axes. The contents of the LED display are the same in each axis.

Operation monitor LEDs

LED	De	escription	Color	ON	OFF	Flashing
		With pulse/sign output settings	Green	- (note 4)	Not in operation	Pulse output
A A-signal display (note 1)	A-signal display (note 1)	With CW/CCW output settings	Green	– (note 4)	Not in operation (forward rotation)	In pulse output operation (forward rotation)
	Pulse output	With pulse/sign output settings	Green	Reverse rotation instruction	Forward rotation instruction	_
В	B-signal display (note 1)	With CW/CCW output settings	Green	_	Not in operation (reverse rotation)	In pulse output operation (reverse rotation)
CL	Displays count	ter clear signal output	Green	Output ON	Output OFF	-
D	Displays near	home state (note 2)	Green	ON	OFF	-
Z	Displays home	e input state (note 2)	Green	ON	OFF	-
PA	Pulse input A-signal display (note 3)		Green	Displays the input status of pulse input A-signal		ut A-signal
PB	Pulse input B-signal display (note 3)		Green	Displays the input status of pulse input B-signal		ut B-signal
ERR	Displays error		Red	If an error occurs	Normal operation	_
ALARM	Displays hardv	vare error	Red	Hardware error	Normal operation	_

(Note 1): The LED for the pulse output A-signal flashes at a cycle (speed) of output frequency, thus looking as if it were continuously lit if the speed is high. So is the LED for the pulse output B-signal.

(Note 2): Near home input (D) and home input (Z) will be lit if the respective inputs are enabled.

(Note 3) The input status of pulse input signals (PA) and (PB) will be displayed.

(Note 4) The LEDs may be continuously lit with or without pulse output if the electronic clutch or electronic cam is in operation.

3 Wiring

3.1 Connection over Wire-pressed Terminal Cable

3.1.1 Specifications of Wire-pressed Terminal Cable

This is a connector that allows loose wires to be connected without removing the wires' insulation. The pressure connection tool is required to connect the loose wires.



Discrete-wire connector (40P)

Suitable wires (strand wire)

Size	Nominal cross-sectional area	Insulation thickness	Rated current
AWG#22	0.3 mm ²	1 5 to 1 1 dia	3 A
AWG#24	0.2 mm ²	1.5 10 1.1 018.	

Connector for wire-pressed terminal cable (provided with the unit)

Manufacturor	Composition of parts	Unit type and required quantity			
Walturacturer	composition of parts	2-axis type	4-axis type		
Panasonic made	Housing (40P)	1 x 1 set	1 x 2 sets		
	Semi-cover (40P)	2 x 1 set	2 x 2 sets		
	5-pin contact (for AW22 and AW24)	8 x 1 set	8 x 2 sets		

(Note) One set is provided for the 2-axis type and two sets are provided for the 4-axis type. If you need more connectors, purchase AFP2801 (2 sets/pack).

Pressure connection tool

Manufacturer	Product no.
Panasonic made	AXY52000FP

Pressure connection tool

3.1.2 Assembly of Connector for Wire-pressed Terminal Cable

The wire end can be directly crimped without removing the wire's insulation, which saves wiring effort.

(Procedure)

1. Bend the contact back from the carrier, and set it in the pressure connection tool.



2. Insert the wire without removing its insulation until it stops, and lightly grip the tool.



3. After press fitting the wire, insert it into the housing.



4. When all wires have been inserted, fit the semi-cover into place.



KEY POINTS





 Contact puller pin to redo wiring If there is a wiring mistake or the wire is incorrectly pressure-connected, use the contact puller pin provided with the fitting to remove the contact.



3.2 I/O Specifications and Terminal Wiring

3.2.1 I/O Specifications



The 4-axis type and 2-axis type use two connectors and one connector, respectively. Signal pins for two axes are allocated to a single connector. There is no difference in pin arrangement between the AX1 and AX2 connector and the AX3 and AX4 connector if the unit is of the 4-axis type. Any pins with the same in number have the same function. The transistor type and line driver type are the same in input terminal and power terminal specifications. Only the performance of the pulse output terminal of the transistor type and that of the line driver type are different from each other.

Pin no.							
1st/ 3rd axis	2nd/ 4th axis	Circ	uit	Signal name		Items	Description
A1	A10			Pulse output A: 5 V DC output	ions	Output type	Open collector
B1	B10	<u> </u>	A1/A10 A2/A11	Pulse output A: Open collector	ecificat	Operating voltage range	4.75 to 26.4 V DC
A2	A11	- L L	B1/B10 B2/B11	Pulse output B: 5 V DC output	put sp	Max. load current	15 mA
B2	B11			Pulse output B: Open collector	Out	ON-state voltage drop	0.6 V

Output terminal (transistor output type)

Pir	n no.					
1st/ 3rd axis	2nd/ 4th axis	Circuit	Signal name		ltems	Description
A1	A10	A1/A10	Pulse output A: Line driver (+)	ions		
B1	B10	O A2/A11	Pulse output A: Line driver (-)	ecificat		Line driver output
A2	A11	B1/B10	Pulse output B: Line driver (-)	put sp	Output type	AM26C31 or equivalent
B2	B11	B2/B11	Pulse output B: Line driver (-)	Out		

Output terminal (line driver output type)

Output terminal (common)

Pir	Pin no.					
1st/ 3rd axis	2nd/ 4th axis	Circuit	Signal name		Items	Description
47	A16		Deviation counter close	suo	Output type	Open collector
A/	AIO	A7/A16	Deviation counter clear	ecificati	Operating voltage range	4.75 to 26.4 V DC
B7	B16	B7/B16 B5/B14	СОМ	out spe	Max. load current	10 mA
				Out	ON-state	1.0 V
B5	B14		Servo ON		voltage drop	

(Note): The deviation counter clear signal will be output for 1 ms on completion of home return control.

Power supply terminal (common)

Pin no.	Circuit	Signal name		Items	Description
A20	o ^{A20}	External power supply input: 24 V DC (+)	pecifications	Supply power range	21.4 to 26.4 V DC
B20	"	External power supply input: 24 V DC (-)	Power supply s	Current consumption	4-axis type 90 mA max. 2-axis type 50 mA max.

(Note): In the case of the 4-axis type, the external power supply input terminals of the two connectors are connected internally.

Input terminal (common)

Pin	no.									
1st/ 3rd axis	2nd/ 4th axis	Circuit	Signal name		Items	Description				
				s	Operating voltage range	21.6 to 26.4 V DC				
			Home input	ficatior	Minimum ON voltage/current	19.2 V DC/5.5 mA				
A3	A12		24 V DC (+) (Z24)	t specit	Maximum OFF voltage/current	2 V DC/2 mA				
			()	nput	Input impedance	Approximately 3 kΩ				
				_	Minimum input pulse width	100 µs or over				
					Operating	3.5 to 5.25 V DC				
		→ + + → B3/B12		suo	voltage range	(5 V DC, line driver specifications)				
	410		Home input	cificati	Minimum ON voltage/current	3 V DC/4 mA				
A4	AIS		5 V DC (+) (Z5)	Input spe	Maximum OFF voltage/current	1 V DC/0.5 mA				
					Input impedance	Approx. 390 Ω				
					Minimum input pulse width	100 µs or over				
B3	B12		Home input (-)	_	_	_				
B4	B13		COM	-	_	_				
									Operating voltage range	21.6 to 26.4 V DC
						Near home input (DOG)				
A5	A14		Near home			19.2 V DC/5.0 mA				
_		• B4/B13	input (DOG)		Minimum ON voltage/current	limit () input (limit)				
		A5/A14		suo		Limit (-) input (Limit -)				
				ficati		19.2 V DC/2.6 mA				
A6	A15		Limit (+) input (Limit +)	out speci	Maximum OFF voltage/current	2 V DC/1.5 mA				
		• B6/B15	(dul		Near home input (DOG)				
						Approximately 3.6 kΩ				
B6	B15		Limit (-) input		Input impedance					
			(Limit -)			Limit (+) input (Limit +)				
						Limit (-) input (Limit -)				

Pir	n no.					
1st/ 3rd axis	2nd/ 4th axis	Circuit	Signal name		Items	Description
			Dulas			3.5 to 5.25 V DC
A8	A17		input A (+)		range	(5 V DC, line driver specifications)
B8	B17	A8/A17 A9/A18 B8/B17 B0/B19	Pulse input A (-)	ficatior	Minimum ON voltage/current	3 V DC/3.2 mA
A9	A18		Pulse input B (+)	: specit	Maximum OFF voltage/current	1 V DC/0.5 mA
				nput	Input impedance	Approx. 390 Ω
B9 B	B18		Pulse	_	Minimum input pulse width	0.5 µs or over
	2.0		input B (-)			(1 MHz max. on each phase)

Note: Use pulse input signals A and B within the following specifications.

■ Using pulse input A and B for 2-phase input.

Pulser input is used for 2-phase input.



3.3 Supply of Power to Drive Internal Circuit

3.3.1 Line Driver Output



3.3.2 Transistor Output

It is possible to get power for the pulse instruction output circuit from the 5-V DC output terminal (pins A1, A2, A10, and A11).



Note:

Make sure that a current not in excess of 15 mA is provided for each signal in the case of using pulse transistor output (open collector output). Add appropriate resistance if the current exceeds 15 mA.

3.4 Connecting Pulse Instruction Signal Input

Connection Positioning unit Motor driver PULSE +5 PULSE Pulse A1.A10 or CW command A or (Line drive) B1.B10 CW SIGN +5V or CCW SIGN Pulse A2.A11 command B or (Line drive) B2,B1 CCW +5V External A20 Power supply input power supply GND +24V DC B20

3.4.1 Line Driver Output Type

3.4.2 Transistor Output Type



Note:

Make sure that a current not in excess of 15 mA is provided for each signal. Add appropriate resistance if the current is in excess.



KEY POINTS

• The use of a twisted-pair cable is recommended to connect the output of the positioning unit and the motor driver.

3.5 Connecting Deviation Counter Clear Output Signal

The following diagram shows an example of connection to the counter clear input of the serve motor driver. This connection requires an external power supply of 5 to 24 V DC.



Note:

- Be sure to use a twisted-pair cable.
- A maximum of 10 mA can flow as a deviation counter clear output signal. Add appropriate resistance if the current is in excess.

Phone: 800.894.0412 - Fax: 888.723.4773 - Web: www.ctiautomation.net - Email: info@ctiautomation.net

3.6 Connecting Servo On Output Signal

The following diagram shows an example of connection to the servo on of the serve motor driver. This connection requires an external power supply of 5 to 24 V DC.



Note:

- Be sure to use a twisted-pair cable.
- A maximum of 10 mA can flow as a deviation counter clear output signal. Add appropriate resistance if the current is in excess.

3.7 Connecting Home Input/Near Home Input Signal

3.7.1 Connecting Home Input (Connecting Motor Driver Z-phase Output)



• The use of a twisted-pair cable is recommended to connect the output of the positioning unit and the motor driver.

3.7.2 Connecting Home Input (Connecting External Switch Sensor)



Input specifications (at 24V DC)

Input voltage range	21.6~26.4V DC
Min. ON voltage/current	19.2V DC/5.5mA
Max. OFF voltage/current	2V DC/2mA
Input impedance	Approx. 3k Ω
Min. input pulse width	100 µ s



3.7.3 Connecting Near Home Input Signal

(Note): B4 and B13 are common to near home input, limit (+) input, limit (-) input, and positioning control start input (timing input).

3.7.4 Connecting Limit Input Signal



(Note): B4 and B13 are common to near home input, limit (+) input, and limit (-) input.

3.8 Connecting Pulse Input

3.8.1 Line Driver Type



3.8.2 Transistor Open Collector Type



3.8.3 Transistor Resistance Pull-up Type



KEY POINTS

The pulser input operation and feedback pulse count of the unit uses the same pulse input terminal. Therefore, select either one of them.

- The use of a twisted-pair cable is recommended.
- In the case of counting 2-phase inputs, such as encoder inputs, use a control code and set the pulse input count to x4 or x2 for the prevention of counting errors.

3.9 Wiring Cautions

Connect the transistor output type or line driver output type to the motor driver over twistedpair cable within the following wiring distance.

<Signals supported>

- Transistor output
- Line driver output
- Deviation counter clear output

Output type	Model no.	Wiring distance
Transistor output type	AFP7PP02T	- 10 m
	AFP7PP04T	
Line driver output type	AFP7PP02L	
	AFP7PP04L	
4 Power On/Off and Check Items

4.1 Safety Circuit Design

Example of a safety circuit

Installation of the over limit switch



Safety Circuit with Positioning Unit

Install over limit switches as shown above.

Connect the switch to the limit (+) input and limit (-) input of the positioning unit.

External safety circuit

Install the safety circuit recommended by the manufacturer of the motor being used.

4.2 Before Turning On the Power

• Check items before turning on the power

System configuration example



(1) Checking connections to the various devices

Check and make sure the various devices have been connected as indicated by the design.

(2) Checking the installation of the external safety circuit

Check and make sure the safety circuit (wiring and installation of over limit switch) based on an external circuit has been installed securely.

(3) Checking the safety circuit with the positioning unit

Check the connections of the positioning unit and over limit switch. Check the installation condition of the over limit switch.

(4) Checking the procedure settings for turning on the power supplies

Make sure settings have been entered so that power supplies will be turned on according to the procedure outlined in section "Procedure for Turning On the Power".

(5) Checking the CPU mode selection switch

Set the CPU unit to PROG. Mode. The CPU unit in RUN mode may operate unexpectedly.



* NOTE

• The use of the positioning unit requires configuration menu settings. Check that each parameter is set properly.

Phone: 800.894.0412 - Fax: 888.723.4773 - Web: www.ctiautomation.net - Email: info@ctiautomation.net

4.3 Procedure for Turning On the Power

4.3.1 Procedure for Turning On the Power

When turning on the power to the system incorporating the positioning unit, consider the nature and statuses of any external devices connected to the system, and take sufficient care so that turning on the power will not initiate unexpected movements.

Procedure

- 1. Turn on the power supplies for input and output devices connected to the PLC. (The power supplies include those for line driver output or open collector output.)
- 2. Turn on the power supply to the PLC.
- 3. Turn on the power supply to the motor driver.



4.3.2 Procedure for Turning Off the Power

Procedure

- 1. Check and make sure the rotation of the motor has stopped, and then turn off the power supply for the PLC.
- 2. Turn off the power supply to the PLC.
- 3. Turn off the power supplies for input and output devices connected to the PLC. (The power supplies include those for line driver output or open collector output.)



4.4 Check with Power Turned On

4.4.1 Check Items After Turning Power On

■ Check items after turning power On System configuration example

Make checks in the following four major steps.



4.4.2 Check on External Safety Circuit

Make a check on the safety circuit recommended by the motor manufacturer, which include a check on the disconnection of the power supply to the motor driver with CW and CCW drive inhibition switch input from an external circuit.

4.4.3 Check on Safety Circuit with Positioning Unit

Step 1

Forcibly operate the over limit switch for the positioning safety circuit and check that the positioning unit correctly receives limit input.

The state of limit input can be checked with the input contact. The valid logic of limit input can be changed in the parameter-setting menu of the Configurator PM7.

Step 2

Input a program, if necessary, to perform the JOG operation of the positioning unit. Then forcibly operate limit input and check that the motor will come to a stop.

You can use the tool operation of the Configurator PM7 to make a check without using a program.

Step 3

Perform the JOG operation of the positioning unit and check that the over limit switch will operate normally.



Operation at limit input

Condition	Direction	Limit status	Operation
When JOG operation	Forward rotation	Limit input (+):ON	Not executable, Error occurs.
is executed		Limit input (-):ON	Executable
	Reverse rotation	Limit input (+):ON	Executable
		Limit input (-):ON	Not executable, Error occurs.
During JOG operation	Forward rotation	Limit input (+):ON	Deceleration stop, Error occurs.
	Reverse rotation	Limit input (-):ON	Deceleration stop, Error occurs.

4.4.4 Operation Checks on Near Home Switch and Home Switch

Step 1

Forcibly operate home input and near home input and check that the operation indicator of the positioning unit will be lit. Monitor the input contact with the FPWIN GR7 as well and make a similar check.

Step 2

Input a home return program to make an actual home return and check that the positioning unit will perform deceleration with near home input.

Point of confirmation

Set the valid logic of home input and near home input in the parameter-setting menu of the Configurator PM7.

Step 3

Repeat the JOG and home return operation of the positioning unit and check that the home stop position will not shift.

Point of confirmation

A shift may result depending on the position of near home input or home input and the return speed.

Step 4

If the home stopping position is shifted, change the position of near home input or reduce the home return speed.



4.4.5 Checking Rotating and Moving Directions and Moving Distance

Step 1

Confirm the rotating direction and moving direction of the motor by the JOG operation of the positioning unit. Use the tool operation function of the Configurator PM7 and perform the JOG operation of the positioning unit.

Point of confirmation

The rotating direction is determined according to the installation of the ball screw or the CW/CCW direction setting parameter.

Step 2

Perform positioning control and check that the moving distance is correct as designed. Use the tool operation function of the Configurator PM7 and perform the JOG or positioning operation of the positioning unit.

Point of confirmation

The moving distance is determined according to the pitch of the ball screw, deceleration gear ratio, or setting movement amount of the positioning data.



5 Unit Allocation and Parameter Settings

5.1 Unit Allocation

5.1.1 I/O Map Registration

Register the unit with the I/O map before making parameter settings.



PROCEDURE

1. Select "Option" \rightarrow "FP7 configuration" from the menu bar.

The FP7 configuration dialog box will be displayed.

2. Select "I/O map" from the left pain.

The I/O map allocation menu will be displayed.

3. Double click the desired slot.

The unit selection dialog box will be displayed.

4. Select "Positioning" from the unit type, select the name of the unit to be used, and press the [OK] button.

Unit selection [Slot No. 1]	×				
Select unit to use	ОК				
Unit type: Positioning 🗸	<u>I</u> nsert				
Unit name: Line driver type, 4-axis, pulse string 🗸	Cancel				
Input time constant: Transistor type, 2-axis, pulse string Transistor type, 4-axis, pulse string					
Line driver type, 2-axis, pulse string Line driver type, 4-axis, pulse string 					
Starting word No. 10 (0 - 511)					
Number of input words: 12 (0 - 128)					
Number of output words: 12 (0 - 128)					
Automatically shift the starting word number for subsequent slots.					
Option					
Exclude this unit from the target for verification.					
Exclude this unit from the target for I/O refresh.					

The message "Updating data display" appears, and the unit selected in the I/O map is registered.

	Slot No.	Unit to use	Staring word
	0	S4E CPU unit	0
V	1	Line driver type, 4-axis, pulse string	10
	2		

5.1.2 Check on I/O Allocation Information

- Each operation start signal, stop signal, home input signal, and positioning completion signal of the positioning unit is allocated to I/O signals.
- I/O numbers actually used vary with the number of the slot where the unit is installed and the first word number.

■ I/O signal allocation (input)

	I/O number						
Signal name	1st axis	2nd axis	3rd axis	4th axis	Virtual axis		
Ready positioning			X0				
Tool operation			X4				
Axis group setting done			X5				
Recalculation done			X7				
Servo lock	X10	X11	X12	X13	X17		
BUSY	X18	X19	X1A	X1B	X1F		
Operation done	X20	X21	X22	X23	X27		
Home return done	X28	X29	X2A	X2B	X2F		
Home input	X30	X31	X32	X33	-		
Near home input	X38	X39	ХЗА	X3B	-		
Auxiliary contact	X48	X49	X4A	X4B	X4F		
Limit +	X50	X52	X54	X56	-		
Limit -	X51	X53	X55	X57	-		
Error annunciation	X60	X61	X62	X63	X67		
Warning annunciation	X68	X69	X6A	X6B	X6F		
Synchronous setting done	X80	X81	X82	X88	-		
Synchronous cancellation	X88	X89	X8A	X8B	-		
Slave axis gear ratio change notice	X90	X91	X92	X93	-		
Slave axis clutch change notice	X98	X99	X9A	X9B	-		

(Note 1): The I/O numbers in the above table show relative addresses based on the base word number. I/O numbers actually used vary with the number of the slot where the unit is installed and the first word number. Example) The home input of 1st axis is X130 for slot number 1 if the first word is number 10.

■ I/O signal allocation (output)

	I/O number					
Signal name	1st axis	2nd axis	3rd axis	4th axis	Virtual axis	
System stop			Y0			
Axis group setting change request			Y5			
Request recalculation			Y7			
Servo ON (The operation is the edge type.)	Y8	Y9	YA	YB	-	
Positioning start (The operation is the edge type.)	Y10	Y11	Y12	Y13	Y17	
Home return start (The operation is the edge type.)	Y18	Y19	Y1A	Y1B	Y1F	
JOG forward rotation (The operation is the level type.)	Y20	Y22	Y24	Y26	Y2E	
JOG reverse rotation (The operation is the level type.)	Y21	Y23	Y25	Y27	Y2F	
Emergency stop (The operation is the level type.)	Y30	Y31	Y32	Y33	Y37	
Deceleration stop (The operation is the level type.)	Y38	Y39	Y3A	Y3B	Y3F	
Pulser operation permit (The operation is the level type.)	Y40	Y41	Y42	Y43	Y47	
J-point speed change (The operation is the edge type.)	Y48	Y49	Y4A	Y4B	Y4F	
Servo OFF request (The operation is the edge type.)	Y50	Y51	Y52	Y53	-	
J-point positioning start	Y58	Y59	Y5A	Y5B	Y5F	
Request error clear	Y60	Y61	Y62	Y63	Y67	
Request warning clear	Y68	Y69	Y6A	Y6B	Y6F	
Synchronous setting request	Y80	Y81	Y82	Y83	-	
Synchronous cancel request	Y88	Y89	Y8A	Y8B	-	
Slave axis gear ratio change request	Y90	Y91	Y92	Y93	-	
Slave axis clutch ON request	Y98	Y99	Y9A	Y9B	-	
Slave axis clutch OFF request	Y100	Y101	Y102	Y103	-	

(Note 1): The I/O numbers in the above table show relative addresses based on the base word number. I/O numbers actually used vary with the number of the slot where the unit is installed and the first word number. Example) The home input of 1st axis is Y110 for slot number 1 if the first word is number 10.

5.2 Axis Allocation for Use

5.2.1 Settings in Configurator PM7

Use the Configurator PM7 to allocate axes for the use of the positioning unit along with the purposes of the axes. The following procedure is explained on the condition that the positioning unit has been already allocated in the I/O map.



PROCEDURE

1. Select the desired positioning unit from the I/O map and press the [Advanced] button.

The configuration menu Configurator PM7 for the positioning unit will start.

Configurator Pt-	17									
Ble Edit View	OnLine Debug Ax	s Settings Optio	ns Help							
	a 📾 🖊 👘 🐂 👌	11 0 0 00	8							
communications d	estination: Home - Sk	t No. 1 Position uni	t: pulse Speed unit: puls	6/8						
Table number	Operation pattern	Control method	X axis (1) movement	Acceleration/deceleration method	Acceleration time (ms)	Deceleration time (ms)	Target speed	Dwell time (ms)	Auxiliary output Comr	ment
1	E: End point	I: Increment	0	L: Linear	100	100	1000	0	0	185
2	E: End point	I: Increment	0	L: Linear	100	100	1000	0	0	
3	E: End point	1: Increment	0	L: Linear	100	100	1000	0	0	
4	E: End point	I: Increment	0	L: Linear	100	100	1000	0	0	
S	E: End point	I: Increment	0	Lt Linear	100	100	1000	0	0	

2. Select "Axis setting" \rightarrow "Change axis" from the menu bar.

The dialog box to set the axes to be used will be displayed.

Axis settings	×
Select model Positioning unit (FP7)	<u>Q</u> K <u>C</u> ancel
Select axis V Axis 1 V Axis 2 V Axis 3 V Axis 4	🗖 Virtual
Please select an axis to use.	

3. Select the axes to be used, and press the [OK] button.

The dialog box for the interpolation operation group setting will be displayed.

4. Drag the icon of each axis to be allocated for interpolation to the interpolation group field.

The following picture shows the allocation of 1st axis and 2nd axis to the interpolation group.

Interpolation operation group set	ttings
Independent	
3 av	i la kis 4 axis tual ax
Interpolation group	
A	В
1 axis 2 axis	

5. Press the [OK] button.

A confirmation message will be displayed.

Configurat	tor PM7
<u> </u>	The axis will be changed. Continue? (Data other than the parameter settings for the axis whose attributes have changed will be initialized.)
	Yes(<u>Y</u>) No (<u>N</u>)

6. Check the contents of the change and press the [Yes] button.

A data table tab each is created for the groups set.





- Setting items, such as the movement and interpolation of X-, Y-, and Z-axis, will be added to the data table, and group name [A] or [B] will be displayed on the tab when the interpolation group is set.
- The virtual axis or slave axis under synchronous control cannot be set to the interpolation groups.

5.3 Parameter Settings

5.3.1 Parameter Settings in Configurator PM7

Use the Configurator PM7 to allocate the most fundamental parameters for positioning control, such as the motor rotation direction, pulse output method (CW/CCW and Pulse/Sign), home input, limit input logic, and positioning control. The following procedure is explained on the condition that the Configurator PM7 has already started.



PROCEDURE

1. Select "Set axis" \rightarrow "Set parameters" from the menu bar.

The parameter dialog box will be displayed.

Parameter settings						x
	Virtual axis	1 a×is [A]	2 axis [A]	3 axis	4 axis	•
Unit setting	P:pulse	P:pulse	P:pulse	P:pulse	P:pulse	
Number of pulses per revolution	1	1	1	1	1	
Movement per revolution	1	1	1	1	1	
Pulse output method		0:Pulse/Sign	0:Pulse/Sign	0:Pulse/Sign	0:Pulse/Sign	
Pulse output rotation direction		0: Clockwise positive	0: Clockwise positive	0: Clockwise positive	0: Clockwise positive	
Limit switch		N: Disabled	N: Disabled	N: Disabled	N: Disabled	_
Limit + switch logic		1:Normal Close	1:Normal Close	1:Normal Close	1:Normal Close	
Limit - switch logic		1:Normal Close	1:Normal Close	1:Normal Close	1:Normal Close	
Home position logic		0:Normal Open	0:Normal Open	0:Normal Open	0:Normal Open	
Home position proximity logic		0:Normal Open	0:Normal Open	0:Normal Open	0:Normal Open	

- 2. Make necessary parameter settings according to the application and press the [OK] button.
- 3. Select "File" \rightarrow "Save Config" from the menu bar.

5.3.2 Parameter Setting Items

Setting items

Parameter name	Description
Unit setting	The unit to be used for setting each axis.
Number of pulses per rotation	Number of pulses per motor rotation (note 1)
Movement amount per rotation	Movement amount per motor rotation (note 1)
Pulse output method	Pulse output method: Pulse/Sign or CW/CCW
Rotating direction of pulse	CW+: + direction is CW.
output	CCW+: + direction is CCW.
Limit switch	Enable/disable the limit switch.
Limit+ switch logic	Limit switch logic in the positive direction
Limit- switch logic	Limit switch logic in the negative direction
Home logic	Home switch logic
Near home logic	Near home switch logic
Pulse input application	Pulse input application
Rotating direction of pulse input	Rotating direction of pulse input (CW/CCW)
Pulse input mode	Mode of pulse input
Pulse input multiplication	Multiplication of pulse input
Software limit (positioning control)	Enables/disables the software limit for positioning control.
Software limit (Home return)	Enables/disables the software limit for home return control.
Software limit (JOG operation)	Enables/disables the software limit for JOG operation.
Upper limit of software limit	The upper limit value of the software limit.
Lower limit of software limit	The lower limit value of the software limit.
Auxiliary output mode	Operating mode of the auxiliary output contact and auxiliary output code.
Auxiliary output ON time (ms)	The period in which the auxiliary output contact is ON.
Movement amount check	Post-check operation with the movement amount check function used
Movement amount check value (Pulse)	Check threshold of the movement amount check function
Numerator of movement amount check correction	The function of movement amount checking is executed based on the pulse input value multiplied by the following ratio.
Denominator of movement amount check correction	(Numerator of movement amount check correction)/(Denominator of movement amount check correction)
Movement amount check interval (ms)	Time interval to execute the movement amount check function.

(Note 1): Set only if the set unit is mm, inch, or degree. It should be cancelled down with the movement amount per rotation.



KEY POINTS

• In the positioning unit, CW refers to the rotating direction with a count increase and CCW refers to the direction with a count decrease. Therefore, limit input in the CW direction is limit + input and that in the CCW direction is limit -.

Parameter name	Description
Startup speed	Startup speed (initial speed) of all types of operation.
Home return – Return setting code	The pattern of the home return.
Home return – Return direction	The operating direction of the home return.
Home return – Return acceleration time	The acceleration time of the home return.
Home return – Return deceleration time	The deceleration time of the home return.
Home return – Return target speed	The target speed of the home return.
Home return – Return creep speed	The speed to search the home position after the proximity input.
Home return - Home coordinates	Present value on completion of the home return
JOG operation - Acceleration/Deceleration pattern settings	The acceleration/deceleration type of JOG operation.
JOG operation – Jog acceleration time	The acceleration time of JOG operation.
JOG operation – Jog deceleration time	The deceleration time of JOG operation.
JOG operation – Target speed	The target rate of JOG operation.
Emergency stop deceleration time (ms)	The deceleration time when the emergency stop is requested by the input contact.
Limit stop deceleration time (ms)	The deceleration time of deceleration operation when the limit is input.
Error stop deceleration time (ms)	The deceleration time of deceleration operation when an error occurs
J point – Operation setting code	The acceleration/deceleration pattern of the J point (speed point)
J point – Acceleration time (ms)	The acceleration pattern of the J point (speed point)
J point – Deceleration time (ms)	The deceleration pattern of the J point (speed point)
J point – Target speed	The target speed of the J point (speed point)
Pulser operation setting code	The pulser input (1 to 4) in the pulser operation.
Pulse input method	Input type of pulse operation
Pulser operation ratio numerator	The number of movement pulses is calculated from the number of input pulses of the pulser multiplied by the ratio below.
Pulser operation ratio denominator	(Numerator of ratio of pulser operation)/(Denominator of ratio of pulser operation)
Pulser operation max. speed	The maximum speed of pulse operation

5.4 Synchronous Parameter/Cam Pattern Settings

5.4.1 Synchronous Parameter Settings

Use the Configurator PM7 to allocate parameters necessary for synchronous control. The following procedure is explained on the condition that the Configurator PM7 has already started.

- 1. 2. 3.
 - PROCEDURE
 - 1. Select "Axis Settings" \rightarrow "Synchronization parameter settings" from the menu bar.

The synchronous parameter dialog box will be displayed.

		1 axis [A]	2 axis [A]	3 axis	4 axis
Quick mous	Select synchronous master axis	No synchronous master	No synchronous master	No synchronous master	No synchronous master
QUICK INDIFE	Deceleration stop method	Linear deceleration	Linear deceleration	Linear deceleration	Linear deceleration
	Deceleration stop time	100	100	100	100
Select master axis	Electronic gear operation settings	Not use	Not use	Not use	Not use
	Gear ratio numerator	1	1	1	1
Ļ	Gear ratio denominator	1	1	1	1
a l	Gear ratio change time	1	1	1	1
1 Alexandre	Clutch operation settings	Not use	Not use	Not use	Not use
~~~	Clutch on trigger type	I/O clutch on request			
ŧ	Edge selection	Level	Level	Level	Level
AS I	Set amount	0	0	0	(
O BE	Method	Direct	Direct	Direct	Direct
	Slip method	Specify slip time	Specify slip time	Specify slip time	Specify slip time
	Slip time	1	1	1	1
	Slip curve selection	Linear	Linear	Linear	Linear
$\square$	Clutch off trigger type	I/O clutch off request			
	Edge selection	Disable	Disable	Disable	Disable
		4			Þ
ect the axis and master axis to synchronize. ase select from the following. synchronous master, Axis 1, Axis 2, Axis 3, Axis 4, Virtual axis, Pulse input 1, Pulse input 2, Pulse input 3, Pulse input 4					

2. Make necessary parameter settings according to the application and press the [OK] button.

# 5.4.2 Cam Pattern Settings

Make electronic cam settings in the case of using an electronic cam. Use the Configurator PM7 to allocate necessary parameters. The following procedure is explained on the condition that the Configurator PM7 has already started.

1.	•		
3.	·	PROCEDURE	

1. Select "Axis Settings"  $\rightarrow$  "Cam pattern settings" from the menu bar.

The cam pattern setting dialog box will be displayed.

🗽 Cam pattern se	ttings							
File Cam Inter	val							
Resolution 1024		Number of cams that can be set	16 Number of se adjustment d	ettable 1000 lata		ispla 🗆 🔨 Spee	e 🗆 🦳 Accelera	mmu Jump
CamAdd	100%							
Delete Duplicate								
Change	0%							
	-100%							
_		0%			50%			100%
Insert Delete	nterval nu	umber Start phase	e (%) End phase (%)	Displacement (	%) Cam curve			*
Shift Adjust								
4						<ul><li>▼</li><li>▶</li></ul>		Ŧ
							ОК	Cancel

- 2. Make necessary parameter settings according to the application and press the [OK] button.
- 3. Select "File"  $\rightarrow$  "Save Configuration" from the menu bar.



## *** KEY POINTS**

- Parameter information saved can be read on the Configurator PM7.
- In the case of synchronous control, basic parameters related to I/O operate according to 5.3 Parameter Settings.



## REFERENCE

Refer to Chapter 8: Automatic Operation (Synchronous Control) for parameter settings related to synchronous control.

# 5.5 Creating Positioning Data Table

## 5.5.1 Construction of Positioning Data Table

Use the Configurator PM7 to allocate the positioning data table. The following procedure is explained on the condition that the Configurator PM7 has already started.

#### Initial display screen of Configurator PM7

• Sheets are divided for each axis, and 600 tables ranging No. 1 to No. 600 can be set.

Configurator Pf-	47									0	
Elle Edit View	OnLine Debug Ax	s Settings Qptio	ns Help								
3 6 8 9 1	6 B A - + + >	11 0 0 0	8								
Communications d	estination: Home - Slo	t No. 1 Position uni	t: pulse Speed unit: puls	e/s							
Table number	Operation pattern	Control method	X axis (1) movement	Acceleration/deceleration method	Acceleration time (ms)	Deceleration time (ms)	Target speed	Dwell time (ms)	Auxiliary output	Comment	
1	E: End point	I: Increment	0	L: Linear	100	100	1000	0	0		
2	E: End point	I: Increment	0	L: Linear	100	100	1000	0	0		
3	E: End point	1: Increment	0	L: Linear	100	100	1000	0	0		
4	E: End point	I: Increment	0	L: Linear	100	100	1000	0	0		
5	E: End point	I: Increment	0	Lt Linear	100	100	1000	0	0		

#### Setting items

Parameter name	Description
Operation pattern	Select one from the following operation patterns.
	E point: Executes the trapezoidal control of only one table.
	C point: Executes the trapezoidal control continuously. Specify an end point (E point) at the end of the continuance point (C-point) control.
	P point: Executes the continuous speed change control. Specify an end point (E point) at the end of the pass point (P-point) control.
	J point: Executes speed control. Specify an end point (E point) at the end of the speed control (J point).
X-axis control method	Select either increment or absolute coordinate.
X-axis movement amount	Input the movement amount of X-axis. The movement amount depends on the unit system specified in the parameter settings.
Acceleration/deceleration pattern	Select the acceleration/deceleration pattern.
Acceleration time (ms)	Set the acceleration time. Set in ms.
Deceleration time (ms)	Set the deceleration time. Set in ms.
Dwell Time (ms)	Set the time from when the positioning instruction in the end point control completes until the positioning done flag turns ON. For the continuance point control, it is the wait time between each table. For the pass point control, the dwell time is ignored.
Auxiliary output	Set the auxiliary output code. When the auxiliary output is set to enable in the parameter settings, the auxiliary output code specified here is output.

(Note 1): The details for the settings in each parameter are indicated in the guidance bar.

(Note 2): In the case of selecting interpolation control, interpolation, Y-axis movement amount, X-axis auxiliary point, Y-axis auxiliary point, and interpolation speed as items are displayed as well.

# 5.5.2 Table No. Positioning Start

- Execute the POSSET command in the user program to specify table numbers on the Configurator PM7.
- The positioning unit will start control under the conditions set in the table by executing the POSSET reference and turning the corresponding positioning start contact ON after specifying the desired slot number, axis number, and table number.



## 5.5.3 Operation Patterns and Tables

- Use a number of tables if the positioning patterns consist of pass point control, continuance point control, and JOG positioning control.
- In these types of control, the tables will be created continuously on the Configurator PM7, and select the end point control for the operation pattern for the last table.
- Specify the first data table number for each control in the program.

#### (Example) Pass point control

Create three positioning data tables, and select "E: End point" for the last table. Furthermore, start the first table number for each control in the user program.



Table number	Operation pattern	Control method	X axis (virtual) movement	Acceleration/deceleration method
1	P: Pass point	I: Increment	50000	L: Linear
2	P: Pass point	I: Increment	100000	L: Linear
3	E: End point	I: Increment	30000	L: Linear



# REFERENCE

For detailed information on each control, refer to Chapter 7. Automatic Operation (Positioning Control)

# 5.6 Saving Parameters

# 5.6.1 Save/Load Configuration

Information on the basic parameters and positioning data tables that have been set for the Configurator PM7 are saved as configuration information along with information on I/O map allocations on a unit-by-unit basis. Save and load the configuration information as necessary.

# 5.6.2 Export and Import

- Basic parameters and positioning parameters set can be exported to and imported from the Configurator PM7.
- Information on positioning parameters and positioning tables saved by using the export function can be reused between projects.



#### PROCEDURE

1. Select "File"  $\rightarrow$  "Export" from the menu bar.

The saving destination and file names are displayed.

2. Enter the saving destination and file name, and press [Save] button.

Information on the parameters and positioning data tables is saved in a file with a ".pm7" extension.



## **KEY POINTS**

• When export is executed, information on the positioning data tables will be saved along with information set in the parameter-setting menu.

# **6** Transfer to Unit and Commissioning

# 6.1 Check on Setting Contents

## 6.1.1 Check on Parameter Data

• The following procedure is explained on the condition that the Configurator PM7 has already started.



# 

1. Select "Debug"  $\rightarrow$  "Check parameters and data values" from the menu bar.

A message box will be displayed to show the check result. If there is an error in the settings for the positioning data tables, an error message will appear and the cursor will move to the corresponding error position.



# 6.1.2 Comparison of Parameter Information

• It is possible to compare information on parameters being edited with information saved in the Configurator PM7. The following procedure is explained on the condition that the Configurator PM7 has already started.



# PROCEDURE

1. Select "Debug"  $\rightarrow$  "Compare"  $\rightarrow$  "File" or "Config" from the menu bar.

When "file" is selected, a dialog box for comparison file selection will be displayed. When "Config" is selected, information edited in the Configurator PM7 will be compared with configuration information saved, and the results of comparison will be displayed.

# 2. Select the target file from the dialog box for the selection of the comparison file, and press the [OK] button.

The information being edited in the Configurator PM7 is compared with the configuration information saved, and the comparison results will be displayed.

Verification result
Verification 1 Home - Slot No. 1 Verification content
Axis information - Match
Parameter data - Match
Positioning data - Mismatch
Synchronization parameters - Match
Cam pattern - Match
Verification result - Mismatch
Comments associated with positioning settings data are not
Leip

# 6.2 Transfer of Parameters

## 6.2.1 Writing Parameters to Unit

- Information on parameters that have been set is transferred as a part of project information to the CPU unit along with other configuration information.
- The following procedure is explained on the condition that the Configurator PM7 has already started.



PROCEDURE

- 1. Select "File"  $\rightarrow$  "Exit" from the menu bar of the Configurator PM7.
- 2. When "Save data in the configuration area?" appears, press [Yes(Y)].
- 3. Press the [OK] button in the FP7 configuration dialog box.
- 4. Select "Online"  $\rightarrow$  "Download to PLC" from the FPWIN GR7 menu bar.

Parameters for the positioning unit will be downloaded to the CPU unit along with the program and other configuration information.

5. Set the FP7 CPU unit to RUN mode.

The configuration information will be transferred to the positioning unit as well so that the positioning unit will be read for commissioning with I/O signals or the Configurator PM7.

#### 6. Select "Option" $\rightarrow$ "FP7 configuration" from the menu bar.

The FP7 configuration dialog box will be displayed.

- 7. Select "I/O map" from the left pane.
- 8. Select the positioning unit from the I/O map and press the [Advanced settings (A)] button.

The Configurator PM7 will be activated.

Select [Online]  $\rightarrow$  [Data monitor]  $\rightarrow$  [Status display]  $\rightarrow$  [Tool operation] so that each menu items of the positioning unit will be available.

# 6.3 Monitoring on Configurator PM7

## 6.3.1 Status Monitor

- It is possible to monitor the connection state of each axis and input state of the external terminal.
- The following procedure is explained on the condition that the Configurator PM7 has already started.



PROCEDURE

1. Select "Online"  $\rightarrow$  "Status monitor" from the menu bar.

The status monitor dialog box will be displayed.

Status monitor				<b>X</b>
Model	FP7 pos	sitioning unit (FP7 ty	pe) 4-axis transisto	or output
Axis [Group]	1 axis	2 axis	3 axis	4 axis
Status	Connected	Connected	Connected	Connected
External terminal input monito	r			
Home position proximity	OFF	OFF	OFF	OFF
Home position	OFF	OFF	OFF	OFF
Limit +	Limit +	Limit +	Limit +	Limit +
Limit -	Limit -	Limit -	Limit -	Limit -
	4			Þ
FROM write count		r		
Firmware version	1.00			
Hardware version	1.01		<u>H</u> elp	Close

# 6.3.2 Data Monitor

• It is possible to monitor the connection state of each axis and input state of the external terminal.



1. Select "Online"  $\rightarrow$  "Data Monitor" from the menu bar.

The data monitor dialog box will be displayed.

Aulia [Oursen]	1 auto	0 auto	0 autia	1
Axis [Group]	I axis	2 axis	3 axis	4 axis
ynchronous master axis	Master	1 axis		
Synchronized output				
Synchronous state	Synchronous	Synchronous	Asynchronous	Asynchronous
Table number executing	0	0	0	0
Auxiliary output code	0	0	0	0
Current value	0	0	0	0
t conversion current val	0 pulse	0 pulse	0 pulse	0 pulse
Pulse input value	0	0	0	0
Deviation	0	0	0	0
Axis state	Stopped	Stopped	Stopped	Stopped
Error code				
[	Clear errors	Clear errors	Clear errors	Clear errors
Warning code				
	Clear warning	Clear warning	Clear warning	Clear warning
	4			Þ

#### Monitor items

Items	Description
Table number executing	The table number that the positioning data is being executed or has been executed.
Auxiliary output code	Auxiliary output code
Current value (pulse)	The current value of the positioning unit.
Unit conversion current value	The unit-converted current value of the positioning unit.
Pulse input value	Monitors the input pulse value.
Deviation	Displays the deviation of the amount of movement while the auto check function for the amount of movement is activated.
Axis state	The operating states of axes or error and warning occurrences.
Error code	The latest error code if an error occurs.
Error clear	Clears the error by clicking this button if an error occurs.
Warning code	Indicates the latest warning code if a warning occurs.
Warning clear	Clears the warning by clicking this button if a warning occurs.



## • NOTES

- If a recoverable error occurs in the positioning unit, click the [Error clear] button to clear the error.
- If a warning occurs in the positioning unit, click [Warning clear] to clear the warning.

# 6.4 Tool Operation

# 6.4.1 Tool Operation Function

- You can perform commissioning with the Configurator PM7 before actually starting the user program.
- Be sure to save the settings and download the project to the CPU unit before starting the tool operation of the positioning unit.
- The following procedure is explained on the condition that the Configurator PM7 has already started.



# 

1. Select "Online"  $\rightarrow$  "Tool Operation" from the menu bar.

The tool operation dialog box will be displayed.

Tool operation in progress
Servo On/Off
Homo Potum
Positioning
Jog Operation…
Teaching
<u>E</u> xit

#### Types of tool operation

Items	Description
Servo ON/OFF	Specifies servo ON/OFF for each axis.
JOG operation	The specified axis can be moved to the specified direction at the specified speed while the operation reference is ON.
Home return	A home return is performed to the home of the machine coordinates according to the specified parameter.
Positioning	Moves from the start table number according to the set contents in the positioning table.
Teaching	Controls the axis manually like JOG operation, and reflects the resulting positioning address on the Data Editing screen.



# KEY POINTS

- The positioning unit cannot go into tool operation while the positioning unit is in user program operation.
- Operation requests with I/O signals will be disabled while the positioning unit is in tool operation.
- If any communication error occurs while the positioning unit is in tool operation, the positioning unit will detect the error and stop automatically.

• If the previous tool operation does not finish properly due to a communication error, etc., the tool operation mode will be cancelled forcibly when the next tool operation starts.

Phone: 800.894.0412 - Fax: 888.723.4773 - Web: www.ctiautomation.net - Email: info@ctiautomation.net

# 6.4.2 JOG Operation with Tool Operation Function

- You can perform commissioning with the Configurator PM7 before actually starting the user program.
- The following procedure is explained on the condition that the Configurator PM7 has already started.



# PROCEDURE

1. Select "Online"  $\rightarrow$  "Tool Operation" from the menu bar.

The tool operation dialog box will be displayed.

2. Select "JOG operation" from the tool operation dialog box.

The tool operation-JOB operation dialog box will be displayed.

Fool operation - Jog operation				
and the second second second second				
poi operation in progres				
Axis [Group]	1 axis	2 axis	3 axis	4 axis
ynchronous master axi	Master	1 axis		
Synchronized output				
Synchronous state	Synchronous	Synchronous	Asynchronous	Asynchronous
	Change synchronization	Change synchronization	Change synchronization	Change synchronization
Current value	0	0	0	0
	Current value update	Current value update	Current value update	Current value update
Unit	pulse	pulse	pulse	pulse
Deviation (pulses)	0	0	0	0
Jog target speed	1000	1000	1000	1000
	Change	Change	Change	Change
JOG	+	+	+	+
	-	-	-	-
Axis state	Stopped	Stopped	Stopped	Stopped
Error code				
	Clear errors	Clear errors	Clear errors	Clear errors
Warning code				
	Clear warning	Clear warning	Clear warning	Clear warning
	4			Þ
Speed Rate	100 %		Help	<u>E</u> xit

3. Press [+] or [-] button in the JOG field.

The JOG operation of the positioning unit starts.

4. Press [Quit] button to terminate the JOG operation.



## **KEY POINTS**

• If an recoverable error occurs in the positioning unit, click the [Clear errors] button to clear the error.

• If a warning occurs in the positioning unit, click [Clear warning] to clear the warning.

Dialog box items				
Items	Description			
Current value	Monitors the feedback values after the unit system conversion for each axis.			
	Click [Present Value Refresh] to display the dialog for inputting value to change the present value.			
Unit	Monitors the unit of positions specified with parameter settings on an axis-by-axis basis on the positioning unit.			
Deviation (Pulse)	Monitors the deviation of the amount of movement while the auto check function for the amount of movement is activated.			
JOG target speed	Monitors and displays the target speed in the JOG operation. Click [Change] to change the target speed for the JOG operation.			
JOG [+]	Click [+] to perform the forward rotation.			
JOG [-]	Click [-] to perform the forward rotation.			
Axis state	The operating states of axes or error and warning occurrences.			
Error code	The latest error code if an error occurs.			
Clear errors	Clears the error by clicking this button if an error occurs.			
Warning code	Indicates the latest warning code if a warning occurs.			
Clear warning	Clears the warning by clicking this button if a warning occurs.			
Speed factor	The target speed of the home return specified in the parameter settings for each axis is regarded as 100%, and the operation is executed at the specified speed rate. Clicking [Speed factor] shows the dialog for inputting the value.			

• This dialog cannot be closed while the positioning unit is in JOG operation.
# 6.4.3 Tool Operation - Home Return

- When the power is turned on, the coordinates of the positioning unit do not coincide with those of the machine position. Execute a home return before starting positioning.
- You can perform commissioning with the Configurator PM7 before actually starting the user program.
- The following procedure is explained on the condition that the Configurator PM7 has already started.



#### PROCEDURE

1. Select "Online"  $\rightarrow$  "Tool Operation" from the menu bar.

The tool operation dialog box will be displayed.

2. Select "Home Return" from the tool operation dialog box.

The tool operation-home return dialog box is displayed.

ool operation - Retur	n to home position			×
ol operation in progres				
Axis [Group]	1 axis	2 axis	3 axis	4 axis
ynchronous master axi	Master	1 axis		
Synchronized output				
Synchronous state	Synchronous	Synchronous	Asynchronous	Asynchronous
	Change synchronization	Change synchronization	Change synchronization	Change synchronization
Current value	0	0	0	0
	ome position coordinate	ome position coordinate	ome position coordinate	ome position coordinate
Unit	pulse	pulse	pulse	pulse
Deviation (pulses)	0	0	0	0
Home return mode	Dog method 1	Dog method 1	Dog method 1	Dog method 1
	Start	Start	Start	Start
Axis state	Stopped	Stopped	Stopped	Stopped
Error code				
	Clear errors	Clear errors	Clear errors	Clear errors
Warning code				
	Clear warning	Clear warning	Clear warning	Clear warning
	4			F
Speed Rate	100 %		Help	<u>E</u> xit

3. Press the [Start] button for the axis to be returned home.

Execute the home return.

4. Press [Quit] button to terminate the home return operation.



## **KEY POINTS**

• If an recoverable error occurs in the positioning unit, click the [Error Clear] button to clear the error.

- If a warning occurs in the positioning unit, click [Warning clear] to clear the warning.
- This dialog cannot be closed while the positioning unit is in home return operation.

Items	Description
Current value	Click [Home position coordinates] to display the dialog for inputting value to change the value after a home return.
Unit	Monitors the unit of positions specified with parameter settings on an axis-by-axis basis on the positioning unit.
Deviation (Pulse)	Displays the deviation of the amount of movement while the auto check function for the amount of movement is activated.
Home return mode	Displays the contents of the home return setting code registered with positioning setting data.
Operation /Stop	Click [Operation] to execute the home return operation. <ul> <li>The button name changes to [Stop].</li> <li>Click [Stop] to execute the deceleration stop operation. The button name changes to [Start].</li> </ul>
State of axis	The operating states of axes or error and warning occurrences.
Error code	The latest error code if an error occurs.
Error clear	Clears the error by clicking this button if an error occurs.
Warning code	Indicates the latest warning code if a warning occurs.
Warning clear	Clears the warning by clicking this button if a warning occurs.
Speed factor	The target speed of the home return specified in the parameter settings for each axis is regarded as 100%, and the operation is executed at the specified speed factor. Clicking [Speed rate] shows the dialog for inputting the value.

#### Dialog box items

# 6.4.4 Tool Operation - Positioning

Specifying a starting table number enables to check if positioning from the starting table operates properly.

2	•	PROCEDURE
3		

1. Select "Online"  $\rightarrow$  "Tool Operation" from the menu bar.

The tool operation dialog box will be displayed.

2. Select "Positioning" from the tool operation dialog box.

Tool operation - Positioning × Axis [Group] 1 axis 2 axis 3 axis 4 axis vnchronous master axis Master 1 axis Synchronized output Synchronous state Synchronous Synchronous Asynchronous Asynchronous Change synchronization Change synchronization Change synchronization Change synchronization Current value 0 Current value update Current value update Current value update Current value update Unit pulse pulse pulse pulse Deviation (pulses) 0 0 0 0 Table number executing Start table number Change Change Change Change Operation Operation Operation Operation Axis state Stopped Stopped Stopped Stopped Error code Clear errors Clear errors Clear errors Clear errors Warning code Clear warning Clear warning Clear warning Clear warning Speed Rate 100 % <u>E</u>xit

The tool operation-positioning dialog box will be displayed.

3. Press the [Change] button under the target start table number field.

The dialog box to set the start table number will be displayed.

- 4. Input the start table number.
- 5. Press the [Operate] button.

Positioning will start from the specified start table number.

6. Press [Exit] button to terminate the positioning operation.



#### KEY POINTS

- For the positioning operation, the setting data should be downloaded to the positioning unit in advance. The operations after the starting table number vary depending on the operation patterns.
- If an recoverable error occurs in the positioning unit, click the [Error clear] button to clear the error.
- If a warning occurs in the positioning unit, click [Warning clear] to clear the warning.
- The positioning operation of the interpolation group starts and stops the axis with the smallest number in the group. If the tool operation function is used, positioning will start by pressing the [Run] button for any axis. A warning message, however, will be displayed unless the [Run] button for the axis with the smallest number is pressed.
- This dialog cannot be closed while the positioning unit is in home return operation.

Items	Description	
Current value	Monitors the feedback values after the unit system conversion for each axis. Click [Current value update] to display the dialog for inputting value to change the present value.	
Unit	Displays the unit of positions specified with parameter settings on an axis-by-axis basis on the positioning unit.	
Deviation (Pulse)	Displays the deviation of the amount of movement while the auto check function for the amount of movement is activated.	
Active table number	Displays the table number when the positioning unit is in operation or it has finished operating.	
Starting table number	Start table number of positioning control. The start table number can be changed by clicking [Change] for the start table number of positioning control.	
	Executes the operation and stop of positioning according to the settings.	
Operation/Stop	<ul> <li>Click [Operation] to execute positioning control, when the button name will change to [Stop].</li> </ul>	
	<ul> <li>Click [Stop] to execute the deceleration stop operation. The button name will change to [Operation].</li> </ul>	
State of axis	The operating states of axes or error and warning occurrences.	
Error code	The latest error code if an error occurs.	
Error clear	Clears the error by clicking this button if an error occurs.	
Warning code	Indicates the latest warning code if a warning occurs.	
Warning clear	Clears the warning by clicking this button if a warning occurs.	
Speed rate	The target speed of the home return specified in the parameter settings for each axis is regarded as 100%, and the operation is executed at the specified speed rate. Clicking [Speed rate] shows the dialog for inputting the value.	

#### Dialog box items

# 6.4.5 Tool Operation - Teaching

Activate each axis manually by the tool operation, and register the positioning addresses where the axes come to a stop as the point data.

1.		
2.	٠	
3.	•	PROCEDUR

1. Select "Online"  $\rightarrow$  "Tool Operation" from the menu bar.

The tool operation dialog box will be displayed.

2. Select "Teaching" from the tool operation dialog box.

The tool operation-teaching dialog box will be displayed.

ol operation - Teachi	ing			
ol operation in progres				
Axis [Group]	1 axis	2 axis	3 axis	4 axis
nchronous master axi	Master	1 axis		
Synchronized output				
Synchronous state	Synchronous	Synchronous	Asynchronous	Asynchronous
	Shange synchronization	Change synchronization	Change synchronization	Change synchronizatio
Current value	0	0	0	
	Current value update	Current value update	Current value update	Current value update
Unit	pulse	pulse	pulse	pulse
Deviation (pulses)	0	0	0	
Jog target speed	1000	1000	1000	100
	Change	Change	Change	Change
100	+	+	+	+
300	-	-	-	-
Table number	1	1	1	
	Teaching	Teaching	Teaching	Teaching
Axis state	Stopped	Stopped	Stopped	Stopped
Error code				
	Clear errors	Clear errors	Clear errors	Clear errors
Warning code				
	Clear warning	Clear warning	Clear warning	Clear warning
	<u> </u>			
Speed Rate	100 %		Help	Exit

- 3. Perform the JOG operation of the positioning unit to stop the positioning unit at the positioning point.
- 4. Press the [Teaching] button.
- 5. Input the table number where the desired positioning information is registered, and click the [OK] button.

The current value will be registered for the amount of movement of the table number specified. If the axis that the teaching operation is performed is the interpolation axis, the current value is registered for the movement amount of the equivalent coordinate in the interpolation group.

6. Press [Exit] button to terminate teaching.



## KEY POINTS

- If an recoverable error occurs in the positioning unit, click the [Error clear] button to clear the error.
- If a warning occurs in the positioning unit, click [Warning clear] to clear the warning.
- The control method for the table number that the teaching operation was performed is automatically changed to "Absolute".
- The result of the teaching becomes effective once the tool operation quits and the setting data is downloaded to the positioning unit.
- This dialog cannot be closed while the positioning unit is in home return operation.

Items	Description			
Current value	Monitors the feedback value on an axis-by-axis basis after set unit conversion. Click [Present Value Refresh] to display the dialog for inputting value to change the present value.			
Set unit	Monitors the unit of positions specified with parameter settings on an axis-by-axis basis on the positioning unit.			
Deviation (Pulse)	Monitors the deviation of the amount of movement while the auto check function for the amount of movement is activated.			
IOC torget apoed	Monitors and displays the target speed in the JOG operation.			
JOG larger speed	Click [Change] to change the target speed for the JOG operation.			
JOG [+]	Click [+] to perform the forward rotation.			
JOG [-]	Click [-] to perform the reverse rotation.			
Table number	Displays the target table number for teaching. Click [Teaching] to change the table number for the teaching and register the current value.			
State of axis	The operating states of axes or error and warning occurrences.			
Error code	The latest error code if an error occurs.			
Error clear	Clears the error by clicking this button if an error occurs.			
Warning code	Indicates the latest warning code if a warning occurs.			
Warning clear	Clears the warning by clicking this button if a warning occurs.			
Speed rate	The target speed of the home return specified in the parameter settings for each axis is regarded as 100%, and the operation is executed at the specified speed rate. Clicking [Speed rate] shows the dialog for inputting the value.			

#### Dialog box items

# **7** Automatic Operation (Positioning Control)

# 7.1 Basic Operation

# 7.1.1 Positioning Control Patterns

#### Type of operations

The automatic operation is an operation mode to perform positioning control. A single axis control and an interpolation control that starts and stops multiple axes simultaneously are available for positioning control.

End point (E-point) control, which uses the positioning data of a single table, and pass point (P-point) control and continuous point (C-point) control, both of which use multiple tables, are available for single axis control and interpolation control. These types of control are described below, and acceleration time and deceleration time can be set individually. For P-point control and C-point control, an E-point should be set as the last table. In P-point control and C-point control, the operation done flag turns ON after the last table is executed.

JOG positioning (J-point) control (i.e., speed control) is available in addition to P-point control, C-point control, and E-point control.

J-point control operates until the start contact of J-point positioning turns ON after the operation of the positioning unit starts, and the next positioning control will start when the start contact of J-point positioning turns ON.

In J-point control, the operation done flag turns ON after the last table is executed.

J-point control can be used for a single axis only.



#### Operation flow of single axis control



Turn the corresponding positioning start contact ON.

#### Operation flow of interpolation control



# 7.1.2 Setting and Operation of E-Point Control

The example below is a case of single-axis control with the positioning unit installed in slot 1. The movement amount setting uses an increment method in pulses.



#### Settings

Items	Setting example		
Operation pattern	E: End point		
Control method	I: Increment		
X-axis movement amount	10000 pulses		
Acceleration/deceleration pattern	L: Linear		
Acceleration time (ms)	100 ms		
Deceleration time (ms)	100 ms		
Target speed	10000 pps		

#### Operation diagram



#### Operation of each contact

- The BUSY flag (X118), which indicates that the motor is running, will turn ON when the positioning control starts, and it will turn OFF when the operation completes.
- The operation done flag (X120), which indicates the completion of operation, will turn ON when the current operation is completed, and it will be held until the next positioning control, JOG operation, home return, or pulser operation starts. The flag will turn ON after the positioning unit transmits a reference for the target position.

# 7.1.3 Setting and Operation of P-Point Control

The example below is a case of single-axis control with the positioning unit installed in slot 1. The movement amount setting uses an increment method in pulses.



#### Settings

Itoms	Setting example			
items	Table 1	Table 2	Table 3	
Operation pattern	P: Pass point	P: Pass point	E: End point	
Control method	I: Increment	I: Increment	I: Increment	
X-axis movement amount	5000 pulses	10000 pulses	3000 pulses	
Acceleration/deceleration pattern	L: Linear	L: Linear	L: Linear	
Acceleration time (ms)	100 ms	200 ms	30 ms	
Deceleration time (ms)	10 ms	20 ms	150 ms	
Target speed	10000 pps	20000 pps	5000 pps	

#### Operation diagram



## Operation of each contact

- The BUSY flag (X118), which indicates that the motor is running, will turn ON when the positioning control starts, and it will turn OFF when the operation completes.
- The operation done flag (X120), which indicates the completion of operation, will turn ON when the current operation is completed, and it will be held until the next positioning control, JOG operation, home return, or pulser operation starts. The flag will turn ON after the positioning unit transmits a reference for the target position.

# 7.1.4 Setting and Operation of P-Point Control

The example below is a case of single-axis control with the positioning unit installed in slot 1. The movement amount setting uses an increment method in pulses.



## Settings

Use the tool software to make positioning data and parameter settings. The unit is set to pulse.

Items	Setting example		
	Table 1	Table 2	Table 3
Operation pattern	C: Continuance point	C: Continuance point	E: End point
Control method	I: Increment	I: Increment	I: Increment
X-axis movement amount	5000 pulses	10000 pulses	3000 pulses
Acceleration/deceleration pattern	L: Linear	L: Linear	L: Linear
Acceleration time (ms)	100 ms	200 ms	30 ms
Deceleration time (ms)	10 ms	20 ms	150 ms
Target speed	10000 pps	20000 pps	5000 pps

#### Operation diagram



#### Operation of each contact

- The BUSY flag (X118), which indicates that the motor is running, will turn ON when the positioning control starts, and it will turn OFF when the operation completes.
- The operation done flag (X120), which indicates the completion of operation, will turn ON when the current operation is completed, and it will be held until the next positioning control, JOG operation, home return, or pulser operation starts. The flag will turn ON after the positioning unit transmits a reference for the target position.

# 7.1.5 Setting and Operation of J-point Control

• JOG positioning (J-point) control operates at target speed until the start contact of J-point positioning turns ON after the operation of the positioning unit starts, and the next positioning control will start when the start contact of J-point positioning turns ON.

#### Settings

	Setting example			
Items	Table 1	J-point axis parameter setting	Table 2	Table 3
Operation pattern	J: Speed point	-	P: Pass point	E: End point
Control method	I: Increment	-	I: Increment	I: Increment
X-axis movement amount	5000 pulses	_	10000 pulses	3000 pulses
Acceleration/deceleration pattern	L: Linear	_	L: Linear	L: Linear
Acceleration time (ms)	100 ms	-	200 ms	30 ms
Deceleration time (ms)	10 ms	-	20 ms	150 ms
Target speed	10000 pps	-	20000 pps	5000 pps
J-point control code	_	Linear acceleration/ deceleration	_	_
J-point acceleration time	-	10 ms	-	-
J-point deceleration time	_	10 ms	_	_
J-point target speed	-	30000 pps	_	_



## KEY POINTS

- Specify parameters for the start of operation in the positioning data table. Specify parameters in the axis parameter-setting menu at the time of speed change.
- J-point control can be used for single-axis control only. It is not available for interpolation control.
- Set the positioning unit to increment mode to implement P-point control, Cpoint control, or E-point control with positions specified after J-point control is implemented.
- Speed control is performed while the positioning unit is in J-point control, in which case, be sure to input the amount of movement for positioning with a value that can secure a target constant-speed area.

#### Operation diagram



#### Operation of each contact

- The BUSY flag (X118) will turn ON when the operation starts and turn OFF when the operation is completed.
- The operation done flag (X120) indicating the state that an operation completed will turn ON when the JOG operation is completed, and it will be held until the next positioning control, JOG operation, home return, or pulser operation starts.
- The target speed will be changed when the J-point speed change contact (Y148) turns ON. The change will be enabled at the edge where the contact turns ON.
- Positioning control will start when J-point positioning start contact (Y158) turns ON.
- Behaviors when the speed change contact turns ON while the positioning unit is accelerating or decelerating the speed
- A speed change is possible during J-point control, but impossible during acceleration or deceleration.
- A speed change will be made after the positioning unit goes to constant speed when the speed change signal turns ON during acceleration or declaration.



# 7.1.6 Sample Program (E-Point, P-Point, and C-Point Control)

#### Sample program



# 7.1.7 Sample Program (J-point Control)

#### Sample program



# 7.1.8 Programming Precautions

#### Programming Precautions

- The last table should be set to E: End point.
- If any value such as a movement amount, acceleration time, deceleration time or target speed is out of the specified range, a set value error will occur when the positioning control starts.
- The start contact and flag number varies depending on the number of axes and the installation position of the unit.
- The specified slot number varies depending on the installation position of the unit.

Condition	Direction	Limit status	Operation
At each control	Forward rotation	Limit input (+):ON	Not executable, Error occurs.
start		Limit input (-):ON	Not executable, Error occurs.
	Reverse rotation	Limit input (+):ON	Not executable, Error occurs.
		Limit input (-):ON	Not executable, Error occurs.
During each type of control	Forward rotation	Limit input (+):ON	Deceleration stop, Error occurs.
	Reverse rotation	Limit input (-):ON	Deceleration stop, Error occurs.

#### Operation at limit input

# 7.2 Interpolation Control

# 7.2.1 Types of Interpolation Control

#### Types of operations

Interpolation control includes 2-axis linear interpolation control, 2-axis circular interpolation control, 3-axis linear interpolation control, and 3-axis spiral interpolation control. The following methods are available to specify the operation of each interpolation control. Select an appropriate method according to the application. The axes in the relation of interpolation are called X-axis and Y-axis for the 2-axis interpolation, and are called X-axis, Y-axis, and Z-axis for the 3-axis interpolation. X-, Y-, and Z-axes are automatically assigned in ascending order of axis signal levels.

In each type of interpolation control, the E-point control that uses one table, P-point control and C-point control that uses multiple tables can be combined arbitrarily as positioning data.

For example, using P-point control enables continuous interpolation control from 2-axis linear control to 2-axis circular interpolation control. The acceleration time and deceleration time can be specified individually. For P-point control and C-point control, an E point should be set as the last table.

Туре	Operation specification method	Necessary data
2-axis linear	Composite speed	Composite speed of X-axis and Y-axis
interpolation control	Long axis speed	Speed of long axis (Axis of which moving distance is long)
2-axis circular	Center/CW direction	X-axis and Y-axis coordinates of center
interpolation	Center specified/CCW direction	X-axis and Y-axis coordinates of center
	Pass point	X-axis and Y-axis coordinate of pass point on arc
3-axis linear interpolation	Composite speed	Composite speed of X-axis, Y-axis, and Z-axis
control	Long axis speed	Speed of long axis (Axis of which moving distance is long)
3-axis spiral	Center/CW direction/X-axis movement	Y-axis and Z-axis coordinates of center
interpolation	Center/CCW direction/Y-axis movement	Y-axis and Z-axis coordinates of center
	Center/CW direction/Y-axis movement	X-axis and Z-axis coordinates of center
	Center/CCW direction/Y-axis movement	X-axis and Z-axis coordinates of center
	Center/CW direction/Z-axis movement	X-axis and Y-axis coordinates of center
	Center/CCW direction/Z-axis movement	X-axis and Y-axis coordinates of center
	Pass point/X-axis movement	Y-axis and Z-axis coordinate of pass point on arc
	Pass point/Y-axis movement	X-axis and Z-axis coordinate of pass point on arc
	Pass point/Z-axis movement	X-axis and Y-axis coordinate of pass point on arc





When the X-axis and Y-axis is the moving axes, each axis in the above diagram is replaced.

# 7.2.2 Setting and Operation of 2-Axis Linear Interpolation

The example below is a case of E-point control with the positioning unit installed in slot 1. The X-axis is set to the 1st axis and the Y-axis is set to the 2nd axis. The movement amount setting is the increment method in pulses.



#### Settings

Items	Setting example
Operation pattern	E: End point
Interpolation operation	0: Linear (Composite speed)
Control method	I: Increment
X-axis movement	10000 pulses
X-axis auxiliary point	0
Y-axis movement	5000 pulses
Y-axis auxiliary point	0
Acceleration/deceleration method	L: Linear
Acceleration time (ms)	100 ms
Deceleration time (ms)	100 ms
Interpolation speed	10000 pps

#### Operation diagram



#### Operation of each contact

- The 1st axis and 2nd axis BUSY flags (X118 and X119) indicating the state that a motor is running will turn ON when the positioning control starts, and they will turn OFF when the operation completes.
- The 1st axis and 2nd axis operation done flags (X120 and X121) indicating the state that an operation completed will turn ON when the JOG operation is completed, and they will be held until the next positioning control, JOG operation, home return, or pulser operation starts.

#### Programming Precautions

- To start the interpolation control, turn ON the positioning start contact of the axis with the smallest number in the same group.
- The values of the X-axis auxiliary point and Y-axis auxiliary point are invalid for the linear interpolation.
- In the case of specifying long axis speed, the composite speed will be faster than the long axis speed.
- If any value such as a movement amount, acceleration time, deceleration time or target speed is out of the specified range, a set value error will occur when the positioning control starts.
- The start contact and flag number varies depending on the number of axes and the installation position of the unit.
- The specified slot number varies depending on the installation position of the unit.

# 7.2.3 Setting and Operation of 2-Axis Circular Interpolation

The example below is a case of E-point control with the positioning unit installed in slot 1. The X-axis is set to the 1st axis and the Y-axis is set to the 2nd axis. The movement amount setting is the increment method in pulses.



#### Settings

Use the tool software to make positioning data and parameter settings. The unit is set to pulse.

Items	Setting example
Operation pattern	E: End point
Interpolation operation	S: Circular (Pass point/CW direction)
Control method	I: Increment
X-axis movement	0 pulse
X-axis auxiliary point	0 pulse
Y-axis movement	20000 pulses
Y-axis auxiliary point	10000 pulses
Acceleration/deceleration pattern	L: Linear
Acceleration time (ms)	100 ms
Deceleration time (ms)	100 ms
Interpolation speed	10000 pps

#### Operation diagram



#### Operation of each contact

- The 1st axis and 2nd axis BUSY flags (X118 and X119) indicating the state that a motor is running will turn ON when the positioning control starts, and they will turn OFF when the operation completes.
- The 1st axis and 2nd axis operation done flags (X120 and X121) indicating the state that an operation completed will turn ON when the JOG operation is completed, and they will be held until the next positioning control, JOG operation, home return, or pulser operation starts.

#### Programming Precautions

- To start the interpolation control, turn ON the positioning start contact of the axis with the smallest number in the same group.
- In the case of the center point specification, the X-axis auxiliary point is the center point of Xaxis, and the Y-axis auxiliary point is the center point of Y-axis. In the case of the pass point, each pass point is set as the pass point of X-axis and Y-axis.
- When the control method is increment, both the center point and pass point will be increment coordinates from the start point.
- When the start point and the operation done point is the same, it performs one circular operation when using the center point method. However, when using the pass point method, an error will occur.
- In the case of the pass point method, when the start point, pass point, and operation done point exist in the same straight line, an arc will not be comprised and an error will occur.
- In the case of specifying long axis speed, the composite speed will be faster than the long axis speed.
- If any value such as a movement amount, acceleration time, deceleration time or target speed is out of the specified range, a set value error will occur when the positioning control starts.
- The start contact and flag number varies depending on the number of axes and the installation position of the unit.
- The specified slot number varies depending on the installation position of the unit.

# 7.2.4 Setting and Operation of 3-Axis Linear Interpolation

The example below is a case of E-point control with the positioning unit installed in slot 1. The X-axis is set to the 1st axis, the Y-axis is set to the 2nd axis, and the Z-axis is set to the 3rd axis. The movement amount setting is the increment method, and the unit is set to pulse.



#### Settings

Items	Setting example		
Operation pattern	E: End point		
Interpolation operation	0: Linear (Composite speed)		
Control method	I: Increment		
X-axis movement amount	10000 pulses		
X-axis auxiliary point	0		
Y-axis movement amount	5000 pulses		
Y-axis auxiliary point	0		
Z-axis movement amount	20000 pulses		
Z-axis auxiliary point	0		
Acceleration/deceleration pattern	L: Linear		
Acceleration time (ms)	100 ms		
Deceleration time (ms)	100 ms		
Interpolation speed	10000 pps		

#### Operation diagram



#### Operation of each contact

- The 1st axis, 2nd axis, and 3rd axis BUSY flags (X118, X119, and X11A) indicating the state that a motor is running will turn ON when the positioning control starts, and they will turn OFF when the operation completes.
- The 1st axis, 2nd axis, and 3rd axis operation done flags (X120, X121, and X122) indicating the state that an operation completed will turn ON when the JOG operation is completed, and they will be held until the next positioning control, JOG operation, home return, or pulser operation starts.

#### Programming Precautions

- To start the interpolation control, turn ON the positioning start contact of the axis with the smallest number in the same group.
- The values of the X-axis auxiliary point and Y-axis auxiliary point are invalid for the linear interpolation.
- In the case of specifying long axis speed, the composite speed will be faster than the long axis speed.
- If any value such as a movement amount, acceleration time, deceleration time or target speed is out of the specified range, a set value error will occur when the positioning control starts.
- The start contact and flag number varies depending on the number of axes and the installation position of the unit.
- The specified slot number varies depending on the installation position of the unit.

# 7.2.5 Setting and Operation of Three-Axis Linear Interpolation

The example below is a case of E-point control with the positioning unit installed in slot 1. The X-axis is set to the 1st axis, the Y-axis is set to the 2nd axis, and the Z-axis is set to the 3rd axis. The movement amount setting is the increment method, and the unit is set to pulse.



#### Settings

Items	Setting example
Operation pattern	E: End point
Interpolation operation	E: Spiral
	(Center/CW direction/Z-axis movement)
Control method	I: Increment
X-axis movement amount	0 pulse
X-axis auxiliary point	0 pulse
Y-axis movement amount	20000 pulses
Y-axis auxiliary point	10000 pulses
Z-axis movement amount	5000 pulses
Z-axis auxiliary point	0
Acceleration/deceleration pattern	L: Linear
Acceleration time (ms)	100 ms
Deceleration time (ms)	100 ms
Interpolation speed	10000 pps

#### Operation diagram



#### Operation of each contact

- The 1st axis, 2nd axis, and 3rd axis BUSY flags (X118, X119, and X11A) indicating the state that a motor is running will turn ON when the positioning control starts, and they will turn OFF when the operation completes.
- The 1st axis, 2nd axis, and 3rd axis operation done flags (X120, X121, and X122) indicating the state that an operation completed will turn ON when the JOG operation is completed, and they will be held until the next positioning control, JOG operation, home return, or pulser operation starts.

#### **Programming Precautions**

- For X-Y plane, in the case of the center point specification, the X-axis auxiliary point is the center point of X-axis, and the Y-axis auxiliary point is the center point of Y-axis. In the case of the pass point, each pass point is set as the pass point of X-axis and Y-axis. These settings are the same for Y-Z plane and X-Z plane.
- When the control method is increment, both the center point and pass point will be increment coordinates from the start point.
- When the start point and the operation done point is the same, it performs one circular operation when using the center point method. However, when using the pass point method, an error will occur.
- In the case of the pass point method, when the start point, pass point, and operation done point exist in the same straight line, an arc will not be comprised and an error will occur.
- In the case of specifying long axis speed, the composite speed will be faster than the long axis speed.
- If any value such as a movement amount, acceleration time, deceleration time or target speed is out of the specified range, a set value error will occur when the positioning control starts.
- The start contact and flag number varies depending on the number of axes and the installation position of the unit.
- The specified slot number varies depending on the installation position of the unit.

# 7.2.6 Sample Program (Interpolation Control)

An example of 3-axis interpolation control is shown below.

#### Sample program



# 7.3 Setting and Operation of Positioning Repeat Function

The positioning repeat function enables continuous positioning control according to the number of repetitions specified.

The number of repetitions is set in the area for the number of positioning repetitions on each axis. The number of repetitions can be set within a range of 2 to 254. It is possible to specify a limitless number of repetitions by setting 255 for the area of the number of positioning repetitions.

Outline of Positioning Repeat Function

The positioning unit operates as shown below in the case of repeating positioning control three times.



If a dwell time of 0 is set for E-point control, i.e., the end point of positioning control, the positioning unit will perform E-point control as P-point control, and complete positioning control after repeating positioning control three times continuously.



If the dwell time is set to a value other than 0 for E-point control, i.e., the end point of positioning control, the positioning unit will perform E-point control as C-point control, and repeat positioning control with a pause specified by the dwell time (ms).

The positioning unit will finish operating after repeating positioning control three times.



#### Setting area for positioning repeat function

Set the number of repetitions of positioning control per axis before starting positioning control. The positioning unit repeats positioning control for the number of repetitions set and finishes operating. The number of repetitions will be reset to the default value on completion of positioning control.

Unit memory no. (Hex)	Name	Description		Setting range	Set unit
UM 00108	Number of 1st axis positioning repetitions	Stores the number of repetitions starting from the starting table number of positioning control of the 1st axis until the E point. If 255 is stored, the positioning unit repeats positioning control an unlimited number of times until you manually stop the operation.		0 to 255	Times
UM 00109	Number of 2nd axis positioning repetitions	Stores the number of repetitions starting from the starting table number of positioning control of the 2nd axis until the E point. If 255 is stored, the positioning unit repeats positioning control an unlimited number of times until you manually stop the operation.	0	0 to 255	Times
UM 0010A	Number of 3rd axis positioning repetitions	Stores the number of repetitions starting from the starting table number of positioning control of the 3rd axis until the E point. If 255 is stored, the positioning unit repeats positioning control an unlimited number of times until you manually stop the operation.	0	0 to 255	Times
UM 0010B	Number of 4th axis positioning repetitions	Stores the number of repetitions starting from the starting table number of positioning control of the 4th axis until the E point. If 255 is stored, the positioning unit repeats positioning control an unlimited number of times until you manually stop the operation.	0	0 to 255	Times
UM 0010F	Number of virtual axis positioning repetitions	Stores the number of repetitions starting from the starting table number of positioning control of the virtual axis until the E point. If 255 is stored, the positioning unit repeats positioning control an unlimited number of times until you manually stop the operation.	0	0 to 255	Times

#### Interruption of repetitive positioning

The following operation will occur only if the positioning unit in repetitive positioning control is decelerated to stop.

#### • Repeating E-point control (with dwell time: 0 ms)

When the positioning unit detects a deceleration stop, the positioning unit will come to a stop after repeating positioning control N+2 times.



#### • Implementing a number of positioning tables continuously

When the positioning unit detects a deceleration stop, the positioning unit will come to a stop after repeating positioning control N+1 times.



The example below is a case of single-axis control with the positioning unit installed in the slot 1. The movement amount setting uses an increment method in pulses.



#### Settings

Itoms	Setting example			
items	Table 1	Table 2	Table 3	
Operation pattern	P: Pass point	P: Pass point	E: End point	
Control method	I: Increment	I: Increment	I: Increment	
X-axis movement amount	5000 pulses	10000 pulses	3000 pulses	
Acceleration/deceleration pattern	L: Linear	L: Linear	L: Linear	
Acceleration time (ms)	100 ms	200 ms	30 ms	
Deceleration time (ms)	10 ms	20 ms	150 ms	
Target speed	10000 pps	20000 pps	5000 pps	
Dwell Time (ms)	0 ms	0 ms	0 ms	
Number of positioning repetitions	3 (written to the setting a	area of the unit memory)		

#### Operation diagram



#### Operation of each contact

- The BUSY flag (X118), which indicates that the motor is running, will turn ON when the positioning control starts, and it will turn OFF when the operation completes.
- The operation done flag (X120), which indicates the completion of operation, will turn ON when the current operation is completed, and it will be held until the next positioning control, JOG operation, home return, or pulser operation starts.



# **8** Automatic Operation (Synchronous Control)

# 8.1 Synchronous Control

## 8.1.1 Outline of Synchronous Control

#### Synchronous control

The positioning unit in synchronous control operates a master axis so that salve axis will operate in synchronization with the master axis. The use of synchronous control provides the following merits.

#### 1. Ease of setting

A number of related axes can be operated with ease by designing the operation of the axes based on the master axis.

#### 2. Ensuring operational safety

If an axis comes to a stop for some reason while the positioning unit is in synchronous control, all the relevant axes under synchronous control will come to a stop. Therefore, you can easily increase the safety of the positioning unit.

#### Outline of Synchronous Control

The synchronous control provides the following functions. These functions are executed in order, and the slave axes operate according to the operation result of each function.

Functions	Outline
Electronic gear	The number of pulses multiplied by the preset electronic gear ratio is output according to the operation of the master axis.
Electronic clutch	The operation of the salve axes can be separated from the operation of the master axis by disengaging the clutch. (The slave axes do not operate.)
Electronic	A function to output pulses according to the preset cam pattern.
cam	Calculates the operation phase of the master axis and outputs cam pulses according to the phase.
	The cam pattern is set with a setting tool.

#### Execution Order of Synchronous Control and Setting Procedures

The following section provides information on the outline of functions achieved by synchronous control and setting procedures for the functions.


# 8.2 Settings for Master and Slave Axes

### 8.2.1 Selection of Master Axis and Settings

The master axis serves as a reference for synchronization control. Start and stop requests for various operations are made to the master axis under synchronous control. It is possible to select one of the following master axes.

#### Types of master axis

Туре	Outline					
	Axes (the 1st to 4th axes) available for the positioning unit.					
Existing axis	Use one of them if the master axis needs to be an object of control as well.					
	If an existing axis is used as the master axis, the rest of the existing axes (three axes) can be used as slave axes.					
	A virtual axis exists in the positioning unit.					
Virtual axia	The existing axes (1st to 4th axes) can be used effectively if the virtual axis is used.					
VIITUAI AXIS	The virtual axis cannot output pulses externally.					
	The virtual axis cannot receive any external input signals, either.					
	The master axis operates according to pulse value input into the positioning unit.					
Pulse input	Use pulse input in the case of connecting an external device, such as an encoder, for the reference of synchronous control.					
	In the case of using pulse input as the master axis, the slave axes will operate according to the pulse input. Therefore, be careful when starting or stopping the operation of the positioning unit.					

#### Types and restrictions of master axis

			Туре	
		Existing axis	Virtual axis	Pulse input
Home return		m	Available to data setting only.	No
JOG operation	n	Yes	Yes	No
	Single axis	Yes	Yes	No
Positioning	Interpolation	Yes	No Available to single axis only.	No
	System/Emergency/ Deceleration stop	Yes	Yes	No
Stop functions	Limit stop	Yes	Questionable Stops only with software limit because of no limit signal input.	No
	Error stop	Yes	Yes	No
Others			Necessary to make settings to use the virtual axis on the Configuration screen.	Synchronizes with external pulse input, and no master axis control is possible. To stop synchronous control, stop the slave axes.



## KEY POINTS

- While the positioning unit is in synchronous control, slave axes set to use the master axis will operate only in synchronization with the master axis, i.e., the slave axes cannot operate independently.
- The virtual axis is assigned to a single axis only. In the case of using the virtual axis, check the box for the virtual axis in the dialog box to set the operating axes on the Configurator PM7.
- The home return of the virtual axis is possible only by data setting.
- If pulse input is set for the master axis, the master axis will synchronize with pulse input from an external device, such as an encoder. Therefore, the master axis cannot be stopped arbitrarily.

## 8.2.2 Selection of Slave Axes and Settings

#### Selection of Slave Axes

- The 1st to 4th axes are available as slave axes. The virtual axis can be used only as the master axis.
- When "Synchronous master axis" is selected in the synchronous parameter dialog box of the Configurator PM7, the corresponding axis will operate as a salve axis for the specified master axis.

Up to four slave axes can be set for a single master axis.

Axes set as slave axes operate in synchronization with the master axis as long as synchronous control is enabled. No slave axes can perform positioning and other control independently from the master axis while synchronous control is enabled.

#### Settings for Slave Axes

The slave axes operate in synchronization with the master axis. Set the following items, however, for each individual salve axis.

- Unit setting
- Number of pulses per rotation
- Movement amount per rotation

## 8.2.3 Enabling/Disabling Synchronous Control

#### Settings to Enable/Disable Synchronous Control

- It is possible to cancel the synchronous state temporarily with a sync cancel request signal turned ON.
- It is possible to operate any slave axes individually while the synchronous state is canceled.
- The slave axes will go into the state of synchronization again with the sync cancel request signal turned OFF.

#### ■ I/O signal allocation

Signal name	1st axis	2nd axis	3rd axis	4th axis	Operation
Synchronous cancel request	Y88	Y89	Y8A	Y8B	ON: Cancel synchronous control; OFF: Execute synchronous control
Synchronous cancel alarm	X88	X89	X8A	X8B	ON: Synchronous control canceled; OFF: Under synchronous control

Operation request axis		Operates with syncl enable	hronous control ed	Operates with synchronous control disabled	
		Master axis set	Master/Slave axis set		
Home return		No The master axis performs a home return. The slave axes do not perform a home return but operate in synchronization with output from the master axis. To enable the slave axes to perform a home return, operate them with synchronous control disabled	No	Yes The master axis or slave axes will perform a home return only if the master axis or the slave axes are so requested.	
JOG operatior	1	Ves	not operate in	Yes	
	Single axis	The slave axes operate in synchronization with the operation request of the master axis.	response to operation requests.	The master axis or slave axes will go into JOG operation only if the master axis or the slave axes are so requested.	
Positioning	Interpolation	Yes Interpolation will be executed upon request if the master axis is the start axis of interpolation. The slave axes operate in synchronization with the master axis.		Yes Interpolation will be executed upon request if the requested axis is the start axis of interpolation.	
	System stop	All the axes come to a stop	hronization settings.		
Stop functions	Emergency stop Deceleration stop	Yes The master axis comes to a stop upon request. The slave axes come to a stop in synchronization with the master axis.	Yes Only axes requested come to a stop. The master axis and other salve axes set on the same master axis continue	Yes Only axes requested come to a stop. (All the axes in interpolation operation come to a stop.)	
	Limit stop	The master axis and all the	operating.	Only axes resulting in a limit error come to a stop.	
	Error stop	stop.		Only axes resulting in an error come to a stop.	

## ■ Difference between synchronous control enabled/disabled

# 8.3 Electronic Gear Function

## 8.3.1 Outline of Electronic Gear Function

#### ■ Electronic Gear Function

The electronic gear function operates the positioning unit at the speed of the master axis multiplied by a preset gear ratio.



#### ■ Cautions for using the electronic gear function.

The use of the electronic gear function makes it possible to set the slave axes to a desired speed relative to the master axis. The movement amount of the slave axes, however, is obtained from the following formula. Therefore, the movement amount of the master axis does not coincide with that of the slave axes.

Movement amount of slave axes = Movement amount of master axis x (gear ratio numerator/Gear ratio denominator)

* On the condition that the gear ratios are constant.

Do not use the electronic gear function if the movement amount of the master axis needs to coincide with that of the salve axes.



Keep in mind that the slave axes may come to a sudden stop if an emergency stop or deceleration stop is executed while making a gear ratio change.

# 8.3.2 Types and Contents of Setting Parameters

Parameter name	Outline
	Set to use or not to use the electronic gear function.
Electronic gear operation settings	The gear ratio of the electronic gear will be set to 1:1 if the electronic gear is not used, and the operation of the master axis will be input as it is into the electronic clutch.
Gear ratio numerator	Determines the gear ratio of the electronic gear.
	Electronic gear ratio is determined by the following formula.
Gear ratio denominator	Output speed of electronic gear = Operating speed of master axis x (Gear ratio numerator/Gear ratio denominator)
Gear ratio change time	The time required to change the current gear ratio to a new gear ratio if the new gear ratio is set for the electronic gear in operation.

The use of the electronic gear requires the following parameter settings.

# 8.3.3 Gear Ratio Changes while in Operation

#### ■ Precautions for gear ratio changes while the positioning unit is in operation

- If the gear ratio is changed with a new gear ratio while the electronic gear is in operation, the new gear ratio will be effective with an elapse of a preset gear change time.
- If the gear ratio change time is 1, the gear ratio will be changed at an acceleration/deceleration time of 0.
- Acceleration or deceleration during the gear ratio change results in linear acceleration or deceleration. S-shaped acceleration or deceleration cannot be used.



#### Programming

Follow the procedure below and write a user program in the case of changing the gear ratio while the positioning unit is in operation.

#### 1. Change the gear ratio.

Change the gear ratio numerator and denominator of the electronic gear in the setting area for the electronic gear.

The gear ratio at the time of starting the positioning unit is set for this area. It is recommended to save the initial gear ratio before change so that the initial gear ratio can be reused with ease.

#### 2. Turn ON the gear ratio change request contact.

Turn ON an I/O signal (electronic gear ratio change request) for the target axis allocated to the unit.

This signal enabled is of edge type. Starts the gear ratio change triggered by the gear ratio change request signal turned ON.

#### ■ I/O allocation

Signal name	1st axis	2nd axis	3rd axis	4th axis
Synchronous slave axis gear ratio change request	Y90	Y91	Y92	Y93
Synchronous slave axis gear ratio change request	X90	X91	X92	X93

Turn OFF the gear ratio change request signal after changing the gear ratio.



# REFERENCE

For detailed information on the gear ratio setting area, refer to 17.7.1 Synchronous Control Setting Area.

# 8.4 Electronic Clutch Function

## 8.4.1 Electronic Clutch Function

The electronic clutch function is used to engage or disengage the clutch for output from the electronic gear. When the electronic clutch is disengaged, the master axis will be separated from the slave axes and the slave axes not in synchronization with the master axis will come to a stop. When the electronic clutch is engaged, the master axis and slave axes will operate in synchronization.



Keep in mind that the slave axes may come to a sudden stop if the clutch is disengaged while making a gear ratio change.

# 8.4.2 Types and Contents of Setting Parameters

The use of the electronic clutch requires the following parameter setting	igs.
---------------------------------------------------------------------------	------

Pa	rameter name	Outline					
		Set to use or not to use the electronic clutch function.					
		The electronic clutch is by default disengaged.					
Electronic clutch used/unused		Be sure to engage the electronic clutch in response to the operation.					
Electronic	ciulon usea/unusea	The electronic clutch will be always engaged when the electronic clutch is not in use, in which case, output data from the electronic gear will be input as it is into the electronic cam. At that time, the master axis will always operate in synchronization with the slave axes.					
	Trigger type	Set an I/O clutch ON request as a trigger to be detected.					
Clutch	Edge selection	Select the method of trigger signal detection from "Level," "Rising edge," or "Falling edge."					
ON	Method	Select "Direct" or "Slip" for the engagement of the clutch.					
	Slip time	If "Slip" is selected, set the slip time.					
	Trigger type	Set an I/O clutch OFF request as a trigger to be detected.					
Clutch	Edge selection	Select the method of trigger signal detection from "Level," "Rising edge," or "Falling edge."					
UFF	Method	Select "Direct" or "Slip" for the engagement of the clutch.					
	Slip time	If "Slip" is selected, set the slip time.					

Phone: 800.894.0412 - Fax: 888.723.4773 - Web: www.ctiautomation.net - Email: info@ctiautomation.net

# 8.4.3 Trigger Types for Electronic Clutch

The following methods are available for the engagement or disengagement of the electronic clutch.

#### ■ Clutch request signal (Y98 to Y9B and Y100 to Y103)

An I/O signal (clutch request signal) allocated to the unit is in control of the electronic clutch.

#### ■ I/O allocation

Signal type	1st axis	2nd axis	3rd axis	4th axis	Operation
Slave axis clutch ON request	Y98	Y99	Y9A	Y9B	
Slave axis clutch OFF request	Y100	Y101	Y102	Y103	
Slave axis clutch operation notice	X98	X99	X9A	X9B	ON: Engaged; OFF: Disengaged



(Note): The above shows an example of the direct method selected for the engagement of the clutch.

## 8.4.4 Engagement Methods of Electronic Clutch

The electronic clutch function engages the clutch to start operating the slave axes and disengages the clutch to stop operating the slave axes, the acceleration or deceleration of the slave axes can be set as shown below.

#### Direct method

This method detects the engagement or disengagement of the clutch to adjust the operating speed of the master axis to coincide with that of the slave axes. In the direct method, the speed of the slave axes with the clutch engaged or disengaged coincides with the operating speed of the master axis with the acceleration and deceleration time set to 0.



#### Slip method

This method detects the engagement or disengagement of the clutch and set the slip time to acceleration time and deceleration time so that the operating speed of the slave axes to follow the operation speed of the master axis. Linear acceleration and deceleration will apply.



# 8.5 Electronic Cam Function

## 8.5.1 Outline of Electronic Cam Function

#### Electronic cam function

The electronic cam function uses a preset cam pattern, determines the movement amount of the slave axes according to the operation of the master axis (phase information) and cam pattern, and outputs the movement amount. The cam pattern uses one rotation of the master axis as an operation reference, based on which the displacement of the slave axes in each phase (rotation angle) is defined on the Configurator screen.



#### Cam pattern

The cam pattern uses one rotation of the master axis as an operation reference, based on which the displacement of the slave axes in each phase (rotation angle) is defined. The cam pattern is defined with the phase (rotation angle) of the master axis based on one rotation as a reference on the X-axis and the displacement on the Y-axis in percent. The cam pattern is set with the desired settings for the positioning unit selected from the FPWIN GR7 Configuration screen.



#### Cam pattern specifications

Setting items	Description
Resolution	1024, 2048, 4096, 8192, 16384, 32768
	Resolutions of 1024, 2048, and 4096: 16
No. of com pattorns	Resolution of 8192: 8
No. of call patients	Resolution of 16384: 4
	Resolution of 32768: 2
Section setting	100%/cycle, 20 sections max.
Displacement setting	100% setting
	Selected from the following ones
Cam curve	Uniform velocity/Constant acceleration/Simple harmonic motion/Cycloid/Modified trapezoid/Modified sine/Trapecloid One-dwell cycloidal m=1/One-dwell cycloidal m=2/3/One-dwell modified trapezoid m=2/3/One-dwell modified trapezoidal (Ferguson)/One-dwell modified sine/One-dwell trapecloid/No-dwell modified trapezoid/NC2 curve/Asymmetric cycloid/Asymmetric modified trapezoid
Adjustment function	Function to adjust the displacement of desired point data.
Adjustment function	1,000 points max. (in units of cam data)
Shift function	Phase shift in created cam data
	0% to 100%
Indication	Displacement/Speed/Acceleration/Jerk
mulcation	A check box allows desired display.

The following specifications of cam patterns can be set.

## 8.5.2 Types and Contents of Setting Parameters

The use of the electronic cam requires the following parameter settings.

Parameter name	Outline
Electronic com	Select the use or non-use of the electronic cam function.
use/non-use	When the electronic cam is not used, the electronic cam function will not work, and output from the electronic clutch will be output as pulses.
	The cam pattern is the most fundamental setting for using the electronic cam function.
Cam pattern	The cam pattern is set in the cam pattern settings window in the FPWIN GR7 Configuration screen.
	The positioning unit converts cam patterns into point data based on the preset cam curves and resolutions.
Cam control master axis period	Set the number of pulses corresponding to the total phase of the cam pattern used (one-rotation data on the master axis).
Cam pattern number to use	Specify the cam pattern number to be used from cam patterns created.
Cam stroke	Set the number of pulses corresponding to the total displacement (100%) of the cam pattern to use.

# 8.5.3 Cam Pattern Setting Method

#### Starting Cam Pattern Setting Screen

Open the Configuration screen on the FPWIN GR7 and select "Positioning settings" so that the setting tool for the positioning unit will start.

Select "Axis settings" - "Cam pattern settings" from the toolbar of the setting tool for the

positioning unit or click the following icon: The Cam Pattern Settings screen is displayed.

A blank screen will be displayed for a new file and settings for cam pattern 1 will be displayed if data already exists.

iolution 16384	-	Number of can		Number of a	vettable data	0000	φ.	∕ Displa	-	. Spee	<b>г</b> ^	Accelera	□ Junp
	1000				12.10.1	-	-		_	_			_
Add	1000												
inter .													
picen		Anner and the second		1					1			1	
	- 6												
				1		····						1	
	-												
	-100K	N					50		-			1	1
nul In		abar Print ab	and the late	-		1973				-			
reet.	erva nu	nber   Start ph	ise (%)]	und private (1	of Displac	sement (%)	CAR	orve	1-1				
data													
9/t													
dut													
									-				

#### Resolution settings

Press the [Resolution] button on the Cam Pattern screen. The Resolution Settings screen will be displayed. Select the desired resolution and press the [OK] button.





## **KEY POINTS**

- The resolution is valid for all cam patterns. You cannot set a different resolution per cam pattern.
- The number of cam patterns available varies with each resolution. The current resolution cannot be changed to a new resolution if the number of cam patterns already set exceeds the number of cam patterns available for the new resolution. Delete the cam pattern and change the resolution.



#### Making/duplicating new cam pattern

The Cam No. Selection screen is displayed by pressing the [Add] button from the Cam field. Select the desired cam number and press the [OK] button.

Add new cam	×
Cam No.	1
	OK Cancel

The cam pattern can be copied. Press the [Duplicate] button and select the copying destination and original cam pattern numbers.

Duplicate cam
Duplication source: 2 Duplication destination:
OK Cancel

To change the cam number, press the [Change] button and select the new cam number.



Note) The cam pattern number already set cannot be changed.

#### Making/duplicating new cam pattern

Set a cam pattern.

Press the [Insert] button from the Interval field. Select the desired starting phase and press the [OK] button.

The cam pattern is by default set to a single section at a phase of 0% to 100%.

The above section is divided into a number of sections by setting the starting phase.

Insert interval	
Settable range	(0.000% to 99.902%)
Start	40 %
	OK Cancel

The selected sections are displayed with a white background and the non-selected sections are displayed with a gray background.



NOTE

In relation to the resolution, the starting phase may not be set to the specified phase value.

#### Editing of the cam table

Edit the cam table data that was created.

Set the following items for each section set:

- Starting phase (%)
- Displacement (%)
- Cam curve

The cam curve changes according to the settings.





#### **KEY POINTS**

- The termination phase cannot be set. The termination phase will be changed automatically if the staring phase is changed.
- Do not make a radical displacement change of set cam curves. There is a
  possibility that the motor cannot keep up with the output in the case of
  rapid displacement.
- Similarly, make settings that a phase of 0% and that of 100% are the same in displacement.

#### Cam table checks

Check the cam table (cam curve) that has been set. The slave axes in synchronous control operate to follow the cam curve cam. Therefore, there will be a possibility that the motor cannot follow the output if the change in the cam curve is steep. In addition, it is important to know information on the acceleration as well as the displacement of the cam as factors affecting the change of the cam curve. The Cam Table Settings screen can display information on the following items besides the displacement.

Display item	Outline
Displacement	An item set on the cam table.
Speed	The operating speed of the cam table for the amount of displacement that has been set is displayed.
	The relative value is displayed.
Acceleration	The acceleration in each phase is displayed.
	Pay attention to points of significant acceleration changes, which involve radical speed changes.
Jerk	Jerk, which is obtained from acceleration differentiated by time, represents the rate of change of acceleration.

Each display item is set by checking the following boxes in the Cam Table Settings screen. Refer to each display item and make setting changes in the cam table.



#### Cam table adjustments

The Cam Table settings screen is provided with a function to make the fine-tuning of set cam curve data. In order to mitigate radical changes, this adjustment function makes it possible to fine-tune cam data that has been set. To make adjustments, select the target section number and press the [Adjust] button. The adjustment screen is displayed. The Adjustment screen displays the tables corresponding to the numbers of the designated sections out of all the sections (0% to 100%) divided by the resolution.

Adjust cam	curve		×
Phase	Control point	Displacement	•
60.0097656	19664	-40.0000000	
60.0128174	19665	-39.9923289	
60.0158691	19666	-39.9846579	
60.0189209	19667	-39.9769868	
60.0219727	19668	-39.9693157	
60.0250244	19669	-39.9616447	
60.0280762	19670	-39.9539736	
60.0311279	19671	-39.9463025	
60.0341797	19672	-39.9386315	
60.0372314	19673	-39.9309604	
60.0402832	19674	-39.9232894	
60.0433350	19675	-39.9156183	
60.0463867	19676	-39.9079472	
60.0494385	19677	-39.9002762	
60.0524902	19678	-39.8926051	
60.0555420	19679	-39.8849340	
60.0585938	19680	-39.8772630	
60.0616455	19681	-39.8695919	
60.0646973	19682	-39.8619208	
60.0677490	19683	-39.8542498	
60.0708008	19684	-39.8465787	
60.0738525	19685	-39.8389076	
60.0769043	19686	-39.8312366	
60.0799561	19687	-39.8235655	
60.0830078	19688	-39.8158944	-
4		Þ	
Clear adjustme	ents (	OK Cano	el

Select the data on the target phases (control points) and change the corresponding displacement data. The adjustments will be reflected by selecting [OK] and the set adjustment data will be cleared by selecting [Adjustment clear]. The numbers of the adjusted sections where the cam curve adjustments have been made are displayed in red, which tells that the adjustments have been completed.

Interval number	Start phase (%)	End phase (%)	Displacement (%)	Cam curve	•	
1	0.0000000	39.9414063	50.0000000	Cycloid		
2	39.9414063	60.0097656	-40.0000000	Modified sine		Adjusted data
3	60.0097656	79.8828125	10.0000000	Trapecloid		(displayed in red)
4	79.8828125	0.0000000	0.0000000	One-dwell trapecloid		(displayed in red)

#### Cam table shift

The created cam pattern is defined with a phase of 0% to 100%, but the actual operation may differ in phase from the reference of the cam pattern. The cam table shift is a function to set the percentage of the created cam pattern for the phase at a current coordinate position of zero.

#### Shift image of electronic cam



Select the shift from "Interval" and set the shift amount.

Settable range (0.0	00% to 99.9	97%)
Phone shift	10.001	46
Phase shift	1000000	79

The created cam pattern is shifted 10% and the display is updated.



Display example: The shift is set to 10%.

#### Cam table saving

The created cam table is saved automatically by pressing the [OK] button in the Cam Table Settings screen. Cam table stored is managed by FPWIN GR7 and set for the positioning unit when it is downloaded to the CPU module.

# **9** Manual Operation (JOG Operation)

# 9.1 Setting and Operation of JOG Operation

The example below is a case of the positioning unit installed in the slot 1. Settings are made in pulses.



#### Settings

Parameters required for the JOG operation of the positioning unit is set in the positioning setting menu of the programming tool.

Items	Setting example
Acceleration/deceleration pattern	0: Linear acceleration/deceleration
Acceleration time (ms)	100 ms
Deceleration time (ms)	100 ms
Target speed	10000 pps

#### Operation diagram



#### Operation of each contact

- The BUSY flag (X118), which indicates that the motor is running, will turn ON when the positioning control starts, and it will turn OFF when the operation completes.
- The operation done flag (X120), which indicates the completion of operation, will turn ON when the current operation is completed, and it will be held until the next positioning control, JOG operation, home return, or pulser operation starts.

#### Sample program



#### Programming Precautions

- The start contact and flag number varies depending on the number of axes and the installation position of the unit.
- The specified slot number varies depending on the installation position of the unit.

	mit input		
Condition	Direction	Limit status	Operation
When JOG	Forward rotation	Limit input (+):ON	Not executable, Error occurs.
operation is executed		Limit input (-):ON	Executable
	Reverse rotation	Limit input (+):ON	Executable
		Limit input (-):ON	Not executable, Error occurs.
During JOG operation	Forward rotation	Limit input (+):ON	Deceleration stop, Error occurs.
	Reverse rotation	Limit input (-):ON	Deceleration stop, Error occurs.

#### Operation at limit input

# 9.2 Changing the Speed During JOG Operation

The target speed can be changed while the positioning unit is in JOG operation.

#### Settings

Parameters required for the JOG operation of the positioning unit is set in the positioning setting menu of the programming tool.

Items	Setting example			
Acceleration/deceleration pattern	0: Linear acceleration/deceleration			
Acceleration time 1 (ms)	100 ms			
Deceleration time 1 (ms)	50 ms			
Target speed 1	10000 pps			
Acceleration time 2 (ms)	200 ms	The set values of acceleration time, deceleration time, and		
Deceleration time 2 (ms)	150 ms	target speed after the speed change are		
Target speed 2	20000 pps	written to the unit memory by the program.		

#### Operation diagram



#### Operation of each contact

- The BUSY flag (X118), which indicates that the motor is running, will turn ON when the Jog operation starts, and it will turn OFF when the operation completes.
- The target speed can be changed freely while the positioning unit is in JOG operation. Use a program to change the target speed.
- The operation done flag (X120), which indicates the completion of operation, will turn ON when the current operation is completed, and it will be held until the next positioning control, JOG operation, home return, or pulser operation starts.

#### Sample program



#### Programming Precautions

- To change the JOG operation speed, use a user program and rewrite the unit memory (UM0082A to UM0082C).
- The start contact and flag number varies depending on the number of axes and the installation position of the unit.
- The specified slot number varies depending on the installation position of the unit.

# **10** Manual Operation (Home Return)

# 10.1 Pattern of Home Return

The home return is a function to move the current position to the reference origin and set the coordinates as 0.

The following home return methods are available for the positioning unit.

# DOG method 1 (Edge detection of near home switch + First rising edge of home position as reference)

The first rising edge of home position switch is detected after detecting the rising edge of the near home switch. It becomes the start point.



#### ■ DOG method 2 (Edge detection of near home switch)

The rising edge of the near home switch is detected. It becomes the start point.



#### DOG method 3 (Edge detection of near home switch + Falling edge of home position as reference)

The falling edge of the near home switch is detected. The first rising edge of the home switch in the home return direction becomes the start point.



#### Limit method 1 (Edge detection of limit switch + First rising edge of home position as reference)

Reverses after detecting the rising edge of the limit switch on the opposite side of the home return direction. The first rising edge of the home switch is detected. It becomes the start point.



#### ■ Limit method 2 (Edge detection of limit switch)

Detects the rising edge of the limit switch in the home return direction and stops. That point becomes the start point.



#### ■ Home position method (Edge detection of home switch)

Moves from the current position in the home return direction, and detects the first rising edge of the home switch and stops. That point becomes the start point.



#### Data Set Method

The current value is considered as the origin.



# 10.2 Setting and Operation of Home Return

The example below is a case of the positioning unit installed in the slot 1. Settings are made in pulses.



## Settings

Parameters required for the home return operation of the positioning unit is set in the positioning setting menu of the programming tool.

Items	Setting example
Return setting code	0: DOG method 1
Return direction	0: Limit (-) direction
Acceleration time (ms)	100 ms
Deceleration time (ms)	100 ms
Target speed	10000 pps
Return creep speed	1000 pps
Deviation counter clear signal ON time	1 ms

## Operation diagram



#### Operation of each contact

- The BUSY flag (X118) indicating the state that a motor is running will turn ON when the home return of the positioning unit starts, and it will turn OFF when the operation completes.
- The deviation counter clear signal will turn ON during the ON time of the deviation counter clear signal on completion of the home return.
- The home return done flag (X128) indicating the state of operation completion will turn ON when the home return operation is completed, and it will be held until the next positioning control, JOG operation, home return, or pulser operation starts. The timing of that the flag turns ON is at the time that the home return operation is completed.

#### Sample program



#### Programming Precautions

- The start contact and flag number varies depending on the number of axes and the installation position of the unit.
- The specified slot number varies depending on the installation position of the unit.

Condition	Direction	Limit status	Operation
When Home return	Forward rotation	Limit input (+):ON	Executable
operation is executed		Limit input (-):ON	Executable
	Reverse rotation	Limit input (+):ON	Executable
		Limit input (-):ON	Executable
During Home	Forward rotation	Limit input (+):ON	Automatic reverse operation
return operation	Reverse rotation	Limit input (-):ON	Automatic reverse operation

#### Operation at limit input

# **11** Manual Operation (Pulser Operation)

# 11.1 Setting and Operation of Pulser Operation

#### Types of Pulser Operation

Pulser operation is a function that uses a pulser connected to the positioning unit to output pulses manually.

The following pulser operation methods are available.

Operation method	Operation
Standard operation	Obtains the number of pulser pulses in 1-ms units and operates.
	Reflects the content of pulse input directly in the actual operation of the positioning unit.
Speed limits (pulses hold)	When the speed of pulse input exceeds the preset maximum speed, the operation will continue with the maximum speed maintained.
	The number of pulser pulses input will be maintained. Therefore, pulses not output will be maintained. Therefore, pulses may be output even if there is no pulser input.
	Speed unit is "Set unit x 1000/s".
Speed limits (Truncate)	When the speed of pulse input exceeds the preset maximum speed, the operation will continue with the maximum speed maintained.
	Pulses are output in synchronization with the operation of the pulser while pulses not output are discarded.
	Speed unit is "Set unit x 1000/s".



The example below is a case of the positioning unit installed in the slot 1. Settings are made in pulses.


#### Settings

Parameters required for the pulser operation of the positioning unit is set in the positioning setting menu of the programming tool.

Items	Setting example	Settable range
Operation setting code	0: Pulser 1	0: Pulser 1 1: Pulser 2 2: Pulser 3 3: Pulser 4
Pulser operation ratio numerator	2	1 to 32,767
Pulser operation ratio denominator	1	1 to 32,767
Pulser exerction method	2: Speed limits	0: Standard operation 1: Speed limits (pulse hold)
Puiser operation method	(truncated)	2: Speed limits (truncated)
Pulser operation max. speed	500	Pulse: 1 to 32,767,000 pps

### Operation diagram



### Operation of each contact

- The BUSY flag (X118) indicating the state that a motor is running will turn ON when the pulser operation permit contact turns ON and will turn OFF when the contact turns OFF.
- The operation done flag (X120) indicating the state of operation completion will turn ON when the pulser operation permit contact is turned OFF and the flag will be maintained until the next positioning control, JOG operation, home return, or pulser operation starts.

#### Manual Operation (Pulser Operation)

#### Sample program



#### Programming Precautions

- The movement amount per an 1-pulse signal from the pulser can be changed by setting the ratio numerator and ratio denominator for the input signal of the pulser.
- The start contact and flag number varies depending on the number of axes and the installation position of the unit.
- The specified slot number varies depending on the installation position of the unit.

#### Operation at limit input

Condition	Direction	Limit status	Operation
When Pulser	Forward rotation	Limit input (+):ON	Not executable, Error occurs.
operation is executed		Limit input (-):ON	Executable
checkled	Reverse rotation	Limit input (+):ON	Executable
		Limit input (-):ON	Not executable, Error occurs.
During Pulser	Forward rotation	Limit input (+):ON	Deceleration stop, Error occurs.
operation	Reverse rotation	Limit input (-):ON	Deceleration stop, Error occurs.

# **12** Stop functions

# **12.1 Settings and Operations of Stop Functions**

Following stop functions are available during operations. Each deceleration time can be set individually. Set the deceleration time according to each occurrence condition of the stop operation.

Name	Occurrence condition	Stop axis	Stop
Deceleration stop	Deceleration stop contact turns ON	Each axis	Stops control with an elapse of deceleration time.
Pause	Deceleration stop contact turns ON	Each axis	Stops control with an elapse of deceleration time, and resume control upon cancellation of the deceleration stop.
Emergency stop	Emergency stop contact turns ON	Each axis	Stops with an elapse of emergency stop deceleration time.
Limit stop	Limit switch input turns ON	Each axis	Stope with an elence of limit stop
Software limit stop	When exceeding the range of the software limit	Each axis	deceleration time.
Error stop	An error occurs	Each axis	Stops with an elapse of error stop deceleration time.
System stop	System stop contact turns ON	All axes	All axes stop without deceleration time.

The deceleration stop, pause, emergency stop, and system stop will be enabled when the respective request contacts in the I/O area turn ON. The stop state will be enabled while each contact is ON and maintained until each request signal is turned OFF. No operation is possible while the positioning unit is in the stop state.

Refer to the following table for the stop by turning contacts ON. It indicates the allocated I/O when the positioning unit is installed in the slot 1.

Contact allocation	Target axis	Name	Description
Y100	All axes	System stop	Contact for requesting the system stop. When it turns ON, all axes will stop at the deceleration time 0.
Y130	1st axis		Requests the emergency stop of the corresponding axis.
Y131	2nd axis		The deceleration time for the emergency stop is set in the
Y132	3rd axis	Emergency stop	emergency stop deceleration time area in the unit memory.
Y133	4th axis		(The operation is of level type.)
Y137	Virtual axis		Note) The deviation counter cannot be cleared.
Y138	1st axis		Requests the deceleration stop of the corresponding axis.
Y139	2nd axis	Deceleration	The deceleration stop time becomes the deceleration time of the
Y13A	3rd axis		positioning unit in operation.
Y13B	4th axis	5100	(The operation is of level type.)
Y13F	Virtual axis	1	Note) The deviation counter cannot be cleared.

# **12.2 Settings and Operations of Pause Functions**

The pause function temporarily stops operation. Toggle between the pause function and the deceleration stop function for use.

The pause function performs a deceleration stop in the deceleration time of operation when the deceleration stop request contact turns ON. After that, the stop state will be maintained while the deceleration stop request contact is ON, and the control stopped will restart when the deceleration stop request contact turns OFF.

Toggle between the pause function and deceleration stop function in the system operation setting area in the unit memory.

Unit memory no. (Hex)	Name	Description
no. (Hex)	Deceleration stop operation	<ul> <li>Description</li> <li>Specify the operation of the positioning unit with the deceleration stop request signal activated (turned ON).</li> <li>0: Deceleration stop While the positioning unit is in repetitive control, the positioning unit will come to a stop after the position moves to E point of the repetitive target. <ol> <li>Pause</li> <li>Performs a deceleration stop, and positioning will restart when the deceleration stop request signal is canceled (turned OFF).</li> <li>The positioning unit will perform the same operation as a deceleration stop unless the positioning unit is in positioning operation.</li> </ol></li></ul>
		<ul> <li>While the positioning unit is in repetitive operation, the positioning unit will come to a stop after the position moves to the E point of the repetitive target, and repetitive control will restart when the deceleration stop request signal is canceled (turned OFF).</li> <li>If a system stop or emergency stop is executed while the positioning unit is paused, the pause state will be canceled and the operation will not restart with the deceleration stop request signal is canceled (turned OFF).</li> </ul>
		Default: 0

#### System operation setting area



#### NOTES

- No deceleration stop can be executed while the pause function is in use. Use the emergency stop function in the case of executing a stop while the pause function is in use.
- The pause function is enabled only when the positioning unit is in automatic operation (positioning control). There will be no difference in operation from a deceleration stop while the positioning unit is in manual operation.

- Like other stop functions, the pause function will maintain the stop state while the deceleration stop (pause) request signal is ON. The pause will be canceled if an emergency stop or system stop is executed while the positioning unit is not operating, and the positioning unit will go into the emergency stop or system stop state.
- Switch the operation of the pause function by rewriting the value in the above unit memory address.

Phone: 800.894.0412 - Fax: 888.723.4773 - Web: www.ctiautomation.net - Email: info@ctiautomation.net

# **13** Supplementary Functions

# 13.1 Dwell Time

The time taken until the next operation after the completion of an executed positioning table in the automatic operation is called dwell time.

#### ■ For E-point control

The dwell time is the time taken from the completion of the position reference until the operation done flag turns ON.



#### ■ For P-point control

While the positioning unit is in P-point control, the positioning table will operate consecutively, and the dwell time will be ignored. For the last table (E point), like E-point control, dwell time is a period required from the completion of the position reference until the operation done flag turns ON.



#### For C-point control

The dwell time is the waiting time for executing the next table from the completion of the positioning table (deceleration stop). For the last table (E point), like E-point control, dwell time is a period required from the completion of the position reference until the operation done flag turns ON.



# 13.2 Software Limit

The system is designed to mechanically set the limit (+) and limit (-) to restrict the moving range of a motor.

Separately from the mechanical limits (+) and (-), the software limit is a function to add the limits for the absolute coordinate managed within the positioning unit. As the software limit is a function for the protection of the motor and AMP, it is recommended to set them to the values within the range of the mechanical limits (+) and (-) as below.



If the operating range of the motor exceeds the setting range of the software limit (upper and lower limit values), an error will occur, and the deceleration stop will be executed. It is necessary to clear the error and move the motor into the range of the software limit using an operation such as JOG operation after the stop.



Whether the software limit enabled or disabled can be specified individually for the positioning control, JOG operation, and home return operation. For example, it is possible to disable the limit software only in home return operation.

# **13.3 Auxiliary Output Code and Auxiliary Output Contact**

The auxiliary output contact is a function to announce externally which table is in operation when the automatic operation (E-point control, C-point control, P-point control, and J-point control) is executed.

The auxiliary output contact and auxiliary output code are available by setting parameter auxiliary output to With mode or Delay mode on an axis-by-axis basis.

#### ■ Auxiliary output contact

The auxiliary output contact operates either in With mode or Delay mode.

Auxiliary output mode	Operation
With mode	When the automatic operation starts, the auxiliary contact flag of the corresponding axis allocated to I/O will turn ON.
Delay mode	The auxiliary contact flags for corresponding axes allocated to the I/O area will turn ON according to the ratio of positioning movement (%) while the positioning unit is in automatic operation.
	The turn ON ratio while the positioning unit is in Delay mode is set in the Delay ratio area of auxiliary output in the unit memory.
	There will be no difference between the With mode and Delay mode in operation if J-point control is set for the automatic operation of the positioning unit.

The ON time of the auxiliary contact flag can be specified in ms increments.



#### NOTE

There will be no difference between the Delay mode and With mode in operation while the positioning unit is in J-point control.

#### Auxiliary output data

The auxiliary output data (1 word) can be set for each table of the positioning data. The content of the process currently carried out can be confirmed by setting auxiliary output.

The values in the auxiliary output data are held until the next positioning table is executed. The auxiliary output data that was output just before the completion of the automatic operation is held.





Auxiliary output data will maintain the value regardless of the type of auxiliary output mode (the with mode or delay mode) until the next positioning table is executed.

# 13.4 Current Value Update

The current value update function is a function to change the current value controlled by the positioning unit to a desired (preset) value.

Refreshing the current value requires data writing to the unit memory.

#### ■ Current value update area (Unit memory)

Unit memory no. (Hex)	Name	Description			
		Only when the corresponding bit for each axis changes to 1 from 0, the current coordinate controlled by the positioning unit to the following current value. After the change, the positioning unit will clear the corresponding			
		bit	Name	Default	Description
UM 000C0	Current value update	0	Current value update request for 1st axis	0	0: No change 1: Changes the
	request flag	1	Current value update request for 2nd axis	0	corresponding coordinate origin.
		2	Current value update request for 3rd axis	0	(After change, the positioning unit clears
		3	Current value update request for 4th axis	0	the corresponding bits to 0 automatically.)
		15 to 4	-	-	-
UM 000C8	Current value update	Current value update coordinate to be preset as the current value of 1st axis.			ant value of tot ovia
UM 000C9	coordinate of 1st axis				ent value of 1st axis.
UM 000CA	Current value update	Stores the	coordinate to be preset	as the curr	ont value of 2nd axis
UM 000CB	coordinate of 2nd axis	Stores the coordinate to be preset as the current value of 2nd axis.			
UM 000CC	Current value update	Other a the example of the her example of the surrent value of Out out			ont value of 2rd axis
UM 000CD	coordinate of 3rd axis	Stores the coordinate to be preset as the current value of 3rd axis.			
UM 000CE	Current value update	Others the second sets to be report on the surrent value of the sets			ant value of 4th avia
UM 000CF	coordinate of 4th axis	Stores the coordinate to be preset as the current value of 4th axis.			
UM 000D6	Current value update	Stores the appreliants to be present on the surrent value of with a lowing			ent value of virtual axis
UM 000D7	coordinate of virtual axis	Siones the coordinate to be preset as the current value of Virtual axis			

#### Current value update procedure

- 1. Write a coordinate to be preset in the current value update coordinate area of the axis to update the current value.
- 2. Preset the target axis bit to 1 in the current value update request flag area. As the current value update process is performed for the axis that is 1 in the current value request flag area, do not set any bit to 1 other than the target axis.
- 3. The current value after unit conversion in each axis information and monitor area is changed to the specified current value.

# NOTE

The value to be changed by updating the current value is the current value after unit conversion.

# 13.5 Coordinate Origin

The positioning unit performs a home return to set the managing coordinate to 0.

The coordinate origin is a function that allows to set the coordinate to a desired value after home return processing.

#### ■ Coordinate origin processing procedure

- 1. Write an coordinate to be the home in the home coordinate area of the target axis for which the coordinate is to be changed after a home return.
- 2. Execute the home return process. After the completion of the home return, the coordinate specified in the above 1 will become the home position.

Unit memory no. (Hex)	Name	Default	Setting range and description
UM 0084A	Coordinate origin of 1st ovic		
UM 0084B	Coordinate origin of 1st axis		
UM 0304A	Coordinate origin of 2nd avia		
UM 0304B	Coordinate origin of 2nd axis		
UM 0584A	Coordinate origin of 2rd ovin		Stores the value of coordinate origin after the home
UM 0584B	Coordinate origin of Sid axis	-	return.
UM 0804A	Coordinate origin of 4th avia		
UM 0804B	Coordinate origin of 4th axis		
UM 1204A	Coordinate origin of virtual axis		
UM 1204B			



NOTE

Set the coordinate origin in the specified unit.

# 13.6 Pulse Input

## 13.6.1 Pulse Input Types

Each axis of the positioning unit has pulse input, thus connecting to a variety of input devices. Select the desired type of pulse input in the positioning setting menu of the tool software.

Input target	Description
Pulser	Select this to use manual pulsers.
	• The use of a pulser operation setting code allows to specify the target axis (ch) where the pulser will be used.
Feedback pulse	Set feedback pulse input in the case of connecting an encoder in order to monitor the rotation of the motor.
	<ul> <li>When feedback pulse input is selected, the positioning unit uses pulse input to perform the feedback pulse count of its own axis, thus detecting the difference between the instruction value and pulse input value.</li> <li>(Automatic check function of movement amount)</li> </ul>
High-speed counter	<ul> <li>Set high-speed counter input to be used as general-purpose counter input.</li> <li>High-speed counter input supports a variety of input types (i.e., two-phase input, direction discrimination input, and individual input).</li> </ul>
	<ul> <li>The positioning unit stores the number of input pulses in the monitor area.</li> </ul>



## 13.6.2 Monitoring Pulse Input Values

The positioning unit can monitor pulse input from programs.

Pulse input monitoring uses the following areas.

Unit memory no. (Hex)	Name	Description		
UM 00436	Pulso input value of 1st avis			
UM 00437	Fuise input value of TSL axis			
UM 00476	Dulas input value of 2nd ovia	Pulse input values are stored according to the pulse input application		
UM 00477	Fuise input value of 210 axis	(e.g., pulser, feedback pulse, or high-speed counter). (Unit: pulse)		
UM 004B6	Bulae input value of 2rd evic	Pulse input values are integrated and stored, and will be cleared if the pulse input application is changed or when the pulse input values are cleared.		
UM 004B7	Pulse input value of 3rd axis			
UM 004F6	Bulae input value of 4th avia			
UM 004F7	Fuise input value of 4th axis			

## 13.6.3 Pulser Input Function

By setting the positioning unit to pulser for the pulse input application, a manual pulser can be used.

Settings allows manual pulsers to connect to different axes. Therefore, a single pulser can operate a number of axes simultaneously. However, pay attention to settings for the axis connected to the pulser and the axes operated by the pulser.

Settings for pulse input application		Pulser operation	
Pulser connecting axis	Pulser operating axis	Operation	Outline
Feedback pulse	Feedback pulse		The positioning unit does not recognize
High-speed counter	High-speed counter Pulser	No	pulse input as the manual pulser, thus not allowing the operation of the pulser.
Pulser	Feedback pulse	Yes	The pulser operates. The feedback pulse function is available while the pulser is in operation.
	High-speed counter	Yes	The pulser operates. The high-speed counter function is available while the pulser is in operation.
Pulser		Yes	The pulser operates.

Refer to the following table and make settings for the pulse input application.

## 13.6.4 Feedback Pulse Function

By setting the pulse input application to feedback pulse, the positioning unit can use the function to utilize feedback pulses from the encoder.

#### Automatic check function of movement amount

The automatic check function of movement amount is used to check whether each axis in operation is operating according to the instruction value, and the function compares the difference between the current value (absolute) under the internal control of the unit and the feedback pulse input (deviation) with a threshold preset. The automatic check function of movement amount works for all types of operation.

The automatic check function of movement amount will work only if the pulse input application is set to feedback pulse, and will not work if it is set to pulser or high-speed counter. The automatic check function of movement amount will be disabled if the synchronous control function is used.



The automatic check function of movement amount is set in the following areas.

#### 1st axis

Unit memory no. (Hex)	Name	Description
UM 00808	Numerator of automatic movement amount check correction	Set a correction value of pulse input at the time of making an automatic movement amount check.
UM 00809	Denominator of automatic	The following formula is used to calculate a deviation feedback value (pulse input value with a correction) from pulse input and make an automatic movement amount check.
	movement amount check correction	Deviation feedback value = (Correction numerator/Correction denominator) x Pulse input
		Set an action when the difference between the instruction value and feedback value exceeds the movement check value at the time of automatic movement amount check.
UM 0080A	Automatic movement amount checking	0: Error An error will occur and the operation of the positioning unit will come to a stop if the difference between the feedback value and reference movement exceeds the movement check value (threshold). The pulse input will be cleared when the error is cleared.
		1: Warning A warning will occur and the operation of the positioning unit will come to a stop if the difference between the feedback value and reference movement exceeds the movement check value (threshold). The pulse input will be cleared when the warning is cleared.
		2: No No movement check is made.
UM 00818	Automatic movement amount check value	Set the threshold to use the automatic check function of movement amount.
UM 0081A	Automatic movement amount check interval	Set the interval of automatic movement amount checking (Unit: ms)

#### 2nd axis

Unit memory no. (Hex)	Name	Description
UM 03008	Numerator of automatic movement amount check correction	
UM 03009	Denominator of automatic movement amount check correction	
UM 0300A	Automatic movement amount checking	Refer to the description for the 1st axis.
UM 03018	Automatic movement amount check value	
UM 0301A	Automatic movement amount check interval	

#### 3rd axis

Unit memory no. (Hex)	Name	Description
UM 05808	Numerator of automatic movement amount check correction	
UM 05809	Denominator of automatic movement amount check correction	
UM 0580A	Automatic movement amount checking	Refer to the description for the 1st axis
UM 05818	Automatic movement amount check value	
UM 0181A	Automatic movement amount check interval	

#### 4th axis

Unit memory no. (Hex)	Name	Description
UM 08008	Numerator of automatic movement amount check correction	
UM 08009	Denominator of automatic movement amount check correction	
UM 0800A	Automatic movement amount checking	Refer to the description for the 1st axis.
UM 08018	Automatic movement amount check value	
UM 0801A	Automatic movement amount check interval	

#### Operation of automatic check function of movement amount

The automatic check function of movement amount operates in the following procedure while the positioning unit is in operation.

- 1. The current position of the positioning unit will be saved in the unit the moment the positioning unit starts operating.
- 2. After the positioning unit starts operating, the automatic check function of movement amount will come to a stop until the automatic movement check interval elapses.
- 3. After the movement amount automatic interval elapses, the deviation feedback value calculated from the current pulse input value will be compared with the saved pulse input value, and the difference (deviation) will be checked whether it is in excess of the value set for the automatic movement check value.
- 4. The current position of the positioning unit will be saved in the unit.
- 5. Steps 2 to 4 above will be repeated.



Set the automatic movement check interval with consideration of the response time of the encoder in use.

#### Deviation monitoring

The value (deviation) calculated by the automatic check function of movement amount can be checked with the program.

The deviation monitor uses the following areas.

Unit memory no. (Hex)	Name	Description			
UM 00434	Deviation of 1st axis				
UM 00435	Deviation of TSI axis				
UM 00474	Doviation of 2nd avia				
UM 00475		The maximum value of the deviation (the difference between the pulse input value and instruction value) will be stored.			
UM 004B4	Doviction of 2rd ovic				
UM 004B5	Deviation of 3rd axis				
UM 004F4	Doviction of 4th oxia				
UM 004F5	Deviation of 4th axis				

#### Clearing pulse input value

Pulses input as feedback pulses are integrated and stored as a pulse input value.

The pulse input value will be cleared at completion of home return when feedback pulses are used for the pulse input application.

Phone: 800.894.0412 - Fax: 888.723.4773 - Web: www.ctiautomation.net - Email: info@ctiautomation.net

#### ■ Changing pulse input value

If the pulse input application is set to feedback pulse, the pulse input value can be changed to a desired value.

Unit memory no. (Hex)	Name	Description					
UM 00241	Pulse count value change requestThe pulse input value will be changed to the set pulse count when the corresponding bit for each axis is set to 1 from 0.						
	flag	This flag is an edge trigger. Be sure to change the flag to 1 from 0 at the time of the change. After the change, the positioning unit will clear the corresponding bits to 0 automatically.					
		bit	Name	Default	Description		
		0	Pulse count change of 1st axis	0	0: The pulse input value is		
		1	Pulse count change of 2nd axis	0	not changed.		
		2	Pulse count change of 3rd axis	0	0→1: Pulse input value		
		3	Pulse count change of 4th axis	0	change		
		15 to 4	_	-	_		
UM 00248	Pulse input value	Sat the desired pulse input value for the 1st avia					
UM 00249	change of 1st axis	Set the t		151 8815.			
UM 0024A	Pulse input value	Out the desired as her insert as her factly a Out suit.					
UM 0024B	change of 2nd axis	Sectile		2110 2015.			
UM 0024C	Pulse input value	Sot the	desired pulse input value for the	ard ovia			
UM 0024D	change of 3rd axis						
UM 0024E	Pulse input value	Sot the	desired pulse input value for the	Ath axis			
UM 0024F	change of 4th axis	Set the desired pulse input value for the 4th axis.					

The following areas are used to change the pulse input value.

## 13.6.5 High-speed Counter Function

By setting the positioning unit to high-speed counter for the pulse input application, pulse input can be used as an external counter.

#### ■ Controlling pulse input

By setting the positioning unit to high-speed counter for the pulse input application, the pulse input count can be stopped as desired. The current pulse input value will be kept on hold when the pulse input count is stopped.

The pulse input count is enabled or disabled with settings in the following areas.

Unit memory no. (Hex)	Name	Description						
UM 00240	Pulse count enable flag	The pulse i correspond	The pulse input value will be changed to the set pulse count when the corresponding bit for each axis is set to 0 from 1.					
		bit	bit Name Default Description					
			1st axis pulse count enabled	0	0: Pulse count enabled			
		1	2nd axis pulse count enabled	0	1: Pulse count disabled			
		2	3rd axis pulse count enabled	0				
		3	4th axis pulse count enabled	0				
		15 to 4	-	-	-			

#### ■ Changing pulse input value

-

If the pulse input application is set to high-speed counter, the pulse input value can be changed to a desired value.

The following areas are used to change the pulse input value.

Unit memory no. (Hex)	Name	Description						
UM 00241	Pulse count value change request flag	The pul corresp This flat of the c corresp	The pulse input value will be changed to the set pulse count when the corresponding bit for each axis is set to 1 from 0. This flag is an edge trigger. Be sure to change the flag to 1 from 0 at the time of the change. After the change, the positioning unit will clear the corresponding bits to 0 automatically.					
		bit	Name	Default	Description			
		0	Pulse count change of 1st axis	0	0: Pulse input value not			
		1	Pulse count change of 2nd axis	0	changed.			
		2	Pulse count change of 3rd axis	0	0→1: Pulse input value change			
		3	Pulse count change of 4th axis	0				
		15 to 4	-	-	-			
UM 00248	Pulse input value		desinad autos issutustus fauth					
UM 00249	change of 1st axis	Set the	desired pulse input value for th	le 1st axis				
UM 0024A	Pulse input value	Cot the	desired pulse input value for th	o Ond ovi	-			
UM 0024B	change of 2nd axis	Set the	desired pulse input value for th	ie znu axi	5.			
UM 0024C	Pulse input value	Cot the	desired sulse issue value for th	o Ord ovid				
UM 0024D	change of 3rd axis	f 3rd axis						
UM 0024E	Pulse input value	Sot the	desired pulse input value for th	o 4th ovic				
UM 0024F	change of 4th axis	Set the						

# 13.7 Startup speed

The positioning unit allows startup speed settings for the startup of each type of operation. The startup speed is available for positioning, JOG operation, and home return control.

#### Setting method of startup speed

Set the startup speed in the parameter-setting menu for each axis of the Configurator PM7.

#### Cautions for start speed settings

- 1. The startup speed will apply to the end of operation as well. The speed at the end of operation cannot be changed.
- 2. The home return creep speed at the time of a home return will not be influenced by the start speed.
- 3. The target speed of each type of operation is not influenced by the start speed. The positioning unit operates at the preset target speed regardless of the preset startup speed.



# **14** Programming Cautions

# 14.1 Programming Cautions

## 14.1.1 Turning Off Power Supply Clears Contents of Unit Memory

The unit memory data of the positioning unit will be cleared when the PLC is turned off.

#### 14.1.2 Not Going to Other Operation from Current Operation

Automatic operation (positioning control) or manual operation (JOG operation, home return, or pulser operation) that has started with the start contact turned ON will continue even if the contact of other operation turns ON.

However, the stop operation (deceleration stop, emergency stop, system stop) can be executed during other types of operation.

## 14.1.3 Operation with the PLC Set to PROG. Mode from RUN Mode

Automatic operation (positioning control) or manual operation (JOG operation, home return, or pulser operation) that has started with the start contact turned ON will continue even if the PLC is switched to PROG. mode from RUN mode.

## 14.1.4 Types of Positioning Data Setting Areas

The positioning unit has a standard 600-point positioning data setting area and 25-point extended area with the following characteristics. Use either of them according to the application.

Items	Standard area	Extended area		
No. of positioning data tables	600 tables	25 tables		
Table number	1 to 600	10001 to 10025		
Positioning parameter settings on Configurator PM7 (note 1)	Available	Available		
	Available			
Positioning data settings on Configurator PM7 (note 2)	Data that has been set is downloaded along with other project data including the program to the CPU unit. Positioning data will be calculated and each type of operation will be ready to start when the power is turned on or the CPU unit is set to RUN mode.	Not available		
	Available	Available		
Positioning data setting with user program (note 2)	Each type of operation will be ready to start after the data is transferred to the unit memory (UM) area with the user program and a recalculation request is made.	Each type of operation will be ready to start after the data is transferred to the unit memory (UM) area with the user program. No recalculation request is required.		
Characteristics	In the case of setting positioning data with the Configurator PM7, the start will be quicker than that with the extended area used.	In the case of setting positioning data with a user program, the start will be quicker than that with the standard area used.		
Application	Suitable to applications where the movement amount, target speed, and other positioning data are determined.	This is suitable for cases where positioning data fluctuates according to the operation results of the PLC.		

Comparison of standard area and expansion area

(Note 1): Positioning parameters refer to operating conditions, such as the JOG operation and home return conditions along with the limit input logic, and deceleration stop time.

(Note 2): Positioning data refers to the individual positioning information such as the movement amount, target speed, acceleration and deceleration time, and operating pattern data, and other individual positioning information.

#### Calculation of reconstructing of standard area

The calculation of reconstruction (recalculation) will be required if the standard positioning data area is overwritten with a user program. If the data is not recalculated after rewriting the positioning table by the program, note that the operation will be executed with the previous positioning table. The recalculation procedure is as follows:

- 1. Change the positioning table in the unit memory.
- 2. Turn ON the recalculation request signal (Y7) in the I/O area.
- 3. Check that the recalculation completion signal (X7) in the I/O area turns ON, and start a desired type of operation.

(Note) The I/O numbers of the recalculation request signal (Y7) and the recalculation completion signal (X7) vary with the first word number allocated to the unit.



## REFERENCE

For the difference in programming method between the standard area and extended area, refer to Section 18 Sample program.

# **15** Errors and Warnings

# **15.1 About Errors and Warnings**

### 15.1.1 Errors and Warnings

If any operational unconformity occurs in the positioning unit, an error or warning will occur. When an error or warning occurs, the following operation will be performed.

Errors	Occurs in any abnormal conditions. When a motor is operating, the operation stops. The motor stopped due to the occurrence of error will not be activated until the error clear is executed.
Warnings	Occurs if there is any operational unconformity but not abnormal. The operation can continue even after the occurrence of warnings, and the motor continues running if the motor is operating.

## 15.1.2 Check and Clearing with Configurator PM7

It is possible to check and clear data on an axis-by-axis basis by selecting [Online]  $\rightarrow$  [Status monitor] on the Configurator PM7 programming tool.

tatus monitor							
Model	FP7 positioning unit (FP7 type) 4-axis transistor output						
Axis [Group]	1 axis	2 axis	3 axis	4 axis			
Status	Connected	Connected	Connected	Connected			
External terminal input monito	r						
Home position proximity	OFF	OFF	OFF	OFF			
Home position	OFF	OFF	OFF	OFF			
Limit +	Limit +	Limit +	Limit +	Limit +			
Limit -	Limit -	Limit -	Limit -	Limit -			
	4			Þ			
FROM write count							
Firmware version	1.00						
Hardware version	1.01		<u>H</u> elp	Close			

## 15.1.3 Check and Clearing with User Program

#### Check on error and warning information

• Use the dedicated command PERED (to get errors and warnings) and read information.



Error and warning codes are stored as shown below.

DT100	Error code
DT101	Warning code

#### Clearing all axes with UCLR command

• When the dedicated UCLR command (to clear errors and warnings), the errors and warnings on all the axes of the positioning unit will be cleared.



### Clearing with I/O signal on each axis

• It is possible to clear errors and warnings on an axis-by-axis basis by turning ON the error/warning clear request flags allocated to the I/O area. The following program shows the clearing of errors on each axis.



#### I/O signal allocation

Signal name	1st axis	2nd axis	3rd axis	4th axis	Virtual axis
Error annunciation	X60	X61	X62	X63	X67
Warning annunciation	X68	X69	X6A	X6B	X6F
Request error clear	Y60	Y61	Y62	Y63	Y67
Request warning clear	Y68	Y69	Y6A	Y6B	Y6F

(Note 1): The I/O numbers in the above table show relative addresses based on the base word number. I/O numbers actually used vary with the number of the slot where the unit is installed and the first word number.

## 15.1.4 Error and Warning Logs

There are log areas to store the error/warning logs within the positioning unit.

Error log	Up to 7 error codes can be stored for each axis (1st axis to 4th axis).
Warnings log	Up to 7 warning codes can be stored for each axis (axis 1 to 4).

Once an error/warning occurs, the error/warning code will be stored in the log area of the axis causing the error.

When an error/warning that is not related to axes occurs, such as an failure in the unit, the error/warning code will be stored in the log areas of all the axes.

The positioning setting menu of the programming tool makes it possible to check only the latest error and warning on each axis.

When referring the error and warning logs for each axis, read the following memory from the PLC.

#### Error log area (unit memory)

#### Warning log area (unit memory)

UM 00128 ~ UM 00137	Error log area of axis 1	
UM 00138 ~ UM 00147	Error log area of axis 2	N
UM 00148 ~ UM 00157	Error log area of axis 3	
UM 00158 ~ UM 00167	Error log area of axis 4	
UM 00198 ~ UM 001A7	Error log area of virtual axis	

UM 00128	-
UM 00129	No. of occurrences of errors
UM 0012A	Error code annunciation
UM 0012B	buffer 1
UM 0012C	Error code annunciation
UM 0012D	buffer 2
UM 0012E	Error code annunciation
UM 0012F	buffer 3
UM 00130	Error code annunciation
UM 00131	buffer 4
UM 00132	Error code annunciation
UM 00133	buffer 5
UM 00134	Error code annunciation
UM 00135	buffer 6
UM 00136	Error code annunciation
UM 00137	buffer 7

UM 001C0 ~ UM 001CF	Warning log area of axis 1	
UM 001D0 ~UM 001DF	Warning log area of axis 2	
UM 001E0 ~ UM 001EF	Warning log area of axis 3	
UM 001F0 ~UM 001FF	Warning log area of axis 4	
UM 00230 ~ UM 0023F	Warning log area of virtual axis	

	—
UM 001C1	No. of occurrences of warnings
UM 001C2	Warning code
UM 001C3	annunciation buffer 1
UM 001C4	Warning code
UM 001C5	annunciation buffer 2
UM 001C6	Warning code
UM 001C7	annunciation buffer 3
UM 001C8	Warning code
UM 001C9	annunciation buffer 4
UM 001CA	Warning code
UM 001CB	annunciation buffer 5
UM 001CC	Warning code
UM 001CD	annunciation buffer 6
UM 001CE	Warning code
UM 001CF	annunciation buffer 7

Number of occurrences of errors/warnings	Stores the number of occurrences of errors and warnings.			
Error/warning annunciation buffers	Stores error and warning codes. Errors and warnings are stored in chronological order beginning with buffer 1, followed by buffer 2, 3, etc.			

# 15.2 Changes in Recovery from Errors

## 15.2.1 Outline

The method to recover from error occurrence varies according to the states when errors occur.

Status if an error occurs	Description	Error type	
Recoverable state (Yes)	Recoverable state (Yes)• After an error occurs, the operating axes stop. • After an error occurs, the Positioning Unit can recover from the error at any timing.		
Unrecoverable state (No)	<ul> <li>A critical error on the positioning unit system</li> <li>If an unrecoverable error occurs, the power supply of the positioning unit should be turned off and on.</li> </ul>	System Error Axis operation error	

# 15.3 Error Code Table

## 15.3.1 System Error (from 1000H)

These are the errors that occur due to any failure within the positioning unit. The system errors are defined as fatal errors for the system. Except for some items, the power supply must be turned off and on again to recover from the errors.

Error code	Error name	Description	Object	Recovered	Countermeasures
1000H	System runaway	System runaway If the error occurs, the ALARM LED on the positioning unit will be lit.	All axes	No	Turn off the power supply and turn it on again.
1001H	Hardware error	An error has occurred in a hardware test with the power supply turned on.	All axes	No	If an error occurs repeatedly, consult your Panasonic
1002H	Unit error	Any error has occurred in the internal processing.	All axes	No	representative.
1003H	System processing error	An error has occurred in the system processing due to some reason.	All axes	Yes	Check the settings. If an error occurs repeatedly with the correct set values, consult your Panasonic representative.
1020H	Tool operation abnormal end	An error in communication with the PC has occurred while operating the programming tool with the positioning setting menu.	All axes	Yes	Check the connection of the cable connecting the PC and PLC. Reboot the PC.
1030H	CPU unit error	An alarm has occurred to the CPU unit.	All axes	No	Check the condition of the CPU unit. Turn off the power supply and turn it on again.
1031H	CPU unit operation mode error	The system in operation has come to a stop because the CPU unit is switched to PROG. Mode.	All axes	Yes	Check the condition of the CPU unit. Set the CPU unit to PROG. Mode.

# 15.3.2 Axis operation error (from 3000H)

Error code	Error name	Description	Object	Recovered	Countermeasures	
3010H	Limit + signal detection	The input on the positive side of the limit has turned ON.	Each axis	Yes	Move the motor into the range of the limit by an appropriate	
3011H	Limit – signal detection	The input on the negative side of the limit has turned ON.	Each axis	Yes	mode, such as JOG operation. Check the limit signal is correct.	
3012H	Limit signal error	Both inputs on the positive and negative sides of the limit have turned ON.	Each axis	Yes	Check the status of the limit signal.	
3020H	Software limit (positive side) detection	The movement amount of the motor has exceeded the upper limit of the software limit.	Each axis	Yes	Move the motor into the range of the software limit by an appropriate mode, such as JOG	
3021H	Software limit (negative side) detection	The movement amount of the motor has exceeded the lower limit of the software limit.	Each axis	Yes	operation. Check the set values of the software limit.	
		An error has occurred in the operation processing of each axis due to some reason.	Each axis	Yes	Check the set values and parameters for the positioning unit.	
3030H	Axis operation error				If an error occurs repeatedly with the correct set values, consult your Panasonic representative.	
3031H	Operation abnormal end	An error has occurred in the operation processing of each axis due to some reason.	Each axis All axes	Yes	If an error occurs repeatedly, consult your Panasonic representative.	
	Axis group operation error	Axis group settings are changed while the positioning unit is in operation or a stop request is	Each axis	Each axis Yes	Changing the axis group should be performed when the axes are not in operation.	
3032N		being made. Axis group settings are outside			Do not make a stop request, either.	
		ine lange.			Check the axis group settings.	
	Interpolation operation error	The operation has stopped due to an error in another interpolation axis during interpolation.	Each axis	Yes	positioning data on interpolation.	
3033H					If an error occurs repeatedly with the correct set values, consult your Panasonic representative.	
3034H	Axis group not settable (In pulser operation)	The axis group settings are changed while the positioning unit is in pulser operation.	Each axis	Yes	Changing the axis group should be performed when the pulser operation enabled signal is OFF.	

These are the errors that will occur while various operations are being executed.

Error code	Error name	Description	Object	Recovered	Countermeasures
3035H	Positioning movement amount error	The positioning movement amount has exceeded the upper or lower limit.	Each axis	Yes	Check the set value.
3040H	Synchronous operation group error	The synchronous group is changed while the positioning unit is in synchronous operation or a stop request is being made. The settings of axis groups are outside the range. An error has occurred during a home return while the positioning unit is in synchronous operation.	Each axis	Yes	Changing the synchronous group should be performed when the busy signal for the axes to be synchronized is OFF. It should be performed when various stop request signals (system stop, emergency stop, deceleration stop) are OFF.
3042H	Synchronous operation home return error	The home return process was executed with setting the synchronous operation to "Enabled" when using synchronous mode A. A method other than the usable home return methods was executed when using synchronous mode B.	Each axis	Yes	Set the simultaneous operation to "Disabled" while the positioning unit is in synchronous mode A. Select a usable home return method while the positioning unit is in synchronous mode B.
3043H	Synchronous operation error	The operation has stopped as an error occurred on another axis while the positioning unit is in synchronous operation.	Each axis	Yes	Check the unit setting of the stopped axis. If an error occurs repeatedly with the correct set values, consult your Panasonic representative.
3044H	Synchronous operation not settable (In pulser operation)	The setting of the synchronous operation was changed while the positioning unit is in pulser operation.	Each axis	Yes	Changing the setting of the synchronous operation should be performed when the pulser operation enabled signal is OFF.
3045H	Synchronous axis difference check error	The difference between the movement amounts of the target axes under synchronous control exceeded the specified difference.	Each axis	Yes	Check the operation of the target axes for the synchronous operation.
3046H	Automatic movement amount check error	The automatic movement amount check function has detected that the difference between the instruction value and feedback value is in excess of the preset automatic movement amount.	Each axis	Yes	Check the operation of the target axes. Check the parameters of the automatic check function of movement amount.
## 15.3.3 Set Value Error (from 4000H)

The following errors occur to various set values made in the positioning setting menu of the programming tool and ladder programs.

Error code	Error name	Description	Object	Recovered	Countermeasures
					Check the following items in the settings of the axis group and independent axis.
4000H	The settings of axis groups are not correct	The settings of axis groups are not correct.	Each axis	Yes	<ul> <li>The same axis number has been registered in more than one group.</li> </ul>
					• Four or more axes have been set in one group.
					<ul> <li>The group is composed of one axis only.</li> </ul>
4002H	Unit setting error	The unit system for the axis setting is out of the	Each axis	Yes	Check if the unit is one of the followings.
		range.			pulse, µm, inch, degree
4004H	Pulse number error	The pulse number is out	Fach axis	Yes	Check the set value.
400411	per rotation	of the range.		100	If the set value is out of the
4005H		_			range, reduce it by the following formula.
	Movement amount error per rotation	The movement amount is out of the range.	Each axis	Yes	(Pulse number per rotation) / (Movement amount per rotation)

Error code	Error name	Description	Object	Recovered	Countermeasures
4010H	Software limit setting error	The upper or lower limit value of software limit is out of the range.	Each axis	Yes	
4020H	Limit stop deceleration time error	The limit stop deceleration time is out of the range.	Each axis	Yes	
4021H	Error stop deceleration time error	The error stop deceleration time is out of the range.	Each axis	Yes	
4022H	Emergency stop deceleration time error	The emergency stop deceleration time is out of the range.	Each axis	Yes	
		The settings of auxiliary output are not correct.			
4028H	Auxiliary output setting error	A mode other than With mode or Delay mode for the auxiliary output mode has been set.	Each axis	Yes	Check the set value.
		The auxiliary output delay ratio while the positioning unit is in Delay mode is not 0 to 100 (%).			repeatedly with the correct set values, consult your Panasonic representative.
		The same axis has been set for the synchronous groups 1 and 2.			
	Synchronous group setting error	Either master axis or slave axis has not been set.	Each axis	Yes	
4030H		Multiple axes have been set for the master or slave axis.			
		The same axis has been set for the master and slave axes.			
		The slave axis has been set to the interpolation group.			
4031H	Synchronous operation mode setting error	Operation settings for the synchronous operation differential check function are incorrect.	Each axis	Yes	
		The pulser input mode is incorrect.			Check the set value.
4042H	Pulser setting error	Pulser operation method is incorrect.	Each axis	Yes	If an error occurs repeatedly with the correct set values, consult
		Pulser operation max. speed is incorrect.			your Panasonic representative.
	Pulso operation	The pulse input application			Check the pulse input application.
4043H	disabled error	axis for which pulse input is permitted.	Each axis	Yes	Set the input application to pulser at the time of using the pulser.

Error code	Error name	Description	Object	Recovered	Countermeasures
4044H	Speed factor error	The setting of the speed factor is out of the range.	Each axis	Yes	
4050H	Startup speed error	The startup speed is out of the range.	Each axis	Yes	
4080H	JOG positioning acceleration/deceler ation type error	The acceleration/deceleration method of the JOG positioning is out of the range.	Each axis	Yes	
4081H	JOG positioning deceleration time error	The deeleration time of the JOG positioning is out of the range.	Each axis	Yes	
4082H	JOG positioning acceleration time error	The acceleration time of the JOG positioning is out of the range.	Each axis	Yes	
4083H	JOG positioning target speed error	The target speed of the JOG positioning is out of the range.	Each axis	Yes	
4102H	Home return target speed error	The target speed of the home return is out of the range.	Each axis	Yes	
4105H	Home return acceleration time error	The acceleration time of the home return is out of the range.	Each axis	Yes	
4106H	Home return deceleration time error	The deceleration time of the home return is out of the range.	Each axis	Yes	Check the set value.
4107H	Home return setting code error	The home return setting code is incorrect.	Each axis	Yes	with the correct set values, consult your Panasonic
4110H	Home return creep speed error	The creep speed of the home return is out of the range.	Each axis	Yes	representative.
4111H	Home return returning direction error	The moving direction of the home return is incorrect	Each axis	Yes	
4112H	Home return limit error	The limit switch is disabled. (It occurs when the home return method is set to the limit method 1 or 2.)	Each axis	Yes	
4120H	Coordinate origin error	The coordinate origin is out of the range.	Each axis	Yes	
4201H	JOG operation target speed error	The target speed of the JOG operation is out of the range.	Each axis	Yes	
4203H	JOG operation acceleration/deceler ation type error	The acceleration/deceleration type of the JOG operation is incorrect.	Each axis	Yes	
4204H	JOG operation acceleration time error	The acceleration time of the JOG operation is out of the range.	Each axis	Yes	
4205H	JOG operation deceleration time error	The deceleration time of the JOG operation is out of the range.	Each axis	Yes	

Error code	Error name	Description	Object	Recovered	Countermeasures
4250H	Current value update error	The set value of the current value update is out of the range.	Each axis	Yes	
4301H	Absolute/incremental setting error	A value other than the absolute/increment is set for the move method.	Each axis	Yes	
4302H	Dwell time error	The set value of the dwell time is out of the range.	Each axis	Yes	
4303H	Positioning starting table No. error	The specified table number is 0, or it exceeds the maximum table number.	Each axis	Yes	
4304H	Table setting error	The last table of the positioning setting tables is not the E point.	Each axis	Yes	
4400H	Positioning movement amount setting error	The movement amount of the positioning operation is out of the range.	Each axis	Yes	
4401H	Positioning acceleration/deceleratio n type error	The acceleration/ deceleration type of the positioning operation is incorrect.	Each axis	Yes	Check the set value. If an error occurs repeatedly with the correct set values,
4402H	Positioning acceleration time error	The acceleration time of the positioning operation is out of the range.	Each axis	Yes	consult your Panasonic representative.
4403H	Positioning deceleration time error	The deceleration time of the positioning operation is out of the range.	Each axis	Yes	
4404H	Positioning target speed error	The target speed of the positioning operation is out of the range.	Each axis	Yes	
4500H	Interpolation type error	The setting of the interpolation type is incorrect.	Each axis	Yes	
4504H	Circular interpolation not executable	The parameter of the circular interpolation (such as center point or pass point) is incorrect.	Each axis	Yes	
4505H	Spiral interpolation not executable	The error occurred while the positioning unit is in spiral interpolation operation as the set value is incorrect.	Each axis	Yes	

Error code	Error name	Description	Object	Recovered	Countermeasures
4600H	Pulse input setting error	The pulse input settings are incorrect.	Each axis	Yes	Check the set value. Check the combination of the input type, input multiplication, and input application.
4605H	Pulse count value change setting error	The set pulse count change value is out of the range.	Each axis	Yes	
4609H	Automatic movement amount check method setting error	The operation of the automatic check function of movement amount is incorrect.	Each axis	Yes	
4610H	Automatic movement amount correction numerator setting error	The automatic movement amount correction numerator is out of the range.	Each axis	Yes	Check the set value.
4611H	Automatic movement amount correction denominator setting error	The automatic movement amount correction denominator is out of the range.	Each axis	Yes	
4613H	Automatic movement amount check interval setting error	The automatic movement amount check interval is out of the range.	Each axis	Yes	

# 15.4 List of Warning Codes

## 15.4.1 Unit Warning (from B000H)

These are the warning codes to be given when the warnings occurred in the positioning unit.

Error code	Error name	Description	Object	Recovered	Countermeasures
		The following request signals were turned ON by the host PLC while			No requests from the PLC can be executed while the positioning unit is in tool operation.
		<ul><li>the positioning unit is in tool operation.</li><li>Positioning start</li></ul>			The following requests, however, can be executed from the PLC while the positioning unit is in tool operation.
B000H	Tool operation	axis)	Each axis	Yes	<ul> <li>Deceleration stop request flag (each axis)</li> </ul>
		request flag (each axis)			<ul> <li>Emergency stop request flag (each axis)</li> </ul>
		JOG     forward/reverse			<ul> <li>System stop request flag (all axes)</li> </ul>
		rotation request flag (each axis)			<ul> <li>Pulser operation enabled flag (each axis)</li> </ul>
	Duplicate start	The same axis was requested to start even though the axis operation has not completed.	Each axis		No requests to any axes in operation can be executed.
					The following requests, however, can be executed while the positioning unit is in operation.
B010H				Yes	<ul> <li>Deceleration stop request flag (each axis)</li> </ul>
					<ul> <li>Emergency stop request flag (each axis)</li> </ul>
					<ul> <li>System stop request flag (all axes)</li> </ul>
B030H	J-point simultaneous start warning	The J-point speed change contact and J- point positioning start contact turn ON simultaneously during the JOG positioning (J- point) operation.	Each axis	Yes	When the both contacts turn ON simultaneously, the J-point positioning start contact will have a priority, and the J-point speed change contact will be ignored.
		The J-point contact are turned ON while the system is accelerating or decelerating the speed			Speed change contact will be turned ON while the positioning unit is in operation at constant speed.

Error code	Error name	Description	Object	Recovered	Countermeasures
B045H	Synchronous axis difference check warning	The difference between the movement amounts of the target axes in synchronous operation has exceeded the specified difference threshold. This warning occurs when the synchronous operation mode and synchronous difference check function are set to Warning.	Each axis	Yes	Check the operation of the target axes for the synchronous operation.
B046H	Automatic movement amount check warning	The automatic movement amount check function has detected that the difference between the instruction value and feedback value is in excess of the preset automatic movement amount. This warning occurs when the operation of the automatic check function of movement amount is set to Warning.	Each axis	Yes	Check the operation of the target axes.
B304H	Recalculation error warning	An error has occurred while recalculation processing is in process.	Each axis	Yes	Check the settings for each axis parameter and interpolation group.

# 16 Troubleshooting

## **16.1 What to Do If an Error Occurs**

### 16.1.1 Motor is not Rotating or Operating (Pulse Output A and B LEDs are Flashing or Lit)

### Solution 1: Servo motor

Check that the servo input is ON.



### Solution 2

Check that the power to the driver is turned on.

### Solution 3

Check that the positioning unit and driver are wired correctly.

### Solution 4

Check that the pulse output coincides in setting (CW/CCW or Pulse/Sign setting) with the driver.

## 16.1.2 Motor is not Rotating or Operating (Pulse Output A and B LEDs off)

### Solution

Review the program.

### **Points of confirmation**

- 1. Check that the I/O numbers are correct.
- 2. Check that the start contact has not been overwritten in the program.
- 3. Check the input logic of the over limit switch. (The error LED is lit if the logic is incorrect.)

## 16.1.3 Reversed Rotation or Movement Direction

### [Example of reversed rotation or movement direction]



### Solution 1

Check that the positioning unit and driver are wired correctly.

#### Points of confirmation

Check that the CW/CCW output or Pulse/Sign output is connected to the corresponding input of the driver.

### ■ Solution 2

Change the pulse output rotation direction of each axis parameter to set the reversed rotating direction.

Phone: 800.894.0412 - Fax: 888.723.4773 - Web: www.ctiautomation.net - Email: info@ctiautomation.net

# **17** Specifications

# 17.1 Specifications

## **17.1.1 General Specifications**

Items	Description			
Operating ambient temperature	0°C to +55°C			
Storage ambient temperature	-40°C to +70°C			
Operating ambient humidity	10% to 95%RH (at 25°C with no-condensing)			
Storage ambient humidity	10% to 95%RH (at 25°C with no-condensing)			
Breakdown voltage	Each external connector pin and entire power supply terminals of CPU unit 500 V AC for 1 minute			
Insulation resistance	Each external connector pin and entire power supply terminals of CPU unit 100 M $\Omega$ min. (at 500 V DC)			
Vibration resistance	Conforming to JIS B 3502 and IEC 61131-2 5 to 8.4 Hz, 3.5-mm single amplitude 8.4 to 150 Hz, acceleration of 9.8 m/s ² 10 sweeps each in X, Y and Z directions (1 octave/min)			
Shock resistance	Conforming to JIS B 3502 and IEC 61131-2 147 m/s ² min in X, Y, and Z directions three times each.			
Noise resistance	1,000 V [p-p], pulse width of 50 ns/1 µs (by noise simulator)			
Environment	Free from corrosive gases and excessive dust.			
EC Directive applicable standard	EMC directive: EN 61131-2			
Overvoltage category	Category II or lower			
Pollution degree	Pollution degree 2 or lower			
Internal current consumption	120 mA or less			

## 17.1.2 Performance Specifications

Items -			Description				
			2-axis t	уре	4-axi	s type	
Product no.			AFP7PP02T	AFP7PP02L	AFP7PP04T	AFP7PP04L	
Voltage output type			Transistor	Line driver	Transistor	Line driver	
No.	of conti	rol axes	2-axis		4-axis		
Interpolation control		n control	2-axis linear interpol 2-axis circular interp	ation olation	2-axis linear int 3-axis linear int 2-axis circular in 3-axis spiral int	erpolation, erpolation, nterpolation and erpolation	
No.	of occu	pied I/O points	Input: 192 points/Ou	tput: 192 points			
	Position specification method		Absolute (absolute p Increment (specified	ositioning) relative position)			
			Pulse				
		Position specified unit	μm (select a minimum instruction unit of 0.1 μm or 1 μm)				
			inch (select a minimum instruction unit of 0.00001 inch or 0.0001 inch)				
			degree (select a minimum instruction unit of 0.1 degree or 1 degree)				
			Pulse: -1,073,741,823 to 1,073,741,823 pulses				
			μm (0.1 μm): -107,374,182.3 to 107,374,182.3 μm				
ы	0		μm (1 μm): -1,073,741,823 to 1,073,741,823 μm				
erati	ontr	Position reference range	inch (0.00001 inch): -10,737.41823 to 10,737.41823 inches				
ope	D C		inch (0.0001 inch): -107,374.1823 to 107,374.1823 inches				
natic	ionir		degree (0.1 degree): -107,374,182.3 to 107,374,182.3 degrees				
utorr	ositi		degree (1 degree): -	1,073,741,823 to	1,073,741,823 de	grees	
AL	<u> </u>		Pulse: 1 to 32,767,0	um/a			
		Speed reference range	μπ. το 52,767,000 μπ/s				
			degree: 0.001 to 32.767.000 inch/s				
		Operation max. speed	500 kpps	4 Mpps	500 kpps	4 Mpps	
		Acceleration/deceleration pattern	Linear acceleration/deceleration S-shaped acceleration/deceleration				
		Acceleration time	0 to 10,000 ms (adjustable in 1-ms increments)				
		Deceleration time	0 to 10,000 ms (adju	stable in 1-ms inc	crements)		
		No. of positioning tables	Each axis: 600 points in standard area and 25 points in extended area				

Itomo					Description		
			items	2-axis type	4-axis type		
Product no.					AFP7PP02T, AFP7PP04T, AFP7PP02L AFP7PP04L		
					PTP control (E- and C-point control)		
			Independent		CP control (P-point co	ontrol)	
		σ		•	Speed control (J-poin	t control)	
tion		metho	2-axis	Linear interpolation	E-, P-, C-point control; composite speed or long- axis speed specification		
operat	ig cont	control	Interpolation	Circular interpolation	E-, P-, C-point control specification	; center or passing point	
omatic	sitionir	0	3-axis	Linear interpolation	E-, P-, C-point control axis speed specification	; composite speed or long- on	
Auto	Ро		Interpolation	Spiral interpolation	E-, P-, C-point control specification	; center or passing point	
		Star	t speed		3 ms max. in standard extended area	d area and 5 ms max. in	
		Other functions Dwell time		Dwell time	0 to 32,767 ms (adjustable in 1-ms increments)		
	ration			Pulse: 1 to 32,767,000 pps			
		Snee	ed reference rang	۵	μm: 1 to 32,767,000 μm/s		
					inch: 0.001 to 32,767.000 inch/s		
					degree: 0.001 to 32,767.000 rev/s		
	edo	Acceleration/deceleration pattern		Linear acceleration/deceleration			
	90	· · ·			S-shaped acceleration/deceleration		
		Acce	Acceleration time		0 to 10,000 ms (adjustable in 1-ms increments)		
tion		Deceleration time			0 to 10,000 ms (adjustable in 1-ms increments)		
bera					Pulse: 1 to 32,767,00	0 pps	
al op		Spee	ed reference rang	e	μm: 1 to 32,767,000 μ	ım/s	
anua			g		inch: 0.001 to 32,767.	000 inch/s	
ŝ	E				degree: 0.001 to 32,7	67.000 rev/s	
	retu	Acce	eleration/decelerat	tion pattern	Linear acceleration/deceleration		
	Home	Acce	eleration time		0 to 10,000 ms (adjustable in 1-ms increments)		
	_	Dece	eleration time		0 to 10,000 ms (adjustable in 1-ms increments)		
		Retu	ırn method		DOG methods (3 type types), data set metho method	es), limit methods (2 od, and home position	
	Pulser operation	Spee	ed reference rang	e	Operates in synchron	ization with pulser input	

Itoms			Description										
	iter	115	2-axi	s type	4-axi	s type							
Product no.			AFP7PP02T	AFP7PP02L	AFP7PP04T	AFP7PP04L							
	Deceleration stop	Deceleration time	Deceleration tim	Deceleration time while in operation									
ions	Emergency stop	Deceleration time	0 to 10,000 ms (adjustable in 1-ms increments)										
p funct	Limit stop	Deceleration time	0 to 10,000 ms (adjustable in 1-ms increments)										
Sto	Error stop	Deceleration time	0 to 10,000 ms (adjustable in 1-ms increments)										
	System stop	Deceleration time	Immediate stop (0 ms): All axes comes to a stop										
			Pulse: -1,073,74	1,823 to 1,073,741	,823 pulses								
	Software limit function			μm (0.1 μm): -107,374,182.3 to 107,374,182.3 μm									
		e limit Setting range	μm (1 μm): -1,073,741,823 to 1,073,741,823 μm										
			inch (0.00001 inch): -10,737.41823 to 10,737.41823 inches										
su									inch (0.0001 inch): -107,374.1823 to 107,374.1823 inches				
atio			degree (0.1 degree): -107,374,182.3 to 107,374,182.3 degrees										
cific			degree (1 degree): -1,073,741,823 to 1,073,741,823 degrees										
er spe	Backup		Parameters and positioning data are saved in flash memories (with no batteries)										
Oth	High-speed counter	Counting range	Counting range -2,147,483,648 to 2,147,483,648 pulses										
	function (note 1)	e Input mode	Phase difference input, direction discrimination input, and individual input (with multiplier function for each mode)										
	• Limit input (	CWL, CCWL monitor	r, and near (DOG) monitor										
Auxiliary output code and auxilia			ary output contact										
Internal current consumption (5 V DC)		300 mA or less	300 mA or less	300 mA or less	300 mA or less								
Evto	rad power	Voltage	21.6 to 26.4 V D	С									
supp	nai power ly	Current consumption	50 mA	90 mA	50 mA	90 mA							
Weight		Approx. 130 g	Approx. 150 g	Approx. 130 g	Approx. 150 g								

(Note 1): The pulser input function and high-speed counter function use the same pulse input terminal. Therefore, select either one of them.

1

# 17.2 I/O Number Allocation

The following I/O numbers indicate offset addresses. The I/O numbers actually allocated are based on the first word number allocated to the unit.

C all	Contact ocation	Target axis	Name	Description	
	X0	All axes	Ready announce	Indicates that the unit is ready to operate internally, and announce the start of the system.	
	X1	-	-	-	
	X2	-	-	-	
	X3	-	-	-	
			Tool	Contact to indicate that the positioning unit is in tool operation.	
	X4	All axes	operation in progress	The start from I/O is not available during the Tool operation. A warning will occur if you attempt to do so.	
٥X٨	X5	All axes	Axis group setting done	Make axis group setting changes in the unit with the axis group setting request contact (Y5) turned ON after making setting changes in the axis group with the program. The contact turns ON upon completion of the setting changes.	
>	X6	-	-	-	
	X7 All axes	X7 All axes Recalculation done			If the recalculation request contact (Y7) turns ON, the positioning data of the unit memory (standard area) will be restructured. This contact will turn ON after restructuring completes.
			If the recalculation request contact (Y7) turns ON again, this contact will be off once.		
				Note) It is used only when the positioning data has been rewritten by ladder programs.	
	X8				
	1	-	-	-	
	XF				
	X10	1st axis	-		
	X11	2nd axis	Servo lock	Turns ON only if there is servo ON output with servo ON signals	
	X12	3rd axis	-	(Y8 to YB).	
	X13	4th axis			
	X14				
		-	-	-	
	X16				
VX1	X17	Virtual axis	Servo lock	Indicates a servo status of the virtual axis. (always UN)	
>	X18	1st axis	-		
	X19	2nd axis	BUSY	Turns ON when the corresponding axis is operating.	
	X1A	3rd axis	-		
	×10	401 805			
	X1E				
	X1F	Virtual axis	BUSY	Turns ON when the virtual axis is operating.	

Example) If the first word number of the unit is 10, the positioning ready signal will be X100.

C all	Contact ocation	Target axis	Name	Description
	X20	1st axis		Turns ON when the operation instruction for the corresponding axis
	X21	2nd axis		completed and the position deviation became in the specified completion width
	X22	3rd axis	Operation	Turns ON when the operation for all the tables completed for P-point
			done	control and C-point control of the automatic operation.
	X23	4th axis		After this contact turns ON, the ON-state will continue until the next control is activated.
	X24			
	1	_	_	-
	X26			
WX2	X27	Virtual axis	Operation done	Turns ON when the operation instruction to the virtual axis is completed.
	X28	1st axis		Turns ON when the home return operation for the corresponding axis is
	X29	2nd axis	Home return	completed.
	X2A	3rd axis	done	After this contact turns ON, the ON-state will continue until the next
	X2B	4th axis		control is activated.
-	X2C			
	1	_	_	-
	X2E			
	X2F	Virtual axis	Home return done	Turns ON when the home return operation for the virtual axis is completed.
	X30	1st axis		A contact to monitor external home position input signal for the
	X31	2nd axis	Home	corresponding axis.
	X32	3rd axis	position	The input logic can be changed in the parameter-setting menu of the
	X33	4th axis		Configurator PM7.
	X34			
	1	-	-	-
ж Х	X37			
Ň	X38	1st axis		A contact to monitor external near home position input signal for the
	X39	2nd axis	Nearhoma	corresponding axis.
	X3A	3rd axis	Neal nome	The input logic can be changed in the parameter-setting menu of the
	X3B	4th axis		Contigurator PM7.
	X3C			
	Ι	-	-	-
	X3F			

C all	ontact ocation	Target axis	Name	Description			
	X40   X47	-	_	_			
	X48	1st axis					
	X49	2nd axis	Auxiliary	Turns ON when the corresponding positioning table of the corresponding			
/X4	X4A	3rd axis	contact	axis is executed.			
\$	X4B	4th axis					
	X4C   X4E	_	_	_			
	X4F	Virtual axis	Auxiliary contact	Turns ON when the corresponding positioning table of the virtual axis is executed.			
	X50	1 ot ovio	Limit +	Monitor contact of the limit + and			
	X51	ISL AXIS	Limit -	Decelerates to stop when the limit input that is on an extension of the			
	X52	2nd avis	Limit +	operating direction turns ON while the positioning unit is in positioning operation, JOG operation, or pulser operation.			
	X53	2110 0713	Limit -	The deceleration stop time during the limit input can be changed in the unit			
10	X54	3rd avis	Limit +	memory.			
WX!	X55	510 8715	Limit -	It will be the contact for the automatic inversion when performing a home			
-	X56	Ath avis	Limit +	The input logic can be changed in the parameter-setting menu of the			
	X57	411 015	Limit -	Configurator PM7.			
	X58   X5F	_	_	_			
	X60	1st axis		Turns ON when an error occurs on the corresponding axis.			
	X61	2nd axis	Error	The contacts of all axes turn ON if all axes have errors.			
	X62	3rd axis	annunciation	The details of the error can be confirmed in the error annunciation area of			
	X63	4th axis		the unit memory.			
	X64   X66	_	-	_			
X6	X67	Virtual axis	Error annunciation	Turns ON when an error occurs on the virtual axis.			
Ś	X68	1st axis		Turns ON when a warning occurs on the corresponding axis.			
	X69	2nd axis	Warning	The contacts of all axes turn ON if a warning occurs on all axes.			
	X6A	3rd axis	annunciation	The details of the warning can be confirmed in the warning annunciation			
	X6B	4th axis		area of the unit memory.			
	X6C   X6E	-	_	-			
	X6F	Virtual axis	Warning annunciation	Turns ON when a warning occurs on the virtual axis.			

a	Contact llocation	Target axis	Name	Description		
~	X70					
XX	I	-	_	-		
_	X7F					
	X80	1st axis		Make synchronous settings in the unit with the synchronous setting		
	X81	2nd axis	Synchronous	request contact (Y80 to Y83) turned ON after making synchronous		
	X82	3rd axis	setting done	setting changes with the program. The contact turns ON upon		
	X83	4th axis		completion of the setting changes.		
	X84					
	I	-	-	-		
X8	X87					
≥	X88	1st axis		Turns ON when the synchronous operation of the positioning unit is		
	X89	2nd axis	Synchronous	canceled with the synchronous setting cancel request contact (Y88 to Y8B) turned ON.		
	X8A	3rd axis	cancel alarm	The synchronous operation of axes cannot be executed if this contact is		
	X8B	4th axis		ON for the axes.		
	X8C					
	I	-	-	_		
	X8F					
	X90	1st axis	Slave axis	Makes gear ratio changes with the salve axis gear ratio change request		
	X91	2nd axis		contact (Y90 to Y93)		
	X92	3rd axis	change notice	The contact for the corresponding axis will turn ON after the gear ratio		
	X93	4th axis		changed.		
	X94					
	I	-	-	-		
6X	X97					
$\geq$	X98	1st axis		The clutch will start operating when the slave axis clutch ON re-request		
	X99	2nd axis	Slave axis	Contact (Y98 to Y9B) or clutch OFF request contacts (Y100 to 103) turn		
	X9A	3rd axis	notice	The contact for the corresponding axis will turn ON after completion of		
	X9B	4th axis		the operation of the clutch.		
	X9C					
	Ι	-	-	-		
	X9F					
0	X100					
VX1	Ι	-	-	-		
>	X10F					
-	X110					
VX1	I	-	_	-		
>	X11F					

C all	ontact ocation	Target axis	Name	Description
	Y0	All axes	System stop	Contact for requesting the system stop. When it turns ON, all axes will stop at the deceleration time 0.
	Y1	-	-	-
	Y2	_	-	-
	Y3	-	_	-
	Y4	-	_	-
	Y5	All axes	Axis group setting change request	This contact will turn ON after the axis group settings are changed. The unit turns OFF this contact after the setting change.
	Y6	-	_	-
WYO				Turn ON this signal when each positioning data (standard area) in the unit memory was changed.
	Y7	All axes	Request recalculation	The positioning data after the table number starting the recalculation specified in the unit memory can be restructured and will be executable by turning ON this signal. When restructuring of the positioning data completes, the recalculation done contact (X7) will turn ON.
				Note) It is used only when the positioning data has been rewritten by ladder programs.
	Y8	1st axis		The serve ON signal for the corresponding axis turns ON at the
	Y9	2nd axis		ON edge of this contact.
	YA	3rd axis	Servo ON	positioning unit is in program mode.
	YB	4th axis		To turn OFF the servo ON signal, turn ON the servo OFF request (Y50 to Y53).
				(The operation is the edge type.)
	YC			
		-	-	-
	Υŀ			Democrate the new Western control of the company of the sector
	Y10	1st axis		Requests the positioning control of the corresponding axis.
	Y11	2nd axis	Desitioning start	positioning control starting table number in the unit memory.
	Y12	3rd axis	Positioning start	(The operation is the edge type.)
	Y13	4th axis		If this contact turns ON while the positioning unit is in tool operation, a warning will be output.
	Y14			
	Ι	-	_	-
۲	Y16			
$^{>}$	Y17	Virtual axis	Positioning start	Requests the positioning control of the virtual axis.
	Y18	1st axis		Requests the home return of the corresponding axis.
	Y19	2nd axis	Home return start	(The operation is the edge type.)
	Y1A	3rd axis		If this contact turns ON while the positioning unit is in tool
	Y1B	4th axis		operation, a warning will be output.
	Y1C			
	I Y1E	-	-	-

C all	Contact Target axis Nar		Name	Description		
	Y1F	Virtual axis	Home return start	Requests the home return of the virtual axis. The home return of the virtual axis is possible only by data setting.		
	Y20	1 at avia	JOG forward			
	Y21	ISL AXIS	JOG reverse			
	Y22	Ond avia	JOG forward	Requests the JOG operation for the corresponding axis.		
	Y23	2nd axis	JOG reverse	(The operation is of level type.)		
	Y24	and avia	JOG forward			
	Y25	3rd axis	JOG reverse	If this contact turns ON while the positioning unit is in tool operation, a warning will be output.		
٧Y2	Y26	Ath and a	JOG forward			
_	Y27	4th axis	JOG reverse			
	Y28					
		_	-	-		
	Y2E					
	Y2E	Virtual axis	JOG forward	Requests the JOG operation of the virtual axis.		
	Y2F	VIItual axis	JOG reverse	(The operation is of level type.)		
	Y30	1st axis		Bequests the emergency step of the corresponding svie		
	Y31	2nd axis	Emorgonov stop	(The operation is of level type )		
	Y32	3rd axis	Liftergency stop	Note) The deviation counter cannot be cleared		
	Y33	4th axis				
	Y34					
		_	-	-		
	Y36					
Υ3	Y37	Virtual axis	Emergency stop	Requests the emergency stop of the virtual axis.		
Ž	Y38	1st axis		Deguasts the deceleration star of the corresponding svip		
	Y39	2nd axis	Decoloration stop	(The operation is of level type )		
	Y3A	3rd axis	Deceleration stop	Note) The deviation counter cannot be cleared		
	Y3B	4th axis				
	Y3C					
		-	-	-		
	Y3E					
	Y3F	Virtual axis	Deceleration stop	Requests the principle stop of the virtual axis.		

C all	ontact ocation	Target axis	Name	Description	
	Y40	1st axis			
	Y41	2nd axis	Pulser	Requests the permission for the pulser operation of the corresponding	
	Y42	3rd axis	enabled	axis. (The operation is of level type.)	
	Y43	4th axis			
	Y44				
		-	-	-	
	Y46				
WY4	Y47	Virtual axis	Pulser operation enabled	Requests the permission for the pulser operation of the virtual axis.	
>	Y48	1st axis		By turning ON this signal while the positioning unit is in L-point operation	
	Y49	2nd axis	J-point speed	the speed changes to the target speed in the specified	
	Y4A	3rd axis	change contact	acceleration/deceleration time and pattern.	
	Y4B	4th axis		(The operation is the edge type.)	
	Y4C				
		-	-	-	
	Y4E				
	Y4F	Virtual axis	J-point speed change contact	Changes the target speed during the JOG (J-point) positioning of the virtual axis.	
	Y50	1st axis			
	Y51	2nd axis	Servo OFF	The same ON signal is turned OEE at the ON adds of this contact	
	Y52	3rd axis	request	(The operation is the edge type )	
	Y53	4th axis			
	Y54				
	1	-	_	-	
	Y57				
۲5	Y58	1st axis		The second structure of the first structure is the second stability of the structure of the	
Ś	Y59	2nd axis	J-point	turns ON during the JOG (J-point) positioning of the corresponding axis.	
	Y5A	3rd axis	start	(The operation is the edge type.)	
	Y5B	4th axis			
	Y5C				
		-	_	-	
	Y5E				
	Y5F	Virtual axis	J-point positioning start	The positioning unit will go to the next table processing when this signal turns ON during the JOG (J-point) positioning of the virtual axis.	

C all	ontact ocation	Target axis	Name	Description
	Y60	1st axis		Requests the error clear of the corresponding axis.
	Y61	2nd axis	Error clear	The processing to recover from errors is performed and the error logs are
	Y62	3rd axis	request	cleared by turning ON this signal.
	Y63	4th axis		Note) Unrecoverable errors cannot be recovered even if this signal turns ON.
	Y64   Y66	_	_	_
۲6	Y67	Virtual axis	Error clear request	Requests the error clear of the virtual axis.
Š	Y68	1st axis		
	Y69	2nd axis	Request	Requests the warning clear of the corresponding axis.
	Y6A	3rd axis	warning clear	The warning logs are cleared by turning ON this signal.
	Y6B	4th axis		
	Y6C			
		-	-	_
	Y6E			
	Y6F	Virtual axis	Request warning clear	Requests the warning clear of the virtual axis.
WY7	Y70   Y7F	_	_	_
	Y80	1st axis		
	Y81	2nd axis	Synchronous	This contact will turn ON after the synchronous operation settings are
	Y82	3rd axis	request	The unit turns OFF this contact after the setting change.
	Y83	4th axis		
<b>/</b> 8	Y84   Y87	_	_	-
$\mathbf{\tilde{s}}$	Y88	1st axis		
	Y89	2nd axis	Synchronous	Turns ON the contact for the axis to cancel the synchronous operation.
	Y8A	3rd axis	cancel request	The unit will not perform the synchronous operation of the axis for which this contact is ON.
	Y8B	4th axis		
	Y8C			
	 Y8F	_	_	

al'	Contact location	Target axis	Name	Description		
	Y90	1st axis		A gear ratio change is made with the contact for the corresponding		
	Y91	2nd axis	Slave axis	axis turned ON while the positioning unit is in synchronous		
	Y92	3rd axis	request	operation.		
	Y93	4th axis		(The operation is the edge type.)		
	Y94					
	I	-	-	_		
6	Y97					
$\leq$	Y98	1st axis		The engagement of the clutch starts by turning ON the contact for		
	Y99	2nd axis	Slave axis	the corresponding axis while the positioning unit is in synchronous		
	Y9A	3rd axis	clutch ON reauest	No axes start unless the clutch is used.		
	Y9B	4th axis		(Set the operation to level type, rising edge, or falling edge.)		
	Y9C					
		-	_	_		
	Y9F					
	Y100	1st axis		The disengagement of the clutch starts by turning ON the contact for the corresponding axis while the positioning unit is in		
	Y101	2nd axis	Slave axis	synchronous operation.		
	Y102	3rd axis	clutch OFF	No axes start unless the clutch is used.		
10		0.2.2	request	(Set the operation to rising edge or falling edge.)		
γ	Y103	4th axis		These signals will be disabled while the slave axis clutch ON request signal is set to level type.		
	Y104					
	1	-	_	-		
	Y10F					
1	Y110					
31	- I	-	-	_		
5	Y11F					

## 17.3 Entire Configuration of Memory Unit Area

The unit memory is in control of parameter and positioning data set values for the positioning unit.

All set values are set with the programming tool software or a user program.

Area name	Unit memory address		Name of each individual area	
		Setting parame	ter control area	
		Operating speed factor area		
		Axis group setting area		
		Current value u	pdate data area	
-		Positioning tabl	e setting area	
Common area	UM 00000 to UM 003FF	Positioning con	Vame of each individual area         pontrol area         tor area         tor area         ea         a data area         ting area         rea         a clear area         in & clear area         in onitor area         area         in monitor area         area         in onitor area         area	
	urea nameUnit memory addressommon 'eaUM 00000 to UM 003FFSet Op Axi Cu Pos Err Wa 	Error annunciat	ion & clear area	
Area name Common area Each axis information area (Note) Each axis setting		Warning annun	ciation & clear area	
		Pulse count cor	ntrol area	
		Synchronous control monitor area		
		System operation setting area		
	UM 00400 to UM 007FF	1st axis	Each axis information & monitor area	
Each axis		2nd axis	Each axis information & monitor area	
information area (Note)		3rd axis	Each axis information & monitor area	
(Note)		4th axis	Each axis information & monitor area	
		Setting parameter control area         Operating speed factor area         Axis group setting area         Current value update data area         Positioning table setting area         Positioning control area         Error annunciation & clear area         Warning annunciation & clear area         Pulse count control area         Synchronous control monitor area         System operation setting area         1st axis       Each axis information & monitor area         2nd axis       Each axis information & monitor area         3rd axis       Each axis information & monitor area         Virtual axis       Each axis information & monitor area         1st axis       Each axis information & monitor area         Virtual axis       Each axis information & monitor area         Yitual axis       Each axis information & monitor area         Positioning data setting area       (600 standard points and 25 expansion points)         Parameter setting area       (600 standard points and 25 expansion points)         Parameter setting area       Positioning data setting area         3rd axis       Positioning data setting area         4th axis       Positioning data setting area         (600 standard points and 25 expansion points)       Parameter setting area         (6		
	LIM 00800		Parameter setting area	
	to UM 02FFF	1st axis	Positioning data setting area (600 standard points and 25 expansion points)	
	1111 02000		Parameter setting area	
	to UM 05FFF	2nd axis	Positioning data setting area (600 standard points and 25 expansion points)	
Fach avia	1114 05000		Parameter setting area	
setting	to UM 07FFF	3rd axis	Positioning data setting area (600 standard points and 25 expansion points)	
Each axis setting	1114 00000		Parameter setting area	
	to UM 0AFFF	4th axis	Positioning data setting area (600 standard points and 25 expansion points)	
	LIM 12000		Parameter setting area	
Common area Each axis information area (Note) Each axis setting	UM 12000 to UM 147FF	Virtual axis	Positioning data setting area (600 standard points and 25 expansion points)	

(Note): Check that the positioning done flag (X0) is turned ON in the case of reading each axis information area with a program.

# 17.4 Details of Common Area in Unit Memory

## 17.4.1 Common Area Configuration

The common area is allocated to the head of the unit memory to make common settings for each axis.

	Unit memory map			
			UM 00085	Setting parameter control area
	Common area	Common areas	UM 00088	Operation speed factor area
UM 003FF		1	UM 000B0 - UM 000B4	Axis group setting area
UM 00400			UM 000C0 - UM 000D7	Current value update data area
	Fach avia		UM 00100 - UM 00107	Positioning table setting area
	information area		UM 00108 - UM 0010F	Positioning control area
			UM 00111 - UM 001A7	Error annunciation & clear area
UM 00800			UM 001A9 - UM 0023F	Warning annunciation & clear area
			UM 00240 - UM 0024F	Pulse count control area
			UM 002B0 - UM 002BF	Synchronous control monitor area
			UM 00389	System operation setting area
	Each axis setting area			
UM 16000 UM 16400	Synchronous control setting area			

## 17.4.2 Setting Parameter Control Area

Set a recalculation starting table number in order to recalculate the positioning data in the standard area.

Unit memory no. (Hex)	Name	Description	Default	Setting range	Set unit
UM 00085	Recalculation starting table number If the ON state of the recalculation request signal (contact Y7) is detected, the positioning unit will recalculate positioning data on all axes beginning with this table number up to number 600.		1	1 to 600	-

### 17.4.3 Operating Speed Factor Area

Unit memory no. (Hex)	Name	Description	Default	Setting range	Set unit
UM 00088	Operating speed factor	It is possible to perform all types of axial control (positioning, JOG, and home return control) at a magnified rate of this speed.	100	1 to 100	%
		Values can be input in percent within a range of 1 to 100 (%).			

## 17.4.4 Axis Group Setting Area

Set an interpolation group on an axis-by-axis basis in this area.

Unit memory no. (Hex)	Name	Description						
UM 000B0	Group A axis settings	Make independent and interpolation settings for each axis in this area. In the case of interpolation, each axis belongs to group A, B, C, or D. For example, if the 1st, 2nd, and 3rd axes belong to group A for three-axis interpolation, set the three corresponding bits for the interpolation settings for group A to 1. In the case of single						
UM 000B1	Group B axis settings	independe correspon A maximu for the sar	independent settings, the axis will not belong to any group. Then turn ON the corresponding bit for the following independent axis settings. A maximum of three axes can be set for interpolation per group. Duplicated settings for the same axis in different groups are not possible.					
	Group C axis settings	bit	Name	Default	Description			
UM 000B2		settings	0	Group attribute of 1st axis	0	0: Not belongs to any group.		
		1	Group attribute of 2nd axis	0	1: Belongs to a group.			
UM 000B3	Group D axis settings	Group D axis	2	Group attribute of 3rd axis	0	An error occurs if four or more bits for		
			3	Group attribute of 4th axis	0	the same group are set to 1 or the same axis is set to 1 for another group.		
		15 to 4	-	_	-			

Name	Description							
Independent axis settings	Set the co	Set the corresponding bit to 1 in this area if the axis is not related to interpolation.						
	Independent axis settings	bit	Name	Default	Description			
		0	Group attribute of 1st axis	0	0: Not belongs to any group.			
		1	Group attribute of 2nd axis	0	1: Belongs to a group.			
		and comige		g-	2	Group attribute of 3rd axis	0	An error will occur if the same
					3	Group attribute of 4th axis	0 axis is set to	axis is set to 1 in another group.
		15 to 4	_	_	_			
	Name Independent axis settings	Name Set the con bit 0 1 2 3 15 to 4	Name     Demonstrate       Independent axis settings     Set the corresponding bit to 1 in this area       0     Group attribute of 1st axis       1     Group attribute of 2nd axis       2     Group attribute of 3rd axis       3     Group attribute of 4th axis       15 to 4     -	Name         Description           Independent axis settings         Set the corresponding bit to 1 in this area if the axis           0         Group attribute of 1st axis         0           1         Group attribute of 2nd axis         0           2         Group attribute of 3rd axis         0           3         Group attribute of 4th axis         0           15 to 4         -         -				

### 17.4.5 Current Value Update Data Area

To change the current value of each axis under the control of the positioning unit, store the changed coordinates in this area and turn ON the current value update request flag.

Unit memory no. (Hex)	Name	Description				
		Only when the corresponding bit for each axis changes to 1 from 0, the current coordinate controlled by the positioning unit to the following current value. After the change, the positioning unit will clear the corresponding bits to 0 automatically.				
		bit	Name	Default	Description	
	Current value	0	Current value update request for 1st axis	0	0: No change 1: Update the current value of the	
UM 000C0	update request flag	1	Current value update request for 2nd axis	0	corresponding axis (The positioning unit will set the	
		2	Current value update request for 3rd axis	0	execution.)	
		3	Current value update request for 4th axis	0		
		15 to 4	-	-	-	
UM 000C8	Current value	Stores the coordinate to be preset as the undating of the current value of 1st axis				
UM 000C9	of 1st axis					
UM 000CA	Current value	Storage the coordinate to be present as the undefine of the current value of 2nd axis				
UM 000CB	of 2nd axis	Stores the coordinate to be preset as the updating of the current value of 2nd a.				
UM 000CC	Current value	Stores the	poordinato to bo propot or	a tha undat	ing of the ourrent value of 2rd avia	
UM 000CD	of 3rd axis	Stores the coordinate to be preset as the updating of the current value of 3rd axis.				
UM 000CE	Current value	Stored the exercting to the present of the undefine of the surrent value of 4th suite				
UM 000CF	of 4th axis	Stores the coordinate to be preset as the updating of the current value of 4th axis.				
UM 000D6	Current value	Stores the coordinate to be proceed as the updating of the current value of virtual avia				
UM 000D7	of virtual axis		oordinate to be preset at		ng of the current value of villual axis.	

## 17.4.6 Positioning Control Starting Table Number Setting Area

Set the starting table number of positioning data on each axis at the time of staring positioning control.

The setting ranges are 1 to 600 for the standard area and 10001 to 10025 for the extended area.

Unit memory no. (Hex)	Name	Description	Default	Setting range	Set unit
UM 00100	The starting table number for the positioning control of 1st axis	Stores the positioning control starting table number of the 1st axis	1	1 to 600 10001 to 10025	_
UM 00101	The starting table number for the positioning control of 2nd axis	Stores the positioning control starting table number of the 2nd axis	1	1 to 600 10001 to 10025	_
UM 00102	The starting table number for the positioning control of the 3rd axis	Stores the positioning control starting table number of the 3rd axis	1	1 to 600 10001 to 10025	_
UM 00103	The starting table number for the positioning control of 4th axis	Stores the positioning control starting table number of the 4th axis	1	1 to 600 10001 to 10025	_
UM 00107	The starting table number for the positioning control of the virtual axis	Stores the positioning control starting table number of the virtual axis	1	1 to 600 10001 to 10025	_

## 17.4.7 Positioning Control Area

- Set the number of repetitions of positioning control per axis.
- The positioning unit repeats positioning control for the number of repetitions set and finishes operating.

The number of repetitions will be reset to the default value on completion of positioning control.

Unit memory no. (Hex)	Name	Description	Default	Setting range	Set unit
UM 00108	Number of 1st axis positioning repetitions	Stores the number of times for repeating the operation starting from the positioning control starting table number of the 1st axis until the E-point.	0	0 to 255	Times
		If 255 is stored, the positioning unit repeats positioning control an unlimited number of times until you manually stop the operation.			
UM 00109	Number of 2nd axis positioning repetitions	Stores the number of times for repeating the operation starting from the positioning control starting table number of the 2nd axis until the E-point.	0	0 to 255	Times
		If 255 is stored, the positioning unit repeats positioning control an unlimited number of times until you manually stop the operation.			
UM 0010A	Number of 3rd axis positioning repetitions	Stores the number of times for repeating the operation starting from the positioning control starting table number of the 3rd axis until the E-point.	0	0 to 255	Times
		If 255 is stored, the positioning unit repeats positioning control an unlimited number of times until you manually stop the operation.			
UM 0010B	Number of 4th axis positioning repetitions	Stores the number of times for repeating the operation starting from the positioning control starting table number of the 4th axis until the E-point.	0	0 to 255	Times
		If 255 is stored, the positioning unit repeats positioning control an unlimited number of times until you manually stop the operation.			
UM 0010F	Number of Virtual axis positioning repetitions	Stores the number of times for repeating the operation starting from the positioning control starting table number of the virtual axis until the E-point.	0	0 to 255	Times
		If 255 is stored, the positioning unit repeats positioning control an unlimited number of times until you manually stop the operation.			

### 17.4.8 Error Annunciation & Clear Area

If errors (involving a stoppage) occur, data on the errors along with the number of errors will be stored on an axis-by-axis basis in this area. If the error clear is executed, the errors and the number of errors that have occurred will be cleared once. Then errors will be judged again. Therefore, the same errors will occur if the error conditions continue. If a unit level error, such as an entire network failure occurs, the data on all the axes will be stored in the error annunciation buffer. Up to 7 errors are stored in the error log.

Errors can be cleared not only in this area but also with the error clear contact.

Unit memory no. (Hex)	Name	Description				
		Clears errors on an axis-by-axis basis				
		bit	Name	Default	Description	
		0	Error clear for 1st axis	0	0: No error clear	
	Frror clear settings on an	1	Error clear for 2nd axis	0	0 to 1: Error clear executed	
UM 00111	axis-by-axis basis	2	Error clear for 3rd axis	0	set the value to 0	
		3	Error clear for 4th axis	0	automatically after execution.)	
		15 to 4	_	-	-	
UM 00129	No. of occurrences of errors on 1st axis	Annunciat	es the number of occurr	ences of e	errors on the 1st axis.	
UM 0012A	1st axis error code					
UM 0012B	annunciation buffer 1					
UM 0012C	1st axis error code					
UM 0012D	annunciation buffer 2					
UM 0012E	1st axis error code					
UM 0012F	annunciation buffer 3					
UM 00130	1st axis error code	The latest error codes are stared in order from buffer such as 1				
UM 00131	annunciation buffer 4	I ne latest error codes are stored in order from buffer number 1.				
UM 00132	1st axis error code	1				
UM 00133	annunciation buffer 5					
UM 00134	1st axis error code					
UM 00135	annunciation buffer 6					
UM 00136	1st axis error code					
UM 00137	annunciation buffer 7					
UM 00139	No. of occurrences of errors on 2nd axis	Annunciates the number of occurrences of errors on the 2nd axis.			errors on the 2nd axis.	
UM 0013A	2nd axis error code					
UM 0013B	annunciation buffer 1	A code will be annunciated if an error occurs.				
UM 0013C	2nd axis error code					
UM 0013D	annunciation buffer 2	A code will be annunciated if an error occurs.				
UM 0013E	2nd axis error code	A code will be appuncieted if an error ecourt				
UM 0013F	annunciation buffer 3	A code will be annunciated if an error occurs.				

Unit memory no. (Hex)	Name	Description		
UM 00140	and ovia array and appunciation buffer 4			
UM 00141		A code will be annunciated if an entri occurs.		
UM 00142	and axis array and appunciation buffer E	A code will be appuncieted if an error accure		
UM 00143		A code will be all functated if all error occurs.		
UM 00144	2nd axis arrar code annunciation buffer 6	A code will be ensured at a stress ecours		
UM 00145		A code will be annunciated if an error occurs.		
UM 00146	and axis array and annunciation buffer 7			
UM 00147		A code will be almunciated if all enor occurs.		
UM 00149	No. of occurrences of errors on 3rd axis	Annunciates the number of occurrences of errors on the 3rd axis.		
UM 0014A	3rd axis error code annunciation huffer 1	A code will be appunciated if an error occurs		
UM 0014B		A code will be annunciated if an error occurs.		
UM 0014C	3rd axis error code annunciation buffer 2	A code will be annunciated if an error occurs		
UM 0014D				
UM 0014E	3rd axis error code annunciation buffer 3	A code will be appunciated if an error occurs		
UM 0014F				
UM 00150	3rd axis error code annunciation buffer 4	A code will be annunciated if an error occurs.		
UM 00151				
UM 00152	3rd axis error code annunciation buffer 5	A code will be annunciated if an error occurs.		
UM 00153				
UM 00154	3rd axis error code annunciation buffer 6	A code will be appunciated if an error occurs		
UM 00155				
UM 00156	3rd axis error code annunciation buffer 7	A code will be annunciated if an error occurs.		
UM 00157				
UM 00159	No. of occurrences of errors on 4th axis	Annunciates the number of occurrences of errors on the 4th axis.		
UM 0015A	Ath axis error code annunciation buffer 1	A code will be appuncieted if an error accure		
UM 0015B		A code will be arritunciated if an error occurs.		
UM 0015C	4th axis error code annunciation buffer 2	A code will be annunciated if an error occurs		
UM 0015D				
UM 0015E	4th axis error code annunciation buffer 3	A code will be annunciated if an error occurs.		
UM 0015F				
UM 00160	4th axis error code annunciation buffer 4	A code will be appunciated if an error occurs		
UM 00161				
UM 00162	4th axis error code annunciation buffer 5	A code will be annunciated if an error occurs.		
UM 00163				
UM 00164	4th axis error code annunciation buffer 6	A code will be appunciated if an error occurs		
UM 00165				
UM 00166	4th axis error code annunciation buffer 7	A code will be annunciated if an error occurs		
UM 00167				
UM 00199	No. of occurrences of errors on virtual axis	Annunciates the number of occurrences of errors on the virtual axis.		

Unit memory no. (Hex)	Name	Description		
UM 0019A	Virtual axis error code	A code will be appuncieted if an error accure		
UM 0019B	annunciation buffer 1	A code will be armunciated if an enor occurs.		
UM 0019C	Virtual axis error code	A code will be annunciated if an error occurs.		
UM 0019D	annunciation buffer 2			
UM 0019E	Virtual axis error code	A code will be annunciated if an error occurs.		
UM 0019F	annunciation buffer 3			
UM 001A0	Virtual axis error code	A code will be annunciated if an error occurs.		
UM 001A1	annunciation buffer 4			
UM 001A2	Virtual axis error code	A gode will be appundicted if an error acquire		
UM 001A3	annunciation buffer 5			
UM 001A4	Virtual axis error code	A code will be annunciated if an error occurs.		
UM 001A5	annunciation buffer 6			
UM 001A6	Virtual axis error code	A code will be annunciated if an error occurs.		
UM 001A7	annunciation buffer 7			
### 17.4.9 Warning Annunciation & Clear Area

If warnings (not involving a stoppage) occur, data on the warnings along with the number of warnings will be stored on an axis-by-axis basis in this area. If the warning clear is executed, the warnings and the number of warnings occurred will be cleared once. Then warnings will be judged again. Therefore, the same warnings will occur if the warning conditions continue. The number of warnings for each axis is annunciated. If a total warning occurs, the data on all the axes will be stored in the warning annunciation buffer. Up to 7 warnings are stored in the warning log.

Unit memory no. (Hex)	Name	Description				
		Clears warnings on an axis-by-axis basis				
		bit	Name	Default	Description	
		0	Warning clear on 1st axis	0	0: No warning clear	
		1	Warning clear on 2nd axis	0	0 to 1: Warning	
UM 001A9	Warning clear settings on	2	Warning clear on 3rd axis	0	(The positioning	
	axis-dy-axis dasis	3	Warning clear on 4th axis	0	unit will set the	
					value to 0	
					after execution.)	
		15 to 4	_	-	-	
UM 001C1	No. of occurrences of warnings	Annuncia axis	ates the number of occurre	ences of w	arnings on the 1st	
UM 001C2	1st axis warning code					
UM 001C3	annunciation buffer 1					
UM 001C4	1st axis warning code					
UM 001C5	annunciation buffer 2					
UM 001C6	1st axis warning code					
UM 001C7	annunciation buffer 3					
UM 001C8	1st axis warning code	The latest warning codes are stored in order from buffer number				
UM 001C9	annunciation buffer 4	1.				
UM 001CA	1st axis warning code					
UM 001CB	annunciation buffer 5					
UM 001CC	1st axis warning code					
UM 001CD	annunciation buffer 6					
UM 001CE	1st axis warning code					
UM 001CF	annunciation buffer 7					
UM 001D1	No. of occurrences of warnings on the 2nd axis	Annunci axis	ates the number of occurre	ences of w	varnings on the 2nd	
UM 001D2	2nd axis warning code	A code v	will be annunciated if a way		rs	
UM 001D3	annunciation buffer 1	A code v			13.	
UM 001D4	2nd axis warning code	A code v	will be annunciated if a way	mina occu	rs	
UM 001D5	annunciation buffer 2					
UM 001D6	2nd axis warning code	A code will be appunciated if a warning occure				
UM 001D7	annunciation buffer 3					

Warnings can be cleared not only in this area but also with the warning clear contact.

Unit memory no. (Hex)	Name	Description	
UM 001D8	2nd axis warning code		
UM 001D9	annunciation buffer 4	A COLO WIII DE ANNUNCIALEU II A WANNING UCCUIS.	
UM 001DA	2nd axis warning code	A code will be appundicted if a warping accure	
UM 001DB	annunciation buffer 5	A code will be annunciated if a warning occurs.	
UM 001DC	2nd axis warning code	A code will be appunciated if a warping occure	
UM 001DD	annunciation buffer 6	A code will be annunciated if a warning occurs.	
UM 001DE	2nd axis warning code	A code will be appunciated if a warning occurs	
UM 001DF	annunciation buffer 7	A code will be annunciated if a warning occurs.	
UM 001E1	No. of occurrences of warnings on the 3rd axis	Annunciates the number of occurrences of warnings on the 3rd axis	
UM 001E2	3rd axis warning code	A code will be appunciated if a warping occurs	
UM 001E3	annunciation buffer 1	A code will be annunciated if a warning occurs.	
UM 001E4	3rd axis warning code	A code will be appunciated if a warning occurs	
UM 001E5	annunciation buffer 2	A code will be allifunciated if a warning occurs.	
UM 001E6	3rd axis warning code	A code will be appunciated if a warning occurs	
UM 001E7	annunciation buffer 3	A code will be allitunelated it a warning occurs.	
UM 001E8	3rd axis warning code	A code will be appunciated if a warning occurs	
UM 001E9	annunciation buffer 4		
UM 001EA	3rd axis warning code	A code will be annunciated if a warning occurs	
UM 001EB	annunciation buffer 5	A code will be allitunelated it a warning occurs.	
UM 001EC	3rd axis warning code	A code will be appunciated if a warning occurs	
UM 001ED	annunciation buffer 6		
UM 001EE	3rd axis warning code	A code will be appunciated if a warning occurs	
UM 001EF	annunciation buffer 7		
UM 001F1	No. of occurrences of warnings on the 4th axis	Annunciates the number of occurrences of warnings on the 4th axis	
UM 001F2	4th axis warning code	A code will be appunciated if a warning occurs	
UM 001F3	annunciation buffer 1	A code will be allitunelated it a warning occurs.	
UM 001F4	4th axis warning code	A code will be annunciated if a warning occurs	
UM 001F5	annunciation buffer 2		
UM 001F6	4th axis warning code	A code will be appunciated if a warning occurs	
UM 001F7	annunciation buffer 3		
UM 001F8	4th axis warning code	A code will be annunciated if a warning occurs.	
UM 001F9	annunciation buffer 4		
UM 001FA	4th axis warning code	A code will be appunciated if a warning occurs	
UM 001FB	annunciation buffer 5		
UM 001FC	4th axis warning code	A code will be annunciated if a warning occurs.	
UM 001FD	annunciation buffer 6		
UM 001FE	4th axis warning code	A code will be annunciated if a warning occurs	
UM 001FF	annunciation buffer 7		
UM 00231	No. of occurrences of warnings on the virtual axis	Annunciates the number of occurrences of warnings on the virtual axis	

Unit memory no. (Hex)	Name	Description	
UM 00232	Virtual axis warning code	A code will be appunciated if a warning occure	
UM 00233	annunciation buffer 1	A code will be annunciated if a warning occurs.	
UM 00234	Virtual axis warning code	A code will be appuncieted if a warping acquire	
UM 00235	annunciation buffer 2	A code will be annunciated it a warning occurs.	
UM 00236	Virtual axis warning code	A code will be annunciated if a warning occurs.	
UM 00237	annunciation buffer 3		
UM 00238	Virtual axis warning code	A code will be annunciated if a warning occurs.	
UM 00239	annunciation buffer 4		
UM 0023A	Virtual axis warning code	A code will be annunciated if a warning occurs.	
UM 0023B	annunciation buffer 5		
UM 0023C	Virtual axis warning code	A code will be ensurated if a warning accure	
UM 0023D	annunciation buffer 6	A code will be annunciated if a warning occurs.	
UM 0023E	Virtual axis warning code	A code will be appunciated if a warping occure	
UM 0023F	annunciation buffer 7	A code will be annunciated if a warning occurs.	

# 17.4.10 Pulse Count Control Area

### Makes input pulse changes if high-speed pulses are set for pulse input.

Unit memory no. (Hex)	Name	Description						
		The pulse	The pulse input will be counted when the corresponding bit for each axis is set to 0.					
		This flag will be enabled only if the pulse input application is set to high-speed counter.						
		bit Name Default			Description			
		0	1st axis pulse count enabled	0	0: Pulse input count enabled			
		1	2nd axis pulse count enabled	0	1: Pulse input count disabled			
		2	3rd axis pulse count enabled	0				
	Pulse count	3	4th axis pulse count enabled	0				
UM 00240	enable flag	4	-	-				
		5	-	-				
		6	-	-	-			
		7	-	-				
		15 to 8	-	-				
		The puls	e input value will be changed t	to the set n	ulse count when the			
		correspo This flag change.	is an edge trigger. Be sure to	change the	flat to 0 from 1 at the time of the			
	Pulse count	bit	Name	Default	Description			
		0	1st axis pulse count change	0	0:			
		1	2nd axis pulse count change	0	Pulse input count change disabled			
UM 00241		2	3rd axis pulse count change	0	Pulse input count change enabled			
	request flag	3	4th axis pulse count change	0				
		4	-	-				
		5	-	-				
		6	-	-	-			
		7	-	-				
		15 to 8	-	-				
UM 00248	Pulse input							
UM 00249	changed value of 1st axis							
UM 0024A	Pulse input							
UM 0024B	changed value of 2nd axis	Set the d	esired pulse input value to rer	blace the cu	irrent value for each axis			
UM 0024C	Pulse input	Section						
UM 0024D	changed value of 3rd axis							
UM 0024E	Pulse input							
UM 0024F	4th axis	T						

# 17.4.11 Synchronous Control Monitor Area

Unit memory no. (Hex)	Name	Description			Default		
		Stores the s	Stores the setting status of the master axis under synchronous control.				
		Stored value					
		Under		Under synchronous	Maste	r axis	
		synchron	ization	cancellation			
		FFFFH		FFFFH	No synchronous		
					setting	js	
		0000H		8000H	The m	aster axis is	
	Monitoring information				subjec	t to monitoring.	
UM 002B0	of synchronous master	0001H		8001H	1st ax	is	FFFFH
	axis for the 1st axis	0002H		8002H	2nd ax	kis	
		0003H		8003H	3rd ax	is	
		0004H		8004H	4th ax	is	
		0010H		8010H	Virtual	axis	
		0021H		8021H	Pulse	input 1	
		0022H		8022H	Pulse	input 2	
		0023H		8023H	Pulse	input 3	
		0024H		8024H	Pulse	input 4	
		The state axis is sto	of the s pred.	ynchronous operatin	g functi	on set for the	
	Monitoring selection	bit	bit Functions			Setting	
UM 002B1	state of synchronous output function for 1st axis	0	Electro	nic gear setting		0: Yes	0000H
		1 Clutch operation settings 1: No		1: No			
		2	2 Electronic cam operation settings				
		3 to 15					
UM 002B2	Monitoring information of synchronous master axis for the 2nd axis	Refer to t	Refer to the description for the 1st axis.			FFFFH	
UM 002B3	Monitoring selection state of synchronous output function for 2nd axis	Refer to t	Refer to the description for the 1st axis.			0000H	
UM 002B4	Monitoring information of synchronous master axis for the 3rd axis	Refer to t	Refer to the description for the 1st axis.			FFFFH	
UM 002B5	Monitoring selection state of synchronous output function for 3rd axis	Refer to t	Refer to the description for the 1st axis.			0000H	
UM 002B6	Monitoring information of synchronous master axis for the 4th axis	Refer to the description for the 1st axis.		FFFFH			
UM 002B7	Monitoring selection state of synchronous output function for 4th axis	Refer to t	Refer to the description for the 1st axis.			0000H	
UM 002BE	Monitoring information of synchronous master axis for the virtual axis	Refer to t	Refer to the description for the 1st axis.		FFFFH		

This is an area for monitoring the setting status of synchronous control.

Unit memory no. (Hex)	Name	Description	Default
UM 002BF	Monitoring selection state of synchronous output function for virtual axis	0000H (fixed)	0000H

# 17.4.12 System Operation Setting Area

Unit memory no. (Hex)	Name	Description
(Hex) UM 00389	Deceleration stop operation	<ul> <li>Specify the operation of the positioning unit with the deceleration stop request signal activated (turned ON).</li> <li>0: Deceleration stop <ul> <li>While the positioning unit is in repetitive operation, the positioning unit will come to a stop after the position moves to E-point of the repetitive target.</li> </ul> </li> <li>1: Pause <ul> <li>Performs a deceleration stop, and positioning will restart when the deceleration stop request signal is canceled (turned OFF).</li> <li>The positioning unit will perform the same operation as a deceleration stop unless the positioning unit is in positioning operation.</li> <li>While the positioning unit is in repetitive operation, the positioning unit will come to a stop after the position moves to the E-point of the repetitive target, and repetitive operation will restart when the deceleration stop request signal is canceled (turned OFF).</li> </ul> </li> <li>If a system stop or emergency stop is executed while the positioning unit is paused, the pause state will be canceled and the operation will not restart with the deceleration stop request signal is canceled (turned OFF).</li> </ul>
		Default: 0

This is an area for changing the operation of the positioning unit.

# 17.5 Details of Each Axis Information Area in Unit Memory

# 17.5.1 Each Axis Information & Monitor Area



i de la

NOTE

Check that the positioning ready flag (X0) is turned ON in the case of reading each axis information area with a program.

## 17.5.2 Each Axis Information & Monitor Area

#### ■ 1st axis information

Unit memory no. (Hex)	Name	Description			Default	Setting range	Set unit
		Stores I/O information connected to each axis.					•
		bit	Name	Defaul	t Dese	cription	
		0	Limit +	0	0: N	on-active	
UM 00431	External terminal input	1	Limit -	0	1: Ac	1: Active	
		2	Near home	0			
		3	Home position	0			
		15 to 4	-	-	-		
UM 00434		Stores the max	imum value of the				
UM 00435	Deviation of 1st axis	deviation (the d pulse input valu	ifference between	the value).	_	-	-
UM 00436	Pulse input value of 1st	Stores pulse input the pulse input feedback pulse	Stores pulse input values according to the pulse input application (e.g., pulser, feedback pulse, or counter).				
UM 00437	axis	Pulse input values will be integrated and stored until the pulse input application is changed or the pulse input is cleared.		-	-	puise	
UM 00438	Implementation or implementation done table of 1st axis	Stores the positioning table number being executed or done.			1	1 to 600	_
UM 00439	Auxiliary output code of 1st axis	Stores the auxiliary output code.			0		-
		Stores the set v positioning repe	value for the numb eat count.	er of			
UM 0043A	Repeat count set value of 1st axis	This area will be set to 1 if the positioning repeat is not implemented.			0	0 to 255	Times
		Stores 255 if the number of positioning repeat times is unlimited.					
		Stores the num operation.	ber of repeat cour	nt in			
UM 0043B	Repeat count current value 1st axis	Stores 1 if the positioning repeat is not implemented.			0	0 to 65,535	Times
		Returns to 0 if the number of repeat count exceeds the upper limit.					
UM 0043C	Current value of 1st avia	Stores the our			0		pulso
UM 0043D					0		puise
UM 0043E	Unit system conversion	Stores the curre	ent value after unit		0		
UM 0043F	current value of 1st axis	conversion.		0	-	-	

### 2nd axis information

Unit memory no. (Hex)	Name	Description
UM 00471	External terminal input monitor of 2nd axis	Refer to the description for the 1st axis.
UM 00474	Deviation of 2nd axis	Refer to the description for the 1st axis.
UM 00476	Pulse input value of 2nd axis	Refer to the description for the 1st axis.
UM 00478	Implementation or implementation done table of 2nd axis	Refer to the description for the 1st axis.
UM 00479	Auxiliary output code of 2nd axis	Refer to the description for the 1st axis.
UM 0047A	Repeat count set value of 2nd axis	Refer to the description for the 1st axis.
UM 0047B	Repeat count current value of 2nd axis	Refer to the description for the 1st axis.
UM 0047C	Current value of 2nd avia	Poter to the description for the 1st avia
UM 0047D		
UM 0047E	Lipit avatam conversion aurrent value of 2nd avia	Poter to the description for the 1st avia
UM 0047F	Onit system conversion current value of 2nd axis	

#### 3rd axis information

Unit memory no. (Hex)	Name	Description	
UM 004B1	External terminal input monitor of 3rd axis	Refer to the description for the 1st axis.	
UM 004B4	Deviation of 3rd axis	Refer to the description for the 1st axis.	
UM 004B6	Pulse input value of 3rd axis	Refer to the description for the 1st axis.	
UM 004B8	Implementation or implementation done table of 3rd axis	Refer to the description for the 1st axis.	
UM 004B9	Auxiliary output code of 3rd axis	Refer to the description for the 1st axis.	
UM 004BA	Repeat count set value of 3rd axis	Refer to the description for the 1st axis.	
UM 004BB	Repeat count current value of 3rd axis	Refer to the description for the 1st axis.	
UM 004BC	Current value of 2rd avia	Poter to the description for the 1st avia	
UM 004BD			
UM 004BE	Light average conversion surrent value of 2rd avia	Poter to the description for the 1st avia	
UM 004BF	onit system conversion current value of 3rd axis	Refer to the description for the 1st axis.	

Unit memory no. (Hex)	Name	Description	
UM 004F1	External terminal input monitor of 4th axis	Refer to the description for the 1st axis.	
UM 004F4	Deviation of 4th axis	Refer to the description for the 1st axis.	
UM 004F6	Pulse input value of 4th axis	Refer to the description for the 1st axis.	
UM 004F8	Implementation or implementation done table of 4th axis	Refer to the description for the 1st axis.	
UM 004F9	Auxiliary output code of 4th axis	Refer to the description for the 1st axis.	
UM 004FA	Repeat count set value of 4th axis	Refer to the description for the 1st axis.	
UM 004FB	Repeat count current value of 4th axis	Refer to the description for the 1st axis.	
UM 004FC	Current value of 4th avia	Pefer to the description for the 1st avia	
UM 004FD			
UM 004FE	Unit system conversion current value of	Poter to the description for the 1st avis	
UM 004FF	4th axis	Refer to the description for the 1st axis.	

### ■ 4th axis information

#### Virtual axis information

Unit memory no. (Hex)	Name	Description	
UM 005F8	Implementation or implementation done table of virtual axis	Refer to the description for the 1st axis.	
UM 005F9	Auxiliary output code of virtual axis	Refer to the description for the 1st axis.	
UM 005FA	Repeat count set value of virtual axis	Refer to the description for the 1st axis.	
UM 005FB	Repeat count current value of virtual axis	Refer to the description for the 1st axis.	
UM 005FC	Current value of virtual axis	Poter to the description for the 1st avis	
UM 005FD		Refer to the description for the 1st axis.	
UM 005FE	Unit system conversion current value of	Poter to the description for the 1st avis	
UM 005FF	virtual axis	Refer to the description for the 1st axis.	

# 17.6 Details of Each Axis Setting Area in Unit Memory

### 17.6.1 Configuration of Each Axis Setting Area

Each axis setting area stores the parameter setting area and positioning data. The positioning data setting area of each axis consists of a standard area with 600 tables and extended area with 25 tables.

UM 00000	Unit memory map	Parameter setting area (Axis 1) UM 00800 - UM 0084F
UM 003FF	Common area	Positioning data setting area (Axis 1)
UM 00400 UM 007FF UM 00800	Each axis	UM 00850 - UM 0085F Table 1 UM 00860 - UM 0086F Table 2
	information area	UM 00870 - UM 0087F Table 3
	Each axis setting area (Axis 1)	
	Each axis setting area (Axis 2)	 Parameter setting area (Axis 2) UM 03000 - UM 0304F Positioning data setting area (Axis 2)
	Each axis setting area (Axis 3)	 Parameter setting area (Axis 3 UM 05800 - UM 0584F Positioning data setting area (Axis 3) UM 05850 - UM 07FFF
·	Each axis setting area (Axis 4)	Parameter setting area (Axis 4) UM 08000 - UM 0804F Positioning data setting area (Axis 4) UM 08050 - UM AFFF
UM 147FF	Each axis setting area (Virtual axis)	Parameter setting area (Virtual axis) UM 12000 - UM 1204F Positioning data setting area (Virtual axis) UM 12050 - UM 147FF

### 17.6.2 Parameter Setting Area

#### ■ First address of each axis positioning parameter area

Axis	1st axis	2nd axis	3rd axis	4th axis	Virtual axis
Unit memory address	UM 00800	UM03000	UM 05800	UM 08000	UM 12000

#### Positioning parameters

Data in the following format is stored from the first address of positioning parameters for each axis.

Offset address	Name	Default	Setting range and description
			Set the movement unit system for the positioning control of each axis. Make sure that all the interpolation axes use the same unit system.
			0100H: mm (minimum position reference of 0.1 µm)
000H	Unit setting	ОH	0101H: mm (minimum position reference of 1 µm)
			0200H: inch (minimum position reference of 0.1 inch)
			0201H: inch (minimum position reference of 1 inch)
			0300H: degree (minimum position reference of 0.1 degree)
			0301H: degree (minimum position reference of 1 degree)
			Any other settings will be errors.
001H	-	-	-
002H	2Н		Set the number of pulses per motor rotation. Settings in mm, inch, or degree are required for pulse count conversion
	per rotation	1	Sotting range: 1 to 22 767
003H			Any other pottings will be errors
			Set the movement amount per motor rotation. Settings in mm, inch, or degree are required for pulse count conversion
004H			Setting range: 1 to 32 767
	Movement amount		Any other settings will be errors
	per rotation	1	Set the following range according to the unit setting
			mm: 1 um
005H			inch: 1/10.000 inch
			degree: 1 degree
006H	_	_	_



# KEY POINTS

The unit memory address of a parameter is based on the first address of the corresponding axis added with the offset address.

The first number of the positioning parameter setting area of each axis.

1st axis	2nd axis	3rd axis	4th axis	Virtual axis
UM 00800	UM 03000	UM 05800	UM 08000	UM 12000

Offset address	Name	Default	setting range and description				
007H	Pulse input mode	20H	Makes puls Make settin Dit 0 1 2 to 3 4 to 5 6 to 7 6 to 7	se input signal ngs according i Name Rotating direction - Pulse input mode Input multiplication	settings. to the application of pulse input. Description Set the rotating direction of pulse input 0: Forward 1: Reverse - Set the pulse input mode. Bit3 Bit2 0 0: 2-phase input 0 1: Direction discrimination input 1 0: Individual input 1 1: Reserve (set by default) Set the desired multiplication of the pulse input count if the pulse input mode (with bits 2 and 3) to 2-phase input. Bit5 Bit4 0 0: x1 (multiplied by 1) 0 1: x2 (multiplied by 2) 1 0: x4 (multiplied by 4) 1 1: Reserve (set by default) Specify the pulse input application of each axis. • Pulser: Connects a manual pulser to pulse input. • Feedback pulse: Connects the feedback pulses of the encoder to pulse input. • High-speed counter Bit7 Bit6 0 0: Pulser 0 1: Feedback pulse 1 0: High-speed counter 1 1: Reserve (set by default)		
008H	Numerator of automatic movement amount check correction	1	Set a correction value of pulse input at the time of making an automatic movement amount check of machinery or equipment. The following formula is used to calculate a deviation feedback value (pulse input value with a correction) from the pulse input terminal and make an				
009H	Denominator of automatic movement amount check correction	1	automatic movement amount check. Deviation feedback value = (Correction numerator/Correction denominator) x Pulse input Setting range: 1 to 32767				

Offset address	Name	Default	Setting range and description
			Set an action when the difference between the instruction value and feedback value exceeds the movement check value at the time of automatic movement amount check.
			0: Error
00AH	Automatic movement amount	0	An error will occur and the operation of the positioning unit will come to a stop if the difference between the feedback value and reference movement exceeds the movement check value (threshold).
	checking	ecking	1: Warning
			An error will occur and the operation of the positioning unit will come to a stop if the difference between the feedback value and reference movement exceeds the movement check value (threshold).
			2: No
			No movement amount check is made.

Offset address	Name	Default	Setting range and description		
			Enables or disables the software limit on each control.		
			bit         Name         Default         Description           0         Enables/disables         0         0: Disables the software limit for positionic control		
			the software limit     for positioning control       for positioning     1: Enables the software limit       control     for positioning control		
	Software limit		1         Enables/disables         0         0: Disables the software limit for home return control           1         Enables/disables         0         1: Enables the software limit		
00BH	enabled/ disabled settings	ОН	positioning unit is in home return		
			operation 0: Disables the software limit		
			the software limit in the JOG operation 1: Enables the software limit for JOG operation		
			15 to 3		
00CH 00DH	Upper limit of software limit	1,073,741,823	Set the upper limit of the software limit for the absolute coordinates. Set the following range according to the unit setting. Pulse: -1,073,741,823 to 1,073,741,823 pulses $\mu$ m (0.1 $\mu$ m): -107,374,182.3 to 107,374,182.3 $\mu$ m $\mu$ m (1 $\mu$ m): -1,073,741,823 to 1,073,741,823 $\mu$ m inch (0.0001 inch): -10,737,41823 to 10,737,41823 inches inch (0.0001 inch): -107,374,1823 to 107,374,1823 inches degree (0.1 degree): -107,374,182.3 to 107,374,182.3 degrees degree (1 degree): -1,073,741,823 to 1,073,741,823 degrees Any other settings will be errors.		
00EH	Lower limit of		Set the upper limit of the software limit for the absolute coordinates. Set the following range according to the unit setting. Pulse: -1,073,741,823 to 1,073,741,823 pulses $\mu$ m (0.1 $\mu$ m): -107,374,182.3 to 107,374,182.3 $\mu$ m		
00FH	1,073,741,832	inch (0.00001 inch): -10,737.41,823 to 10,737.41,823 µm inch (0.00001 inch): -10,737.41823 to 10,737.41823 inches inch (0.0001 inch): -107,374.1823 to 107,374.1823 inches degree (0.1 degree): 0.0 to 359.9 degrees degree (1 degree): 0 to 359 degrees Any other settings will be errors.			

Offset address	Name	Default	Setting range and description					
010H	-	-	-					
011H	-	<b> </b> _	-					
			Set whet output fu	her to use or not to nction of the auxili	o use t ary ou	the auxilia itput code	ry output contact and auxiliary whether to be used or unused.	
			The ON I auxiliary	time of the auxiliar output ON time.	y outp	ut contact	t is determined by the following	
			bit	Name	Defa	ult Des	scription	
012H	Auxiliary output mode	1000H	0 to 7	Auxiliary output mode	0	000	0H: The auxiliary output function (auxiliary output contact or code) is not used. 11H: With mode used 12H: Delay mode used	
			15 to 8	Auxiliary output ON time	10	Sett (25	ting range: 00H (0 ms) to FFH 5 ms).	
	Audion output		When us to output	ing the delay mode	e for tl	he auxiliar	ry output, specify the ratio (%)	
013H	Delay rate	0	The setting range is 0(%) to 100(%). If the setting is 50%, the auxiliary output will be performed when the positioning movement amount exce 50%.				setting is 50%, the auxiliary ing movement amount exceeds	
014H	_	<b>—</b>	<u> </u>	-				
			Make pulse output, home position, near home, and limit signal settings.					
			bit	Name		Default	Description	
			0	Output mode		0	0: Pulse/Sign 1: CW/CCW	
			1	Rotating directio	'n	0	0: Count + Direction CW 1: Count + Direction CCW	
015H	Pulse output	2011	2	Home logic		0	0:Normal Open 1:Normal Close	
01011	control code	0011	3	Near home logic	;	0	0:Normal Open	
				_			1:Normal Close	
			4	Limit + Logic		1	0:Normal Open	
							1:Normal Close	
			5	Limit - Logic		1	0:Normal Open	
			15 to 6			0		
-		<u> </u>	13100					
			Make sta	rtup speed setting	s for e	each type	of operation.	
			Make a s	startup speed chan	ige be	fore starti	ng each type of operation.	
016H			Setting ra	Setting range: 0 to 32,767,000				
Startun an	Startun speed	0	Anv othe	r settinas will be e	rrors.			
	Otariup Speed	0	Set the fo	ollowing range acc	ording	to the ur	nit settina.	
			Pulse: 1	to 32 767 000 pps		,	in ootning.	
017H			um: 1 to	32 767 000 µm/s				
01711			inch: 0.0	02,707,000 μm/0	nch/s			
			degree: (	0.001  to  32.767.000  m	10 rev/	s		

Offset address	Name	Default	Setting range and description
018H	Automatic movement amount check value	10000	Set the threshold to use the automatic check function of movement amount. Setting range: 0 to 65536 Default: 10000 (pulses)
019H	-	-	-
01AH	Automatic movement amount check interval	0	Set the interval of automatic movement amount checking in ms . Setting range: 0 to 32767 (ms) Default: 0 (ms)
01BH	-	_	-
01CH	-	-	-
01DH	-	-	-
01EH	_	-	-
01FH	-	-	_

Offset address	Name	Default	Setting range and description
			Sets the pattern of the home return.
020H	Home return setting code	0	0: DOG method 1 1: DOG method 2 2: DOG method 3 3: Limit method 1 4: Limit method 2 5: Phase Z method 8: Data set Any other settings will be errors.
021H	Home return direction	0	Set the direction of the home return. 0: Elapsed value decrement direction (limit negative direction) 1: Elapsed value increment direction (limit positive direction) Any other settings will be errors.
022H	Acceleration time in home return operation		Sets the acceleration/deceleration time while the positioning unit is in home return operation. When home return control starts, the positioning unit will go into
023H	Deceleration time in home return operation	100	Acceleration operation in the preset time. After hear nome input is ON, the positioning unit will go into deceleration operation in the preset time and move into creeping speed. Setting range: 0 to 10,000 (ms) Any other settings will be errors.
024H	024H Home return target speed error	1 000	Sets the target speed for home return control. After home return control starts, the positioning unit will accelerate to target speed if there is no near home input. Setting range: 1 to 32,767,000 Any other settings will be errors.
025H		1,000	Set the following range according to the unit setting. Pulse: 1 to $32,767,000$ pps µm: 1 to $32,767,000$ µm/s inch: 0.001 to $32,767.000$ inch/s degree: 0.001 to $32,767.000$ rev/s

Offset address	Name	Default	Setting range and description				
026H	026H Home return creep speed		Set the s Set a spe	peed to search the eed lower than the ta	home posi arget hom	ition after near home input. e return speed.	
			Setting ra	ange: 1 to 32,767,00 r settings will be err	)0 ors.		
		100	Set the fo	ollowing range acco	rding to th	e unit setting.	
			Pulse: 1	to 32,767,000 pps			
027H			inch: 0.0	01 to 32,767.000 inc	ch/s		
			degree: (	0.001 to 32,767.000	rev/s		
			Set the C completion	ON time of the devia	tion count	er clear signal after home return	
028H Deviation counter clear signal ON time	1	Setting ra	ange: 1 to 100 ms				
		The devi excess o	ation counter clear s f 100 ms is made.	signal is se	et to 100 ms even if a setting in		
		Sets the	operation mode of t	he JOG o	peration.		
			bit	Name	Default	Description	
			0	-	-	-	
029H	SOG operation setting code	ОН	1	Acceleration / Deceleration pattern settings	0	0: Linear acceleration/deceleration 1: S-shaped acceleration/deceleration	
			2 to 15	_	-	_	
			Sets the	acceleration/decele	ration time	e for JOG operation.	
02AH	JOG operation acceleration time	100	When JC accelerat JOG ope	OG operation starts, tion operation in the tration is ON, the po	the position preset time sitioning u	ning unit will go into ne. After the start contact of nit will go into deceleration a stop.	
	IOC operation		oporation				
02BH	deceleration time		Setting range: 0 to 10,000 (ms)				
			Any other settings will be errors.				
			Set the ta	arget speed for JOG	operation	).	
0201			After the start of the JOG operation of the positioning unit, the positioning unit will accelerate to move to the target speed while the start contact of the JOG operation is ON.				
02011			The positis reache	tioning unit will oper d.	ate at targ	et speed after the target speed	
	JOG operation target	1.000	Setting ra	ange: 0 to 32.767.00	00		
	speea		Any othe	r settings will be err	ors.		
			Set the fo	ollowing range acco	rding to th	e unit setting.	
02DH			Pulse: 1	to 32,767,000 pps			
			µm: 1 to	32,767,000 µm/s			
			inch: 0.0	01 to 32,767.000 inc	ch/s		
			degree: 0.001 to 32,767.000 rev/s				

Offset address	Name	Default	Setting range and description
02EH	_	-	-
02FH	_	_	-
030H	_	_	-
031H	_	_	_
032H	_	_	_
033H	Emergency stop deceleration time	100	This parameter will be enabled if an emergency stop request is made with I/O, and the deceleration of the positioning unit will be completed in the specified deceleration time. Setting range: 0 to 10,000 (ms) Any other settings will be errors.
034H	_	-	_
035H	Limit stop deceleration time	100	This parameter will be enabled if limit input is ON while the positioning unit is in operation, and the deceleration of the positioning unit will be completed in the specified deceleration time. Setting range: 0 to 10,000 (ms) Any other settings will be errors.
036H	_	_	-
037H	Error stop deceleration time	100	This parameter will be enabled if an error occurs, and the deceleration of the positioning unit will be completed in the specified deceleration time. Setting range: 0 to 10,000 (ms) Any other settings will be errors.
038H	Pulser operation setting code	0	If a pulse operation request is made with I/O, select the desired pulser input from pulser inputs 1 to 4. 0: Pulser input 1 1: Pulser input 2 2: Pulser input 3 3: Pulser input 4 Any other settings will be errors.
039H	Pulser operation ratio numerator	1	Set a multiplier for the input pulse train for the operation of the pulser. The number of reference pulses is obtained from the pulse train input from the pulser multiplied by the numerator of the pulser operation ratio/denominator of pulser operation ratio. Setting range: 1 to 32,767 Any other settings will be errors.
03AH	Pulser operation ratio denominator	1	Set a divisor for the input pulse train for the operation of the pulser. The number of reference pulses is obtained from the pulse train input from the pulser multiplied by the numerator of the pulser operation ratio/denominator of pulser operation ratio. Setting range: 1 to 32,767 Any other settings will be errors.

Offset address	Name	Default		Setting 1	ange and d	lescription		
03BH	Pulser operation method	0	<ul> <li>Area to set the single and interpolation operation pattern of positioning.</li> <li>0: Standard operation</li> <li>1: Speed limit (pulse hold)</li> <li>2: Speed limit (truncated)</li> <li>Any other settings will be errors.</li> </ul>					
03CH	-	_	_					
03DH	-	_	_					
03EH	-	_	_					
03FH	_	-	_					
040H	_	-	_					
			Set the c	ontrol code for J-point Name	t control. Default	Description		
041H	J-point control code	он	0 1 2 to 15	— Acceleration/ Deceleration pattern settings —		<ul> <li>–</li> <li>0: Linear acceleration/deceleration</li> <li>1: S-shaped acceleration/deceleration</li> <li>–</li> </ul>		
042H	J-point acceleration time	400	Sets the	acceleration/decelera	tion time f	or J-point control.		
043H	J-point deceleration time	100	Setting range: 0 to 10,000 (ms) Any other settings will be errors.					
044H		1.000	Sets the target speed for J-point control. Setting range: 0 to 32,767,000 Any other settings will be errors.					
045H		1,000	Set the following range according to the unit setting. Pulse: 1 to 32,767,000 pps μm: 1 to 32,767,000 μm/s inch: 0.001 to 32,767.000 inch/s degree: 0.001 to 32,767.000 rev/s					
046H	_	_	-					
047H	_	-	-					

Offset address	Name	Default	Setting range and description
			The maximum speed of the pulser operation with speed limits selected.
048H	Bulact operation		The positioning unit will operate at maximum speed if the speed obtained from pulse input multiplied by the numerator of pulse operation/denominator of pulser operation is in excess of the specified maximum speed.
	max. speed	0	
049H			Unit: Set unit x 1000/s
			Input range: 0 to 32767000 (pulse/s)
			* If this area has been set to 0, it is the minimum speed in the set unit.
04AH	Coordinate origin		Starsa the value of econdinate origin ofter the home return
04BH	Coordinate origin	-	Stores the value of coordinate origin after the nome return.
04CH	-	-	-
04DH	-	_	-
04EH	-	-	-
04FH	-	-	-

### 17.6.3 Positioning Data Setting Areas

#### Positioning table

Data in the following format is stored from the first address of the positioning table for each axis.

Refer to the list in and after page 17-52 for the first address of each positioning table.

Offset address	Name	Default	Setting range and description					
			Area to s pattern of	et the position f positioning.	specific	ation met	hod and acceleration/deceleration	
000H			bit	Name		Default	Description	
			0	Increment/abs	olute	00H	0: Increment mode	
	Control code	0H	1	Acceleration/ Deceleration p settings	Acceleration/ Deceleration pattern settings		0: Linear acceleration/deceleration 1: S-shaped acceleration/ deceleration	
			15 to 2	-		_	—	
			Area to s The relati group set The settin enabled f	Area to set the single and interpolation operation pattern of positioning. The relationship of interpolation is in conformity with the settings for the axi group setting area in the unit memory common area. The settings for the axis with the smallest number in the axis group are enabled for interpolation control.				
			7 to 0	Control	00H	00H: E	E point control (End point control)	
				pattern		01H: F 02H: 0 03H: Any o	<ul> <li>P point control (Pass point control)</li> <li>C point control (Continuation point)</li> <li>J point control (Speed point control)</li> <li>ther settings will be errors.</li> </ul>	
001H	Operation pattern	он	15 to 8	Interpolation setting	00H	Any o OOH: I O1H: I 10H: 0 ( 11H: 0 ( 20H: 0 50H: 5 ( 52H: 5 ( 52H: 5 ( 53H: 5 ( 55H: 5 ( 60H: 5 ( 60H: 5 ( 61H: 5 ( 62H: 6 ( 62H: 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 ( 6 (	Inter settings will be errors. Linear interpolation (Composite speed) Linear interpolation (Long axis speed) Circular interpolation (Center point/CW direction) Circular interpolation (Pass point) Spiral interpolation (Center point/CW direction/X-axis movement) Spiral interpolation (Center point/CW direction/X-axis movement) Spiral interpolation (Center point/CW direction/Y-axis movement) Spiral interpolation (Center point/CW direction/Y-axis movement) Spiral interpolation (Center point/CW direction/Y-axis movement) Spiral interpolation (Center point/CW direction/Y-axis movement) Spiral interpolation (Center point/CW direction/Z-axis movement) Spiral interpolation (Center point/CW direction/Z-axis movement) Spiral interpolation (Center point/CW direction/Z-axis movement) Spiral interpolation (Pass point/X-axis movement) Spiral interpolation Pass point/Y-axis movement) Spiral interpolation Pass point/Z-axis movement) Spiral interpolation Spiral	

Offset address	Name	Default	Setting range and description
002H	-	-	-
003H	_	-	-
004H	Positioning		The setting area for acceleration time and deceleration time for positioning operation.
00411	time		Different settings can be made for acceleration and deceleration.
Desitioning		100	The settings for the axis with the smallest number in the axis group are enabled for interpolation operation.
005H	deceleration		Setting range: 0 to 10,000 (ms)
			Any other settings will be errors.
			The target axis will operate at target speed in the case of single axis operation and operate at target interpolation speed in the case of interpolation operation.
006H	Positioning		The settings for the axis with the smallest number in the axis group are enabled for interpolation operation.
			Setting range: 1 to 32,767,000
	(Interpolation	1000	Any other settings will be errors.
	speed)		Set the following range according to the unit setting.
0.0711			Pulse: 1 to 32,767,000 pps
007H			μm: 1 to 32,767,000 μm/s
			inch: 0.001 to 32,767.000 inch/s
			degree: 0.001 to 32,767.000 rev/s

Offset address	Name	Default	Setting range and description
			The setting area for the positioning movement amount for positioning operation.
008H			The amount of increment movement or absolute coordinates will be set according to the control code settings.
			Setting range: -1,073,741,823 to 1,073,741,823
			Any other settings will be errors.
	Positioning	0	Set the following range according to the unit setting.
	movement amount	0	Pulse: -1,073,741,823 to 1,073,741,823 pulses
			μm (0.1 μm): -107,374,182.3 to 107,374,182.3 μm
			μm (1 μm): -1,073,741,823 to 1,073,741,823 μm
009H			inch (0.00001 inch): -10,737.41823 to 10,737.41823 inches
			inch (0.0001 inch): -107,374.1823 to 107,374.1823 inch
			degree (0.1 degree): -107,374,182.3 to 107,374,182.3 degrees
			degree (1 degree): -1,073,741,823 to 1,073,741,823 degrees
			The setting area for auxiliary points (center and passing points) in the case of circular interpolation or spiral interpolation operation.
04AH			Setting range: -1 073 741 823 to 1 073 741 823
			Any other settings will be errors
			Set the following range according to the unit setting
		0	Pulse: -1.073.741.823 to 1.073.741.823 pulses
		0	um (0.1 um): -107.374.182.3 to 107.374.182.3 um
			um (1 um): -1.073.741.823 to 1.073.741.823 um
			inch (0.00001 inch): -10,737.41823 to 10,737.41823 inches
00BH			inch (0.0001 inch): -107,374.1823 to 107,374.1823 inch
			degree (0.1 degree): -107,374,182.3 to 107,374,182.3 degrees
			degree (1 degree): -1,073,741,823 to 1,073,741,823 degrees
-			
00CH	Dwell Time	0	On completion of the positioning of this table, the operation of the next table will start after stopping the motor for the dwell time in the case of the continuance point (C-point), the dwell time will be ignored in the case of the passing point (P-point), and the positioning done contact will turn ON after a pause of the dwell time in the case of end point (E-point) control.
			Setting range: 0 to 32 767 (ms)
			Any other settings will be errors
			Any other settings will be enors. Make auxiliary output mode settings for the parameter setting area to
00DH	Auxiliary output code	0	specify data to be output to the auxiliary output codes for the each axis information & monitor area.
			No setting ranges, in particular.
00EH	_	-	-
00FH	_	-	-



# KEY POINTS

The unit memory address of each item on the positioning table is based on a separate address allocated to each axis and table added with the offset address.

Table no.	1st axis	2nd axis	3rd axis	4th axis	Virtual axis
1	UM 00850	UM 03050	UM 05850	UM 08050	UM 12050
2	UM 00860	UM 03060	UM 05860	UM 08060	UM 12060
3	UM 00870	UM 03070	UM 05870	UM 08070	UM 12070
4	UM 00880	UM 03080	UM 05880	UM 08080	UM 12080
5	UM 00890	UM 03090	UM 05890	UM 08090	UM 12090
6	UM 008A0	UM 030A0	UM 058A0	UM 080A0	UM 120A0
7	UM 008B0	UM 030B0	UM 058B0	UM 080B0	UM 120B0
8	UM 008C0	UM 030C0	UM 058C0	UM 080C0	UM 120C0
9	UM 008D0	UM 030D0	UM 058D0	UM 080D0	UM 120D0
10	UM 008E0	UM 030E0	UM 058E0	UM 080E0	UM 120E0
11	UM 008F0	UM 030F0	UM 058F0	UM 080F0	UM 120F0
12	UM 00900	UM 03100	UM 05900	UM 08100	UM 12100
13	UM 00910	UM 03110	UM 05910	UM 08110	UM 12110
14	UM 00920	UM 03120	UM 05920	UM 08120	UM 12120
15	UM 00930	UM 03130	UM 05930	UM 08130	UM 12130
16	UM 00940	UM 03140	UM 05940	UM 08140	UM 12140
17	UM 00950	UM 03150	UM 05950	UM 08150	UM 12150
18	UM 00960	UM 03160	UM 05960	UM 08160	UM 12160
19	UM 00970	UM 03170	UM 05970	UM 08170	UM 12170
20	UM 00980	UM 03180	UM 05980	UM 08180	UM 12180
21	UM 00990	UM 03190	UM 05990	UM 08190	UM 12190
22	UM 009A0	UM 031A0	UM 059A0	UM 081A0	UM 121A0
23	UM 009B0	UM 031B0	UM 059B0	UM 081B0	UM 121B0
24	UM 009C0	UM 031C0	UM 059C0	UM 081C0	UM 121C0
25	UM 009D0	UM 031D0	UM 059D0	UM 081D0	UM 121D0
26	UM 009E0	UM 031E0	UM 059E0	UM 081E0	UM 121E0
27	UM 009F0	UM 031F0	UM 059F0	UM 081F0	UM 121F0
28	UM 00A00	UM 03200	UM 05A00	UM 08200	UM 12200
29	UM 00A10	UM 03210	UM 05A10	UM 08210	UM 12210
30	UM 00A20	UM 03220	UM 05A20	UM 08220	UM 12220
31	UM 00A30	UM 03230	UM 05A30	UM 08230	UM 12230
32	UM 00A40	UM 03240	UM 05A40	UM 08240	UM 12240
33	UM 00A50	UM 03250	UM 05A50	UM 08250	UM 12250
34	UM 00A60	UM 03260	UM 05A60	UM 08260	UM 12260
35	UM 00A70	UM 03270	UM 05A70	UM 08270	UM 12270
36	UM 00A80	UM 03280	UM 05A80	UM 08280	UM 12280
37	UM 00A90	UM 03290	UM 05A90	UM 08290	UM 12290

■ First address of each positioning table

Table no.	1st axis	2nd axis	3rd axis	4th axis	Virtual axis
38	UM 00AA0	UM 032A0	UM 05AA0	UM 082A0	UM 122A0
39	UM 00AB0	UM 032B0	UM 05AB0	UM 082B0	UM 122B0
40	UM 00AC0	UM 032C0	UM 05AC0	UM 082C0	UM 122C0
41	UM 00AD0	UM 032D0	UM 05AD0	UM 082D0	UM 122D0
42	UM 00AE0	UM 032E0	UM 05AE0	UM 082E0	UM 122E0
43	UM 00AF0	UM 032F0	UM 05AF0	UM 082F0	UM 122F0
44	UM 00B00	UM 03300	UM 05B00	UM 08300	UM 12300
45	UM 00B10	UM 03310	UM 05B10	UM 08310	UM 12310
46	UM 00B20	UM 03320	UM 05B20	UM 08320	UM 12320
47	UM 00B30	UM 03330	UM 05B30	UM 08330	UM 12330
48	UM 00B40	UM 03340	UM 05B40	UM 08340	UM 12340
49	UM 00B50	UM 03350	UM 05B50	UM 08350	UM 12350
50	UM 00B60	UM 03360	UM 05B60	UM 08360	UM 12360
51	UM 00B70	UM 03370	UM 05B70	UM 08370	UM 12370
52	UM 00B80	UM 03380	UM 05B80	UM 08380	UM 12380
53	UM 00B90	UM 03390	UM 05B90	UM 08390	UM 12390
54	UM 00BA0	UM 033A0	UM 05BA0	UM 083A0	UM 123A0
55	UM 00BB0	UM 033B0	UM 05BB0	UM 083B0	UM 123B0
56	UM 00BC0	UM 033C0	UM 05BC0	UM 083C0	UM 123C0
57	UM 00BD0	UM 033D0	UM 05BD0	UM 083D0	UM 123D0
58	UM 00BE0	UM 033E0	UM 05BE0	UM 083E0	UM 123E0
59	UM 00BF0	UM 033F0	UM 05BF0	UM 083F0	UM 123F0
60	UM 00C00	UM 03400	UM 05C00	UM 08400	UM 12400
61	UM 00C10	UM 03410	UM 05C10	UM 08410	UM 12410
62	UM 00C20	UM 03420	UM 05C20	UM 08420	UM 12420
63	UM 00C30	UM 03430	UM 05C30	UM 08430	UM 12430
64	UM 00C40	UM 03440	UM 05C40	UM 08440	UM 12440
65	UM 00C50	UM 03450	UM 05C50	UM 08450	UM 12450
66	UM 00C60	UM 03460	UM 05C60	UM 08460	UM 12460
67	UM 00C70	UM 03470	UM 05C70	UM 08470	UM 12470
68	UM 00C80	UM 03480	UM 05C80	UM 08480	UM 12480
69	UM 00C90	UM 03490	UM 05C90	UM 08490	UM 12490
70	UM 00CA0	UM 034A0	UM 05CA0	UM 084A0	UM 124A0
71	UM 00CB0	UM 034B0	UM 05CB0	UM 084B0	UM 124B0
72	UM 00CC0	UM 034C0	UM 05CC0	UM 084C0	UM 124C0
73	UM 00CD0	UM 034D0	UM 05CD0	UM 084D0	UM 124D0
74	UM 00CE0	UM 034E0	UM 05CE0	UM 084E0	UM 124E0
75	UM 00CF0	UM 034F0	UM 05CF0	UM 084F0	UM 124F0
76	UM 00D00	UM 03500	UM 05D00	UM 08500	UM 12500
77	UM 00D10	UM 03510	UM 05D10	UM 08510	UM 12510
78	UM 00D20	UM 03520	UM 05D20	UM 08520	UM 12520
79	UM 00D30	UM 03530	UM 05D30	UM 08530	UM 12530

Table no.	1st axis	2nd axis	3rd axis	4th axis	Virtual axis
80	UM 00D40	UM 03540	UM 05D40	UM 08540	UM 12540
81	UM 00D50	UM 03550	UM 05D50	UM 08550	UM 12550
82	UM 00D60	UM 03560	UM 05D60	UM 08560	UM 12560
83	UM 00D70	UM 03570	UM 05D70	UM 08570	UM 12570
84	UM 00D80	UM 03580	UM 05D80	UM 08580	UM 12580
85	UM 00D90	UM 03590	UM 05D90	UM 08590	UM 12590
86	UM 00DA0	UM 035A0	UM 05DA0	UM 085A0	UM 125A0
87	UM 00DB0	UM 035B0	UM 05DB0	UM 085B0	UM 125B0
88	UM 00DC0	UM 035C0	UM 05DC0	UM 085C0	UM 125C0
89	UM 00DD0	UM 035D0	UM 05DD0	UM 085D0	UM 125D0
90	UM 00DE0	UM 035E0	UM 05DE0	UM 085E0	UM 125E0
91	UM 00DF0	UM 035F0	UM 05DF0	UM 085F0	UM 125F0
92	UM 00E00	UM 03600	UM 05E00	UM 08600	UM 12600
93	UM 00E10	UM 03610	UM 05E10	UM 08610	UM 12610
94	UM 00E20	UM 03620	UM 05E20	UM 08620	UM 12620
95	UM 00E30	UM 03630	UM 05E30	UM 08630	UM 12630
96	UM 00E40	UM 03640	UM 05E40	UM 08640	UM 12640
97	UM 00E50	UM 03650	UM 05E50	UM 08650	UM 12650
98	UM 00E60	UM 03660	UM 05E60	UM 08660	UM 12660
99	UM 00E70	UM 03670	UM 05E70	UM 08670	UM 12670
100	UM 00E80	UM 03680	UM 05E80	UM 08680	UM 12680
101	UM 00E90	UM 03690	UM 05E90	UM 08690	UM 12690
102	UM 00EA0	UM 036A0	UM 05EA0	UM 086A0	UM 126A0
103	UM 00EB0	UM 036B0	UM 05EB0	UM 086B0	UM 126B0
104	UM 00EC0	UM 036C0	UM 05EC0	UM 086C0	UM 126C0
105	UM 00ED0	UM 036D0	UM 05ED0	UM 086D0	UM 126D0
106	UM 00EE0	UM 036E0	UM 05EE0	UM 086E0	UM 126E0
107	UM 00EF0	UM 036F0	UM 05EF0	UM 086F0	UM 126F0
108	UM 00F00	UM 03700	UM 05F00	UM 08700	UM 12700
109	UM 00F10	UM 03710	UM 05F10	UM 08710	UM 12710
110	UM 00F20	UM 03720	UM 05F20	UM 08720	UM 12720
111	UM 00F30	UM 03730	UM 05F30	UM 08730	UM 12730
112	UM 00F40	UM 03740	UM 05F40	UM 08740	UM 12740
113	UM 00F50	UM 03750	UM 05F50	UM 08750	UM 12750
114	UM 00F60	UM 03760	UM 05F60	UM 08760	UM 12760
115	UM 00F70	UM 03770	UM 05F70	UM 08770	UM 12770
116	UM 00F80	UM 03780	UM 05F80	UM 08780	UM 12780
117	UM 00F90	UM 03790	UM 05F90	UM 08790	UM 12790
118	UM 00FA0	UM 037A0	UM 05FA0	UM 087A0	UM 127A0
119	UM 00FB0	UM 037B0	UM 05FB0	UM 087B0	UM 127B0
120	UM 00FC0	UM 037C0	UM 05FC0	UM 087C0	UM 127C0
121	UM 00FD0	UM 037D0	UM 05FD0	UM 087D0	UM 127D0

Table no.	1st axis	2nd axis	3rd axis	4th axis	Virtual axis
122	UM 00FE0	UM 037E0	UM 05FE0	UM 087E0	UM 127E0
123	UM 00FF0	UM 037F0	UM 05FF0	UM 087F0	UM 127F0
124	UM 01000	UM 03800	UM 06000	UM 08800	UM 12800
125	UM 01010	UM 03810	UM 06010	UM 08810	UM 12810
126	UM 01020	UM 03820	UM 06020	UM 08820	UM 12820
127	UM 01030	UM 03830	UM 06030	UM 08830	UM 12830
128	UM 01040	UM 03840	UM 06040	UM 08840	UM 12840
129	UM 01050	UM 03850	UM 06050	UM 08850	UM 12850
130	UM 01060	UM 03860	UM 06060	UM 08860	UM 12860
131	UM 01070	UM 03870	UM 06070	UM 08870	UM 12870
132	UM 01080	UM 03880	UM 06080	UM 08880	UM 12880
133	UM 01090	UM 03890	UM 06090	UM 08890	UM 12890
134	UM 010A0	UM 038A0	UM 060A0	UM 088A0	UM 128A0
135	UM 010B0	UM 038B0	UM 060B0	UM 088B0	UM 128B0
136	UM 010C0	UM 038C0	UM 060C0	UM 088C0	UM 128C0
137	UM 010D0	UM 038D0	UM 060D0	UM 088D0	UM 128D0
138	UM 010E0	UM 038E0	UM 060E0	UM 088E0	UM 128E0
139	UM 010F0	UM 038F0	UM 060F0	UM 088F0	UM 128F0
140	UM 01100	UM 03900	UM 06100	UM 08900	UM 12900
141	UM 01110	UM 03910	UM 06110	UM 08910	UM 12910
142	UM 01120	UM 03920	UM 06120	UM 08920	UM 12920
143	UM 01130	UM 03930	UM 06130	UM 08930	UM 12930
144	UM 01140	UM 03940	UM 06140	UM 08940	UM 12940
145	UM 01150	UM 03950	UM 06150	UM 08950	UM 12950
146	UM 01160	UM 03960	UM 06160	UM 08960	UM 12960
147	UM 01170	UM 03970	UM 06170	UM 8970	UM 12970
148	UM 01180	UM 03980	UM 06180	UM 08980	UM 12980
149	UM 01190	UM 03990	UM 06190	UM 08990	UM 12990
150	UM 011A0	UM 039A0	UM 061A0	UM 089A0	UM 129A0
151	UM 011B0	UM 039B0	UM 061B0	UM 089B0	UM 129B0
152	UM 011C0	UM 039C0	UM 061C0	UM 089C0	UM 129C0
153	UM 011D0	UM 039D0	UM061D0	UM 089D0	UM 129D0
154	UM 011E0	UM 039E0	UM 061E0	UM 089E0	UM 129E0
155	UM 011F0	UM 039F0	UM 061F0	UM 089F0	UM 129F0
156	UM 01200	UM 03A00	UM 06200	UM 08A00	UM 12A00
157	UM 01210	UM 03A10	UM 06210	UM 08A10	UM 12A10
158	UM 01220	UM 03A20	UM 06220	UM 08A20	UM 12A20
159	UM 01230	UM 03A30	UM 06230	UM 08A30	UM 12A30
160	UM 01240	UM 03A40	UM 06240	UM 08A40	UM 12A40
161	UM 01250	UM 03A50	UM 06250	UM 08A50	UM 12A50
162	UM 01260	UM 03A60	UM 06260	UM 08A60	UM 12A60
163	UM 01270	UM 03A70	UM 06270	UM 08A70	UM 12A70

Table no.	1st axis	2nd axis	3rd axis	4th axis	Virtual axis
164	UM 01280	UM 03A80	UM 06280	UM 08A80	UM 12A80
165	UM 01290	UM 03A90	UM 06290	UM 08A90	UM 12A90
166	UM 012A0	UM 03AA0	UM 062A0	UM 08AA0	UM 12AA0
167	UM 012B0	UM 03AB0	UM 062B0	UM 08AB0	UM 12AB0
168	UM 012C0	UM 03AC0	UM 062C0	UM 08AC0	UM 12AC0
169	UM 012D0	UM 03AD0	UM 062D0	UM 08AD0	UM 12AD0
170	UM 012E0	UM 03AE0	UM 062E0	UM 08AE0	UM 12AE0
171	UM 012F0	UM 03AF0	UM 062F0	UM 08AF0	UM 12AF0
172	UM 01300	UM 03B00	UM 06300	UM 08B00	UM 12B00
173	UM 01310	UM 03B10	UM 06310	UM 08B10	UM 12B10
174	UM 01320	UM 03B20	UM 06320	UM 08B20	UM 12B20
175	UM 01330	UM 03B30	UM 06330	UM 08B30	UM 12B30
176	UM 01340	UM 03B40	UM 06340	UM 08B40	UM 12B40
177	UM 01350	UM 03B50	UM 06350	UM 08B50	UM 12B50
178	UM 01360	UM 03B60	UM 06360	UM 08B60	UM 12B60
179	UM 01370	UM 03B70	UM 06370	UM 08B70	UM 12B70
180	UM 01380	UM 03B80	UM 06380	UM 08B80	UM 12B80
181	UM 01390	UM 03B90	UM 06390	UM 08B90	UM 12B90
182	UM 013A0	UM 03BA0	UM 063A0	UM 08BA0	UM 12BA0
183	UM 013B0	UM 03BB0	UM 063B0	UM 08BB0	UM 12BB0
184	UM 013C0	UM 03BC0	UM 063C0	UM 08BC0	UM 12BC0
185	UM 013D0	UM 03BD0	UM 063D0	UM 08BD0	UM 12BD0
186	UM 013E0	UM 03BE0	UM 063E0	UM 08BE0	UM 12BE0
187	UM 013F0	UM 03BF0	UM 063F0	UM 08BF0	UM 12BF0
188	UM 01400	UM 03C00	UM 06400	UM 08C00	UM 12C00
189	UM 01410	UM 03C10	UM 06410	UM 08C10	UM 12C10
190	UM 01420	UM 03C20	UM 06420	UM 08C20	UM 12C20
191	UM 01430	UM 03C30	UM 06430	UM 08C30	UM 12C30
192	UM 01440	UM 03C40	UM 06440	UM 08C40	UM 12C40
193	UM 01450	UM 03C50	UM 06450	UM 08C50	UM 12C50
194	UM 01460	UM 03C60	UM 06460	UM 08C60	UM 12C60
195	UM 01470	UM 03C70	UM 06470	UM 08C70	UM 12C70
196	UM 01480	UM 03C80	UM 06480	UM 08C80	UM 12C80
197	UM 01490	UM 03C90	UM 06490	UM 08C90	UM 12C90
198	UM 014A0	UM 03CA0	UM 064A0	UM 08CA0	UM 12CA0
199	UM 014B0	UM 03CB0	UM 064B0	UM 08CB0	UM 12CB0
200	UM 014C0	UM 03CC0	UM 064C0	UM 08CC0	UM 12CC0
201	UM 014D0	UM 03CD0	UM 064D0	UM 08CD0	UM 12CD0
202	UM 014E0	UM 03CE0	UM 064E0	UM 08CE0	UM 12CE0
203	UM 014F0	UM 03CF0	UM 064F0	UM 08CF0	UM 12CF0
204	UM 01500	UM 03D00	UM 06500	UM 08D00	UM 12D00
205	UM 01510	UM 03D10	UM 06510	UM 08D10	UM 12D10

Table no.	1st axis	2nd axis	3rd axis	4th axis	Virtual axis
206	UM 01520	UM 03D20	UM 06520	UM 08D20	UM 12D20
207	UM 01530	UM 03D30	UM 06530	UM 08D30	UM 12D30
208	UM 01540	UM 03D40	UM 06540	UM 08D40	UM 12D40
209	UM 01550	UM 03D50	UM 06550	UM 08D50	UM 12D50
210	UM 01560	UM 03D60	UM 06560	UM 08D60	UM 12D60
211	UM 01570	UM 03D70	UM 06570	UM 08D70	UM 12D70
212	UM 01580	UM 03D80	UM 06580	UM 08D80	UM 12D80
213	UM 01590	UM 03D90	UM 06590	UM 08D90	UM 12D90
214	UM 015A0	UM 03DA0	UM 065A0	UM 08DA0	UM 12DA0
215	UM 015B0	UM 03DB0	UM 065B0	UM 08DB0	UM 12DB0
216	UM 015C0	UM 03DC0	UM 065C0	UM 08DC0	UM 12DC0
217	UM 015D0	UM 03DD0	UM 065D0	UM 08DD0	UM 12DD0
218	UM 015E0	UM 03DE0	UM 065E0	UM 08DE0	UM 12DE0
219	UM 015F0	UM 03DF0	UM 065F0	UM 08DF0	UM 12DF0
220	UM 01600	UM 03E00	UM 06600	UM 08E00	UM 12E00
221	UM 01610	UM 03E10	UM 06610	UM 08E10	UM 12E10
222	UM 01620	UM 03E20	UM 06620	UM 08E20	UM 12E20
223	UM 01630	UM 03E30	UM 06630	UM 08E30	UM 12E30
224	UM 01640	UM 03E40	UM 06640	UM 08E40	UM 12E40
225	UM 01650	UM 03E50	UM 06650	UM 08E50	UM 12E50
226	UM 01660	UM 03E60	UM 06660	UM 08E60	UM 12E60
227	UM 01670	UM 03E70	UM 06670	UM 08E70	UM 12E70
228	UM 01680	UM 03E80	UM 06680	UM 08E80	UM 12E80
229	UM 01690	UM 03E90	UM 06690	UM 08E90	UM 12E90
230	UM 016A0	UM 03EA0	UM 066A0	UM 08EA0	UM 12EA0
231	UM 016B0	UM 03EB0	UM 066B0	UM 08EB0	UM 12EB0
232	UM 016C0	UM 03EC0	UM 066C0	UM 08EC0	UM 12EC0
233	UM 016D0	UM 03ED0	UM 066D0	UM 08ED0	UM 12ED0
234	UM 016E0	UM 03EE0	UM 066E0	UM 08EE0	UM 12EE0
235	UM 016F0	UM 03EF0	UM 066F0	UM 08EF0	UM 12EF0
236	UM 01700	UM 03F00	UM 06700	UM 08F00	UM 12F00
237	UM 01710	UM 03F10	UM 06710	UM 08F10	UM 12F10
238	UM 01720	UM 03F20	UM 06720	UM 08F20	UM 12F20
239	UM 01730	UM 03F30	UM 06730	UM 08F30	UM 12F30
240	UM 01740	UM 03F40	UM 06740	UM 08F40	UM 12F40
241	UM 01750	UM 03F50	UM 06750	UM 08F50	UM 12F50
242	UM 01760	UM 03F60	UM 06760	UM 08F60	UM 12F60
243	UM 01770	UM 03F70	UM 06770	UM 08F70	UM 12F70
244	UM 01780	UM 03F80	UM 06780	UM 08F80	UM 12F80
245	UM 01790	UM 03F90	UM 06790	UM 08F90	UM 12F90
246	UM 017A0	UM 03FA0	UM 067A0	UM 08FA0	UM 12FA0
247	UM 017B0	UM 03FB0	UM 067B0	UM 08FB0	UM 12FB0

Table no.	1st axis	2nd axis	3rd axis	4th axis	Virtual axis
248	UM 017C0	UM 03FC0	UM 067C0	UM 08FC0	UM 12FC0
249	UM 017D0	UM 03FD0	UM 067D0	UM 08FD0	UM 12FD0
250	UM 017E0	UM 03FE0	UM 067E0	UM 08FE0	UM 12FE0
251	UM 017F0	UM 03FF0	UM 067F0	UM 08FF0	UM 12FF0
252	UM 01800	UM 04000	UM 06800	UM 09000	UM 13000
253	UM 01810	UM 04010	UM 06810	UM 09010	UM 13010
254	UM 01820	UM 04020	UM 06820	UM 09020	UM 13020
255	UM 01830	UM 04030	UM 06830	UM 09030	UM 13030
256	UM 01840	UM 04040	UM 06840	UM 09040	UM 13040
257	UM 01850	UM 04050	UM 06850	UM 09050	UM 13050
258	UM 01860	UM 04060	UM 06860	UM 09060	UM 13060
259	UM 01870	UM 04070	UM 06870	UM 09070	UM 13070
260	UM 01880	UM 04080	UM 06880	UM 09080	UM 13080
261	UM 01890	UM 04090	UM 06890	UM 09090	UM 13090
262	UM 018A0	UM 040A0	UM 068A0	UM 090A0	UM 130A0
263	UM 018B0	UM 040B0	UM 068B0	UM 090B0	UM 130B0
264	UM 018C0	UM 040C0	UM 068C0	UM 090C0	UM 130C0
265	UM 018D0	UM 040D0	UM 068D0	UM 090D0	UM 130D0
266	UM 018E0	UM 040E0	UM 068E0	UM 090E0	UM 130E0
267	UM 018F0	UM 040F0	UM 068F0	UM 090F0	UM 130F0
268	UM 01900	UM 04100	UM 06900	UM 09100	UM 13100
269	UM 01910	UM 04110	UM 06910	UM 09110	UM 13110
270	UM 01920	UM 04120	UM 06920	UM 09120	UM 13120
271	UM 01930	UM 04130	UM 06930	UM 09130	UM 13130
272	UM 01940	UM 04140	UM 06940	UM 09140	UM 13140
273	UM 01950	UM 04150	UM 06950	UM 09150	UM 13150
274	UM 01960	UM 04160	UM 06960	UM 09160	UM 13160
275	UM 01970	UM 04170	UM 06970	UM 09170	UM 13170
276	UM 01980	UM 04180	UM 06980	UM 09180	UM 13180
277	UM 01990	UM 04190	UM 06990	UM 09190	UM 13190
278	UM 019A0	UM 041A0	UM 069A0	UM 091A0	UM 131A0
279	UM 019B0	UM 041B0	UM 069B0	UM 091B0	UM 131B0
280	UM 019C0	UM 041C0	UM 069C0	UM 091C0	UM 131C0
281	UM 019D0	UM 041D0	UM 069D0	UM 091D0	UM 131D0
282	UM 019E0	UM 041E0	UM 069E0	UM 091E0	UM 131E0
283	UM 019F0	UM 041F0	UM 069F0	UM 091F0	UM 131F0
284	UM 01A00	UM 04200	UM 06A00	UM 09200	UM 13200
285	UM 01A10	UM 04210	UM 06A10	UM 09210	UM 13210
286	UM 01A20	UM 04220	UM 06A20	UM 09220	UM 13220
287	UM 01A30	UM 04230	UM 06A30	UM 09230	UM 13230
288	UM 01A40	UM 04240	UM 06A40	UM 09240	UM 13240
289	UM 01A50	UM 04250	UM 06A50	UM 09250	UM 13250

Table no.	1st axis	2nd axis	3rd axis	4th axis	Virtual axis
290	UM 01A60	UM 04260	UM 06A60	UM 09260	UM 13260
291	UM 01A70	UM 04270	UM 06A70	UM 09270	UM 13270
292	UM 01A80	UM 04280	UM 06A80	UM 09280	UM 13280
293	UM 01A90	UM 04290	UM 06A90	UM 09290	UM 13290
294	UM 01AA0	UM 042A0	UM 06AA0	UM 092A0	UM 132A0
295	UM 01AB0	UM 042B0	UM 06AB0	UM 092B0	UM 132B0
296	UM 01AC0	UM 042C0	UM 06AC0	UM 092C0	UM 132C0
297	UM 01AD0	UM 042D0	UM 06AD0	UM 092D0	UM 132D0
298	UM 01AE0	UM 042E0	UM 06AE0	UM 092E0	UM 132E0
299	UM 01AF0	UM 042F0	UM 06AF0	UM 092F0	UM 132F0
300	UM 01B00	UM 04300	UM 06B00	UM 09300	UM 13300
301	UM 01B10	UM 04310	UM 06B10	UM 09310	UM 13310
302	UM 01B20	UM 04320	UM 06B20	UM 09320	UM 13320
303	UM 01B30	UM 04330	UM 06B30	UM 09330	UM 13330
304	UM 01B40	UM 04340	UM 06B40	UM 09340	UM 13340
305	UM 01B50	UM 04350	UM 06B50	UM 09350	UM 13350
306	UM 01B60	UM 04360	UM 06B60	UM 09360	UM 13360
307	UM 01B70	UM 04370	UM 06B70	UM 09370	UM 13370
308	UM 01B80	UM 04380	UM 06B80	UM 09380	UM 13380
309	UM 01B90	UM 04390	UM 06B90	UM 09390	UM 13390
310	UM 01BA0	UM 043A0	UM 06BA0	UM 093A0	UM 133A0
311	UM 01BB0	UM 043B0	UM 06BB0	UM 093B0	UM 133B0
312	UM 01BC0	UM 043C0	UM 06BC0	UM 093C0	UM 133C0
313	UM 01BD0	UM 043D0	UM 06BD0	UM 093D0	UM 133D0
314	UM 01BE0	UM 043E0	UM 06BE0	UM 093E0	UM 133E0
315	UM 01BF0	UM 043F0	UM 06BF0	UM 093F0	UM 133F0
316	UM 01C00	UM 04400	UM 06C00	UM 09400	UM 13400
317	UM 01C10	UM 04410	UM 06C10	UM 09410	UM 13410
318	UM 01C20	UM 04420	UM 06C20	UM 09420	UM 13420
319	UM 01C30	UM 04430	UM 06C30	UM 09430	UM 13430
320	UM 01C40	UM 04440	UM 06C40	UM 09440	UM 13440
321	UM 01C50	UM 04450	UM 06C50	UM 09450	UM 13450
322	UM 01C60	UM 04460	UM 06C60	UM 09460	UM 13460
323	UM 01C70	UM 04470	UM 06C70	UM 09470	UM 13470
324	UM 01C80	UM 04480	UM 06C80	UM 09480	UM 13480
325	UM 01C90	UM 04490	UM 06C90	UM 09490	UM 13490
326	UM 01CA0	UM 044A0	UM 06CA0	UM 094A0	UM 134A0
327	UM 01CB0	UM 044B0	UM 06CB0	UM 094B0	UM 134B0
328	UM 01CC0	UM 044C0	UM 06CC0	UM 094C0	UM 134C0
329	UM 01CD0	UM 044D0	UM 06CD0	UM 094D0	UM 134D0
330	UM 01CE0	UM 044E0	UM 06CE0	UM 094E0	UM 134E0
331	UM 01CF0	UM 044F0	UM 06CF0	UM 094F0	UM 134F0

Table no.	1st axis	2nd axis	3rd axis	4th axis	Virtual axis
332	UM 01D00	UM 04500	UM 06D00	UM 09500	UM 13500
333	UM 01D10	UM 04510	UM 06D10	UM 09510	UM 13510
334	UM 01D20	UM 04520	UM 06D20	UM 09520	UM 13520
335	UM 01D30	UM 04530	UM 06D30	UM 09530	UM 13530
336	UM 01D40	UM 04540	UM 06D40	UM 09540	UM 13540
337	UM 01D50	UM 04550	UM 06D50	UM 09550	UM 13550
338	UM 01D60	UM 04560	UM 06D60	UM 09560	UM 13560
339	UM 01D70	UM 04570	UM 06D70	UM 09570	UM 13570
340	UM 01D80	UM 04580	UM 06D80	UM 09580	UM 13580
341	UM 01D90	UM 04590	UM 06D90	UM 09590	UM 13590
342	UM 01DA0	UM 045A0	UM 06DA0	UM 095A0	UM 135A0
343	UM 01DB0	UM 045B0	UM 06DB0	UM 095B0	UM 135B0
344	UM 01DC0	UM 045C0	UM 06DC0	UM 095C0	UM 135C0
345	UM 01DD0	UM 045D0	UM 06DD0	UM 095D0	UM 135D0
346	UM 01DE0	UM 045E0	UM 06DE0	UM 095E0	UM 135E0
347	UM 01DF0	UM 045F0	UM 06DF0	UM 095F0	UM 135F0
348	UM 01E00	UM 04600	UM 06E00	UM 09600	UM 13600
349	UM 01E10	UM 04610	UM 06E10	UM 09610	UM 13610
350	UM 01E20	UM 04620	UM 06E20	UM 09620	UM 13620
351	UM 01E30	UM 04630	UM 06E30	UM 09630	UM 13630
352	UM 01E40	UM 04640	UM 06E40	UM 09640	UM 13640
353	UM 01E50	UM 04650	UM 06E50	UM 09650	UM 13650
354	UM 01E60	UM 04660	UM 06E60	UM 09660	UM 13660
355	UM 01E70	UM 04670	UM 06E70	UM 09670	UM 13670
356	UM 01E80	UM 04680	UM 06E80	UM 09680	UM 13680
357	UM 01E90	UM 04690	UM 06E90	UM 09690	UM 13690
358	UM 01EA0	UM 046A0	UM 06EA0	UM 096A0	UM 136A0
359	UM 01EB0	UM 046B0	UM 06EB0	UM 096B0	UM 136B0
360	UM 01EC0	UM 046C0	UM 06EC0	UM 096C0	UM 136C0
361	UM 01ED0	UM 046D0	UM 06ED0	UM 096D0	UM 136D0
362	UM 01EE0	UM 046E0	UM 06EE0	UM 096E0	UM 136E0
363	UM 01EF0	UM 046F0	UM 06EF0	UM 096F0	UM 136F0
364	UM 01F00	UM 04700	UM 06F00	UM 09700	UM 13700
365	UM 01F10	UM 04710	UM 06F10	UM 09710	UM 13710
366	UM 01F20	UM 04720	UM 06F20	UM 09720	UM 13720
367	UM 01F30	UM 04730	UM 06F30	UM 09730	UM 13730
368	UM 01F40	UM 04740	UM 06F40	UM 09740	UM 13740
369	UM 01F50	UM 04750	UM 06F50	UM 09750	UM 13750
370	UM 01F60	UM 04760	UM 06F60	UM 09760	UM 13760
371	UM 01F70	UM 04770	UM 06F70	UM 09770	UM 13770
372	UM 01F80	UM 04780	UM 06F80	UM 09780	UM 13780
373	UM 01F90	UM 04790	UM 06F90	UM 09790	UM 13790
Table no.	1st axis	2nd axis	3rd axis	4th axis	Virtual axis
-----------	----------	----------	----------	----------	--------------
374	UM 01FA0	UM 047A0	UM 06FA0	UM 097A0	UM 137A0
375	UM 01FB0	UM 047B0	UM 06FB0	UM 097B0	UM 137B0
376	UM 01FC0	UM 047C0	UM 06FC0	UM 097C0	UM 137C0
377	UM 01FD0	UM 047D0	UM 06FD0	UM 097D0	UM 137D0
378	UM 01FE0	UM 047E0	UM 06FE0	UM 097E0	UM 137E0
379	UM 01FF0	UM 047F0	UM 06FF0	UM 097F0	UM 137F0
380	UM 02000	UM 04800	UM 07000	UM 09800	UM 13800
381	UM 02010	UM 04810	UM 07010	UM 09810	UM 13810
382	UM 02020	UM 04820	UM 07020	UM 09820	UM 13820
383	UM 02030	UM 04830	UM 07030	UM 09830	UM 13830
384	UM 02040	UM 04840	UM 07040	UM 09840	UM 13840
385	UM 02050	UM 04850	UM 07050	UM 09850	UM 13850
386	UM 02060	UM 04860	UM 07060	UM 09860	UM 13860
387	UM 02070	UM 04870	UM 07070	UM 09870	UM 13870
388	UM 02080	UM 04880	UM 07080	UM 09880	UM 13880
389	UM 02090	UM 04890	UM 07090	UM 09890	UM 13890
390	UM 020A0	UM 048A0	UM 070A0	UM 098A0	UM 138A0
391	UM 020B0	UM 048B0	UM 070B0	UM 098B0	UM 138B0
392	UM 020C0	UM 048C0	UM 070C0	UM 098C0	UM 138C0
393	UM 020D0	UM 048D0	UM 070D0	UM 098D0	UM 138D0
394	UM 020E0	UM 048E0	UM 070E0	UM 098E0	UM 138E0
395	UM 020F0	UM 048F0	UM 070F0	UM 098F0	UM 138F0
396	UM 02100	UM 04900	UM 07100	UM 09900	UM 13900
397	UM 02110	UM 04910	UM 07110	UM 09910	UM 13910
398	UM 02120	UM 04920	UM 07120	UM 09920	UM 13920
399	UM 02130	UM 04930	UM 07130	UM 09930	UM 13930
400	UM 02140	UM 04940	UM 07140	UM 09940	UM 13940
401	UM 02150	UM 04950	UM 07150	UM 09950	UM 13950
402	UM 02160	UM 04960	UM 07160	UM 09960	UM 13960
403	UM 02170	UM 04970	UM 07170	UM 09970	UM 13970
404	UM 02180	UM 04980	UM 07180	UM 09980	UM 13980
405	UM 02190	UM 04990	UM 07190	UM 09990	UM 13990
406	UM 021A0	UM 049A0	UM 071A0	UM 099A0	UM 139A0
407	UM 021B0	UM 049B0	UM 071B0	UM 099B0	UM 139B0
408	UM 021C0	UM 049C0	UM 071C0	UM 099C0	UM 139C0
409	UM 021D0	UM 049D0	UM 071D0	UM 099D0	UM 139D0
410	UM 021E0	UM 049E0	UM 071E0	UM 099E0	UM 139E0
411	UM 021F0	UM 049F0	UM 071F0	UM 099F0	UM 139F0
412	UM 02200	UM 04A00	UM 07200	UM 09A00	UM 13A00
413	UM 02210	UM 04A10	UM 07210	UM 09A10	UM 13A10
414	UM 02220	UM 04A20	UM 07220	UM 09A20	UM 13A20
415	UM 02230	UM 04A30	UM 07230	UM 09A30	UM 13A30

Table no.	1st axis	2nd axis	3rd axis	4th axis	Virtual axis
416	UM 02240	UM 04A40	UM 07240	UM 09A40	UM 13A40
417	UM 02250	UM 04A50	UM 07250	UM 09A50	UM 13A50
418	UM 02260	UM 04A60	UM 07260	UM 09A60	UM 13A60
419	UM 02270	UM 04A70	UM 07270	UM 09A70	UM 13A70
420	UM 02280	UM 04A80	UM 07280	UM 09A80	UM 13A80
421	UM 02290	UM 04A90	UM 07290	UM 09A90	UM 13A90
422	UM 022A0	UM 04AA0	UM 072A0	UM 09AA0	UM 13AA0
423	UM 022B0	UM 04AB0	UM 072B0	UM 09AB0	UM 13AB0
424	UM 022C0	UM 04AC0	UM 072C0	UM 09AC0	UM 13AC0
425	UM 022D0	UM 04AD0	UM 072D0	UM 09AD0	UM 13AD0
426	UM 022E0	UM 04AE0	UM 072E0	UM 09AE0	UM 13AE0
427	UM 022F0	UM 04AF0	UM 072F0	UM 09AF0	UM 13AF0
428	UM 02300	UM 04B00	UM 07300	UM 09B00	UM 13B00
429	UM 02310	UM 04B10	UM 07310	UM 09B10	UM 13B10
430	UM 02320	UM 04B20	UM 07320	UM 09B20	UM 13B20
431	UM 02330	UM 04B30	UM 07330	UM 09B30	UM 13B30
432	UM 02340	UM 04B40	UM 07340	UM 09B40	UM 13B40
433	UM 02350	UM 04B50	UM 07350	UM 09B50	UM 13B50
434	UM 02360	UM 04B60	UM 07360	UM 09B60	UM 13B60
435	UM 02370	UM 04B70	UM 07370	UM 09B70	UM 13B70
436	UM 02380	UM 04B80	UM 07380	UM 09B80	UM 13B80
437	UM 02390	UM 04B90	UM 07390	UM 09B90	UM 13B90
438	UM 023A0	UM 04BA0	UM 073A0	UM 09BA0	UM 13BA0
439	UM 023B0	UM 04BB0	UM 073B0	UM 09BB0	UM 13BB0
440	UM 023C0	UM 04BC0	UM 073C0	UM 09BC0	UM 13BC0
441	UM 023D0	UM 04BD0	UM 073D0	UM 09BD0	UM 13BD0
442	UM 023E0	UM 04BE0	UM 073E0	UM 09BE0	UM 13BE0
443	UM 023F0	UM 04BF0	UM 073F0	UM 09BF0	UM 13BF0
444	UM 02400	UM 04C00	UM 07400	UM 09C00	UM 13C00
445	UM 02410	UM 04C10	UM 07410	UM 09C10	UM 13C10
446	UM 02420	UM 04C20	UM 07420	UM 09C20	UM 13C20
447	UM 02430	UM 04C30	UM 07430	UM 09C30	UM 13C30
448	UM 02440	UM 04C40	UM 07440	UM 09C40	UM 13C40
449	UM 02450	UM 04C50	UM 07450	UM 09C50	UM 13C50
450	UM 02460	UM 04C60	UM 07460	UM 09C60	UM 13C60
451	UM 02470	UM 04C70	UM 07470	UM 09C70	UM 13C70
452	UM 02480	UM 04C80	UM 07480	UM 09C80	UM 13C80
453	UM 02490	UM 04C90	UM 07490	UM 09C90	UM 13C90
454	UM 024A0	UM 04CA0	UM 074A0	UM 09CA0	UM 13CA0
455	UM 024B0	UM 04CB0	UM 074B0	UM 09CB0	UM 13CB0
456	UM 024C0	UM 04CC0	UM 074C0	UM 09CC0	UM 13CC0
457	UM 024D0	UM 04CD0	UM 074D0	UM 09CD0	UM 13CD0

Table no.	1st axis	2nd axis	3rd axis	4th axis	Virtual axis
458	UM 024E0	UM 04CE0	UM 074E0	UM 09CE0	UM 13CE0
459	UM 024F0	UM 04CF0	UM 074F0	UM 09CF0	UM 13CF0
460	UM 02500	UM 04D00	UM 07500	UM 09D00	UM 13D00
461	UM 02510	UM 04D10	UM 07510	UM 09D10	UM 13D10
462	UM 02520	UM 04D20	UM 07520	UM 09D20	UM 13D20
463	UM 02530	UM 04D30	UM 07530	UM 09D30	UM 13D30
464	UM 02540	UM 04D40	UM 07540	UM 09D40	UM 13D40
465	UM 02550	UM 04D50	UM 07550	UM 09D50	UM 13D50
466	UM 02560	UM 04D60	UM 07560	UM 09D60	UM 13D60
467	UM 02570	UM 04D70	UM 07570	UM 09D70	UM 13D70
468	UM 02580	UM 04D80	UM 07580	UM 09D80	UM 13D80
469	UM 02590	UM 04D90	UM 07590	UM 09D90	UM 13D90
470	UM 025A0	UM 04DA0	UM 075A0	UM 09DA0	UM 13DA0
471	UM 025B0	UM 04DB0	UM 075B0	UM 09DB0	UM 13DB0
472	UM 025C0	UM 04DC0	UM 075C0	UM 09DC0	UM 13DC0
473	UM 025D0	UM 04DD0	UM 075D0	UM 09DD0	UM 13DD0
474	UM 025E0	UM 04DE0	UM 075E0	UM 09DE0	UM 13DE0
475	UM 025F0	UM 04DF0	UM 075F0	UM 09DF0	UM 13DF0
476	UM 02600	UM 04E00	UM 07600	UM 09E00	UM 13E00
477	UM 02610	UM 04E10	UM 07610	UM 09E10	UM 13E10
478	UM 02620	UM 04E20	UM 07620	UM 09E20	UM 13E20
479	UM 02630	UM 04E30	UM 07630	UM 09E30	UM 13E30
480	UM 02640	UM 04E40	UM 07640	UM 09E40	UM 13E40
481	UM 02650	UM 04E50	UM 07650	UM 09E50	UM 13E50
482	UM 02660	UM 04E60	UM 07660	UM 09E60	UM 13E60
483	UM 02670	UM 04E70	UM 07670	UM 09E70	UM 13E70
484	UM 02680	UM 04E80	UM 07680	UM 09E80	UM 13E80
485	UM 02690	UM 04E90	UM 07690	UM 09E90	UM 13E90
486	UM 026A0	UM 04EA0	UM 076A0	UM 09EA0	UM 13EA0
487	UM 026B0	UM 04EB0	UM 076B0	UM 09EB0	UM 13EB0
488	UM 026C0	UM 04EC0	UM 076C0	UM 09EC0	UM 13EC0
489	UM 026D0	UM 04ED0	UM 076D0	UM 09ED0	UM 13ED0
490	UM 026E0	UM 04EE0	UM 076E0	UM 09EE0	UM 13EE0
491	UM 026F0	UM 04EF0	UM 076F0	UM 09EF0	UM 13EF0
492	UM 02700	UM 04F00	UM 07700	UM 09F00	UM 13F00
493	UM 02710	UM 04F10	UM 07710	UM 09F10	UM 13F10
494	UM 02720	UM 04F20	UM 07720	UM 09F20	UM 13F20
495	UM 02730	UM 04F30	UM 07730	UM 09F30	UM 13F30
496	UM 02740	UM 04F40	UM 07740	UM 09F40	UM 13F40
497	UM 02750	UM 04F50	UM 07750	UM 09F50	UM 13F50
498	UM 02760	UM 04F60	UM 07760	UM 09F60	UM 13F60
499	UM 02770	UM 04F70	UM 07770	UM 09F70	UM 13F70

Table no.	1st axis	2nd axis	3rd axis	4th axis	Virtual axis
500	UM 02780	UM 04F80	UM 07780	UM 09F80	UM 13F80
501	UM 02790	UM 04F90	UM 07790	UM 09F90	UM 13F90
502	UM 027A0	UM 04FA0	UM 077A0	UM 09FA0	UM 13FA0
503	UM 027B0	UM 04FB0	UM 077B0	UM 09FB0	UM 13FB0
504	UM 027C0	UM 04FC0	UM 077C0	UM 09FC0	UM 13FC0
505	UM 027D0	UM 04FD0	UM 077D0	UM 09FD0	UM 13FD0
506	UM 027E0	UM 04FE0	UM 077E0	UM 09FE0	UM 13FE0
507	UM 027F0	UM 04FF0	UM 077F0	UM 09FF0	UM 13FF0
508	UM 02800	UM 05000	UM 07800	UM 0A000	UM 14000
509	UM 02810	UM 05010	UM 07810	UM 0A010	UM 14010
510	UM 02820	UM 05020	UM 07820	UM 0A020	UM 14020
511	UM 02830	UM 05030	UM 07830	UM 0A030	UM 14030
512	UM 02840	UM 05040	UM 07840	UM 0A040	UM 14040
513	UM 02850	UM 05050	UM 07850	UM 0A050	UM 14050
514	UM 02860	UM 05060	UM 07860	UM 0A060	UM 14060
515	UM 02870	UM 05070	UM 07870	UM 0A070	UM 14070
516	UM 02880	UM 05080	UM 07880	UM 0A080	UM 14080
517	UM 02890	UM 05090	UM 07890	UM 0A090	UM 14090
518	UM 028A0	UM 050A0	UM 078A0	UM 0A0A0	UM 140A0
519	UM 028B0	UM 050B0	UM 078B0	UM 0A0B0	UM 140B0
520	UM 028C0	UM 050C0	UM 078C0	UM 0A0C0	UM 140C0
521	UM 028D0	UM 050D0	UM 078D0	UM 0A0D0	UM 140D0
522	UM 028E0	UM 050E0	UM 078E0	UM 0A0E0	UM 140E0
523	UM 028F0	UM 050F0	UM 078F0	UM 0A0F0	UM 140F0
524	UM 02900	UM 05100	UM 07900	UM 0A100	UM 14100
525	UM 02910	UM 05110	UM 07910	UM 0A110	UM 14110
526	UM 02920	UM 05120	UM 07920	UM 0A120	UM 14120
527	UM 02930	UM 05130	UM 07930	UM 0A130	UM 14130
528	UM 02940	UM 05140	UM 07940	UM 0A140	UM 14140
529	UM 02950	UM 05150	UM 07950	UM 0A150	UM 14150
530	UM 02960	UM 05160	UM 07960	UM 0A160	UM 14160
531	UM 02970	UM 05170	UM 07970	UM 0A170	UM 14170
532	UM 02980	UM 05180	UM 07980	UM 0A180	UM 14180
533	UM 02990	UM 05190	UM 07990	UM 0A190	UM 14190
534	UM 029A0	UM 051A0	UM 079A0	UM 0A1A0	UM 141A0
535	UM 029B0	UM 051B0	UM 079B0	UM 0A1B0	UM 141B0
536	UM 029C0	UM 051C0	UM 079C0	UM 0A1C0	UM 141C0
537	UM 029D0	UM 051D0	UM 079D0	UM 0A1D0	UM 141D0
538	UM 029E0	UM 051E0	UM 079E0	UM 0A1E0	UM 141E0
539	UM 029F0	UM 051F0	UM 079F0	UM 0A1F0	UM 141F0
540	UM 02A00	UM 05200	UM 07A00	UM 0A200	UM 14200
541	UM 02A10	UM 05210	UM 07A10	UM 0A210	UM 14210

Table no.	1st axis	2nd axis	3rd axis	4th axis	Virtual axis
542	UM 02A20	UM 05220	UM 07A20	UM 0A220	UM 14220
543	UM 02A30	UM 05230	UM 07A30	UM 0A230	UM 14230
544	UM 02A40	UM 05240	UM 07A40	UM 0A240	UM 14240
545	UM 02A50	UM 05250	UM 07A50	UM 0A250	UM 14250
546	UM 02A60	UM 05260	UM 07A60	UM 0A260	UM 14260
547	UM 02A70	UM 05270	UM 07A70	UM 0A270	UM 14270
548	UM 02A80	UM 05280	UM 07A80	UM 0A280	UM 14280
549	UM 02A90	UM 05290	UM 07A90	UM 0A290	UM 14290
550	UM 02AA0	UM 052A0	UM 07AA0	UM 0A2A0	UM 142A0
551	UM 02AB0	UM 052B0	UM 07AB0	UM 0A2B0	UM 142B0
552	UM 02AC0	UM 052C0	UM 07AC0	UM 0A2C0	UM 142C0
553	UM 02AD0	UM 052D0	UM 07AD0	UM 0A2D0	UM 142D0
554	UM 02AE0	UM 052E0	UM 07AE0	UM 0A2E0	UM 142E0
555	UM 02AF0	UM 052F0	UM 07AF0	UM 0A2F0	UM 142F0
556	UM 02B00	UM 05300	UM 07B00	UM 0A300	UM 14300
557	UM 02B10	UM 05310	UM 07B10	UM 0A310	UM 14310
558	UM 02B20	UM 05320	UM 07B20	UM 0A320	UM 14320
559	UM 02B30	UM 05330	UM 07B30	UM 0A330	UM 14330
560	UM 02B40	UM 05340	UM 07B40	UM 0A340	UM 14340
561	UM 02B50	UM 05350	UM 07B50	UM 0A350	UM 14350
562	UM 02B60	UM 05360	UM 07B60	UM 0A360	UM 14360
563	UM 02B70	UM 05370	UM 07B70	UM 0A370	UM 14370
564	UM 02B80	UM 05380	UM 07B80	UM 0A380	UM 14380
565	UM 02B90	UM 05390	UM 07B90	UM 0A390	UM 14390
566	UM 02BA0	UM 053A0	UM 07BA0	UM 0A3A0	UM 143A0
567	UM 02BB0	UM 053B0	UM 07BB0	UM 0A3B0	UM 143B0
568	UM 02BC0	UM 053C0	UM 07BC0	UM 0A3C0	UM 143C0
569	UM 02BD0	UM 053D0	UM 07BD0	UM 0A3D0	UM 143D0
570	UM 02BE0	UM 053E0	UM 07BE0	UM 0A3E0	UM 143E0
571	UM 02BF0	UM 053F0	UM 07BF0	UM 0A3F0	UM 143F0
572	UM 02C00	UM 05400	UM 07C00	UM 0A400	UM 14400
573	UM 02C10	UM 05410	UM 07C10	UM 0A410	UM 14410
574	UM 02C20	UM 05420	UM 07C20	UM 0A420	UM 14420
575	UM 02C30	UM 05430	UM 07C30	UM 0A430	UM 14430
576	UM 02C40	UM 05440	UM 07C40	UM 0A440	UM 14440
577	UM 02C50	UM 05450	UM 07C50	UM 0A450	UM 14450
578	UM 02C60	UM 05460	UM 07C60	UM 0A460	UM 14460
579	UM 02C70	UM 05470	UM 07C70	UM 0A470	UM 14470
580	UM 02C80	UM 05480	UM 07C80	UM 0A480	UM 14480
581	UM 02C90	UM 05490	UM 07C90	UM 0A490	UM 14490
582	UM 02CA0	UM 054A0	UM 07CA0	UM 0A4A0	UM 144A0
583	UM 02CB0	UM 054B0	UM 07CB0	UM 0A4B0	UM 144B0

Table no.	1st axis	2nd axis	3rd axis	4th axis	Virtual axis
584	UM 02CC0	UM 054C0	UM 07CC0	UM 0A4C0	UM 144C0
585	UM 02CD0	UM 054D0	UM 07CD0	UM 0A4D0	UM 144D0
586	UM 02CE0	UM 054E0	UM 07CE0	UM 0A4E0	UM 144E0
587	UM 02CF0	UM 054F0	UM 07CF0	UM 0A4F0	UM 144F0
588	UM 02D00	UM 05500	UM 07D00	UM 0A500	UM 14500
589	UM 02D10	UM 05510	UM 07D10	UM 0A510	UM 14510
590	UM 02D20	UM 05520	UM 07D20	UM 0A520	UM 14520
591	UM 02D30	UM 05530	UM 07D30	UM 0A530	UM 14530
592	UM 02D40	UM 05540	UM 07D40	UM 0A540	UM 14540
593	UM 02D50	UM 05550	UM 07D50	UM 0A550	UM 14550
594	UM 02D60	UM 05560	UM 07D60	UM 0A560	UM 14560
595	UM 02D70	UM 05570	UM 07D70	UM 0A570	UM 14570
596	UM 02D80	UM 05580	UM 07D80	UM 0A580	UM 14580
597	UM 02D90	UM 05590	UM 07D90	UM 0A590	UM 14590
598	UM 02DA0	UM 055A0	UM 07DA0	UM 0A5A0	UM 145A0
599	UM 02DB0	UM 055B0	UM 07DB0	UM 0A5B0	UM 145B0
600	UM 02DC0	UM 055C0	UM 07DC0	UM 0A5C0	UM 145C0
10001	UM 02E70	UM 05670	UM 07E70	UM 0A670	UM 14670
10002	UM 02E80	UM 05680	UM 07E80	UM 0A680	UM 14680
10003	UM 02E90	UM 05690	UM 07E90	UM 0A690	UM 14690
10004	UM 02EA0	UM 056A0	UM 07EA0	UM 0A6A0	UM 146A0
10005	UM 02EB0	UM 056B0	UM 07EB0	UM 0A6B0	UM 146B0
10006	UM 02EC0	UM 056C0	UM 07EC0	UM 0A6C0	UM 146C0
10007	UM 02ED0	UM 056D0	UM 07ED0	UM 0A6D0	UM 146D0
10008	UM 02EE0	UM 056E0	UM 07EE0	UM 0A6E0	UM 146E0
10009	UM 02EF0	UM 056F0	UM 07EF0	UM 0A6F0	UM 146F0
10010	UM 02F00	UM 05700	UM 07F00	UM 0A700	UM 14700
10011	UM 02F10	UM 05710	UM 07F10	UM 0A710	UM 14710
10012	UM 02F20	UM 05720	UM 07F20	UM 0A720	UM 14720
10013	UM 02F30	UM 05730	UM 07F30	UM 0A730	UM 14730
10014	UM 02F40	UM 05740	UM 07F40	UM 0A740	UM 14740
10015	UM 02F50	UM 05750	UM 07F50	UM 0A750	UM 14750

Table no.	1st axis	2nd axis	3rd axis	4th axis	Virtual axis
10016	UM 02F60	UM 05760	UM 07F60	UM 0A760	UM 14760
10017	UM 02F70	UM 05770	UM 07F70	UM 0A770	UM 14770
10018	UM 02F80	UM 05780	UM 07F80	UM 0A780	UM 14780
10019	UM 02F90	UM 05790	UM 07F90	UM 0A790	UM 14790
10020	UM 02FA0	UM 057A0	UM 07FA0	UM 0A7A0	UM 147A0
10021	UM 02FB0	UM 057B0	UM 07FB0	UM 0A7B0	UM 147B0
10022	UM 02FC0	UM 057C0	UM 07FC0	UM 0A7C0	UM 147C0
10023	UM 02FD0	UM 057D0	UM 07FD0	UM 0A7D0	UM 147D0
10024	UM 02FE0	UM 057E0	UM 07FE0	UM 0A7E0	UM 147E0
10025	UM 02FF0	UM 057F0	UM 07FF0	UM 0A7F0	UM 147F0

# 17.7 Unit Memory Synchronous Control Setting Area

# 17.7.1 Synchronous Control Setting Area

This is an area for monitoring the setting status of synchronous control.

Unit memory no. (Hex)	Description		
UM 16000 - UM1600F		Synchronous control common setting area	
UM 16010 - UM1601F	Synchronous setting	Electronic gear setting area	
UM 16020 - UM1604F	area of 1st axis	Clutch setting area	
UM 16050 - UM1606F		Electronic cam setting area	
UM 16070 - UM1607F		Synchronous control common setting area	
UM 16080 - UM1608F	Synchronous setting	Electronic gear setting area	
UM 16090 - UM160BF	area of 2nd axis	Clutch setting area	
UM 160C0 - UM160DF		Electronic cam setting area	
UM 160E0 - UM160EF		Synchronous control common setting area	
UM 160F0 - UM160FF	Synchronous setting	Electronic gear setting area	
UM 16100 - UM1612F	area of 3rd axis	Clutch setting area	
UM 16130 - UM1614F		Electronic cam setting area	
UM 16150 - UM1615F		Synchronous control common setting area	
UM 16160 - UM1616F	Synchronous setting	Electronic gear setting area	
UM 16170 - UM1619F	area of 4th axis	Clutch setting area	
UM 161A0 - UM161BF		Electronic cam setting area	
UM 161C0 - UM163FF	(Not used)		

Phone: 800.894.0412 - Fax: 888.723.4773 - Web: www.ctiautomation.net - Email: info@ctiautomation.net

## 17.7.2 Detailed Information on Synchronous Control Setting Area

Make synchronous control settings in this area. These values set in the Configuration menu will be stored automatically. Therefore, individual settings are not necessary.

Offset address	Name	Default	Description			
			Set the ma	Set the master axis for each axis.		
			Set value	Master axis		
			0000H	No synchronous master axis or the target set axis is the		
Each a synchi maste selecti			0001H	1st axis		
	Each axis		0002H	2nd axis		
	synchronous	0000H	0003H	3rd axis		
	master axis		0004H	4th axis		
	Selection		0010H	Virtual axis		
			0021H	Pulse input 1		
			0022H	Pulse input 2		
			0023H	Pulse input 3		
			0024H	Pulse input 4		
			The state of the s	of the synchronous operating	function set for the axis	
	Each axis		bit	Functions	Setting	
001	synchronous output		0	Electronic gear setting	0: Yes	
001H	function	00000	1	Clutch operation settings	1: No	
	selection		2	Electronic cam operation settings		
			3-15	Area reserved for system		

#### Synchronous control common setting area

#### Electronic gear setting area

Offset address	Name	Default	Description
010H - 011H	Each axis gear ratio numerator	1	1 to 2,147,483,647
012H - 013H	Each axis gear ratio denominator	1	1 to 2,147,483,647
014H	Each axis gear change time	1	1 to 10000

### Clutch setting area

Offset address	Name	Default	Description
020H	Clutch ON trigger types	00H	00H: I/O clutch ON request
			Set enabled conditions for the trigger signal.
0211	Clutch ON edge selection	004	00H: Level
02111	Clutch ON edge selection	0011	01H: Rising edge
			02H: Falling edge
028H	Clutch OFF trigger types	00H	00H: I/O clutch OFF request
			Set enabled conditions for the trigger signal.
0201	Clutch OFF edge selection	00Н	00H: Level
02911			01H: Rising edge
			02H: Falling edge
030H	Clutch ON method	00H	00H: Direct
00011			01H: Slip
032H	Clutch ON slip method	00H	00H: Slip time setting
033H	Clutch ON slip time	1	1 to 10000 ms
036H	Clutch ON slip curve selection	00H	00H: Linear
040		0011	00H: Direct
040H	Clutch OFF method		01H: Slip
042H	Clutch OFF slip method	00H	00H: Slip time setting
043H	Clutch OFF slip time	1	1 to 10000 ms
046H	Clutch OFF slip curve selection	00H	00H: Linear

## Electronic cam setting area

Offset address	Name	Default	Description
050H	Cam control	1	Settings for cam control synchronous master cycle
- 051H synchronous master axis cycle		1	1 to 2,147,483,647
053H	Cam pattern number used	1	Registered cam pattern number for use
			1 to (16)
054H	Com stroke emount	1	Displacement upper limit settings for cam control
- 055H	Cam stroke amount		1 to 2,147,483,647

# 17.8 Dimensions

#### ■ 2-axis type



# **18** Sample program

# 18.1 Basic Configuration and Contact Allocations of Sample Programs

In the sample programs, the internal relays are used for the start contacts of each operation. Connect them to the input contacts such as switches as needed.

#### Basic Configuration



The positioning unit installed in slot 1. The 1st axis and 2nd axis of the positioning unit connect to a stepping motor each, with the linear interpolation of the 2nd axis sampled. This example is shown on the condition that parameter settings for each axis are made in the positioning setting menu of the programming tool and saved in the positioning unit.

Number	Description		
R2	Request home return		
R3	Request positioning start		
R4	1st axis JOG forward request		
R5	1st axis JOG reverse request		
R6	2nd axis JOG forward request		
R7	2nd axis JOG reverse request		
R10	Error clear		
R11	Request set value change		
R100	Operation enabled flag for 1st axis		
R101	1st axis JOG forward OFF edge		
R102	1st axis JOG reverse OFF edge		
R200	Operation enabled flag for 2nd axis		
R201	2nd axis JOG forward OFF edge		
R202	2nd axis JOG reverse OFF edge		

#### Used contacts and data registers

Number	Description		
X100	Ready positioning flag		
X104	Tool operation for all axes		
X107	Recalculation done flag		
X118	1st axis BUSY flag		
X119	2nd axis BUSY flag		
X160	Error occurrence annunciation for 1st axis		
X161	Error occurrence annunciation for 2nd axis		
Y107	Request recalculation		
Y110	Positioning start for 1st axis		
Y118	Home return of 1st axis		
Y119	Home return of 2nd axis		
Y120	1st axis JOG forward		
Y121	1st axis JOG reverse		
Y122	2nd axis JOG forward		
Y123	2nd axis JOG reverse		
Y160	Error clear for 1st axis		
Y161	Error clear for 2nd axis		

Number	Description		
DT0	Starting table number		
DT101	Number of errors of 1st axis		
DT102 - DT115	Error contents of 1st axis		
DT121	Number of errors of 2nd axis		
DT122 - DT135	Error contents of 2nd axis		
DT10 - DT25	Positioning data (of 1 table) of 1st axis		
DT30 - DT45	Positioning data (of 1 table) of 2nd axis		

# 18.2 Sample program

## 18.2.1 When Settings Done in Standard Area with Programming tool

#### Sample program







## 18.2.2 When Setting Positioning Data in Extended Area by Programming

Write positioning data in the extended area by programming.

Recalculating the positioning data is not necessary as the extended area is used.

#### Replace the part of the positioning start program in the sample program

#### Positioning start program





## 18.2.3 When Setting Positioning Data in Standard Area by Programming

Write positioning data in the standard area by programming.

Recalculating the positioning data is necessary after setting the positioning data.

#### Replace the part of the positioning start program in the sample program

#### Positioning start program





# **Record of changes**

Manual No.	Date	Record of Changes
WUME-FP7POSP-01	Mar.2013	First Edition