

RTX 1000A Series PRESSURE TRANSMITTER



Safety

To use this equipment safely, you must use the data and procedures in these publications:

- The "Calibration data and instructions" for the equipment
- This user manual

These publications contain instructions to operate the equipment and maintain it in a safe condition. To prevent damage or injury:

- Obey all warnings and cautions.
- Use the equipment only for the specified applications.
- Operate the equipment only in the specified limits.

To install and use the equipment, use only approved engineers who have the necessary skills and qualifications.

Hazardous areas

Some versions of this equipment are certified for use in hazardous areas (the ATEX Directive 94/9/EC - Equipment and Protective Systems Intended for Use in Potentially Explosive Atmospheres). For these versions, the publication "Calibration data and instructions" contains additional data. The additional data includes some or all of these items:

- Marking details
- Materials
- Installation
- Configuration/Calibration (or Connections to other equipment)
- Maintenance
- Repair
- Special conditions for safe use



This product complies with the requirements of the relevant EEC directives. For data on the applied standards, refer to the "Declaration of Conformity".

RTX 1000A Series User Manual

ABBREVIATIONS

The abbreviations in this publication are as follows:

Note: Abbreviations are the same in the singular and plural.

a	absolute pressure
A/D	analogue to digital
ATEX	ATmosphères EXplosibles (explosive atmospheres)
AWG	American wire gage
COSHH	control of substances hazardous to health regulations
D/A	digital to analogue
DAC	digital to analogue convertor
DC	direct current
DIN	Deutsche Industrie Norm
DIP	dual inline package
DPM	digital pressure module
°C	degrees Celsius
°F	degrees Fahrenheit
EEPROM	electrically erasable programmable read-only memory
EMC	electromagnetic compatibility
FS	full-scale
g	gauge pressure
kg	kilogram
kgf.m	kilogram-force metre
lb	pound
lb.ft	pound-force feet
LCD	liquid crystal display
LDV	lower display value
LRV	lower range value

ABBREVIATIONS (continued)

m	metre
mA	milliampere
max	maximum
mbar	millibar
μF	microfarads
mH	millihenry
min	minimum/minute
mm	millimetre
mmH_2O	millimetre of water
MWP	maximum working pressure
Nm	newton metres
PCB	printed circuit board
psi	pound-force per square inch
PTFE	polytetrafluoroethylene
PV	primary variable
RFI	radio frequency interference
RH	relative humidity
RTX	rangeable transmitter
s	seconds
sg	specific gravity
TSL	terminal straight line
UDV	upper display value
URL	upper range limit
URV	upper range value
V	volt
Ω	ohm
W	watt

RTX 1000A Series User Manual

CONTENTS

Section	title	page
	Safety	i
	ABBREVIATIONS	ii
	CONTENTS	iv
1	DESCRIPTION	1-1
1.1	Introduction	1-1
1.2	About the Electronics Housing	1-1
1.3	Identification Codes	1-3
2	TECHNICAL DATA	2-1
2.1	Pressure Ranges	2-1
2.2	Environment Data	2-1
2.3	Performance Data	2-1
2.4	Physical Data	2-4
3	INSTALLATION	3-1
3.1	Introduction	3-1
3.2	Special Tools and Equipment	3-1
3.3	Location and Mounting	3-2
3.4	To Rotate the Display Thru 90°	3-2
3.5	To Rotate the Housing	3-3
3.6	Impulse Piping	3-3
3.7	The Transmitter Pressure Connections	3-4
3.8	Liquid Level Measurement	3-6
3.9	Electrical Data	3-7
3.10	System Checks	3-10

CONTENTS (continued)

4	OPERATION	4-1
4.1	General	4-1
4.2	Manual Configuration Facilities	4-2
4.3	Manual Configuration - LCD Operation	4-3
4.4	Manual Configuration - Calibration	4-4
5	Maintenance	5-1
5.1	General	5-1
5.2	Fault Finding	5-2
5.3	Returned Goods Procedure	5-3
	Safety Precautions	5-3
	Important Notice	5-3
	Approved Service Agents	Back cover

RTX 1000A Series User Manual

ILLUSTRATIONS

Figure	title	page
1-1	General view	1-1
1-2	Transmitter schematic diagram	1-2
2-1	Range limits	2-1
2-2	Dimensions (Transmitter)	2-4
2-3	Dimensions (Optional mounting bracket)	2-5
3-1	Display - Turn thru 90°	3-2
3-2	Housing locking screws	3-3
3-3	Piping arrangements	3-5
3-4	Open tank level measurement	3-6
3-5	Power and load requirements	3-7
3-6	Electrical conduit configuration	3-9
3-7	Transmitter connections	3-9
4-1	Location of DIP switches and push buttons	4-2
4-4	Calibration set-up for safe areas	4-4
5-1	Fault finding from the output signal	5-2

TABLES

Table	title	page
1-1	Identification codes	1-4
3-1	Wire resistance	3-8
4-1	DIP switch operation	4-2
4-2	Steps to change the LCD configuration	4-3
5-1	LCD alarm codes and error messages	5-2

1 DESCRIPTION

1.1 Introduction

The GE Druck RTX 1000A series is a process pressure transmitter that measures the pressure of liquid, gas or vapour and gives an analogue output proportional to the applied pressure. The transmitter is available in a compact and lightweight metal housing with facilities for direct mounting to pipeline installations. The type of housing is specified in the order.

To adjust the transmitter operation, there are push-buttons and switches on the electronics module

1.2 About the Electronics Housing (Figure 1-1)

The electronics housing contains a digital pressure module (DPM), electronics module, connecting cables and the terminal block.




Figure 1-1 General view




Figure 1-2 Transmitter schematic diagram

Digital Pressure Module (DPM) - (Figure 1-2)

The sensing element in the DPM is constructed from a micro-machined silicon diaphragm assembly bonded to a stainless steel or Hastelloy body. A Hastelloy isolation diaphragm and silicone fluid isolates the sensing element from the process media.

The sensor piezo-resistors, diffused into the surface of the silicon diaphragm, produce a signal in response to applied pressure. The accuracy of the sensor element is enhanced by measuring the residual errors over its operating temperature and pressure range and applying digital compensation in the transmitter electronics.

Electronics Module (Figure 1-2)

The electronics module uses microprocessor technology to give a compact circuit with the minimum of components. The module produces an extremely stable signal unaffected by changes in ambient temperature.

An optional LCD shows a value proportional to the measured pressure. Unless an alternative configuration is specified in the order, the factory configuration shows the pressure value as a percentage of the calibrated span. To change the configuration, refer to section 4.

1.3 Identification Codes (Table 1-1)

Table 1-1 shows the identification codes for the transmitter. Before you install the transmitter, use this table to make sure that the data on the transmitter is correct.

RTX 1000A Series User Manual

Table 1-1 Identification codes

RTX 10		Base Model Number			
Code	Diaphragm	Process Wetted Body		Fill Fluid	
00	Hastelloy C	316 stainless steel		Silicone oil	
10	Hastelloy C	Hastelloy C		Silicone oil	
20	Inconel 625*	Inconel 625*		Silicone oil	
Code	Output				
A	4 - 20 mA				
Code	Max Span	Min Span	Notes		
04	0 - 700 mbar	0 - 70 mbar	Gauge or absolute		
07	0 - 2 bar	0 - 200 mbar	Gauge or absolute		
10	0 - 7 bar	0 - 700 mbar	Gauge or absolute		
13	0 - 20 bar	0 - 2 bar	Gauge or absolute		
16	0 - 70 bar	0 - 7 bar	Gauge or absolute		
18	0 - 200 bar	0 - 20 bar	Sealed gauge or absolute		
22	0 - 700 bar	0 - 70 bar	Sealed gauge or absolute		
24	0 - 1400 bar **	0 - 140 bar	Sealed gauge or absolute		
Code	Type				
A	Absolute				
G	Gauge (sealed gauge for ranges above 70 bar)				
Code	Process Connection				
1	G½ female				
2	½-14 NPT female				
3	G½ male to BS EN 837-1 (DIN 16288)				
4	½ NPT male				
5	9/16" tube Autoclave Engineers medium pressure, SF562CX20 female***				
Code	Electrical Entry				
M	M20 female				
N	½-14 NPT female (via adaptor)				
P	PG 13.5 female (via adaptor)				
Code	Electronics Housing	End-caps			
0	Aluminium alloy	Aluminium alloy			
S	Stainless steel	Aluminium bronze			
Code	Approvals				
0	Safe area				
I	ATEX Intrinsically Safe (EEx ia)				
D	ATEX Flameproof (EEx d)				
N	ATEX Type 'n' (EEx nL)				
Code	Options				
0	None				
LA	Digital indicator				
B	Bracket mounting				
T	DIN 3.1B material certificate				

Example identification code

RTX10 - 00 - A - 07 - G - 2 - M - 0 - 0 - 0

* Only available with range code 24, process connection code 5, and approval options 0, I or N.

** Range code 24 (0-1400 bar) only applies to RTX 1020 models.

*** Process connection code 5 (autoclave fitting) only applies to range code 24.

RTX 1000A Series User Manual

Accuracy

0.15% of calibrated span. This includes non-linearity, hysteresis and repeatability.

Long term stability

At standard reference conditions, the maximum change in calibration is not more than 0.2% URL in a five year period.

Time response

Update rate (Compensated pressure reading) 100ms

Damping (switch selection) 0.1 or 1 s to reach 63% of final value

Temperature effects

-40°C to -20°C (-40°F to -4°F): 0.5% URL +1% span

-20°C to +50°C (-4°F to +122°F): 0.25% URL +0.75% span

+50°C to +85°C (+122°F to +185°F): 0.5% URL +1% span

Mounting position effect

Negligible effect. For ranges below 700 mbar, you can adjust the 'g' offset effect with the zero offset control.

Error conditions (NAMUR NE 43 compliant)

Failure mode (< 3.6 or > 21 mA) Switch selected option

Under range 3.8 mA minimum

Over range 20.5 mA maximum

An optional LCD shows the applicable alarm data. If the pressure is not in the upper or lower range limits, the pressure value on the display will flash.

Turn-on time

..... 2 seconds

Electronics housing

Material Aluminium alloy with polyester powder coating
or Stainless steel with aluminium bronze end-caps

Environmental protection IP67

Overpressure

These pressure values will not degrade performance:

- 6 x URL for 700 mbar range
- 4 x URL (140 bar max) for ranges: 2 bar to 70 bar
- 2 x URL (900 bar max) for ranges: 200 bar to 700 bar
- 2000 bar for 1400 bar range

Pressure containment

These pressures may damage the sensor but there is no leakage of the process media.

- 10 x URL for 700 mbar range
- 6 x URL (200 bar max) for ranges: 2 bar to 70 bar
- 200 bar for ranges up to 70 bar absolute
- 1400 bar for ranges: 200 bar to 700 bar sealed gauge and absolute
- 2100 bar for 1400 bar range

Process media

A liquid, gas or vapour compatible with a fully welded assembly that includes:

- A Hastelloy C276 diaphragm, and a body that is made of either 316 stainless steel or Hastelloy C276. Complies with NACE MR-01-75.
- Inconel 625 (1400 bar range, range code 24 only).

Sensor fill fluid

- Silicone oil

Output current

(two wire configuration) 4 - 20 mA

The output is proportional to the calibrated pressure range.

Supply voltage (at the terminals)

Safe area 12 to 35 V DC

Hazardous area Refer to the "Calibration data and instructions"

RTX 1000A Series User Manual

2.4 Physical Data

Electrical/Process connections

..... Refer to table 1-1

Dimensions

..... Refer to figure 2-2, 2-3


Weight (without options)

Aluminium housing ≈ 1.14 kg (2.51 lb)

Stainless steel housing ≈ 2.7 kg (5.95 lb)

Options


- Digital indicator: polarity sign + 5 digits
 - Aluminium option Add ≈ 0.16 kg (0.35 lb)
 - Stainless steel option Add ≈ 0.3 kg (0.66 lb)
- Mounting bracket/bolts (stainless steel)
- Material traceability for pressure containment parts to EN10204 3.1B



*LCD indicator option: 138 mm (5.43")

Dimensions in millimetres (inches) - illustration not to scale

Figure 2-2 Dimensions (Transmitter)



Dimensions in millimetres (inches) - illustration not to scale

Figure 2-3 Dimensions (Optional mounting bracket)

RTX 1000A Series User Manual

3 INSTALLATION

Note: If the equipment is certified for use in a hazardous area, refer to the publication "Calibration data and instructions" for additional data.

3.1 Introduction

The following procedures detail the correct installation of the unit.

Use qualified plant installation personnel and follow good engineering practice at all times.

WARNINGS:

- 1. OBSERVE APPROPRIATE LOCAL SAFETY INSTRUCTIONS.**
- 2. BEFORE INSTALLATION, EXAMINE ALL FITTINGS AND EQUIPMENT FOR DAMAGE AND MAKE SURE THAT ALL EQUIPMENT IS TO THE CORRECT PRESSURE RATING.**
- 3. USE THE IDENTIFICATION CODE ON THE TRANSMITTER TO MAKE SURE THAT IT HAS THE CORRECT SPECIFICATION FOR THE INSTALLATION (REFER TO TABLE 1-1).**

3.2 Special Tools and Equipment

The following special tools and equipment are required.

Note: Equivalent substitutes can be used.

Special tools

- Applicable torque wrench
- GE Druck UPS-II [to measure current output]
- Multimeter [to measure loop resistance]

Materials

- Piping - the necessary length and rating depends on the distances.
- Fittings to connect the above items including (but not limited to):
 - Pipe tee (steam or high temperature liquid)
 - Pipe fittings
- Pipe compound or Teflon tape (where local piping codes allow)
- Loctite PST sealant

RTX 1000A Series User Manual

3.3 Location and Mounting (Figure 3-3)

Although designed to withstand harsh industrial environments, the transmitter should be located to minimize the following:

- Vibration
- Ambient temperature fluctuations
- Physical impact or shock

3.4 To Rotate the Display Thru 90° (Figure 3-1)

If applicable, use the following procedure to turn the optional display in the electronics housing.




Figure 3-1 Display - Turn thru 90°

1. Isolate the power supply to the transmitter.
2. Remove the end-cap.
3. Loosen each screw/washer (x4).
4. Turn the PCB and the display bezel thru 90° until the screws align with the spacers again.
5. Tighten each screw/washer (x4) back in position, but make sure that there is not too much force on the cables, and that they are not caught.
6. Attach the end-cap.

3.5 To Rotate the Housing (Figure 3-2)

CAUTION: Do not rotate the electronics housing on the transmitter more than 180 degrees relative to the pressure connection.

Two locking screws (hexagon socket screws) lock the electronics housing to the sensor body. To rotate the housing, loosen both of the screws and rotate the housing. When the angle is correct, tighten the screws.

Note: Do not remove the locking screws.




Figure 3-2 Housing locking screws

3.6 Impulse Piping (Figure 3-3)

The purpose of arranging impulse piping for the specific application is to maintain a single phase of fluid in the piping and transmitter. Liquid applications should maintain a liquid state and allow any air or gas formation to travel up and away from the transmitter. Gas applications should allow the formation of liquids to drain down and away from the transmitter.

The pipe or tubing used for connection must be rated for continuous operation at the pipeline designed pressure and temperature. Threaded pipe fittings create voids (where air can be trapped) and increase the possibility of leaks. When installing the connecting tubing or impulse piping, the following apply:

- Horizontally installed impulse piping must slope at least 75 mm per metre (approximately 1" per foot). For liquid and steam applications the piping must slope down towards the transmitter. For gas applications the piping must slope down away from the transmitter.
- Impulse piping should be kept as short as possible and maintained at ambient temperature avoiding fluctuations and gradients.

RTX 1000A Series User Manual

- Installations outdoors for liquid or saturated gas service may require insulation and heat tracing to prevent freezing.
- For installations where the transmitter is more than 1.8 m (6 feet) from the tapping, the impulse piping must be supported to prevent sagging and vibration.
- Impulse piping must be located in protected areas or against walls or ceilings. If routed across a floor, protective coverings or kick plates must be used. High temperature piping or equipment should be avoided.
- Appropriate pipe sealing compound rated at the design piping temperature must be used on all threaded connections. When making threaded connections between stainless steel fittings, Loctite PST Sealant is recommended.

3.7 The Transmitter Pressure Connections

The recommended connection uses a two-valve manifold connected between the transmitter and the process pressure. Before connecting the transmitter remove the protection caps and carefully inspect the sealing face and threaded bore of the connection for damage.

Liquid service connections (Figure 3-3a)

Liquid measurement connections should be made to the side of the process line to avoid deposits of sediment. The transmitter should be mounted beside or below the connection so that gases vent into the process line.

Gas service connections (Figure 3-3b)

Gas measurement connections should be made to the top or side of the process line. The transmitter should be mounted beside or above the connection allowing any liquid to drain into the process line.

Steam service connections (Figure 3-3c)

Steam measurement connections should be made to the side of the process line. The transmitter should be mounted below the connection so that the piping remains filled with condensate. Live steam must not come into contact with the transmitter; to prevent this the lines should be filled with water or condensate.




Figure 3-3 Piping arrangements

RTX 1000A Series User Manual

3.8 Liquid Level Measurement (Figure 3-4)

Gauge pressure transmitters can be used to measure liquid level in an open or vented tank by measuring the hydrostatic pressure head. The head pressure can be calculated by multiplying the liquid height above the transmitter diaphragm by the specific gravity of the liquid.

The tank's volume and shape does not affect the head pressure. If the transmitter is mounted below the zero point (minimum level) of the measured range, zero suppression will be required.




Figure 3-4 Open tank level measurement

Calculations

$$\begin{aligned} \text{Min. level} &= (1000 \times 1.1) \text{ mmH}_2\text{O} \\ &= 1100 \text{ mmH}_2\text{O} \\ \text{Max level} &= ([1000 + 5000] \times 1.1) \text{ mmH}_2\text{O} \\ &= (6000 \times 1.1) \text{ mmH}_2\text{O} \\ &= 6600 \text{ mmH}_2\text{O} \\ \text{Range} &= 1100 \text{ to } 6600 \text{ mmH}_2\text{O} \\ (\text{Span} &= 5500 \text{ mmH}_2\text{O}) \end{aligned}$$

3.9 Electrical Data

Note: If the equipment is certified for use in a hazardous area, refer to the publication "Calibration data and instructions" for additional data.

WARNING: SWITCH OFF AND ISOLATE THE POWER SUPPLY BEFORE CONNECTING OR DISCONNECTING THE TRANSMITTER.

CAUTIONS:

1. The transmitter uses DC power in a 2-wire system to control current through a resistive load.
2. Do not apply more than 35 Volts to the loop circuit. The transmitter may be damaged.

General

The electrical installation must comply with local wiring codes and standards. To get the full performance from the transmitter, carefully choose the wiring scheme to be used and take care connecting the transmitter.

Power and maximum load (Figure 3-5)

The total loop resistance must include the connection wire resistance.




Figure 3-5 Power and load requirements

RTX 1000A Series User Manual

Wire selection (Table 3-1)

To get the best EMC performance, use shielded twisted pair cable for the field wiring.

- Select a wire gauge for the required total length so the transmitter operates within the load requirements.
- When using external power supplies, make sure the connection polarity allows current to flow into the +ve terminal and out of the -ve terminal. Refer to figure 3-7.

Table 3-1 Wire resistance

AWG	Wire Diameter		Loop Resistance	
	Inches	mm	Ohms/Foot	Ohms/Meter
16	0.0508	(1.291)	0.0082	0.0264
18	0.0403	(1.024)	0.0128	0.0418
20	0.0320	(0.812)	0.0204	0.0666
22	0.0254	(0.644)	0.0322	0.1060
24	0.0201	(0.511)	0.0514	0.1680

Note: The typical values for resistance per length are doubled as the circuit is a direct current loop.

Electrical conduit (Figure 3-6)

Use electrical conduit in accordance with local wiring codes. The electronics housing has two threaded holes for electrical conduit connections. The configuration in figure 3-6 prevents moisture getting into the housing. If conduit is not used, use the correct cable gland/plugs to seal the housing.




Figure 3-6 Electrical conduit configuration

Electrical connections (Figure 3-7)

The transmitter is a 2-wire loop powered device. The marks +ve and -ve identify the polarity of the connection terminals.

A label in the transmitter shows how to use the third terminal to measure the output current from the transmitter. In hazardous areas, do not use this third terminal.




Figure 3-7 Transmitter connections

Because the transmitter circuit is isolated from the housing, one of the signal wires (+ve or -ve) can be earthed (grounded) if necessary.

3.10 System Checks

Leak test

Before the system is filled and/or commissioned, do a leak test with compressed air (or other inert compressed gas) or water. The minimum test pressure must be equal to the normal operating pressure. The maximum pressure is the MWP.

- Apply pressure at a convenient point on the system.
- Apply an applicable leak test solution to the impulse piping, valves, transmitter connections and joints.
- Look for a continuous stream of bubbles.
- Bleed the system.
- Do all the necessary repairs, and test the system again.
- Return the system to the original configuration.

Transmitter test

Connect the necessary instruments to monitor the pressure signal . If necessary, connect a milliammeter to measure the output from the transmitter.

- Apply power to the transmitter.
- Apply the applicable pressure.
- Monitor the pressure signal.

Refer to the 'Operation' section for the procedures to set up and operate the transmitter.

4 OPERATION

Note: If the equipment is certified for use in a hazardous area, refer to the publication "Calibration data and instructions" for additional data.

4.1 General

CAUTION: DO NOT over-pressurize the system.

Pressure ranges

The transmitter label shows the factory calibrated range and the maximum working pressure (MWP).

Start up procedure

When power is supplied to the transmitter, the output is set to the applicable alarm level (Refer to table 4-1). When the start up sequence is complete, the output changes to give the applicable process value.

During start up, the display (if applicable) shows these items:

1. the LCD test: -8.8.8.8.8
2. the software version (example: 1.00.00)

When the start up sequence is complete, the display shows a value proportional to the measured pressure.

Alarm/Error conditions

Refer to the 'Maintenance' section.

RTX 1000A Series User Manual

4.2 Manual Configuration Facilities (Figure 4-1)

The manual configuration facilities (DIP switches and push buttons) are in the electronics module. To get access to the electronics module, remove the end-cap (with access to the electronics module).




Figure 4-1 Location of DIP switches and push buttons

Table 4-1 DIP switch operation

DIP Switch	Function	Set ON	Set OFF
1	Write Protection	To prevent accidental changes to the EEPROM values.	1) To change the range values (zero and/or span). 2) To set up the display - if applicable.
2	Alarm level	To use the high NAMUR alarm (> 21 mA) when there is a transmitter failure.	To use the low NAMUR alarm (< 3.6 mA) when there is a transmitter failure.
3	Damping	To use the ON_Damping factor. Default = 1 s	To use the OFF_Damping factor. Default = 0.1 s
4	Push button operation	To change the range values (zero and/or span).	To set up the display - if applicable.

Calibration adjustment - Lower range value (LRV)

1. Set DIP switch 1 to OFF and DIP switch 4 to ON (Refer to table 4-1).
2. Supply the necessary pressure and let the pressure become stable.
3. Press the S and Z buttons together.
The optional display shows CAL, then a pressure value that flashes.
4. *Option - Return to normal operation without change:*
Wait 25 seconds or press S and Z together.
Option - Save the new LRV:
Press the Z button. The signal output is set to 4 mA and the optional display shows a pressure value that does not flash.
Note: If the value is not in the applicable range, the value is ignored and the optional display shows 'Error'.
5. Set DIP switch 1 to ON (Refer to table 4-1).

Calibration adjustment - Upper range value (URV)

To minimise measurement errors, do the LRV before the URV, then follow these steps:

- 1 - 3 As above.
4. *Option - Return to normal operation without change:*
Wait 25 seconds or press S and Z together.
Option - Save the new URV:
Press the S button. The signal output is set to 20 mA and the optional display shows a pressure value that does not flash.
Note: If the value is not in the applicable range, the value is ignored and the optional display shows 'Error'.
5. Set DIP switch 1 to ON (Refer to table 4-1).

RTX 1000A Series User Manual

5 MAINTENANCE

Note: If the equipment is certified for use in a hazardous area, refer to the publication "Calibration data and instructions" for additional data.

5.1 General

The transmitter contains no moving parts and requires a minimum of maintenance.

Visual inspection

- Inspect the transmitter for damage and corrosion. Any damage to the transmitter must be assessed. If the housing is no longer sealed against water and/or dust, the transmitter must be replaced.

Cleaning

- Clean the transmitter case with a damp lint-free cloth and mild detergent.
- Corrosion must be removed and the area of corrosion cleaned and, if necessary, neutralized.
- If the product has been in contact with hazardous or toxic materials, obey all the applicable COSHH references and precautions when handling.

RTX 1000A Series User Manual

5.2 Fault Finding (Figure 5-1)

If the measured pressure goes above URV or goes below LRV, the output signal will saturate at the following values:




Figure 5-1 Fault finding from the output signal

Failure alarm indications (Table 5-1)

If there is a specified fault condition, the transmitter output changes to the specified NAMUR alarm level. The alarm level is set by the position of DIP switch 2 (refer to table 4-1).

If applicable, the optional display shows an alarm code to help identify the fault (AL xx). Table 5-1 shows some of the codes. If there are several fault conditions, the alarm code is the hexadecimal sum of all the applicable codes.

Table 5-1 LCD alarm codes and error messages

Code	Possible cause	To correct the error
AL 02	Too much positive or negative pressure.	Supply pressure in the specified limits for the device.
	DPM error	Power off, wait 25 seconds, then power on again.
AL 04	DPM data not received	Power off, wait 25 seconds, then power on again.
	LCD adjustment has loosened the DPM cable connection on the PCB.	Examine the DPM cable connection (Figure 3-1).
AL 08	LCD adjustment has loosened the DPM cable connection on the PCB.	Examine the DPM cable connection (Figure 3-1).
Error	Configuration error. The range is not in the specified limits for the device.	Refer to section 2 for the specified range limits.
Prot	Configuration error. DIP switch 1 set to ON (Write protect).	Set DIP switch 1 to OFF, then follow the procedures in Section 4.

If you cannot identify the code or the fault condition does not change, contact an approved service agent.

Over/under range

If the measured pressure goes above or below the set range of the transmitter, the electronics module causes the transmitter output to change.

When the measured pressure is under range, the transmitter output continues below the 4.0 mA level until it reaches 3.8 mA (figure 5-1). When the measured pressure is over range, the transmitter output continues above the 20.0 mA level until it reaches 20.5 mA (figure 5-1).

If applicable, the optional display will also show a flashing pressure value.

5.3 Returned Goods Procedure

If the transmitter becomes unserviceable or requires calibration, it can be returned to the GE Druck Service Department.

Please contact our Service Department, either by 'phone or fax, to obtain a Returned Goods Authorization (RGA) number. You will need to give the following information:

- Product (i.e. RTX 1000A)
- Pressure range
- Serial number
- Details of defect/work to be undertaken
- Calibration traceability requirements
- Operating conditions

Safety Precautions

You must also tell us if the product has been in contact with hazardous or toxic materials. Please supply the applicable COSHH references and precautions to be taken when handling.

Important Notice

Service or calibration by unauthorized sources will affect the warranty and may not guarantee further performance. If the equipment has "Hazardous area" approval, the approval will also be invalid.

RTX 1000A Series User Manual
