



Emulex Driver for FreeBSD User Manual

Copyright, Trademarks, and Disclaimer

EMULEX CONFIDENTIAL. Copyright © 2012 Emulex. All rights reserved worldwide. Unpublished work. No part of this document may be reproduced by any means or translated to any electronic medium without (a) the prior written consent of Emulex, and (b) the preservation of this notice on all copies and partial copies. Copying, access, use or distribution requires an applicable written agreement approved by Emulex.

Information furnished by Emulex is believed to be accurate and reliable. However, no responsibility is assumed by Emulex for its use; or for any infringements of patents or other rights of third parties which may result from its use. No license is granted by implication or otherwise under any patent, copyright, trade secret or related rights of Emulex.

Emulex, the Emulex logo, AutoPilot Installer, AutoPilot Manager, BlockGuard, Connectivity Continuum, Convergenomics, Emulex Connect, Emulex Secure, EZPilot, FibreSpy, HBAnyware, InSpeed, LightPulse, MultiPulse, OneCommand, OneConnect, One Network. One Company., SBOD, SLI, and VEngine are trademarks of Emulex. All other brand or product names referenced herein are trademarks or registered trademarks of their respective companies or organizations.

Emulex provides this documentation “as is” without any warranty of any kind, either expressed or implied, including but not limited to the implied warranties of merchantability or fitness for a particular purpose. Emulex may make improvements and changes to the product described in this manual at any time and without any notice. Emulex assumes no responsibility for its use, nor for any infringements of patents or other rights of third parties that may result. Periodic changes are made to information contained herein; although these changes will be incorporated into new editions of this documentation, Emulex disclaims any undertaking to give notice of such changes.

Emulex, 3333 Susan Street
Costa Mesa, CA 92626

Supported Driver Versions

The following table lists the Emulex-supported Ethernet drivers that are applicable in this manual.

A checkmark “✓” indicates the type of driver distribution that is supported.

Driver Version	Driver Distribution	Operating System Version
	Out-of-Box	
Ethernet Drivers		
4.1.377.0	✓	FreeBSD 8.1
4.1.377.0	✓	FreeBSD 8.2

Table of Contents

Supported Driver Versions	3
1. Introduction	5
Overview	5
Supported Versions and Adapters	5
Features	5
Known Issues.....	5
2. Installing and Uninstalling	6
General Installation Requirements	6
Installing the FreeBSD Driver Kit	6
Uninstalling the FreeBSD Driver Kit	6
UpdatingUpdating the FreeBSD Driver Kit	7
Loading and Unloading the Driver	7
3. Configuration	8
NIC Driver Configuration	8
Viewing Device Driver Statistics	9
Updating the Firmware	10

1. Introduction

Overview

This *FreeBSD NIC Driver User Manual* provides installing, uninstalling, updating, and configuring procedures for an Emulex-supported FreeBSD NIC driver release.

Supported Versions and Adapters

This manual is applicable to several versions of FreeBSD NIC drivers, operating systems, firmware, and adapters.

- For a list of supported Emulex drivers for FreeBSD and their associated compatible operations systems, see “Supported Driver Versions” on page 3.
- For supported firmware versions and their latest release, see the “Downloads” page on the Emulex website for the specific adapter.

The FreeBSD operating system supports the Emulex OCe11102 converged network adapter (CNA). The driver and CNA support:

- PCI-e bus standard
- Statistics - Ethernet statistics provided for the number of packets received and sent, as well as, errors encountered.
- Jumbo Packets - Packets greater than 1500 bytes.
- VLAN - Virtual Local Area Network.
- Multicast - Packets sent from a source to a group of destinations.
- RSS - load balancing on Rx traffic across multiple Rx queues.
- TSO/LSO (TCP Segmentation Offload/Large Segment Offload) - off loads Tx traffic to hardware to improve performance.
- CSO - Check-sum computation offload to hardware.
- Bonding - Ethernet bonding across multiple ports for load balancing and fail-over.
- PXE - Preboot eXecution Environment for network boot.
- MSI-x - Message Signal Interrupts
- Promiscuous mode - Configuring an Ethernet interface to accept traffic from any destination.
- Debugging capability

Known Issues

Known issues are defined in the *Emulex Drivers for FreeBSD Release Notes*, which are available on the driver’s “Downloads” page on the Emulex website.

2. Installing and Uninstalling

General Installation Requirements

Prior to driver installation, follow these requirements:

- Install a supported Emulex OneConnect CNA adapter in the system. Refer to the adapter's installation manual for specific hardware installation instructions.
- Install the FreeBSD NIC driver on a dual-core (or better) server with AMD-64 architecture and MSI-X support.
- Use a supported operating system:
 - FreeBSD 8.1
 - FreeBSD 8.2

Installing the FreeBSD Driver Kit

To install the FreeBSD driver kit:

1. Download the appropriate driver kit from the Emulex website.
2. Log on as "root" and type:

```
pkg_add oce-<VERSION>-<ARCH>.tbz
```

For example:

```
pkg_add oce-4.1.86.0-amd64.tbz
```
3. Type:

```
echo 'oce_load="YES"' >> /boot/loader.conf
```
4. Reboot the system.

Uninstalling the FreeBSD Driver Kit

To uninstall the FreeBSD driver kit:

1. Log on as "root".
2. Type:

```
pkg_delete oce-<VERSION>-<ARCH>
```

For example,

```
pkg_delete oce-4.1.86.0-amd64
```
3. Type:

```
remove 'oce_load="YES"' entry in /boot/loader.conf
```
4. Reboot the system.

Updating the FreeBSD Driver Kit

To update the FreeBSD driver:

1. Type:

```
pkg_update oce-<VERSION>-<ARCH>.tbz
```

For example,

```
pkg_update oce-4.1.86.0-amd64.tbz
```

2. Reboot the system.

Loading and Unloading the Driver

To load the kernel module, type:

```
kldload oce.ko
```

To unload the kernel module, type:

```
kldunload oce.ko
```

3. Configuration

NIC Driver Configuration

Kernel Module Parameters

Table 3-1 Kernel Module Parameters

Parameter	Description
disable_msix	Default: 0 Allowed values: 1 kenv name: hw.oce.disable_msix sysctl name: not applicable "0" allows MSIx interrupts to be used, if available. "1" causes the INTx interrupt to be used even if MSIx is available. This parameter is not available via sysctl.
max_rsp_handled	Default: 512 Allowed values: 1-1024 kenv name: hw.oce.max_rsp_handled sysctl name: dev.oceX.max_rsp_handled max_rsp_handled indicates the maximum number of received frames that are processed during a single receive frame interrupt.
enable_csum	Default: 1 Allowed values: 1 kenv name: hw.oce.enable_csum sysctl name: not applicable "1" reveals to the network layers above the driver that the adapter is capable of performing TCP, UDP and IP Checksum offload. "0" disables this parameter. This parameter is not available via sysctl.

Table 3-1 Kernal Module Parameters

Parameter	Description																																								
trace_enable	<p>Default: 0x00000001</p> <p>Allowed values: 0-0xffffffff</p> <p>kenv name: hw.oce.trace_enable</p> <p>sysctl name: dev.oceX.trace_enable</p> <p>Each bit corresponds to a trace flag. Each trace flag turns on a separate set of trace messages. Bit 0 corresponds to ERROR, so it should always be enabled to show unexpected errors. Trace messages are displayed on the console and the /var/log/messages file. The following are different sets of trace messages:</p> <table> <tbody> <tr><td>OCE_TRACE_ERROR</td><td>0x00000001</td></tr> <tr><td>OCE_TRACE_ENTRY_EXIT</td><td>0x00000002</td></tr> <tr><td>OCE_TRACE_IOCTL</td><td>0x00000004</td></tr> <tr><td>OCE_TRACE_MAILBOX</td><td>0x00000008</td></tr> <tr><td>OCE_TRACE_INIT</td><td>0x00000010</td></tr> <tr><td>OCE_TRACE_INTR</td><td>0x00000020</td></tr> <tr><td>OCE_TRACE_FAST_INTR</td><td>0x00000040</td></tr> <tr><td>OCE_TRACE_TX</td><td>0x00000080</td></tr> <tr><td>OCE_TRACE_RX</td><td>0x00000100</td></tr> <tr><td>OCE_TRACE_PCI</td><td>0x00000200</td></tr> <tr><td>OCE_TRACE_UNHANDLED</td><td>0x00000400</td></tr> <tr><td>OCE_TRACE_IF</td><td>0x00000800</td></tr> <tr><td>OCE_TRACE_RING_BUF</td><td>0x00001000</td></tr> <tr><td>OCE_TRACE_FUNC</td><td>0x00002000</td></tr> <tr><td>OCE_TRACE_STRUCT</td><td>0x00004000</td></tr> <tr><td>OCE_TRACE_STATS</td><td>0x00008000</td></tr> <tr><td>OCE_TRACE_HEXDUMPS</td><td>0x00010000</td></tr> <tr><td>OCE_TRACE_FLAGS</td><td>0x00020000</td></tr> <tr><td>OCE_TRACE_NONE</td><td>0x00000000</td></tr> <tr><td>OCE_TRACE_ALL</td><td>0xFFFFFFFF</td></tr> </tbody> </table>	OCE_TRACE_ERROR	0x00000001	OCE_TRACE_ENTRY_EXIT	0x00000002	OCE_TRACE_IOCTL	0x00000004	OCE_TRACE_MAILBOX	0x00000008	OCE_TRACE_INIT	0x00000010	OCE_TRACE_INTR	0x00000020	OCE_TRACE_FAST_INTR	0x00000040	OCE_TRACE_TX	0x00000080	OCE_TRACE_RX	0x00000100	OCE_TRACE_PCI	0x00000200	OCE_TRACE_UNHANDLED	0x00000400	OCE_TRACE_IF	0x00000800	OCE_TRACE_RING_BUF	0x00001000	OCE_TRACE_FUNC	0x00002000	OCE_TRACE_STRUCT	0x00004000	OCE_TRACE_STATS	0x00008000	OCE_TRACE_HEXDUMPS	0x00010000	OCE_TRACE_FLAGS	0x00020000	OCE_TRACE_NONE	0x00000000	OCE_TRACE_ALL	0xFFFFFFFF
OCE_TRACE_ERROR	0x00000001																																								
OCE_TRACE_ENTRY_EXIT	0x00000002																																								
OCE_TRACE_IOCTL	0x00000004																																								
OCE_TRACE_MAILBOX	0x00000008																																								
OCE_TRACE_INIT	0x00000010																																								
OCE_TRACE_INTR	0x00000020																																								
OCE_TRACE_FAST_INTR	0x00000040																																								
OCE_TRACE_TX	0x00000080																																								
OCE_TRACE_RX	0x00000100																																								
OCE_TRACE_PCI	0x00000200																																								
OCE_TRACE_UNHANDLED	0x00000400																																								
OCE_TRACE_IF	0x00000800																																								
OCE_TRACE_RING_BUF	0x00001000																																								
OCE_TRACE_FUNC	0x00002000																																								
OCE_TRACE_STRUCT	0x00004000																																								
OCE_TRACE_STATS	0x00008000																																								
OCE_TRACE_HEXDUMPS	0x00010000																																								
OCE_TRACE_FLAGS	0x00020000																																								
OCE_TRACE_NONE	0x00000000																																								
OCE_TRACE_ALL	0xFFFFFFFF																																								

Viewing Device Driver Statistics

To view device driver statistics, type:

```
sysctl -a | grep oce
```

Updating the Firmware

To update the firmware:

1. Copy the code below to the makefile.

```
.KMOD=elxflash  
FIRMWS=imagename.ufi:elxflash  
.include <bsd.kmod.mk>
```
2. Replace “imagename” in the copied code with the actual firmware file name. The format is <filename>.ufi.
3. Copy this makefile and the firmware file to a temporary directory.
4. Execute a “make” command in the directory. This generates an elxflash.ko file.
5. Copy the elxflash.ko file to /lib/modules.
6. Execute the command:

```
sysctl dev.oce.<if_id>.fw_upgrade=elxflash
```
7. Reboot the machine.

One of the following errors codes will be displayed if the firmware update failed.

- Invalid BE3 firmware image
- Invalid Cookie. Firmware image corrupted?
- cmd to write to flash rom failed.