

■ Next Generation Critical Cooling  
for Room and Row

## Liebert PEX

*Efficiency And Reliability For High Availability Cooling*



## Chilled Water Models User Manual



# Liebert.PEX Chilled Water Series Air Conditioner

## User Manual

Version            V1.1  
Revision date    May 6, 2010  
BOM                31011830

---

Emerson Network Power provides customers with technical support. Users may contact the nearest Emerson local sales office or service center.

Copyright © 2010 by Emerson Network Power Co., Ltd.

All rights reserved. The contents in this document are subject to change without notice.

Emerson Network Power Co., Ltd.

Address: No.1 Kefa Rd., Science & Industry Park, Nanshan District 518057, Shenzhen China

Homepage: [www.emersonnetworkpower.com.cn](http://www.emersonnetworkpower.com.cn)

E-mail: [support@emersonnetwork.com.cn](mailto:support@emersonnetwork.com.cn)

### **ATTENTION - AUSTRALIA & NEW ZEALAND CUSTOMERS**

Please note that the following features apply to PEX units marketed and sold into Australia and New Zealand. These features differ to the content in this user manual and should be considered when specifying, installing, commissioning or maintaining the equipment. Contact your local Emerson sales office for further information or clarification.

- \* 2 way chilled water motorised valves
- \* EC fan option uses 3.1kW motor for all models



# Contents

Chapter 1 Overview.....	1
1.1 Model Description.....	1
1.2 Main Components.....	1
1.3 Remote Monitoring Software .....	2
1.4 Environmental Requirements .....	2
1.4.1 Operation Environment.....	2
1.4.2 Storage Environment .....	3
Chapter 2 Mechanical Installation .....	4
2.1 Installation Preparation .....	4
2.1.1 Transportation And Movement.....	4
2.1.2 Unpacking .....	4
2.1.3 Inspection.....	5
2.1.4 Installation Notes.....	6
2.2 System Installation Arrangement .....	6
2.2.1 General Arrangement.....	6
2.2.2 Mechanical Parameters.....	7
2.3 Installing Chilled Water AC Unit .....	14
2.3.1 Installation Requirement.....	14
2.3.2 Installation Procedures .....	15
2.4 Piping.....	19
2.5 Removing Transport Fastener And Vibration Absorber.....	21
2.6 Adjusting Water Level Regulator.....	24
2.7 Installation Inspection .....	25
Chapter 3 Electric Installation.....	26
3.1 Work Introduction And Installation Notes .....	26
3.2 Wiring Of Chilled Water AC Unit.....	26
3.2.1 Locating Electrical Interfaces.....	26
3.2.2 Connecting Power Cable Of Chilled Water AC Unit.....	27
3.2.3 Connecting Control Cables .....	28
3.3 Installation Inspection .....	29
Chapter 4 System Start-Up Commissioning.....	30
4.1 Locating MCBs.....	30
4.2 Start-Up Commissioning .....	32
4.2.1 Preparation Before Commissioning.....	32
4.2.2 Commissioning Procedures .....	32
4.2.3 Inspection After Commissioning .....	33
Chapter 5 iCOM Controller .....	34
5.1 LCD .....	34
5.2 Button And Indicator Panel.....	34
5.3 Structure Chart Of Control Menu.....	36

5.4 Startup Interface .....	36
5.5 Main Interface.....	36
5.6 USER MENUS .....	37
5.6.1 PASSWORD .....	37
5.6.2 SETPOINTS .....	37
5.6.3 EVENT LOG.....	37
5.6.4 GRAPHICS.....	39
5.6.5 SET ALARMS .....	39
5.6.6 SENSOR DATA .....	40
5.6.7 DISPLAY SETUP .....	41
5.6.8 TOTAL RUN HRS .....	42
5.6.9 SLEEP MODE .....	43
5.6.10 SERVICE INFO .....	43
5.6.11 ACTIVE ALARMS .....	43
5.7 SERVICE MENUS .....	43
5.7.1 PASSWORD LEVEL .....	44
5.7.2 SETPOINTS .....	44
5.7.3 STANDBY .....	45
5.7.4 WELLNESS.....	45
5.7.5 DIAGNOSTICS.....	48
5.7.6 SET ALARMS .....	50
5.7.7 CALIBRATION.....	52
5.7.8 NETWORK SETUP .....	52
5.7.9 OPTIONS SETUP .....	53
5.7.10 SERVICE INFO .....	54
5.8 ADVANCED MENUS.....	54
5.8.1 PASSWORD LEVEL .....	54
5.8.2 FACTORY SETUP .....	55
5.9 MBV Settings.....	59
5.10 EVENT NAME AND DEFINITION .....	60
Chapter 6 Application Of INTELLISLOT .....	64
6.1 Introduction Of Host Communication Card.....	64
6.2 Installing Host Communication Card .....	65
6.3 Commissioning Host Communication Component .....	65
6.3.1 Setting HyperTerminal .....	66
6.3.2 Setting 485 Communication Card .....	67
6.3.3 Setting TCP/IP Communication Card.....	68
6.3.4 Setting SNMP Parameters Of TCP/IP Communication Card .....	70
6.4 Host Communication Networking Diagram .....	73
Chapter 7 System Operation And Maintenance .....	74
7.1 System Diagnosis Test.....	74
7.1.1 Self-diagnosis Function.....	74
7.1.2 Electric Control Part.....	74
7.2 Filter .....	75
7.3 Fan Kit.....	76

7.3.1 Fan Bearing And Blades .....	76
7.3.2 Belt.....	76
7.3.3 Motor.....	76
7.4 Infrared Humidifier.....	76
7.5 Electrical Heater.....	78
7.6 Water Flow Control Valve.....	79
Chapter 8 Failure Diagnosis And Troubleshooting.....	80
Appendix 1 The Structure Chart Of Electric Control Box .....	83
Appendix 2 Circuit Diagram .....	86
Appendix 3 The Structure Chart Of Micro-processing Controller Menu .....	87



# Chapter 1 Overview

The Liebert.PEX chilled water air conditioner (chilled water AC for short) is a medium-large sized precision environment control system configured with electrical heater and humidifier, suitable for the environment control of the equipment room or computer room. It uses the chilled water supplied by the cooling water units. It aims to provide a sound operation environment for precision equipment, such as sensitive equipment, industry processing equipment, communication equipment and computers.

This chapter introduces the model description, main components and environmental requirements of chilled water AC.

## 1.1 Model Description

The model description of the chilled water AC is shown in Figure 1-1.




Figure 1-1 Model description

## 1.2 Main Components

The chilled water AC unit includes heat exchanger, infrared humidifier, fan, electrical heater, water flow control valve and micro-processing controller.

### Heat exchanger

Use finned-tube heat exchanger with high heat emission efficiency. The model-specific distributions can ensure the even distribution of chilled water in each loop and greatly improve the efficiency of the heat exchanger, as well as minimize the water resistance of heat exchanging coil.

**Infrared humidifier**

Configure with infrared humidifier which is easy for teardown, cleaning and maintenance. It is adjustable to a wide range of water qualities, with fast startup and high humidifying efficiency.

**Fan**

Use forward centrifugal fan with high efficiency and reliability, large airflow and long blowing distance. With the belt transmission mechanism, it is easy for maintenance. The user can also select electronically commutated (EC for short) fan with backward blades. EC fan is energy-saving and space-saving with high efficiency and low noise. It is also subject to stepless speed regulation. For the structure of EC fan downflow unit, the solution of air supply by putting fan unit under floor is considered, which can significantly improve the efficiency of air supply.

**Electrical heater**

Use screw finned U type stainless steel electrical heating tube, with fast heating speed and evenly distributed heat volume.

**Water flow control valve**

The water flow control valve can adjust the chilled water flow quantity according to the cooling requirement. It is connected to the system pipes with live joints, easy for field installation and maintenance, thus reducing the project installation cost.

**Micro-processing controller**

The micro-processing controller of the chilled water AC uses an LCD screen with blue backlight and 128 × 64 dots. The user interface operation is simple. The multi-level password protection can effectively prevent illegal operation. It also features power failure auto-restoration and high / low voltage protection function. The operation time of components is available through the menus. The expert-level fault diagnosis system can display the current fault information automatically, facilitating the maintenance. It can store up to 400 records of historical events. The panel of micro-processing controller is shown in Figure 1-2.



Figure 1-2 Micro-processing controller panel

### 1.3 Remote Monitoring Software

The chilled water AC can communicate with the host computer through a configured communication port to receive the control of the host software.

### 1.4 Environmental Requirements

#### 1.4.1 Operation Environment

See Table 1-1 for details.

Table 1-1 Operation environment requirement

Item	Requirement
Operation range	Indoor temperature: 4°C ~ 40°C Chilled water supply temperature: 5°C ~ 13°C
Altitude	< 1000m. Above that, derating is required
Operation voltage range	400V (-10% ~ +10%), three-phase AC, 50Hz

### 1.4.2 Storage Environment

See Table 1-2 for details.

*Table 1-2 Storage environment requirement*

Item	Requirement
Storage environment	Indoor, clean, no dust
Ambient humidity	5%RH ~ 85%RH (non-condensing)
Ambient temperature	-20°C ~ +54°C
Storage time	Total transportation and storage time should not exceed 6 months. Otherwise, the performance needs to be re-evaluated

## Chapter 2 Mechanical Installation

This chapter introduces the mechanical installation of the chilled water AC, including the transportation and movement, unpacking, inspection, installation notes and installation procedures.

### 2.1 Installation Preparation

#### 2.1.1 Transportation And Movement

Railroad transportation and shipping are the recommended means of transportation. If truck transportation is unavoidable, choose roads that are less bumpy in order to protect the equipment.

The chilled water AC is heavy (see Table 2-1 for the weight parameters). It is recommended to use a mechanical handbarrow such as an electric forklift when unpacking and moving the equipment to the place closest to the installation site. Insert the tines of the forklift below the pallet, as shown in Figure 2-1. Align the tines with the center of gravity to prevent the unit from falling over.



Figure 2-1 Fork direction

Keep the obliquity within  $75^{\circ} \sim 105^{\circ}$  during the movement, as shown in Figure 2-2. Extreme incline is not allowed.




Figure 2-2 Moving obliquity

#### 2.1.2 Unpacking

Move the equipment to the place closest to the final installation site and then unpack it.

Follow the procedures below to unpack the unit:

1. Removing the side boards and top cover

The chilled water AC uses international packaging. You can use a hammer or straight screwdriver to straighten the hook, as shown in Figure 2-3.



Figure 2-3 Straightening the hook

At first, straighten all the hooks that fix side board I, and remove side board I. Then straighten all the hooks that fix side board II, and remove side board II. At last remove top cover III, as shown in Figure 2-4.




Figure 2-4 Removing side boards and top cover

## 2. Removing the pallet

The chilled water AC is fixed onto the pallet with M10 × 70 screws, as shown in Figure 2-5. You can use an M10 open-end spanner, a ratchet spanner or a sleeve to remove the fixing screws.




Figure 2-5 Fixing screw position of pallet

### 2.1.3 Inspection

After receiving the product, you should check it against the packing list. If any parts are found missing, distorted or damaged, please report to the carrier immediately. If any covert defects are found, please report to the carrier and the local office of Emerson Network Power Co., Ltd.

### 2.1.4 Installation Notes

To realize the designed performance and maximum product life, correct installation is vital. This section should be used in conjunction with local industry standards for mechanical and electrical installations. Note the following items:

1. The chilled water AC is designed for integrated floor installation. It should be installed on the floor of the equipment room or computer room.
2. Before the installation, make sure that the installation environment meets the requirements (see 1.4 *Environmental Requirements*) and the building should be transformed to accommodate the construction work of piping, wiring and ventilation ducts.
3. Follow the design drawings strictly when installing the equipment, and reserve the space for maintenance. The engineering dimensions drawings provided by the manufacturer can serve as a reference.

## 2.2 System Installation Arrangement

### 2.2.1 General Arrangement

The general arrangement of the chilled water AC is shown in Figure 2-6.




Figure 2-6 General arrangement diagram

#### Note

1. ————— : Factory piping.
2. - - - - - : Field piping (by technicians).
3. \*: Components are not supplied by Emerson but are recommended for proper circuit operation and maintenance.
4. After the project installation, exhaust the AC unit before filling water to ensure the efficiency of the heat exchanger.
5. In winter, the AC unit in northern area does not operate for a long term; you must empty the water in AC unit to protect the heat exchanger from frost cracking.

## 2.2.2 Mechanical Parameters

### Dimensions

The dimensions of the chilled water AC are shown in Figure 2-7, Figure 2-8, Figure 2-9 and Table 2-1.




Figure 2-7 One-bay series (unit: mm)




Figure 2-8 Two-bay series (unit: mm)




Figure 2-9 Three-bay series (unit: mm)

Table 2-1 Dimension

Model	Dimensions (W × D × H) (mm)	Net weight (kg)
P1020	853 × 874 × 1970	≤ 315
P1030	853 × 874 × 1970	≤ 315
P1040	853 × 874 × 1970	≤ 338
P1050	853 × 874 × 1970	≤ 343
P2050	1704 × 874 × 1970	≤ 476
P2070	1704 × 874 × 1970	≤ 476
P2090	1704 × 874 × 1970	≤ 505
P2100	1704 × 874 × 1970	≤ 530
P3110	2553 × 874 × 1970	≤ 656

Model	Dimensions (W × D × H) (mm)	Net weight (kg)
P3140	2553 × 874 × 1970	≤ 706
P3150	2553 × 874 × 1970	≤ 715

**Plenum dimensions**

You can select the air supply plenum with grids for the upflow system. The appearance of the plenum is shown in Figure 2-10, Figure 2-11 and Figure 2-12. The detailed dimensions are listed in Table 2-2.




Figure 2-10 One-bay plenum




Figure 2-11 Two-bay plenum




Figure 2-12 Three-bay plenum

Table 2-2 Dimensions of plenum (unit: mm)


Type	A	B	C
One-bay	867	853	400 (600, optional)
Two-bay	867	1704	400 (600, optional)
Three-bay	867	2553	400 (600, optional)

**Note**


If the height of the plenum selected for air conditioner unit exceeds 600mm, consult the factory for non-standard production.

**Base cut-out location dimensions**


The base cut-out position dimensions of the chilled water AC are shown in Figure 2-13, Figure 2-14 and Figure 2-15.



One-bay series




Two-bay series




Three-bay series


Figure 2-13 Base cut-out locations of the upflow series (unit: mm)



One-bay series



Two-bay series



Three-bay series

Figure 2-14 Base cut-out locations of the forward fan downflow series (unit: mm)




Figure 2-15 Base cut-out locations of the backward fan downflow series (unit: mm)

### Side panel cut-out locations

If piping and wiring from the base are difficult, connection from side panel can be selected. The locations and dimensions of knock-out holes are shown in Figure 2-16. You can select the in and out holes according to the factual needs, but must confirm that any two cables of pipe, power cable and signal cable cannot use the same hole.




Figure 2-16 Knock-out holes of side panel (unit: mm)

## 2.3 Installing Chilled Water AC Unit

### 2.3.1 Installation Requirement

#### Equipment room requirement

The requirements of equipment room are as follows:

1. Damp proof and heat preservation must be done to make sure that the system can operate normally.
2. The equipment room should have good heat insulation and sealed damp proof layer. The damp proof layer of the ceiling and walls must use polyethylene film, and the coating of the concrete wall and the floor must be damp proof.
3. Prevent the outdoor air from entering the equipment room, because the outdoor air that enters the equipment room may increase the load of heating, cooling, humidifying and dehumidification of the system. It is recommended that the inhalation of outdoor air be kept below 5% of the total indoor airflow.
4. All the doors and windows should be closed and the seams should be as narrow as possible.

#### Installation space requirement

#### Note

The chilled water AC will generate condensed water, and water leakage may damage the precision equipment nearby. So do not install the system in the vicinity of any precision equipment, and the installation site must provide drain pipes.

1. To ensure normal operation, the installation space for the indoor unit shall be capacious enough.

2. Too small space for the indoor unit will baffle the airflow, shorten the cooling cycle; the air supply and air exhaust may mix, and the decibel may rise.
3. Do not place the indoor unit in a concave or at the end of a strip area.
4. Do not huddle multiple indoor units, lest there should be mixed airflow, unbalanced load and competitive operation.
5. For the convenience of daily maintenance, do not install other equipment (such as smoke detector) above the cabinet.
6. Backward fan downflow unit: because the fan needs to sink during the operation, so the floor must be higher than 400mm.

Figure 2-17 shows the installation place of the indoor unit.




Figure 2-17 Installation place of indoor unit (unit: mm)

#### Maintenance space requirement

Leave more than 600mm of maintenance space in the front and on both sides of the chilled water AC unit, as shown in Figure 2-17.

### 2.3.2 Installation Procedures

The installation procedures of indoor unit are as follows:

1. Make the mounting base according to the dimensions in Figure 2-18, Figure 2-19 and Figure 2-20 and the requirements in Table 2-3. You can make it yourself or contact Emerson Network Power Co., Ltd. for non-standard production.




Figure 2-18 Mounting base of one-bay series (unit: mm)




Figure 2-19 Mounting base of two-bay series (unit: mm)




Figure 2-20 Mounting base of three-bay series (unit: mm)

Table 2-3 Specifications of indoor unit mounting base

Item	Specification	Remark	
Steel plate	100mm × 100mm × (5 ~ 6.5)mm	-	
Angle steel	40mm × 40mm × 3mm	-	
Rubber cushion	Top	Thickness: 3mm ~ 5mm	
	Lateral	Thickness: 2mm ~ 3mm	
	Bottom	Thickness: 10mm ~ 12mm	
Installation hole for expansion bolt	-	Install the bolts according to your requirements	
H	One-bay	H = 200mm (upflow unit) H = 300mm (forward fan downflow unit, according to the floor height) H ≥ 400mm (backward fan downflow unit)	1. The forward downflow unit needs guide plate. 2. Size H here is for reference only, and it shall be determined according to the actual needs. Backward fan downflow unit: because the fan needs to sink during the operation, size H must be larger than 400mm
	Two-bay		
	Three-bay		
<b>Note:</b> The external side boards of the unit cannot bear weight. Take this into consideration while selecting angle steels and fixing holes			

2. Lay a layer of rubber cushion on the top, lateral of mounting base and on the bottom of the steel plate respectively. See Figure 2-18, Figure 2-19 and Figure 2-20 for their positions and see Table 2-3 for the thickness.
3. Determine the installation position. Fix the mounting base onto the mounting base according to the site conditions and your requirement.
4. Fix the AC unit onto the mounting base with nuts, spring washers, flat washers and bolts.
5. Backward fan downflow unit: the fan must sink under floor, the detailed operation procedures are as follows:
  - a. Before placing the unit to the actual installation location, open the rear board and remove the backward fan fixing board, then install the rear board, see Figure 2-21;





Figure 2-21 Removing backward fan fixing board

- b. Place the unit to the actual installation location, and remove backward fan transportation fixing board and pallet, see Figure 2-22;
  - Remove the humidifier water tray drain pipe;
  - Remove the transportation fixing board (7 fixing screws);
  - Remove the pallet (2 fixing screws);


**Note**

When removing the pallet, you must grasp the handle and support the fan so as to prevent the fan from falling.



**Figure 2-22 Removing backward fan transportation fixing board and pallet**

- c. Grasp the handle, make a slow 90° rotation CCW of backward fan, so the fan would sink under pallet, see Figure 2-23;
- d. Install the fan fixing board, and tighten the 5 fixing screws, see Figure 2-23.



**Figure 2-23 Fan sinking under floor**

## 2.4 Piping

The pipes to connect include:

1. Water drain-pipe of the unit.
2. Water inlet pipe of infrared humidifier.
3. Chilled water inlet and outlet pipes.

Connecting the water drain-pipe of the unit

The condensing water of infrared humidifier and evaporator is converged by the cross connector and drains through the drain pipe, as shown in Figure 2-24. The outer diameter (OD) of the pipe is 25mm. If the drain pipe is used by three or more units, the minimal OD of the pipe should be 40mm.

### Note

1. A  $\Phi 25$  hose clamp is delivered as an accessory to connect the drain pipe.
2. Because the humidifier contains boiling water, the plastic pipe must be rated higher than 194°F.
3. When connecting the drain pipe, make sure that the U bend is installed vertically and the 'U' shape is not distorted, so as to ensure that the cooling water can be drained immediately and effectively.




Figure 2-24 Connection of water in and out pipes

**Connecting water inlet pipe of infrared humidifier**

Connect water pipes for the infrared humidifier. To facilitate maintenance, a strainer / non-return isolation valve is fitted to the supply water pipe. The infrared humidifier reserves a copper pipe (OD: 6.35mm) as shown in Figure 2-25. 1/4" copper screw nut is put at the end of the copper pipe. Please connect it with the 1/4" x 1/2" converted copper thread in the attached bag. Connect it with pipes according to the site condition. Make sure the connection is well sealed to prevent leakage. The pipe pressure is 100kPa ~ 700kPa.

Where the main pressure may rise above 700kPa, a pressure reducer should be fitted. Where the pressure falls below 100kPa, a water tank and pump system should be used.

**Note**

Main water supply connections must be made in accordance with local laws and regulations.




Figure 2-25 Infrared humidifier

**Connecting chilled water inlet and outlet pipes**

The chilled water inlet and outlet pipes are connected with the chilled water unit by welding, as shown in Figure 2-26. Inlet and outlet pipes should be welded according to the labels on the unit. Please do not reverse the connection. Chilled water inlet and outlet pipes can be connected through the bottom plate or the side plate. For the pipe entrance, please refer to Figure 2-13, Figure 2-14 and Figure 2-15. The chilled water inlet and outlet pipes should have soft connector at the unit connections. The chilled water inlet pipes should be equipped with the water filter with over 60 meshes to facilitate the clearance of impurities in the pipes. The chilled water inlet and outlet pipes need to be equipped with several isolation valves, which can cut off water sources during maintenance. One of the isolation valves can be a balancing valve. Chilled water system with a balancing valve would be more efficient and more accurate in controlling water distribution. For detailed distribution, please refer to Figure 2-6.

Water pressure should be able to overcome the water pressure drop caused by all the components of water system. Considering the possibility that water pressure drop would increase due to incrustation and impurities resulted from long-time running of the system. Therefore, when choosing the head components

(e.g. pump), we should consider making 20% ~ 25% redundancy. The weight of the water pipes connected with the unit should not be assumed by the unit. The chilled water inlet and outlet pipes must be kept warm. Table 2-4 shows the connecting dimensions of chilled water in and out pipes of various units.




Figure 2-26 Welding figure of chilled water in and out pipes

Table 2-4 OD of chilled water in and out pipes

Model	OD of chilled water in and out pipes (mm)	Model	OD of chilled water in and out pipes (mm)
P1020	32	P2090	42
P1030	32	P2100	42
P1040	32	P3110	54
P1050	32	P3140	54
P2050	42	P3150	54
P2070	42		

## 2.5 Removing Transport Fastener And Vibration Absorber

In order to protect partial components from being damaged and distorted due to bumping, impact and resonance, fasteners and vibration absorbers are mounted at certain locations before delivery. Remove the fasteners and vibration absorbers before installation and commissioning.

### Removing transport binding belt of front door

To protect the front door from moving during transport, tighten the gemel of the front door with binding string. Before putting the unit into operation, you should cut the binding string. Each front door needs two binding strings. See Figure 2-27 for their position.




Figure 2-27 Binding string of front door

### Removing transport fastener of fan components


#### 1. Upflow unit

To minimize the fan operation noise and prolong the belt life, the motor base of the fan is designed with a semi-free self-tension structure. During transportation, to protect the semi-free structure from failing or collapsing due to resonance, the upflow unit is especially fastened with sheet metal connector (left and right symmetrical, one at each side), as shown in Figure 2-28.

You should cut the binding string on the belt and remove the sheet metal connectors on both sides of the motor before the power-on operation. Removing the sheet metal connectors requires the collaboration of two persons, with one holding the motor and the other removing the sheet metal connector.

 **Note**


After opening the front door of unit, you will see a warning label concerning the removal of the sheet metal connector on the sealing panel of the fan. Do remove the sheet metal connector by following the preceding instructions.



**Figure 2-28** Transportation fan unit binding screw and string

## 2. Downflow unit

During transportation, to protect the semi-free structure from falling or collapsing due to resonance, the motor mounting plate is fixed on the bottom plate with connector by bolts, as shown in Figure 2-29. You must remove the two connectors before the power-on operation.



**Figure 2-29** Transportation fan unit binding screw

 **Note**

In any case, never put hands into the triangle gap between the motor installation board and base.

### Removing the transport components of infrared humidifier

In order to protect the infrared humidifier lamp from being damaged during transportation, the transport protection foam should be fitted to the infrared humidifier components. Before operating the unit, check the protection foam, and connect high water-level detection switch cable. If you operate the unit without complying with this, the infrared humidifier cannot operate normally and fire may be caused.

Detailed operation procedures are as follows:

1. Cut off the binding wire, and remove the protection foam fixed under the lamp, as shown in Figure 2-30 and Figure 2-31.



Figure 2-30 Removing protection foam 1




Figure 2-31 Removing protection foam 2

2. Remove the four self-tapping screws in the front cover plate of the infrared humidifier connection box, and then remove the front cover plate, as shown in Figure 2-32.






Figure 2-32 Opening front cover plate of the connection box

3. Lead the detection switch cable of the high water-level through the cable access hole, as shown in Figure 2-30. Then insert the corresponding cable terminals and the HWA cable terminals in the connecting box, as shown in Figure 2-33.



**Figure 2-33** Connecting the corresponding cable terminals of the high water-level detection switch and the HWA cable terminal

4. Close the front cover of the infrared humidifier’s connection box, and tighten the self-tapping screw.
5. The infrared humidifier’s high water-level detection switch floating pole and its body have been tightened with the rubber string in factory, as shown in Figure 2-34. Before operating the unit, remove the rubber string, otherwise the unit cannot detect and alarm the high water-level.




**Figure 2-34** Floating pole of the high water-level sense switch

Remove the rubber string to fix the pipe

To avoid the sheet-metal from damaging the longer copper pipe, the damping foam is used to underlay or clamp the pipe before it leaves the factory. The foam should be removed and cleaned before commissioning.

## 2.6 Adjusting Water Level Regulator

The water level regulator of the infrared humidifier is screwed down completely. Before commissioning, unscrew the water level regulator till its head is 45mm above the water tray bottom, as shown in Figure 2-35.



**Figure 2-35** Adjusting distance from the water tray

## 2.7 Installation Inspection

After the mechanical installation is completed, you should check that:

1. A certain space is left around the unit for maintenance. For details, see *Maintenance space requirement* in **2.3.1 Installation Requirement**;
2. The equipment is installed vertically and the installation fasteners have been fixed;
3. The pipes connecting the indoor unit and outdoor unit have been connected;
4. The condensate pump (if needed) has been installed;
5. The drain pipe has been connected;
6. The water supply pipe for infrared humidifier has been connected;
7. All pipe joints have been fixed;
8. The transport fasteners have been removed;
9. The water level regulator of the infrared humidifier has been unscrewed to the required height;
10. The debris (such as transportation materials, structure materials and tools) inside or around the equipment has been cleaned.

After confirming the preceding points, you can then start the electrical installation.

## Chapter 3 Electric Installation

This chapter introduces the electric installation of the chilled water AC, including the work introduction, installation notes, wiring of the unit and installation inspection.

### 3.1 Work Introduction And Installation Notes

Wires to be connected on-site

1. Unit power cables.
2. Unit input and output control cables.

Installation notes

1. The connection of all power cables, control cables and ground cables must comply with local electrician regulations;
2. See the equipment nameplate for the full load current. The cable sizes should meet the local wiring rules;
3. Mains supply requirement: 380Vac, 50Hz;
4. The electrical installation must be completed by trained personnel;
5. Before the wiring, use a multimeter to measure the power supply voltage and make sure that the power supply has been switched off.

### 3.2 Wiring Of Chilled Water AC Unit

#### 3.2.1 Locating Electrical Interfaces

Opening the front door of the chilled water AC unit can reveal the interfaces of electrical control box, as shown in Figure 3-1, Figure 3-2 and Figure 3-3.




Figure 3-1 Electrical control box interfaces of one-bay series




Figure 3-2 Electrical control box interfaces of two-bay series




Figure 3-3 Electrical control box interfaces of three-bay series

### 3.2.2 Connecting Power Cable Of Chilled Water AC Unit

The power interfaces are located as shown in Figure 3-1, Figure 3-2 and Figure 3-3 and the power interface is amplified as shown in Figure 3-4. Connect terminals L1, L2, L3, N, and PE to their counterparts of external power supply. Fix the input cables to the cable clamp located on the right inner side panel, as shown in Figure 3-5. As for the cable specification, see the unit maximum operation current in Table 3-1.




Figure 3-4 Amplified figure of power interface




Figure 3-5 Cable clamp

**Note**

The cable sizes should meet the local wiring rules.

Table 3-1 Maximum operation current of AC unit

Model	Maximum operation current (A)	Model	Maximum operation current (A)
P1020	13.1	P2090	23.5
P1030	13.1	P2100	23.5
P1040	13.1	P3110	28.2
P1050	13.1	P3140	28.2
P2050	23.5	P3150	28.2
P2070	23.5		

### 3.2.3 Connecting Control Cables

The control interfaces are located as shown in Figure 3-1, Figure 3-2 and Figure 3-3. The control interface is amplified in Figure 3-6. The upper part of the terminal block is connected to the AC unit, while the lower part is used as user control signal interfaces.




Figure 3-6 Wiring of control interfaces

**Note**

Before connecting the control cables, the wiring personnel must take antistatic measures.

You can connect the following monitoring and alarm devices.

#### Remote shutdown (RSD)

Terminals 37 and 38 can be connected to the remote shutdown switch. By default, terminals 37 and 38 are shorted. Remove the shorting wire if remote shutdown is needed. When terminals 37 and 38 are open, the system is shut down.

#### Smoke detect (SDC)

Terminals 91, 92 and 93 can be connected to the smoke sensor, with 91 being the common terminal, 92 being the NO contact, and 93 being the NC contact. You can select NO or NC contact according to the smoke sensor logic.

Terminals 80 and 81 are used to output external alarms for the smoke sensor.

#### Customized alarm terminals

Terminals 50, 51, 55 can be connected to three kinds of sensors, including fire sensor and water sensor. Terminal 24 is the common terminal. After connecting sensors to the terminals, you should set the corresponding customized alarm through the microprocessor. See 5.7.6 *SET ALARMS* for details. When the contactor is open and there is no external alarm, the input state of the customized terminal is open. But when the contactor is closed and the external alarm is raised, the input state of the customized terminal will be shorted. At this time, the system will raise sirens, and the LCD of indoor unit will display the alarm information. If a PC installed with Emerson monitoring software is connected to the system, the alarm will also be displayed on the PC.

The terminals can be defined as follows:

Terminals 50 and 24: remote alarm (optional).

Terminals 51 and 24: water sensor (by default).

Terminals 55 and 24: safe switch for condensation water pump (optional).

#### Water-under-floor sensor (WUF)

Each unit is equipped with one WUF sensor. You should connect one end of the sensor to terminal 51, and the other end to the common terminal 24. The number of sensors in parallel connection is not limited, but there is only one water-under-floor alarm for each unit.

#### Condensing pump safe switch (CPSS)

When the CPSS is configured, you should connect one end of the CPSS to terminal 55, and the other end to the common terminal 24.

#### External common alarm terminals

Terminals 75 and 76 can be used as external common alarm terminals. They are controlled by the external alarm relay K3 on the circuit board. They output signals to external alarm devices, such as the alarm indicator. When critical alarm occurs, the contactor will close to trigger remote alarms, send signals to the building management system or dial the paging system automatically. The power supply of the external alarm system is user self-prepared.

Refer to *Appendix 2 Circuit Diagram* for the detailed definition of other terminals.

## 3.3 Installation Inspection

After the electrical installation is completed, you should check and confirm that:

1. The power resource voltage meets the rating on the nameplate.
2. The system electric loop has no open circuit or short circuit.
3. Power cables and grounding cables are connected to the circuit breakers, indoor unit and outdoor unit.
4. The ratings of the circuit breakers and fuses are correct.
5. The control cables are properly connected.
6. All the cable connections are fastened, with no loose screws.

You can start commissioning after confirming the preceding points.

# Chapter 4 System Start-Up Commissioning

This chapter introduces the start-up commissioning of the chilled water AC, including preparation before commissioning, commissioning procedures and inspection after commissioning.

## 4.1 Locating MCBs

The MCBs are located as shown in Figure 4-1, Figure 4-2 and Figure 4-3.




Figure 4-1 MCBs of one-bay series




Figure 4-2 MCBs of two-bay series




Figure 4-3 MCBs of three-bay series

1: Fan MCB

2: Electrical heater MCB

3: Infrared humidifier MCB

4: Control board MCB

5: Main isolation switch

## 4.2 Start-Up Commissioning

### 4.2.1 Preparation Before Commissioning

#### Mechanical and system part

1. Check that the protection materials during transportation have been removed;
2. Check that the motor pulley and the fan pulley are fixed, the motor bearing and fan bearing are parallel, the belt is perpendicular to the two bearings and the tension of the belt is proper;
3. The pressure-leak detection of the chilled water system has been done and the chilled water system is confirmed to be qualified;
4. The cleaning and emptying of the chilled water system have been done (air vent valve is located in the top of the heat exchanger coil);
5. The chilled water system has been confirmed ready for operation;
6. The water supply-/drainage-pipe system of the humidification system has been reliably connected according to the material requirements and has been checked against leakage;
7. Make sure the equipment room temperature is above 68°F with sufficient heat load. If the heat load is insufficient, heat the equipment room with other heating devices, or by forcibly hand-running the heater of the unit or adjacent other equipment (in this case, go through the following procedures till the third step of 4.2.2 *Commissioning Procedures*) to make sure the heat load is sufficient for the commissioning.

#### Electrical part

1. Check that the input voltage of the main power is -10% ~ +15% of the rating;
2. Check that all electrical or control cables are correctly connected. Fasten all the connecting terminals;
3. The power cables and the low voltage control cables are laid away from each other;
4. Check the phase sequence. The phase sequences of all three-phase devices have been adjusted consistent before delivery. During commissioning, you only need to ensure the phase sequence of a random three-phase device is correct. In step two of 4.2.2 *Commissioning Procedures*, you can use a straight screwdriver to click on the fan contactor within the electric control box to judge the phase sequence by observing the wind direction. If the phase sequence is wrong, exchange any two phases of the L line of the power supply.

### 4.2.2 Commissioning Procedures

1. Turn off the MCBs of various parts. Turn on the main MCB and control MCB and check the control voltage.
2. Switch on the fan MCB and click on the contactor of the indoor fan with a screwdriver to confirm the rotation direction of the fan. Start the equipment and measure all the phase currents of the fan.
3. Switch on the electrical heater MCB and change the temperature setting to start the electric reheat, or start the heater manually. Measure all the phase currents of electrical heater.

To trigger the electrical heater, you should:

Change the temperature setting (see 5.7 *SERVICE MENUS*) to 9°F higher than the indoor temperature. The system should then trigger the call for heating and the electric reheat starts to work. Then set the temperature setting to 9°F lower than the indoor temperature. If the electrical heater stops working, it means the heating function is normal. Keeping the temperature setting can make no heating requirement. Continue the following commissioning steps.

4. Switch on the humidification MCB and change the humidity setting to start the humidifier, or start the humidifier manually. Measure all the phase currents of the humidifier. Manually charge water into the cooling system to check that the charge-/drainage-pipes do not leak and the drainage pipes are clear.

To trigger the humidifier, you should:

Adjust the humidity setting (see 5.7 *SERVICE MENUS*) to 10% higher than the indoor relative humidity. The control system should then trigger the call for humidification, and the humidifier starts to work. If the humidifier stops working when the humidity setting is lower than the indoor relative humidity, it means the humidifying function is normal.

---

#### Note

After commissioning, restore the humidity setting to the default or the original setting.

---

5. Change the temperature setting and start the refrigeration, or start the refrigeration manually. Record the water flow quantity of the system and water resistance.

To start the refrigeration (open the water flow control valve), you should:

Change the temperature setting (see 5.7 *SERVICE MENUS*) to 9°F lower than the indoor temperature. The control system should then trigger the call for refrigeration, and the water flow control valve switches on. After at least three minutes of refrigeration, change the temperature setting to 9°F higher than the indoor temperature. If the water flow control valve is closed, it means the refrigeration function is normal.

6. Change the humidity setting and the unit will enter a dehumidifying status. Record the water flow quantity of the system and water resistance.

To trigger dehumidification, you should:

Change the humidify setting (see 5.7 *SERVICE MENUS*) to 10% lower than the indoor relative humidity. The control system should then trigger the call for dehumidification, the water flow control valve switches on. Note that during the commissioning process, if the indoor temperature is 5.4°F higher than the temperature setting, the system may enter the forced refrigeration mode, and the dehumidification demand will not be responded. After commissioning, restore the humidity setting to the default or the original setting.

### 4.2.3 Inspection After Commissioning

1. Check that all output functions are automatic;
2. Check that the temperature & humidity settings and control precisions are set reasonably;
3. Make sure all the other functions are set reasonably.

## Chapter 5 iCOM Controller

The iCOM controller adopts menu operation. It can monitor, display and operate the precision cooling air conditioner and control the environment within a set range. This chapter expounds the LCD, button and indicator panel, structure chart of control menu, startup interface, main interface, USER MENUS, SERVICE MENUS, ADVANCED MENUS and EVENT NAME AND DIFINITION of the iCOM controller.

### 5.1 LCD

An LCD is located on the front panel of the Liebert.PEX2 series air conditioner. The LCD can display the current state of the equipment room, such as temperature and humidity, and so on. You can also read and modify the equipment configuration through the LCD.

The LCD uses blue backlight. If no button is pressed within a certain period of time (settable; default: 5min), the backlight will be off, until the next time any button is pressed.

### 5.2 Button And Indicator Panel

Nine buttons and two indicators are located on the button and indicator panel, including:

- Indicators: alarm indicator and operation indicator.
- Buttons: ON/OFF button, enter button, ESC button, up button, down button, left button, right button, alarm silence button and help button.

The button and indicator panel is shown in Figure 5-1.




Figure 5-1 Button and indicator panel

The indicators are described in Table 5-1.

Table 5-1 Indicator description

Indicator	Description
Alarm indicator	The alarm indicator turns on in red upon alarms. It is off after the alarm is cleared
Operation indicator	The operation indicator is on in green when the unit is operating. When the unit is shut down, it will be on in yellow

The functions of the buttons are described in Table 5-2.

Table 5-2 Function description of buttons

Button	Function description
ON/OFF button	<ol style="list-style-type: none"> <li>1. Switch on/off the system. Press the ON/OFF button to shut down an operating system, or to start an idle system.</li> <li>2. Test the display state of the backlight of the LCD and the operation indicator. After powering-on, when the system is in the standby state (defined as test state in this manual), pressing the ON/OFF button will switch between the operation indicator (green then) and the LCD backlight. This function is used to test whether the LCD backlight and the operation indicator are normal</li> </ol>
Enter button	<ol style="list-style-type: none"> <li>1. Enter the selected menu, or save the setting after parameters are changed. When you are entering a menu or changing a parameter, the menu and the parameter will be high lighted.</li> <li>2. Test the display of characters. When the system is in the test state, pressing the enter button will display the ASCII code. This function is used to test whether the characters are displayed normally on the LCD</li> </ol>
ESC button	<ol style="list-style-type: none"> <li>1. Quit the current menu.</li> <li>2. Abolish the current change of parameter.</li> <li>3. Test the LCD high light. Pressing the ESC button to switch the LCD between light and high light when the system is in the test state. This function can test whether the LCD high light is normal</li> </ol>
Up button	<ol style="list-style-type: none"> <li>1. Increase the value of the displayed parameter during parameter setting.</li> <li>2. Scroll a row or a screen up in the query state.</li> <li>3. Test the buzzer. Pressing the up button when the system is in the test state will increase the buzzing frequency (initial value: 0%). Meanwhile the buzzer will sound at the set frequency. This function is used to test whether the buzzer is normal</li> </ol>
Down button	<ol style="list-style-type: none"> <li>1. Decrease the value of the displayed parameter during parameter setting.</li> <li>2. Scroll a row or a screen down in the query state.</li> <li>3. Test the buzzer. If the buzzer frequency is not 0%, pressing the down button when the system is in the test state will decrease the buzzing frequency. Meanwhile the buzzer will sound at the set frequency. This function is used to test whether the buzzer is normal</li> </ol>
Left button	<ol style="list-style-type: none"> <li>1. Select the left bit during the parameter setting operation.</li> <li>2. Test the LCD contrast. Pressing the left button when the system is in the test state will decrease the LCD contrast (by default: 100%). This function is used to test whether the LCD contrast is normal</li> </ol>
Right button	<ol style="list-style-type: none"> <li>1. Select the right bit during the parameter setting operation.</li> <li>2. Test the LCD contrast. If the LCD contrast is not 100%, pressing the right button when the system is in the test state will increase the LCD contrast. This function is used to test whether the LCD contrast is normal</li> </ol>
Alarm silence button	<ol style="list-style-type: none"> <li>1. The system will issue an alarm sound upon alarms. If you press the alarm silence button, the alarm sound will be eliminated.</li> <li>2. Clear the current alarm after the alarm sound is silenced.</li> <li>3. Test the alarm indicator, and rest the LCD contrast and buzzer frequency. Pressing the alarm silence button when the system is in the test state will switch the alarm indicator between on and off. It can test whether the alarm indicator is normal. Meanwhile, reset the LCD contrast to 100% and buzzer frequency to 0%</li> </ol>
Help button	<ol style="list-style-type: none"> <li>1. Display the online help.</li> <li>2. Test the yellow display of the LCD operation indicator. When the system is in the test state, pressing the help button will switch on and off the LCD operation indicator. This function is used to test whether the yellow display of the LCD operation indicator is normal</li> </ol>

 **Note**

1. After the system is powered on, the system will assume the operation state before power-off. For example, if the system is in the work state when it is powered off, it will enter the work state automatically after power-on. You do not need to start it manually.
2. When the system is in the test state, the setpoints will not be written into the iCOM controller.

### 5.3 Structure Chart Of Control Menu

Please refer to *Error! Reference source not found.*

### 5.4 Startup Interface

After the system is powered on, it is in the waiting state. The LCD will display the interface shown in Figure 5-2.




Figure 5-2 Startup interface

### 5.5 Main Interface

After power-on, the LCD will enter the main interface after 20s. The main interface provides the general information of the relative equipment status, including current temperature and humidity, temperature and humidity setpoints, equipment output status (fan, compressor, cooling, heating, dehumidifying, humidifying), alarm and maintenance status.

The main interface has two display modes: graphical and simple. The difference between the two display modes is that the graphic interface (see Figure 5-3) displays the percentage output chart of the function components while the simple interface (see Figure 5-4) displays the icons of current operation mode only. The switching of two modes can be realized by operating the menu. For details, refer to 5.6.7 DISPLAY SETUP. The upper left corner of the main interface displays the current unit number; the upper right corner displays the current system status. If there is no button operation for 255s on other menu display screen, the LCD screen will return to the main interface.




Figure 5-3 Graphical mode of main interface




Figure 5-4 Simple mode of main interface

The icons of the graphical mode and the simple mode on the main interface are defined in Table 5-3.

Table 5-3 Definition of icons

Icon	Definition	Icon	Definition
	Fan running	FC	Free cooling
	Cooling		Maintenance
	Hot water heating		Dehumidifying
	Electric heating		Humidifying

## 5.6 USER MENUS

Press the enter or down button on the main interface to enter the USER MENU, as shown in Figure 5-5. The USER MENUS are displayed in six pages, each displaying one or two submenus. Press the enter button to highlight the submenu, the up or down button to browse the submenus, and the enter button to enter the selected one.




Figure 5-5 USER MENUS

### 5.6.1 PASSWORD

The password is necessary for some setpoints. After inputting the password (user password: 149), use the up button and down button to browse all the options, and then press the enter button to enter the selected one.

### 5.6.2 SETPOINTS

The setpoints will not be lost when the power fails. You can enter to browse and set the parameters in the SETPOINTS submenu through the USER MENU. The left row displays the parameter codes; the middle row, the parameter name; the right row, the setpoints, as shown in Table 5-4.

Table 5-4 Descriptions of SETPOINTS parameters

Parameters		Default	Setting range	Description
U102	TEMP SET	23°C	5°C ~ 40°C	Temperature setpoint
U103	HUM SET	50%	1% ~ 80%	Humidity setpoint
U104	HUM CTRL	Rel	Pred (predictive), Comp (compensable), Rel (relative)	Humidity control type
U105	SUP SENS	No	No, Lim, Ctrl, Cool	Supply air type
U106	SUP TEMP	15°C	5°C ~ 25°C	Air temperature limit setpoint
U107	BACK TSP	15°C	5°C ~ 40°C	Backup temperature setpoints

If you want to modify the preceding setpoints, you should input the password before entering the SETPOINTS menu. Then press the enter button to highlight it and use the up and down button to scroll the options. Press the enter button to select one parameter, use the up or down button to set the value, and press the enter button to save the change.

### 5.6.3 EVENT LOG

You can enter the EVENT LOG menu without a password, as shown in Figure 5-6.




Figure 5-6 EVENT LOG menu

The EVENT LOG menu saves the last 400 system records. The event types include message, warning and alarm.

- When the event type is message, the LCD will display the event name only.
- When the event type is warning, the LCD will display the event name and the alarm indicator will turn on in red.
- When the event type is alarm, the LCD will display the event name, the alarm indicator will turn on in red, and an audible alarm will be raised.

#### 5.6.4 GRAPHICS

The GRAPHICS menu provides two kinds of graphs: RETURN TEMP and RETURN HUMIDITY. These graphs reflect the temperature and humidity changes over a period of time in the past.

In the graphs, the current temperature or humidity is the origin, the time is the horizontal axis, and the temperature or humidity is the vertical axis, as shown in Figure 5-7.




Figure 5-7 The graph of return temperature and return humidity

As the horizontal axis, the time range can be set into eight kinds. Each pixel indicates different time in different time ranges. See Table 5-5 for the detailed time range.

Table 5-5 Time range

Time range	Time indicated by each pixel	Time range	Time indicated by each pixel
8min	6s	2d	36min
32min	24s	4d	72min
1hr	45s	8d	144min
12hr	9min	16d	288min
24hr	18min		

The scaling of the vertical axis can also be set. For the RETURN TEMP, the scaling range is  $\pm 3 \sim \pm 20$ ; for the RETURN HUMIDITY, the scaling range is  $\pm 10 \sim \pm 30$ . The bigger the scaling range is, the bigger the value each pixel indicates will be, and the more centered the curves will be.

You can set the parameters without inputting the password. Press the enter button to highlight the parameters, use the up or down button to select one parameter. Then press the enter button again to enter the parameter, and use the up or down button to set the value. Press the enter button to save the change at last.

#### 5.6.5 SET ALARMS

The SET ALARMS menu is used to set the upper and lower limits of temperature and humidity alarms. The settings will not be lost when the power fails. You can select the 'SET ALARMS' submenu to browse and set the parameters through the USER MENUS. The parameters are described in Table 5-6.

##### Note

It is recommended not to change the system defaults. If you consider it necessary to change the defaults, consult professionals first and set the alarm settings under the guidance of them.

Table 5-6 Descriptions of SET ALARMS parameters

Parameters		Default	Setting range	Description
U202	RTN SNSR	Yes	Yes, No	Return air alarm enable
U203	HI TEMP	27°C	1°C ~ 99°C	High return air temperature alarm setpoint
U204	LO TEMP	18°C	1°C ~ 99°C	Low return air temperature alarm setpoint
U205	HI HUM	60%	1% ~ 99%	High return air humidity alarm setpoint
U206	LOW HUM	40%	1% ~ 99%	Low return air humidity alarm setpoint
U207	SENSOR A	No	Yes, No	Sensor A alarm enable
U208	HI TEMP A	50°C	1°C ~ 99°C	High temperature alarm setpoint of sensor A
U209	LO TEMP A	25°C	1°C ~ 99°C	Low temperature alarm setpoint of sensor A
U210	HI HUM A	70%	1% ~ 99%	High humidity alarm setpoint of sensor A
U211	LO HUM A	30%	1% ~ 99%	Low humidity alarm setpoint of sensor A
U213	SUP SNSR	No	Yes, No	Supply air alarm enable
U214	HI SUP T	24°C	1°C ~ 99°C	High supply air temperature alarm setting value
U215	LO SUP T	10°C	1°C ~ 99°C	Low supply air temperature alarm setting value

To browse through the menu, press the enter button to highlight the option, and use the up or down button to scroll.

Password is required for changing the setpoints. Then, enter the SET ALARMS menu, press the enter button to highlight the option, use the up or down button to browse the submenu. Press the enter button to enter the selected parameter. Use the up or down button to change the setpoints, and press the enter button to save the change, or press the ESC button to quit the change.

### 5.6.6 SENSOR DATA

You can monitor the data acquired by the sensors through the SENSOR DATA menu. The values are read only, no setting or change is allowed. The parameters are described in Table 5-7.

Table 5-7 Descriptions of SENSOR DATA parameters

Parameters		Unit	Description	Parameters		Unit	Description
U301	TEMP A	°C	Temperature of sensor A	U313	Hi Temp	°C	Daily high temperature
U302	HUM A	%	Relative humidity of sensor A	U314	Lo Te H	h	Daily low temperature (hour)
U303	TEMP B	°C	Temperature of sensor B	U314	Lo Te M	m	Daily low temperature (minute)
U304	HUM B	%	Relative humidity of sensor B	U314	Lo Te S	s	Daily low temperature (second)
U305	TEMP C	°C	Temperature of sensor C	U314	Lo Temp	°C	Daily low temperature
U306	HUM C	%	Relative humidity of sensor C	U315	Hi Hu H	h	Daily high humidity (hour)
U307	FC TEMP	°C	Free cooling temperature	U315	Hi Hu M	m	Daily high humidity (minute)
U308	AMB TEMP	°C	Outdoor temperature	U315	Hi Hu S	s	Daily high humidity (second)
U309	FC STATE	-	Free cooling status	U315	Hi Humi	%	Daily high humidity
U310	DS1 TEMP	°C	Temperature of digital scroll 1	U316	Lo Hu H	h	Daily low humidity (hour)
U311	DS2 TEMP	°C	Temperature of digital scroll 2	U316	Lo Hu M	m	Daily low humidity (minute)
U313	Hi Te H	hr	Daily high temperature (hour)	U316	Lo Hu S	s	Daily low humidity (second)
U313	Hi Te M	m	Daily high temperature (minute)	U316	Lo Humi	%	Daily low humidity
U313	Hi Te S	s	Daily high temperature (second)				

### 5.6.7 DISPLAY SETUP

The DISPLAY SETUP menu is used to set the LCD display attributes. Password is not required for changing the setpoints. The parameters are described in Table 5-8.

Table 5-8 Descriptions of DISPLAY SETUP parameters

Parameters		Default	Setting range	Description
U401	LANGUAG	EN	RUS, CZE, CHI, ESP, FRE, ITA, DEU, EN, POR	Language options
U402	YEAR	2005	-	Current year
U402	MONTH	04	01 ~ 12	Current month
U402	DAY	19	01 ~ 31	Current day
U403	HOUR	19h	-	Current hour
U403	MINUTE	8min	-	Current minute
U403	SECOND	17s	-	Current second
U404	TEMP F/C	°C	°F, °C	Temperature indication
U405	CONTRAST	50%	0% ~ 100%	Display contract
U406	BUZ FREQ	50%	0% ~ 100%	Buzzer frequency. 0% means buzzer silenced
U406	BUZ TEST	Off	On, Off	Buzzer frequency test switch. It determines whether or not there will be sound accompanying the adjustment of BUZ FREQ through the setting
U407	BACKLITE	5min	5min, 10min, 30min, 1hr, 12hr	Backlight time, or the backlight time when there is no button operation
U408	SCREEN	Graph	Graph, Simple, SimCo, GraCo	Main interface display mode
U409	SHOWS	A + S	SET, ACT, A + S	Main interface display mode of setpoints and actual values. Range: SET: only setpoints of the temperature and humidity are displayed. ACT: only actual temperature and humidity are displayed. A + S: both setpoints and actual values of the temperature and humidity are displayed
U410	DISPLAY	Norm	Norm (normal), Inv	Display color
U411	DATE	m/d/y	m/d/y, d.m.y, y-m-d	Date display format

### 5.6.8 TOTAL RUN HRS

The TOTAL RUN HRS menu records the total run time (unit: hr) of the system components. You can also set the run time limits of the system components through this menu. If the actual component run time exceeds the set limit, alarms will be raised.

This menu requires password. You can reset the total run time to zero in order to restart timing.

 **Note**

Resetting the timers is not needed unless the components are replaced.

The parameters on this menu are described in Table 5-9. Each component has a LIMIT option to set the run time limit of the corresponding component.

Table 5-9 Descriptions of TOTAL RUN HRS parameters

Parameters			Default	Related component	Parameters			Default	Related component
U502	MOTOR(S)	1000hr	32000hr	Fan motor	U507	EL HEAT1	34hr	32000hr	Electric heater 1
U502	LIMIT	U507			LIMIT				
U503	COMP1	500hr	32000hr	Compressor 1	U508	EL HEAT2	45hr	32000hr	Electric heater 2
U503	LIMIT	U508			LIMIT				
U504	COMP2	500hr	32000hr	Compressor 2	U509	EL HEAT3	0hr	32000hr	Electric heater 3
U504	LIMIT	U509			LIMIT				
U505	CW/FC	1000hr	32000hr	Chilled water/free cooling	U510	HUM	7hr	32000hr	Humidifier
U505	LIMIT	U510			LIMIT				
U506	HG/HW	23hr	32000hr	Hot gas/hot water	U511	DEHUM	1hr	32000hr	Dehumidification
U506	LIMIT	U511			LIMIT				

## 5.6.9 SLEEP MODE

In the sleep mode, the air conditioner unit can realize auto-on/off. Through the SLEEP MODE menu, you can set two time zones of the sleep mode, and select the sleep timing mode. The parameters on this menu are described in Table 5-10.

Table 5-10 Descriptions of SLEEP MODE parameters

Parameters		Default	Setting range	Description	
U602	MON	No	Yes, No	Sleep mode day, including Monday ~ Sunday. Set the value of any day to 'Yes', and the system will enter sleep mode on that day every week. This parameter works together with the following hour and minute settings to designate an exact time	
U602	TUE	No			
U602	WED	No			
U602	THU	No			
U602	FRI	No			
U602	SAT	No			
U602	SUN	No			
U605	START 1	0hr	-	Sleep mode start time 1. The first parameter is used to set the hour of time, and the second one is used to set the minute of time	
U605	START 1	0m		Sleep mode end time 1. The first parameter is used to set the hour of time, and the second one is used to set the minute of time	
U605	STOP 1	0hr			
U605	STOP 1	0m			
U607	START 2	0hr		Sleep mode start time 2. The first parameter is used to set the hour of time, and the second one is used to set the minute of time	
U607	START 2	0m			
U607	STOP 2	0hr			Sleep mode end time 2. The first parameter is used to set the hour of time, and the second one is used to set the minute of time
U607	STOP 2	0m			
U609	TIME MOD	Auto	Auto, Yes, No	Timing mode setting. Range: Auto: during the system sleep time, if high/low temperature occurs, the system will resume operation and mask the alarm for 15min. The system will re-enter the sleep mode after the alarm is cleared Yes: start sleep mode No: no sleep mode	
U610	TIME TYP	S.OFF	S.OFF, DEADB	Timing mode selection	
U611	DEADBAND	K	2K ~ 15K	Used to set the deadband temperature setting range	

## 5.6.10 SERVICE INFO

The SERVICE INFO menu provides the contact information of customer service personnel. The information is read only.

## 5.6.11 ACTIVE ALARMS

The ACTIVE ALARMS menu displays the active alarms of the system. No password is required to query this menu.

## 5.7 SERVICE MENUS

Press the right button at the first page of the USER MENUS, and you can enter the SERVICE MENUS, as shown in Figure 5-8.

The SERVICE MENUS are displayed in five pages. Each page displays one or two submenus. Press the enter button to highlight the submenus, and use the up or down button to scroll up or down. Press the enter button to enter the selected submenu.




Figure 5-8 SERVICE MENUS

### 5.7.1 PASSWORD LEVEL

It is operated by Emerson service personnel.

### 5.7.2 SETPOINTS

Different from the SETPOINTS in the USER MENU, the SETPOINTS in SERVICE MENUS has many more parameters. See Table 5-11 for the parameter descriptions.

Table 5-11 Descriptions of SETPOINTS parameters

Parameters	Default	Setting range	Description
S102 TEMP SET	25°C	5°C ~ 40°C	Temperature setpoint
S103 CTRL TYPE	PI	Prop, PI, Intel, No	Control type selection
S104 TEMP PB	7K	2.2K ~ 30K	Temperature proportional band setpoint, or the P in PID control
S105 TEMP INT	min	-	Temperature integration time setpoint, or the I in PID control
S107 AUTOSET	Yes	Yes, No	Autoset enable
S108 TEMP DB	0K	0K~20K	Temperature deadband setting range
S109 2ND SETP	23°C	5°C ~ 40°C	-
S110 BACK TSP	23°C	5°C ~ 40°C	Backup temperature setpoint
S111 HEAT DB	0K	0K~20K	Heaters deadband setting range
S113 HUM SET	50%	1% ~ 80%	Humidity setpoint
S114 HUM CTRL	Pred	Comp, Rel, Pred	Humidity control type
S115 HUM PB	10%	1% ~ 20%	Humidity proportional band
S116 HUM INT	5min	-	Humidity integration time
S117 HUM DB	0%	1% ~ 50%	Humidity deadband setting range
S118 LO LIM 1	k	-	Dehum/Heat low limit 1
S119 LO LIM 2	-1.7K	-5.5K ~ -1.1K	Dehum/Heat low limit 2
S124 SUP SENS	No	No, Lim, Ctrl, Cool	Supply air type
S125 SUP TEMP	5°C	5°C ~ 27°C	Air supply limit temperature setpoint
S126 SUP TYPE	PI	Prop, PI, PID, Intel	Supply control type
S127 SUP PB	12K	2K ~ 30K	Supply proportional band
S128 SUINT	0min	0 ~ 15min	Supply integration
S130 SUP DB	-	0K~20K	Supply deadband
S131 VPULS	5%	0 ~ 10%	Valve Pulse
S132 CF0	-	0.01 ~ 100%	Cooling filter at 0%
S132 CF100	-	0.01 ~ 100%	Cooling filter at 100%
S133 RET CO	0K	0 ~ 10K	Return Compensation
S135 AMB TYPE	No	CONT, EFC, VAL, No	DT between Room/Outdoor Type
S136 AMB DT	5°C	0°C ~ 20°C	DT between Room Air/Outdoor
S137 FC TYPE	No	No, CONT, VAL	DT between Room/FC Type
S138 FC DT	4.5°C	0°C ~ 20°C	DT between Room Air/FC Fluid
S139 MIN CW	No	Yes, No	Minimum CW temperature protection selection
S140 MIN CW	7°C	0°C ~ 20°C	Minimum CW temperature value

Parameters		Default	Setting range	Description
S141	LOCK FC	0°C	0°C ~ 9°C	Lockout FC at FC Fluid below
S142	TRANS CH	2%	0.1 ~ 100%	Transition Change
S146	FANSPEED	Auto	Auto, Man, ECO, SUP, DELT	VSD Fanspeed
S147	VSD SET	100%	0 ~ 100%	Standard speed of the unit
S148	VSD MIN	60%	0 ~ 100%	Minimum speed of the unit
S149	VSD DEH	60%	0 ~ 100%	Speed used during dehum
S150	VSD NOP	100%	0 ~ 100%	Speed used when CI is active
S151	FF0%	0.2%	0 ~ 100%	Fanspeed Change (at 0%)
S151	FF100%	1%	0 ~ 100%	Fanspeed Change (at 100%)
S152	FRD	0s	0 ~ 300s	Fanspeed Reposition Delay
S153	HAD	-	-	-
S154	HAP	6°C	2°C ~ 30°C	Fanspeed P-Band
S155	HAI	5min	0 ~ 15min	Fanspeed Integration
S157	SCR TYPE	-	-	-
S158	CO1 ON	-	-	-
S159	CO1 OFF	-	-	-
S160	CO1 TD	-	-	-
S161	CO2 ON	-	-	-
S162	CO2 OFF	-	-	-
S163	CO2 TD	-	-	-
S164	CYCLET	-	-	-
S165	SCR FACT	-	-	-
S166	ACT SCR	-	-	-

### 5.7.3 STANDBY

The parameters of the STANDBY menu are described in Table 5-12.

Table 5-12 Descriptions of STANDBY parameters

Parameters		Default	Setting range	Description
S502	#STANDBY	1	0 ~ 32	Number of standby units
S503	ROTATION	Daily	No, Daily, MON ~ SUN, M - MON ~ M - SUN	Rotation frequency setting of the running and standby units. Range: Daily: rotate once a day. MON ~ SUN: rotate once a week. The rotation occurs on Monday ~ Sunday of the week. For example, MON means rotation occurs on Monday of every week. M - MON ~ M - SUN: rotate once a month. The rotation occurs on Monday ~ Sunday of the first week of the month. For example, M - MON means rotation occurs on Monday of the first week of every month
S504	ROT HOUR	hr	-	Used to set the hour of the detailed time while rotation
S505	ROT MIN	min	-	Used to set the minute of the detailed time while rotation
S506	ROT BY	1	1 ~ 8	The unit number for a rotation
S507	DO ROT	No	Yes, No	Perform one rotation
S508	CASCADE	No	CO/HE, Cool, Yes, No	Cascade function selection. 'Yes' corresponds to temperature and humidity control and 'no' corresponds to closing the cascade
S509	STBY HT	No	Yes, No	Whether to start all standby units upon high temperature alarm

### 5.7.4 WELLNESS

The iCOM controller calculates the bonus and penalty over the equipment maintenance based on the parameters in the WELLNESS menu and the equipment operation historical data, so as to find out the next system maintenance time.

Informing the maintenance personnel of the maintenance time makes the air conditioner run in the optimal mode, which reduces the chances of faults and raises the system reliability.

The WELLNESS menu includes nine groups of parameters, including WELLNESS BASICs, and WELLNESS MOTOR, WELLNESS COMPs, WELLNESS HEATs and WELLNESS HUM. See Table 5-13 ~ Table 5-21 for detailed parameter descriptions.

**WELLNESS BASIC1**

*Table 5-13 Descriptions of WELLNESS BASIC1 parameters*

Parameters		Default	Setting range	Description
S002	FREQ/YR	1pY	0pY ~ 12pY	Maintenance frequency every year
S003	BONUS	MM	0MM ~ 12MM	Bonus setting
S004	PENALTY	MM	0MM ~ 12MM	Penalty setting
S005	LAST PM	YY	-	Last maintenance. Year (YY), month (MM) and day (DD). This parameter is read only
S005	LAST PM	MM		
S005	LAST PM	DD		

**WELLNESS BASIC2**

*Table 5-14 Descriptions of WELLNESS BASIC2 parameters*

Parameters		Default	Setting range	Description
S006	NAME	-	-	Service personnel setting
S007	CONFIRM	No	Yes, No	Maintenance confirmation selection
S008	NEXT PM	-	-	Calculated next maintenance. This parameter is read only

**WELLNESS MOTOR**

*Table 5-15 Descriptions of WELLNESS MOTOR parameters*

Parameters		Default	Description
S013	STARTS	-	Number of fan starts since the last maintenance
S014	RUN HRS	hr	Fan run hours since the last maintenance
S015	AVG RUN	min	Average fan run time calculated through number of fan starts and run hours
S016	BEST	1	Starts per day best
S017	WORST	24	Starts per day worst
S018	ALARMS	0	Number of alarms since the last maintenance
S019	BONUS	0MM	Bonus amount. Actual bonus calculated through the number of starts and average run time. This value determines the time for the next maintenance

**WELLNESS COMP1**

*Table 5-16 Descriptions of WELLNESS COMP1 parameters*

Parameters		Default	Description
S024	STARTS	-	Number of compressor 1 starts since the last maintenance
S025	RUN HRS	hr	Compressor 1 run hours since the last maintenance
S026	AVG RUN	min	Average compressor 1 run time calculated through the number of starts and run hours
S027	BEST	12	Starts per day best
S028	WORST	240	Starts per day worst
S029	HP AL	0	Number of high pressure alarms occurred to compressor 1 since the last maintenance
S030	LP AL	0	Number of low pressure alarms occurred to compressor 1 since the last maintenance
S031	OL AL	0	Number of overload alarms occurred to compressor 1 since the last maintenance
S032	DS HT AL	0	Number of digital scroll high temperature alarms occurred to compressor 1 since the last maintenance
S033	BONUS	0MM	Bonus amount. Actual bonus calculated through the number of starts and average run time. This value determines the time for the next maintenance

**WELLNESS COMP2**

*Table 5-17 Descriptions of WELLNESS COMP2 parameters*

Parameters		Default	Description
S035	STARTS	-	Number of compressor 2 starts since the last maintenance
S036	RUN HRS	hr	Compressor 2 run hours since the last maintenance

Parameters		Default	Description
S037	AVG RUN	min	Average compressor 2 run time calculated through the number of starts and run hours
S038	BEST	12	Starts per day best
S039	WORST	240	Starts per day worst
S040	HP AL	0	Number of high pressure alarms occurred to compressor 2 since the last maintenance
S041	LP AL	0	Number of low pressure alarms occurred to compressor 2 since the last maintenance
S042	OL AL	0	Number of overload alarms occurred to compressor 2 since the last maintenance
S043	DS HT AL	0	Number of digital scroll high temperature alarms occurred to compressor 2 since the last maintenance
S044	BONUS	0MM	Bonus amount. Actual bonus calculated through the number of starts and average run time. This value determines the time for the next maintenance

### WELLNESS HEAT1

Table 5-18 Descriptions of WELLNESS HEAT1 parameters

Parameters		Default	Description
S046	STARTS	-	Number of electric heater 1 starts since the last maintenance
S047	RUN HRS	hr	Electric heater 1 run hours since the last maintenance
S048	AVG RUN	min	Average electric heater 1 run time calculated through the number of starts and run hours
S049	BEST	24	Starts per day best
S050	WORST	240	Starts per day worst
S051	ALARMS	0	Number of high pressure alarms since the last maintenance
S052	BONUS	0MM	Bonus amount. Actual bonus calculated through the number of starts and average run time. This value determines the time for the next maintenance

### WELLNESS HEAT2

Table 5-19 Descriptions of WELLNESS HEAT2 parameters

Parameters		Default	Description
S057	STARTS	-	Number of electric heater 2 starts since the last maintenance
S058	RUN HRS	hr	Electric heater 2 run hours since the last maintenance
S059	AVG RUN	min	Average electric heater 2 run time calculated through the number of starts and run hours
S060	BEST	24	Starts per day best
S061	WORST	240	Starts per day worst
S062	ALARMS	0	Number of high pressure alarms since the last maintenance
S063	BONUS	0MM	Bonus amount. Actual bonus calculated through the number of starts and average run time. This value determines the time for the next maintenance

### WELLNESS HEAT3

Table 5-20 Descriptions of WELLNESS HEAT3 parameters

Parameters		Default	Description
S068	STARTS	-	Number of electric heater 3 starts since the last maintenance
S069	RUN HRS	hr	Electric heater 3 run hours since the last maintenance
S070	AVG RUN	min	Average electric heater 3 run time calculated through the number of starts and run hours
S071	BEST	24	Starts per day best
S072	WORST	240	Starts per day worst
S073	ALARMS	0	Number of high pressure alarms since the last maintenance
S074	BONUS	0MM	Bonus amount. Actual bonus calculated through the number of starts and average run time. This value determines the time for the next maintenance

### WELLNESS HUM

Table 5-21 Descriptions of WELLNESS HUM parameters

Parameters		Default	Description
S079	STARTS	-	Number of humidifier starts since the last maintenance
S080	RUN HRS	hr	Humidifier run hours since the last maintenance

Parameters		Default	Description
S081	AVG RUN	min	Average humidifier run time calculated through the number of starts and run hours
S082	BEST	24	Starts per day best
S083	WORST	240	Starts per day worst
S084	ALARMS	0	Number of high pressure alarms since the last maintenance
S085	BONUS	0MM	Bonus amount. Actual bonus calculated through the number of starts and average run time. This value determines the time for the next maintenance

### 5.7.5 DIAGNOSTICS

The DIAGNOSTICS menu is classified into two groups. After entering the menu, pressing the up button and down button can switch between two groups and pressing the enter button can enter the parameters of the corresponding group. The parameters of group 1 are settable and used to help the maintenance personnel start and cut off devices by hand in site, so as to realize the diagnosis for devices. The parameters of group 2 are read only and reflect the fault condition of the devices. See Table 5-22 for detailed descriptions.

Table 5-22 Descriptions of DIAGNOSTICS parameters

Parameters		Default	Setting range	Description	
Group 1	S302	HP1 CODE	0	-	HP 1 alarm counting. The counter can be reset to 0 through the parameter
	S303	HP2 CODE	0	-	HP 2 alarm counting. The counter can be reset to 0 through the parameter
	S304	HT1 CNT	0	-	HT 1 alarm counting. The counter can be reset to 0 through the parameter
	S305	HT2 CNT	0	-	HT 2 alarm counting. The counter can be reset to 0 through the parameter
	S306	LP1 CODE	0	-	LP 1 alarm counting. The counter can be reset to 0 through the parameter
	S307	LP2 CODE	0	-	LP 2 alarm counting. The counter can be reset to 0 through the parameter
	S308	LP1 ACT	br	-	Actual LP 1
	S309	LP2 ACT	br	-	Actual LP 2
	S310	LP1 ACT	br	-	Actual LP 1
	S311	LP2 ACT	br	-	Actual LP 2
	S313	MANUAL	No	Yes, No	Selecting 'Yes' can turn on or off the components; selecting 'No' can prohibit manual setting
	S314	MOTOR(S)	On	On, Off	Diagnosis switch of fan motor. The settings 'On' and 'Off' are used to manually start and shut down the fan respectively
	S315	COMP1	Off	On, Off	Diagnosis switch of compressor 1. The 'On' setting of this parameter can start compressor 1 only when the fan has been started
	S315	C1 MODE	Run	Run, Evac, Charg	Compressor 1 operation mode selection
	S316	C1 CAP	Off	On, Off	Refrigeration capacity output of digital scroll compressor 1
	S317	C1 CYCLE	0%	-	-
	S318	LLSV 1	Off	On, Off	Diagnostic of liquid line solenoid valve of compressor 1
	S319	COMP2	Off	On, Off	Diagnostic swtich of compressor 2. Note that the On setting of this parameter can start compressor 2 only when the fan has been started
	S319	C2 MODE	Run	Run, Evac, Charg	Compressor 2 operation mode selection
	S320	C2 CAP	Off	-	Refrigeration capacity output of digital scroll compressor 2
S321	C2 CYCLE	0%	-	-	
S322	LLSV2	Off	On, Off	Diagnosis switch of liquid line solenoid valve of compressor 2	
S324	EL HEAT1	Off	On, Off.	Diagnosis switch of electric heater 1. The 'On' setting of this parameter can start electric heater 1 only when the	

Parameters		Default	Setting range	Description	
				air loss is normal	
	S325	EL HEAT2	Off	On, Off.	Diagnosis switch of electric heater 2. The 'On' setting of this parameter can start electric heater 2 only when the air loss is normal
	S326	EL HEAT3	Off	On, Off.	Diagnosis switch of electric heater 3. The 'On' setting of this parameter can start electric heater 3 only when the air loss is normal
	S327	SCR HEAT	-	0 ~ 100 %	SCR Heat
	S328	DEHUMI	Off	On, Off	Diagnostic switch of Dehumidification solenoid valve
	S329	HUM FILL	Off	On, Off	Diagnosis switch of solenoid valve of water supply to the humidifier
	S330	HUM	Off	On, Off	Diagnosis switch of humidifier. The 'On' setting of this parameter can start the humidifier only when the air loss is normal
Group 1	S331	H DRAIN	-	On, Off	Humidifier drain
	S332	HUM.C.	0.00A	-	Electric current of humidifier
	S335	ALM REL	Off	On, Off	Diagnostic switch of alarm relay.
	S336	K11 REL	-	On, Off	Diagnostic switch of free cooling relay.
	S337	3P1 OPEN	Off	On, Off	Diagnostic switch of 3-phase electric regulator.
	S337	3P2 OPEN	Off	On, Off	
	S338	3P1 CLOSE	Off	On, Off	
	S338	3P2 CLOSE	Off	On, Off	
	S339	BV CTRL	-	Man, Auto	Ball valve control type
	S340	MBV1 POS	-	0 ~ 100%	MBV1 position, MBV2 position
	S340	MBV2 POS	-	0 ~ 100%	
	S341	ANALOG1	0%	0 ~ 100%	Diagnostic output of analog variable 1 ~ 4. They can be set to be percentage of desired output
	S342	ANALOG2	0%	0 ~ 100%	
S343	ANALOG3	0%	0 ~ 100%		
S344	ANALOG4	0%	0 ~ 100%		
Group 2	S345	RSD	On	On, Off	Remote shut down. Range: On, Off
	S346	AIR LOSS	OK	OK, ACT	Air loss alarm. OK means the system is normal. ACT means the air loss is active, and abnormality occurred
	S347	MOTOR OL	ACT	OK, ACT	Fan motor overload alarm. OK means the fan is normal. ACT means the fan is overloaded, and abnormality occurred
	S348	FILTER	OK	OK, ACT	Filter clogging situation. OK means normal; ACT means the filter is clogged
	S349	CUSTOM1	OK	OK, ACT	States of customized alarms 1 ~ 4. 'OK' means normality; 'ACT' means that the alarm is active and that abnormality occurs
	S350	CUSTOM2	OK	OK, ACT	
	S351	CUSTOM3	Ok	OK, ACT	
	S352	CUSTOM4	OK	OK, ACT	
	S353	HEAT SAF	OK	OK, ACT	Status heaters safety
	S354	FLOW AT	%	-	-
	S355	FLOW ACT	%	-	-
	S356	HP1	OK	OK, ACT	State of high pressure switch 1. OK means normal. ACT means abnormal
	S357	LP1	OK	OK, ACT	State of low pressure switch 1. OK means normal. ACT means abnormal
	S358	C1 OL	OK	OK, ACT	Overload state of compressor 1. OK means normal. ACT means abnormal
	S359	HP2	OK	OK, ACT	State of high pressure switch 2. OK means normal. ACT means abnormal
	S360	LP2	OK	OK, ACT	State of low pressure switch 2. OK means normal. ACT means abnormal
	S361	C2 OL	OK	OK, ACT	Overload state of compressor 2. OK means normal. ACT means abnormal
	S367	HUM PROB	OK	OK, ACT	Humidifier fault state. OK means normal. ACT means abnormal
	S368	DT1	-	OK, ACT	Status DT1 (Outdoor/Glycol)
S369	DT2	-	OK, ACT	Status DT2 (Glycol/Room)	

Parameters		Default	Setting range	Description
S370	DT3	On	On, Off	Status DT3 (Room/Setpoint)
S371	MIN CW	-	OK, ACT	Status Min CW
S372	LWD Val	-	-	-
S374	LSI	-	-	-
S375	COND 2	-	-	-
S376	COND 1	-	-	-
S379	V_CTRL	Time	Time, Feedb	Valve Control
S380	V_CAL	No	Yes. No	Start Valve Calibration
S381	CAL_STAT	Idle	-	-
S382	CLSD 1	-	-	-
S383	OPEN 1	-	-	-
S384	V1FDB	-	-	-
S385	CLSD 2	-	-	-
S386	OPEN 2	-	-	-
S387	V2FDB	-	-	-

**5.7.6 SET ALARMS**

The SET ALARMS menu is displayed in nine pages. The first page provides the settings of alarm upper/lower limits and customized alarms. The other eight pages provide the settings of alarm delay.

**Alarm upper/lower limits setting**

The alarm upper/lower limits in the SERVICE MENUS are set the same as those in the USER MENUS. For details, see Table 5-6.

**Customized alarms setting**

See Table 5-23 for the descriptions of customized alarms setting.

*Table 5-23 Descriptions of customized alarms setting*

Parameters		Default	Parameters		Default
S202	RTN SNSR	Yes	S215	LO SUP	10°C
S203	HI TEMP	°C	S224	CUST IN1	WATER
S204	LO TEMP	°C	S225	C1 ACT	CLOSE
S205	HI HUM	60%	S226	CUST IN2	WATER
S206	LOW HUM	40%	S227	C2 ACT	CLOSE
S207	SENSOR A	No	S228	CUST IN3	WATER
S208	HI TEMP A	°C	S229	C3 ACT	CLOSE
S209	LO TEMP A	°C	S230	CUST IN4	HEAT A
S210	HI HUM A	%	S231	C4 ACT	OPEN
S211	LO HUM A	%	S232	WA AC AL	No
S213	SUP SNSR	No	S233	WAT OFF	No
S214	HI SUP T	24°C			

CUST IN1, CUST IN2, CUST IN3 and CUST IN4 can be set to 21 types of input. See Table 5-24 for details.

*Table 5-24 Descriptions of types*

Types	Description	Types	Description	Types	Description
SMOKE	Smoke alarm	RH+HU	Rht + Hum lockout	RJTVS	HTRJ TVSS
WATER	Water leakage alarm	COMP	Compressor lockout	Fire	Fire Alarm
C PMP	Cooling pump alarm	Call	Call for service	2.Set	2nd Setpoint
FLOW	Insufficient water alarm	Temp	High temperature alarm	NoP	No Power
G PMP	Standby pump alarm	Air	Air loss alarm	LSI	LSI
STBY	Standby unit alarm	FC L.	FC lockout	Cnd 1	Condensor 1 Fail
C-In1	Customized alarm 1	HeatA	Heater alarm	Cnd 2	Condensor 2 Fail
C-In2	Customized alarm 2	FLOSD	Flow AL SD	ScRed	D-Scroll Red
C-In3	Customized alarm 3	FLOLC	Flow AL LC	Swap V	Swap Valve
C-In4	Customized alarm 4	ComPD	Comp Lock PD	ECFan	EC Fan Fail
RHT	Reheater lockout	En FC	Enable FC,		
HUM	Humidifier lockout	RJVFD	HTRJ VFD		

C1 ACT, C2 ACT, C3 ACT and C4 ACT correspond to the customer alarms. 'OPEN' means normally open, 'CLOSE' means normally closed.

**Alarm delays setting**

The alarm delays are the time after faults occur and before the alarms are triggered. See Figure 5-9 for the menu format.

SET ALARMS		2/10	01
	DEL	EN	T
S236	FOL	5	Yes ALM
S237	LOA	3	Yes ALM
S238	CF	2	Yes WRN
S239	HRT	30	Yes WRN
S240	LRT	30	Yes WRN
S241	HRH	30	Yes WRN

Figure 5-9 Alarm delay

The alarm name, delay time, delay enabling and alarm type are displayed from left to right in the list.

The alarm delay can be set to 0 ~ 9999. Unit: second.

The delay enabling determines whether the alarm will be displayed and the alarm menu is entered, Options include 'Yes' and 'No'.

The alarm type can be set to 'ALM' (alarm), 'WRN' (warning) and 'MSG' (message). They determine the alarm degree of the corresponding event.

The alarm names are listed in Table 5-25.

Table 5-25 Alarm name description

SN	Alarm/event name	Description	SN	Alarm/event name	Description
S236	FOL	Fan overload	S266	LOF	Loss of flow
S237	LOA	Loss of airflow	S267	SGP	Standby glycol pump on
S238	CF	Filter clogged	S268	STB	Standby unit on
S239	HRT	High room temp.	S269	HUP	Humidifier problem
S240	LRT	Low room temp.	S270	NOC	No connection w/Unit1
S241	HRH	High room hum.	S271	-	No connection w/UnitX
S242	LRH	Low room hum.	S272	LOP	LOSS OF POWER
S243	HTA	High temperature of sensor A	S275	CI1	Customized input 1
S244	LTA	Low temperature of sensor A	S276	CI2	Customized input 2
S245	HHA	High humidity of sensor A	S277	CI3	Customized input 3
S246	LHA	Low humidity of sensor A	S278	CI4	Customized input 4
S249	OL1	Compressor 1 overload	S279	CS	Call for service
S250	OL2	Compressor 2 overload	S280	HTD	High temperature
S251	HP1	Compressor 1 high pressure	S281	LB1	Loss of air blower 2
S252	HP2	Compressor 2 high pressure	S282	RL	Reheat lockout
S253	LP1	Compressor 1 low pressure	S283	HL	Humidifier lockout
S254	LP2	Compressor 2 low pressure	S284	FCL	FC lockout
S255	PD1	Compressor 1 pumpdown fails	S285	CL	Compressor(s) lockout
S256	PD2	Compressor 2 pumpdown fails	S288	SC1	Short cycle 1
S257	HT1	Digital scroll 1 high temperature	S289	SC2	Short cycle 2
S258	HT2	Digital scroll 2 high temperature	S290	NOP	NO power
S259	EHO	EL HEAT HIGH TEMP	S291	CN1	Condensor 1 Fail
S262	WHE	Working hours exceeded	S292	CN2	Condensor 2 Fail
S263	SMO	Smoke detected	S293	EFF	EC Fan fail
S264	WUF	Water under floor	S294	HST	High supply air temperature
S265	CPH	Condenser pump high water	S295	LST	Low supply air temperature

### 5.7.7 CALIBRATION

The CALIBRATION menu can calibrate sensors by setting offsets. The parameters are listed in Table 5-26. The parameters are in pairs: the former is the calibrated value and the latter is the calculated value, or the sum of the measured value and the calibrated value. This value is engaged in the calculation of control need.

Table 5-26 Descriptions of CALIBRATION parameters

Parameters		Default	Description
S602	RTN TEMP	K	Calibrated return air temperature. It can be set as a positive or negative value. Use the up and down buttons to change the setting value, 0.1K at each step
S603	CAL TEMP	25°C	Sum of the calibrated value and measured return air temperature. This value is compared with the setting value as the system actual temperature and is engaged in the calculation
S604	RTN HUM	+0.0%	Calibrated return air humidity. It can be set as a positive or negative value. Use the up and down buttons to change the setting value, 1% at each step
S605	CAL HUM	44.0%	Sum of the calibrated value and measured return air humidity. This value is compared with the setting value as the system actual humidity and is engaged in the calculation
S606	DS1 NTC	+0.0K	Calibrated digital scroll 1NTC. It can be set as a positive or negative or positive value. Use the up and down buttons to change the setting value, 0.1K at each step
S607	CAL DS1	29°C	Sum of the calibrated value and return air humidity measured by digital scroll 1NTC sensor. This value is engaged in the calculation
S608	DS2 NTC	+0.0K	Calibrated digital scroll 2NTC. It can be set as a positive or negative value. Use the up and down buttons to change the setting value, 0.1K at each step
S609	CAL DS2	25°C	Sum of the calibrated value and return air humidity measured by digital scroll 2NTC sensor. This value is engaged in the calculation
S610	OUT SNS	°C	Outdoor Sensor
S611	CAL OUT	+0.0K	Calibrated Outdoor Sensor
S613	TEMP A	+0.0K	Calibrated value of temperature sensor A
S614	CAL A	°C	Calculated value corresponding to temperature sensor A
S615	HUM A	+0.0%	Calibrated value of humidity sensor A
S616	CAL A	44.0%	Calculated value corresponding to humidity sensor A
S617	TEMP B	TH	Calibrated value of temperature sensor B
S618	TYPE B	+0.0K	Type of temperature sensor B
S619	CAL B	°C	Calculated value corresponding to temperature sensor B
S620	HUM B	+0.0%	Calibrated value of humidity sensor B
S621	CAL B	44.0%	Calculated value corresponding to humidity sensor B
S622	TYPE C	TH	Type of temperature sensor C
S624	FC SNSR	-	Free cooling temperature sensor. PTC or NTC sensor can be configured according to the actual configuration
S625	FC SNSR	+0°C	Calibrated value of free cooling temperature sensor
S626	CAL FC	°C	Calculated value of free cooling temperature sensor
S627	SUP SNSR	NTC	Air supply temperature sensor. PTC or NTC sensor can be configured
S628	SUP TEMP	+0.0K	Calibrated value of air supply temperature sensor
S629	CAL SUP	°C	Calculated value of air supply temperature sensor
S630	TEMP C	+0.0K	Calibrated value of temperature sensor C
S631	CAL C	°C	Calculated value of temperature sensor C
S632	HUM C	+0.0%	Calibrated value of humidity sensor C
S633	CAL C	%	Calculated value of humidity sensor C

### 5.7.8 NETWORK SETUP

The NETWORK SETUP menu is used to set the parameters when the system is in a network subject to the monitoring of a host. See Table 5-27 for parameter descriptions.

Table 5-27 Descriptions of NETWORK SETUP parameters

Parameters		Default	Setting range	Description
S802	#UNITS	1	1 ~ 32	Range: 1 ~ 32
S803	TEAMWORK	No	No, 1, 2	Range: No, 1, 2

Parameters		Default	Setting range	Description
S824	MON ADD	3	1 ~ 99	Monitoring address No. of the unit
S825	MON T.O.	No	No, 1, 2	Monitoring Timeout
S825	MON H.S.	3	1 ~ 99	Monitoring Handshake
S831	CS CTRL	No	Save, Load, No	Save the parameter set through MON ADD to the iCOM controller. 'No' means not saved
S831	CS STAT	Change	Change, Valid	Indication of the saving state of the parameter set through MON ADD. 'Change' means that the parameter is changed but not saved. 'Valid' means that the setting is valid and saved
S832	NW CTRL	No	Save, Load, No	Save the parameter set through U2U GRP to the iCOM controller. 'No' means not saved
S832	NW STAT	Valid	Change, Valid	Indication of the saving state of the parameter set through U2U GRP. 'Change' means that the parameter is changed but not saved. 'Valid' means that the setting is valid and saved
S835	MON PROT	Vlcty	Vlcty, HN, IGM, No	Host monitoring protocol setting. Range: Vlcty (Velocity uses intelligent card), HN (Hironet), IGM (ECA2), No
S836	IP #1	192	-	Set IP address
S836	IP #2	168		
S836	IP #3	254		
S836	IP #4	1		
S837	NM #1	255	-	Set subnet mask
S837	NM #2	255		
S837	NM #3	255		
S837	NM #4	0		
S838	GW #1	0	-	Set gateway address
S838	GW #2	0		
S838	GW #3	0		
S838	GW #4	0		
S840	U2U PROT	GBP	-	-
S841	U2U ADD	3	-	Group address No. of this unit
S842	U2U GRP	1	-	-
S843	BL CTRL	No	S + R, No	Boot program variant load. Saving the change of S835 ~ S841 needs the S + R command of this parameter. The system will reset after the saving, and configure according to the new parameters
S843	BL STAT	Change	Change, Valid	Indication of whether or not the parameters set through S835 ~ S841 are saved. 'Change' means that the parameter is changed but not saved. 'Valid' means that the setting is valid and saved
S844	SR CTRL	No	C + R, No	Static RAM data reset control. If the change of S835 ~ S841 are not saved, using the C + R command in this parameter can restore S835 ~ S841 to their original settings, and the system will reset afterwards
S844	SR STAT	Valid	-	STD
SW#		-	-	Version No. of the control software
MAC		00:00:68:19:31:70	00:00:68:19:31:70	MAC address of the network card of the iCOM controller
NAME		UNIT	UNIT	Name of the unit. By default: UNIT. You can change the name as you need

### 5.7.9 OPTIONS SETUP

The OPTIONS SETUP menu is used to set the parameters according to the equipment-specific demands. See Table 5-28 for detailed descriptions.

Table 5-28 Descriptions of OPTIONS SETUP parameters

Parameters		Default	Setting range	Description
S402	COMP SEQ	Auto	Auto, 1 (compressor 1 being the primary one)	Compressor sequence. Range: Auto, 1 (compressor 1 being the primary one), 2 (compressor 2 being the primary one)

Parameters		Default	Setting range	Description
			primary one), 2 (compressor 2 being the primary one)	
S403	LP DELAY	1min	-	Low pressure alarm delay
S405	EL HEAT	1	0 ~ 3	Electric heating stages
S406	EL HEAT C	-	-	-
S407	HW HEAT	No	Yes, No	Hot water heating enabled
S408	ALL HEAT	3	0 ~ 3	heating stages.
S409	LWDconn	No	Yes, No	LWD connected. Range: Yes (water low sensor connected), No (water low sensor not connected)
S409	V_CTRL	Time	Time, Feedback	-
S410	3P RUN	165s	-	3P actuator runtime
S411	3P DIR	DIR	DIR, REV	3P actuator direction
S413	HUM ENAB	Yes	Yes, No	Humidification enabled
S414	IR FLUSH	150%	-	Infrared flush rate
S415	HUMSTEAM	%	-	-
S416	HUM CONT	On, Off	On, Off, Prop	Humidifier control mode
S417	HUM.TIME	s	-	Humidifier bottle flush time
S418	HUM.MAN	Yes	Yes, No	Humidifier bottle manual flush enabled
S419	DEHUM EN	Yes	Yes, No	Dehumidification enabled.
S420	REST EN	Yes	Yes, No	Auto restart enabled
S421	RESTART	s	-	Unit auto restart time
S422	ONOFF EN	Yes	Yes, No	On-off key enabled. If “no” is selected, the ON/OFF key cannot be used to perform on/off operation on the machine.
S424	CW FLUSH	0hr	-	Cooling water auto flush time, unit: hr (hour)
S425	FC FLUSH	0hr	-	Free cooling auto flush time, unit: hr (hour)
S426	HT FLUSH	0hr	-	Hot water auto flush time, unit: hr (hour)
S427	BALL OFF	+0.0br	-	-
S428	HEAT AS	-	-	-
S429	CW_CTRL	-	-	-
S430	MAIN V	-	-	-
S431	VALV ROT	-	-	-
S432	VALV TIM	-	-	-
S433	DEHUM OP	-	-	-

### 5.7.10 SERVICE INFO

The SERVICE INFO menu provides the contact information of maintenance personnel. The maintenance personnel can input and save their contact information through this submenu.

## 5.8 ADVANCED MENUS

The ADVANCED MENUS include PASSWORD LEVEL, FACTORY SETUP and PASSWORDS, as shown in Figure 5-10.




Figure 5-10 ADVANCED MENUS

### 5.8.1 PASSWORD LEVEL

It is operated by Emerson service personnel.

## 5.8.2 FACTORY SETUP

The FACTORY SETUP menu is displayed in nine pages. The parameters are described in Table 5-29 ~ Table 5-38.

### Unit code related settings

Table 5-29 Descriptions of unit code related settings

Parameters (1/9)		Default	Setting range	Description
A003	UC 01	0	-	Unit code setting. The code has 18 bits. Each bit can be set as 0 ~ 20
...	...	...		
A003	UC 06	0		
A005	UC 07	0		
...	...	...		
A005	UC 12	0		
A007	UC 13	0		
...	...	...		
A007	UC 18	0		
A008	UC CTRL	No	Save, Load, Compare, No	Options include: Save: after UC01 ~ UC18 are changed, the changed can be saved through the save command. Load: load parameters to the unit code directly. Compare: compare the present parameters and the parameters to be loaded. No: All changes are cancelled. Keep the old parameters
A009	UC STAT	OK	Not available, Invalid, OK, Changed, Updating	Unit code status. Range: Not available: parameters set through UC01 ~ UC18 are unavailable. Invalid: parameters set through UC01 ~ UC18 are invalid. OK: parameters set through UC01 ~ UC18 are effective. Changed: parameters UC01 ~ UC18 are changed, but not saved. Updating: parameters are updating
A010	EL CTRL	Load	-	External data can be loaded through the load command
A011	EL STAT	OK	Not available, Invalid, OK, Changed, Updating	Exception list status. Range: Not available: parameters set through UC01 ~ UC18 are unavailable. Invalid: parameters set through UC01 ~ UC18 are invalid. OK: parameters set through UC01 ~ UC18 are effective. Changed: parameters UC01 ~ UC18 are changed, but not saved. Updating: parameters are updating

### System related settings

Table 5-30 Descriptions of system related settings

Parameters (2/9)		Default	Setting range	Description
A102	REFRIG	R22	R407C, R22, R410A	Refrigerant type selection
A103	MOTOR OL	SHUTD	SHUTD, DISAB	Main fan overload. The action to take after the fan overload. Range: SHUTD (fan shuts down), DISAB (shut down humidifier, dehumidifier and heater, only keep the cooling unit running)
A104	AIR LOSS	SHUTD	SHUTD, DISAB	The action to take after the loss of airflow. Range: SHUTD (fan shuts down), DISAB (shut down humidifier, dehumidifier and heater, only keep the cooling unit running)
A105	# COMP	0	0 ~ 2	Number of compressors
A106	COMP DLY	s	-	Compressor delay time
A107	COMP ON	min	0 ~ 5min	Compressor minimum on time
A108	COMP OFF	3min	0 ~ 5min	Compressor minimum off time
A109	PUMPDOWN	Yes	Yes, No	Pump down enable

A110	CAP TYPE	No	4step, HGBP, DS, DS + TH, No	Capacity control type. 4step: four steps. HGBP: hot gas bypass. DS: digital scroll. DS + TH: digital scroll and temperature switch. No: with no need for capacity control type
A111	FLOCT	0s	0 ~ 180s	Shutdown time of airflow loss

### Other settings

Table 5-31 Descriptions of other settings

Parameters (3/9)		Default	Setting range	Description
A113	DS CYCLE	s	-	Digital scroll cycle
A114	DS HT	°C	-	Digital scroll high temperature
A115	DS SWB	°C	-	Digital scroll switchback
A116	LP TYPE	Analog	Analog, Digital	Low pressure device type
A117	LP PH1	ps	-	Low pressure threshold phase 1
A118	LP PH2	ps	-	Low pressure threshold phase 2
A119	LC PRE	0.0s	-	Liquid control pre-time
A120	LC POST	0.0s	-	Liquid control post-time
A121	CHARGE P	br	-	Loss of Charge Protection

## LP sensor related settings

Table 5-32 Descriptions of LP sensor related settings

Parameters (4/9)		Default	Setting range	Description
A124	LP1 LOW	10%	0 ~ 100%	LP1 sensor lower threshold (percentage)
A124	LP1 LOW	0bbr	10 ~ 50br	LP1 sensor lower threshold
A125	LP1 HIGH	90%	0 ~ 100%	HP1 sensor lower threshold (percentage)
A125	LP1 HIGH	10.3br	10 ~ 50br	HP1 sensor lower threshold
A126	LP1 ACT	-	-	Actual LP1 signal. Read only
A127	LP2 LOW	10%	0 ~ 100%	LP2 sensor lower threshold (percentage)
A127	LP2 LOW	0br	10 ~ 50br	LP2 sensor lower threshold
A128	LP2 HIGH	90%	0 ~ 100%	HP2 sensor lower threshold (percentage)
A128	LP2 HIGH	10.3br	10 ~ 50br	HP2 sensor lower threshold
A129	LP2 ACT	-	-	Actual LP2 signal. Read only
A130	PD CUT	br	-	Pumpdown cutout
A131	PD RECYC	br	-	Pumpdown recycle
A132	HEAT REJ	W/G	FSC, L-T, W/G	Heat rejection control. Range: FSC: fan speed control; L-T: Lee-Temp; W/G: water/glycol cooling

## Free-cooling, HG and HW related settings

Table 5-33 Descriptions of free-cooling, HG and HW related settings

Parameters (5/9)		Default	Setting range	Description
A135	K11 ACT	DEH	WNG, DEH, NOP, FC	-
A136	C/W F DUR	3min	1min ~ 3min	Cooling water flush duration
A137	COOL TYP	SINGL	Singl, FC, DC	Three cooling type
A138	STOP FC+	°C	-	Stop FC at setpoint + or value
A139	FC F DUR	0min	1min ~ 3min	Freecooling flush duration
A140	FC F K11	Yes	Yes, No	Freecooling flush starts R5
A141	COMP + FC	No	Yes, No	Compressor plus FC simultaneously
A142	HW F DUR	3min	0 ~ 3min	Hot water flush duration
A143	HG HEAT	No	Comp.1, Comp.2, No	Hot gas heating enabled
A144	HEAT OP	STAGE	Stage, Delay, No	Electric heater operation mode

## Humidification and dehumidification related settings

Table 5-34 Descriptions of humidification and dehumidification related settings

Factory 6/9		Default	Setting range	Description
A146	HUM TYPE	IFS	External, IFS, IFL, PEX6, PEX9, PEX12, 21LLA, 53LLC, 53HLB, 93LLE, 93HLD, d3H, HT2, HT5, HT9, SGH, No	Humidifier model
A147	HUM VOLT	V	-	-
A148	HUM LAST	15hr	-	Detect whether the last operation time exceeds this cycle setting during the startup of the humidifier. Unit: hr
A149	PREFILL	30s or 57s	-	Prefill time. Unit: second
A150	FILL	57s	-	Fill time. Unit: second
A151	HUM ON	584s	-	Humidifier on time. Unit: second
A152	DEH COMP	1	1, 2, both	Dehumidification with compressor. When 1 or 2 is selected, compressor 1 or 2 is used for dehumidification. When Both is selected, the two compressors are both used for dehumidification

Analog output related settings

Table 5-35 Descriptions of analog output related settings

Factory 7/9		Default	Setting range	Description
A157	ANOUT1LO	0%	0 ~ 100%	-
A157	ANOUT1HI	100%	0 ~ 100%	
A158	ANOUT2LO	0%	0 ~ 100%	
A158	ANOUT2HI	100%	0 ~ 100%	
A159	ANOUT3LO	0%	0 ~ 100%	
A159	ANOUT3HI	100%	0 ~ 100%	
A160	ANOUT4LO	0%	0 ~ 100%	
A160	ANOUT4HI	100%	0 ~ 100%	
A161	FS HE/HU	100%	0 ~ 100%	
A163	ANOUT1	No	-	
A164	ANOUT2	No	-	
A165	ANOUT3	No	-	
A166	ANOUT4	No	-	

Table 5-36 Descriptions of analog output options

Options	Description	Options	Description
CW010	CW/FC 0 ~ 10V	ALBD2	AlarmBoard 2
HW	Hot water	ALBD3	AlarmBoard 3
HW175	Hot water 1.75	IVAR	I-Variex 1
VSD	Variable fan speed drive	HUM%	HT HUM
COOL	Cooling	SUP	Supply Temperature
CV175	CW/FC 1.75	RET	Return Temperature
COOL1	Cooling 1	HUMI	Humidifier
COOL2	Cooling 2	SUPSA	Supersaver
HEAT	Heater	INVCO	Inverted Cool
No	No use	HEAT3	Heating 33%
MBV1	Motorized ball vavle1	CW210	CW/FC 2V ~ 10V
MBV2	Motorized ball vavle 2	C2010	CW2 0 ~ 10V
SCR	Silicon controlled rectifier	C2175	CW2 1.75
CONF	Configurable	C2210	CW2 2 ~ 10V
ALBD1	AlarmBoard 1		

Analog action related settings

Table 5-37 Descriptions of analog action related settings

Parameters (8/9)		Default	Setting range	Description
A168	AO1 STA	0%	0% ~ 100%	Analog output 1 start percentage
A168	AO1 STA	0V	0V ~ 10V	Analog output 1 start voltage
A169	AO1 END	100%	0% ~ 100%	Analog output 1 end percentage
A169	AO1 END	10V	0V ~ 10V	Analog output 1 end voltage
A170	AO2 STA	0%	0% ~ 100%	Analog output 2 start percentage
A170	AO2 STA	0V	0V ~ 10V	Analog output 2 start voltage
A171	AO2 END	100%	0% ~ 100%	Analog output 2 end percentage
A171	AO2 END	10V	0V ~ 10V	Analog output 2 end voltage
A172	AO3 STA	0%	0% ~ 100%	Analog output 3 start percentage
A172	AO3 STA	0V	0V ~ 10V	Analog output 3 start voltage
A173	AO3 END	100%	0% ~ 100%	Analog output 3 end percentage
A173	AO3 END	10V	0V ~ 10V	Analog output 3 end voltage
A174	AO4 STA	0%	0% ~ 100%	Analog output 4 start percentage
A174	AO4 STA	0V	0V ~ 10V	Analog output 4 start voltage
A175	AO4 END	100%	0% ~ 100%	Analog output 4 end percentage
A175	AO4 END	10V	0V ~ 10V	Analog output 4 end voltage

LL related settings

Table 5-38 Descriptions of LL related settings

Parameters (9/9)		Default	Setting range	Description
A179	LL1 LOW	%	0 ~ 100%	HPT1 low limit percentage setting
A179	LL1 LOW	br	10.0 ~ 50.0br	HPT1 low limit setpoint
A180	LL1 HIGH	%	0 ~ 100%	HPT1 high limit percentage setting
A180	LL1 HIGH	br	10.0 ~ 50.0br	HPT1 high limit setpoint
A181	LL1 ACT	%	-	HPT1 actual percentage, read only
A182	LL1 ACT	br	-	HPT1 actual value, read only
A183	LL2 LOW	%	0 ~ 100%	HPT2 low limit percentage setting
A183	LL2 LOW	br	10.0 ~ 50.0br	HPT2 low limit setpoint
A184	LL2 HIGH	%	0 ~ 100%	HPT2 high limit percentage setting
A184	LL2 HIGH	br	10.0 ~ 50.0br	HPT2 high limit setpoint
A185	LL2 ACT	%	-	HPT2 actual percentage, read only
A186	LL2 ACT	br	-	HPT2 actual value, read only

### 5.9 MBV Settings

Through the ADVANCED MENUS screen (see Figure 5-11), you can view the current status of the cooled valve. MBV menu is displayed in six pages, and the description of the menus is listed in Table 5-39.




Figure 5-11 ADVANCED MENU screen

Table 5-39 MBV settings

Parameters		Default	Range	Description
A403	UNIT HI PRESS	-	-	Unit high pressure
A404	MBV OP PRESS	-	-	MBV control available pressure
A405	MBV POSITION	-	-	MBV position
A406	ACTIVE OFFSET	-	-	Active offset
A408	MBV PHASE	-	-	-
A409	COMPR LP PHASE	-	-	-
A410	MBV PRESS READ	-	-	-
A411	MBV POSITION SET	-	-	-
A414	START OFFSET	-	-	-
A415	MAX OFFSET STEP	-	-	-
A416	SERVICE OFFSET	-	-	-
A417	START DELAY	-	-	-
A418	STOP DELAY	-	-	-
A419	4ST OPEN PRESET	-	-	-
A420	4ST CLOSE PRESET	-	-	-
A424	MBV REINT	-	-	-
A425	READ INTERVAL	-	-	-
A426	DIG SCROLL FILTER	-	-	-
A427	4ST-30SEC LOADING	-	-	-
A428	PUMPDOWN PRESS	-	-	-

Parameters		Default	Range	Description
A431	REPOSITION COUNTER	-	-	MBV reposition counter
A432	REPOSITION COUNTER RESET	-	-	Reposition counter reset
A436	U4	-	-	U4 proportional band
A437	U3A	-	-	U3A proportional band
A438	U2A	-	-	U2A proportional band
A439	U1	-	-	U1 proportional band
A440	L1	-	-	L1 proportional band
A441	L2A	-	-	L2A proportional band
A442	L3	-	-	L3 default proportional band
A443	ACTIVE OFFSET	-	-	ACTIVE OFFSET
A444	4ST PHASHE	-	-	4ST PHASHE
A447	MAX	-	-	Max proportional band
A448	U4	-	-	U4 default proportional band
A449	U3A	-	-	U3A default proportional band
A450	U3B	-	-	U3B default proportional band
A451	U2A	-	-	U2A default proportional band
A452	U2B	-	-	U2B default proportional band
A453	U1	-	-	U1 default proportional band
A458	L1	-	-	L1 default proportional band
A459	L2A	-	-	L2A default proportional band
A460	L2B	-	-	L2B default proportional band
A461	L3	-	-	L3 default proportional band
A462	MIN	-	-	Min proportional band

## 5.10 EVENT NAME AND DEFINITION

See Table 5-40 for event name and definition.

Table 5-40 List of event name and definition

Event	Definition
General Alarm	General Alarm
COMP 1 HIGH PRESSURE	Compressor 1 high pressure
COMP 1 LOW PRESSURE	Compressor 1 low pressure
HIGH CW TEMP	Chilled water high temperature
LOSS OF CW FLOW	Loss of chilled water
EL HEAT HIGH TEMP	Electric heater high temperature
MAIN FAN OVERLOAD	Main fan overload
LOSS OF AIRFLOW	Loss of air flow
CLOGGED FILTERS	Clogged filters
CUSTOMER INPUT n (n = 1 ~ 4)	Customer input n (n = 1 ~ 4)
FC LOCKOUT	Free cooling lockout
LP Transducer 1 Fail	Low pressure transducer 1 fails
CALL SERVICE	Call for service
HIGH TEMPERATURE	High temperature alarm
LOSS OF AIR BLOWER 1	Loss of air blower 1
HIGH ROOM TEMP	High room temperature
LOW ROOM TEMP	Low room temperature
HIGH ROOM HUM	High room humidity
LOW ROOM HUM	Low room humidity
HIGH TEMP SENSOR A	High temperature of sensor A
LOW TEMP SENSOR A	Low temperature of sensor A
HIGH HUM SENSOR A	High humidity of sensor A
LOW HUM SENSOR A	Low humidity of sensor A
UNIT HRS EXCEEDED	Unit has exceeded operating time
COMP 1 HRS EXCEEDED	Compressor 1 has exceeded operating time limit
HUM HRS EXCEEDED	Humidifier has exceeded operating time limit
SUPPLY SENSOR FAILURE	Supply sensor failure

Event	Definition
DSCROLL 2 SENSOR FAIL	Digital scroll 2 sensor fails
ROOM SENSOR FAILURE	Room sensor failure
SENSOR A FAILURE	Sensor A failure
LP Transducer 2 Fail	Low pressure transducer 2 fails
NETWORK FAILURE	Network failure
Low Start Pressure 1	Alarm of low start pressure 1
UNIT ON	Unit on
UNIT OFF	Unit off
SLEEP MODE	Sleep mode
STANDBY MODE	Standby mode
POWER ON	Power on
POWER OFF	Power off
Unit n disconnected (n = 1 ~ 32)	Unit n disconnected (n = 1 ~ 32)
COMP 2 HIGH PRESSURE	Compressor 2 high pressure
COMP 2 LOW PRESSURE	Compressor 2 low pressure
COMP 2 HRS EXCEEDED	Compressor 2 has exceeded operating time limit
DSCROLL 1 SENSOR FAIL	digital scroll 1 sensor fails
FREECOOL TEMP SENSOR	Free cooling source sensor failure
Low Start Pressure 2	Alarm of low Start Pressure 2
ON-OFF KEY DISABLED	ON-OFFkey disabled
LWD SENSOR FAIL	Low water level sensor fails
WATER LEAKAGE	Water leakage alarm
Dummy 67	Dummy alarm 067
RAM / Battery Failure	RAM/battery failure
Low Memory 1	Low memory 1
NO CONNECTION w/Unit1	No connection with unit 1
COMP 1 OVERLOAD	Compressor 1 overload
COMP 2 OVERLOAD	Compressor 2 overload
WRONG DAMPER POSITION	Wrong damper position
Dummy 074	Dummy alarm 074
HP 1 SENSOR FAIL	High pressuresensor 1 fails
HP 2 SENSOR FAIL	High pressure sensor 2 fails
COMP POWER REDUCTION ACTIVE	Compressor power reduction active
NO POWER	No power
UNIT DISABLED	Humidification/heating disabled due to unit failure
UNIT SHUT DOWN	Unit shutdown due to failure
Low Coil Pressure 1	Low coil pressure 1
Low Coil Pressure 2	Low coil pressure 2
Low OP Pressure 1	Low op pressure 1
Low OP Pressure 2	Low op pressure 2
UNIT SYNCHRONISATION	Unit recovers online
HUMIDIFIER PROBLEM	Humidifier failure
REMOTE SHUTDOWN	Remote shutdown
DEHUM HRS EXCEEDED	Dehumidifier has exceeded operating time limit
FC HRS EXCEEDED	Free cooling source has exceeded operating time limit
C1 FREEZE PROTECTION	Compressor 1 freeze protection
COMP 1 PUMPDOWN FAIL	Compressor 1 pumpdown fails
MEMORY 1 FAIL	Memory 1 fail
MEMORY 2 FAIL	Memory 2 fail
HCb not connected	Humidifier control board not connected
BMS Disconnected	Battery management system disconnected
COMP 2 PUMPDOWN FAIL	Compressor 2 pumpdown fails
DIG SCROLL1 HIGH TEMP	Digital scroll 1 high temperature
DIG SCROLL2 HIGH TEMP	Digital scroll 2 high temperature
Dummy 099	Dummy alarm 099
RESERVED 100	Reserved 100
RESERVED 101	Reserved 101
RESERVED 102	Reserved 102

Event	Definition
Dummy 103	Dummy alarm 103
SMOKE DETECTED	Smoke detected
WATER UNDER FLOOR	Water leakage under floor
COND PUMP-HIGH WATER	Condensing pump high water level
LOSS OF FLOW	Loss of water flow
STBY GLYCOL PUMP ON	Standby glycol pump on
STANDBY UNIT ON	Standby unit on
HW/HG HRS EXCEEDED	Hot water/hot gas has exceeded operating time limit
EL HEAT1 HRS EXCEEDED	Electric heater 1 has exceeded operating time limit
EL HEAT2 HRS EXCEEDED	Electric heater 2 has exceeded operating time limit
EL HEAT3 HRS EXCEEDED	Electric heater 3 has exceeded operating time limit
UNIT CODE MISSING	Unit code missing
UNIT CODE n MISMATCH (n = 01 ~ 18)	Unit code n mismatch (n = 01 ~ 18)
FRONT DOOR OPEN	Front door not closed
REAR DOOR POEN	Rear door not closed
LOSS COMPRESSOR POWER	Loss of compressor power
CABINET SENSOR FAIL	Cabinet sensor fail
CABINET H-SENSOR FAIL	Cabinet H-sensor fail
EMERGENCY DAMPER FAIL	Emergency damper fails
HIGH CABINET TEMP	High cabinet temperature
LOW CABINET TEMP	Low cabinet temperature
HIGH EXT DEWPOINT	High external dewpoint
LOSS OF POWER	Loss of power
REHEAT LOCKOUT	Reheater lockout
HEAT REJ VFD	HEAT REJ VFD
HUMIDIFIER LOCKOUT	Humidifier lockout
HEAT REJ TVSS	HEAT REJ TVSS
COMPRESSOR (S) LOCKOUT	Compressor lockout
AMBIENT SENSOR FAIL	Ambient sensor fail
HUMIDIFIER LOW AMPS	Humidifier low current
COMP 1 SHORT CYCLE	Compressor 1 short cycle
COMP 2 SHORT CYCLE	Compressor 2 short cycle
HUMIDIFIER HIGH AMPS	Humidifier high current
HUMIDIFIER LOW WATER	Humidifier low water level
SYSTEM OFF REQUESTED	System off requested
SYSTEM OFF CONFIRMED	System off confirmed
C2 FREEZE PROTECTION	Compressor 2 freeze protection
FIRE ALARM	Fire alarm
HEATERS OVERHEATED	Heaters overreheated
CONDENSER 1 FAILURE	Condenser 1 failure
CONDENSER 2 FAILURE	Condenser 2 failure
HUM CYLINDER WORN	Humidifier cylinder worn
FC STOPPED FOR 1 HOUR	Free cooling stopped for 1 hour
MAINTENANCE DONE	Maintenance done
MAINTENANCE NEEDED	Maintenance needed
REDUCED ECO AIRFLOW	Reduced eco airflow
LOSS OF FLOW PUMP 1	Loss of flow pump 1
LOSS OF FLOW PUMP 2	Loss of flow pump 2
COMP 3 HIGH PRESSURE	Compressor 3 high pressure
COMP 4 HIGH PRESSURE	Compressor 4 high pressure
CONDENSATION DETECTED	Condensation detected
COMP 1 LOW PRESSURE	Compressor 1 low pressure
HIGH REF TEMPERATURE	High refrigerant temperature
LOW REF TEMPERATURE	Low refrigerant temperature
REFRIGERANT SENSOR FAIL	Refrigerant sensor fail
HIGH TEMP SENSOR B	High temperature sensor B
LOW TEMP SENSOR B	Low temperature sensor B
COMP 2 LOW PRESSURE	Compressor 2 low pressure

Event	Definition
SENSOR B FAILURE	Sensor B failure
COMP 3 SHORT CYCLE	Compressor 3 short cycle
COMP 4 SHORT CYCLE	Compressor 4 short cycle
HIGH DEWPOINT	High dewpoint
PUMP SHORT CYCLE	Pump short cycle
Top Fan Failure	Top fan failure
CONTROL VALVE FAILURE	Control valve failure
PUMP 1 HRS EXCEEDED	Pump 1 has exceeded operating time limit
PUMP 2 HRS EXCEEDED	Pump 2 has exceeded operating time limit
COMP 3 HRS EXCEEDED	Compressor 3 has exceeded operating time limit
COMP 4 HRS EXCEEDED	Compressor 4 has exceeded operating time limit
TANDEM 1 PUMPDOWN FAIL	Tandem 1 pumpdown fail
TANDEM 2 PUMPDOWN FAIL	Tandem 2 pumpdown fail
TANDEM 1 LOW PRESSURE	Tandem 1 low pressure
TANDEM 2 LOW PRESSURE	Tandem 2 low pressure
HIGH FLUID TEMPERATURE	High fluid temperature
LOW FLUID TEMPERATURE	Low fluid temperature
FLUID SENSOR FAILURE	Fluid sensor failure
FAN FAILURE	Fan failure
FEEDBACK SIGNAL 1 FAILURE	Feedback signal 1 failure
SUPPLY CW SENSOR FAILURE	Supply chilled water sensor failure
RETURN CW SENSOR FAILURE	Return chilled water sensor failure
SUPPLY REF SENSOR FAILURE	Supply refrigerant sensor failure
RETURN REF SENSOR FAILURE	Return refrigerant sensor failure
VALVE HRS EXCEEDED	Valve has exceeded operating time limit
COMP 1A HIGH PRESSURE	Compressor 1A high pressure
COMP 1B HIGH PRESSURE	Compressor 1B high pressure
COMP 2A HIGH PRESSURE	Compressor 2A high pressure
COMP 2B HIGH PRESSURE	Compressor 2B high pressure
COMP 1A HRS EXCEEDED	Compressor 1A has exceeded operating time limit
COMP 1B HRS EXCEEDED	Compressor 1B has exceeded operating time limit
COMP 2A HRS EXCEEDED	Compressor 2A has exceeded operating time limit
COMP 2B HRS EXCEEDED	Compressor 2B has exceeded operating time limit
COMP 1A SHORT CYCLE	Compressor 1A short cycle
COMP 1B SHORT CYCLE	Compressor 1B short cycle
COMP 2A SHORT CYCLE	Compressor 2A short cycle
COMP 2B SHORT CYCLE	Compressor 2B short cycle
HIGH SUPPLY TEMPERATURE	High supply temperature
LOW SUPPLY TEMPERATURE	Low supply temperature
HIGH RETURN HUMIDITY	High return humidity
LOW RETURN HUMIDITY	Low return humidity
NOISE RED MODE STARTED	Noise reduced mode started
NOISE RED MODE STOPPED	Noise reduced mode stopped
RACK SENSOR 1~10 FAILURE	Rack sensor 1 ~ 10 failure
HIGH RETURN TEMPERATURE	High return temperature
ROOM HUMIDITY PROBLEM	Room humidity problem
iCOM-DO #0 ~ #2 DISCONNECTED	iCOM-do #0 ~ #2 disconnected
FEEDBACK SIGNAL 2 FAILURE	Feedback signal 2 failure
BOTTOM FAN FAILURE	Bottom fan failure
EC FAN FAULT	EC fan fault

## Chapter 6 Application Of INTELLISLOT

This chapter introduces the application of the host communication component INTELLISLOT, including the introduction, installation and commissioning of the host communication card.

### 6.1 Introduction Of Host Communication Card

The chilled water series air conditioner supports two communication cards below:

#### 1. TCP/IP communication card

The TCP/IP communication card is shown in Figure 6-1. This card can provide network port, MIB library and browse the data through IE.




Figure 6-1 TCP/IP communication card

#### 2. 485 communication card

The 485 communication card is shown in Figure 6-2. This card can provide the Modbus protocol of the RS485 port to the host.




Figure 6-2 485 communication card

## 6.2 Installing Host Communication Card

### Installing communication card

The chilled water series air conditioner units have been equipped with installation boxes 1 and 2. If you want to install the host communication configuration, insert the communication card into the installation box 1 and tighten the bolts as shown in Figure 6-3.




Figure 6-3 Installing communication card

### Connection

The electrical schematic figure of the host communication configuration is shown in Figure 6-4. P61, P65 and P67 cables have been connected in factory. So you should only connect the communication card to the monitoring center.




Figure 6-4 Electrical schematic figure of host communication configuration

## 6.3 Commissioning Host Communication Component

After the communication cable is connected, you can start to set the HyperTerminal and communication card parameters.

### Note

Before commissioning, you must access the 'SERVICE Menus' of the iCOM control board to set **S824 MON ADD** as '3', **S835 MON PORT** as 'Vlcty(Velocity)' and **S843 BL CTRL** as 'S+R' in the "Network Setup".

### 6.3.1 Setting HyperTerminal

The 485 communication card and TCP/IP communication card must be set for communicating with the host monitoring system. Use the communication cable provided together with the communication card to connect the RS232 port of the computer and the console port of the communication card and then set the parameters using the HyperTerminal of Windows. The detailed setting procedures are as follows:

1. Click Start-> Programs -> Accessories -> Communications -> HyperTerminal, the HyperTerminal interface will pop up, as shown in Figure 6-5. Type the name 'tt' in the Name field, and then click the OK button.




Figure 6-5 Typing the name

2. In the Connect To dialog box, choose the serial port being used (such as 'COM1'), and click the OK button, as shown in Figure 6-6.



Figure 6-6 Choosing serial port

3. Set the communication parameters shown in Figure 6-7 and click the OK button.




Figure 6-7 Setting port property

### 6.3.2 Setting 485 Communication Card

Set the parameters of the 485 communication card according to the following procedures:

1. After setting the HyperTerminal, click the OK button, the following interface will appear.

```
Emerson Network Power OpenComms 485
Discovering Device...

Main Menu
-----
1: 485 Network Settings
2: Factory Settings
3: Firmware Updates
4: Device Connection State

q: Quit and abort changes
x: Exit and save

Please select a key ?>
```

2. Type '1' and the interface shown in the following figure will appear.

```
Emerson Network Power OpenComms 485
Discovering Device...

485 Network Settings Menu
-----
1: Enabled Application      Modbus Server
2: Control                  enabled
3: Server ID                1
4: Communications Rate     9600

<ESC>: Cancel menu level

Please select a key ?> _
```

3. Type '1' and the interface shown in the following figure will appear.

```
Valid Selections:
-----
1. Modbus Server
2. IGMNet Server

Select Auxiliary Com Port Application: ( <Esc> - Cancel) ?>
```

4. Type '1' and select Modbus protocol, the interface shown in the following figure will appear.

```
Emerson Network Power OpenComms 485
Discovering Device...

485 Network Settings Menu
-----
1: Enabled Application      Modbus Server
2: Control                  enabled
3: Server ID                2
4: Communications Rate     9600

<ESC>: Cancel menu level

Please select a key ?> 3
```

5. Type '3' and select the ID used to communicate between the communication card and the host, the interface shown in the following figure will appear.

```
Enter the server ID (1 - 255) ?>
```

6. Type the server ID under the command prompt, the interface shown in the following figure will appear.

```
Emerson Network Power OpenComms 485
ICOM Environmental Control

485 Network Settings Menu
-----
1: Enabled Application      Modbus Server
2: Control                 enabled
3: Server ID               2
4: Communications Rate     9600

<ESC>: Cancel menu level
Please select a key ?> 4
```

7. Type '4' and the interface shown in the following figure will appear.

```
Valid Selections:
-----
1. 9600
2. 19200
3. 38400
Select BaudRate: ( <Esc> - Cancel ) ?>
```

8. Type '1', '2' or '3' to select the baud rate, and the interface shown in the following figure will appear.

```
Emerson Network Power OpenComms 485
ICOM Environmental Control

Main Menu
-----
1: 485 Network Settings
2: Factory Settings
3: Firmware Updates
4: Device Connection State

q: Quit and abort changes
x: Exit and save

Please select a key ?>
```

9. Press the Esc button to exit and return the main interface. If you type 'x', the setting can be saved. After saving, the 485 communication card will be restarted.

10. On the main interface, type '4', and you can check whether the communication status between the communication card and the chilled water series air conditioner is normal, as shown in the following figure.

Device Connection State		
Stage	Status	Details
00:01:04 (SysUpTime)		
Discovering Communication Protocol	Complete	VELOCITY
Discovering Device	Complete	ICOM Environmental Control
Reading Device Information	Complete	100 %
Launching Services	Complete	100 %
Running Application	00:00:57 (SysUpTime)	
Connection Count	1	

### 6.3.3 Setting TCP/IP Communication Card

Set the parameters of the TCP/IP communication card according to the following procedures:

1. After the HyperTerminal is set, you can click the OK button, the interface shown in the following figure will appear.

```

Emerson Network Power OpenComms WEB
Discovering Device...

Main Menu
-----
1: System Information
2: IP Network Settings
3: Factory Settings
4: Firmware Updates
5: Device Connection State

q: Quit and abort changes
x: Exit and save

Please select a key ?>

```

2. Type '2' and the interface a shown in the following figure will appear.

```

Emerson Network Power OpenComms WEB
ICOM Environmental Control

IP Network Settings Menu
-----
1: Boot/IP Settings
2: SNMP Communications
3: Web Server
4: Telnet Server
5: Change Username/Password

<ESC>: Cancel menu level

Please select a key ?> _

```

3. Type '1' and the interface shown in the following figure will appear.

Normally, the Boot mode should be set to Static. If the user network can distribute the address automatically, select DHCP, and the IP address, netmask and gateway do not need to be set. Type '3', '4' and '5' and then type the corresponding IP address, netmask and gateway respectively. These three parameters should be given by the user.

```

Emerson Network Power OpenComms WEB
ICOM Environmental Control

Boot/IP Settings Menu
-----
1: Speed/Duplex      Auto
2: Boot mode         Static
3: IP Address        142.100.8.35
4: Netmask           255.255.254.0
5: Default Gateway  142.100.8.1

<ESC>: Cancel menu level

Please select a key ?>

```

4. Press Esc button to exit and return to the main interface, as shown in the following figure. If you type 'x', the setting can be saved. After saving, the TCP/IP communication card will be restarted.

```

Emerson Network Power OpenComms WEB
Discovering Device...

Main Menu
-----
1: System Information
2: IP Network Settings
3: Factory Settings
4: Firmware Updates
5: Device Connection State

q: Quit and abort changes
x: Exit and save

Please select a key ?>

```

5. On the main interface, type '5', and then you can check whether the communication status between the communication card and the chilled water series air conditioner is normal, as shown in the following figure.

Device Connection State		
Stage	Status	Details
00:11:14 (SysUpTime)		
Discovering Communication Protocol	Complete	VELOCITY
Discovering Device	Complete	ICOM Environmental Control
Reading Device Information	Complete	100 %
Launching Services	Complete	100 %
Running Application	00:01:09 (SysUpTime)	
Connection Count	1	

### 6.3.4 Setting SNMP Parameters Of TCP/IP Communication Card

After the HyperTerminal of the TCP/IP communication card is set, you can set the parameters for this communication card. See the following for details:

1. Type the IP address of the TCP/IP communication card in the address bar of IE browser. If the interface shown in Figure 6-8 appears, it indicates that the communication between the communication card and the iCOM controller is abnormal. If the State is Completing or In Process, it indicates that the communication card is communicating with the iCOM controller.



The web card is attempting to establish a communication link to the Liebert device.

Phase	State	Detail
Discovering Communication Protocol	Pending	VELOCITY
Discovering Device	Pending	
Reading Device Information	Pending	0% Complete
Launching Services	Pending	0% Complete

Connection Count: 0

If this message appears for more than 3 minutes it may indicate a communication problem, and may require service assistance. Please verify wiring and consult the troubleshooting section of your user's manual.

If further assistance is necessary, visit [Liebert.com](http://Liebert.com).

Last updated: Monday - July 28, 2008 10:19:35am

Figure 6-8 Initial interface (1)

After normal communication, the interface shown in Figure 6-9 will appear.




Figure 6-9 Initial interface (2)

2. Click the configure tab to enter the configuration interface, as shown in Figure 6-10.



Figure 6-10 Configuration interface

3. Click the **Access on SNMP** at the left hand of the interface, as shown in Figure 6-11. Type user name 'Liebert' and password 'Liebert' and click the **OK** button to enter the setting interface of configure. Note that the user name and password are case-sensitive.




Figure 6-11 Typing user name and password

4. Configure the **Network Management System (NMS)** of the host monitoring center in Figure 6-12. Click the **Edit** button and type the IP address of the NMS in **IP Address**. Select the 'read' or 'write' in **Access**, type 'Public' in **Community** and then click the **Save** button.

**Note**

1. Before setting the NMS, the **Edit** button is displayed in the interface. After editing the configuration, the **Edit** button will become the **Save** button.
2. After the NMS is configured, you must click the **Save** button to save the setting.




Figure 6-12 NMS configuration interface of SNMP host monitoring center (1)

5. Unfold the SNMP at the left hand of the interface as shown in figure 6-13 and click Traps to set IP Address, Port and Community of the NMS for receiving Traps. After modifying, you must click Save to save the setting.




Figure 6-13 NMS configuration interface of SNMP host monitoring center (2)

## 6.4 Host Communication Networking Diagram

The networking figure of the TCP/IP communication card (SNMP protocol) is shown in Figure 6-14. The air conditioner number is not limited.




Figure 6-14 Networking figure of TCP/IP communication card

**Note**

The single unit does not need HUB.

The networking figure of the 485 communication card (Modbus protocol) is shown in Figure 6-15. Up to 32 air conditioner units can be connected.




Figure 6-15 Networking figure of 485 communication card

## Chapter 7 System Operation And Maintenance

### 7.1 System Diagnosis Test

#### 7.1.1 Self-diagnosis Function

As limited by the environmental conditions, certain components may remain idle for a long time, and there is no telling of whether they are faulty. However, upon urgent needs, such components may fail to meet the demand. Therefore it is necessary to check the system components regularly. The controller provides the function that enables you to turn on/off the components on site manually so as to check their functionality. For the operation instruction, see 5.7.5 *DIAGNOSTICS*.

---

 **Note**

1. During the operation of the chilled water series cooling system, lethal voltage may be present in the internal parts. It is a must to obey all the notes and warnings marked on the equipment or contained in this manual, otherwise injury or fatality may occur.
  2. Only qualified maintenance and repairing personnel can operate and process the system.
- 

#### 7.1.2 Electric Control Part

##### Electric maintenance

Carry out visual inspection and handling over the electrical connection by referring to the following items.

1. Overall electrical insulation test: find out the unqualified contacts and handle them. Note to disconnect the fuses or MCBs of the control part during the test lest the high voltage should damage the control components.
2. Carry out detection over the contactors before the power-on, make sure the contactors can act freely without obstruction.
3. Clean the electric and control components of dust with brush or dry compressed air.
4. Check the closing of contactors for arcs or signs of burning. Replace the contactor if necessary.
5. Fasten all the electric connection terminals.
6. Check that the sockets and plugs are in good condition. Replace those loosened ones.

##### Control maintenance

Carry out visual inspection, simple function test and handling over the control parts by referring to the following items.

1. Visually inspect the power transformers and isolation transformers and test the output voltage.
2. Check that there are no signs of aging on the control interface board, display control board, sensor board and fuse board.
3. Clean the electric control components and control board of dust and dirt with brush and electronic dust removing agent.
4. Check and fasten the I/O ports at the control interface board, including the connection between display control board and control interface board, as well as between the temperature/humidity sensor board and the interface board.
5. Check the connection between the user wiring terminals (37, 38) and the control interface board.
6. Check the output connection between the control interface board and the contactors, and the input connection between the control interface board and various components, including fan overload protector, heating over-temperature protection switch, humidifier dry-burn protection switch, humidifier top protection switch, filter clogging switch, fan air-flow safety switch and water flow control valve.
7. Replace the electric components that are detected faulty, such as faulty control fuses (or MCBs) and control boards.

8. Use temperature/humidity measuring meter with high precision to proof-read and calibrate the temperature/humidity sensor readings. Note to set the humidity control mode to relative humidity control during the process of calibration.

9. Check the following external sensors.

1) Smoke detector (optional)

The power supply of the smoke detector is located at the bottom (or top) of the upflow (or downflow) unit. It incessantly samples the air, analyzes the samples and makes judgment. It requires no calibration.

2) Water leak detector

The water leak detector has a dry contactor. The contactor will close when the detector probes detect water or other conductive liquid.

The detector should be placed away from any water pool or drainage trench on the floor, 2m ~ 2.5m away from the machine. Do not place it directly under the machine. The recommended location for the water leak detector is shown in Figure 7-1.




Figure 7-1 Recommended location for the water leak detector

**Note**

1. Before connecting any mechanical parts or cables, make sure the power supply of the control unit has been disconnected.
2. Do not use the water leak detector adjacent to flammable liquid or use it to detect flammable liquid.

10. Adjust the setting points. Check the auto-flush control logic of water pan of the infrared humidifier and the action of the functional parts according to control logic.

11. Simulate the fault scenario to check the work state of protection devices including high/low voltage alarm, high/low temperature alarm, high/low water level alarm and over-temperature protection device.

## 7.2 Filter

To ensure efficient operation, the dust filter must be checked once a month, and be replaced as required. The filter clogging switch and pressure difference switch are located as shown in Figure 7-2.




Figure 7-2 Filter clogging switch and pressure difference switch

Turn off the power before replacing the filter. You need to adjust the setting point of the filter clogging switch if the new filter is of a different model. The filter clogging switch is located in the electric control box. It samples the air pressures before and behind the filter through a black hose, and decides the output after comparing the two values.

To adjust the setting point of the filter clogging switch, you should:

1. After replacing the filter, restore and seal all the panels, so that the alarm point can be found precisely.
2. Keep the fan running, and rotate the rotary switch of the filter clogging switch counter clockwise until the filter alarm is triggered.
3. Rotate the rotary switch clockwise for 2.5 rounds, or rotate it to the point where the filter should be replaced.



#### Note

1. Set the setting point properly. Otherwise, the filter alarm may be triggered too frequently; or, in the opposite case, the dust accumulation on the filter could not trigger the alarm, endangering the system operation due to deteriorated ventilation.
  2. If you are unsure about the setting point, consult with Emerson before using a filter of a different model to replace the old one.
- 

## 7.3 Fan Kit

**For forward fan:** The fan components that require regular checking include belt, motor bracket, fan bearing and blades.

The fan and the installation board use integrated design. The belt tension is regulated automatically under the force of gravity, so as to reduce the fan vibration and protect the belt. If you need more details, please contact the manufacturer.

### 7.3.1 Fan Bearing And Blades

Check the fan regularly to make sure the bearing is firmly fixed. Rotate the blades and make sure that they do not scratch the wall of the air duct. Because the bearing is permanently sealed and self-lubricated, check for signs of wearing when adjusting the belt. Roll the belt and observe the motion of the fan bearing. If any abnormal displacement is observed, replace the bearing.

### 7.3.2 Belt

Measure the belt tension with a tension meter. You can also press down the belt at the middle point between the two pulleys. The displacement should be 0.5" ~ 1".

If the belt is found worn out or distorted, replace it with a new belt. The new belt should be of the same model as the old one.

### 7.3.3 Motor

To replace the failed motor, you should be very careful, especially with the upflow unit. Use a dedicated fixture to hold the motor before removing the fixing bolts at the bottom of the motor.

**For backward EC fan :** Regular check items of the fan include motor working status, fan blade status, fan assembly fixation, and the clearance between the fan and the inlet ring.

Specially note that the fan components and the inlet ring are fixed firmly. Rotate the blades to make sure that they do not scratch the adjacent metal plate. You should also dispose any abnormal airflow obstruction factors in time, for protecting the refrigeration system and other system components from airflow reduction.

## 7.4 Infrared Humidifier

During the normal operation of the humidifier, sediment will accumulate on the water pan. To ensure efficient operation of the humidifier, you need to clean the sediment regularly. However, the cleansing cycle varies because the water is different in different regions. It is recommended to check, and cleanse (when necessary) the water pan, once a month.

Remove the water level regulator to drain the water pan. Disconnect the drainage pipe, remove the dry-burning protection switch of the water pan, remove the fixing screws at the two ends of the pan, and pull out the water pan. Cleanse the water pan with water and hard brush, and restore the water pan by reversing the preceding procedures.

 **Note**

Before removing the water pan, make sure that the power has been cut off, and the water in the water pan is not too hot.

The autoflush function of the humidifier can prolong the cleansing cycle. However, timed check and maintenance are indispensable.

**Replacing the lamps of the humidifier**

The lamp of the infrared humidifier is shown in Figure 7-3. Follow the procedures below to replace it.

1. Cut off the main isolation switch power.
2. Unplug all the control lines of the humidifier and cut off the cable ties that bind the humidifier power cables. The plugs are located to the left of the humidifier and are accessible directly.
3. After draining the water in the water pan, remove the drainage pipe, remove the fixing screws on both sides of the humidifier (two for each side), and then pull out the humidifier.
4. Open the cover plate (for single-door system, this cover plate has been opened in step two) to reveal the ceramic socket. Use the multimeter to locate the burned lamp.
5. Remove the humidifier water pan.
6. Remove the brackets in the middle that support the lamps.




Figure 7-3 Lamps of infrared humidifier

7. Remove the screws that fix the cables of the lamp to be replaced from the ceramic sockets (note to hold the lamp with hand).
8. Pull down the lamp.
9. Install a new lamp.

 **Note**

Do not touch the quartz lamp with bare hands! Greasy sediment and finger prints can seriously shorten the life span of quartz lamps. Therefore, wear clean cotton gloves during the operation.

10. Restore the humidifier by reversing steps 3 ~ 8.

**Autoflush system of the infrared humidifier**

 **Note**

To ensure the normal operation of the autoflush system, the humidifier demands a water source with minimum water flow of 1 gpm (0.063 l/s) and minimum pressure of 20 psig (138kPa).

**Operation of the autoflush**

The autoflush control program is an integral part of the infrared humidifier system. The program automatically controls a water makeup valve to maintain the proper water level in the humidifier pan during operation. When a call for humidification exists, the program will firstly check how long the infrared humidifier has been off.

1. If the off time is equal to or greater than the programmed value (factory default is 15hr), it is assumed that the pan is dry and a program called pre-fill is initiated to add water to the pan. The pre-fill time is different depending on the pan size. The factory default for a large pan is 60s and for a small pan is 30s. During the

pre-fill operation the infrared lamps are inactive, and the humidification is suppressed. In this way, small quantity of water will be added to the water pan to prevent the damage of the water pan by dry burning.

2. If the off time is less than the default value of the program, the pre-fill program is bypassed and the infrared lamps and water valve are activated at the same time to fill the pan to the proper water level and initiate humidification. Small water pan will be filled for 4min, while large water pan will be filled for 7min, and then the water makeup valve is closed.

During normal infrared humidification operation the water makeup valve is periodically closed (no pan fill) and opened (pan fill) based on a timing sequence to allow for the evaporation of water from the pan. Water filling will be triggered for every 8min of humidification (for small water pan) or every 10min of humidification (for large water pan) to make up the consumed water and flush the minerals floating on the water of the water pan. The water filling quantity may be set by the customer according to the local water quality.

You can modify the percentage from 110% to a maximum of 500% in 1% increments.

The autoflush system will periodically flush the water pan to prevent the accumulation of sediments because of erosion effect. Because of the difference of water supply in different regions, the water flowing past the system shall be set with program to match the local needs. The selectable water quantity is 110% to 500% of the water flow rate. The autoflush system will operate automatically after water quantity is selected, and no further adjustment is needed. See Figure 7-4 for humidification control logic.




Figure 7-4 Humidification control logic

### 7.5 Electrical Heater

Check the rust on the electrical heater. If necessary, clean the rust with wire brush, or replace the heater. The electrical heater is classified into upflow electrical heater and downflow electrical heater, as shown in Figure 7-5. Three temperature switches are in series connected within the internal control circuit of the electrical heater, including two auto-reset switches and one manual reset switch. When the electrical heater does not respond to the heating demand, check if the manual reset switch has been disconnected.




Figure 7-5 Upflow and downflow electrical heater

## 7.6 Water Flow Control Valve

The water flow control valve adjusts the valve position by collecting the refrigeration requirement signal, so as to control the water flow through the heat exchanger coil. The heavier the load is, the more water flow is allowed to flow through the heat exchanger coil. The water flow control valve is composed of a regulator body, connector ( Small actuator without connectors, such as Figure 7-6 left; large actuator is equipped with connectors, such as Figure 7-6 right and actuator.




Figure 7-6 Water flow control valve

### Adjusting method

The water flow control valve automatically adjusts the valve position according to the refrigeration requirement, so as to make sure the temperature and humidity of the AC room are within the control range. When the refrigeration requirement is big, the valve would open wider and the water flow would increase. When the refrigeration requirement is small, the valve would open narrower and the water flow would decrease.

### Test function

When there is refrigeration and dehumidification requirement, the valve would open and have water flow. When there is no refrigeration or dehumidification requirement, the valve would close and have no water flow.

# Chapter 8 Failure Diagnosis And Troubleshooting

This chapter introduces the failure diagnosis and troubleshooting and can be used together with the alarm section.

 **Warning**

Some circuits have fatal high voltage, only professional technicians are allowed to maintain and operate the unit. You must be particularly careful in troubleshooting with power on.

 **Note**

If jumpers are used for troubleshooting, remember to remove the jumper after maintenance. Otherwise, the equipment may be damaged.

For failure diagnosis and troubleshooting of each component, please refer to Table 8-1 to Table 8-4.

*Table 8-1 Fan Troubleshooting*

Symptom	Potential causes	Items to be examined or handled
Fan cannot be started	No main power supply	Examine the rated voltage of L1, L2 and L3
	Circuit breaker disconnection or fuse burnout	Examine the fuse and circuit breaker of main fan
	Overload, circuit breaker disconnection	Manual reset. Examine the average current
	Contactor not pulling on	Examine whether there is 24V AC voltage between P36-3 and E1. If there is, but the contactor cannot pull on, then the contactor has failures. Please replace the contactor
	Control panel failure	Examine whether there is 24V AC voltage between P36-3 and E1. If there is not, then the control panel has failures. Please check whether the green LED beside silicon control Q5 on the control panel is on or not
	Control panel failure (For backward EC fan)	Examine whether there is ≤ 10V DC voltage between P53-2 and P53-3. If there is not, then the control panel has failures
	Fuse panel failure	Examine whether there is 24V AC voltage between P36-3 and E1. If there is not, and the green LED beside Q5 is not on, please check further whether LED DS4 beside F4 on the fuse panel is on, or take down F4 to test whether it is burnt out
	Fan not functioning	Replace the fan

*Table 8-2 Refrigeration and dehumidification system troubleshooting*

Symptom	Potential causes	Items to be examined or handled
No refrigeration or dehumidification	Control panel failure	Examine whether there is 24V AC voltage between P51-1 and E1, P52-1 and E1. If there is not, then the control panel has failures
	Fuse panel failure	Examine whether there is 24V AC voltage between P51-1 and E1, P52-1 and E1. If there is not, please check further whether LEDs DS3 and DS4 beside F4 on the fuse panel are on, or take down F3, F4 to test whether they are burnt out
	Failure to turn on the water valve	Examine whether there is 10V DC voltage between water valve VDC/mA and E5 terminal. If there is, then the water valve has failures. Please replace the water valve

Table 8-3 Infrared humidifier troubleshooting

Symptom	Potential causes	Items to be examined or handled
No humidification	No water injection for the water tray	Examine the water source
		Check whether watering electromagnetic valve works
		Examine the state of high-water level switch/overflow valve
		Check whether the water-in pipe is blocked
	No humidification requirement	Examine the controller state
	Humidification contactor cannot pull on.	Examine the circuit voltage of the contactor and fuse or the circuit breaker
		Examine the open humidifier safety equipment: the water tray overtemperature protection switch, the lamp overtemperature protection switch. Connect P35-6 and P35-5 terminals with jumper. If the contactor closes, please replace the serial safety equipment and then remove the jumper
Lamp of the humidifier is burnt out.	Replace the lamp	

Table 8-4 Heating system troubleshooting

Symptom	Potential causes	Items to be examined or handled
Heating system does not operate, and the contactor does not pull on.	No heating requirement	Examine the controller state
	Heating system safety equipment disconnection	For secondary electric heating, inspection of P34-6 and P34-7 terminals should be made. If heating system begins to operate, it means that the safety equipment is disconnected. Then you should remove the jumper and replace the safety equipment
Contactor pull-on, no heating effect.	Heater burnout	Cut off the power, and detect the resistance characteristics of the heater with ohmmeter

Attached table 1: Table of maintenance inspection items (monthly)

Date:

Prepared by:

Equipment model:

Serial No.:

Filter

- \_\_\_ 1. Check whether the filter is damaged or blocked.
- \_\_\_ 2. Check the filter block switch.
- \_\_\_ 3. Clean the filter.

Fan

- \_\_\_ 1. Whether there is deformation on the fan blades.
- \_\_\_ 2. Whether there is bearing wear (For forward fan).
- \_\_\_ 3. Belt tightness and its state (For forward fan).
- \_\_\_ 4. Whether fan and inlet ring are fixed firmly ( For backward EC fan )
- \_\_\_ 5. Whether blades scratch the adjacent metal plate (For backward EC fan)

Water flow regulating valve

- \_\_\_ 1. Check water flow.
- \_\_\_ 2. Check water resistance.

Heating system

- \_\_\_ 1. Examine the operation of re-heating system components.
- \_\_\_ 2. Check the component corrosion status.

Infrared humidifier

- \_\_\_ 1. Check whether there is block on water tray drain.
- \_\_\_ 2. Examine the quartz lamp of the humidifier.
- \_\_\_ 3. Examine water tray mineral deposits.

Signature\_\_\_\_\_

Note: Please copy this table as an archive record.

**Attached table 2: Table of equipment maintenance inspection items (semi-annual)**

Date

Prepared by:

Equipment model:

Serial No.:

**Filter**

- \_\_\_ 1. Check whether the filter is damaged or blocked.
- \_\_\_ 2. Check the filter block switch.
- \_\_\_ 3. Clean the filter.

**Fan**

- \_\_\_ 1. Whether there is deformation on the fan blades.
- \_\_\_ 2. Whether there is bearing wear (For forward fan).
- \_\_\_ 3. Belt tightness and its state (For forward fan).
- \_\_\_ 4. Check and fasten the circuit connector (For forward fan).
- \_\_\_ 5. Whether fan and inlet ring are fixed firmly (For backward EC fan).
- \_\_\_ 6. Whether blades scratch the adjacent metal plate (For backward EC fan)

**Chilled water coil**

- \_\_\_ 1. Clean water pipe system.
- \_\_\_ 2. Check whether there is leakage in water system.

**Heating system**

- \_\_\_ 1. Examine the operation of re-heating system components.
- \_\_\_ 2. Check the component corrosion status.
- \_\_\_ 3. Check and fasten the circuit connector.

**Infrared humidifier**

- \_\_\_ 1. Check whether there is block on water tray drain
- \_\_\_ 2. Examine the quartz lamp of the humidifier.
- \_\_\_ 3. Examine water tray mineral deposits.
- \_\_\_ 4. Check and fasten the circuit connector.

**Electric control**

- \_\_\_ 1. Examine the fuse and circuit breaker.
- \_\_\_ 2. Check and fasten the circuit connector.
- \_\_\_ 3. Check the control procedure.
- \_\_\_ 4. Check whether the contactor can pull on or not.

Signature \_\_\_\_\_

**Note: Please copy this table as an archive record**

# Appendix 1 The Structure Chart Of Electric Control Box




Figure 1 Internal structure of one-bay series electrical control box




Figure 2 Internal structure of two-bay series electrical control box




Figure 3 Internal structure of three-bay series electrical control box

- |                           |                           |                                 |                                      |
|---------------------------|---------------------------|---------------------------------|--------------------------------------|
| 1—Fan MCB                 | 6—Fuse board              | 11—N/PE terminal                | 16—Fan contactor                     |
| 2—Bus                     | 7—Control board           | 12—Backup reheat relay          | 17—Fan overcurrent protector         |
| 3—Electrical heater MCB   | 8—Control terminal        | 13—Isolation transformer        | 18—Main isolation switch             |
| 4—Infrared humidifier MCB | 9—Ground current detector | 14—Humidification contactor     | 19—Temperature/humidity sensor board |
| 5—Control board MCB       | 10—Power transformer      | 15—Electrical heating contactor | 20—Main N terminal                   |
|                           |                           |                                 | 21—Main grounding terminal           |

## Appendix 2 Circuit Diagram




Figure 4 Circuit diagram

### Appendix 3 The Structure Chart Of Micro-processing Controller Menu




Figure 5 Structure diagram of user menu




Figure 6 Structure diagram of maintenance menu

**Emerson Network Power Asia**

**Australia**

T: 1800-065345  
F: 61-2-97438737

**China**

T: 86-755-860-10808  
F: 86-755-860-10245

**India**

T: 91-22-67208000  
F: 91-22-25828358

**Indonesia**

T: 62-21-2513003  
F: 62-21-2510622

**Japan**

T: 81-3-54038594  
F: 81-3-54032924

**Korea**

T: 82-2-34831500  
F: 82-2-5927883

**Malaysia**

T: 603-78845000  
F: 603-78845188

**New Zealand**

T: 64-3-3392060  
F: 64-3-3392063

**Pakistan**

T: 92-42-36622526 to 28  
F: 92-42-36622530

**Philippines**

T: 63-2-6203600  
F: 63-2-6203693

**Singapore**

T: 65-64672211  
F: 65-64670130

**Thailand**

T: 66-2-6178260  
F: 66-2-6178277 / 78

**Vietnam**

T: 84-4-37628908  
F: 84-4-37628909

---

**Marketing.AP@Emerson.com**

**Emerson Network Power.**

The global leader in enabling *Business-Critical Continuity™*.

- |                |  |                              |                               |
|----------------|--|------------------------------|-------------------------------|
| ■ AC Power     | ■ Embedded Computing                     | ■ Outside Plant              | ■ Racks & Integrated Cabinets |
| ■ Connectivity | ■ Embedded Power                         | ■ Power Switching & Controls | ■ Services                    |
| ■ DC Power     | ■ Infrastructure Management & Monitoring | ■ Precision Cooling          | ■ Surge Protection            |

Business-Critical Continuity, Emerson Network Power and the Emerson Network Power logo are trademarks and service marks of Emerson Electric  
©2010 Emerson electric Co.

AP11ENT-PEXCWV1-UM