

# MiniDE

## User Manual



## **COPYRIGHT and TRADEMARK**

All rights reserved by APANTA LCC, Porland, Oregon, USA. No part of this document may be reproduced in any form or by any means without written permission from the product manufacturer. Changes are periodically made to the information in this document. They will be incorporated in subsequent editions. The product manufacturer may make improvements and /or changes in the product described in this document at any time.

All the registered trademarks referred to this manual are belonging to their respective companies.

## **WARRANTY STATEMENT**

Apantac LLC (herein after referred to as "Apantac") warrants to the original purchaser of the products manufactured by Apantac (the "Product,") will be free from defects in material and workmanship for a period of three (3) year from the date of shipment of the Product to the purchaser.

If the Product proves to be defective during the three (3) year warranty period, the purchaser's exclusive remedy and Apantac's sole obligation under this warranty is expressly limited, at Apantac's sole option, to:

- (a) repair the defective Product without charge for parts and labor or,
- (b) provide a replacement in exchange for the defective Product or,
- (c) if after a reasonable time, is unable to correct the defect or provide a replacement Product in good working order, then the purchaser shall be entitled to recover damages subject to the limitation of liability set forth below.

### Limitation of Liability

Apantac's liability under this warranty shall not exceed the purchase price paid for the defective product. In no event shall Apantac be liable for any incidental, special or consequential damages, including without limitation, loss of profits for any breach of this warranty.

If Apantac replaces the defective Product with a replacement Product as provided under the terms of this Warranty, in no event will the term of the warranty on the replacement Product exceed the number of months remaining on the warranty covering the defective Product.

Equipment manufactured by other suppliers and supplied by Apantac carries the respective manufacturer's warranty. Apantac assumes no warranty responsibility either expressed or implied for equipment manufactured by others and supplied by Apantac.

This hardware warranty shall not apply to any defect, failure or damage:

- a) Caused by improper use of the Product or inadequate maintenance and care of the Product;
- b) Resulting from attempts by those other than Apantac representatives to install, repair, or service the Product;
- c) Caused by installation of the Product in a hostile operating environment or connection of the Product to incompatible equipment;

# Table of Contents

1.0 What's in the Box .....	1
2.0 Key Features .....	1
3.0 Specifications .....	1
4.0 Front/Rear Panels .....	2
4.1. Front Panel .....	2
4.2. Rear Panel .....	2
5.0 Accessories .....	3
6.0 Installation .....	4
7.0 Configuration and Programming .....	5
7.1. Getting Started .....	5
7.2. Connecting to the CP-16 with a Web Browser.....	5
7.3. MiniDE Administration Setup .....	6
7.3.1. MiniDE Module Setup.....	7
7.3.2. Multiviewer Connection Setup .....	9
7.4. MiniDE Operation .....	11
7.4.1. MiniDE Programming .....	12
7.4.2. GPIO Control Setup .....	13
Appendix I AXP Commands.....	15
Appendix II Reset to Defaults .....	17

## 1.0 WHAT'S IN THE BOX

- 1 x MiniDE Multiviewer
- 1 x Rack Mount Kit
- 1 x RJ50 to DB9 cable with terminal block for GPI/Tally
- 1 x RJ45 to DB9 cable for RS-232

### Important Note:

Default IP address: 192.168.1.151

## 2.0 Key Features

- Four universal inputs – HDMI/DVI, VGA, YPbPr, CVBS
- Windows can be re-sized freely
- Built-in web page setup, can be easily accessed by any web browser

## 3.0 Specifications

<b>Description</b>	4 input multiviewer
<b>Software</b>	Built-in web interface
<b>Connectors</b>	
<b>IP</b>	100 Base-Tx, Ethernet TCP/IP on RJ45 port
<b>GPI0</b>	8 lines on 10-wire RJ50 port (adapter cable/breakout provided)
<b>RS232</b>	Serial on RJ45 connector (adapter cable provided). ( Serial port use not currently available in firmware )
<b>DVI/HDMI</b>	DVI/HDMI, VGA, YPbPr, Composite
<b>EMI/RFI</b>	Complies with FCC Part 15, Class A, CE, EU, EMC, C-tick
<b>Power</b>	DC 5-Volt, 3.2 Amp power adapter
<b>Size</b>	440mm W x 125mm D x 44mm H (not including rack mounting 'rack-ears')
<b>Mounting</b>	Rack mount, 1 rack unit in height

## 4.0 Front/Rear Panels

### 4.1 Front Panel





Figure 4-1 MiniDE Front Panel

### 4.2 Rear Panel


Figure 4-2: MiniDE Rear Panel

# 5.0 Accessories

	
<p>Power Adapter</p>	<p>2 x Mounting Plate</p>
	
<p>RJ50 to DB9 Cable for GPI/O</p>	<p>RJ45 to DB9 Cable for RS-232</p>
	
<p>Terminal Block for GPI/O</p>	

# 6.0 Installation

## Ethernet Wiring




## GPI/O Wiring

Connect the GPI port to the DB9 breakout wiring block using the RJ50-DB9 adapter cable.  
*(NOTE: The RJ50 connector has 10 contacts and a metal shielded end.)*

GPI inputs can be provided by either relay contact closures or open-collector circuits of external equipment. GPI connections must include the ground (GND) reference. The input is activated when it is brought to the ground reference level.

GPO outputs provide a 5volt output level from the MiniIDE when active, and ground level when inactive.



# 7.0 Configuration and Programming

## 7.1 Getting Started

The MiniDE is designed to be a low cost quad split multiviewer. It has a built-in web browser interface that makes setup easy.

## 7.2 Connecting to the MiniDE with a Web Browser

The default address for the MiniDE is 192.168.1.151. Open a web browser and type 192.168.1.151 in the URL address line. When connected the login page will be displayed.

The default username is "apantac", the default password is "apantac". The username and password are case sensitive.




Figure 7.1: MiniDE login page

## 7.3 MiniDE Administration Setup

After you logon to the MiniDE page, you will be able to access 3 tabs, Setup, Advance and Administration. Click the Administration tab.

The screenshot displays the MiniDE Administration Setup interface. At the top, there is a header with the APANTAC logo, contact information (7556 SW Bridgeport Road, Portland, OR, 97224, USA; Phone: +1 503 968 3000; Fax: +1 503 389 7921), and the URL http://www.apantac.com/. The page title is "MiniDE Web control" and there is a "Logout" link. Below the header, there are three tabs: "Setup", "Advance", and "Administration". The "Administration" tab is selected. The main content area is divided into several sections, each with a red border:

- Username:** A text input field for the username, with "Apply" and "Cancel" buttons below it.
- Password:** Three text input fields for "Old Password", "New Password", and "Confirm Password", with "Apply" and "Cancel" buttons below them.
- Network:** A series of settings including:
  - DHCP Client: A dropdown menu set to "Disable".
  - Static IP Address: 192.168.1.152
  - Static Subnet Mask: 255.255.255.0
  - Static Default Gateway: 192.168.1.1
  - Static DNS Server: 168.95.1.1
- Connection Type:** A dropdown menu set to "TCP".
- Transmit Timer:** 100 ms, with a note "Please enter an integer between 10~65535".
- Server/Client Mode:** A dropdown menu set to "Client".
- Server Listening Port:** 2009, with a note "Please enter an integer between 1024~65535".
- Client Destination Host Name/IP:** 192.168.1.154, with a note "Please enter host IP address(e.g. 192.168.1.151)".
- Client Destination Port:** 101, with a note "Please enter an integer between 101~65535".

Below the Network section, there is another section with a red border:

- Accessible IP Setting:** Four text input fields for "IP #1", "IP #2", "IP #3", and "IP #4", all containing "0.0.0.0". A dropdown menu for "Control" is set to "Disable".

At the bottom of the page, there is a red "Attention:" warning: "For the <Accessible IP Setting> change to take effect, you must power cycle or reboot the device". Below this warning are "Apply" and "Cancel" buttons.

Figure 7.2: Administration Tab, MiniDE settings

APANTAC LLC, 7556 SW BRIDGEPORT ROAD, PORTLAND, OR 97224  
[INFO@APANTAC.COM](mailto:INFO@APANTAC.COM), TEL: +1 503 968 3000, FAX: +1 503 389 7921

### 7.3.1 MiniDE Module Setup

The areas outlined in red in the figure 7.2 above pertain to the MiniDE module itself.

- **Username**

The default username for logging on to these setup webpage is "apantac". This can be changed to your preference. Click the corresponding "Apply" button after entering your information.

- **Password**

The default password for logging on to these setup webpage is "apantac". This can be changed to your preference. Click the corresponding "Apply" button after entering your information.

- **DHCP Client**

DHCP can be Enabled or Disabled. Enabling DHCP will cause your network's DHCP server (server or router) to assign the MiniDE an IP Address of it's choice. Not knowing the assigned IP Address will make displaying the setup webpages difficult. If your I.T. department insists on DHCP, they should program their DHCP server (router) to assign a known, preselected IP Address to the MiniDE unit. To apply these changes click the 'Apply' button at the bottom of this webpage and then click the 'Reboot' button on the Setup tab.

*NOTE: If DHCP is Enabled, the following four network settings will be ignored. (Your Network's DHCP server will assign them.)*

- **Static IP Address**

The IP Address of the MiniDE module. This should be set to an address on the same subnet as the multiviewers it will control.

- **Static Subnet Mask**

Default subnet masks depend on the class of your network.

Network class	Network IP addresses	Subnet Mask
Class A	10 . xxx . xxx . xxx	255 . 255 . 0 . 0
Class B	172 . xxx . xxx . xxx	255 . 255 . 240 . 0
Class C	192 . 168 . xxx . xxx	255 . 255 . 255 . 0

- **Static Default Gateway**

Not applicable when MiniDE and Multiviewers are on the same local subnet network.

- **Static DNS Server**

Not applicable when MiniDE and Multiviewers are on the same local subnet network.

## Accessible IP Setting

**WARNING:** If enabled, only computers with these IP addresses can login to the MiniDE's webpages.

- **IP #1 through IP #4**

Enter the IP addresses of the computer's to be permitted to login to, access, and change the MiniDE's settings.

- **Control**

This will enable or disable the 'Accessible IP Setting' function and settings. See the above warning prior to enabling this function.

## 7.3.2 Multiviewer Connection Setup

The areas outlined in red in the figure below pertain to the MiniDE connecting to the Computer.

The screenshot displays the 'Administration' tab of the APANTAC MiniDE Web control interface. The page is divided into several sections: 'Username', 'Password', 'Network', and 'Accessible IP Setting'. A red rectangular box highlights the 'Network' section, which includes the following fields and values:

Field	Value
DHCP Client	Disable
Static IP Address	192.168.1.152
Static Subnet Mask	255.255.255.0
Static Default Gateway	192.168.1.1
Static DNS Server	168.95.1.1
Connection Type	TCP
Transmit Timer	100 ms
Server/Client Mode	Client
Server Listening Port	2009
Client Destination Host Name/IP	192.168.1.154
Client Destination Port	101

Below the 'Network' section is the 'Accessible IP Setting' section, which includes four IP address fields (IP #1 to IP #4) all set to 0.0.0.0, and a 'Control' dropdown menu set to 'Disable'. An attention message at the bottom states: 'Attention: For the <Accessible IP Setting> change to take effect, you must power cycle or reboot the device'. The page also features a 'Logout' link in the top right corner and 'Apply' and 'Cancel' buttons at the bottom.

Figure 7.3: Administration Tab, Multiviewer settings  
APANTAC LLC, 7556 SW BRIDGEPORT ROAD, PORTLAND, OR 97224  
[INFO@APANTAC.COM](mailto:INFO@APANTAC.COM), TEL: +1 503 968 3000, FAX: +1 503 389 7921

- **Connection Type**  
TCP or UDP protocol. Default is TCP (Apantac Tahoma multiviewers utilize TCP protocol.)
- **Transmit Timer**  
Transmission timeout limit. Default is '100'. Change to 200 or 300 ms if experiencing trouble with the multiviewer not receiving commands and no other reason can be found.
- **Server / Client Mode**  
Default is 'Client' and cannot be changed.
- **Server Listening Port**  
Default is '2009'.
- **Client Destination Host Name / IP**  
N/A
- **Client Destination Port**  
Default is '101', do not change. (Apantac Tahoma multiviewers utilize port 101 for receiving AXP command protocol.)

## 7.4 MiniDE Operation

The Setup tab provides for programming the MiniDE output format, input source format, window coordinates and position, and zoom settings





Figure 7.4: Setup Tab

## 7.4.1 MiniDE Programming

- **Frame Rate**


The first line in the Setup screen is Frame Rate. A pull down menu displays all available selections. At the time of this publication only two formats are available: 1080p at 60Hz or 50Hz/



- **Window Source Format**


APANTAC LLC, 7556 SW BRIDGEPORT ROAD, PORTLAND, OR 97224  
[INFO@APANTAC.COM](mailto:INFO@APANTAC.COM), TEL: +1 503 968 3000, FAX: +1 503 389 7921

The next available setting is the Window Source Format. This is a pull down menu that allows selection of the input source format. The options are CVBS, Component, VGA and HDMI/DVI.




- **Window Coordinates**

Below the Source Format cells are the four window coordinates. These position the windows on the screen. The values are in pixels. With a 1080p Frame Rate, the picture is 1920 pixels wide by 1080 pixels tall. In this example the four windows are evenly spaced in to four quadrants



When the “Apply” button is clicked, the controller will respond with a confirmation pop-up. You must click “OK” to apply the changes.



## 7.5 MiniDE Advance tab

The Advance tab provides further administration setup and service.

<http://www.apantac.com/>



**APANTAC**  
Signal Processing Solutions

Apantac © 2012 [support@apantac.com](mailto:support@apantac.com)  
 7556 SW Bridgeport Road,  
 Portland, OR, 97224, USA  
 Phone: +1 503 968 3000-  
 Fax: +1 503 389 7921

**CP-16**  
**Web control**

[Logout](#)

Setup
Advance
Administration

**Warning!**  
 Before you proceed with any changes on this page, please first consult Apantac support

**Firmware Upgrade Settings**

TFTP Server IP:

File Name:

**Auto Warning Report Settings**

Cold Start:

Authentication Failure:

Local IP Address Changed:

Password Changed:

- **Firmware Upgrade Settings**

**For use by authorized service personnel only.** Contact Apantac Technical Support prior to making any changes on this page.

- **Auto Warning Report Settings**

When certain setup actions are performed an alternate webpage is displayed as standard warnings. These are enabled by default and there are no reasons to alter these settings.

