



INSTALLATION AND OPERATING INSTRUCTIONS

**Thank you for choosing this
Automatic Digital Humidistat!**



About the Automatic Digital Humidistat

In Automatic Mode the humidistat will adjust the humidity in your home based on the outdoor temperature, lowering the humidity in cold weather to reduce condensation. The humidistat can operate in Manual Mode to control humidity to a specific relative Humidity. In most homes, Automatic operation is preferred to reduce condensation on windows and within the structure. Manual mode is necessary where the outdoor temperature sensor cannot be installed. Manual mode may be desirable where valuable artwork, instruments or woodwork demand constant humidity. The LCD Display is backlit and easy to read. Operation and Installation are simple. The humidistat can be mounted on an interior wall or on the return duct of the HVAC System.

Precautions

This Humidistat must be installed by a Qualified Technician. Always turn off power to the HVAC system prior to Installing or Servicing the Humidifier or Humidistat. Improper operation can result in over or under humidification. Over humidification can result in condensation, structural damage or mold. Condensation within a building's structure can cause a loss of structural strength. Condensation can also enable mold and mildew growth resulting in personal injury and damage to building structure and contents. Older and poorly insulated structures cannot withstand the same humidity levels as newer well insulated buildings. Read these instructions carefully. This humidistat requires a 24 volt, AC power supply. Improper voltage can cause malfunction or damage to the control. The technical specifications for this product and the contents of the user manual are subject to change without notice.

Specifications

Voltage	18-30 VAC, 60Hz.
Switching Load	1 amp max. 30 volt
Outdoor Sensor	max. 200 ft. 61m.
Auto Mode	
Control Range	10%-60% RH.
Outdoor Temp.	-10°F, -23°C min.

Manual Mode	
Control Range	10%-75% RH
Accuracy -RH (77°F, 25°C)	10%-90% ±3%RH
Accuracy Drift Per Year	±0.5%RH
Accuracy Indoor Temp.	±2°F, ±1°C
Accuracy Outdoor Temp	±2°F, ±1°C

Resolution, Temp or RH	1° or 1%.
Relay Close	Setting - 1%RH
Relay Open	Setting +1%RH


Humidistat Locations

YES!

Return Air Duct
Interior Wall
Where it's Seen

NO!

Supply Plenum
Furnace Jacket
Furnace Room Wall
Closet, Closed Room
Anywhere in Garage
On Block Wall
Crawl space
Kitchen Wall
Laundry wall
Out of Sight



Outdoor Sensor Location



YES!

North Wall
East Wall
Over Snow Line
Inlet of Air Intake
Less than 200' from
humidistat.



NO!

South Wall
West Wall
Below Snow
Deep in Intake
More than 200'
from humidistat.

Wall Installation




Duct Installation




Wiring


WIRING OUTDOOR SENSOR




WIRING TO 24V. HUMIDIFIER



WIRING TO FAN POWER HUMIDIFIER




WIRING TO ELITE STEAM HUMIDIFIERS



Testing the System

1. Re-assemble system and check all connections.
2. Restore power to the HVAC system.
3. Start HVAC System by raising thermostat setting.
4. Check to see that display is on.
5. Set to TEST MODE by pressing "Drop" and "thermo" together for 5 seconds. The relay will close and the "+" will flash for 2 minutes or press a key to set to OFF MODE.
6. Set to OFF mode to verify humidifier operation ceases.
7. The humidistat will stay in OFF Mode unless set to Manual or Automatic mode. See "Operation".



Operating Modes


Press any button to light the display. Press the "DROP" button to select the Operating Mode, Off, Manual or Auto.

OFF Mode

The Humidifier is turned off.

MANUAL Mode

The humidistat will work to maintain the single humidity selected. You can set your desired humidity level by pressing "UP" or "DOWN". The humidifier will turn ON or OFF according to your manual setting. The humidifier will operate when the measured relative humidity falls more than 1% below the set point until the measured relative humidity is 1% above the set point. When the humidifier is operating, the "+" will display. Humidity may have to be lowered when weather is colder or if condensation is suspected. The settings table to the right or a similar table may be used to compensate for cold outside temperatures.



Outdoor Temperature	Suggested Setting
-20°F -29°C	15%
-10°F -23°C	20%
0°F -18°C	25%
+10°F -12°C	30%
+20°F -7°C	35%
+30°F -1°C	40%

AUTO Mode

The humidistat will automatically raise the humidity as the outdoor temperature increases. This provides the highest possible humidity. The humidistat will automatically lower the humidity as temperatures drop. This minimizes the risk of condensation on cold surfaces like windows.

The Auto Humidity Index Set Point may be changed from 0 (low) to 10 (high) by pressing "UP" or "DOWN". The Humidity Index is based on the outdoor temperature and indoor humidity. The humidifier will switch ON/OFF according to the calculated auto humidity index set point. When the humidifier is operating, the "+" will display. Lower Index settings are for older homes with less insulation and poor vapor barriers. Higher Index settings are for newer homes with complete vapor barriers, triple pane windows and high R value insulation.

- 1-2 Older than 1950, no vapor barrier, little insulation.
- 3-4 Built 1950-1965, no vapor barrier, R6 insulation.
- 5-6 Built 1965-1975, craft vapor barrier, R11 insulation.
- 7-8 Built 1980-1990, craft vapor barrier, R19, double pane windows.
- 9-10 Built after 1990, poly vapor barrier, R38 insulation, foam exterior cladding, triple pane windows.

If condensation is seen or suspected, reduce index by 2 until condensation stops. The vertical bars indicate the humidity index; one bar for two index points.

AUTO Mode Target Humidity

Humidity Index	Outdoor Temperature °F							
	-20	-10	0	10	20	30	40	50
1	0	5	10	15	20	25	30	35
2	0	8	13	18	23	28	33	38
3	0	11	16	21	26	31	36	41
4	0	14	19	24	29	34	39	44
5	0	17	22	27	32	37	42	47
6	0	20	25	30	35	40	45	50
7	0	23	28	33	38	43	48	53
8	0	26	31	36	41	46	51	56
9	0	29	34	39	44	49	54	59
10	0	32	37	42	47	52	57	62

OFFSET Mode

To change the calibration of the humidistat, an offset may be entered to the Humidity, Indoor Temperature or Outdoor Temperature displays. Press both "UP" and "DOWN" buttons together to enter OFFSET mode. The word "OFFSET" and "RH" will display. Press "UP" or "DOWN" to change the humidistat's Humidity calibration. Press both "UP" and "DOWN" buttons together again to change the Indoor Temperature offset. Press both "UP" and "DOWN" buttons together again to change the Outdoor Temperature offset.

Display a Temperature

Press the "THERMOMETER" button to move between displaying indoor and outdoor temperature. "Tree" will be displayed when showing outdoor temperature. "House" will be displayed when showing indoor temperature. To change between °F and °C units, press the "°F/°C" button.

Trouble Shooting

"HOUSE" Flashing The indoor temperature sensor has failed.

"TREE" Flashing The outdoor temperature sensor has failed.

Humidifier Turns On and Off Repeatedly

Check that input voltage is between 18 and 30 volts, AC and not intermittent.

Check that humidistat is NOT mounted: 1. on supply duct. 2. downstream of humidifier. 3. closer to humidifier than 12 inches.

Make sure that Outdoor Sensor wiring is not close to line voltage wires.

Humidifier Runs Continuously

If humidifier operates while HVAC system is off, check that power to humidifier is switched with HVAC operation.

If humidifier operates every time HVAC System runs, compare humidity to set point. If humidity is lower than set point, humidistat will call for operation.

Humidifier Does Not Run

Check wiring to/from humidistat. Verify 18-30 volts. Use "TEST MODE".

Humidifier Runs When Air Conditioning Is On

If this is undesirable, change wiring to be powered only in heating periods.

Humidity not high enough

Fault with Humidifier. Check humidifier, water supply, electrical connections. HVAC operating time too short. Check humidifier trouble shooting.

Humidifier undersized. Review humidity load and humidifier capacity.

Humidity Too High

Wiring fault. Set humidistat to "OFF" mode and check that operation ceases.

Outdoor sensor is being kept warm. Check that sensor is not buried in snow, on south side of house being warmed by sun or is too far inside of air intake.

Limited Warranty

This humidistat is warranted to the consumer against defects in materials and workmanship for a period of one year from the date of installation. Defective parts will be repaired without charge except for removal, reinstallation and transportation costs. To obtain repair service under this limited warranty, the consumer must send the defective part to the manufacturer.

There are no express warranties covering this humidistat other than set forth above. The implied warranties of merchantability and fitness for a particular purpose are limited in duration to one year. The manufacturer assumes no liability in connection with the installation or use of this product, except as stated in this limited warranty. The manufacturer will in no event be liable for incidental or consequential damages.

Any questions pertaining to this limited warranty should be addressed to the manufacturer. USA: The manufacturer has elected not to make available the informal dispute settlement mechanism which is specified in the Magnuson-Moss Warranty Act.