

# **HVE**

## **Audio/Video Encoders**

HVE1	HVE1X
HVE4	HVE4X
HVE8	HVE8X

## **User Guide**



# **User Guide**

## Revisions

<b>Issue</b>	<b>Date</b>	<b>Revisions</b>
A	09/2013	New document.
Va Rev A	10/2013	Added Index. Minor text updates throughout. Updated the data storage capacity and network protocols in the Specifications section. Added an index. Added a section in chapter 6 about setting the RS-232 port as a transparent channel.

# Contents

<b>About This Document</b> . . . . .	<b>19</b>
Overview of Contents . . . . .	19
Typographical Conventions . . . . .	20
<b>1 Introduction</b> . . . . .	<b>21</b>
Features . . . . .	22
Encoding Features . . . . .	22
Network Features . . . . .	22
PTZ . . . . .	23
Alarm . . . . .	23
Exceptions . . . . .	23
Logs . . . . .	24
<b>2 Installing an HVE Encoder</b> . . . . .	<b>25</b>
Installation . . . . .	25
Installing the Hard Disk Drive (HDD) [HVE8(X) only] . . . . .	25
Preparing for Installation . . . . .	26
Installing the HDD . . . . .	26
HVE1/HVE1X Encoder Front and Rear Panels . . . . .	28
HVE4/HVE4X Encoder Front and Rear Panels . . . . .	30
HVE8/HVE8X Encoder Front and Rear Panels . . . . .	32
Connecting Alarms . . . . .	33
Connecting Alarm Inputs . . . . .	33
Alarm Input Connections for an Emerson Alarm . . . . .	33
Alarm Input Connections for a Normal Alarm . . . . .	34
Connecting Alarm Outputs . . . . .	34
<b>3 Connecting to an HVE Encoder via the Internet</b> . . . . .	<b>37</b>
Installing the IP Utility . . . . .	37
Configuring Network Parameters . . . . .	39
Searching for Online Devices . . . . .	39
Automatically Searching for Online Devices . . . . .	39
Manually Searching for Online Devices . . . . .	40
Modifying Network Parameters . . . . .	41
Connecting to an Online IP Device . . . . .	42
Accessing an HVE Encoder Through a Web Browser . . . . .	42
<b>4 Viewing Live Video</b> . . . . .	<b>45</b>
Starting Live View . . . . .	45
Starting Live View for All Cameras . . . . .	46
Live View Toolbar . . . . .	46
Full Screen Mode . . . . .	46
Capturing an Image . . . . .	47
Configuring the Save Path for Captured Images . . . . .	47
Controlling a PTZ Camera . . . . .	47
Connecting to a PTZ Camera . . . . .	48

	Configuring for a PTZ Camera . . . . .	48
	Controlling a PTZ Camera . . . . .	48
	Setting and Calling Presets . . . . .	49
	Linking a Preset to an Alarm . . . . .	50
	Configuring Video Parameters . . . . .	50
<b>5</b>	<b>Configuring the Encoder . . . . .</b>	<b>53</b>
	Configuring Time Settings . . . . .	54
	Configuring Network Settings . . . . .	56
	Configuring TCP/IP Settings . . . . .	56
	Configuring Port Settings . . . . .	57
	Configuring DDNS Settings . . . . .	58
	Configuring PPPoE Settings . . . . .	60
	Configuring Email Settings . . . . .	61
	Adding the Network Disk . . . . .	63
	Configuring SNMP Settings . . . . .	64
	Configuring QoS Settings . . . . .	66
	Configuring FTP Settings . . . . .	67
	Configuring SOCKS Settings . . . . .	68
	Configuring UPnP™ Settings . . . . .	69
	Configuring HTTPS Settings . . . . .	70
	Configuring Bonjour Settings . . . . .	72
	Configuring the IP Address Filter . . . . .	72
	Configuring the Multicast Address . . . . .	73
<b>6</b>	<b>Configuring Camera Settings . . . . .</b>	<b>75</b>
	Configuring OSD Settings . . . . .	75
	Configuring Display Settings . . . . .	75
	Configuring Text Overlay . . . . .	76
	Configuring Video Settings . . . . .	77
	Configuring Snapshot Settings . . . . .	79
	Configuring and Handling Alarms . . . . .	81
	Configuring Motion Detection . . . . .	81
	Configuring the Motion Detection Area . . . . .	81
	Configuring the Arming Schedule . . . . .	82
	Configuring the Alarm Actions for Motion Detection . . . . .	83
	Configuring an External Alarm Input . . . . .	86
	Configuring a Video Loss Alarm . . . . .	88
	Configuring the Tamper-proof Alarm . . . . .	89
	Configuring Exception Handling . . . . .	90
	Configuring a Privacy Mask . . . . .	91
	Configuring RS-232/RS-485 Port Settings . . . . .	93
	Configuring RS-232 Port Settings . . . . .	93
	Configuring the RS-232 Port as a Transparent Channel . . . . .	93
	Configuring RS-485 Port Settings . . . . .	94
<b>7</b>	<b>Configuring Recording and Capturing Settings . . . . .</b>	<b>97</b>
	Configuring Holiday Settings . . . . .	97
	Configuring Scheduled Recording and Capturing . . . . .	99
<b>8</b>	<b>Playing Back Recorded Video . . . . .</b>	<b>103</b>
	Playing Back a Specific Time . . . . .	105
	Determining the Type of Recorded Video . . . . .	105
<b>9</b>	<b>Managing User Accounts . . . . .</b>	<b>107</b>
	Adding a User . . . . .	107
	Modifying a User . . . . .	108
	Deleting a User . . . . .	109
<b>10</b>	<b>Searching Logs, Viewing Device Information, and Maintaining the Encoder . . . . .</b>	<b>111</b>
	Searching Logs . . . . .	111

Viewing Device Information . . . . .	112
Maintenance . . . . .	113
Restarting the Encoder . . . . .	113
Restoring Default Settings . . . . .	113
Importing or Exporting Configuration Files . . . . .	114
Importing Configuration Files . . . . .	114
Exporting Configuration Files . . . . .	115
Upgrading the System . . . . .	115
<b>Appendix A Troubleshooting . . . . .</b>	<b>117</b>
The encoder cannot be pinged . . . . .	117
The transparent channel has been set, but the encoder still does not receive data . . . . .	117
The encoder cannot be added with the software . . . . .	117
The encoder cannot control a PTZ camera . . . . .	118
Video cannot be viewed through the Web browser . . . . .	118
<b>Appendix B HVE1(X) Specifications . . . . .</b>	<b>119</b>
Dimensions . . . . .	121
<b>Appendix C HVE4(X) Specifications . . . . .</b>	<b>123</b>
Dimensions . . . . .	125
<b>Appendix D HVE8(X) Specifications . . . . .</b>	<b>127</b>
Dimensions . . . . .	129
<b>Index . . . . .</b>	<b>131</b>



# Figures

Figure 2-1	Removing the Cover from an HVE8(X) Encoder . . . . .	27
Figure 2-2	Installing and Securing the HDD in an HVE8(X) Encoder. . . . .	27
Figure 2-3	Connecting the Data Line and the Power Cord . . . . .	27
Figure 2-4	HVE1 (X) Front Panel. . . . .	28
Figure 2-5	HVE1 (X) Rear Panel . . . . .	29
Figure 2-6	HVE4(X) Front Panel. . . . .	30
Figure 2-7	HVE4(X) Rear Panel . . . . .	31
Figure 2-8	HVE8(X) Front Panel. . . . .	32
Figure 2-9	HVE8(X) Rear Panel . . . . .	32
Figure 2-10	Alarm Input Connections for an Emerson Alarm . . . . .	33
Figure 2-11	Alarm Input Connections for a Normal Alarm . . . . .	34
Figure 2-12	Alarm Output Connections . . . . .	34
Figure 3-1	IP Utility . . . . .	38
Figure 3-2	Found Devices . . . . .	40
Figure 3-3	Editing Network Parameters in the Modify Network Parameters Window . . . . .	41
Figure 3-4	Honeywell IP Utility Window . . . . .	42
Figure 3-5	Login Window . . . . .	43
Figure 3-6	Encoder Main Page . . . . .	44
Figure 4-1	Live View Window . . . . .	45
Figure 4-2	Message Confirming Successful Image Capture . . . . .	47
Figure 4-3	RS-485 Port Settings. . . . .	48
Figure 4-4	PTZ Controls . . . . .	49
Figure 4-5	Preset List . . . . .	49
Figure 4-6	PTZ Linking Configuration . . . . .	50
Figure 4-7	Video Parameters Button in the Live View Window . . . . .	51
Figure 4-8	Expanded Video Parameters Menu . . . . .	51
Figure 5-1	Local Configuration Window. . . . .	53
Figure 5-2	Time Settings Interface . . . . .	54
Figure 5-3	Time Zone Selection . . . . .	55
Figure 5-4	NTP Server Time Synchronization. . . . .	55
Figure 5-5	Daylight Saving Time Settings. . . . .	56
Figure 5-6	TCP/IP Interface for Network Settings . . . . .	56
Figure 5-7	DNS Server Configuration . . . . .	57
Figure 5-8	Port Settings Interface . . . . .	57
Figure 5-9	DDNS Interface . . . . .	58

Figure 5-10	DDNS Settings - IP Server Settings . . . . .	58
Figure 5-11	DDNS Settings - DynDNS Settings . . . . .	59
Figure 5-12	DDNS Settings - PeanutHull Settings . . . . .	59
Figure 5-13	DDNS Settings - HVEDDNS Settings . . . . .	60
Figure 5-14	PPPoE Settings Interface . . . . .	61
Figure 5-15	Email Settings Interface . . . . .	62
Figure 5-16	NetHDD Settings Interface. . . . .	63
Figure 5-17	HDD Settings Interface . . . . .	64
Figure 5-18	SNMP Settings Interface. . . . .	65
Figure 5-19	SNMPv3 Settings Interface . . . . .	66
Figure 5-20	QoS Settings Interface. . . . .	67
Figure 5-21	FTP Settings Interface . . . . .	68
Figure 5-22	SOCKS Settings Interface . . . . .	69
Figure 5-23	NAT Interface . . . . .	70
Figure 5-24	HTTPS Interface . . . . .	71
Figure 5-25	Creating a Self-signed Certificate . . . . .	71
Figure 5-26	Bonjour Settings Interface . . . . .	72
Figure 5-27	IP Address Filter Configuration Interface . . . . .	73
Figure 5-28	Adding an IP Address to the IP Address Filter . . . . .	73
Figure 5-29	Advanced Settings Interface. . . . .	73
Figure 6-1	Display Settings Interface . . . . .	75
Figure 6-2	Camera Name Text Field . . . . .	76
Figure 6-3	Adjusting the OSD Display Position . . . . .	76
Figure 6-4	Copying Settings to Other Cameras . . . . .	76
Figure 6-5	Text Overlay Configuration Interface . . . . .	77
Figure 6-6	Copying Settings to Other Cameras . . . . .	77
Figure 6-7	Video Settings Interface . . . . .	78
Figure 6-8	Copying Settings to Other Cameras . . . . .	79
Figure 6-9	Snapshot Settings Interface . . . . .	80
Figure 6-10	Copying Settings to Other Cameras . . . . .	80
Figure 6-11	Motion Detection Settings Interface . . . . .	82
Figure 6-12	Arming Schedule Tab . . . . .	83
Figure 6-13	Linkage Method Tab for Motion Detection . . . . .	84
Figure 6-14	Selecting an Alarm Output Channel. . . . .	84
Figure 6-15	Alarm Output Settings Interface . . . . .	85
Figure 6-16	Edit Schedule Time Interface . . . . .	86
Figure 6-17	Selecting a Channel for Motion Event Detection . . . . .	86
Figure 6-18	Alarm Input Settings Interface . . . . .	87
Figure 6-19	Linkage Method Tab for Alarm Input Settings. . . . .	88
Figure 6-20	Video Loss Settings Interface . . . . .	89
Figure 6-21	Tamper-proof Settings Interface. . . . .	90
Figure 6-22	Exception Settings Interface. . . . .	91
Figure 6-23	Privacy Mask Settings Interface . . . . .	92
Figure 6-24	RS-232 Serial Port Settings Interface . . . . .	93
Figure 6-25	RS-232 Settings Interface . . . . .	94

Figure 6-26	RS-485 Serial Port Settings Interface . . . . .	94
Figure 7-1	Holiday Settings Interface . . . . .	98
Figure 7-2	Edit Holiday Interface . . . . .	98
Figure 7-3	Checking the Holiday Settings List . . . . .	98
Figure 7-4	Schedule Settings Interface . . . . .	99
Figure 7-5	Edit Schedule Interface . . . . .	100
Figure 7-6	Advanced Recording Parameters . . . . .	102
Figure 7-7	Copying the Settings to Other Cameras . . . . .	102
Figure 8-1	Playback Interface . . . . .	103
Figure 8-2	Calendar . . . . .	104
Figure 8-3	Playing Back Video . . . . .	104
Figure 8-4	Playback Slidebar . . . . .	105
Figure 8-5	Recorded Video Color Key . . . . .	105
Figure 9-1	User Management Settings Interface . . . . .	107
Figure 9-2	Add User Interface . . . . .	108
Figure 9-3	User Account - Modifying a User . . . . .	109
Figure 9-4	Modify User Interface . . . . .	109
Figure 9-5	Confirmation Message for Deleting a User . . . . .	109
Figure 10-1	Log Interface . . . . .	111
Figure 10-2	Basic Device Information Configuration Interface . . . . .	112
Figure 10-3	Maintenance Interface . . . . .	113
Figure 10-4	Confirmation Message for Rebooting the Encoder . . . . .	113
Figure 10-5	Restore or Default Interface . . . . .	114
Figure 10-6	Confirmation Message for Restoring or Returning the Encoder to Defaults . . . . .	114
Figure 10-7	Import Configuration File Interface . . . . .	114
Figure 10-8	Remote Upgrade Interface . . . . .	115



## Tables

Table 1-1	HVE Encoders Model Numbers . . . . .	21
Table 2-1	Tested Compatible HDDs. . . . .	26
Table 2-1	HVE1 Front Panel Elements . . . . .	28
Table 2-2	HVE1 Rear Panel Elements. . . . .	29
Table 2-3	HVE4 Front Panel Elements . . . . .	30
Table 2-4	HVE4 Rear Panel Elements. . . . .	31
Table 2-5	HVE8 Front Panel Elements . . . . .	32
Table 2-6	HVE8 Rear Panel Elements. . . . .	32
Table 3-1	Supported Web Browsers . . . . .	42
Table 3-2	Main Page Elements . . . . .	44
Table 4-1	Live View Toolbar . . . . .	46
Table 4-2	Connections for PTZ Cameras . . . . .	48
Table 4-3	PTZ Controls . . . . .	49
Table 4-4	Video Modes . . . . .	51
Table 5-1	Configurable Encoder Settings. . . . .	53
Table 5-2	Port Defaults . . . . .	57
Table 6-1	Customizeable Options for Video Main or Sub Streams. . . . .	78
Table 6-2	Default RS-485 Port Settings . . . . .	95
Table 7-1	Recording and Capturing Types . . . . .	101
Table 8-1	Playback Controls . . . . .	104



---

## Cautions and Warnings

---

	<p><b>CAUTION</b> RISK OF ELECTRIC SHOCK DO NOT OPEN</p>			<p>THIS SYMBOL INDICATES THAT DANGEROUS VOLTAGE CONSTITUTING A RISK OF ELECTRIC SHOCK IS PRESENT WITHIN THE UNIT.</p>
<p>CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE THE COVER. NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.</p>				<p>THIS SYMBOL INDICATES THAT IMPORTANT OPERATING AND MAINTENANCE INSTRUCTIONS ACCOMPANY THIS UNIT.</p>

Installation and servicing should be performed only by qualified and experienced technicians to conform to all local codes and to maintain your warranty.

**CAUTION** 12 V DC models require the use of CSA Certified/UL Listed Class 2 power adapters to ensure compliance with electrical safety standards.

---

## Regulatory Statements

---

### FCC Compliance Statement

**Information to the User:** This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

---

**Note** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

---

## Canadian Compliance Statement

This Class A digital apparatus complies with Canadian ICES-003.  
Cet appareil numérique de la Classe A est conforme à la norme NMB-003 du Canada.

## Manufacturer's Declaration of Conformance

### North America

The equipment supplied with this guide conforms to UL 60950-1 and CSA C22.2 No. 60950-1.

### Europe

The manufacturer declares that the equipment supplied is compliant with the essential requirements of the EMC directive 2004/108/EC, conforming to the requirements of standards EN 55022 for emissions, EN 50130-4 for immunity, and EN 60950 for electrical equipment safety.

## Waste Electrical and Electronic Equipment (WEEE)



**Correct Disposal of this Product** (applicable in the European Union and other European countries with separate collection systems).

This product should be disposed of, at the end of its useful life, as per applicable local laws, regulations, and procedures.

---

## Safety Instructions

---

**BEFORE OPERATING OR INSTALLING THE UNIT, READ AND FOLLOW ALL INSTRUCTIONS.**

**AFTER INSTALLATION, retain the safety and operating instructions for future reference**

1. **HEED WARNINGS** - Adhere to all warnings on the unit and in the operating instructions.

## 2. INSTALLATION

- Install in accordance with the manufacturer's instructions.
  - Installation and servicing should be performed only by qualified and experienced technicians to conform to all local codes and to maintain your warranty.
  - Do not install the unit in an extremely hot or humid location, or in a place subject to dust or mechanical vibration. The unit is not designed to be waterproof. Exposure to rain or water may damage the unit.
  - Any wall or ceiling mounting of the product should follow the manufacturer's instructions and use a mounting kit approved or recommended by the manufacturer.
3. **POWER SOURCES** - This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supplied to your facility, consult your product dealer or local power company.
  4. **HEAT** - Situate away from items that produce heat or are heat sources such as radiators, heat registers, stoves, or other products (including amplifiers).
  5. **WATER AND MOISTURE** - Do not use this unit near water or in an unprotected outdoor installation, or any area classified as a wet location.
  6. **MOUNTING SYSTEM** - Use only with a mounting system recommended by the manufacturer, or sold with the product.
  7. **ATTACHMENTS** - Do not use attachments not recommended by the product manufacturer as they may result in the risk of fire, electric shock, or injury to persons.
  8. **ACCESSORIES** - Only use accessories specified by the manufacturer.
  9. **CLEANING** - Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.
  10. **SERVICING** - Do not attempt to service this unit yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.
  11. **REPLACEMENT PARTS** - When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock or other hazards.

---

## Warranty and Service

---

Subject to the terms and conditions listed on the Product warranty, during the warranty period Honeywell will repair or replace, at its sole option, free of charge, any defective products returned prepaid.

In the event you have a problem with any Honeywell product, please call Customer Service at 1.800.323.4576 for assistance or to request a **Return Merchandise Authorization (RMA)** number.

Be sure to have the model number, serial number, and the nature of the problem available for the technical service representative.

Prior authorization must be obtained for all returns, exchanges, or credits. **Items shipped to Honeywell without a clearly identified Return Merchandise Authorization (RMA) number may be refused.**

# About This Document

This document introduces the HVE series of Audio/Video encoders. It covers how to install and operate an HVE encoder.

This document is intended for installers and operators.

---

## Overview of Contents

---

This document contains the following chapters and appendixes:

- [Chapter 1, Introduction](#), introduces the HVE encoders.
- [Chapter 2, Installing an HVE Encoder](#), describes the physical installation of an HVE encoder, including connections, installing a HDD, and descriptions of the front panel and the back panel.
- [Chapter 3, Connecting to an HVE Encoder via the Internet](#), describes how to find and connect to the encoder via an internet search engine.
- [Chapter 4, Viewing Live Video](#), describes how to view live video, how to capture a picture, and how to control a PTZ camera.
- [Chapter 5, Configuring the Encoder](#), describes how to configure the encoder settings, including IP settings, email settings, UPnP settings, HTTPS settings, and Bonjour settings.
- [Chapter 6, Configuring Camera Settings](#), describes how to use the encoder to remotely configure camera settings, including snapshot settings, alarm settings, video settings, and privacy zones.
- [Chapter 7, Configuring Recording and Capturing Settings](#), describes how to configure recording and capturing settings, including schedules.
- [Chapter 8, Playing Back Recorded Video](#), describes how to play back recorded video.
- [Chapter 9, Managing User Accounts](#), describes how to manage user accounts.
- [Chapter 10, Searching Logs, Viewing Device Information, and Maintaining the Encoder](#), describes how to search logs, view device information, restart or restore the encoder to factory default settings, import or export configuration files, and upgrade the encoder system.
- [Index](#), provides a searchable list for easy access to the document.

---

## Typographical Conventions

---

This document uses the following typographical conventions:

Font	What it represents	Example
Helvetica	Keys on the keyboard	Press Ctrl+C
Lucida	Values of editable fields that are mentioned in the body text of the document for reference purposes, but do not need to be entered as part of a procedure	The <b>Time from</b> field can be set to Hours:Minute:Seconds.
	Text strings displayed on the screen Syntax	The message Unauthorized displays. (object) entered
<b>Swiss721 BT Bold</b>	Words or characters that you must type. The word “enter” is used if you must type text and then press the Enter or Return key.	Enter the <b>password</b> .
	Menu titles and other items you select	Double-click <b>Open</b> from the <b>File</b> menu.
	Buttons you click to perform actions	Click <b>Exit</b> to close the program.
<i>Italic</i>	Placeholders: words that vary depending on the situation	Enter your <i>user name</i> .
	Cross-reference to external source	Refer to the <i>System Administrator Guide</i> .
	Cross-reference within document	See <i>Chapter 2, Installation</i> .

# 1

## Introduction

Incorporating the latest in encoding technology, the HVE(X) series of Audio/Video encoders digitizes analog video, and then can store that video on a Hard Disk Drive (HDD) or SATA drive, or transmit that video over the internet.

Using the latest embedded processor, the HVE(X) Series Audio/Video encoders provide:

- More powerful capabilities in audio/video encoding
- More data storage via microSD (HVE1, HVE1X, HVE4, HVE4X) or HDD (HVE8, HVE8X)
- More support for various network protocols
- More stability and reliability because the code is downloaded in FLASH

**Table 1-1 HVE Encoders Model Numbers**

<b>Model number</b>	<b>Description</b>
HVE1	1-channel, Audio/Video Encoder, microSD compatible, NTSC
HVE1X	1-channel, Audio/Video Encoder, microSD compatible, PAL
HVE4	4-channel, Audio/Video Encoder, microSD compatible, NTSC
HVE4X	4-channel, Audio/Video Encoder, microSD compatible, PAL
HVE8	8-channel, Audio/Video Encoder, SATA HDD compatible, NTSC
HVE8X	8-channel, Audio/Video Encoder, SATA HDD compatible, PAL

---

## Features

---

### Encoding Features

- H.264/MPEG4/MPEG2/MJPEG encoding
- Encoding up to 4CIF resolution
- Dual-stream encoding
- Either compound stream encoding or video stream encoding (with audio and video synchronization during compound stream encoding)

### Network Features

- One 10M/100Mbps adaptive Ethernet interface (PoE) for HVE1(X)/HVE4(X) models
- One 10M/100M/1000Mbps adaptive Ethernet interface for HVE8(X) models
- Multiple browser support: IE, FireFox, Chrome, and Safari
- Remote web browser access by HTTPS ensures high security
- Netfilter builds internet firewalls based on packet filtering
- QoS protocol enhances data transmission performance
- Support for SNMPv1/v2c/v3 simple network management protocol
- mDNS-based Apple's Bonjour protocol enables automatic device discovery
- Supports email notifications, FTP uploading, and alarm uploading by SOCKS v4/v5 proxy server
- Zero configuration networking (Zeroconfig) enables the device to automatically obtain the IPv4 link-local IP addresses (range: 169.254.1.0 to 169.254.254.255)
- Auto/manual port mapping by UPnP™
- Supports PSIA and ONVIF protocols
- Supports Honeywell IP Utility ver 1.53 for automatically searching and discovering the online devices in the local network area
- Automatically acquires IP addresses through the DHCP protocol
- Supports RTSP/RTP standard stream media protocol, which allows users to view live video through unicast
- Supports multicast addresses for live viewing of multiple cameras through the network
- Supports two-way audio and single-direction broadcasting
- Supports transmission via RS-232 and RS-485 transparent channels (except HVE1/HVE1X)
- Supports access to the internet through PPPoE, and supports Peanut Hull, DynDNS, and HVEDDNS
- Supports NTP for setting the time
- Connectible with a network HDD in NAS and IPSAN mode

- Supports sending emails by SMTP protocol, and supports attaching captured JPEG images and SSL encryption
- Supports remote JPEG image capturing with user-defined image resolution and quality

## PTZ

- Supports multiple PTZ protocols - Channels can be configured for:
  - Protocol type
  - RS-485 address
  - Baud rate
  - Data bit
  - Stop bit
  - Even and odd parity
  - Stream control method
  - Remote configuration for presets, patrols, and patterns
- Supports PTZ linkage configuration to link relay alarm inputs with the callup of predefined presets, patrols, and patterns

## Alarm

- Supports Relay Alarm Input
  - Configurable to either Normally Open (NO) mode or Normally Closed (NC) mode
  - Select from up to four different alarm arming periods
  - Supports triggering the corresponding alarm handling methods, relay alarm output, buzzer alarm, upload to control center, PTZ linkage, presets/patrols/pattern callup.
- Supports Relay Alarm Output
  - Connect relay alarm output with alarm devices for alarm handling within an arming period.

## Exceptions

- Supports Exception Alarm Handling
  - Exception alarms include network disconnect alarm, IP address conflict alarm, and illegal access alarm.
  - Supports multiple alarm handling methods, relay alarm output, buzzer alarm, and uploading to a center.
- Supports Exception Reboot
  - Software Watchdog –Inspects important device threads and system resources. Automatically reboots the device if an exception is detected.
  - Firmware Watchdog –Inspects the device firmware. Automatically reboots the device if an exception in system task scheduling is detected.

## Logs

Supports log classification into operation logs, alarm logs, exception logs, and information logs. Users can search and view all recorded system logs by date or type, as well as export the logs to text format over the network.

---

**Note** A hard disk/network disk/microSD card must be connected before log operation.

---

# 2

## Installing an HVE Encoder

This chapter explains:

- Encoder installation and connections
- HDD installation [HVE8(X) only]
- Encoder front and back panels
- Alarm connections

---

### Installation

---

The HVE1(X)/HVE4(X)/HVE8(X) encoders are highly advanced surveillance equipment that should be installed with care. If your encoder supports a HDD, then please ensure that you install a manufacturer-recommended HDD. See [Table 2-1](#) for a list of recommended HDDs.

During encoder installation:

- Use brackets for rack mounting.
- Ensure that there is ample room for audio and video cables.
- When installing the cables, ensure that the bend radius of the cables is no less than five times its diameter.
- Connect both the alarm and the RS-485 cable.
- Allow at least 2cm (~0.75 inch) of space between rack-mounted devices.
- Ensure that the encoder is grounded.
- Ensure that the environmental temperature is within -10°C–55°C (14°F–131°F).
- Ensure that the environmental humidity is within 10%–90%.

### Installing the Hard Disk Drive (HDD) [HVE8(X) only]

This section applies only to HVE8(X) models, which have room for a Hard Disk Drive (HDD) for recording.

## Preparing for Installation

Your HVE8(X)encoder comes from the factory without a HDD. Follow these instructions to install a HDD that is appropriate for your situation according to the total capacity, which is calculated in terms of the Schedule Recording Settings (please see [Configuring Scheduled Recording and Capturing on page 99](#)). The installation and removal of the hard disk should be done by qualified professionals.

Before installing a HDD, please ensure the power is disconnected from the device. Only a factory-recommended HDD should be used for this installation.

**Table 2-1 Tested Compatible HDDs**

SEAGATE	
Capacity	HDD Model
3T	ST3000VX000-9YW1
2T	ST2000VX000-9YW1
	ST2000VX002-1AH1
	ST2000VM003-1CT1
1T	ST1000VM002-9ZL1
	ST31000322CS
	ST1000VX000-9YW1
	ST31000526SV
500G	ST3500410SV
	ST3500411SV
250G	ST3250312CS
	ST3250310SV
	ST3250820SV
WD	
Capacity	HDD Model
2T	WD20EURS-63S
1T	WDC WD10EVDS-63U

**Required Tools:** Screwdriver

## Installing the HDD


1. Use the screwdriver to unfasten the screws on both sides and the rear panel of the encoder, then remove the cover from the chassis and set aside.

**Figure 2-1 Removing the Cover from an HVE8(X) Encoder**




2. Place the HDD into the slot on the chassis, and then secure it in position by tightening the screws at the bottom of the chassis.

**Figure 2-2 Installing and Securing the HDD in an HVE8(X) Encoder**



3. Remove the HDD data line from the accessories box. Plug one end of the data line to the circuit board, and the other end to the data line port on the HDD. Connect the power cord to the HDD in the same way.

**Figure 2-3 Connecting the Data Line and the Power Cord**



4. Replace the chassis cover, and then tighten the screws on both sides and the rear panel of the encoder.

## HVE1/HVE1X Encoder Front and Rear Panels

Figure 2-4 HVE1(X) Front Panel




Table 2-1 HVE1 Front Panel Elements

	Interface Element	Function
1	PWR LED Indicator	Lights red when the device is powered on. Lights orange when a microSD card is inserted.
2	VIDEO IN	BNC connector for video input.
3	LINE IN	3.5mm connector for two-way audio input. Connect to an audio input device or an active pick-up, a microphone, etc.
4	AUDIO OUT	3.5mm connector for audio output. Connect to an audio output device, such as a loudspeaker.
5	microSD	microSD interface for data storage up to 32 GB, Class 6 and above.
6	RESET	Restore to the factory default settings by holding the <b>RESET</b> button for more than 15 seconds after the power is turned on.

Figure 2-5 HVE1(X) Rear Panel




Table 2-2 HVE1 Rear Panel Elements

	Interface Element	Function
1	ALARM IN/OUT	Relay alarm input/output. The maximum voltage/current supported by the relay output is 12 V / 1 A.  <b>Note</b> The alarm output terminal provides no JP2 pin.
2	RS-485	RS-485 connection for pan, tilt, zoom control.
3	LAN	10M/100Mbps adaptive Ethernet interface (PoE).  The right LED indicator lights green when the network cable is connected. The left LED indicator blinks orange when receiving or transmitting data.
4	DC 12 V	12 V DC power supply
5	GND	Ground

---

**Note** The HVE1(X) model encoder does not support/supply a beeper/audio alert.

---

## HVE4/HVE4X Encoder Front and Rear Panels

Figure 2-6 HVE4(X) Front Panel




Table 2-3 HVE4 Front Panel Elements

	Interface Element	Function
1	PWR LED Indicator	Lights red when the device is powered on. Lights orange when a microSD card is inserted.
2	LINE IN	3.5mm connector for a two-way audio input. Connect to an audio input device or an active pick-up, a microphone, etc.
3	AUDIO OUT	3.5mm connector for audio output. Connect to an audio output device, such as a loudspeaker.
4	VIDEO IN	BNC connectors for video input.
5	AUDIO IN	Inputs for audio.

Figure 2-7 HVE4(X) Rear Panel




Table 2-4 HVE4 Rear Panel Elements

	Interface Element	Function
1	ALARM IN	Relay alarm input.
2	ALARM OUT	Relay alarm output. The maximum voltage/current supported by the relay output is 12 V / 1 A.
3	RS-232	Serial interface for configuring the encoder's parameters, or for using as a transparent channel. See <a href="#">Configuring the RS-232 Port as a Transparent Channel on page 93</a> .
4	RS-485	RS-485 connection for pan, tilt, zoom control.
5	RESET	Restore to the factory default settings by holding the RESET button for more than 15 seconds after the power is turned on.
6	microSD	microSD interface for data storage up to 32 GB, Class 6 and above.
7	LAN	10M/100Mbps adaptive Ethernet interface (PoE). The right LED indicator lights green when the network cable is connected. The left LED indicator blinks orange when receiving or transmitting data.
8	DC 12 V	12 V DC power supply
9	GND	Ground

---

**Note** The HVE4(X) model encoder does not support/supply a beeper/audio alert.

---

## HVE8/HVE8X Encoder Front and Rear Panels

Figure 2-8 HVE8(X) Front Panel



Table 2-5 HVE8 Front Panel Elements

	Interface Element	Function
1	POWER	Lights red when the device is powered on.
2	STATUS	Lights red when reading data from or writing data to the HDD.
3	Tx/Rx	Does not light when the encoder is not connected to the network. Blinks green when receiving or transmitting data. Blinks at a higher frequency when receiving or transmitting large amounts of data.

Figure 2-9 HVE8(X) Rear Panel




Table 2-6 HVE8 Rear Panel Elements

	Interface Element	Function
1	VIDEO IN	BNC connectors for video input.
2	LINE IN	3.5mm connector for two-way audio input. Connect to an audio input device or an active pick-up, a microphone, etc.
3	AUDIO OUT	3.5mm connector for audio output. Connect an audio output device, such as a loudspeaker.
4	AUDIO IN	Inputs for audio.

**Table 2-6 HVE8 Rear Panel Elements**


	Interface Element	Function
5	LAN	10/100/1000 Mbps adaptive Ethernet interface. The right LED indicator lights green when the network cable is connected. The left LED indicator blinks orange when data is transmitting/receiving.
6	RESET	Restore to the factory default settings by holding the RESET button for more than 15 seconds after the power is turned on.
7	RS-232, RS-485	Serial interface for configuring the encoder's parameters, or for using as a transparent channel. See <a href="#">Configuring the RS-232 Port as a Transparent Channel on page 93</a> . RS-485 connection for pan, tilt, zoom control.
8	ALARM IN	Relay alarm inputs.
9	ALARM OUT	Relay alarm outputs.
10	DC 12 V	12 V DC power supply
11	GND	Ground

## Connecting Alarms

### Connecting Alarm Inputs

HVE encoders support open/close relay inputs for alarms. For the alarm input signal not in open/close relay signal mode, please connect as shown in the following diagrams.

#### Alarm Input Connections for an Emerson Alarm

**Figure 2-10 Alarm Input Connections for an Emerson Alarm**


---

**Note** The relay input port on the encoder should be set to **NC** mode.

---

## Alarm Input Connections for a Normal Alarm


**Figure 2-11 Alarm Input Connections for a Normal Alarm**



## Connecting Alarm Outputs

HVE encoders support open/close relay inputs for the alarm output mode. Alarm inputs can be configured as NO or NC. AC and DC loads are different, so different alarm output connection methods are used for each. For alarm output connections, please connect as shown in the following diagram.

**Figure 2-12 Alarm Output Connections**




---

**Note** The HVE1(X) has no JJ1 relay.

---

Please note the different connections for JJ1 show in [Figure 2-12](#).

For the DC load, JJ1 can be safely used both in NC or NO modes. It is recommended that you use within the limit of 12 V / 1 A. For external AC input, the JJ1 relay must be open. The motherboard provides two jumpers, which each correspond to an alarm output. These jumpers are factory set to be connected.



# 3

## Connecting to an HVE Encoder via the Internet

The encoder can also be accessed through a Web browser for configuration and operation. You can use:

- Microsoft Internet Explorer 6/7/8/9
- Mozilla Firefox 3.5 and above
- Google Chrome 8 and above
- Apple Safari 5.0.2 and above

Windows XPSP1 and above (32-bit) is required.

Before you can access the encoder through the internet, you must configure the encoder's network settings. See [Configuring Network Parameters on page 39](#).

Before you start:

- Connect the device to the LAN, and prepare a PC that is connected to the same LAN with the device.
- Know the following:
  - Factory default device user name: **admin**
  - Factory default device password: **1234**
  - Factory default device IP address: **192.168.0.250**

---

## Installing the IP Utility

---

---

**Note** Before installing the Honeywell IP Utility, ensure that your encoder is connected to your network through a CAT5 Ethernet cable.

---

---

**Note** We recommend that you disable any Norton's AntiVirus software that might be running on your workstation.

---

To discover the IP device and configure the network settings, you must first install the IP Utility. For more information, see the user guide on the software CD that came with your encoder, or go to [www.honeywell.com/security](http://www.honeywell.com/security).


---

**Note** You must have Windows administrator privileges for the workstation onto which the Honeywell IP Utility is being installed.

---

1. Insert the software CD. Autorun will start the installation. If autorun does not start, browse to the CD drive, and run **Honeywell IP Utility Setup.exe**.
2. Follow the steps in the InstallShield wizard.
3. Log on to the IP Utility by double-clicking the IP Utility icon () on the desktop. The main IP Utility page appears.

**Figure 3-1 IP Utility**



---

## Configuring Network Parameters

---

If you do not know the IP address of the encoder, and this is not the first time you are using the encoder, then you can use SADP (IP finder) software or the Serial port tools to find the encoder's IP address, and to configure the IP address or other network parameters. We recommend that you change the default IP address for the first use.

---

**Note** For the first-time user, the default user name is **admin**, and the default password is **1234**. The default IP address is **192.168.0.250**.


---

## Searching for Online Devices

### Automatically Searching for Online Devices

After you log on to the IP Utility, the devices on the network are automatically discovered and listed in the Discovery pane. After the initial discovery, auto-refresh continues to discover newly added network devices.

Figure 3-2 Found Devices



**Note** Found devices will automatically appear 15 seconds after they go online. They will disappear from the list 45 seconds after they go offline.

## Manually Searching for Online Devices


Click the **Refresh** button  to manually refresh the Online Device list. The newly discovered devices will be added to the list.

**Note** You can click **Up** or **Down** buttons on each column heading to reorder the information. Click **>>** to expand the device table, and to hide the network parameter panel on the right side. Click **<<** to show the network parameter panel.

## Modifying Network Parameters

1. Click to select a connected device in the device list. The network parameters for the selected device appear in the **IP Network Settings** panel on the right side.
2. Configure the network settings.
  - **Automatically** – Click to select **Obtain an IP Address automatically**, enter the **Device Name**, then click **Apply**. The network settings are automatically assigned from the network server.
  - **Manually** – Click to deselect **Obtain an IP Address automatically**, then enter the **Device Name**, **IP Address**, **Subnet Mask**, and **Gateway**. Then click **Apply**.

**Figure 3-3** Editing Network Parameters in the Modify Network Parameters Window




---

**Note** Check the IP network settings before clicking **Apply**. Incorrect values might cause a failure when connecting the tool to the encoder.

---



---

**Note** Contact your network administrator if you have any network-related issues or questions about your network.

---

## Connecting to an Online IP Device

1. Connect to your IP device by double-clicking it in the **Discovery** pane, or by selecting it and clicking . The name for the connected device turns bold and blue, and the **Launch Browser** button becomes active.
2. Click **Launch Browser**. The Honeywell IP Utility login window opens.

**Figure 3-4 Honeywell IP Utility Window**




---

## Accessing an HVE Encoder Through a Web Browser

---

HVE encoders can be accessed through a Web browser for configuration and operation.

**Table 3-1 Supported Web Browsers**

Microsoft Internet Explorer 6, 7, 8, 9
--

Mozilla Firefox 3.5 and above
-------------------------------

Google Chrome 8 and above
---------------------------

Apple Safari 5.0.2 and above
------------------------------

Windows XP SP1 and above (32-bit)
-----------------------------------

1. Open the web browser.
2. Enter the encoder's IP address (default: **192.168.0.250**), and then press **Enter** on your keyboard.

The login window appears.

**Figure 3-5 Login Window**

---

**Note** When the HTTPS feature is enabled, the system uses the HTTPS login mode (**https://192.168.0.250**) by default when you enter the IP address. You can also enter **http://IP address/index.asp** (for example, **http://192.168.0.250/index.asp**) if you want to use the HTTP mode to log into the device.

---

3. Enter the user name (default: **admin**) and password (default: **1234**) to log into the system. The main page appears.
4. Download and install the plug-in from the main page. Follow the prompts.

---

**Note** After initial log in and plug-in installation, you will automatically enter the main page after logging in. [?]

---

When you have successfully downloaded and installed the plug-in, the encoder main page appears.

Figure 3-6 Encoder Main Page




Table 3-2 Main Page Elements

Element	Description
<b>Menu Bar</b>	Click to choose <b>Live View</b> , <b>Playback</b> , <b>Log</b> , <b>Configuration</b> .
<b>Device List</b>	Displays the connected encoder and its channels.
<b>Window division</b>	Select from 1-, 4-, and 8-channel view.
<b>Live Video Window</b>	Displays live video from the chosen camera.
<b>Toolbar</b>	Select actions while live viewing, such as live view, image capture, recording, turn audio on/off, etc.
<b>PTZ Control</b>	Control PTZ cameras, including camera lights and camera wiper.
<b>Preset Setting/Calling</b>	Set and recall presets for PTZ cameras.
<b>Video Parameters Settings</b>	Configure live video brightness, contrast, hue, and saturation.

# 4

## Viewing Live Video

When connected, Live View shows real-time video for the connected camera.

---

**Note** After your first successful login, the system will automatically enter the Live View page.

---


---

## Starting Live View

---

1. Click to select a window for viewing live video.

**Figure 4-1** Live View Window



2. Double-click a camera  in the device list to start live view.

## Starting Live View for All Cameras

Click  on the lower toolbar to start live view of all cameras on the device list.

## Live View Toolbar

**Table 4-1 Live View Toolbar**

Icon	Function
	Select the window division mode for display.
	Start Live View.
	Stop Live View.
	Capture an image in Live View.
	Manually start recording video.
	Manually stop recording video.
	Start PTZ control (must be supported by a PTZ camera).
	Previous Page.
	Next Page.
	Turn audio On.
	Turn audio Off.
	Start two-way audio.
	Stop two-way audio.

---

**Note** Before you can use two-way audio or can record with audio, you must select **Video & Audio** for the **Stream Type**. See **Video Type** in [Table 6-1](#) on [page 78](#).

---

## Full Screen Mode

Double-click on a live video window to view that video in the full-screen mode. Double-click again to return to normal mode.

---


## Capturing an Image

---

In Live View, click  in the toolbar to capture a live image.

When you have successfully captured an image, a message appears.

**Figure 4-2** Message Confirming Successful Image Capture



## Configuring the Save Path for Captured Images

To configure the saving path for captured images, go to **Configuration > Local Configuration**. See [Figure 5-1, Local Configuration Window](#), on [page 53](#).

---

**Note** The captured image is saved as a JPEG.

---

---

## Controlling a PTZ Camera

---

In Live View mode, you can use your encoder to control a PTZ camera. Using your mouse, you can click any of the 8 directional buttons in the display window to control a PTZ camera.

Before you begin controlling a PTZ camera, ensure that the following conditions are met:

- The connected camera supports PTZ control.
- The baud rate, PTZ control, and address on the encoder are configured the same as on the connected PTZ camera.

## Connecting to a PTZ Camera

Connect the R+ and R- terminals of the pan/tilt/zoom unit to the RS-485 D+ and the RS-485 D- terminals of the encoder.


**Table 4-2 Connections for PTZ Cameras**

On the camera, connect the	To the ...on the encoder
R+ terminal	RS-485 D+ terminal
R- terminal	RS-485 D- terminal

## Configuring for a PTZ Camera

1. Go to **Remote Configuration** > **Serial Port Settings** > **485 Serial Port**.
2. Ensure that the baud rate, PTZ control, and address on the encoder are configured the same as on the connected PTZ camera. See [Figure 4-3](#).

**Figure 4-3 RS-485 Port Settings**



RS-485 Settings	
Channel No.	Analog Camera 1
Baud Rate	9600
Data Bit	8
Stop Bit	1
Parity	None
Flow Ctrl	None
PTZ Protocol	Diamond
PTZ Address	1

---

**Note** The default for **Diamond** PTZ protocol is **Even** parity.

---

## Controlling a PTZ Camera

In Live View mode, you can use the PTZ control buttons to control a PTZ camera.

**Figure 4-4 PTZ Controls****Table 4-3 PTZ Controls**

Button	Function
	Zoom in (+) and out (-).
	Focus near (+) and far (-).
	Iris open (+) and close (-).
	Click to turn on/off a light (available if the connected PTZ camera supports a light/has an external light).
	Click to turn on/off the wiper (available when the connected PTZ camera supports a wiper function).
	Slide the bar to set the PTZ speed from level 1 to 7.

## Setting and Calling Presets

1. Select a preset number from the Preset list.

**Figure 4-5 Preset List**

2. Use the PTZ controls to move the PTZ camera's field of view to the desired position. You can:
  - Pan the camera to the left or right.
  - Tilt the camera up or down.
  - Zoom in or out.
  - Refocus the lens.
3. Click to save the current camera position.

---

**Note** Up to 256 presets can be configured, depending on the applied PTZ protocol.

---

### Calling a Preset

This feature allows you to instantly position the camera to a preset scene (camera lens orientation, focus, and zoom) when an event occurs.

You can recall pre-defined presets at any time.

In Live View mode, select a predefined preset from the list, then click .

## Linking a Preset to an Alarm

The preset can also be used to link to the alarm input when an alarm event occurs.

To link a preset to an alarm, configure as shown in [Figure 4-6](#).

**Figure 4-6 PTZ Linking Configuration**



The screenshot shows a configuration panel titled "PTZ Linking". It contains four rows of settings:

Setting	Value	Enable
PTZ Linking	A1	<input type="checkbox"/>
Preset No.	1	<input type="checkbox"/> Enable
Patrol No.	1	<input type="checkbox"/> Enable
Pattern No.	1	<input type="checkbox"/> Enable

For more information about configuring PTZ linkage settings, please see [Configuring RS-485 Settings on page 93](#).

---

## Configuring Video Parameters

---

You can configure the video parameters, including the brightness, contrast, saturation, and hue.


1. Click  in the bottom right corner of the Live View window.

Figure 4-7 Video Parameters Button in the Live View Window



The Video parameters menu expands.

Figure 4-8 Expanded Video Parameters Menu




2. Select the video mode appropriate for the lighting condition.

Table 4-4 Video Modes

Mode	Description
<b>Standard</b>	Suitable for general lighting conditions. (default setting)
<b>Indoor</b>	The image is relatively smoother.
<b>Outdoor</b>	The image is relatively clearer and sharper. Contrast and saturation are high.
<b>Dim Light</b>	The image is smoother than the other three modes.

3. Move the slider to set the brightness, contrast, saturation and hue from 0—255. The default value is **128** for the brightness, contrast, and hue, and is **136** for saturation.
4. Move the slider to set the sharpness from 0—15, and the denoising level to 0—3. The default value is **3** for the sharpness and **1** for the denoising level.

---

**Note** Click  to restore to the default settings.

---

# 5

## Configuring the Encoder

1. Click **Configuration** > **Local Configuration** to enter the Local Configuration window.

**Figure 5-1 Local Configuration Window**

The screenshot shows the 'Local Configuration' window with the following settings:

- Protocol: TCP
- Stream Type: Main Stream
- Image Size: Auto-fill
- Record File Size: 512M
- Live View Performance: Balanced
- Save record files to: C:\Web\DownloadFiles
- Save snapshots in live view to: C:\Web\DownloadFiles
- Save snapshots when playback to: C:\Web\DownloadFiles
- Save clips to: C:\Web\DownloadFiles
- Save downloaded files to: C:\Web\DownloadFiles

A 'Save' button is located at the bottom left of the window.

2. Configure the settings. Click **Browse** to change the directories for saving video files and pictures.

**Table 5-1 Configurable Encoder Settings**

Setting	Description
<b>Protocol Type</b>	Select the protocol type for stream transmission. <b>UDP:</b> Provides more real-time audio and video streams. <b>TCP:</b> Ensures complete delivery of streaming data and better video quality. However, real-time video quality is reduced.
<b>Stream Type</b>	Select <b>Main</b> or <b>Sub</b> stream type for Live View for the Web browser. See <a href="#">Configuring Video Settings on page 77</a> for the parameter settings for the Main and Sub streams.
<b>Image Size</b>	Select the window division.
<b>Record File Size</b>	Select the size of packed video files during manual recording. Select from <b>256MB</b> , <b>512MB</b> , or <b>1GB</b> .

**Table 5-1 Configurable Encoder Settings**

Setting	Description
<b>Live View Performance</b>	Choose the way that live video is displayed. Select from <b>Least Delay</b> , <b>Balanced</b> (delay and fluency), or <b>Best Fluency</b> .
<b>Save recorded files to</b>	Set the saving path for the manually recorded video files.
<b>Save snapshots in live view to</b>	Set the saving path for the manually captured pictures in live view mode.
<b>Save snapshots when in playback to</b>	Set the saving path for the pictures captured in playback mode.
<b>Save clips to</b>	Set the saving path for the video files clipped in playback mode.
<b>Save downloaded files to</b>	Set the saving path for the downloaded video files or pictures.

## Configuring Time Settings

1. Click **Remote Configuration** > **Device Parameters** > **Time Settings** to enter the Time Settings interface.

**Figure 5-2 Time Settings Interface**

The screenshot shows the 'Time Settings' interface with the following fields and options:

- Time Zone:** (GMT+00:00) Dublin, Edinburgh, London
- NTP:**
  - NTP
  - Server Address:** [Text input field]
  - NTP Port:** [Text input field]
  - Interval:** [Text input field] min.
- Manual Time Sync:**
  - Manual Time Sync
  - Device Time:** 2013-08-05T21:57:02
  - Set Time:** 2013-08-05T21:48:37   Sync. with computer time
  - Enable DST
  - Start Time:** Jan | First | Sun | 00
  - End Time:** Jan | First | Sun | 02
  - DST Bias:** 30min
- Save** button

2. Select the **Time Zone**. From the drop-down menu, select the Time Zone that is closest to the device's location.

**Figure 5-3 Time Zone Selection**

Time Settings

Time Zone (GMT+00:00) Dublin, Edinburgh, London

3. Select the time synchronization. Select from either **NTP** or **Manual Time Sync**.

**NTP:** Selecting NTP means that a Network Time Protocol (NTP) Server, which you have configured, will be used to ensure the accuracy of your encoder's date and time.

If the encoder is connected to a Dynamic Host Configuration Protocol (DHCP) network that has time properties that are configured, then the encoder automatically synchronizes with the time server.

**Manual Time Sync:** Selecting **Manual Time Sync** means that you configure the date and time in the Set Time field. You have the option of clicking **Sync. with computer time** to synchronize the encoder time with the time of the local PC.

### Configuring NTP Time Sync by NTP Server

- a. Click to enable **NTP**.

**Figure 5-4 NTP Server Time Synchronization**

NTP

NTP

Server Address 210.72.145.44

NTP Port 80

Interval 30 min.

- b. Enter the NTP server IP address.
- c. Enter the NTP port.
- d. Select an interval for the time between the two NTP server synchronizing actions. Select from **1** to **10080** minutes.

### Configuring the Time and Date Manually

- a. Click to enable **Manual Time Sync**.
- b. Click  to open the pop-up calendar used for setting the date and time.

Aug 2013

Sun	Mon	Tue	Wed	Thu	Fri	Sat
28	29	30	31	1	2	3
4	5	6	7	8	9	10
11	12	13	14	15	16	17
18	19	20	21	22	23	24
25	26	27	28	29	30	31
1	2	3	4	5	6	7

Time 22 : 6 : 27

OK

- c. Select the date and time from the popup calendar. Click  to quickly set the time.

4. Configure the Daylight Saving Time (DST) settings.
  - a. Click to enable **DST**.

**Figure 5-5 Daylight Saving Time Settings**

The screenshot shows the DST settings interface. At the top, there is a checkbox labeled 'Enable DST' which is checked. Below this are three rows of settings, each with a label and a dropdown menu:

- Start Time:** Jan, First, Sun, 00
- End Time:** Aug, Last, Sun, 02
- DST Bias:** 30min

At the bottom of the interface is a 'Save' button.

- b. Select the **Start Time** and **End Time** for the DST period, then select a **DST Bias** period.
5. Click **Save** to save the new settings.

---

## Configuring Network Settings

---

### Configuring TCP/IP Settings

Network settings must be properly configured before you can operate the encoder over a network.

1. Click **Remote Configuration** > **Network Settings** > **TCP/IP** to enter the TCP/IP settings interface.

**Figure 5-6 TCP/IP Interface for Network Settings**

The screenshot shows the TCP/IP settings interface. At the top, there is a 'NIC Settings' section with a dropdown menu for 'NIC Type' set to 'Auto'. Below this are several input fields and a checkbox:

- IPv4 Address:** 172.9.11.51
- IPv4 Subnet Mask:** 255.255.255.0
- IPv4 Default Gateway:** 172.9.11.1
- IPv6 Address:** 2001::240:3cff:fe3f:7269
- IPv6 Default Gateway:** fe80::20c:29ff:fe7b:1c18
- Mac Address:** 00:40:3c:3f:72:69
- MTU:** 1500
- DHCP:** (checkbox)

The unit 'Byte' is indicated at the bottom right of the MTU field.

2. Configure the NIC settings, including the NIC Type, IPv4 Address, IPv4 Subnet Mask, IPv4 Default Gateway, and MTU settings.

---

**Note** The MTU range is only from 500 to 1500.

---

3. If the DHCP server is available, then click the DHCP checkbox to automatically obtain an IP address and other network settings from that server.
4. If the DNS server settings are required for some applications (for example, for sending email), then carefully configure the Preferred DNS Server and Alternate DNS Server.

**Figure 5-7 DNS Server Configuration**

5. Click **Save** to save the new settings.

## Configuring Port Settings

You can set the encoder's ports, including the HTTP port, RTSP port, and HTTPS port.

1. Click **Remote Configuration > Network Settings > Port** to enter the Port settings interface.

**Figure 5-8 Port Settings Interface**

2. Enter the values for each port.

**Table 5-2 Port Defaults**

Port	Default
HTTP	80
RTSP	554
HTTPS	443

3. Click **Save** to save these new settings.

---

**Note** You will be asked to reboot the encoder to activate these new settings.

---

## Configuring DDNS Settings

If your encoder is set to use PPPoE as its default network connection, then you might set Dynamic DNS (DDNS) to be used for network access.

---

**Note** Prior registration with your DDNS provider is required before configuring the system to use DDNS.

---

1. Click **Remote Configuration** > **Network Settings** > **DDNS Settings** to enter the DDNS settings interface.

**Figure 5-9 DDNS Interface**

2. Click the **Enable DDNS** checkbox.
3. Select the **DDNS Type** from the drop-down menu. Select from **IPServer**, **DynDNS**, **PeanutHull**, and **HVEDDNS**.

### IPServer

- a. Select **IPSever** from the DDNS Type drop-down menu.
- b. Enter a **Server Address**.

**Figure 5-10 DDNS Settings - IP Server Settings**

- c. Click **Save** to save the new settings.

---

**Note** For the IP Server, you have to apply a static IP, subnet mask, gateway, and primary DNS from the ISP. The Server IP should be entered with the static IP address of the PC that runs the IPServer software.

---

## DynDNS

- a. Select **DynDNS** from the DDNS Type drop-down menu.

**Figure 5-11 DDNS Settings - DynDNS Settings**

DDNS

Enable DDNS

DDNS Type: DynDNS

Server Address: members.dyndns.org

Domain: 123.dyndns.com

User Name: 123

Password: •••••

Confirm: •••••

Save

- b. Enter a **Server Address** for DynDNS (for example, *members.dyndns.org*).
- c. Enter the domain that is obtained from the DynDNS website in the **Device Domain Name** text field.
- d. Enter the **User Name** and **Password** that is registered on the DynDNS website. Confirm the password.
- e. Click **Save** to save the new settings.

## PeanutHull

- a. Select **PeanutHull** from the DDNS Type drop-down menu.

**Figure 5-12 DDNS Settings - PeanutHull Settings**

DDNS

Enable DDNS

DDNS Type: PeanutHull

Server Address:

Domain:

User Name: 123.gicp.net

Password: •••••

Confirm: •••••

Save

- b. Enter the **User Name** and **Password** that is given by the PeanutHull website.

- c. Click **Save** to save the new settings.

## HVEDDNS

- a. Select **HVEDDNS** from the DDNS Type drop-down menu.

**Figure 5-13 DDNS Settings - HVEDDNS Settings**

The screenshot shows a configuration window titled 'DDNS'. At the top, there is a checkbox labeled 'Enable DDNS' which is checked. Below this is a dropdown menu for 'DDNS Type' with 'HVEDDNS' selected. Underneath are several text input fields: 'Server Address' containing 'www.hrgdvr-ddns.com', 'Domain', 'User Name', 'Password', and 'Confirm'. At the bottom of the form is a blue 'Save' button.

- b. Enter the encoder's **Domain** name.
- You can register the alias for the encoder's device name in the HVEDDNS server first, and then enter the domain name's alias in the encoder.

OR

- Enter the domain name directly in the encoder to create a new one.

---

**Note** If a new alias for the device's domain name is defined in the encoder, it will replace the old one that is registered on the server.

---

- c. Click **Save** to save the new settings.

## Configuring PPPoE Settings

Your encoder also allows access by Point-to-Point Protocol over Ethernet (PPPoE).

- Click **Remote Configuration** > **Network Settings** > **PPPoE Settings** to enter the PPPoE settings interface.

**Figure 5-14 PPPoE Settings Interface**

2. Check the **PPPoE** checkbox.
3. Enter a **User Name**, **Password**, and **Confirm Password** for PPPoE access.

---

**Note** The User Name and Password should be assigned by your ISP.

---

4. Click **Save** to save these new settings and exit the PPPoE Settings interface.

## Configuring Email Settings

The encoder can be configured to send alarm event-triggered email notifications to all designated receivers. The types of triggering events can include motion detection, video loss, and tampering.

Before configuring email settings, ensure that the following conditions are met:

- The encoder is connected to a local area network (LAN) that maintains an SMTP mail server. The network must also be connected to either an intranet or to the Internet, depending on the location of the email accounts to which you want to send notifications.
- You have configured the DNS server settings under **Remote Configuration > Network Settings > TCP/IP** before using the email function. See [Configuring TCP/IP Settings on page 56](#).

To configure email settings:

1. Enter the basic network settings (**Remote Configuration > Network Settings > TCP/IP**) to set the IPv4 address, IPv4 Subnet Mask, IPv4 Default Gateway, and the preferred DNS Server.
2. Click **Remote Configuration > Network Settings > Email** to enter the Email settings interface.

**Figure 5-15 Email Settings Interface**

3. Configure the following:

Configurable Field	Description
<b>Authentication</b>	Optional. If your email server requires authentication, check this checkbox to use authentication to log in to this server, and enter the login <b>User Name</b> and <b>Password</b> .
<b>SMTP Server</b>	The SMTP server IP address of the host name (for example, <i>smtp.263xmail.com</i> )
<b>SMTP Port</b>	The SMTP port. The default TCP/IP port used for SMTP is <b>25</b> .
<b>Enable SSL</b>	Click the checkbox to enable SSL if required by the SMTP server. When the SSL is enabled, the default TCP/IP port used for SMTP is <b>465</b> .
<b>Interval</b>	The interval refers to the time between two actions of sending attached pictures.
<b>Attach Image</b>	Check if you want to send email with attached alarm images.
<b>Sender</b>	The sender's name.
<b>Sender's Address</b>	The sender's address.
<b>Choose Receiver</b>	Select the receiver to which the Email is sent. Up to 3 receivers can be configured.
<b>Receiver</b>	The name of the user to be notified.
<b>Receiver's Address</b>	The address of the user to be notified.

4. Click **Save** to save these new settings.

For more information about email notifications, please see the following sections:

- [Configuring Motion Detection on page 81](#)
- [Configuring External Alarm Input on page 86](#)
- [Configuring a Video Loss Alarm on page 88](#)
- [Configuring the Tamper-proof Alarm on page 89](#)
- [Configuring Exception Handling on page 90](#)

## Adding the Network Disk

You should add the network disk before recording, playing back video, or searching the log.

Before adding the network disk, ensure that the following conditions are met:

- The network storage device is available within the network and is properly connected.
- The network storage device is configured with NAS or IP SAN mode (please refer to the User Manual for the IP SAN/NAS).

To add a network disk:

1. Click **Remote Configuration** > **Network Settings** > **NetHDD** to enter the NetHDD settings interface.

**Figure 5-16 NetHDD Settings Interface**

HDD No.	Server Address	File Path	Type
1	172.10.14.10	/dvr/honeywell	NAS
2			NAS
3			NAS
4			NAS
5			NAS
6			NAS
7			NAS
8			NAS

Save

2. Enter the **Network Storage System IP address** and the **File Path** in the correct fields.
3. Select the type of Network Storage System, either **IP SAN** or **NAS**.

**NAS Mode:** Enter the storage device's IP address. The default file path is */dvr/share*, in which the share name is user-defined when creating the DVR of the network storage.

**IP SAN Mode:** Enter the storage device's IP address. The default file path is *iqn.2004-05.storos.t-service ID*, in which the service ID is user-defined when creating the iSCSI volume of the network storage.

4. Click **Save** to add the configured network disk.
5. Initialize the added network disk.
  - a. Click **Remote Configuration** > **HDD Management** to enter the HDD settings interface.

**Figure 5-17 HDD Settings Interface**

The screenshot shows the 'HDD Management' interface. It features a table with columns for HDD No., Capacity, Free space, Status, Type, and Property. Below the table are dropdown menus for 'HDD No.' (set to HDD1) and 'Property' (set to R/W), along with 'Set' and 'Format' buttons. There is also a 'Select All' checkbox under the 'HDD Initialization' section.

HDD No.	Capacity	Free space	Status	Type	Property
<input checked="" type="checkbox"/> HDD01	298.09GB	252.00GB	Normal	Local	R/W
<input type="checkbox"/> HDD17	19.50GB	19.00GB	Normal	NAS	R/W

HDD No.  Property

HDD Initialization

Select All

You can see the capacity, free space, status, type, and property of the added network disk.

- b. If the status of the network disk is **Uninitialized**, select the disk from the list by checking the checkbox, and then click the **Init** button to start initializing the disk.

When the initialization is complete, the disk **Status** will become **Normal**.

6. Select the **HDD No.**, and select the **Property** for the added network disk. For the Property, choose from **R/W** or **Read-only**.

---

**Note** Please refer to the user manual for IP SAN/NAS for the creation of the File Path in Network Management.

---



---

**Note** Up to 8 NAS disks or IP SAN disks can be connected.

---

## Configuring SNMP Settings

Simple Network Management Protocol (SNMP) is an Internet-standard protocol for managing devices on IP networks. You can use SNMP to get camera status, parameters, and alarm-related information.

Before setting the SNMP, please ensure the following conditions are met:

- The SNMP software is downloaded.
- The encoder is configured to receive the device information via the SNMP port.

By setting the Trap Address, the device can send the alarm event and exception messages to the surveillance center.

---


**Note** The SNMP version you select should be the same as that of the SMNP software.

---

To configure the SNMP settings:

1. Click **Remote Configuration** > **Network Settings** > **SNMP** to enter the SNMP settings interface.

**Figure 5-18 SNMP Settings Interface**



The screenshot shows the SNMP configuration interface. It includes the following fields and controls:

- Enable SNMPv1**: A checkbox that is checked.
- Enable SNMP v2c**: An unchecked checkbox.
- Read SNMP Community**: A text input field containing the value "public".
- Write SNMP Community**: A text input field containing the value "private".
- Trap Address**: An empty text input field.
- Trap Port**: A text input field containing the value "162".

2. Configure the following:
  - a. Check the checkbox to enable **SNMPv1** or **SNMPv2c**.
  - b. Configure the **Read SNMP Community** (default: **public**) and the **Write SNMP Community** (default: **private**).
  - c. Configure the **Trap Address** (default: **empty**) and **Trap Port** (default: **162**).

---

**Note** You can enable both SNMPv1 and SNMPv2c.

---

3. After the SNMPv3 is enabled, you can configure the read username (default: **public**).  
**[Where does that window come from?]**

**Figure 5-19 SNMPv3 Settings Interface**

The screenshot displays the SNMPv3 Settings Interface. It features two identical sections for 'Read' and 'Write' operations. At the top, there is a checkbox for 'Enable SNMPv3' which is checked. Below this, the 'Read' section includes: 'Read UserName' (public), 'Security Level' (auth, priv), 'Authentication Algorithm' (MD5 selected, SHA unselected), 'Authentication Password' (masked with dots), 'Private-key Algorithm' (DES selected, AES unselected), and 'Private-key password' (masked with dots). The 'Write' section includes: 'Write UserName' (private), 'Security Level' (auth, priv), 'Authentication Algorithm' (MD5 selected, SHA unselected), 'Authentication Password' (masked with dots), 'Private-key Algorithm' (DES selected, AES unselected), and 'Private-key password' (masked with dots). At the bottom, the 'SNMP Port' is set to 161. A 'Save' button is located at the very bottom of the interface.

---

**Note** By default, SNMPv1, SNMPv2c, and SNMPv3 are disabled.

---

4. Select a security level. Choose from:
  - **no auth, no priv**
  - **auth, no priv**
  - **no auth, priv**
  - **auth, priv**
5. Configure the Authentication Algorithm and Private-key Algorithm parameters.
  - You can configure the Authentication Algorithm and Private-key Algorithm parameters if the security level is set to **auth, priv**.
  - You cannot configure the Authentication Algorithm and Private-key Algorithm parameters if the security level is set to **no auth, no priv**.
6. Set the **SNMP Port** (default: **161**).
7. Click **Save** to save these new settings.

## Configuring QoS Settings

QoS (Quality of Service) can help with network delay and network congestion by configuring the priority in which data is sent. The use of a QoS-aware network can prioritize traffic and therefore allow critical flows to be served before lower priority flows.

The encoder can mark the data packets for video/audio, event/alarm, and management network traffic with different DSCP values which identify different priority levels for sending data.

To configure QoS settings:

1. Click **Remote Configuration** > **Network Settings** > **QoS** to enter the QoS settings interface.

**Figure 5-20 QoS Settings Interface**

2. Check the checkbox to enable the QoS function.
3. Enter **DSCP (Differentiated Services Codepoint)** value for the following:
  - Video/Audio
  - Event/Alarm
  - Management traffic

The DSCP value is used to mark the traffic's IP header. It defines the priority level for the specified type of traffic, for example, how much bandwidth to reserve for it.

The valid range for DSCP is 0 to 63.

Higher DSCP values indicate higher priority levels.

4. Click **Save** to save these new settings.

---

**Note** You will have to reboot the encoder to activate the settings.

---

## Configuring FTP Settings

Images captured by the encoder can be uploaded to an FTP server.

1. Click **Remote Configuration** > **Network Settings** > **FTP** to enter the FTP settings interface.

**Figure 5-21 FTP Settings Interface**

2. Check the checkbox to enable FTP.
3. Configure the following settings:
  - Server Address
  - Port
  - User Name
  - Password
  - Directory
  - Upload Type
    - a. **Directory:** In the Directory Structure field, you can select the root directory, parent directory, and child directory.  
 If you select **Parent Directory**, then you have the option to use the Device Name, Device Number, or Device IP for the name of the directory  
 If you select **Child Directory**, then you can use the Camera Name or Camera No. as the name of the directory.
    - b. **Upload Type:** Check to enable uploading the captured picture to the FTP server.
4. Click **Save** to save these new settings.

## Configuring SOCKS Settings

SOCKEt Secure (SOCKS) is an Internet protocol that routes network packets between a client and a server through a proxy server. This feature is useful if the encoder is located on a local network behind a firewall, and Email notifications, FTP uploads, alarms, and such need to be sent to a destination outside the local network (such as the Internet). SOCKS4 and SOCKS5 are supported. SOCKS5 provides authentication so only authorized users may access a server.

To configure SOCKS settings:

1. Click **Remote Configuration** > **Network Settings** > **SOCKS** to enter the SOCKS settings interface.

**Figure 5-22 SOCKS Settings Interface**

SOCKS

Enable SOCKS

Server 172.9.11.61

Server Port 1080

Server Type SOCKS5

User Name

Password

Confirm

Local networks Use semicolon(;) to separate local networks, use slash (/) to separate ip address and network mask, example: 192.168.1.2/255.255.255.0;192.168.1.3/255.255.255.0

Save

2. Configure the following settings:
  - **Server:** Enter the address for the SOCKS server.
  - **Server Port:** Enter the port for the SOCKS server (default: **1080**).
  - **Server Type:** Select the server type, either **SOCKS4** or **SOCKS5**. When you select SOCKS5, you can enable the user authentication on the server, and then enter the login user name and password.
  - **Local Networks:** Define the local network segment which does not need to use the SOCKS proxy server. You can enter multiple network addresses and use the semicolon (;) to separate them. For example, *10.0.0.0/255.0.0.0; 172.16.0.0/255.240.0.0*.
3. Click **Save** to save these new settings.

## Configuring UPnP™ Settings

UPnP (Universal Plug and Play) permits the device seamlessly discover the presence of other network devices on the network and establish functional network services for data sharing, communications, etc. If you want to use the UPnP function to quickly connect the device to the WAN via a router, then you should configure the UPnP parameters of the device.

Before configuring UPnP settings, please ensure the following conditions are met:

- Enable the UPnP for the router to which your device is connected.
- If the network working mode of the device is set to **Multi-address**, then the Default Route of the device should be in the same network segment as that of the LAN IP address of the router.

To configure UPnP settings:

1. Click **Remote Configuration** > **Network Settings** > **NAT** to enter the NAT settings interface.

**Figure 5-23 NAT Interface**

Protocol Name	Enable	External Port	Router LAN IP	Router WAN IP	Status
HTTP	Yes	39220	192.168.1.2	172.9.11.40	Valid
RTSP	Yes	55872	192.168.1.2	172.9.11.40	Valid
HTTPS	Yes	38264	192.168.1.2	172.9.11.40	Valid
SDK	Yes	44386	192.168.1.2	172.9.11.40	Valid

2. Check to **Enable UPnP**.
3. Select the **Port Mapping Mode** to either **Auto** or **Manual**.  
When you select **Auto**, then the mapping ports can be automatically assigned by the router. Go to [step 5](#). [\[?\]](#)  
When you select **Manual**, then you should continue to [step 4](#) to edit the mapping ports.
4. Configure the HTTP Port (for access by WEB browser), SDK Port Mapping (for access by client software), RTSP Port, and HTTPS Ports.

---

**Note** You can use the default port number, or change it according to your requirements.  
The **Ports** field indicate the port number for mapping in the router.

---

5. Click **Save** to save these new settings.  
After successfully configuring port mapping, you can view the port mapping status on the Port Mapping area of the NAT interface.

## Configuring HTTPS Settings

HTTPS (Hyper Text Transfer Protocol Secure) ensures the transferred data is encrypted using Secure Socket Layer (SSL) or Transport Layer Security (TLS). HTTPS provides authentication of the web site and the associated web server that the encoder is communicating with, and creates a secure channel over an insecure network. HTTPS URLs begin with **https://** and use port **443** by default.

To configure HTTPS settings:

1. Click **Remote Configuration** > **Network Settings** > **HTTPS** to enter the HTTPS settings interface.

**Figure 5-24 HTTPS Interface**

The screenshot shows the HTTPS configuration interface with the following sections:

- HTTPS**: A checkbox labeled "Enable HTTPS (Please make sure that the certificate is already installed)".
- Create**: Two buttons labeled "Create" next to "Create Self-signed Certificate" and "Create Certificate Request".
- Install Signed Certificate**: A "Certificate Path" input field with "Browse" and "Upload" buttons.
- Created Request**: A "Created Request" input field with "Delete" and "Download" buttons.
- Installed Certificate**: An "Installed Certificate" input field with a "Delete" button.
- A "Save" button at the bottom.

2. Create the self-signed certificate or the authorized certificate.

**Creating a self-signed certificate:**

- a. Click **Create** next to **Create Self-signed Certificate**.

A dialog box opens.

**Figure 5-25 Creating a Self-signed Certificate**

The dialog box contains the following fields and options:

- Country**: Input field with "CN" and a note "\* example: CN".
- Hostname/IP**: Input field with "172.6.23.67" and a note "\*".
- Validity**: Input field with "200" and a note "Day \* range :1-5000".
- Password**: Input field.
- State or province**: Input field.
- Locality**: Input field.
- Organization**: Input field.
- Organizational Unit**: Input field.
- Email**: Input field.
- Buttons**: "OK" and "Cancel" buttons at the bottom right.

- b. Enter the country, host name/IP, validity, and other information.
- c. Click **OK** to save these new settings.

**Creating an authorized certificate:**

- a. Click **Create** next to **Create Certificate Request**.
  - b. Download the certificate request and submit it to the trusted certificate authority for signature.
  - c. After receiving the signed valid certificate, import the certificate to the device.
3. When you have successfully created and installed the certificate, check the checkbox to enable the HTTPS function.

---

**Note** After the HTTPS feature is enabled, the system will use the HTTPS login mode by default when you input the IP address (for example, `https://192.168.0.250`). You can also input **http://IP address/index.asp** (for example, `http://192.168.0.250/index.asp`) if you want to use HTTP mode to log into the device.

---

## Configuring Bonjour Settings

Bonjour is enabled by default, and the video encoder can be automatically detected by operating systems and clients that support this protocol. Bonjour is required for discovery using the Honeywell IP Utility.

Before you configure Bonjour settings, please ensure that the following condition is met:

- The Bonjour plugin is installed on your PC before enabling the Bonjour function.

To configure Bonjour settings:

1. Click **Remote Configuration** > **Network Settings** > **Bonjour** to enter the Bonjour settings interface.

**Figure 5-26 Bonjour Settings Interface**

2. Click the checkbox to **Enable Bonjour**.
3. Edit the device's name. The name is shown when the device is detected by the system.

---

**Note** You can use only letters, numbers, and "-" for the device's name.

---

4. Click **Save** to save these new settings.

## Configuring the IP Address Filter

By enabling the IP Address Filter, you can allow or forbid certain IP addresses access to the encoder.

Up to 256 IP addresses can be added to the list (allowed/forbidden) by Web Browser.

1. Click **Remote Configuration** > **Network Settings** > **IP Address Filter** to enter the IP address filter settings interface.

**Figure 5-27 IP Address Filter Configuration Interface**

IP Address Filter

Enable IP Address Filter

IP Address Filter Type: Forbidden

Add Modify Delete Clear

No.	IP
-----	----

Note: Before you enable the "Forbidden" filtering type, please make sure the IP address you are using is not in the IP addresses list, and before you enable the "Allowed" filtering type, please make sure the IP address you are using has been added to the IP addresses list; or else the network access from this IP address may be disconnected.

Save

2. Check the checkbox to **Enable IP Address Filter**.
3. Select the filter type for the IP address. Choose from **Allowed** or **Forbidden**.
4. Click **Add** to add the IP address to the IP address filter.

**Figure 5-28 Adding an IP Address to the IP Address Filter**

IP Address: 192.8.23.3

OK Cancel

---

**Note** Up to 256 IP addresses can be added to the allowed/forbidden list, by Web browser.

---

5. Click **Save** to save these new settings.

## Configuring the Multicast Address

The multicast address can be configured to allow live viewing of more than the maximum number of cameras through the network.

A multicast address spans the Class-D IP range of 224.0.0.0 to 239.255.255.255. We recommend that you use an IP address ranging from 239.252.0.0 to 239.255.255.255.

1. Click **Remote Configuration** > **Network Settings** > **Advanced** to enter the Advanced Settings interface.

**Figure 5-29 Advanced Settings Interface**

Advanced

Multicast Address: 239.252.82.36

Save

2. Enter the multicast address in the text field.
3. Click **Save** to save these new settings.

# 6

## Configuring Camera Settings

### Configuring OSD Settings

#### Configuring Display Settings

You can customize the camera name and configure and format the time display as it appears on the screen.

1. Click **Remote Configuration** > **Camera Settings** > **Display Settings** to enter the Display Settings interface.

**Figure 6-1** Display Settings Interface



The screenshot displays the 'Display Settings' interface. At the top, there are two dropdown menus: 'Channel No.' set to 'Analog Camera1' and 'Camera Name' set to 'Camera 01' with a '(cannot copy)' note. Below these is a 'Live View' window showing a highway with various vehicles, including a red bus and a white van, with a red 'Camera 01' label in the bottom right corner. To the right of the live view is the 'OSD Settings' section, which includes several checkboxes and dropdown menus: 'Display Name' (checked), 'Display Date' (unchecked), 'Display Week' (unchecked), 'Time Format' (set to '24-hour'), 'Date Format' (set to 'MM-DD-YYYY'), and 'Display Mode' (set to 'Not transparent & Not flashing').

2. Select a camera from the drop-down menu.

3. Enter a camera name in the **Camera Name** text field.

**Figure 6-2 Camera Name Text Field**



4. Click the boxes next to **Display Name**, **Display Date**, and **Display Week** to enable/disable the display of those elements.
5. Select the **Time Format**, **Date Format**, and **OSD Display** modes from their drop-down menus.
6. Adjust the location of the OSD by moving the text frame on the preview image.

**Figure 6-3 Adjusting the OSD Display Position**



7. (Optional) If you want to copy the display settings for the current camera to other cameras, expand the **Copy to Camera** panel, and select the camera(s) to which to copy the settings, or click **Select All** to select all cameras.

**Figure 6-4 Copying Settings to Other Cameras**



8. Click **Save** to save these new settings.

## Configuring Text Overlay

1. Click **Remote Configuration** > **Camera Settings** > **Text Overlay Settings** to enter the Text Overlay Settings interface.

**Figure 6-5 Text Overlay Configuration Interface**

2. Select a camera from the drop-down list.
3. Click the checkbox to enable editable text for that camera. In the editable text field next to the camera, enter the desired text for the overlay.
4. Click **Save** to save these new settings.
5. Adjust the position of the overlaid text by moving the text frame on the preview image.
6. (Optional) If you want to copy the text overlay settings for the current camera to other cameras, expand the **Copy to Camera** panel, and select the camera(s) to which to copy the settings, or click **Select All** to select all cameras.

**Figure 6-6 Copying Settings to Other Cameras**

7. Click **Save** to save these new settings.

---

## Configuring Video Settings

---

1. Click **Remote Configuration** > **Camera Settings** > **Video Settings** to enter the Video Settings interface.

**Figure 6-7 Video Settings Interface**

The screenshot shows the 'Video Settings' interface with the following configurations:

- Channel No.: Analog Camera1
- Stream Type: Main Stream(Normal)
- Video Type: Video&Audio
- Resolution: 704\*480
- Bitrate Type: Variable
- Video Quality: Medium
- Frame Rate: 30
- Max. Bitrate: 1792 Kbps
- I Frame Interval: 100
- Video Encoding: H.264

Below the settings, there is a 'Copy to Camera' section with a 'Select All' checkbox and individual checkboxes for cameras A1 through A8. A 'Save' button is located at the bottom.

2. Select a camera from the drop-down list.
3. Select the **Stream Type** for the camera. Choose from **Main Stream (Normal)**, **Main Stream (Event)**, or **Sub Stream**.

**Main Stream** - Used for recording and live viewing with good bandwidth.

**Sub Stream** - Used for live viewing when the bandwidth is low.

For more information about changing the main stream to sub stream for live viewing, please see [Local Configuration Window on page 53](#).

4. Customize the following settings for the selected Main or Sub stream:

**Table 6-1 Customizeable Options for Video Main or Sub Streams**


Option	Description
<b>Video Type</b>	Select the video type for streaming, including a video plus audio composite stream. The audio signal will be recorded only when the Video Type is selected as Video&Audio.
<b>Resolution</b>	Select the resolution for the video input.
<b>Bitrate Type</b>	Select the bitrate type as <b>Constant</b> or <b>Variable</b> .
<b>Video Quality</b>	When Variable is selected for the Bitrate type, you can choose from up to 6 levels of video quality.
<b>Frame Rate</b>	Set the frame rate from <b>1</b> to <b>30</b> fps.  The Frame Rate is used to describe the frequency at which a video stream is updated. This rate is measured in frames per second (fps). Choose a higher frame rate when there is movement in the video stream, as the higher frame rate maintains image quality.

**Table 6-1** Customizable Options for Video Main or Sub Streams

Option	Description
<b>Max. Bitrate</b>	Set the maximum bit rate from <b>32</b> to <b>8192</b> Kbps.
<b>I Frame Interval</b>	Set the I frame interval from <b>1</b> to <b>400</b> (frames). The higher value results in lower video quality.
<b>Video Encoding</b>	Select the video encoding standard. Choose from <b>H.264</b> , <b>MPEG2</b> , <b>MPEG4</b> , or <b>MJPEG</b> .

**Note** When the MJPEG video encoding standard is selected, the frame rate can be set from **1** to **15** fps, and the maximum bitrate is not configurable.

- (Optional) If you want to copy the video settings for the current camera to other cameras, expand the **Copy to Camera** panel, and select the camera(s) to which to copy the settings, or click **Select All** to select all cameras.

**Figure 6-8** Copying Settings to Other Cameras

- Click **Save** to save these new settings.

## Configuring Snapshot Settings

You can configure scheduled snapshots and event-triggered snapshots. The captured pictures can be stored on a HDD, on an SD card (if supported) or on the netHDD. You can also upload the event-triggered snapshots to an FTP server.

To configure snapshot settings:

- Click **Remote Configuration** > **Camera Settings** > **Snapshot** to enter the Snapshot settings interface.

**Figure 6-9 Snapshot Settings Interface**

**Snapshot**

Channel No. Analog Camera1

**Timing**

Format JPEG

Resolution 352\*240

Quality Medium

Interval 5 second

**Event-Triggered**

Format JPEG

Resolution 352\*240

Quality Medium

Interval 5 second

**Copy to Camera**

Select All

A1  A2  A3  A4  A5  A6  A7  A8

Save

2. Select a channel for capturing pictures.
3. Configure the timed snapshot and event-triggered snapshot parameters, including the format, resolution, quality, and the time that passes between two snapshots (interval). For the interval, select from **1 sec**, **2 sec**, **3 sec**, **4 sec**, and **5 sec**.
4. (Optional) If you want to copy the snapshot settings for the current camera to other cameras, expand the **Copy to Camera** panel, and select the camera(s) to which to copy the settings, or click **Select All** to select all cameras.

**Figure 6-10 Copying Settings to Other Cameras**

**Copy to Camera**

Select All

A1  A2  A3  A4  A5  A6  A7  A8

Save

5. Click **Save** to save these new settings.

---

**Note** Timed snapshots are stored on the HDD, the SD card (if supported), or the netHDD. Event-triggered snapshots can be uploaded to FTP. Check the **Upload to FTP** checkbox  Upload to FTP in either the Motion Detection Settings or the Alarm Input interface.

---

For more information, please see [Configuring Motion Detection on page 81](#) or [Configuring an External Alarm Input on page 86](#).

For more information about FTP, please see [Configuring FTP Settings on page 67](#).

---

## Configuring and Handling Alarms

---

This section explains how to configure the encoder to respond to alarm events. You can configure the following settings:

- Motion Detection
- External Alarm Input
- Video Loss Alarms
- Tamper-proof Alarms
- Handling Exceptions

Alarm events can trigger alarm actions, such as:

- Notifying the Surveillance Center
- Sending Emails
- Triggering Alarm Output

### Configuring Motion Detection

Motion Detection is a feature which can detect a motion event in the surveillance scene, then alert personnel and record the video for the motion event.

Steps for Configuring for Motion Detection:

1. Configure the Motion Detection Area. See [Configuring the Motion Detection Area on page 81](#).
2. Configure the Arming Schedule for Motion Detection. See [Configuring the Arming Schedule on page 82](#).
3. Configure the Alarm Actions that are taken when a motion event is detected. See [Configuring the Alarm Actions for Motion Detection on page 83](#).

#### Configuring the Motion Detection Area

1. Click **Remote Configuration** > **Camera Settings** > **Motion Detection** to enter the Motion Detection settings interface.

**Figure 6-11 Motion Detection Settings Interface**

2. Select a camera to configure for motion detection.
3. Check the checkbox to **Enable Motion Detection**.
4. Click the **Draw Area** button . Draw a motion detection area by clicking and dragging the mouse in the live video image.

---

**Note** You can draw up to 8 motion detection areas within the same image.

---

5. Click **Stop Drawing**  to finish drawing the motion detection area. Click **Clear All**  to clear all drawn areas.
6. Move the slide bar  to set the sensitivity for the camera.
7. Click **Save** to save these new settings.

## Configuring the Arming Schedule

1. Click the **Arming Schedule** tab.

Figure 6-12 Arming Schedule Tab

Motion Detection

Channel No. Analog Camera1

Enable Motion Detection

Area Settings **Arming Schedule** Linkage Method

Edit

	0	2	4	6	8	10	12	14	16	18	20	22	24
Mon													
Tue													
Wed													
Thu													
Fri													
Sat													
Sun													

Save

2. Click **Edit** to edit the arming schedule.

---

**Note** The timing segments cannot overlap. Up to 8 segments can be configured for each day.  
The **Holiday** option is available in the Schedule drop-down list only after you have enabled a holiday schedule in **Holiday Settings**.

---

3. Choose the day for which you want to set the arming schedule.
4. Click  to set the time period for the arming schedule.
5. (Optional) After setting the arming schedule, you can copy the schedule to other days.
6. Click **OK** to save these new settings.

## Configuring the Alarm Actions for Motion Detection

You can specify the what happens (alarm type) when an event is triggered.

1. Click the **Linkage Method** tab to enter the setting interface.

**Figure 6-13 Linkage Method Tab for Motion Detection**

Motion Detection

Channel No. Analog Camera1

Enable Motion Detection

Area Settings Arming Schedule **Linkage Method**

Normal Linkage

Full Screen Monitoring  Audible Warning  Notify Surveillance Center  Send Email  Upload to FTP

Trigger Alarm Output  Select All

A->1  A->2  A->3  A->4

Trigger Channel  Select All

A1  A2  A3  A4  A5  A6  A7  A8

Save

2. Select the alarm linkage method(s), including **Audible Warning**, **Notify Surveillance Center**, **Send Email**, and **Upload to FTP**.

**Audible Warning:** Triggers an audible beep from the encoder when an alarm is detected. (HVE8/HVE8X models only)

**Notify Surveillance Center:** Sends an exception or alarm signal to a remote alarm host when an event occurs. The alarm host is the PC that has the Remote Client installed.

**Send Email:** Sends an email with alarm information to a specified user or users when an event occurs.

---

**Note** To send an email when an event occurs, you first must go to the network setting interface to set the related parameters. See [Configuring Email Settings on page 61](#).

---

**Upload to FTP:** Captures an image when an alarm is triggered, and uploads the picture to an FTP server.

3. Select the channel for which you want to trigger an external alarm output when a motion detection event occurs.


**Figure 6-14 Selecting an Alarm Output Channel**

Trigger Alarm Output  Select All

A->1  A->2  A->3  A->4

4. Configure Alarm Output settings.
  - a. Click **Remote Configuration** > **Alarm Settings** > **Alarm Output** to enter the Alarm Output settings interface.

**Figure 6-15 Alarm Output Settings Interface**



- b. Select one alarm output channel in the **Alarm Output** drop-down list.
- c. The Delay time can be set to **5sec, 10sec, 30sec, 1min, 2min, 5min, 10min,** or **Manual**. The Delay refers to the time duration that the alarm output remains in effect after an alarm occurs.

---

**Note** If you choose **Manual**, then you need to manually disable the alarm output.

---

- d. Click **Edit** to enter the **Edit Schedule Time** interface.

**Figure 6-16 Edit Schedule Time Interface**

Period	Start Time	End Time
1	00 : 08	12 : 00
2	14 : 00	18 : 00
3	00 : 00	00 : 00
4	00 : 00	00 : 00
5	00 : 00	00 : 00
6	00 : 00	00 : 00
7	00 : 00	00 : 00
8	00 : 00	00 : 00

Copy to Week:  Select All

Mon  Tue  Wed  Thu  Fri  Sat  Sun

The time schedule configuration is the same as the setting of the Arming Schedule for Motion Detection.

See [Configuring the Arming Schedule on page 82](#) for more about the Arming Schedule.

- e. Return to the **Alarm Output Settings** interface, then click **Save** to save these new settings.
5. Select the channel on which you want to trigger recording when a motion detection event occurs.

**Figure 6-17 Selecting a Channel for Motion Event Detection**

Trigger Channel  Select All

A1  A2  A3  A4  A5  A6  A7  A8

6. Click **Save** to save these new settings.

## Configuring an External Alarm Input

1. Click **Remote Configuration** > **Alarm Settings** > **Alarm Input** to enter the Alarm Input settings interface.

Figure 6-18 Alarm Input Settings Interface

The screenshot shows the 'Alarm Input Settings' interface. At the top, there are four input fields: 'Alarm Input No.' with a dropdown menu showing 'A<-1', 'IP Address' with a text box containing 'Local', 'Alarm Type' with a dropdown menu showing 'NO', and 'Alarm Name' with a text box containing '(cannot copy)'. Below these fields are two tabs: 'Arming Schedule' (which is selected) and 'Linkage Method'. An 'Edit' button is located to the right of the tabs. The main area is a grid for the arming schedule. The columns represent hours from 0 to 24 in increments of 2. The rows represent days of the week: Mon, Tue, Wed, Thu, Fri, Sat, and Sun. The entire grid is filled with a blue color, indicating that the alarm is armed for all hours and days. Below the grid is a 'Copy to Alarm' section with a 'Select All' checkbox and seven checkboxes labeled A<-1 through A<-8. A 'Save' button is located at the bottom of the interface.

2. Select an **Alarm Input number** and **Alarm Type** from their drop-down menus. Select from **NO** (Normally Open) or **NC** (Normally Closed) for the Alarm Type.
3. Set the arming schedule for the alarm input. See [Configuring the Arming Schedule on page 82](#) for more about the Arming Schedule.
4. Click the **Linkage Method** tab to set the actions taken for the alarm input.

**Figure 6-19 Linkage Method Tab for Alarm Input Settings**

Alarm Input Settings

Alarm Input No. A<-1 IP Address Local

Alarm Type NO Alarm Name (cannot copy)

Arming Schedule Linkage Method

Normal Linkage

Full Screen Monitoring  Audible Warning  Notify Surveillance Center  Send Email  Upload to FTP

Trigger Alarm Output  Select All

A->1  A->2  A->3  A->4

Trigger Channel  Select All

A1  A2  A3  A4  A5  A6  A7  A8

PTZ Linking

PTZ Linking A2

Preset No. 1  Enable

Patrol No. 1  Enable

Pattern No. 1  Enable

Copy to Alarm

Select All

A<-1  A<-2  A<-3  A<-4  A<-5  A<-6  A<-7  A<-8

Save

For more information, please see [Configuring the Alarm Actions for Motion Detection on page 83](#).

5. (Optional) You can also choose the PTZ linking for the alarm input if your camera is installed with a PTZ camera.
  - a. Choose the PTZ linking channel.
  - b. Check the related checkbox to enable **Preset Calling**, **Patrol Calling**, or **Pattern Calling**, then enter the preset/patrol/pattern number to be linked.
6. (Optional) Copy these settings to other alarm inputs.
7. Click **Save** to save these new settings.

## Configuring a Video Loss Alarm

1. Click **Remote Configuration** > **Camera Settings** > **Video Loss** to enter the Video Loss settings interface.

**Figure 6-20 Video Loss Settings Interface**

2. Select a camera for which to configure the video loss alarm.
3. Check the checkbox for **Enable Video Loss**.
4. Click **Edit** to edit the arming schedule for video loss detection.

The arming schedule configuration is the same as the setting of the arming schedule for motion detection.

Please see [Configuring the Arming Schedule on page 82](#) for more information.


5. Click the **Linkage Method** tab to set the actions taken when a video loss alarm is triggered.

Please see [Configuring the Alarm Actions for Motion Detection on page 83](#) for more information.

## Configuring the Tamper-proof Alarm

When you enable this function, an alarm will trigger whenever there's tampering with the camera's image.

1. Click **Remote Configuration** > **Camera Settings** > **Tamper-proof** to enter the Tamper-proof Alarm settings interface.

**Figure 6-21 Tamper-proof Settings Interface**

2. Select a camera for which to configure the tamper-proof detection alarm.
3. Click the **Enable Tamper-proof** checkbox.
4. Set the tamper-proof area.  
See [Configuring the Motion Detection Area on page 81](#) for how to define an area.
5. Click **Edit** to edit the arming schedule for the tamper-proof alarm.  
Please see [Configuring the Arming Schedule on page 82](#) for more information.
6. Click the **Linkage Method** tab to set the actions taken when a video loss alarm is triggered.  
Please see [Configuring the Alarm Actions for Motion Detection on page 83](#) for more information.

## Configuring Exception Handling

Choose what happens when an exception occurs. An exception is an event such as the following:

- HDD full
- HDD error
- Network disconnected
- IP address conflict
- Illegal access
- Video standard mismatch
- Video signal exception
- Record/capture exception
- Video resolution mismatch

---


**Note** When the resolution selected under **Remote Configuration > Camera Settings > Video Settings** and the actual video input resolution do not match, you will get an exception alarm. Please see [Configuring Video Settings on page 77](#).

---

To configure exception handling:

1. Click **Remote Configuration > Exception** to enter the Exceptions Settings interface.

**Figure 6-22 Exception Settings Interface**



2. Check the appropriate checkboxes for the actions you wish to take place when an Exception alarm is triggered. For more information, please see [Configuring the Alarm Actions for Motion Detection on page 83](#).
3. Click **Save** to save these new settings.

---


## Configuring a Privacy Mask

---

The Privacy Mask enables you to cover certain areas on the video channel to prevent sensitive areas from being viewed or recorded.

To configure a privacy mask:

1. Click **Configuration > Remote Configuration > Camera Settings > Privacy Mask** to enter the Privacy Mask settings interface.

**Figure 6-23 Privacy Mask Settings Interface**

2. Select a camera for which you want to configure a privacy mask.
3. Check the **Enable Privacy Mask** checkbox to enable this function.
4. Click the **Draw Area** button  **Draw Area**.
5. Draw a motion privacy mask area by clicking and dragging the mouse in the live video image.

---

**Note** You can draw up to 4 privacy mask areas.

---

6. Click **Stop Drawing**  **Stop Drawing** to finish drawing the motion detection area.  
Click **Clear All**  **Clear All** to clear all drawn areas.
7. Click **Save** to save these new settings.

---

## Configuring RS-232/RS-485 Port Settings

---

### Configuring RS-232 Port Settings

---


**Note** HVE1/HVE1X encoders do not have an RS-232 serial port.

---

Through the serial port management tools, the RS-232 serial port can be used for configuration.

1. Click **Remote Configuration** > **Serial Port Settings** > **232 Serial Port** to enter the 232 Serial Port settings interface.

**Figure 6-24 RS-232 Serial Port Settings Interface**



The screenshot shows the 'RS-232 Settings' interface with the following configuration:

Parameter	Value
Baud Rate	115200
Data Bit	8
Stop Bit	1
Parity	None
Flow Ctrl	None
Usage	Console

A 'Save' button is located at the bottom left of the form.

---

**Note** If you want to connect the encoder by the RS-232 port, the parameters of the RS-232 port should be exactly the same as the parameters you configured here.

---

2. Click **Save** to save these new settings.


### Configuring the RS-232 Port as a Transparent Channel

In order to receive data, you must set the RS-232 port as a transparent channel.

Setting the RS-232 port as a transparent channel:

1. Click **Remote Configuration** > **Serial Port Settings** > **232 Serial Port** to enter the RS-232 Settings interface.

Figure 6-25 RS-232 Settings Interface



2. Select **Transparent Channel** from the Usage drop-down menu.
3. Click **Save** to save this new setting.

## Configuring RS-485 Port Settings

The RS-485 serial port is used to control PTZ cameras. You must configure the PTZ parameters before you can control the PTZ unit.

1. Click **Remote Configuration** > **Serial Port Settings** > **485 Serial Port** to enter the RS-485 Serial Port Settings interface.

Figure 6-26 RS-485 Serial Port Settings Interface

- Set the RS-485 parameters.

**Table 6-2** Default RS-485 Port Settings

Setting	Default
Baud Rate	9600
Data Bit	8
Stop Bit	1
Parity	None
Flow Control	None

---

**Note** The Baud Rate, Address, and PTZ Protocol parameters should be exactly the same as the parameters of the connected PTZ camera.

---

- Click **Save** to save these new settings.



# 7

## Configuring Recording and Capturing Settings

Before configuring the settings for recording and capturing, ensure that the following conditions are met:

- Ensure that the encoder is connected to an HDD (if supported), network disk, or microSD card (if supported).
- Ensure that the HDD or network disk has been initialized for first-time use.

For more information about storage, please see [Adding the Network Disk on page 63](#).

You can choose from two recording/capturing types: **Manual** or **Scheduled**.

---

## Configuring Holiday Settings

---

It's a good idea to have a different plan for recording during holidays.

1. Click **Remote Configuration** > **Camera Settings** > **Holiday Settings** to enter the holiday settings interface.

**Figure 7-1 Holiday Settings Interface**

**Holiday Settings**

The periods of holiday cannot be overlapped.

No.	Holiday Name	Status	Start Date	End Date	Edit
1	Holiday1	Disable	1.Jan	1.Jan	
2	Holiday2	Disable	1.Jan	1.Jan	
3	Holiday3	Disable	1.Jan	1.Jan	
4	Holiday4	Disable	1.Jan	1.Jan	
5	Holiday5	Disable	1.Jan	1.Jan	
6	Holiday6	Disable	1.Jan	1.Jan	
7	Holiday7	Disable	1.Jan	1.Jan	
8	Holiday8	Disable	1.Jan	1.Jan	
9	Holiday9	Disable	1.Jan	1.Jan	
10	Holiday10	Disable	1.Jan	1.Jan	
11	Holiday11	Disable	1.Jan	1.Jan	
12	Holiday12	Disable	1.Jan	1.Jan	
13	Holiday13	Disable	1.Jan	1.Jan	
14	Holiday14	Disable	1.Jan	1.Jan	
15	Holiday15	Disable	1.Jan	1.Jan	
16	Holiday16	Disable	1.Jan	1.Jan	
17	Holiday17	Disable	1.Jan	1.Jan	

2. Select a holiday from the Holiday Settings list, then click to edit the holiday. The Edit Holiday interface opens.

**Figure 7-2 Edit Holiday Interface**

**Edit Holiday**

Holiday Name:

Enable Holiday:

Type:

Start Date:

End Date:

- a. Enter the holiday name.
  - b. Check the checkbox to enable the holiday.
  - c. Select the holiday type from the drop-down list. Choose from **By Month**, **By Week**, or **By Date**.
  - d. Set the **Start** and **End Dates**.
  - e. Click **OK** to save these new settings, and to go back to the **Holiday Settings** interface.
3. Check the Holiday Settings list to ensure that the correct settings have been entered.

**Figure 7-3 Checking the Holiday Settings List**

No.	Holiday Name	Status	Start Date	End Date	Edit
1	Holiday1	Enable	1.Jan	3.Jan	
2	Holiday2	Enable	1.May	3.May	
3	Holiday3	Disable	1.Jan	1.Jan	
4	Holiday4	Disable	1.Jan	1.Jan	
5	Holiday5	Disable	1.Jan	1.Jan	
6	Holiday6	Disable	1.Jan	1.Jan	

Repeat these steps for each holiday. Up to 32 holidays can be configured.

---

**Note** The Holiday option is available in the Schedule drop-down list after you have enabled Holiday Schedule in Holiday Settings.

---



---

## Configuring Scheduled Recording and Capturing

---

1. Click **Remote Configuration** > **Camera Settings** > **Schedule Settings** to enter the Schedule Settings interface.

**Figure 7-4** Schedule Settings Interface

Schedule Settings

Channel No. Analog Camera1

Record Capture

Enable Record Schedule Edit Advanced

	0	2	4	6	8	10	12	14	16	18	20	22	24
Mon													
Tue													
Wed													
Thu													
Fri													
Sat													
Sun													
Holiday													

Copy to Camera

Select All

A1  A2  A3  A4  A5  A6  A7  A8

Save

Legend:

- Normal
- Motion Detection
- Alarm
- Motion | Alarm
- Motion & Alarm

2. From the drop-down menu, select the camera for which you want to configure the recording or capturing schedule.
3. Click the **Record** or **Capture** tab.
4. Check the checkbox for either **Enable Record Schedule** or **Enable Capture Schedule** to enable that function.
5. Click **Edit** to enter the Edit Schedule interface.

**Figure 7-5 Edit Schedule Interface**

The screenshot shows the 'Edit Schedule' interface. At the top, there are tabs for 'Mon', 'Tue', 'Wed', 'Thu', 'Fri', 'Sat', 'Sun', and 'Holiday'. Below the tabs, there are two radio buttons: 'All Day' (unselected) and 'Customize' (selected). To the right of the radio buttons is a 'Record Type' dropdown menu set to 'Normal'. Below this is a table with 8 rows and 4 columns: 'Period', 'Start Time', 'End Time', and 'Record Type'. Each 'Start Time' and 'End Time' cell has a small calendar icon to its right. Below the table, there is a 'Copy to Week' checkbox (unchecked) and a 'Select All' checkbox (checked). Below these are checkboxes for each day of the week: Mon (checked), Tue (unchecked), Wed (unchecked), Thu (unchecked), Fri (unchecked), Sat (unchecked), Sun (unchecked), and Holiday (unchecked). To the right of these checkboxes is a blue 'Copy' button. At the bottom right of the interface are 'OK' and 'Cancel' buttons.

Period	Start Time	End Time	Record Type
1	00 : 00	12 : 00	Normal
2	13 : 00	20 : 00	Motion Detection
3	00 : 00	00 : 00	Normal
4	00 : 00	00 : 00	Normal
5	00 : 00	00 : 00	Normal
6	00 : 00	00 : 00	Normal
7	00 : 00	00 : 00	Normal
8	00 : 00	00 : 00	Normal

6. Choose the day of the week for which you want to configure scheduled recording or capturing.
  - a. Select **All Day** or configure a **Customized** time period.
    - If you want to configure an all-day recording/capturing period, then please check the **All Day** checkbox.
    - If you want to configure a specific time period for recording/capturing, then please check the **Customize** checkbox. Then enter a **Start Time** and an **End Time** period.

---

**Note** The time of each holiday period cannot overlap. Up to 8 periods can be configured.

---

- b. Select either a **Record Type** or a **Capture Type**. Choose from **Normal**, **Motion**, **Alarm**, **Motion&Alarm**, and **Motion/Alarm**.

**Table 7-1 Recording and Capturing Types**

Type	Description
<b>Normal</b>	If you select <b>Normal</b> , then the video will be recorded/captured automatically according to the schedule.
<b>Motion Detection</b>	<p>If you select <b>Motion</b>, then the video will be recorded/captured when motion is detected.</p> <p>Besides configuring the record/capture schedule, you have to set the motion detection area and check the <b>Trigger Channel</b> checkbox for the <b>Linkage Method</b> in the <b>Motion Detection</b> settings interface.</p> <p>See <a href="#">Configuring Motion Detection on page 81</a>.</p>
<b>Alarm</b>	<p>If you select <b>Alarm</b>, then the video will be recorded/captured when the alarm is triggered.</p> <p>Besides configuring the record/capture schedule, you have to set the <b>Alarm Type</b> and check the <b>Trigger Channel</b> checkbox for the <b>Linkage Method</b> in the <b>Motion Detection</b> settings interface.</p> <p>See <a href="#">Configuring Motion Detection on page 81</a>.</p>
<b>Motion &amp; Alarm</b>	<p>If you select <b>Motion &amp; Alarm</b>, then the video will be recorded/captured when motion is detected and the alarm are triggered at the same time.</p> <p>Besides configuring the record/capture schedule, you have to configure the settings on the <b>Motion Detection</b> and <b>Alarm Input Settings</b> interfaces.</p> <p>See <a href="#">Configuring Motion Detection on page 81</a>.</p> <p>See <a href="#">Configuring External Alarm Input on page 86</a>.</p>
<b>Motion or Alarm</b>	<p>If you select <b>Motion   Alarm</b>, the video will be recorded/captured when the alarm is triggered or motion is detected.</p> <p>Besides configuring the record/capture schedule, you have to configure the settings on the <b>Motion Detection</b> and <b>Alarm Input Settings</b> interfaces.</p> <p>See <a href="#">Configuring Motion Detection on page 81</a>.</p> <p>See <a href="#">Configuring External Alarm Input on page 86</a>.</p>

- c. (Optional)

Check the **Select All** checkbox, then click **Copy** to copy these settings to the whole week.

Select individual days to which to copy these settings by clicking the appropriate checkbox.

- d. Click **OK** to save these new settings and to then exit the **Edit Schedule** interface.

7. Click **Advanced** to configure advanced recording parameters such as Pre- and Post-Event recording intervals, and when to overwrite recordings and to record audio.

**Figure 7-6 Advanced Recording Parameters**

Advanced

Pre-record 5s

Post-record 5s

Redundant Record No

Overwrite Yes

Record Audio Yes

Expired Time 5 Day

OK Cancel

**Pre-Record:** Choose from **No Pre-Record**, **5 sec**, **10 sec**, **15 sec**, **20 sec**, **25 sec**, or **30 sec**.

**Post Record:** Choose from **5 sec**, **10 sec**, **30 sec**, **1 min**, **2 min**, **5 min**, or **10 min**.

8. To copy the recording settings of the current camera to other cameras, expand the **Copy to Camera** panel, then either select specific cameras to which you want to copy the settings, or click **Select All** to select all cameras.

**Figure 7-7 Copying the Settings to Other Cameras**

Copy to Camera

Select All

A1  A2  A3  A4  A5  A6  A7  A8

Save

9. Click **Save** to validate these new settings.

# 8

## Playing Back Recorded Video

Recorded video files can be remotely played back through a Web browser.


Before playing back recorded video, ensure that the following conditions are met:

- Ensure that the encoder is connected to an HDD (if supported), network disk, or microSD card (if supported).
- Ensure that the HDD or network disk has been initialized for first-time use.

Playing back recorded video:

1. Click **Playback** on the menu bar to enter the playback interface.

**Figure 8-1 Playback Interface**



2. Select a camera from the device list for playback.
3. Select a day from the calendar, and then click **Search**.

**Figure 8-2 Calendar**



4. Click **Play** to play the video found for that date.

**Figure 8-3 Playing Back Video**



**Table 8-1 Playback Controls**

Button	Function	Button	Function
	Select window division mode		Play/Pause
	Stop playback		Reverse playback?
	Fast forward		Play by single frames
	Stop all channels from playing		Capture pictures in playback mode
	Download video files		Start/Stop clipping video files
	Audio on/off		

---

# Playing Back a Specific Time

---

You can use the mouse to drag the progress bar to locate an exact playback point.

**Figure 8-4 Playback Sidebar**



Or you can enter the specific time in the time field  , then click .


---

# Determining the Type of Recorded Video

---

The recorded video is assigned a specific color which indicates the type of video.

**Figure 8-5 Recorded Video Color Key**





# 9

## Managing User Accounts

Click **Remote Configuration** > **Remote Configuration** > **User Management** to enter the User Management settings interface.

**Figure 9-1** User Management Settings Interface



The screenshot shows a web interface titled "User Information". At the top, there are three buttons: "Add", "Modify", and "Delete". Below these buttons is a table with three columns: "No.", "User Name", and "Level". The table contains one row with the following data:

No.	User Name	Level
1	admin	Administrator

Only an **admin** user has the ability to create normal users. Up to 31 users can be created.

---

## Adding a User

---

1. Click **Add** to enter the Add User interface.

**Figure 9-2 Add User Interface**

2. Enter a **User Name** and **Password**, and then confirm the password.
3. Select a user **Level**. Choose from **Operator** or **User**.

The user levels have different permissions.

**Operator:** Operators have access to the following: Local Log Search in the Local Configuration, Remote Log Search and Two-way Audio in Remote Configuration, and all operating permissions in Camera Configuration.

**User:** Guest users have access to the following: Local Log Search in the Local Configuration, Remote Log Search in Remote Configuration, and only local/remote playback in Camera Configuration.

4. Configure the user permissions for the selected user account, including **Basic Permissions** and **Camera Operation**.
5. Click **OK** to save these new changes.

---

## Modifying a User

---



---

**Note** You need the admin password to modify the admin user.

---

1. Select a user account from the list on the User Information interface.

**Figure 9-3 User Account - Modifying a User**

The screenshot shows a 'User Information' interface with three buttons: 'Add', 'Modify', and 'Delete'. Below the buttons is a table with three columns: 'No.', 'User Name', and 'Level'. The table contains three rows of user data.

No.	User Name	Level
1	admin	Administrator
2	user01	Operator
3	user02	Operator

2. Click **Modify** to enter the **Modify User** interface.

**Figure 9-4 Modify User Interface**

The screenshot shows the 'Modify user' interface. It includes fields for 'User Name' (containing 'user01'), 'Password' (masked with dots), 'Level' (a dropdown menu set to 'Operator'), and 'Confirm' (masked with dots). Below these fields are two tabs: 'Basic Permission' and 'Camera Configuration'. Under 'Basic Permission', there are four checked checkboxes: 'Local: Upgrade/Format', 'Local: Shutdown/Reboot', 'Local: Parameters Settings', and 'Local: Log Search'. Under 'Camera Configuration', there are eight checked checkboxes: 'Remote: Parameters Settings', 'Remote: Log Search / Interrogate Working Status', 'Remote: Upgrade / Format', 'Remote: Two-way Audio', 'Remote: Shutdown / Reboot', 'Remote: Notify Surveillance Center / Trigger Alarm Output', 'Remote: Video Output Control', and 'Remote: Serial Port Control'. At the bottom are 'OK' and 'Back' buttons.


3. Make the necessary changes, and then click **OK** to save these new settings.

---

## Deleting a User

---

1. Select a user account from the list on the User Information interface.
2. Click **Delete**, and a confirmation message pops up.

**Figure 9-5 Confirmation Message for Deleting a User**

3. Click **OK** to confirm the deletion of the selected user account.

# 10

## Searching Logs, Viewing Device Information, and Maintaining the Encoder

### Searching Logs

Log files store operation, alarm, and exception information for the device. These log files can be viewed and exported at any time.

Before you begin, ensure that the following conditions are met:

- Ensure that the encoder is connected to an HDD (if supported), network disk, or microSD card (if supported).
- Ensure that the HDD or network disk has been initialized for first-time use.

For more information about storage, please see [Adding the Network Disk on page 63](#).

1. Click **Log** on the menu bar to enter the Log interface.

**Figure 10-1 Log Interface**

The screenshot shows the Log interface with a menu bar at the top containing 'Live View', 'Playback', 'Log', and 'Configuration'. The 'Log' menu item is selected. Below the menu bar is a table of log entries with columns: No., Time, Major Type, Minor Type, Channel No., Local/Remote User, and Remote Host IP. The table contains 13 rows of log data. To the right of the table is a search panel with the following fields: Major Type (dropdown menu), Minor Type (dropdown menu), Start Time (text input), and End Time (text input). Below the search fields is a 'Search' button and a 'Save Log' button. At the bottom of the table, there is a summary row: 'Total 42 Items First Page Prev Page 1/1 Next Page Last Page'.

No.	Time	Major Type	Minor Type	Channel No.	Local/Remote User	Remote Host IP
1	2013-07-11 14:16:51	Operation	Power On			0.0.0.0
2	2013-07-11 14:16:51	Information	HDD Information			0.0.0.0
3	2013-07-11 14:16:51	Information	S.M.A.R.T. Information	1		0.0.0.0
4	2013-07-11 14:19:05	Operation	Remote: Get Parameters		admin	172.9.11.41
5	2013-07-11 14:19:05	Operation	Remote: Get Parameters		admin	172.9.11.41
6	2013-07-11 14:19:05	Operation	Remote: Get Parameters		admin	172.9.11.41
7	2013-07-11 14:19:05	Operation	Remote: Get Parameters		admin	172.9.11.41
8	2013-07-11 14:19:07	Operation	Remote: Get Parameters		admin	172.9.11.41
9	2013-07-11 14:19:08	Operation	Remote: Get Parameters		admin	172.9.11.41
10	2013-07-11 14:19:00	Operation	Remote: Get Parameters		admin	172.9.11.41
11	2013-07-11 14:19:08	Operation	Remote: Get Parameters		admin	172.9.11.41
12	2013-07-11 14:19:08	Operation	Remote: Get Parameters		admin	172.9.11.41
13	2013-07-11 14:19:00	Operation	Remote: Get Parameters	A1	admin	172.9.11.41

2. Enter log search conditions to refine the search, including **Major Type**, **Minor Type**, **Start Time**, and **End Time**.
3. Click **Search**.

The log files that match the search criteria display in the log list. See [Figure 10-1](#).

---

**Note** Up to 100 log files can be displayed at a time.

---

4. Click  Save Log to save the searched log files to a local directory.


---

## Viewing Device Information

---

Click **Remote Configuration > Device Parameters > Device Information** to enter the device Basic Information interface.

**Figure 10-2 Basic Device Information Configuration Interface**



Basic Information	
Device Name	HVE8
Device No.	255
Model	HVE8
Serial No.	HVE80020130711AARR412499295WC
Firmware Version	V1.1.0 build 130808
Encoding Version	V5.0 build 130619
Number of Channels	8
Number of HDDs	2
Number of Alarm Input	8
Number of Alarm Output	4
<input type="button" value="Save"/>	

You can edit the **Device Name** and the **Device No.**. You can view the device information, including **Model**, **Serial No.**, **Firmware/Encode Version**, **Number of Channels**, **Number of HDDs**, and **Number of Alarm Input / Output**.

## Maintenance

In the Maintenance interface, you can reboot the encoder, restore it to default settings, import and export configuration files, and upgrade the system.

Click **Remote Configuration** > **Maintenance** to enter the Maintenance interface.

**Figure 10-3 Maintenance Interface**



## Restarting the Encoder

1. Click **Reboot** on the Maintenance interface.  
A confirmation message appears.


**Figure 10-4 Confirmation Message for Rebooting the Encoder**



2. Click **OK** to reboot the encoder. Click **Cancel** to cancel rebooting the recorder.


## Restoring Default Settings

1. Click **Restore** or **Default** on the Maintenance interface.

**Figure 10-5 Restore or Default Interface**

- Select **Restore** to restore the encoder to the default settings for all parameters except the IP address, the subnet mask, the gateway, and the port.
- Select **Default** to restore the encoder to the default settings for all parameters.

A confirmation message appears.

**Figure 10-6 Confirmation Message for Restoring or Returning the Encoder to Defaults**

2. Click **OK** to restore the encoder to default settings and then reboot the device to validate the settings.

## Importing or Exporting Configuration Files

The encoder's configuration files can be exported to a local device for backup. The configuration files of one encoder can be imported to multiple encoders if they are to be configured with the same parameters.

### Importing Configuration Files

1. Click **Maintenance** ► **Import Config File** to open the **Import Config. File** interface.

**Figure 10-7 Import Configuration File Interface**

2. Click **Browse** to select the file from the selected backup device.
3. Click the **Import** button to import a configuration file.

---

**Note** After importing configuration files, the encoder reboots automatically.

---


## Exporting Configuration Files

1. Click **Maintenance** ► **Export Config File** to open the **Export Config. File** interface.
2. Click the **Export** button to export configuration files to the selected local backup device.

## Upgrading the System

1. Click **Maintenance** ► **Remote Upgrade** to open the Remote Upgrade interface.

**Figure 10-8 Remote Upgrade Interface**



Remote Upgrade

Firmware	<input type="text"/>	Browse	Upgrade
Status			

Note : The upgrading process will be 1 to 10 minutes, please don't disconnect power to the device during the process. The device reboots automatically after upgrading.

2. Click **Browse** to select the local update file.
3. Click **Upgrade** to start remote upgrade.





## Troubleshooting

---

### The encoder cannot be pinged

---

**Possible solutions:**

- Check the cable connections between the encoder and the switch.
- Please see [Configuring Network Parameters on page 39](#), and ensure that the device's IP matches your computer's IP.

### The transparent channel has been set, but the encoder still does not receive data

---

**Possible solutions**

- Ensure that the RS-232 port has been set as a transparent channel. See [Configuring the RS-232 Port as a Transparent Channel on page 93](#).
- Ensure that the encoder is properly connected.

### The encoder cannot be added with the software

---

**Possible solution:**

- Check the encoder IP.
- Ensure that the encoder is properly connected.
- Ensure that the user name and password for the encoder are correct.

---

## The encoder cannot control a PTZ camera

---

- Possible solution:**
- Check the RS-485 connections between the encoder and PTZ camera.
  - Ensure that the PTZ address, protocol, and baud rate settings for the encoder match the same settings on the connect PTZ camera.

---

## Video cannot be viewed through the Web browser

---

- Possible solution:**
- Check the network connection.
  - Ensure that the encoder username and password are entered correctly.
  - Ensure that the encoder port is entered correctly.





## HVE1 (X) Specifications

This section lists the technical specifications for the HVE1 1-channel encoder.

<b>Operational</b>	
Video Compression	H.264/MPEG4/MPEG2/MJPEG
Video Input	1 channel
Audio Compression	G.71u
Audio Input	1 channel
Two-way Audio Input	1 channel
Audio Output	1 channel
Recording Resolution	4CIF/2CIF/CIF/QCIF
Frame Rate	H.264/MPEG4/MPEG2 encoding: 25 fps (P) / 30 fps (N); MJPEG encoding: 15 fps
Video Bit Rate	32 Kbps ~ 3072 Kbps, or user defined (Max. 8192 Mbps)
Audio Bit Rate	64 kbps
Dual Stream	Supported
Stream Type	Video / Video + Audio
Data Storage Type	NAS, microSD
Data Storage Capacity	4 GB up to 32 GB and above, Class 6 and above for microSD storage
Network Protocols	IPv4/v6, HTTP, HTTPS, QoS layer3 DiffServ, FTP, SMTP, Bonjour, UPnP, SNMPv1/v2c/v3(MIB-II), DNS, DynDNS, hkDDNS, NTP, RTSP, RTP/RTCP, TCP, UDP, IGMP, ICMP, DHCP, ARP, SOCKSv4/v5, PSIA, ONVIF, HIKCGI, netFilter
<b>Electrical</b>	
Power Supply	12 V DC
Power Consumption	≤ 8 W
<b>Mechanical</b>	
Dimensions (W x H x D)	3.1 x 1.5 x 3.5 inches (80 × 39 × 90 mm)
Weight	≤ 1.1 lbs (≤ 0.5 kg)
Construction	Housing: Die-cast aluminum

<b>Connections</b>	
Video Input	BNC 1 Vp-p @ 75 ohms
Video Output	1 - Composite main monitor, BNC 1 Vp-p @ 75 ohms 1 - VGA Main Monitor 1 - Spot BNC 1 Vp-p @ 75 ohms
Audio Input	3.5 mm interface (2.0 Vp-p, 1 ohm) (LINE IN)
Audio Output	3.5 mm interface (Linear, 600 ohms)
Two-way Audio Input	3.5 mm interface (2.0 Vp-p, 1 ohm) (LINE IN)
Network Interface	1 RJ-45 10 M / 100 Mbps adaptive Ethernet interface (PoE)
Serial Interface	1 half-duplex RS-485 interface
Alarm In	1
Alarm Out	1
Data Storage	1 microSD interface
<b>Environmental</b>	
Temperature	Operating: 14°F to 131°F (-10°C to 55°C) Storage: -4°F to 149°F (-20°C to 65°C)
Relative Humidity	10% to 90%, non-condensing
<b>Regulatory</b>	
Emissions	EN 55022 FCC Part 15B, Class A
Immunity	EN 50130-4
Safety	EN 60950-1 North America ETL listed to UL/CSA 60950-1

## Dimensions









## HVE4(X) Specifications

This section lists the technical specifications for the HVE4 4-channel encoder.

<b>Operational</b>	
Video Compression	H.264/MPEG4/MPEG2/MJPEG
Video Input	4 channels
Audio Compression	G.71u
Audio Input	4 channels
Two-way Audio Input	1 channel
Audio Output	1 channel
Recording Resolution	4CIF/2CIF/CIF/QCIF
Frame Rate	H.264/MPEG4/MPEG2 encoding: 25 fps (P) / 30 fps (N); MJPEG encoding: 15 fps
Video Bit Rate	32 Kbps ~ 3072 Kbps, or user defined (Max. 8192 Mbps)
Audio Bit Rate	64 kbps
Dual Stream	Supported
Stream Type	Video / Video + Audio
Data Storage Type	NAS, microSD
Data Storage Capacity	16 GB up to 32 GB and above, Class 6 and above for microSD storage
Network Protocols	IPv4/v6, HTTP, HTTPS, QoS layer3 DiffServ, FTP, SMTP, Bonjour, UPnP, SNMPv1/v2c/v3(MIB-II), DNS, DynDNS, hkDDNS, NTP, RTSP, RTP/RTCP, TCP, UDP, IGMP, ICMP, DHCP, ARP, SOCKSv4/v5, PSIA, ONVIF, HIKCGI, netFilter
<b>Electrical</b>	
Power Supply	12 V DC
Power Consumption	≤ 8 W
<b>Mechanical</b>	
Dimensions (W x H x D)	4.5 x 1.9 x 128 inches (114 × 48 × 5.0 mm)
Weight	≤ 2.2 lbs (≤ 1.0 Kg)
Construction	Housing: Die-cast aluminum

<b>Connections</b>	
Video Input	BNC 1 Vp-p @ 75 ohms
Video Output	1 - Composite main monitor, BNC 1 Vp-p @ 75 ohms 1 - VGA Main Monitor 1 - Spot BNC 1 Vp-p @ 75 ohms
Audio Input	3.5 mm interface (2.0 Vp-p, 1 ohm) (LINE IN)
Audio Output	3.5 mm interface (Linear, 600 ohms)
Two-way Audio Input	3.5 mm interface (2.0 Vp-p, 1 ohm) (LINE IN)
Network Interface	1 RJ-45 10 M / 100 Mbps adaptive Ethernet interface (PoE)
Serial Interface	1 half-duplex RS-485 interface 1 RS-232 interface
Alarm In	4
Alarm Out	2
Data Storage	1 microSD interface
<b>Environmental</b>	
Temperature	Operating: 14°F to 131°F (-10°C to 55°C) Storage: -4°F to 149°F (-20°C to 65°C)
Relative Humidity	10% to 90%, non-condensing
<b>Regulatory</b>	
Emissions	EN 55022 FCC Part 15B, Class A
Immunity	EN 50130-4
Safety	EN 60950-1 North America ETL listed to UL/CSA 60950-1

## Dimensions









## HVE8(X) Specifications

This section lists the technical specifications for the HVE8 8-channel encoder.

<b>Operational</b>	
Video Compression	H.264/MPEG4/MPEG2/MJPEG
Video Input	8 channels
Audio Compression	G.71u
Audio Input	8 channels
Two-way Audio Input	1 channel
Audio Output	1 channel
Recording Resolution	4CIF/2CIF/CIF/QCIF
Frame Rate	H.264/MPEG4/MPEG2 encoding: 25 fps (P) / 30 fps (N); MJPEG encoding: 15 fps
Video Bit Rate	32 Kbps ~ 3072 Kbps, or user defined (Max. 8192 Mbps)
Audio Bit Rate	64 kbps
Dual Stream	Supported
Stream Type	Video / Video + Audio
Data Storage Type	NAS, SATA
Data Storage Capacity	Up to 4 TB capacity for each disk
Network Protocols	IPv4/v6, HTTP, HTTPS, QoS layer3 DiffServ, FTP, SMTP, Bonjour, UPnP, SNMPv1/v2c/v3(MIB-II), DNS, DynDNS, hkDDNS, NTP, RTSP, RTP/RTCP, TCP, UDP, IGMP, ICMP, DHCP, ARP, SOCKSv4/v5, PSIA, ONVIF, HIKCGI, netFilter
<b>Electrical</b>	
Power Supply	12 V DC
Power Consumption	≤ 30 W
<b>Mechanical</b>	
Dimensions (W x H x D)	12.4 x 1.8 x 7.9 inches (315 × 45 × 200 mm)
Weight	≤ 4.4 lbs (≤ 2.0 Kg)
Construction	Housing: Steel chassis

<b>Connections</b>	
Video Input	BNC 1 Vp-p @ 75 ohms
Video Output	1 - Composite main monitor, BNC 1 Vp-p @ 75 ohms 1 - VGA Main Monitor 1 - Spot BNC 1 Vp-p @ 75 ohms
Audio Input	3.5 mm interface (2.0 Vp-p, 1 ohm) (LINE IN)
Audio Output	3.5 mm interface (Linear, 600 ohms)
Two-way Audio Input	3.5 mm interface (2.0 Vp-p, 1 ohm) (LINE IN)
Network Interface	1 RJ-45 10 M / 100 Mbps / 1000 Mbps adaptive Ethernet interface
Serial Interface	1 half-duplex RS-485 interface 1 RS-232 interface
Alarm In	8
Alarm Out	4
<b>Environmental</b>	
Temperature	Operating: 14°F to 131°F (-10°C to 55°C) Storage: -4°F to 149°F (-20°C to 65°C)
Relative Humidity	10% to 90%, non-condensing
<b>Regulatory</b>	
Emissions	EN 55022 FCC Part 15B, Class A
Immunity	EN 50130-4
Safety	EN 60950-1 North America ETL listed to UL/CSA 60950-1

## Dimensions





# Index

## A

- adding
  - users [107](#)
- alarm actions configuration [83](#)
- alarm center notification [84](#)
- alarm host [84](#)
- alarm inputs
  - connections [33](#)
  - number of [112](#)
- alarm outputs
  - connections [34](#)
  - number of [112](#)
- alarm recording [101](#)
- alarm setup
  - emerson alarm [33](#)
- alarm-in connectors [29](#), [31](#), [33](#)
- alarm-out connectors [29](#), [31](#), [33](#)
- alarms
  - alarm center notification [84](#)
  - audible warning [84](#)
  - configuration [81](#)
  - linking a preset to [50](#)
  - sending emails [84](#)
  - uploading to ftp [84](#)
- arming schedule configuration [82](#)
- attach image [62](#)
- audible warning [84](#)
- audio [78](#)
- audio on/off [46](#), [104](#)
- audio-in connectors [30](#)
- audio-out connector [28](#), [30](#), [32](#)
- authentication request [62](#)
- authorized certificate, creating [71](#)

## B

- baud rate, default [95](#)
- bitrate [78](#)
- bonjour settings configuration [72](#)
- brightness [44](#)
- browser [37](#)

## C

- Canadian compliance [16](#)
- capture an image [46](#)
- cautions [15](#)
- choose receiver [62](#)
- clipping video files [104](#)
- compliance
  - Canadian [16](#)
  - FCC [15](#)
- configuration files
  - exporting [115](#)
  - importing [114](#)
- configuring
  - a privacy mask [91](#)
  - a video loss alarm [88](#)
  - alarm actions [83](#)
  - alarm center notification [84](#)
  - alarms [81](#)
  - arming schedule [82](#)
  - audible warning [84](#)
  - audio [78](#)
  - bitrate [78](#)
  - bonjour settings [72](#)
  - clip save location [54](#)
  - date manually [55](#)
  - DDNS [59](#)
  - DHCP server [57](#)
  - display settings [75](#)
  - DNS server [57](#)
  - downloaded files save path [54](#)
  - DynDNS [59](#)
  - email settings [61](#)
  - encoder [53](#)
  - exception handling [90](#)
  - external alarm inputs [86](#)
  - frame rate [78](#)
  - ftp directories [68](#)
  - ftp settings [67](#)
  - holiday settings [97](#)
  - HTTPS settings [70](#)
  - HVEDDNS [60](#)
  - I frame interval [79](#)
  - image capture settings [47](#)

- image size [53](#)
- IP address [72](#)
- IP server [58](#)
- live view performance [54](#)
- maximum bitrate [79](#)
- motion detection [81](#)
- motion detection area [81](#)
- multicast address [73](#)
- NetHDD [63](#)
- network settings [56](#)
- PeanutHull [59](#)
- port mapping mode [70](#)
- port settings [57](#)
- PPPoE [60](#)
- protocol type [53](#)
- PTZ camera [48](#)
- QoS settings [66](#)
- recorded files save location [54](#)
- recording file size [53](#)
- recording type [101](#)
- resolution [78](#)
- RS-232 port as a transparent channel [93](#)
- RS-232 serial port [93](#)
- RS-485 port [48](#)
- RS-485 serial port [93](#)
- schedule image capture [99](#)
- schedule time [85](#)
- scheduled recording [99](#)
- sending emails [84](#)
- snapshot settings [79](#)
- snapshots save location [54](#)
- SNMP settings [64](#)
- SOCKS settings [68](#)
- stream type [53](#), [78](#)
- tamper-proof alarms [89](#)
- TCP/IP settings [56](#)
- text overlay [76](#)
- time manually [55](#)
- time settings [54](#)
- upload to ftp [84](#)
- UPnP settings [69](#)
- video encoding standard [79](#)
- video parameters [50](#)
- video quality [78](#)
- video settings [77](#)
- video type [78](#)
- connecting
  - alarm inputs [33](#)
  - alarm outputs [34](#)
  - PTZ cameras [48](#)
- connectors
  - alarm-in [29](#), [31](#), [33](#)
  - alarm-out [29](#), [31](#), [33](#)
  - audio-in [30](#)
  - audio-out [28](#), [30](#), [32](#)
  - line-in [28](#), [30](#)
  - RS-232 [31](#), [33](#)
  - RS-485 [29](#), [31](#), [33](#)

- video-in [28](#), [30](#), [32](#)
- contrast [44](#)
- controlling PTZ cameras [49](#)
- creating
  - authorized certificates [71](#)
  - self-signed certificates [71](#)

## D

- data bit, default [95](#)
- date configuration [55](#)
- daylight saving time [56](#)
- DDNS [58](#)
- DDNS configuration [59](#)
- Declaration of Conformance [16](#)
- default
  - baud rate [95](#)
  - data bit [95](#)
  - Diamond PTZ protocol [48](#)
  - file path for IP SAN [63](#)
  - file path for NAS [63](#)
  - flow control, flow control, default [95](#)
  - HTTP port [57](#)
  - HTTPS port [57](#), [70](#)
  - live video brightness [52](#)
  - live video contrast [52](#)
  - live video denoising level [52](#)
  - live video hue [52](#)
  - live video saturation [52](#)
  - live video sharpness [52](#)
  - parity [95](#)
  - restoring live video to default settings [52](#)
  - RTSP port [57](#)
  - server port [69](#)
  - SMTP port [62](#)
  - SNMP [65](#)
  - SNMP port [66](#)
  - SNMPv3 username [65](#)
  - stop bit [95](#)
  - TCP/IP port [62](#)
  - trap address [65](#)
  - trap port [65](#)
  - video standard setting [51](#)
- default settings, restoring to [113](#)
- deleting users [109](#)
- device information, viewing [112](#)
- device IP password factory default [37](#)
- device name [112](#)
- device number [112](#)
- device password factory default [37](#)
- DHCP [57](#)
- Diamond PTZ protocol default [48](#)
- differentiated services codepoint [67](#)
- display settings configuration [75](#)
- DNS [57](#)
- download video files [104](#)
- DSCP [67](#)
- DST [56](#)

DynDNS [58](#)  
 DynDNS configuration [59](#)

## E

email settings  
   attach image [62](#)  
   authentication request [62](#)  
   choose receiver [62](#)  
   interval [62](#)  
   receiver's address [62](#)  
   receiver's name [62](#)  
   sender's address [62](#)  
   sender's name [62](#)  
   SMTP port [62](#)  
   SMTP server [62](#)  
   SSL [62](#)  
 email settings configuration [61](#)  
 emerson alarm [33](#)  
 encoder configuration [53](#)  
 encoder, restarting [113](#)  
 encoding version [112](#)  
 exception handling configuration [90](#)  
 exporting configuration files [115](#)  
 external alarm input configuration [86](#)

## F

factory defaults  
   device IP password [37](#)  
   device password [37](#)  
   user name [37](#)  
 FCC compliance [15](#)  
 features  
   alarm [23](#)  
   encoding [22](#)  
   exceptions [23](#)  
   logs [24](#)  
   network [22](#)  
   ptz [23](#)  
 firmware version [112](#)  
 frame rate [78](#)  
 ftp  
   directories configuration [68](#)  
   settings configuration [67](#)  
   uploading to [80](#)

## H

H.264 [79](#)  
 hard disk drive [25](#)  
 HDD [25](#)  
   compatible models [26](#)  
 HDD, initializing [63](#)  
 holiday periods, how many are available [100](#)  
 holiday settings configuration [97](#)  
 HTTP port default [57](#)  
 HTTPS port default [57](#), [70](#)  
 HTTPS settings configuration [70](#)

hue [44](#)  
 HVEDDNS configuration [60](#)

## I

I frame interval [79](#)  
 image capture [46](#), [104](#)  
 image capture settings [47](#)  
 image size [53](#)  
 importing configuration files [114](#)  
 initializing the added network disk [63](#)  
 initializing the HDD [63](#)  
 installing  
   hard disk drive [25](#)  
   IP utility [37](#)  
 interval [62](#)  
 IP address filter configuration [72](#)  
 IP network settings [41](#)  
 IP SAN default path [63](#)  
 IP SAN disks, how many can be connected [64](#)  
 IP SAN mode [63](#)  
 IP server configuration [58](#)  
 IP utility installation [37](#)  
 IPv4 [56](#)

## J

JJ1 relay [35](#)

## L

LAN [29](#), [31](#), [33](#)  
 LED [32](#)  
 line-in connector [28](#), [30](#)  
 live view performance [54](#)  
 live view settings [44](#)  
 log search [111](#)

## M

manual recording [46](#)  
 manual time sync [55](#)  
 maximum bitrate [79](#)  
 maximum number of user accounts [107](#)  
 menu bar [44](#)  
 microSD card slot [28](#), [31](#)  
 MJPEG [79](#)  
 model [112](#)  
 modifying users [108](#)  
 motion and alarm recording [101](#)  
 motion detection [81](#)  
 motion detection area [81](#)  
 motion detection areas, how many [82](#)  
 motion or alarm recording [101](#)  
 motion recording [101](#)  
 MPEG2 [79](#)  
 MPEG4 [79](#)  
 MTU [56](#)  
 multicast address configuration [73](#)

**N**

NAS default path [63](#)  
 NAS disks, how many can be connected [64](#)  
 NAS mode [63](#)  
 NetHDD settings [63](#)  
 network parameters, modifying [41](#)  
 network settings, configuring [56](#)  
 network time protocol [55](#)  
 NIC [56](#)  
 normal recording [101](#)  
 NTP [55](#)  
 number (maximum) of motion detection areas [82](#)  
 number of channels [112](#)  
 number of HDDs [112](#)

**O**

operating system requirements [37](#)  
 OS [37](#)

**P**

parity, default [95](#)  
 PeanutHull configuration [59](#)  
 PoE [29](#), [31](#), [33](#)  
 port mapping mode [70](#)  
 port settings configuration [57](#)  
 power indicator [28](#), [30](#)  
 power supply [29](#), [31](#), [33](#)  
 PPPoE configuration [60](#)  
 preset, linking to an alarm [50](#)  
 presets [44](#)  
 privacy mask configuration [91](#)  
 privacy mask, how many are available [92](#)  
 protocol type [53](#)  
 PTZ  
     camera configuration [48](#)  
     camera connections [48](#)  
     camera controls [49](#)  
     controls [44](#)  
     setting a preset [49](#)

**Q**

QoS settings, configuring [66](#)

**R**

receiver's address [62](#)  
 receiver's name [62](#)  
 record [46](#)  
 recording file size [53](#)  
 regulatory [15](#)  
 related documents [20](#)  
 reset [28](#), [31](#), [33](#)  
 resolution [78](#)  
 restarting  
     encoder [113](#)  
 RS-232 [31](#), [33](#)

RS-232 port  
     configuring as a transparent channel [93](#)  
 RS-232 serial port configuration [93](#)  
 RS-485 [29](#)  
 RS-485 connectors [31](#), [33](#)  
 RS-485 serial port configuration [48](#), [93](#)  
 RTSP port default [57](#)

**S**

safety instructions [16](#)  
 saturation [44](#)  
 save clips location [54](#)  
 save location for recorded files [54](#)  
 saving path for snapshots [54](#)  
 schedule image capture [99](#)  
 schedule recording [99](#)  
 schedule time configuration [85](#)  
 searching logs [111](#)  
 self-signed certificates [71](#)  
 sender's address [62](#)  
 sender's name [62](#)  
 sending emails [84](#)  
 serial number [112](#)  
 serial port configuration [48](#)  
 server port default [69](#)  
 setting  
     RS-232 port as a transparent channel [93](#)  
 setting a PTZ preset [49](#)  
 settings  
     IP network [41](#)  
 SMTP port [62](#)  
 SMTP port default [62](#)  
 SMTP server [62](#)  
 snapshot settings [79](#)  
 SNMP default settings [65](#)  
 SNMP port default [66](#)  
 SNMP settings [64](#)  
 SNMPv3 default username [65](#)  
 SOCKS settings configuration [68](#)  
 SSL [62](#)  
 status indicator [32](#)  
 stop bit, default [95](#)  
 stream type [53](#), [78](#)  
 supported web browsers [42](#)  
 system upgrade [115](#)

**T**

tamper-proof alarm configuration [89](#)  
 TCP/IP port default [62](#)  
 TCP/IP settings [56](#)  
 text overlay configuration [76](#)  
 time configuration [55](#)  
 time settings [54](#)  
 time zone [55](#)  
 transparent channel, configuring RS-232 port as [93](#)  
 trap address, default [65](#)

trap port, default [65](#)  
two-way audio [46](#)

## U

upgrading the system [115](#)  
uploading to ftp [80](#), [84](#)  
UPnP settings configuration [69](#)  
user accounts  
    adding a user [107](#)  
    deleting a user [109](#)  
    modifying a user [108](#)  
user accounts, maximum number [107](#)  
user name default [37](#)

## V

video encoding standard [79](#)  
video files, downloading [104](#)  
video loss alarm configuration [88](#)  
video parameters, configuring [50](#)  
video quality [78](#)  
video settings configuration [77](#)  
video standard

    default [51](#)  
video type [78](#)  
video-in connectors [28](#), [30](#), [32](#)  
viewing  
    device name [112](#)  
    device number [112](#)  
    encoding version [112](#)  
    firmware version [112](#)  
    model [112](#)  
    number of alarm inputs [112](#)  
    number of alarm outputs [112](#)  
    number of channels [112](#)  
    number of HDDs [112](#)  
    serial number [112](#)  
viewing device information [112](#)

## W

warnings [15](#)  
warranty [17](#)  
web browser  
    supported [42](#)  
WEEE [16](#)





**Honeywell Security Products Americas (Head Office)**

2700 Blankenbaker Pkwy, Suite 150

Louisville, KY 40299, USA

[www.honeywell.com/security](http://www.honeywell.com/security)

☎ +1 800 323 4576

**Honeywell Security Northern Europe**

Ampèrestraat 41

1446 TR Purmerend, The Netherlands

[www.honeywell.com/security/nl](http://www.honeywell.com/security/nl)

☎ +31 (0) 299 410 200

**Honeywell Security Europe/South Africa**

Aston Fields Road, Whitehouse Industrial Estate

Runcorn, WA7 3DL, United Kingdom

[www.honeywell.com/security/uk](http://www.honeywell.com/security/uk)

☎ +44 (0) 1928 754 028

**Honeywell Security Deutschland**

Johannes-Mauthe-Straße 14

D-72458 Albstadt, Germany

[www.honeywell.com/security/de](http://www.honeywell.com/security/de)

☎ +49 (0) 7431 801-0

**Honeywell Security Products Americas  
Caribbean/Latin America**

9315 NW 112th Ave.

Miami, FL 33178, USA

[www.honeywell.com/security/clar](http://www.honeywell.com/security/clar)

☎ +1 305 805 8188

**Honeywell Security France**

Immeuble Lavoisier

Parc de Haute Technologie

3-7 rue Georges Besse

92160 Antony, France

[www.honeywell.com/security/fr](http://www.honeywell.com/security/fr)

☎ +33 (0) 1 40 96 20 50

**Honeywell Security Pacific**

Level 3, 2 Richardson Place

North Ryde, NSW 2113, Australia

[www.asia.security.honeywell.com](http://www.asia.security.honeywell.com)

☎ +61 2 9353 7000

**Honeywell Security Italia SpA**

Via della Resistenza 53/59

20090 Buccinasco

Milan, Italy

[www.honeywell.com/security/it](http://www.honeywell.com/security/it)

☎ +39 (0) 2 4888 051

**Honeywell Security Asia**

35F Tower A, City Center, 100 Zun Yi Road

Shanghai 200051, China

[www.asia.security.honeywell.com](http://www.asia.security.honeywell.com)

☎ +86 21 5257 4568

**Honeywell Security Middle East/N. Africa**

Emaar Business Park, Sheikh Zayed Road

Building No. 2, Office No. 30

Post Office Box 232362

Dubai, United Arab Emirates

[www.honeywell.com/security/me](http://www.honeywell.com/security/me)

☎ +971 (0) 4 450 5800

**Honeywell Security España**

Avenida de Italia, nº 7, 2ª planta

C.T. Coslada

28821 Coslada, Madrid, Spain

[www.honeywell.com/security/es](http://www.honeywell.com/security/es)

☎ +34 902 667 800

# Honeywell

[www.honeywell.com/security](http://www.honeywell.com/security)

+1 800 323 4576 (North America only)

<https://www.honeywellsystems.com/ss/techsupp/index.html>

Document 800-15877V1 – Rev A – 10/2013

© 2013 Honeywell International Inc. All rights reserved. No part of this publication may be reproduced by any means without written permission from Honeywell. The information in this publication is believed to be accurate in all respects. However, Honeywell cannot assume responsibility for any consequences resulting from the use thereof. The information contained herein is subject to change without notice. Revisions or new editions to this publication may be issued to incorporate such changes.