



Technical Manual



Stepper motor control **SMCI33**

NANOTEC ELECTRONIC GmbH & Co. KG
Gewerbestraße 11
D-85652 Landsham near Munich, Germany

Tel. +49 (0)89-900 686-0
Fax +49 (0)89-900 686-50
info@nanotec.de

Editorial

© 2010

Nanotec[®] Electronic GmbH & Co. KG
Gewerbestraße 11
D-85652 Landsham / Pliening, Germany

Tel.: +49 (0)89-900 686-0
Fax: +49 (0)89-900 686-50

Internet: www.nanotec.de

All rights reserved!

MS-Windows 2000/XP/Vista/7 are registered trademarks of the Microsoft Corporation.

Version/Change overview

Version	Date	Changes
1.0	02/20/2009	New issue C+P
2.0	07/01/2009	Revision C+P
2.1	04/08/2010	Revision C+P
2.2	11/08/2010	Revision C+P

About this manual

Target group

This technical manual is aimed at designers and developers who need to operate a Nanotec® stepper motor without much experience in stepper motor technology.

Important information

This technical manual must be carefully read before installation and commissioning of the stepper motor control.

Nanotec® reserves the right to make technical alterations and further develop hardware and software in the interests of its customers to improve the function of this product without prior notice.

This manual was created with due care. It is exclusively intended as a technical description of the product and as commissioning instructions. The warranty is exclusively for repair or replacement of defective equipment, according to our general terms and conditions, liability for subsequent damage or errors is excluded. Applicable standards and regulations must be complied with during installation of the device.

For criticisms, proposals and suggestions for improvement, please contact the above address or send an email to: info@nanotec.com

Additional manuals

Please also note the following manuals from Nanotec:

NanoPro User Manual	Configuration of controllers with the NanoPro software	
Programming manual	Controller programming <ul style="list-style-type: none">• Command reference• NanoJ• COM interface	

The manuals are available for download at www.nanotec.com.

Contents

1	Overview	5
2	Connection and commissioning	6
2.1	Connection diagram	6
2.2	Commissioning	8
3	Connections and circuits	10
3.1	Inputs and outputs (I/O): Connector X1	10
3.2	Encoder connection: Connector X2	12
3.3	Stepper motor connection: Connector X3	13
3.4	Voltage supply connection: Connector X4	14
3.5	RS485 network: connector X5	15
4	Operating modes	17
5	Troubleshooting	19
6	Technical data	20
Index		22

1 Overview

Introduction

The stepper motor control SMCI33 is an extremely compact and cost-effective constant current power output stage with integrated Closed-Loop current control.

Due to the great capacity and functions available, it offers designers and developers a rapid and simple method of resolving numerous drive requirements with less programming effort.

It is used for controlling standard stepper motors (including with attached encoders) or motors with integrated encoders or brakes.

Variants

The SMCI33 is available in the following variants:

- SMCI33-1: with USB interface (drivers necessary)
- SMCI33-2: with RS-485 interface

SMCI33 functions

The stepper motor control SMCI33 contains the following functions:

- Microstep -1/1 – 1/64 final output stage (step resolution of up to 0.014° in motor with a step angle of 0.9° in 1/64 step mode)
- Closed-Loop current control (sinusoidal commutation via the encoder)
- Rotation monitoring for optional encoder
- RS485 or USB interface for parameterisation and control
- Sequence programs with NanoJ
- Network capability up to 254 motors
- Easy programming with the NanoPro Windows software



Closed-Loop current control (sinusoidal commutation via the encoder):

In contrast to conventional stepper motor positioning controls where only the motor is actuated or the position adjusted via the encoder, sinusoidal commutation controls the stator magnetic field via the rotary encoder as in a servomotor. The stepper motor acts in this operating mode as nothing more than a high pole servomotor, i.e. the classic stepper motor noises and resonances vanish. As the current is controlled, the motor can no longer lose any steps up to its maximum torque.

If the controller recognizes that the rotor is falling behind the stator field due to overload, adjustments are made with optimal field angle and increased current. In the opposite case, i.e. if the rotor is running forward due to the torque, the current is automatically reduced so that current consumption and heat development in the motor and controller are much lower compared to normal controlled operation.

NanoJ

The integrated programming language NanoJ, based on the Java standard, means complete application programs can be realized on the drivers that can be executed independently without a higher-order controller.

The programs can be created, compiled directly and written to the controller with the free NanoJEasy editor.

NanoJ is only supported by the RS485 firmware.

More detailed information can be found in the separate programming manual.

Settings

The operating behavior of the motor can be set and optimized according to individual requirements by setting the motor-related parameters. The parameters can be set using the NanoPro software and significantly reduce commissioning time.

More detailed information on this can be found in the separate NanoPro user manual.

Rotation monitoring

Even if stepper motors do not lose steps during normal operation, the integrated speed control provides additional security in all operating modes, e.g. against motor stalling or other external sources of error. The monitoring function detects a stalled motor or step loss after half a step at the most (for 1.8° stepper motors).

Automatic error correction is possible after the drive profile is ended or during the drive.

2 Connection and commissioning

2.1 Connection diagram

Introduction

To operate a stepper motor with the SMCI33 stepper motor control, the wiring must be implemented according to the following connection diagram.


Inputs (Pin 1 to 6) on the connector X1 and the encoder input (connector X2) can be used optionally.

Connection diagram SMCI33

Nanotec / Connection diagram / SMCI 33-1 (USB) / SMCI 33-2 (RS 485)

Speed and positioning control (Closed Loop) via

- a) PC - for control and parameterization of c), d) and e)
- b) Industrial control system
- c) SPS - e.g. Logo or Easy
- d) Analog / Joystick
- e) Stand alone - via external switch



2.2 Commissioning

Introduction

The connection and commissioning of the SMCI33 stepper motor are described below.

This section describes the main first steps you need to take to be able to quickly begin working with the SMCI33 if you are using the NanoPro software from a PC. You will find more detailed information in the separate NanoPro manual.




If you want to work at a later time with a PLC or your own program, you will find the necessary information in the separate "Command Reference".

Familiarize yourself with the SMCI33 stepper motor control and the corresponding NanoPro control software before you configure the controller for your application.

Procedure

Proceed as follows to commission the controller:

Step	Action	Note
1	Install the NanoPro control software on your PC. See the NanoPro separate manual.	Download of www.nanotec.com
2	Connect the controller to the stepper motor according to the connection diagram.	Connection diagram, see Section 2.1. Detailed information on connections can be found in Chapter 3.
3	Switch on the operating voltage (24 V DC ... 48 V DC).	The green LED lights up.
4	If necessary, install the USB driver and the driver for the converter cable ZK-RS485-USB.	Download www.nanotec.com in the Support/Download/Driver menu item
5	CAUTION! Danger of overvoltage at the USB interface. When using notebooks connected to the line supply, detach the power cable before connecting the USB cable.	
6	Connect the controller with your PC. Use one of the following converter cables for this purpose: <ul style="list-style-type: none">• ZK-RS485-RS232 for connection to the serial interface• ZK-RS485-USB or conventional USB cable, type MINI-B, for connecting to the USB interface (for SMCI33-1)	Order number: <ul style="list-style-type: none">• ZK-RS485-RS232• ZK-RS485-USB

Step	Action	Note
7	Start the NanoPro software. 	The NanoPro main menu appears.
8	Select the <Communication> tab. 	
9	In the field "Port", select the COM port to which the SMCI33 is connected. 	The number of the COM port to which the controller is connected can be found in the device manager of your Windows PC. (System control/system/hardware).
10	Select the "115200 bps" entry in the "Baudrate" selection field.	
11	Check the current setting using the motor data sheet.	Under no circumstances may the current be set to a value higher than the rated current of the motor.
12	Select the <Mode> tab. 	
13	Click on the <Test Record> button to carry out the pre-set travel profile. 	The connected motor operates with the pre-set travel profile (default travel profile after new installation).
14	You can now enter your required settings. For instance, you can enter a new travel profile.	See the NanoPro separate manual.

3 Connections and circuits


3.1 Inputs and outputs (I/O): Connector X1

Introduction

An overview of the assignments can be found in the wiring diagram in Section 2.1). This section looks in detail at the assignment, functions and circuits of the connector X1.

The connectors and sockets used are from Phoenix, order number: FK-MC 2/4/5/12.

Connection diagram



Pin assignment

Pin no.	Name	Observations
1	Input 1	5-24 V Optocoupler
2	Input 2	5-24 V Optocoupler
3	Input 3	5-24 V Optocoupler
4	Input 4	5-24 V Optocoupler
5	Input 5	5-24 V Optocoupler
6	Input 6	5-24 V Optocoupler
7	Com	Signal GND
8	Output 1	Open-Collector
9	Output 2	Open-Collector
10	Output 3	Open-Collector
11	Analog In	-10 V ... +10 V
12	GND	Power & Analogue GND

Note:

Com and GND connection are not connected. Com is the ground connection for the inputs and GND is the ground connection for outputs and the internal circuitry.

Function of the inputs

All digital inputs – with the exception of the "Clock" input in the clock directional mode – can be freely programmed using the NanoPro software (e.g. as a limit position switch, enable, etc.) and can be used for sequential control with NanoJ.


All inputs can be configured for "active-high" (PNP) or "active-low" (NPN) with NanoPro.

Input circuits

All inputs (apart from the "Analogue In" input) are electrically isolated by optocouplers from the voltage supply of the SMCI33 and designed for 5 - 24 V input signals at an input current of 10 mA.


Note:

The voltage must not exceed 24 V. It should drop below 2 V for safe switching off and be at least 4.5 V for safe switching on.



Output circuits

The outputs are transistor outputs in Open-Collector circuits (0 switching, max. 30 V / 30 mA). An LED can be integrated to test the output. The LED lights up when the output is active.



3.2 Encoder connection: Connector X2

Optional encoder

An optional encoder can be connected to the stepper motor control.

By default, the closed-loop control for a three-channel encoder is set up with 500 pulses/revolution in an 1.8° stepping motor. With an 0.9° stepper motor, you should use an encoder with 1000 pulses/revolution to achieve the same control quality. Depending on the application, it may make sense to use higher encoder resolutions (up to max. 2000 pulses/revolution) to improve control quality or to use a lower resolution (min. 200 pulses/revolution) for low-cost applications or for step monitoring alone.

The following encoder resolutions can normally be processed by the controller: 192, 200, 256, 400, 500, 512, 1000, 1024, 2000, 2048.

Recommended:

Where possible, use Nanotec encoders with the order number WEDS/WEDL-5541 Xxx.


If an encoder is **not** used, the "Disable" mode must be set in the "Error correction" tab in the "Rotation Direction Mode" selection menu. See the NanoPro separate manual.

Using encoders with line drivers

The encoders of the WEDL series with a line driver output an inverted signal in addition to the encoder signal; this leads to better interference immunity and is especially recommended for long lines lengths.

We recommend shielding and twisting the encoder line to minimize interference with the encoder signal from the outside. To be able to connect negative signals to the SMCI33, you require adapter ZK-SMCI-LD.

Encoder connection diagram (X2)



Note:

Complete connection diagram, see Section 2.1.

Pin assignment connector X2: Encoder

Pin no.	Name	Observations
1	+5 V	
2	Track (B)	
3	Track (A)	
4	Index track (I)	
5	GND	

3.3 Stepper motor connection: Connector X3

General information

The motor is connected to the SMCI33 with a 4-wire cable. Twisted wire pair cables with braided shields are recommended.




Danger of electrical surges

Mixing up the connections can destroy the output stage! See also the data sheet of the connected stepper motor.

Never disconnect the link when operating voltage is applied!

Never disconnect lines when live!

Connection diagram



Note:

Complete connection diagram, see Section 2.1.

Pin assignment connector X3: Stepper motor

Pin no.	Name	Observations
1	A	See the data sheet of the connected stepper motor.
2	A/	
3	B/	
4	B	

Motor with 6 or 8 connections

If you are using a motor with 6 or 8 connections, you need to connect the windings.

The pin configuration for the motor can be found on the motor data sheet, which can be downloaded from www.nanotec.de.

3.4 Voltage supply connection: Connector X4

Permissible operating voltage

The permissible operating voltage for the SMCI33 stepper motor control lies between +24 and +48 V DC; it must not exceed 50 V or fall below 21 V.

A charging condenser with minimum 4700 µF (10000 µF) must be provided for the operating voltage to prevent exceeding the permissible operating voltage (e.g. during braking).



Danger of electrical surges

Connect charging condenser with minimum 4700 µF!

Connect a condenser with 10000µF for motors with flange size 86x86 (series ST8918) or greater!


An operating voltage > 50 V will destroy the output stage!

Mixing up the connections can destroy the output stage!

Never disconnect the link when operating voltage is applied!

Never disconnect lines when live!

Connection diagram voltage supply (X4)



Note:

Complete connection diagram, see Section 2.1.

Pin assignment

Pin no.	Name	Observations
1	Vcc	Operating voltage +24 V DC ... +48 V DC
2	GND	Earth (0 V)

Accessories for voltage supply

Appropriate power packs and charging condensers are available as accessories:

Name	Order identifier
Power pack	NTS-xxV-yA (xx=voltage: 24 or 48 V, y=current: 2.5, 5 or 10 A) Information on the selection of the required power supply unit can be found in our FAQ on www.nanotec.de .
Charging condenser	Z-K4700 or Z-K10000

Note:

Further information about accessories can be found on the Nanotec website:
www.nanotec.com

3.5 RS485 network: connector X5


SMCI33 in a network

Up to 254 stepper motor controls can be controlled in a network from a PC or PLC.

These network connections are set up via the RS485 interface.

D-sub socket connector

A 9 pin D-Sub socket connector is located on the top of the SMCI33 (connector X5). The connector X5 provides the optional connection to the RS485 network.



Pin assignment connector X5: RS485 interface

Pin no.	Name	Observations
1	NC	Not assigned
2	Rx+	RS-485 Rx+
3	+5 V	Output +5 V
4	Tx+	RS-485 Tx+
5	NC	
6	NC	
7	Rx-	RS-485 Rx-
8	GND	Output GND (0 V)
9	Tx-	RS-485 Tx-

Two-wire operation

To enable RS485 two-wire transmission capability, all bus stations must have a direction control.


An intelligent converter, which automatically switches to transmission mode when a start bit is received at the RS-232 interface and returns to reception mode at the end of the stop bit, enables two-wire operation of the SMCI33. This solution does not require software support.

We can recommend the ICP-7520 converter, for example, that is available from Schuricht.

Talk to our Technical Hotline if you require support for this.

Circuit diagram RS485 network

CONNECTION DIAGRAMM RS485 NETWORK CONTROLLER



4 Operating modes

Introduction

Depending on the travel profile, the motor can be operated using different operation modes. Due to the great capacity and functions available, it offers designers and developers a rapid and simple method of resolving numerous drive requirements with less programming effort.

Select the required operating mode for each drive profile and configure the controller according to your requirements.


More detailed information can be found in the separate NanoPro manual.

Overview of operating modes and their areas of application

Operation mode	Application
Relative positioning	Use this mode when you wish to travel to a specific position.
Absolute positioning	The motor travels according to a specified drive profile from a Position A to a Position B.
Internal reference run	During the internal reference run, the motor travels to an internal reference point at the set minimum speed (index mark of encoder, only in combination with an encoder).
External reference run	During an external reference run, the motor travels to a switch connected to the reference input.
Speed mode	Use this mode when you wish to travel with a specific speed (e.g. a conveyor belt or pump speed). In the speed mode, the motor accelerates with a specified ramp from the starting speed (start frequency "V Start") to the specified maximum speed (maximum frequency "V Normal"). Several inputs enable the speed to be changed on-the-fly to different speeds.
Flag positioning mode	The flag positioning mode offers a combination of the speed and positioning modes. The motor is initially operated in speed mode; when a trigger point is reached, it changes to the positioning mode and the specified setpoint position (relative to the trigger position) is approached. This operating mode is used for labeling, for example: the motor first travels with the set ramp to the synchronous speed of the conveyed goods. When the labels are detected, the preset distance (position) is traveled to apply the labels.

Operation mode	Application
Clock direction mode, left	
Clock direction mode, right	
Clock direction mode Int. Ref.	Use this mode when you wish to operate the motor with a superordinate controller (e.g. CNC controller). In the clock direction mode, the motor is operated via two inputs with a clock and a direction signal from a superordinate positioning control (indexer).
Clock direction mode Ext. Ref.	Depending on the mode selected (Int. Ref./Ext. Ref.), the internal and external reference runs are supported.
Analog and joystick mode	The motor is controlled in this operating mode simply with a potentiometer or a joystick (-10 V to +10 V). Use this mode if you want to use the motor in a simple application: <ul style="list-style-type: none"> Setting a specific speed, e.g. via an external potentiometer, Traveling synchronously with a superordinate controller with analog output (-10 V to +10 V).
Analogue positioning mode	Use this mode when you wish to travel to a specific position. The voltage level on the analog input is proportional to the required position.
Torque mode	Use this mode when you require a specific output torque independent of the speed as is the case in typical winding and unwinding applications. The maximum torque is specified via the analog input.

Selecting the operating mode in NanoPro



5 Troubleshooting

Troubleshooting procedure

Proceed with care during troubleshooting and error rectification to avoid damaging the controller.

	Danger of electrical surges An operating voltage > 50 V and incorrect connections can destroy the end stage. Never disconnect the link when operating voltage is applied! Never disconnect lines when live!
---	---

Possible error

Error	Possible cause	Rectification
Controller is not ready	Data transmission to SMCI33 not possible (communication error): Incorrect COM port selected.	In the "Communication" tab, select the PC port to which you have connected the SMCI33 (e.g." COM-1") The port used can be found in the device manager of your PC.
	The communication cable is not connected or is interrupted.	Use only the recommended converter from Nanotec: <ul style="list-style-type: none">• ZK-RS485-RS232• ZK-RS485-USB
	A non-existent motor number (module number) is set.	Set the correct module address. See the separate manual on NanoPro.
	The power supply of the SMCI33 is interrupted.	Check voltage supply, switch on if necessary.
	Another open program is blocking the COM port to which the SMCI33 is connected.	Close down other programs on your PC.
	Inadmissible data was sent to the controller during the output of a travel profile.	Click on the <Yes> button to stop the travel profile. The SMCI33 switches back to the "Ready" state. The data can then be resent to the controller.
Transmission error	Data transmission to the SMCI33 is disturbed (sender or receiver are disturbed).	Check that the motor connection is correctly wired. We recommend using the following Nanotec converters: <ul style="list-style-type: none">• ZK-RS485-RS232• ZK-RS485-USB
Position error	The motor cannot reach the position or the limit switch was overrun.	Click the <Yes> button in the error message; the error is reset.
Red LED on the SMCI33 lit up.	Overtemperature of power electronics > 75 °C	Switch off controller and allow to cool. The error is reset when the SMCI33 is disconnected from the power supply unit.
	Undervoltage	Check voltage supply.

6 Technical data

Electrical connections

Operating voltage Vb	DC 24 V to 48 V $\pm 4\%$
Max. phase current	Adjustable up to max. 3 A/phase Continuous current 2 A/phase
Current drop	Adjustable 0 to 80% of phase current
Interfaces	<ul style="list-style-type: none"> • SMCI33-1: USB standard • SMCI33-2: RS-485 (4-wire) 115200 baud (adjustable) 1 start bit, 8 data bits, 1 stop bit no parity

Controller parameters

Step resolution	Full Step Half Step Quarter Step Fifth Step Eighth Step Tenth Step 16th Step 32nd Step 64th step Adaptive microstep (1/128)
Step frequency	0 to 50 kHz in clock direction mode 0 to 25 kHz in all other modes
Position monitoring	Automatic error correction up to 0.9°


Inputs and outputs

Inputs	6 optocouplers 5 – 24 V $\pm 10\%$ <ul style="list-style-type: none"> • Safe switch off: max. 2 V • Safe switch on: min. 4.5 V Signal delay time: <ul style="list-style-type: none"> • Inputs 1 to 5: 120 μs • Input 6: 10 μs
Outputs	<ul style="list-style-type: none"> • 3 transistor outputs in Open-Collector circuits (0 switching, max. 30 V/30 mA)

Protective circuits

Overvoltage and undervoltage	Protective circuit for voltages > 50 V or < 21 V
Max. heat sink temperature	Approx. 67 °C
Max. ambient temperature	0 to 40 °C

SMCI33 dimensions



A complete set of datasheets is available for downloading at www.nanotec.de.

Connectors

The following connectors are available on the SMCI33:

- Connectors X1, X2, X3 and X4:
Phoenix connector, type MICRO COMBICON
- Connector X5:
 - SMCI33-1: Mini-USB Type B
 - SMCI33-2: Sub-D 9-pin (RS485)

Index

A

Accessories for voltage supply 14

C

Closed-Loop current control 5

Commissioning 8

Connection diagram 7

Connection diagram inputs and outputs (I/O) 10

Connection diagram stepper motor 13

Connection diagram voltage supply 14

Connector X1 10

Connector X2 12

Connector X3 13

Connector X4 14

Connector X5 15

E

Encoder 6, 12

Encoder connection diagram 12

I

Input circuits 11

Inputs and outputs (I/O) 10

N

NanoJ 6

O

Operating modes 17

Operating voltage 14

Output circuits 11

P

Pin assignment connector X2 12

Pin assignment connector X3 13

Pin assignment connector X4 14

Pin assignment of X1 connector 10

Pin assignment of X5 connector 15

Protective circuits 20

R

Rotation monitoring 6

RS485 network 15

S

SMCI33 functions 5

Stepper motor 13

T

Two-wire operation 15

V

Variants 5

Voltage supply 14