

P&E Microcomputer Systems, Inc. PKGPPCNEXUS

Quick Start Guide for the PHYTEC phyCORE-MPC5554 Rapid Development Kit

Visit us on the web: www.pemicro.com
© 2006 P&E Microcomputer Systems, Inc.
All Rights Reserved

CONTENTS

1	Topics Included In This Guide	1
2	PKGPPCNEXUS - Software Overview.....	3
3	Installing the PKGPPCNEXUS Development Environment.....	4
	3.1 Changing the Default Installation Location.....	4
4	PKGPPCNEXUS – Quick Start Guide.....	5
	4.1 Configuring the Target Board	5
	4.2 Starting WinIDE	5
	4.3 Creating a New Project with a WinIDE Template.....	6
	4.4 Files Included in the Template Project	8
	4.5 Windows Layout for C-compilation.....	9
	4.6 Viewing Source Files to Compile - The Build Dialog	11
	4.7 Viewing Compiler Options	12
	4.8 Compiling the Application, Interpreting the Result	12
	4.9 Programming Flash Using PROGPPCNEXUS	15
	4.10 Starting the Debugger	18
	4.11 Boot Assist Module Considerations.....	19
	4.12 Loading the Debug Information	20
	4.13 Stepping through C Instructions	21
	4.14 Using Code Window Quick Execution Features	23
	4.15 Using Code Window Popup Debug Evaluation Hints.....	25
	4.16 Using the Variables Window	26
	4.16.1 Modifying a Variable's Value	27
	4.16.2 Modifying a Variable's Properties	28
	4.17 Using the register interpreter.....	29
	4.17.1 Register interpreter display.....	29
	4.17.2 Adding Register Field Descriptions to the VAR Window.....	31
	4.18 Executing the PowerPC Nexus Application.....	31
	4.19 Creating an Application for SRAM.....	32

1 Topics Included In This Guide

This document is a step-by-step guide to using PKGPPCNEXUS with the Phytex phyCORE-MPC5554 evaluation board. The guide covers creating a C language project, compiling the source code with the GNU compiler, programming code to internal Flash memory and internal SRAM, and debugging with the P&E ICDPPCNEXUS in-circuit debugger.

The "PKGPPCNEXUS User's Manual" includes detailed information about using WinIDE to configure the GNU compiler. The "Application Framework and Solutions Guide" summarizes the process of customizing the target application for your system.

2 PKGPPCNEXUS - Software Overview

The P&E PKGPPCNEXUS Windows development environment for PowerPC Nexus includes software to edit and compile C source code for the PowerPC Nexus family of processors that use the e200z6 core. PKGPPCNEXUS contains software for programming Flash and debugging with a PowerPC Nexus target system.

This version of PKGPPCNEXUS provides templates for building an application for the MPC5553 and MPC5554 processors. Although the templates are intended to be used with select evaluation boards, you may use PKGPPCNEXUS to create an application for any MPC5553 or MPC5554 board. The GNU compiler supports any PowerPC processor that implements the e200z6 core or e200z3 core operating in non-VLE mode.

PKGPPCNEXUS includes the following software:

WinIDE – Integrated Development Environment for the PowerPC Nexus architecture.

This is the primary editing environment for the software kit. It is the launch pad for other applications, such as the P&E in-circuit debugger, P&E in-circuit Flash programmer, and the GNU C compiler. Control the settings for the GCC compiler within the WinIDE environment.

ICDPPCNEXUS – In-Circuit Debugger for PowerPC Nexus series devices.

This debugger supports reading and writing memory and variables, loading code to RAM, controlling processor execution, and more. Use the debugger to step through both assembly language and C language source code. The debugger loads the Elf/Dwarf (version 2.0) debug file format, which is output by many compilers, such as the GNU compiler included in this package.

PowerPC EABI SPE GCC Compiler – Windows GNU C compiler for select PowerPC 55xx targets.

Without requiring a UNIX shell, this compiler executes under the Windows operating system. WinIDE controls the operation of the compiler, providing one-touch compilation of a C project. The GNU software produces both the Elf/Dwarf 2.0 and S19 file formats. P&E's in-circuit Flash programmer will program with the S19 file, and P&E's in-circuit debugger will use the Elf/Dwarf file for debugging.

The GNU toolset includes the following components:

- GCC version 3.4.4
- Binutils version 2.15.91
- Newlib version 1.13.0

Both GCC and Binutils have been patched to support the e200z6 core and e200z3 core operating in non-VLE mode.

PROGPPCNEXUS – In-circuit Flash programmer for PowerPC Nexus.

Register File Viewer for PowerPC Nexus

This software simplifies viewing and editing PowerPC registers and register bits.

3 Installing the PKGPPCNEXUS Development Environment

You must have administrator privilege on the Windows 95/98/ME/NT/XP computer that will host the software. After launching the installer, follow the instructions to install all of the software in the default location, C:\pemicro\pkgppcnexus.

Take note of several subdirectories in the PKGPPCNEXUS installation directory:

\gnu
GNU/GCC software (P&E Build)

\gnu\bin
GNU/GCC executables (P&E Build)

3.1 Changing the Default Installation Location

The default installation location for PKGPPCNEXUS is C:\pemicro\pkgppcnexus. Using the installer software, you may install the software at any location.

We do not recommend that you manually change the location of PKGPPCNEXUS after installation. Do not copy-and-past the GNU compiler to a different location. However, you may place your source code and WinIDE project files at any location.

4 PKGPPCNEXUS – Quick Start Guide

The following sections walk you through select tasks using PKGPPCNEXUS. *For more information regarding each of the P&E software components, see the Windows help files for WinIDE, ICDPPCNEXUS, and PROGPPCNEXUS.*


4.1 Configuring the Target Board

There are templates to create projects for both internal Flash and internal SRAM using the phyCORE-MPC5554 board. First, we will create a project that runs in internal Flash. Be sure that your target board is configured to boot from internal Flash memory. Later, we will create a project for RAM only.

4.2 Starting WinIDE

After installing PKGPPCNEXUS, launch the WinIDE development environment by using the Windows Start menu. Select the WinIDE icon in the program group for the P&E PowerPC Nexus kit. Alternatively, double-click on the **WinIDE32.exe** icon in the installation directory, **C:\pemicro\pkgppcnexus**.

When the WinIDE development environment launches for the first time, it will display a file containing a description of the documentation included with PKGPPCNEXUS.




A WinIDE project file contains the names of user files associated with a project as well as a wide range of compilation and editing settings. The WinIDE project name appears in the title bar of the main WinIDE window, shown as ReadMe_pkgPPCnexus.ppf, above.


4.3 Creating a New Project with a WinIDE Template

Use WinIDE's templates to create a C language project for your target system. Use the template to create a new WinIDE project and to automatically configure the GNU C compiler. After WinIDE copies default source files to your new project folder, it will tailor the compiler settings for your target system.

Begin by selecting the WinIDE Environment menu, New Project from Template. A list of processors or evaluation boards will appear. Select the template "**EVB_PHYTEC_PHYCOREMPC5554**". This will create a project that will reside in internal Flash and utilize internal SRAM and cache. We will discuss the template "EVB_PHYTEC_PHYCOREMPC5554_SRAM" later.




A dialog will ask you to select an empty directory for the new project.




Instead of selecting an existing directory, type the path and name of a new folder in the edit box. Then, hit the Create New Folder button, then **OK**. WinIDE will create the new, empty folder.

Next, type the name of your new project file.



WinIDE will ask you for the root directory of the GNU compiler. In most cases, WinIDE will automatically select the correct folder. The default compiler root directory is **C:\pemicro\pkgppcnexus\gnu**.



WinIDE will ask if you want to save the initial project, ReadMe_pkgPPCnexus.ppf; select **No** or **Yes**.

The default project files will now be located in the new project directory, **C:\new_project**. WinIDE will open the new WinIDE project file, project.PPF.

4.4 Files Included in the Template Project

A PowerPC Nexus template creates a project whose source code is very similar to the Freescale code for the processor. Freescale publishes this processor initialization code on the Freescale website. Differences between the Freescale source code and the P&E code are clearly noted in the P&E source code.

The P&E template includes Freescale's header files and initialization code for the PowerPC processor, as well as P&E's linker script and WinIDE project file. Take note of several subdirectories and files within the new project directory:

Subdirectory \headers

This folder contains Freescale header files for the PowerPC 55xx.

Subdirectory \src

This includes the Freescale initialization source code for the PowerPC 55xx.

Subdirectory \PEGnu

The folder contains the P&E linker script, WinIDE project file, and compiler output files, such as the ELF/DWARF, s-record, and compiler error log files.

P&E GNU Linker Script (*.ld)


This file works in conjunction with the Freescale code to control the memory map of the PowerPC application. The top of the linker script contains user defined settings, such as stack location and other memory settings.

WinIDE Project File (*.ppf)


This file contains all of the WinIDE settings, including compiler settings. Do not alter this file manually in a text editor.

4.5 Windows Layout for C-compilation

After creating your new project with a template, WinIDE will open the project file. **Close** the initial file, **ReadMe.txt**, which appears. WinIDE's window contains two areas, a left window pane to display open project files and a right window pane to display the names of the files in the current WinIDE project. Open the file, **main.c**, whose file name appears on the right pane. Click on the file name to open **main.c**, maximize the file, and WinIDE will appear as below:




The file, **err.log**, will contain the output messages of the GNU compiler, including warnings and errors. If this file is not already open during compilation, WinIDE will automatically open **err.log**. Opening the error log before running GCC will maintain the log's state, its window size and location. Open the error log and arrange the windows, as pictured below:




4.6 Viewing Source Files to Compile - The Build Dialog

WinIDE project files appear in WinIDE's right window pane. These files are not automatically passed to the GNU compiler. To view the files that will be compiled, select WinIDE's Environment menu, Environment Settings, Assembler/Compiler tab, Build Dialog. Add files, remove files, or change the compilation order from within this dialog. It is not necessary to alter the Build Dialog for this example.



4.7 Viewing Compiler Options


WinIDE configures the GNU compiler to build the PowerPC application. To view the compiler settings, select WinIDE's Environment menu, Environment Settings, Assembler/Compiler tab.



Use this screen, including the Compiler Options (General), Compiler Options (Paths), WinIDE Error Options, and Build Dialog, to configure the GNU compiler. It is not necessary to change the GNU compiler settings for this example.


4.8 Compiling the Application, Interpreting the Result

The default memory map for our example uses on-chip Flash memory, internal SRAM, and cache. For this example, use the default memory map, making no changes to the P&E linker script or the Freescale source files.

To compile the PowerPC Nexus application, either press the <F4> function key or click the compilation button  on the tool bar at the top of the WinIDE screen.


When compiling, WinIDE will generate a Windows batch file to control the GNU compiler. The batch file will contain the compiler settings from WinIDE.

The user may be prompted to confirm that the existing batch file should be overwritten.




Click **OK**. WinIDE will execute the batch file, and the batch file will execute the GNU compiler. WinIDE will read the results of the compilation and display the compiler messages in the file, **err.log**.

If there are no errors during compilation, WinIDE's status bar will indicate that WinIDE detects no errors.



To ensure that no error has occurred, always refer to the output in **err.log** to view all compiler messages.

If there is an error during compilation, WinIDE automatically opens the file containing the first error and attempts to highlight the line with the error.




WinIDE's status bar, at the bottom of the window, displays the first compiler error message. WinIDE recovers error messages from the file **err.log**. For more information on a specific error, refer to the compiler output in **err.log**. Certain errors, such as those that occur during linking, may not have a corresponding source line. To be sure that no error has occurred during the build process, always refer to the log file.


4.9 Programming Flash Using PROGPPCNEXUS

The template project produces a PowerPC Nexus application that will execute in the on-chip Flash memory. The PowerPC target application uses on-chip SRAM for global variables and on-chip cache for stack space. Use the default memory map for this example. The application base address, in Flash, is 0x00000000.

After compiling the application, program the application to on-chip Flash memory. Power down the target board. Before launching the Flash programming software, connect the host PC to the target board using a P&E hardware interface, such as the Cyclone MAX (USB port), USB-ML-PPCNEXUS (USB port), or the CABPPCNEXUS (parallel port). Power up the target board.

Launch the Flash programming software from within WinIDE by using the <F7> hotkey or the programming button  on the tool bar. Alternatively, there is an icon for PROGPPCNEXUS in the Windows Start menu in the program group for PKGPPCNEXUS.


After starting the Flash programmer, the connection assistant dialog will appear.



Use the drop-down menu labeled "Port" to choose the proper PC connection to your target board.


Click the Connect button, and PROGPPCNEXUS will attempt to contact the target processor. PROGPPCNEXUS will attempt to establish communications and to reset the processor.

Next, the Flash programmer will prompt you for a programming algorithm file.



Select the appropriate file in the Algorithms folder of the installation directory, and click Open. For this example, select **5554_2meg_04_and_Later.PCP**.


At this point, double click the **"EM Erase module"** command and allow the command to complete.




Issue the **"BM Blank check module"** command, and wait for the command to complete. Next, issue the **"SS Specify Object File"** command. The software will prompt for the S19 file. Select the file *main.s19* in the directory **C:\new_project\PEGnu**. Next, execute the commands **"PM Program module"** followed by **"VM Verify module"**. If PROGPPCNEXUS reports no errors, then the Flash memory on the processor has been programmed.

Exit the Flash programmer.

4.10 Starting the Debugger

After compiling and programming the PowerPC Nexus application to Flash, launch the debugger from WinIDE by using the <F6> key or the “run debugger” button  on the tool bar. Alternately, use the debugger icon in the program group for PKGPPCNEXUS, located in the Windows Start menu.


Upon starting the debugger, the connection assistant dialog appears.



Use the drop-down menu labeled "**Port**" to choose the proper PC connection to your target board.

Click the **Connect** button, and ICDPPCNEXUS will attempt to contact the processor. Using the default debugger settings, ICDPPCNEXUS will establish communications and reset the processor.


After establishing communications, the main debugger screen will appear, and a debugger macro should automatically execute and complete. If you do not see the debugger macro executing, issue the `MACRO` command in the debugger and select the file **C:\pemicro\pkgppcnexus\WPC5500_any_init.mac**. See the next section for an explanation of this debugger macro file.



4.11 Boot Assist Module Considerations


This section does not contain any steps for the user to complete, it simply explains the initialization that the debugger performs on the processor. A debugger initialization script controls the processor initialization. The user can view and modify all the script's initialization tasks.

The processor Boot Assist Module (BAM) would normally initialize the memory of the processor. However, when running the target application from the debugger, the BAM functionality is disabled. To account for this, the debugger must run a script file on reset. The script initializes the memory of the processor similar to the way in which the BAM would initialize the processor.

The appropriate macro file should automatically run on reset. To run the script file manually, type the MACRO command in the debugger status window or click the play macro  button on the debugger toolbar. Select the macro file **MPC5500_any_init.mac**, located in the PKGPPCNEXUS installation directory as well as **C:\new_project\PEGnu** in this example. When the script file runs, if the debugger has not been configured to run in silent mode, you will see a significant number of status messages scroll down the status window of the debugger.

The macro file MPC5500_any_init.mac does not initialize the external bus. You may run the macro files **MPC5500_ebi_32.mac** or **MPC5500_ebi_16.mac** to configure the external bus for 32-bit or 16-bit memory.


To configure the debugger macro to execute automatically on reset, select the debugger Configuration menu, Automated Script Options dialog, shown here:



4.12 Loading the Debug Information


After executing the initialization script, it is time to load the debugging information into the debugger. Issue the HLOADMAP command (type in HLOADMAP and hit enter) in the debugger status window, and select the Elf/Dwarf file, **C:\new_project\PEGnu\main.elf**. This will load the debug information that corresponds to the PowerPC application, now located in Flash.

Depending on the version of ICDPPCNEXUS, the debugger may display the following dialog box:



This warning relates to the format of the GNU Elf/Dwarf file. *For more information, see the document "P&E, GNU, and Elf/Dwarf".* When using GNU GCC, always select **"Yes"**.

After loading the Elf/Dwarf 2.0 file, the debugger status window will display the amount of debug and object information loaded from the file.



```


Status Window
>pc 00001104 ;Setting PC to entry point of application.
613 source line records in 15 files.
102 symbols defined.
0 object bytes loaded.
File loaded properly.
Ready

```

By default, when the debugger loads an Elf/Dwarf 2.0 file, the debugger sets the program counter (PC) to the start address of the target application.

4.13 Stepping through C Instructions

After loading the Elf/Dwarf file, the debugger code window displays assembly language startup code. After loading the file *main.elf*, the code window should show this source:




```

Code Window 2: Source (__start.s)
# Set up Read and Accesses by all Masters (Ref. Errata 105 - pre-Rev.A)
lis r5, FLASH_BIUAPR@h # Load upper address of BIUAPR into R5
ori r5, r5, FLASH_BIUAPR@l # Load lower address of BIUAPR into R5
lis r6, 0xFFFF # Load 0xFFFF into upper R6
ori r6, r6, 0xFFFF # Load 0xFFFF into lower R6
stw r6, 0(r5) # Store 0xFFFFFFFF into FLASH_BIUAPR

*****
# Call the individual assembly modules:
b1 cfg_CACHE # Invalidate and enable unified cache.

```

To run past the startup code, issue the debugger command "**GOTIL main**" in the status window. Note that the labels are case sensitive and that the "main" label should be lowercase. This will set a breakpoint at the beginning of the main function in **main.c** and start the processor running. Execution should stop almost immediately, and the program counter will be pointing to valid C source code.



```

Code Window 2: Source (main.c)
→ • #ifdef PEGNU
• int main (void) {

    #else
    void main (void) {
    #endif


    /* The code located here in "main()" may be replaced with */
    /* your application code.                                     */
    → • int cnt = 0;
    → • // Initialize the GPIO port for output.
    → • init_LED(PIN_EMIOS0, PIN_HI); /* P&E modification */

    /* The following function call, when commented out, will bypass the */
    /* interrupt configuration and use example.                             */
    //xcptn_xmpl();

    /* The following function call uses ".data" and ".sdata" elements */
    /* to force their inclusion at link time. Comment out or delete */
    /* this function call to bypass example use of initialized data. */
    → • use_elements();

    while (1) {
  
```


Instead of using the GOTIL command, you may step through the startup code to reach the main function. Step through the initialization code, or any source code, using the high-level language source step command. Use this feature by typing HSTEP in the status window or by clicking the high-


level step button  on the debugger tool bar. Each time the HSTEP command executes, the debugger will rapidly single step assembly instructions until it encounters the next source instruction, at which point target execution will cease. When the debugger reaches the next source instruction, all visible windows will be updated with data from the board.

After reaching the main function, step through several C language instructions. Notice that some instructions will take longer to step through than others because each C instruction may consist of a greater or fewer number of underlying assembly instructions.

4.14 Using Code Window Quick Execution Features


In the source code window, there will be a small red dot and a small blue arrow next to each source instruction that has underlying object code. If a large blue arrow appears on a source line, this indicates that the program counter (PC) points to this instruction. If a large red stop sign appears on the source line, this indicates that a breakpoint exists on this line.



Set a breakpoint at an instruction by double-clicking the tiny red dot. To remove a breakpoint, double-click the large red stop sign. When you issue the HGO command or click the high-level language GO button  on the debugger tool bar, execution will begin in real-time. If the debugger encounters a breakpoint, execution will stop on this source line. If it does not encounter a breakpoint, target execution will continue until you press a key or use the stop button on the debugger tool bar.

By double clicking the small blue arrow, you will be issuing a GOTIL command to the address of this source line. A GOTIL command will set a single breakpoint at the desired address, and the processor will begin executing code in real-time from the point of the current program counter (PC). When the debugger encounters the GOTIL address, execution stops. If the debugger does not encounter this location, execution continues until you press a key or use the stop button on the debugger tool bar. Note that all user breakpoints are ignored when the GOTIL command is used.


You may also double-click the red and blue symbols in the disassembly window. The disassembly window may display an additional symbol, a small, blue "S" enclosed in a box. This indicates that that a source code instruction begins on this disassembly instruction.



```
Code Window 2 : Disassembly
+ * main          9421FFE0 STWU R1,-0020(R1)
+ * 0000000C      7C0802A6 MFLR R0
+ * 00000010      93E1001C STW R31,001C(R1)
+ * 00000014      90010024 STW R0,0024(R1)
+ * 00000018      7C3F0B78 OR R31,R1,R1
+ * 0000001C      480010E5 BL 00001100
+ * 00000020      38000000 LI R0,0000
+ * 00000024      901F0008 STW R0,0008(R31)
+ * 00000028      386000B3 LI R3,00B3
+ * 0000002C      38800001 LI R4,0001
+ * 00000030      48000D4D BL init_LED
+ * 00000034      4800003D BL use_elements
+ * 00000038      38000000 LI R0,0000
+ * 0000003C      901F0008 STW R0,0008(R31)
+ * 00000040      801F0008 LWZ R0,0008(R31)
+ * 00000044      3D200098 LIS R9,0098
+ * 00000048      6129967F ORI R9,R9,967F
```

4.15 Using Code Window Popup Debug Evaluation Hints

When debugging source code, it is advantageous to view the contents of a variable while viewing your source code. The in-circuit debugger has a feature, debug hints, which displays the value of a variable while the mouse cursor is held over the variable name. The hint may be displayed in any of three locations, as shown below.



The three locations for the debug hints are the code window title bar, the status window caption bar, and a popup hint that appears over the variable in source code. You can configure the hints to display in any combination. Set the locations in the configuration menu of the debugger.

The information in the popup hint box is similar to the information displayed in the variables window.

cnt : \$00000000 {Address=\$40010FD0 Type=signed long}

The information includes the variable name (cnt), value (\$0), and type (signed long).

4.16 Using the Variables Window


The variables window displays the current value of application variables. The following window shows a display of variables from the example application.



Variables that are pointer types are displayed in red. Normal variables are displayed in black. Real time variables are displayed in blue. A real time variable is a variable that is updated while the processor is running. Add real time variables by using the RTVAR *varname* command in the status window. Add normal variables by using the VAR *varname* command.

To view the variables above, type "**var cnt**" and "**var &cnt**" in the debugger status window. Also, you may add a variable by right clicking the variables window and choosing "**Add a variable**". Delete a variable by selecting it in the variables window, right clicking, and choosing "**Delete variable**".


When adding a variable using the pop-up menu, the debugger displays the following screen.



In the variable field, type the address or name of the variable. Typically, set the type of the variable to "**Default**", which means that the variable will be displayed as it is defined in the debugging information. When adding a variable, you may specify the numeric display base of the variable.


4.16.1 Modifying a Variable's Value

To modify the current value of a variable, double-click the **variable name** in the variables window. If the debugger supports modification of this type of variable, it will display the modify variable dialog. Check the “**Modify value**” checkbox, and type the variable’s new value. After you click the **OK** button, the debugger updates the variable value on the target memory, and the debugger refreshes the variable window to display the new value. Note that the debugger will not edit certain user-defined types, such as enumerated types.



4.16.2 Modifying a Variable's Properties

To modify a variable's display properties, such as the type or numeric display base, double-click the **variable name** in the variables window. Check "**Modify display properties**" in the modify variable dialog. Change the variable type and base. Click the **OK** button, and the debugger will update the variable's display properties in the variables window.





4.17 Using the register interpreter


The register interpreter provides a descriptive display of bit fields within the processor's peripheral registers. The register interpreter allows you easily to change the value of these registers. You may quickly check the current state of a peripheral and examine the configuration of the target device.

When you use the register interpreter within the debugger, it reads the current value of the peripheral register, decodes it, and displays it. When using the register interpreter within WinIDE, all the fields are initialized to 0. When the user hits the Enter key, the value is written into the editor at the current cursor location, as opposed to being written back into memory, as the debugger does.


Note that the register interpreter is available for select processors only.

4.17.1 Register interpreter display


To launch the register interpreter in the debugger, either use the “**R**” command or click the view/edit register  button on the tool bar. To display the interpreter from WinIDE, use the “**SHIFT-F1**” keystroke combination or the register files  button on the tool bar. In either application, a window will appear that allows you to select a peripheral block to examine.




Double clicking the module of choice will launch the register selection window.



Double clicking a specific register will launch the edit/display window for that register.



The window lists the keystrokes and mouse actions, allowing you to modify the values of each of the fields. After right clicking on a specific field, the register interpreter will display all options for that field.




In the debugger, when you quit the register view/edit window by hitting the **ESC** key, you will be given the opportunity to write the new value into the register, as shown in the following window.



4.17.2 Adding Register Field Descriptions to the VAR Window

Add register bit fields to the variables window by using the “**_TR**” command in the debugger. Add bit fields defined within a register description. After selecting the register field, the field appears in the debugger variables window, and the debugger will continually update its value. A variables window with fields from a chip select register may look like this.



4.18 Executing the PowerPC Nexus Application

Issue the HGO command in the debugger. The PowerPC Nexus application will execute in real time. The LED on the target board should be blinking.

4.19 Creating an Application for SRAM

You may create an application for the MPC5554 that runs in on-chip SRAM and cache only. The PowerPC application will not use Flash memory.

Follow these steps:

1. In WinIDE, select the **Environment menu**, New Project from Template. Select **EVB_PHYTEC_PHYCOREMPC5554_SRAM**. Finish creating the new project and compile using <F4>. The new PowerPC application will execute in on-chip SRAM at address 0x40000000 and use the cache as stack space.
2. In WinIDE, press <F6> to launch the debugger. The debugger should automatically execute macro file **mpc5500_any_init.mac**. If not, issue the MACRO command in the debugger and select **C:\pemicro\pkgppcnexus\mpc5500_any_init.mac**.
3. In the debugger, issue the **HLOAD** command. Select your *Elf/Dwarf* file, such as **C:\new_project\PEGnu\main.elf**. This will load the object code to SRAM as well as load the debugging information to the debugger. When you see source code in the debugger, you are ready to debug as described in the previous sections.

Document: QuickStart Guide for the PHYTEC phyCORE-MPC5554 Rapid Development Kit
Document number: L-486e_1, 2006

How would you improve this manual?

Did you find any mistakes in this manual?

page

Submitted by:

Customer number:

Name:

Company:

Address:

Return to:

PHYTEC Technologie Holding AG
Postfach 100403
D-55135 Mainz, Germany
Fax : +49 (6131) 9221-33

