

Megawin 8051 Writer

User Manual

By Vincent Y. C. Yu


Contents

1	Introduction	3
2	Install the PC-site AP and Driver for the Writer	4
2.1	Install the Driver	4
2.2	Install the AP	4
3	MCU's Flash Memory Configuration	5
3.1	MPC89L516/556X2	5
3.2	MPC89L(E)51/52/53	6
3.3	MPC89L(E)54/58/515	7
3.4	MPC82L(E)52	8
3.5	MPC82L(E)54	9
3.6	MPC82G516	10
3.7	MG84FL54BD & MG84FL54RBD	11
4	MCU's Hardware Option	12
4.1	For MPC89L516/556X2	12
4.2	For MPC89L(E)51/52/53/54/58/515	13
4.3	For MPC82L(E)52/54	14
4.4	For MPC82G516	15
4.5	For MG84FL54BD & MG84FL54RBD	16
5	Easily Use the Writer	17
5.1	The "Auto" button	18
5.2	To program the AP-memory & IAP-memory	19
5.3	To program the ISP-memory	20
5.4	To program the AP-memory & IAP-memory & ISP-memory	21
5.5	To program the hardware option	22
5.5.1	Only the hardware option is programmed	22
5.5.2	The hardware option is programmed along with the Flash memory	23
5.6	To dump the Target's Flash data	24
5.7	To get the checksum of the Target's Flash data	25
5.8	To disable the hardware option: SB & LOCK	26
5.9	To insert the ISP-code	27
6	Megawin Project File (MPJ File)	30
	Revision History	32

1 Introduction

The “Megawin 8051 Writer” is a proprietary programmer designed for all Megawin’s 8051 MCU products. It functions as a bus-powered USB device and thus doesn’t need any extra power supply. And, the compact hardware and the friendly software help users easily use this Writer. In addition, its low cost prevents users from suffering an expensive universal Programmer.

Picture of the “Megawin 8051 Writer”



2 Install the PC-site AP and Driver for the Writer

2.1 Install the Driver

Plug the Writer into the PC's USB port, and do as follows when the monitor shows a prompt about new hardware found.

- 1) Select **No, not this time**, click **Next**.
- 2) Select **Install from a list or specific location**, click **Next**.
- 3) Select **Search for the best driver in these locations** and **Include this location in the search**, click **Browse**.
- 4) Locate the driver folder [(2) [PC-site Driver](#)], click **OK**.
- 5) Click **Next**. The driver installation starts.
- 6) Click **Finish** when the installation completes.

To check if the Programmer was correctly installed, follow the listed steps:

- 1) Open the **My Computer** folder.
- 2) Open the **Control Panel** folder.
- 3) Open the **System**.
- 4) Click on the **Hardware** tab at the top of the dialog box, then click on the **Device Manager**.
- 5) Click on the plus sign in front of the **Universal Serial Bus Controllers** to check the device listing.

If the installation was completed successfully, you may find an entry, **Megawin 8051 Writer**, in the listing.

2.2 Install the AP

Run "**Setup.exe**" (in the [(1) [PC-site AP](#)] folder) to install the application program for the Writer on your PC. Using its default installing setting, you will find the item "**Megawin Utilities \ Megawin 8051 Writer (v...)**" appearing in the Windows' START-menu.

(Note: the v?..?? means the current version and may be upgraded in the future.)

3 MCU's Flash Memory Configuration


Before using the "Megawin 8051 Writer", it is necessary for the user to know the configuration of the MCU's Flash memory.

3.1 MPC89L516/556X2

Figure 3.1 shows the configuration of the Flash memory of MPC89L516/556X2. The total memory size is 64K bytes, and the ISP-memory is user-configured by using this Writer.

For MPC89L516/556X2, there is no dedicated IAP-memory. The AP-memory and IAP-memory are mixed together and share the same Flash area excluding the ISP-memory.

Figure 3.1: MPC89L516/556X2 Flash Memory Configuration



!!! Note: For MPC89L516/556X2, the AP-memory and IAP-memory are mixed together in the same Flash area.

3.2 MPC89L(E)51/52/53


Figure 3.2 shows the configuration of the Flash memory of MPC89L(E)51/52/53. The total memory size is 15K bytes, and the ISP-memory is user-configured by using this Writer.

For MPC89L(E)51/52, there is an IAP-memory if the ISP-memory has been configured at least 1K bytes.

For MPC89L(E)53, there is always no IAP-memory.

Table 3.2 shows the relation between IAP-memory and ISP-memory.

Figure 3.2: MPC89L(E)51/52/53 Flash Memory Configuration



!!! Note: MPC89L(E)53 has no IAP-memory.

Table 3.2: IAP-memory Range and Size for MPC89L(E)51/52

Part No.	IAP-memory Range (Size)			
	ISP_size =0KB	ISP_size =1KB	ISP_size =2KB	ISP_size=4KB
MPC89L(E)51	(NA)	0x1000~0x37FF (10KB)	0x1000~0x33FF (9KB)	0x1000~0x2BFF (7KB)
MPC89L(E)52	(NA)	0x2000~0x37FF (6KB)	0x2000~0x33FF (5KB)	0x2000~0x2BFF (3KB)

3.3 MPC89L(E)54/58/515


Figure 3.3 shows the configuration of the Flash memory of MPC89L(E)54/58/515. The total memory size is 63K bytes, and the ISP-memory is user-configured by using this Writer.

For MPC89L(E)54/58, there is an IAP-memory if the ISP-memory has been configured at least 1K bytes.

For MPC89L(E)515, there is always no IAP-memory.

Table 3.3 shows the relation between IAP-memory and ISP-memory.

Figure 3.3: MPC89L(E)54/58/515 Flash Memory Configuration



!!! Note: MPC89L(E)515 has no IAP-memory.


Table 3.3: IAP-memory Range and Size for MPC89L(E)54/58

Part No.	IAP-memory Range (Size)			
	ISP_size =0KB	ISP_size =1KB	ISP_size =2KB	ISP_size=4KB
MPC89L(E)54	(NA)	0x4000~0xF7FF (46KB)	0x4000~0xF3FF (45KB)	0x4000~0xEBFF (43KB)
MPC89L(E)58	(NA)	0x8000~0xF7FF (30KB)	0x8000~0xF3FF (29KB)	0x8000~0xEBFF (27KB)

3.4 MPC82L(E)52

Figure 3.4 shows the configuration of the Flash memory of MPC82L(E)52. The total memory size is 8K bytes, and the IAP-memory & ISP-memory are user-configured by using this Writer.

Figure 3.4: MPC82L(E)52 Flash Memory Configuration



The IAP-memory lower boundary is determined by the MCU's hardware option *IAPLB*. Two examples show how to configure the *IAPLB*:

Example-1:

4K bytes of IAP-memory is wanted while no ISP-memory is configured.

→ *IAPLB* should be programmed to *0x10*, so the IAP-memory range will be *0x1000~0x1FFF* (total 4K bytes).

Example-2:

4K bytes of IAP-memory is wanted while 1K bytes of ISP-memory has been configured at *0x1C00~0x1FFF*.

→ *IAPLB* should be programmed to *0x0C*, so the IAP-memory range will be *0x0C00~0x1BFF* (total 4K bytes).

The user can find that the range of IAP-memory range is:

Lower boundary = $IAPLB \times 256$, and


Upper boundary = $ISP_start_address - 1$.

Where, **IAPLB** should be an *even number*.

3.5 MPC82L(E)54

Figure 3.5 shows the configuration of the Flash memory of MPC82L(E)54. The total memory size is 15.5K bytes, and the IAP-memory & ISP-memory are user-configured by using this Writer.

Figure 3.5: MPC82L(E)54 Flash Memory Configuration



The IAP-memory lower boundary is determined by the MCU's hardware option *IAPLB*. Two examples show how to configure the *IAPLB*:

Example-1:

4K bytes of IAP-memory is wanted while no ISP-memory is configured.

→ *IAPLB* should be programmed to 0x2E, so the IAP-memory range will be 0x2E00~0x3DFF (total 4K bytes).

Example-2:

4K bytes of IAP-memory is wanted while 1.5K bytes of ISP-memory has been configured at 0x3800~0x3DFF.

→ *IAPLB* should be programmed to 0x28, so the IAP-memory range will be 0x2800~0x37FF (total 4K bytes).

The user can find that the range of IAP-memory range is:

Lower boundary = **IAPLB**×256, and


Upper boundary = **ISP_start_address** – 1.

Where, **IAPLB** should be an *even number*.

3.6 MPC82G516

Figure 3.6 shows the configuration of the Flash memory of MPC82G516. The total memory size is 64K bytes, and the IAP-memory & ISP-memory are user-configured by using this Writer.

Figure 3.6: MPC82G516 Flash Memory Configuration



The IAP-memory lower boundary is determined by the MCU's hardware option *IAPLB*. Two examples show how to configure the *IAPLB*:

Example-1:

4K bytes of IAP-memory is wanted while no ISP-memory is configured.

➔ *IAPLB* should be programmed to *0xF0*, so the IAP-memory range will be *0xF000~0xFFFF* (total 4K bytes).

Example-2:

4K bytes of IAP-memory is wanted while 1K bytes of ISP-memory has been configured at *0xFC00~0xFFFF*.

➔ *IAPLB* should be programmed to *0xEC*, so the IAP-memory range will be *0xEC00~0xFBFF* (total 4K bytes).

The user can find that the range of IAP-memory range is:

Lower boundary = **IAPLB**×256, and


Upper boundary = **ISP_start_address** – 1.

Where, **IAPLB** should be an *even number*.

3.7 MG84FL54BD & MG84FL54RBD

Figure 3.7 shows the configuration of the Flash memory of MG84FL54BD & MG84FL54RBD. The total memory size is 16K bytes, and the IAP-memory & ISP-memory are user-configured by using this Writer.

Figure 3.7: MG84FL54BD & MG84FL54RBD Flash Memory Configuration



The IAP-memory lower boundary is determined by the MCU's hardware option *IAPLB*. Two examples show how to configure the *IAPLB*:

Example-1:

1K bytes of IAP-memory is wanted while no ISP-memory is configured.

→ *IAPLB* should be programmed to 0x3C, so the IAP-memory range will be 0x3C00~0x3FFF (total 1K bytes).

Example-2:

1K bytes of IAP-memory is wanted while 2K bytes of ISP-memory has been configured at 0x3800~0x3FFF.

→ *IAPLB* should be programmed to 0x34, so the IAP-memory range will be 0x3400~0x37FF (total 2K bytes).

The user can find that the range of IAP-memory range is:

Lower boundary = $IAPLB \times 256$, and

Upper boundary = $ISP_start_address - 1$.

Where, **IAPLB** should be an *even number*.

4 MCU's Hardware Option

4.1 For MPC89L516/556X2

PIN_EN:

[enabled]: When powered up or RST-pin reset, MCU will boot from ISP-memory if ISP-memory is configured and P1.1 & P1.0 are tied to ground.

[disabled]: MCU always boots from AP-memory.

MOVCL:

[enabled]: "MOVC-instruction" is invalid for security while MCU is executing from external program.

[disabled]: "MOVC-instruction" is always available.

SB:

[enabled]: Code dumped on a universal Writer or Programmer is scrambled for security.

[disabled]: Not scrambled.

LOCK:

[enabled]: Code dumped & Device ID read on a universal Writer or Programmer is locked to be 0xFF for security.

[disabled]: Not locked.

EN6T:

[enabled]: MCU runs at 6T mode (6 clocks per machine-cycle, double speed compared to a traditional 8051)

[disabled]: MCU runs at 12T mode (12 clocks per machine-cycle, like a traditional 8051)

4.2 For MPC89L(E)51/52/53/54/58/515

MOVCL:

[enabled]: "MOVC-instruction" is invalid for security while MCU is executing from external program.
[disabled]: "MOVC-instruction" is always available.

SB:

[enabled]: Code dumped on a universal Writer or Programmer is scrambled for security.
[disabled]: Not scrambled.

LOCK:

[enabled]: Code dumped & Device ID read on a universal Writer or Programmer is locked to 0xFF for security.
[disabled]: Not locked.

FZWDTCR:

[enabled]: The WDTCR register will be initialized to its reset value (0x00) *only by power-on reset.*
(*For example, if WDTCR=0x2D, it still keeps at 0x2D rather than 0x00 after RST-pin, S/W or WDT reset.*)
[disabled]: The WDTCR register will be initialized to its reset value (0x00) by all reset (including power-on, RST-pin, S/W and WDT reset).

OSCDN:

[enabled]: Oscillating gain is reduced down for EMI reduction if Fosc < 25MHz.
[disabled]: Normal gain. (For Fosc > 25MHz)

HWBS:

[enabled]: When powered up, MCU will boot from ISP-memory if ISP-memory is configured.
[disabled]: MCU always boots from AP-memory.

EN6T:

[enabled]: MCU runs at 6T mode (6 clocks per machine-cycle, double speed compared to a traditional 8051)
[disabled]: MCU runs at 12T mode (12 clocks per machine-cycle, like a traditional 8051)

4.3 For MPC82L(E)52/54

LVFWP:

[enabled]: Enable LVFWP (Low-Voltage Flash Write Protection) while IAP or ISP programming.
 [disabled]: Disable LVFWP.

ENLVR:

[enabled]: Enable LVR (Low-Voltage Reset).
 [disabled]: Disable LVR.

HWBS:

[enabled]: When power-on, MCU will boot from ISP-memory if ISP-memory is configured.
 [disabled]: MCU always boots from AP-memory.

SB:

[enabled]: Code dumped on a universal Writer or Programmer is scrambled for security.
 [disabled]: Not scrambled.

LOCK:

[enabled]: Code dumped & Device ID read on a universal Writer or Programmer is locked to 0xFF for security.
 [disabled]: Not locked.

OSCDN:

[enabled]: Oscillating gain is reduced down for EMI reduction.
 [disabled]: Normal gain.

HWBS2: *(only for MPC82L/E54)*

[enabled]: Like HWBS, the reset from RST-pin can also cause MCU to boot from ISP-memory.
 [disabled]: Where MCU boots from is determined by **HWBS**.

ENROSC:

[enabled]: Enable built-in RC oscillator.
 [disabled]: Disable built-in RC oscillator.

HWENW (accompanied with arguments **HWWIDL** and **HWPS[2:0]**):

[enabled]: Automatically enable Watch-dog Timer by the hardware when the MCU is powered up.

It means that:

In the WDTCSR register, the hardware will automatically:

- (1) set **ENW** bit,
- (2) load **HWWIDL** into **WIDL** bit, and
- (3) load **HWPS[2:0]** into **PS[2:0]** bits.

For example:

If **HWWIDL** and **HWPS[2:0]** are programmed to be 1 and 5, respectively, then **WDTCSR** will be initialized to be 0x2D when MCU is powered up, as shown below.

WDTCSR (Watch-Dog-Timer Control Register)

7	6	5	4	3	2	1	0
WRF	-	ENW	CLRWD	WIDL	PS2	PS1	PS0
		↑ set 1		↑ load HWWIDL		↑ load HWPS[2:0]	

[disabled]: No action on Watch-dog Timer when the MCU is powered up.

4.4 For MPC82G516

LVFWP:

[enabled]: Enable LVFWP (Low-Voltage Flash Write Protection) while IAP or ISP programming.
 [disabled]: Disable LVFWP.

ENLVRC:

[enabled]: Enable PMU unit to generate low voltage reset when V30-pin voltage drops below 2.4V.
 [disabled]: Disable LVRC.

HWBS:

[enabled]: When power-on, MCU will boot from ISP-memory if ISP-memory is configured.
 [disabled]: MCU always boots from AP-memory.

SB:

[enabled]: Code dumped on a universal Writer or Programmer is scrambled for security.
 [disabled]: Not scrambled.

LOCK:

[enabled]: Code dumped & Device ID read on a universal Writer or Programmer is locked to 0xFF for security.
 [disabled]: Not locked.

OSCDN:

[enabled]: Oscillating gain is reduced down for EMI reduction.
 [disabled]: Normal gain.

HWBS2:

[enabled]: Like HWBS, the reset from RST-pin can also cause MCU to boot from ISP-memory.
 [disabled]: Where MCU boots from is determined by **HWBS**.

ENLVRO:

[enabled]: Enable MCU to generate low voltage reset when VDD-pin voltage drops below 3.7V.
 [disabled]: No low voltage reset.

ENROSC:

[enabled]: Enable built-in RC oscillator.
 [disabled]: Disable built-in RC oscillator.

WDSFWP:

[enabled]: The special function register WDTCSR will be software-write-protected except the bit CLRW.
 [disabled]: The special function register WDTCSR is free to be written by software.

HWENW (accompanied with arguments **HWWIDL** and **HWPS[2:0]**):

[enabled]: Automatically enable Watch-dog Timer by the hardware when the MCU is powered up.

It means that:

In the WDTCSR register, the hardware will automatically:

- (1) set **ENW** bit,
- (2) load **HWWIDL** into **WIDL** bit, and
- (3) load **HWPS[2:0]** into **PS[2:0]** bits.

For example:

If **HWWIDL** and **HWPS[2:0]** are programmed to be 1 and 5, respectively, then **WDTCSR** will be initialized to be 0x2D when MCU is powered up, as shown below.

WDTCSR (Watch-Dog-Timer Control Register)

7	6	5	4	3	2	1	0
WRF	-	ENW	CLRW	WIDL	PS2	PS1	PS0
		↑ set 1		↑ load HWWIDL		↑ load HWPS[2:0]	

[disabled]: No action on Watch-dog Timer when the MCU is powered up.

4.5 For MG84FL54BD & MG84FL54RBD

HWBS:

[enabled]: When power-on, MCU will boot from ISP-memory if ISP-memory is configured.
 [disabled]: MCU always boots from AP-memory.

SB:

[enabled]: Code dumped on a universal Writer or Programmer is scrambled for security.
 [disabled]: Not scrambled.

LOCK:

[enabled]: Code dumped & Device ID read on a universal Writer or Programmer is locked to 0xFF for security.
 [disabled]: Not locked.

HWBS2:

[enabled]: Like HWBS, the reset from RST-pin can also cause MCU to boot from ISP-memory.
 [disabled]: Where MCU boots from is determined by **HWBS**.

WDTCR_WP:

[enabled]: If MCU runs in the AP-memory, the special function register WDTCR will be software-write-protected except the bit CLRW; And, if MCU runs in the ISP-memory, it will be software-write-protected except the bits CLRW, PS2, PS1 and PS0.
 [disabled]: The special function register WDTCR is free to be written by software.

HWENW (accompanied with arguments HWWIDL and HWPS[2:0]):

[enabled]: Automatically enable Watch-dog Timer by the hardware when the MCU is powered up.

It means that:

In the WDTCR register, the hardware will automatically:

- (1) set **ENW** bit,
- (2) load **HWWIDL** into **WIDL** bit, and
- (3) load **HWPS[2:0]** into **PS[2:0]** bits.

For example:

If **HWWIDL** and **HWPS[2:0]** are programmed to be 1 and 5, respectively, then **WDTCR** will be initialized to be 0x2D when MCU is powered up, as shown below.


WDTCR (Watch-Dog-Timer Control Register)

7	6	5	4	3	2	1	0
WRF	-	ENW	CLRW	WIDL	PS2	PS1	PS0
		↑ set 1		↑ load HWWIDL		↑ load HWPS[2:0]	

[disabled]: No action on Watch-dog Timer when the MCU is powered up.

5 Easily Use the Writer

The following figure shows the GUI (Graphic User Interface) of the PC-site application program. Based on the GUI, the following sub-sections will demonstrate how to easily use this Writer.




5.1 The “Auto” button

To facilitate the manual operation, an automatic button, “Auto”, on the GUI is designed. This button comprises:

- (1) Whole-chip Erase,
- (2) Check ID,
- (3) Program Option,
- (4) Erase,
- (5) Blank Check,
- (6) Program, and
- (7) Verify.

You can select any operation items you want, and then click “Run” to start the batch processing.



5.2 To program the AP-memory & IAP-memory

Step1: Select part no.

Step2: Select programming area: "AP-memory + IAP-memory".


Step3: Click "Read Option" to check the current ISP-memory size for Step4.

Step4: Load file with size not more than: (total memory size) – (ISP-memory size).

Step5: Click "Auto", configure the wanted batch processing.

Step6: Click "Run" to start the batch processing.

(Note: Step3 is optional.)



The screenshot shows the Megawin 8051 Writer (v3.70) interface. Red arrows and labels indicate the following steps:

- Step1:** Select Part Number: MPC89E52.
- Step2:** Select Programming Area: AP-memory + IAP-memory.
- Step3:** Click "Read Option" under H/W Option.
- Step4:** Load File (button).
- Step5:** Click "Auto" button.
- Step6:** Click "Run" button in the Auto dialog.

The "Auto" dialog box shows the following configuration:

- ☐ Whole-chip Erase
- ☒ Check ID
- ☐ Program Option
- ☒ Erase
- ☒ Blank Check
- ☒ Program
- ☒ Verify

5.3 To program the ISP-memory

Step1: Select part no.


Step2: Select programming area: "ISP-memory".

Step3: Load the ISP code with size not more than ISP-memory size.

Step4: Click "Auto", configure the wanted batch processing.

Step5: Click "Run" to start the batch processing.

Note: If the ISP-memory is not configure, refer to Section 5.5 for how to configure an ISP-memory.



The screenshot shows the Megawin 8051 Writer (v3.70) interface. Red arrows and labels indicate the following steps:

- Step1:** Points to the "Part Number" dropdown menu, which is set to "MPC89E52".
- Step2:** Points to the "Programming Area" section, where "ISP-memory" is selected.
- Step3:** Points to the "Load File" button on the left sidebar.
- Step4:** Points to the "Auto" button on the right sidebar.

The main window displays a "Binary Code Buffer" with a table of hexadecimal and binary data. Below this, there are sections for "H/W Option" (ISP-memory, IAP-memory), "Whole-chip Erase", "Program Option", and "Read Option". A "Message" box at the bottom right shows "Load file ... => OK".

An inset window titled "Auto" is shown at the bottom right, with a red arrow pointing to it from the "Auto" button in the main window. This window contains the following options:

- ☐ Whole-chip Erase
- ☒ Check ID
- ☐ Program Option
- ☒ Erase
- ☒ Blank Check
- ☒ Program
- ☒ Verify

At the bottom of the "Auto" window, there are "Run" and "Exit" buttons. A red arrow points to the "Run" button, labeled "Step5".

5.4 To program the AP-memory & IAP-memory & ISP-memory


Step1: Select part no.

Step2: Select programming area: "AP + IAP + ISP".

Step3: Load file with size not more total memory size.

Step4: Click "Auto", configure the wanted batch processing.

Step5: Click "Run" to start the batch processing.



The screenshot shows the Megawin 8051 Writer (v3.70) interface. Red arrows and labels indicate the steps for programming:

- Step1:** Points to the "Part Number" dropdown menu, which is set to "MPC89E515".
- Step2:** Points to the "Programming Area" section, where the radio button for "AP + IAP + ISP" is selected.
- Step3:** Points to the "Load File" button in the left sidebar.
- Step4:** Points to the "Auto" button in the right sidebar.
- Step5:** Points to the "Run" button in the "Auto" dialog box.

The "Auto" dialog box is shown in the bottom right, with the following options checked:

- ☒ Check ID
- ☒ Erase
- ☒ Blank Check
- ☒ Program
- ☒ Verify

The "Whole-chip Erase" option is unchecked. The "Run" button is highlighted.

5.5 To program the hardware option

5.5.1 Only the hardware option is programmed

The hardware option includes ISP-memory/IAP-memory (cf. Section 3) and miscellaneous hardware control (cf. Section 4). The following steps show how to program the hardware option.


Step1: Select part no.

Step2: Configure the hardware option.

Step3: Click "Program Option".


Step4: Click "Read Option" to read back for checking.

(Note: Step4 is optional.)




5.5.2 The hardware option is programmed along with the Flash memory

Sections 5.2~5.4 show that only the Flash memory is programmed while the hardware option is left unchanged. In fact, the user can program the hardware option along with the Flash memory. The user just needs to configure the hardware option and add "Program Option" into the Auto batch processing, as shown below. After batch processing, not only the Flash memory but also the hardware option are programmed.



Note that if the "Program Option" is added into the Auto batch processing and the H/W Option setting is left blank, as shown below, all the hardware options will be disabled after the batch processing.



5.6 To dump the Target's Flash data


If the target chip is not locked or scrambled, then its whole Flash data can be dumped. The dumped data are stored in the binary code buffer, and the user can save it in the local disk

Step1: Select part no.

Step2: Click "Dump Target".

Step3: Click "Save Buffer" to save the dumped data to the local disk.

(Note: The current hardware option is also dumped and displayed in the H/W Option area.)




5.7 To get the checksum of the Target's Flash data

If a chip is not locked or scrambled, then you can get the checksum of its whole Flash data.

Step1: Select part no.

Step2: Click "Get Checksum".



5.8 To disable the hardware option: SB & LOCK

For a **locked** chip (i.e., LOCK option is enabled), all read-out data including the device ID will become 0xFF. So, the user always get the following error message even if you have selected the correct part no.



For a **scrambled** chip (i.e., SB option is enabled), all read-out data are scrambled to become random data except that its device ID is left unchanged.


In both these conditions, only whole-chip-erase can make LOCK & SB become disabled.

Step1: Select Part No.

Step2: Click "Whole-chip Erase".

Step3: Check if un-lock successfully by clicking "Check ID".

(Note: Step3 is optional.)



5.9 To insert the ISP-code

Normally the MCU chips shipped from Megawin already have the following configuration:

For all parts except MG84-series,


- (1) ISP-memory with 1K bytes is configured,
- (2) Megawin-provided ISP code is programmed, and
- (3) the H/W options HWBS, SB and LOCK are enabled.

For MG84-series,

- (1) ISP-memory with 2K bytes is configured,
- (2) Megawin-provided ISP code is programmed, and
- (3) the H/W options HWBS, HWBS2, SB and LOCK are enabled.

However, for developing purpose, the user may apply the whole-chip erasing to the chip, and therefore the ISP function is cancelled. To activate the ISP function again after the developing is finished, the user just needs to click the button **"Insert ISP-code"**. Two kinds of ISP code can be inserted. One is the *Megawin-provided ISP code*, which is the same as that programmed when shipping; And the other one is the *User-defined ISP code*, which is developed by the user himself for special purpose.

Click **"Insert ISP-code"** to insert the ISP code




When an application code **was** loaded before inserting the ISP-code

As shown below, the GUI setting after inserting the ISP-code will automatically become:

- (1) Programming Area: *AP+IAP+ISP* is selected,
- (2) ISP-memory: a proper size for the ISP-code is selected, and
- (3) H/W option: *HWBS* is enabled. (Or, *HWBS* & *HWBS2* are enabled for MG84-series.)

In addition to the options related to ISP operation, the user may configure the other H/W options at this time.




When an application code **was not** loaded before inserting the ISP-code

As shown below, the GUI setting after inserting the ISP-code will automatically become:

- (1) Programming Area: *ISP-memory* is selected,
- (2) ISP-memory: a proper size for the ISP-code is selected, and
- (3) H/W option: *HWBS* is enabled. (Or, *HWBS* & *HWBS2* are enabled for MG84-series.)

In addition to the options related to ISP operation, now the user may configure the other H/W options. Of course, the user may load the application code at this time, and therefore the Programming Area will be automatically changed to *AP+IAP+ISP*.



6 Megawin Project File (MPJ File)

The user can save all the relevant programming information together in a Megawin project file (MPJ file). The MPJ file includes the following relevant programming information appearing on the GUI:


- (1) Part Number,
- (2) Programming Area,
- (3) H/W Option,
- (4) Binary Code Buffer, and
- (5) The configuration of the Auto button.

Note:

The MPJ file is also used for **Customer Programming Request Service** provided by Megawin. For this service, the user needs to send this MPJ file to Megawin.

Save to an MPJ File


To save all the relevant programming information to an MPJ file, click the button “**Save *.MPJ**”, as shown below. Of course, before clicking this button, you should have finished the proper configuration: the Part Number, the Programming Area and the H/W Option. And, the application code should be loaded.



Load an MPJ File

To restore all the relevant programming information to the GUI, click the button “**Load File**”, as shown below, and select the file type *Megawin Project Files (*.MPJ)*. Now, all the files with extension *MPJ* will be listed. Select the MPJ file you want. Now, you can click the **Auto** button to program a new chip.

Load an
MPJ file
Select
File Type: *.MPJ



Revision History

Revision	Description	Date
v3.40	(1) Change the Writer's MCU from MPC89L516 to MPC89L515. (2) Add automatically upgrading the firmware of the Writer's MCU.	2007/06/28
v3.50	(1) Fix the AP bug: if load a HEX file by "ALL Files (*.*)", the HEX file will be wrongly regarded as a binary file. (2) Update the Writer MCU's F/W version to v0206. (3) Update the driver to "0E6A0304_8051Writer_v3.00.inf" for Vista OS. (4) Add Megawin Project File (MPJ File).	2007/07/17
v3.60	(Not released)	2007/08/01
v3.70	Add "Insert ISP-code" function.	2007/10/05
v3.80	Modify description for HWENW. (Section 4.3 & 4.4)	2007/11/15
	Correct description for ENLVRO, from 3.8V to 3.7V. (Section 4.4)	2007/12/06
	Add new parts: MG84FL54BD & MG84FL54RBD	2008/01/09