


Table of Contents


Instrument Set-up	2
Introduction	2
Overview	2
Display	3
Insert batteries	3
Operations	4
Switching ON/OFF	4
Clear	4
Message Codes	4
Beep ON/OFF	4
Illumination ON/OFF	4
Distance unit setting	4
Adjusting measuring reference / tripod	5
Multifunctional endpiece	5
Measuring Functions	6
Measuring single distance	6
Permanent / Minimum-Maximum measuring	6
Add / Subtract	6
Area	7
Volume	8
Pythagoras (2-point)	9
Pythagoras (3-point)	9
Stake out	10
Memory (10 last displays)	11
Delete Memory	11
Technical Data	12
Message Codes	13
Care	13

Safety Instructions	13
Areas of responsibility	13
Permitted use	14
Prohibited use	14
Hazards in use	14
Limits of use	14
Disposal	14
Electromagnetic Compatibility (EMC)	14
FCC statement (applicable in U.S.)	15
Laser classification	15
Labelling	15

Instrument Set-up

Introduction

 The safety instructions and the user manual should be read through carefully before the product is used for the first time.

 The person responsible for the product must ensure that all users understand these directions and adhere to them.


The symbols used have the following meanings:

 **WARNING**


Indicates a potentially hazardous situation or an unintended use which, if not avoided, will result in death or serious injury.

 **CAUTION**

Indicates a potentially hazardous situation or an unintended use which, if not avoided, may result in minor injury and/or appreciable material, financial and environmental damage.


 Important paragraphs which must be adhered to in practice as they enable the product to be used in a technically correct and efficient manner.

Overview




Instrument Set-up


Display



Insert batteries




i To ensure a reliable use, do not use zinc-carbon batteries. Change batteries when battery symbol is flashing.



Operations

Switching ON/OFF




2 sec

Device is turned OFF.


i

Press ON button 2 sec to start continuous laser mode. If no key is pressed for 180 sec, the device switches off automatically.

Clear



Undo last action.



Leave actual function, go to default operation mode.

Message Codes


If the info icon appears with a number, observe the instructions in section "Message Codes".
Example:



Beep ON/OFF




2 sec simultaneously



Illumination ON/OFF



2 sec simultaneously



Distance unit setting





2 sec

Switch between the following units:


0.000 m	0.00 ft
0.0000 m	0'00" 1/32
0.00 m	0.00 in
	0 in 1/32

Operations

Adjusting measuring reference / tripod




Multifunctional endpiece



i The orientation of the endpiece is automatically detected and the zero point is accordingly adjusted.

Measuring Functions


Measuring single distance




i

Target surfaces: Measuring errors can occur when measuring to colourless liquids, glass, styrofoam or semi-permeable surfaces or when aiming at high gloss surfaces. Against dark surfaces the measuring time increases.

Permanent / Minimum-Maximum measuring




Add / Subtract




i

Measuring Functions

Area






i The result is shown in the main line and the measured value above.






Measuring Functions



Volume


1  



2  Aim laser at first target point.



3  

4  Aim laser at second target point.




5  

6  Aim laser at third target point.

7  

8  **2 sec** 

i The result is shown in the main line and the measured value above.

-  80.208 m — Circumference
-  208.703 m² — Ceiling/floor area
-  78.694 m³ — Volume

Measuring Functions

Pythagoras (2-point)

1 2 Aim laser at upper point.

3 4 Aim laser rectangular at lower point.

5 8.294 m

i Notice additional Pythagoras measurement information at the bottom of the next page.

Pythagoras (3-point)

1 2 Aim laser at upper point.

3 4 Aim laser at rectangular point.

5 6 Aim laser at lower point.


7 8.294 m

i Notice additional Pythagoras measurement information at the bottom of the next page.

i **Pythagoras measurements:**

- Pressing the measuring key for 2 sec in the function activates automatically Minimum or Maximum measurement.
- For accurate indirect results, the use of a tripod is recommended.

Stake out




3x



2




3



Adjust value




Approve value and start measurement.



4

Move device slowly along the stake-out line. The distance to the next stake out point is displayed.





0.240 m is missing up to next 0.625 m distance.

i


When approaching a stake out point to less than 0.1 m the instrument starts to beep. The function can be stopped by pressing the CLEAR/OFF button.

Measuring Functions

Memory (10 last displays)



Delete Memory



Distance measurement	
Typical Measuring Tolerance*	$\pm 1.5 \text{ mm} / 0.06 \text{ in}$ ***
Maximum Measuring Tolerance**	$\pm 2.5 \text{ mm} / 0.10 \text{ in}$ ***
Range of target plate	60 m / 197 ft
Typical Range*	60 m / 197 ft
Range at unfavourable condition ****	50 m / 164 ft
Smallest unit displayed	0.1 mm / 1/32 in
Ø laser point at distances	6 / 30 / 40 mm (10 / 50 / 60 m)
General	
Laser class	2
Laser type	635 nm, < 1 mW
Protection class	IP54 (dust- and splash water protected)
Autom. laser switch off	after 90 s
Autom. power switch-off	after 180 s
Battery durability (2 x AAA)	up to 5000 measurements
Dimension (H x D x W)	117 x 57 x 32 mm 4.6 x 2.4 x 1.3 in
Weight (with batteries)	0.14 kg / 4.938 oz
Temperature range:	
- Storage	-25 to 70 °C -13 to 158 °F
- Operation	-10 to 50 °C 14 to 122 °F

* applies for 100 % target reflectivity (white painted wall), low background illumination, 25 °C

** applies for 10 to 500 % target reflectivity, high background illumination, - 10 °C to + 50 °C

*** Tolerances apply from 0.05 m to 10 m with a confidence level of 95%. The maximum tolerance may deteriorate to 0.1 mm/m between 10 m to 30 m and to 0.2 mm/m for distances above 30 m

**** applies for 100 % target reflectivity, background illumination of approximately 30'000 lux

Functions	
Distance measuring	yes
Min/Max measuring	yes
Permanent measuring	yes
Stake-out	yes
Addition/Subtraction	yes
Area	yes
Volume	yes
Pythagoras	2-point, 3-point
Memory	10 displays
Beep	yes
Illuminated display	yes
Multifunctional endpiece	yes

Message Codes

If the message **Error** does not disappear after switching on the device repeatedly, contact the dealer.

If the message **InFo** appears with a number, press the Clear button and observe the following instructions:

No.	Cause	Correction
204	Calculation error	Perform measurement again.
252	Temperature too high	Let device cool down.
253	Temperature too low	Warm device up.
255	Received signal too weak, measuring time too long	Change target surface (e.g. white paper).
256	Received signal too high	Change target surface (e.g. white paper).
257	Too much background light	Shadow target area.
258	Measurement outside of measuring range	Correct range.
260	Laser beam interrupted	Repeat measurement.

Care

- Clean the device with a damp, soft cloth.
- Never immerse the device in water.
- Never use aggressive cleaning agents or solvents.

Safety Instructions

The person responsible for the instrument must ensure that all users understand these directions and adhere to them.

Areas of responsibility

Responsibilities of the manufacturer of the original equipment:

Techtronic Industries GmbH
Max-Eyth-Strasse 10,
71364 Winnenden, Germany

The company above is responsible for supplying the product, including the User Manual in a completely safe condition. The company above is not responsible for third party accessories.

Responsibilities of the person in charge of the instrument:

- To understand the safety instructions on the product and the instructions in the User Manual.
- To be familiar with local safety regulations relating to accident prevention.
- Always prevent access to the product by unauthorised personnel.

Safety Instructions

Permitted use

- Measuring distances
- Tilt measurement

Prohibited use

- Using the product without instruction
- Using outside the stated limits
- Deactivation of safety systems and removal of explanatory and hazard labels
- Opening of the equipment by using tools (screwdrivers, etc.)
- Carrying out modification or conversion of the product
- Use of accessories from other manufacturers without express approval
- Deliberate dazzling of third parties; also in the dark
- Inadequate safeguards at the surveying site (e.g. when measuring on roads, construction sites, etc.)
- Deliberate or irresponsible behaviour on scaffolding, when using ladders, when measuring near machines which are running or near parts of machines or installations which are unprotected
- Aiming directly in the sun

Hazards in use

WARNING

Watch out for erroneous measurements if the instrument is defective or if it has been dropped or has been misused or modified. Carry out periodic test measurements. Particularly after the instrument has been subject to abnormal use, and before, during and after important measurements.



CAUTION

Never attempt to repair the product yourself. In case of damage, contact a local dealer.

WARNING

Changes or modifications not expressly approved could void the user's authority to operate the equipment.

Limits of use

-  Refer to section "Technical data".
-  The device is designed for use in areas permanently habitable by humans. Do not use the product in explosion hazardous areas or in aggressive environments.

Disposal

CAUTION

Flat batteries must not be disposed of with household waste. Care for the environment and take them to the collection points provided in accordance with national or local regulations.

The product must not be disposed with household waste.

Dispose of the product appropriately in accordance with the national regulations in force in your country.



Adhere to the national and country specific regulations.

Product specific treatment and waste management can be downloaded from our homepage.

Electromagnetic Compatibility (EMC)

WARNING

The device conforms to the most stringent requirements of the relevant standards and regulations.

Yet, the possibility of causing interference in other devices cannot be totally excluded.

Safety Instructions


FCC statement (applicable in U.S.)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Laser classification



The device produces visible laser beams, which are emitted from the instrument: It is a Class 2 laser product in accordance with:

- IEC60825-1 : 2007 „Radiation safety of laser products“

Laser Class 2 products:

Do not stare into the laser beam or direct it towards other people unnecessarily. Eye protection is normally afforded by aversion responses including the blink reflex.

⚠ WARNING

Looking directly into the beam with optical aids (e.g. binoculars, telescopes) can be hazardous.

⚠ CAUTION

Looking into the laser beam may be hazardous to the eyes.

Labelling

Milwaukee

LASER RADIATION. DO NOT STARE INTO BEAM. CLASS 2 LASER PRODUCT.

3 V = / 0,3 A
Code: 4000 4461 11
max. Power < 1 mW Wave length 620-690nm
Complies with 21 CFR 1040.10 and 1040.11

CE

LDM 60
Laser Distance Meter
Made in Hungary

Technronic Industries GmbH
Max-Eyth-Straße 10 - 71364 Winnenden Germany

Cover the English text on the rating plate with the included sticker in your national language prior to first operation.

LDM 60 4000 4461 11
Ser. No.: XXXXX M JJJJ

Art.No.:XXXXXX P/N:23456789

Subject to change (drawings, descriptions and technical data) without prior notice.