

Welcome to use Our Injection Molding Machine Control System

Safety Cautions

(Please read it before installation)



I. Danger

1. In order to ensure the secure operation of the whole system in case of the abnormal external power and the control system's failing to function, please set up the external safe circuit for the control system.
2. Upon its failure to detect the abnormal conditions of input and output, the control system cannot control the output. Therefore, please design the external circuit and framework to ensure the safe operation of the system.



Cautions

1. Please read this User's Guidance carefully before installation.
2. Do not dismantle the host computer shell and keyboard without permission.
3. In case of any questions, please dial the after-service service hotline of PORCHESON.

PORCHESON TECHNOLOGY CO., LTD

BK108

Operator's Manual

Software Version: V2.0

2003.03 Version

System Configuration &
Installation **5**

Button Operation
specification **9**

Explanation of the Param
eter/Function Setting **16**

Explanation of the System
Debugging and Setting **41**

Input/output State
Detection **53**

Reference & Appendices **58**

All copyrights are reserved, any duplication without the prior authorization shall be forbidden.

Contents

Chapter 1 System Configuration & Installation

1. System Configuration & Remarks.....p5
2. Features of the PS680AM Control System..... p5
3. Installation and Debugging of Computer Control System..... p6

Chapter 2 Specifications of the Button-Pressed Operations

1. Figure of Keyboard of the Operation Panel (See the figure below)..... p9
2. Explanation of the Functional Keys..... p10
3. Explanation of the Parameter Setting button.....p11
4. Cursor Key.....p11
- 5.Operation Mode Selection Key..... p12
6. Electrothermal ON/OFF key and Motor ON/OFF key..... p12
7. Emergency Reset Key..... p12
8. Manual Operation Keys.....p13
9. Setting Scope of Numeric Items..... p15

Chapter 3: Descriptions on setting parameters/functions

1. The main control panel shown while turning on..... p16
2. Setting for mould close information..... p20
3. Set mould opening information..... p21
4. Set the plastic injecting information..... p22
5. Set the pressure retaining information.....p23
6. Set plastic melting/drawing/cooling information.....p24
7. Set the stuff auto-clearing up information..... p25
8. Set the table information..... p26
9. Set the mould adjusting information.....p27
10. Set the ejecting forward information.....p28
11. Set loose core information..... p29
12. Set the air blow information..... p30
13. Set time/count information.....p31

14. Set temperature information	p32
15. Set warm-up information	p33
16. Temperature tracing / tracing curve	p34
17. Set Module information	p35
18. Set production information	p36
19. SPC tracing records for production administration	p37
20. information modification passes to record	p38
21. pressure, speed curve	p39
22. special parameter adjustmetn / Setting	p40

Chapter 4 Instructions for the System Commissioning Settings

1. Engineer Setting Page	p41
2. Delay Setting Page	p42
3. Pressure/Flow Slope Setting Page	p43
4. Pressure Pre-Adjustment Page	p44
5. Flow Pre-Adjustment Page	p45
6. Back Pressure Pre-Adjustment Page	p46
7. Electronic Ruler Setting Page	p47
8. Special Function Options Page	p48
9. Standby Function Setting Page	p49
10. Programmable Standby Function Page	p50
11. Temperature Parameter/Time Setting Page	p51
12. Machine No./ Production-Factory Value Setting Page	p52

Chapter 5 Input/Output Mode Inspection

1. Input Inspection Page	p53
2. Output Inspection Page	p56

Reference & Appendices

1. BK108 keyboard installation dimension Layout	p58
2. external dimensions and installation hole positions drawings for power supply case and transformer	p59
3. Exterior dimensions and installation hole position drawings for main controller	p59
4. PS800AM system wiring drawing	p60
5. Input and output wiring drawing	p61
6. Motor heating wiring drawing	p59

Chapter 1 System Configuration & Installation

1. System Configuration & Remarks

No.	Code	Content	Q'ty	Remarks
1	PS800AM	Host Computer	1 Set	26/28+10
2	BK108	Keyboard	1 Set	320*240
3	SPS300	Power pack	1 Set	300W
4	DB-15F	15-core cable	1	1m-5m, optional


2. Characteristics of PS680AM Control System

- ▶ The whole computer may control all functions and temperatures.
- ▶ The system has bright LCD display and 320*240 Dot 5.7" concolorous/colorful (optional)
- ▶ The system adopts CPU design with fast operating speed, precise control and high stability.
- ▶ The control host computer adopts the blocking design with time-saving installation and rapid maintenance.
- ▶ It has the real time function to display time and date in real time.
- ▶ OFF It has the screen screensaver function, it will power off when there is no operation within 5 minutes.
- ▶ With 80 groups of mode data storage, it may enter the model description and real-time operating help in Chinese and English.
- ▶ The cipher setting and data locking can prevent the operators from changing the established data arbitrarily to influence the quality of products.
- ▶ There are multiple languages for your choice that display dynamically in real time.
- ▶ Packing modulus setting function for 6-digit output may set the packing modulus.
- ▶ Various self-plugging and tein type programs are applicable for the self-plugging and tein control in different types.
- ▶ PID (Proportional Integral Derivative) with self temperature control has 6 sections of temperatures.
- ▶ Ejector nozzle temperature can be controlled with open or enclosed loop.
- ▶ Temperature may be preset a week in advance to enable more convenient operation.
- ▶ Various types of travel control modes, range travel switch/3-path coder/electric ruler (optional)
- ▶ Various types of Glue Shot ways, 4 sections of Glue Shot and class-3 pressure preservation
- ▶ Failure Self-detection functions, alarm display and voice prompt
- ▶ LED indicators for output and input may it convenient to inspect and maintain the system.
- ▶ Input and output are done by the optically coupled circuit to isolate the interference of the external circuitry.
- ▶ In the inspection window, you can inspect all input and output points and the moving states of key.
- ▶ 3-path standard D/A proportional output, the maximum current output 3A (PS610 is 2-path).
- ▶ Presetting of the voltage and runoff values, proportional valve available for the products in all brands and better linear proportion.
- ▶ With remote communication functions, it can let you do the programming and upgrading softwares easily and remotely.
- ▶ With just one controller, to which you connect up to 255 injection machines; and it can also monitor the production of the each machine and print out a report for each of them.

3. Installation and Debugging of Computer Control System

3. 1 Cautions upon Installing the Control System

The design of control system is simple and easy, only one 15-core shielding cable connecting the keyboard and host computer shell with flexible and handy installation and connection. The sketch map for installation is shown as follows:



control box equipment;outfit (for reference only)

- (1) Upon installing the host control box, adopt the enclosed distribution cabinet at the first choice. It shall be fixed in the well-ventilated, greaseproof and dustproof conditions equipped with a fan and dustproof. The distribution box shall be stored under 60°.
- (2) Upon fixing the host computer and power pack, please keep the interconnecting parts such as all AC connectors and transformers as far away from each other as possible to prevent the electric wave interference from the electronic grid.
- (3) All electric wires and shielding wires shall not be cut off, lengthened or curtailed arbitrarily. You should use the electric wires and shielding wires provided by this company to prevent from influencing the reliability and normal operation of the control system.
- (4) The shell of flame couple shall adopt the shielding wire. When the outer shielding of all flame couples adopts the thermal couple reticles, the reticle and machines shall be well grounded and connected to the ground with the earthing resistance below 10Ω.
- (5) Upon wiring, separate the high and low pressure line from the computer control line as much as possible, do not bind all electrical wires together to prevent the interference from affecting the reliable operation of control system.
- (6) Upon fixing the keyboard and 15-core communication connections of the host computer, you shall press and tweak with force to prevent the poor connection from affecting the reliable operation of control system.
- (7) Pay special attention to the oil valve outlet public port YCOM, it shall be connected well to prevent the computer from inputting while having the phenomenon of oil valve having no motion.

3. 2 Inspection of the Control System

- (1) After installation completed, carry out an overall inspection if all connection lines are well fixed including the switching power supply, host computer shell, electrothermal output line and the thermal couple of keyboard, etc.
- (2) After the line inspection completed, carry out an electric connection inspection. First take out the 11-digital output line plug of the DC power supply outlet port, namely the power pack, and then power on to examine and measure if the voltage is the same as the nominal values and observe if the output indicator on the power pack is normal.
- (3) Power off after the measurement completed, insert the DC power supply to input to the plug of host computer shell. After power-on again for inspection, LCD on the keyboard will display the normal state of the main page. Revolve on the emergency stop switch to check if the RUN indicator on the host computer shell turns on. When it turns on, it indicates that the system can work soundly.

3. 3 Setting of the Control System

- (1) After the system having shown normal operating state, press  button on the monitor page to adjust color and comparison.


- (2) To conduct the parameter setting and memory testing, press  button to select a group of


module numbers and then set data in all screens. Press  button to save data. Disconnect

the power and connect it again after a few time, the system will automatically call the data of module numbers saved by you. In case of they are correct, it indicates that the memory is all right.

- (3) Afterwards, set the data in all relevant data (please see Chapter III Explanation of the Parameter Setting for the detailed operations). Upon setting in the first time, set the pressure and speed as little as possible and then after all movements come normally, gradually increase the values to normal parameters to prevent from damaging the mechanical performances.
- (4) After all parameter set, save them and carefully inspect if all input and output points are normal. Carry out an overall inspection of the alarm system, including the front and back safety doors. The wire of safety doors shall be connected as stated in the following figure.

Safety Door






Safety Door Wiring Diagram (for reference only)

★ Safety Doors * Special Explanation:

When a light turns on and the other does not upon closing/opening the doors, or in case of other abnormal conditions, the system will issue an alarm 2 seconds later for Safety Door Failure and simultaneously terminate all operating output. In the semi-automatic mode, the condition for opening/closing the safety doors is that the time from LS1, LS2, LS3, LS4 all turn [OFF] to all turn [ON] is more than 0.5 as valid in order to prevent the twitter of safety door switches from causing error operation.

Chapter 2 Explanation of the Key Operations

1. Figure of Keyboard on the Operation Panel (See the figure below)



2. Explanation of the Functional Keys

Keys	Usage
 <p>开锁模 M.PLT</p>	Enter into the screen to set the mold opening & locking movement
 <p>射胶 INJECTION</p>	Enter into the screen to set the Glue Shot and pressure-preserving movement
 <p>熔胶 FEEDING</p>	Enter into the screen to set the feeding, glue taking and automatic material removal movement
 <p>射台/调模 NOZZ/ADJ.</p>	Enter into the screen to set the nozzle and model adjustment
 <p>顶针/抽芯 EJE/CORE</p>	Enter into the screen to set ejector, self-plugging and huff.
 <p>时间 TIME</p>	Enter into the screen to set timing and counting.
 <p>温度 TEMP.</p>	Enter into the screen to set temperature and pre-heating.
 <p>资料 DATUM</p>	Enter into the screen to set the changes to mold and production facilities.
 <p>监视 MONITOR</p>	Return to the monitor screen in any time.
 <p>帮助 HELP</p>	The on-line help screen upon entering into the current state.

3. Explanation of the Parameter Setting



0-9 numeric keys are used for data input in the data setting screen. When the electric lock is in “OFF” state, these ten numbers are locked to ensure the data will not be changed arbitrarily. In the meanwhile, there are 26 English letters and special symbols respectively on 0-1 numeric keys used for the input of Chinese and English letters as well as the machine serial number. [DELETE] key is used to delete the error words during entering the parameters and serial numbers. [INPUT] key is used to select the functions during function selection and used to confirm during item confirmation.

4. Cursor Key

Keys	Usage
	Skip key, pressing it will skip the cursor to the upper line
	Escape key, pressing it will move the cursor to the left
	Escape key, pressing it will move the cursor to the right
	Skip key, pressing it will skip the cursor to the lower line

5.Operation Mode Selection Key

Keys	Usage	Remarks
	Pressing this key will enter the system into manual state.	There is an indicator on the left upper of all keys. Pressing any key will turn on this indicator, indicating the system is in this state. Every time the computer is started, the default state of system is manual operation. In case of the temperature has not reached the set value, the system is impossible to perform semi-automatic and automatic operations. The indicator will not turn on when the semi-automatic/automatic operation key pressed till the temperature reaches the set value.
	Pressing this key will enter the system into semi-automatic operation	
	Pressing this key will enter the system into automatic operation	

6. Electrothermal ON/OFF key



and Motor ON/OFF key



In the manual mode, press the key once and the indicator at the left upper will turn on, indicating the function state has opened. Pressing the key again and this indicator will turn off, indicating the function state has shut off. Repeatedly pressing this key, the functions will turn on or off in turn. Upon the emergency switch stops, the motor will power off swiftly without affecting the electrothermal operation.

7. Emergency Reset



Key

In any moment, pressing the key once and the indicator at the left upper will turn on, the system will skip back to the manual mode and simultaneously terminal all movement outputs without affecting the mote and electrothermal operation. This key is also used to release the key in case of alarm for abnormal conditions.

8. Manual Operation Keys

Keys	Usage	Operation Conditions
 <p>开模 MOLD OPEN</p>	Model-opening operations 1	1. The mold has not opened to the termination position.
 <p>锁模 MOLD CLOSE</p>	Mold-locking operating	1. Normal safety door input; 2. Ejector retracts till bumping; 3. Mold has not locked to the termination position; 4. The signals (mold-locking) of robot hands have been connected when the robot hands are selected.
 <p>射胶 INJECTION</p>	Glue Shot Operation 1	1. In case of time glue shot selected, the injection time has not completed; 2. In case of the position selected, it has not reached the glue-shot termination position; 3. Temperatures within all sections of material canister shall not exceed the leeway scope (without temperature alarm)
 <p>抽胶 DECOMP</p>	抽胶操作	1. Temperatures within all sections of material canister shall not exceed the leeway scope (without temperature alarm)
 <p>顶进 EJECT ADV</p>	Ejection advance operation 1	1. The travel of ejection advance has not come to the termination position; 2. The mold has opened to the termination position. 3. The self-plugging position limit has connected or the self-plugging time has come when self-plugging is selected. 4. The signals (ejection advance) of robot hands have been connected when the robot hands are selected.
 <p>顶退 EJECT RET</p>	Liftoff operation	1. The travel of liftoff has not come to the termination position; 2. The mold has opened to the termination position.
 <p>座进 NOZZLE ADV</p>	Nozzle advance operation	1、 No condition;
 <p>座退 NOZZLE RET</p>	Nozzle backward operation	1、 No condition;
 <p>调模 MOLD ADJ.</p>	Mold-adjusting Selection	1. When the system is in manual state, press this key and the indicator will turn on, enabling the manual Mold-adjusting or press +automatic Mold-adjusting key for automatic Mold-adjusting. Other operating keys will not work.

Keys	Usage	Operation Conditions
	Slow State	1. After this key is pressed and performing the mold-opening/locking operation, all flows are set in slow speed.
	Feeding Operation	1. Feeding has not come to the termination position; 2. Temperatures within all sections of material canister shall not exceed the leeway scope (without temperature alarm)
	Automatic Material Removal Operation	1. Selection and use of automatic material removal; 2. Times of automatic material removal not completed; 3. Temperatures within all sections of material canister shall not exceed the leeway scope (without temperature alarm)
	Several Items Operation	1. The operating conditions are the same as those for ejection advance and liftoff; 2. The time of ejector setting has not completed.
	Lubricating Pump Work	1. No condition;
	Male Mold Huff Operation	1. Selection and usage of male mold huff; 2. The time of male mold huff has not completed.
	Female Mold Huff Operation	1. Selection and usage of female mold huff; 2. The time of female mold huff has not completed
	Automatic Mold-Adjusting Flow	1. Manual mold-adjusting key has been selected; 2. Automatic mold-adjusting key function has been selected.
	Mold-Adjusting Backward Operation	1. To select the mold-adjusting use state; 2. The mold-adjusting retract has not come to the termination position.
	Mold-Adjusting Forward Operation	1. To select the mold-adjusting use state; 2. The mold-adjusting advance has not come to the termination position.

Keys	Usage	Operation Conditions
	Chip-insertion Operation A	<ol style="list-style-type: none"> 1. Selection and usage of Self-plugging A; 2. Chip-insertion A has not come to the termination position or the time has not completed; 3. Liftoff has reached its position or the liftoff time has come.
	Chip-Extraction Operation A	<ol style="list-style-type: none"> 1. Selection and usage of Self-plugging A; 2. Chip-insertion A has not come to the termination position or the time has not completed; 3. Liftoff has reached its position or the liftoff time has come.
	Chip-insertion Operation B	<ol style="list-style-type: none"> 1. Selection and usage of Self-plugging B; 2. Chip-insertion B has not come to the termination position or the time has not completed; 3. Liftoff has reached its position or the liftoff time has come.
	Chip-Extraction Operation B	<ol style="list-style-type: none"> 1. Selection and usage of Self-plugging B; 2. Chip-insertion B has not come to the termination position or the time has not completed; 3. Liftoff has reached its position or the liftoff time has come.

9. Setting Scope of Numeric Items


Number	Setting Items	Setting Scope	Unit
1	Time Setting	Digital ≤ 999.9	Second
2	Pressure Setting	Digital ≤ 140	Bar
3	Speed Setting	Digital ≤ 99	%
4	Temperature Setting	Digital ≤ 999 Maximum 630°C for actual use Centigrade	$^{\circ}\text{C}$
5	Storage of Mold Data	Digital ≤ 80	Number
6	Predicted Turnout	Digital ≤ 999999	PC

In case of the set values exceed the above-mentioned scopes, the system will not accept the numbers set and keep the original set values. For the habit of data input, the data input of this system is display from right to left.

Chapter 3: Descriptions on setting parameters/functions

1. The Main Control panel while turning on

Connect with power, turn the red urgent stop switches, the operation light of the computer-RUN -flickers, the following menu shown on the display, now the control system is running and it is ready to operate the machine.



Press  key at any time after re-turning on the computer, and then enter the menu of the monitor

menu of the machine. This menu is for monitoring temperature and machine running condition. The names and numbers of the moulds will be set in mould information menu. The temperature scale and current oil temperature show the real value of each stage thus its information cannot be modified. Each function of the menus is described as follows:

The descriptions on mode:

Mode	Meanings
	Motor is running
	Electrical heating opened
	Lubricator is lubricating.
	Lubrication failing or Not released
	Electronic eye function

The descriptions on display:

Display	表 含义及描述 意义及说明
Manual	The running mode of the machine;
Injection Nozzle	This section is heating;
Mould number	The current mould number;
Movable mould	Shows the current position of the mould. The unit: mm;
Screw	Shows the current position of the screw. The unit: mm;
Thimble	Shows the current position of the thimble. The unit: mm;
Pressure	The set pressure value of the current movement;
Flux	The set flux value of the current movement;
Output	Record the numbers of mould opening for current mould number during the automatic operation of the system;
Set	The time value and counter data of the current movement;
Operation	When a time value set for current movement, only the operation time increase to the set time, the next movement starts. When it is the number was set, the acted numbers will be shown on the display till the numbers reach the set counter date.;
Whole process	The real operation cycle time of the system;
In low temperature	The current alarm contents of the display;

Re-press



key to show the following menus

2003.01.06 【Alarm note】 10:07:12			
Date	Happen	Alarm content	Unchain
01日	10:03	Abnormal sensors	10:03
01日	12:08	Clamping mould not completed on time	12:08
01日	15:16	Plastic melting not completed on time	15:16
01日	15:17	Failure of mould releasing	15:17
01日	15:18	Mould opening not fixed on time.	15:18
01日	15:19	Mould opening not fixed	15:19
01日	15:20	Failure of manipulator	15:20
01日	15:21	Failure of motor	15:21
01日	15:22	End of the cycle time	15:22
01日	15:23	Scheduled mould opening	15:23

Descriptions on alarm mode

Alarm	Source	Solution
Exits unclosed	The mode locking stops and “xits unclosed” showed if you operate mode locking while exits unclosed;	Check if the switches of the front and rear exits are correctly connected with input interface of X00 and X15 and check if they can be pressed normally.
Open Exits	In “Semi auto” mode, the exits remain unopened while a single cycle ended;	Open the exits, take out the products, close exits and than continue the processing.
Failure of sensor inspection	In automatic operation, when the inspecting sensor is not “ON” after thimble withdrawing in sensor cycling mode and the mid-time is over, it warns “Failure of sensor inspection” ;	Remove the failure of Ejecting forward and Ejecting backward and judge if there are any long cover. The connection lines and the sensor itself should be mainly inspected when the light of X20 input point always shines.
Mould opening not fixed	When eject forward manually, the mould opening not reach the position of stopping mould opening;	Re-open or check if the mould opening termination X12 has been put through.
Clamping mould not fixed on time	Clamping mould not completed within “ the time limitation of the mould opening or closing” ;	Check the clamping mould process, extend properly “ the time limitation of the mould opening or clamping” if it is normal.
Low pressure mould protecting time is over	It will warn if it has not turned into high pressure when the low-pressure time is over.	Check the mould, extend properly “he low pressure time” if there is not any redundant objects.
Failure of Exit	Alarm when there is only one press in X00and X15;	Check if the switches of the front and rear exits are correctly connected with input interface of X00 and X15 and check if they can be pressed normally.
Plastic melting not completed on time	Plastic melting not completed within “ the time limitation of plastic melting” ;	Check the plastic melting process and find out if the plastic in plastic drum has been run out. Extend properly “ the time limitation of plastic melting” if it is normal.
Failure of plastic injection	The plastic injection testing stroke switches X20 has not been pressed or the electronic ruler has not reached the plastic injection testing point during plastic injection.	Check plastic injection process and adjust the deviation value of plastic injection testing; (e.g.: stroke). Strap input interface X20 on common interface (XCOM) when not test plastic injection.
Failure of motor	Alarm when signal inputs motor protection point X27.	Check if there is a protection on the oil hydraulic motor caused by relay against overload.
Cycle time is over	When Auto production cycle time is longer than set [cycle time]	Check the auto production process, extend properly the set [cycle time] if it is normal.


Alarm	Source	Solution
Knockout core A not completed. Knockout core B not completed.	Machine has chosen knockout core A and B. It requires that the knockout space of the knockout core must have been connected when eject forward or multi-eject forward;	Check if the stop switches of the knockout core A and B are connected correctly and if they can be pressed normally. Set a stop mode in function menu for knockout core A and B when you do not use the knockout core function.
The set output reached	The machine stops when the output stopping machine function started or the numbers of mould opening have reached the set output number.	Solution: If you need the machine continues running after the output reached, just set the [stop after alarm] in production menu as [out]; or reset the total mould opening of the current mould number .

Descriptions on operation/prompt mode


Alarm	Source
High temperature in 1,2,3, 4, 5 stages Injection nuzzle.	The real temperature related to the stage of the machine hopper is higher than the set top limited value.
Low temperature in 1,2,3, 4, 5 stages Injection nuzzle.	The real temperature related to the stage of the machine hopper is higher than the set top limited value.
Temperature short circuit n 1,2,3, 4, 5 stages Injection nuzzle	The real temperature related to the stage of the machine hopper is higher than the set top limited value.
Auto stuff clearing up completed	After the set number movement completed and while auto stuff clearing up.
Auto mould adjusting completed	Auto mould adjusting completed when using mould auto adjusting.
Auto mould adjusting not completed	Auto mould adjusting not completed when using mould auto adjusting.
Enter manual mode first	When operate manual keys in auto mode.
Functions not selected	Certain function has not been selected when manual operate its keys.
Start motor	How to select motor: Prompt when the semi-auto/auto keys are pressed, as the motor has not been started.
Next cycle Prepared	In auto mode, the mid-time between completing a cycle and starting next cycle.
Sensor prepared	The mid-time has not been reached after withdrawing thimbles during auto sensor cycling.
Exit mould adjusting mode first	When operate non-[adjust forward, backward and auto mould adjusting] keys in mould adjusting mode.
Enter mould adjusting mode first	When operate [adjust forward, backward and auto mould adjusting] keys in non-mould- adjusting mode.

2 Set mould close information

Press 开锁模
M.PLT key, enter the menu for setting mould close, now the menu is as following:




Descriptions on setting parameters/ process/function mode




- (1). Process: while mould close, enter slow clamping first, and then enter fast clamping when the stroke arrives at 509.5mm, and then enter low pressure clamping when stroke runs another 105.0mm, and then enter high pressure clamping when stroke runs another 2.0mm till clamping completed. It alarms[low pressure mould protection time is over] when the low pressure time is over but not enter the high pressure yet.
- (2). Low pressure protection: Set a smaller low-pressure time for mould close, it is best to be fitting, otherwise, the mould can not be protected.
- (3). Differential mould close: press input keys to select [on] or [off], output when select [on] for quick mould close Y52, not output when select [off] for quick mould close Y52,

3. Set mould opening information

Press 开锁模
M.PLT key twice, enter the menu for setting mould opening, now the menu is as following:




Descriptions on setting parameters/ process/function mode




- (1). Process: while mould opening, enter slow mould opening first, and then switches to quick mould opening when stroke arrives at 50.5mm, and then switches to moderate speed mould opening when arrives at 205.9mm, and then switches to low speed mould opening when arrives at 559.5mm, and then mould opening completed when arrives at 600.0mm.
- (2). Time limitation to mould opening and clamping: time limitation to mould opening and clamping, please set it longer, and it is better to be fitting, otherwise, the system alarms [mould opening/clamping not completed on time].
- (3). The function of manipulator: if a manipulator needed, please select [on] for it. After [on] selected, the machine will output manipulator signal while mould opening completed. Before mould close, the next cycle starts only after receiving the manipulator signal, and stop the output of it at the same time.

4. Set the plastic injecting information

Press  key once, enter the menu for setting plastic injection, now the menu is as following:



Descriptions on setting parameters/ process/function mode




- (1). Process: while plastic injecting, 1 stage injects plastic first, and then switches to 2 stage when arrives at 220.0mm, and then switches to 3 stage when arrives at 150.9mm, and then switches to 4 stage when arrives at 98.5mm, and then switch to pressure retaining when arrives at 10.0mm
- (2). The whole process of plastic injecting; monitor the normal plastic injecting process. Equal time arrives when start plastic injecting ---start timing and switch to pressure retaining whatever the arrives the distance or not. Thus the injecting time should be set longer than real time.
- (3). Testing on Plastic injecting: both [on] and [off] can be selected, it is in semi-auto/auto mode when [on] is selected. The computer will select automatically the average of the plastic injecting of the first 20 moulds as testing point of plastic injecting. A numerical value scope of tolerance can be set in pressure retaining page. [Failure of plastic injecting] alarms when the plastic injecting has not reached or over passed the testing scope after the 21st mould, and meanwhile the production management will take it as a reject.

5. Set the pressure retaining information

Press  key twice, enter the menu for setting pressure retaining, now the menu is as following:


2003.1.2
【Hold press】
15:32:15



	3Lev	2Lev	1Lev
Pres(bar)	35	50	55
Flux(%)	25	39	19
Time(s)	1.2	3.0	2.5
The function of slope	Nuse	Nuse	Nuse

InjCheck 20.5 PmtError ± 5.5

Descriptions on setting parameters/ process/function mode



- (1). Process: when enter pressure retaining after injecting, enter the 1st grade pressure of pressure retaining and speed movement first, and than [the 1st grade time is over] enters the 2nd grade of pressure retaining, and than enter the 3rd grade pressure retaining through [the 2nd grade pressure retaining is over], and than switches to plastic melting delay after [the 3rd grade pressure retaining is over]
- (2).How to use: it will be controlled as following when only 1st pressure retaining control is needed for molding condition: key the 1st pressure retaining time in the box of 1st grade time, pressure retaining 2nd time [000.0, it is 0 when (out)], pressure retaining 3rd time [000.0, it is 0 when (out)].
- (3).The function of slope: Controlling on pressure is for retaining pressure or change of slope. Refer to the set menu, the real output pressure is as the picture above right.

6. Set plastic melting/drawing/cooling information

Press 熔 胶
FEEDING

key twice, enter the menu for setting plastic melting/drawing/cooling, now the menu


is asfollowing:

2003.1.2 【 Melt/Take/cool 】 15:32:15

	F.Tk	Me11	Me12	B.Tk
Pres(bar)	30	120	85	50
BYa(bar)	***	15	20	***
Flux(%)	25	85	60	25
Place(mm)	30.0	170.5	285.0	300.0

Cool.T	30.5	Melt Lim	120.5
--------	------	----------	-------


Descriptions on setting parameters/ process/function mode




- (1). Process: After retaining pressure, front drawing first, switches to melting 1 when arrives at 30.0mm, and than switches to melting 2 when arrives at 170.5mm, and than switches to back drawing when arrives at 285.0mm, and than plastic melting completed when arrives at 300.0mm.
- (2). Time limitation to plastic melting: the time for monitoring no-stuff. The uncompleted plastic melting will be taken as no-stuff when time is over. So set the time limitation longer than real plastic melting time, otherwise it alarms [plastic melting not completed on time].
- (3). Cooling time: In auto mode, cooling time stars just after plastic injecting pressure retaining. The time for plastic melting and drawing is a part of cooling time. When the process time is longer than cooling time, the cooling time is over. Mould can be opened only after plastic melting/drawing completed. Otherwise mould will be opened as soon as the cooling time is over.

7. Set the stuff auto-clearing up information

Press  key twice, enter the menu for setting stuff auto-clearing up, now the menu is as following:




Descriptions on setting parameters/ process/function mode



- (1). Process: How to use the stuff auto-clearing up function. In manual mode, press the key of stuff auto-clearing up, the system starts the stuff auto-clearing up process, first is the process of with drawing, and than cycles automatically according with process shown in the diagram above.
- (2). Plastic melting delay: Starting delay time for plastic melting, switches to plastic melting through the time delay after plastic injection pressure retaining completed.
- (3). Times of stuff clearing up: the times of repeating plastic melting and injecting.

8. Set the table information

Press  key once, enter the menu for setting table, now the menu is as following:




Descriptions on setting parameters/ process/function mode

- (1). Slow entry movement: switches to slow entry movement and combines with mould after touching table stop switch. Thus prevent clinking and protecting mould.
- (2). Auto table:[off], [plastic melting completed]or[cooling completed] can be selected. If [plastic melting completed] is selected, withdrawing after plastic melting completed in auto mode.
- (3) Stop withdrawing: [process] or [time] can be selected, if [process] is selected, stops at the withdrawing place of stop limit switch [X007] controlling after auto injecting table withdrawing to the back of injection table.

9. Set the mould adjusting information

Press  key twice, enter th menu for setting mould adjusting, now the menu is as following:




Descriptions on setting parameters/ process/function mode

- (1). How to adjust mould: [Manual] or [Auto] can be selected, the pressure for mould adjusting is about 20-50 bar, the speed is 30-60%.
- (3). Fine adjusting mode: [Time] or [gear number] can be selected. Select [time] if the machine is not mounted with sensor; the initial value is controlled by [time]; select [gear number] if there is a sensor, the initial value is controlled by [gear number].
- (3). The time of mould closing: In auto mould adjusting, time limitation for mould closing.
- (4). How to use auto mould adjusting: Select [auto] for mould adjusting, press the keys of [mould adjusting] and [auto mould adjusting], and than enter the mode of auto mould adjusting as soon as the exit shut. The movement pressure and flux of adjusting forward and backward in the process of auto mould adjusting is controlled by a set value in the fine adjusting box. The sound of [D,D] can be heard and [mould adjusting completed] shown after the mould adjusting completed.
- (5). While adjust mould manually or automatically, the forward time of mould adjusting is controlled by stop limit switch X21 before adjusting mould; the backward time of mould adjusting is controlled by stop limit switch X22 after mould adjusted;

10. Set the ejecting forward information

Press  key once, enter the menu for setting ejector forward, now the menu is as following:




Descriptions on setting parameters/ process/function mode

- (1). Times fixed ejecting forward: [Ejecting forward] → [Ejecting backward stop] as a cycle, move in according to times.
- (2) Vibrating ejecting forward: [ejecting forward stop] → [ejecting forward stop, off] as a cycle, the movements are set in according to the times of the ejecting forward. The ejecting backward movement ends when times finished.
- (3) Ejecting forward retaining: Used in semi-auto. Stops while ejecting forward movement reach its limits, and not ejecting backward until before closing mould in next cycle.
- (4). Ejecting backward delaying: after ejecting forward and backward completed, the ejecting backward movement occurs while the set time delayed.
- (5). Ejecting forward delaying: after mould opening completed, the ejecting forward movement occurs while the set time delayed.
- (6). Retaining function: if the retaining time is set as 00, there is no retaining function. The retaining function is for retaining pressure, speed and starting retaining time for the output after ejecting forward completed. The retaining movement is completed as soon as the time is over.
- (7). [note]: No times limitation while eject forward manually,(except for 0000)

11. Set loose core information

Press


 顶针/抽芯
EJE/CORE

key twice, enter the menu for setting loose core, now the menu is as following:

2003.1.2		【Tak Core】		15:32:15	
CoreA	Use		CoreB	Use	
Amode	Count		Bmode	Time	
	Ain	Aout	Bin	Bout	
Pres(bar)	60	65	30	35	
Flux(%)	35	50	25	15	
Time(s)	680	680	2.0	3.5	
Place(mm)	255.2	50.5	300.2	100.0	

参数设定/功能方式说明

- (1) The function of loose core A: [On] or [Off] can be selected.
- (2). The function of loose core B: [On] or [Off] can be selected.
- (3). Mode A. [Time], [stroke] and [count] can be selected. If [time] selected, set the time till the movement of loose core A terminated; if [stroke] selected, the movement of loose core will not terminate until the stop signal [X25, X26] of input point shows ON; if [count] selected, pipe thread control can be taken, and the movement termination is decided by the number of pipe tread pulse inputted through [X25, X26].
- (4). Mode B: [Time], [stroke] and [count] can be selected. If [time] selected, set the time till the movement of loose core B terminated; if [stroke] selected, the movement of loose core will not terminate until the stop signal [X30, X30] of input point shows ON; if [count] selected, pipe thread control can be taken, and the movement termination is decided by the number of pipe tread pulse inputted through [X30, X31].
- (5). Time/gear number: Time or gear number can be set in this box, when [time] is selected for loose core A and B, the set value in the box is time. When [count] is selected for loose core A and B, the set value in the box is gear number.
- (6). Start position: The position for starting the movement of core knock in or knock out where the mould stops-- is a set value for the movement of core loose A and B.



12. Set the air blow information

Press  key thrice, enter the menu for setting air blow information, now the menu is as following:

2003.1.2		【Huff Set】		15:32:15	
					
			Blow Male	Blow Female	
Time(s)			1.5	2.3	
Dely(s)			0.2	0.1	
Stat Loc			0.M.F	0.M.T	
Func Mod			Use	Use	

Descriptions on setting parameters/ function mode

- (1) Why blowing air: This function can be used in the stamping mould that need air blow.
- (2). Time delay: Delay first when arrives automatically at the position of air blow, and than blow air when delay time starts.
- (3) Starting position: [Pre-mould opening] can be selected. [Pre-mould opening] is taken as a set value for the movement of air blow.
- (4). Function mode: [On] or [Off] can be selected, no movement of air blow if [Off] is selected.



13. Set time/count information

Press




key thrice, enter the menu for setting time/count, now the menu is as following:

2003.1.2		【Time/Count Set】		15:32:15	
Lubr.M.N	99999	MiddTime	999.9		
LubricTT	999.9	Cycle T.	999.9		
Lubric.T	999.9	Act Li.T	999.9		
LubricGP	999.9	Fau.Warn	999.9		
Pc.ON.Time	00580	H	02	M	
Auto.ON.Time	00505	H	15	M	
Mato.RUN.Time	00535	H	59	M	


Description on setting parameters

- (1). Lubricating modulus: Count mould opening times. The oil pump starts when mould opening times reach the set value.
- (2). Total time for Lubrication: the total time spent in this lubrication.
 - (1). the output of the repeated operation with the total time for lubricatin.
 - (4). The interval of the repeated operation with the total time for lubricatin.
- (5). Mid-time: During auto process, it is the time between completed thimble movement and starting a movement of moulds clamping of next cycle.
- (6). Cycle time: The time limitation to operation cycle in automatic process. The system alarms [cycle time is over] when the real operating time is longer than cycle time limitation.
- (7). Movement time limitation: the max time permitted when output movement.
- (8). Error alarm bell: The max time when error output occurs. To avoid long time alarming, the bell stops alarm when time is over
- (9).during the output time of lubrication, if it fails to detect any lubrication pressure signal, it would trigger an alarm, telling that the lubrication is failing. If “opping working” after the failing of lubrication is chosen, then it would stop lubricating and would change to work in manual mode and stop the engine after the cycle of the alarming.



14. Set temperature information

Press  key, enter the menu for setting temperature, now the menu is as following:



Description on setting parameters

The set temperature value is 1°C (Celsius). The temperature of the hopper of injection molding machine is close-loop controlled after it is fed back to controlling system by K and J style thermal electric couple.

The system provides total 6 stages of temperature control and 1 stage oil temperature testing. [Open-loop] / [close-loop] can be selected to control temperature for injection nozzle. The system monitors the temperature in every area to find out if the temperature overpasses the set top and bottom limitation. It cannot inject or melt plastic if the temperature is lower than the bottom limitation and than the cold preventing screw starts. It alarms when the temperature is higher than the top limitation. The temperature of each stage is shown on the main menu.

部分塑胶密度与料管加热温度参考资料

原料简名	密度	加热温度°C	原料简名	密度	加热温度°C
A.B.S	1.01-1.05	190-270	PMMA	1.17-1.20	180-260
PS	1.05	190-240	PPO	1.08-1.09	260-330
A.S	1.06-1.07	180-250	PA/NYLON	1.08-1.17	230-290
H.P.S	1.05-1.08	220-280	NYLON66	1.03-1.15	280-330
L.P.S	0.91-0.93	150-260	PVC/S	1.20-1.40	150-180
H.P.E	0.94-0.96	190-260	PVC/H	1.30-1.58	160-200
P.P	0.98-0.90	200-290	P.E.T	1.38-1.41	280-310
P.C	1.2-1.22	280-320	P.T	1.41-1.52	220-280
P.O.M	1.41-1.42	190-230			

15. Set warm-up information

Press  key twice, enter the menu for setting warm-up, now the menu is as following:

2003.1.2 **WarmUP Set**  15:32:15

Func **Use** Today: Tues

Week	Set	Open-Time	Set	Clos-Time
Mon	ON	8:30	ON	16:40
Tue	ON	8:00	ON	17:00
Wed	ON	7:30	ON	17:30
Thu	ON	7:00	ON	18:00
Fri	ON	6:30	ON	18:30
Sat	ON	8:24	ON	19:00
Sun	ON	9:00	ON	19:30


Description on setting parameters

Warm-up function: Can set a time for seven days a week in advance. The system controls the heating system to heat through the set value of the intraday [on]/[off] time. The system heats automatically the hopper to working temperature before operator comes to the office. The operator's waiting time for heating hopper is decreased.


*[note]: The input value of time adopts the input value of 24 hours system. 00:00 is 12: 00 Midnight.

16: Temperature monitoring and tracing curve panel.

Press  key for 3 times to enter the panel, and it is as follows:



Press  key for 4 times to enter the temperature tracing curve panel, and it is as follows:




Description on setting parameters

- (1). Display: That is to monitor the historic tracing curve of the temperature of a specific segment. For reference, it can provide historic parameters of each segment, which are up to the past 6 hours. This lets the operator more insight of the variation of the actual temperature and let compare and analyze how the change of the temperature affects the quality of the products.
- (2). Interval of the sample record: is the interval of the sampling process, the range could be between 5 to 10 minutes.

17. Set mould information

Press  key, enter the menu for setting mould, now the menu is as following:



Description on setting parameters

- (1). Mould number: this system can store 80 mould numbers. The system can provide automatically the information of the modified mould number after they have been modified.
- (2). How to store mould: Move cursor to the box of mould numbers, key in the mould number; and than move the cursor to the box of the name of the mould, key in the name of the mould; this system provides the input modes with English/Chinese phonetic alphabet; move the cursor to box of storage after the name has been keyed in and than press [enter] to store the name.
- (3). How to get mould: Move cursor to the box of mould numbers, key in the mould number that will be read out, move the cursor to the box of reading out, press [enter] to read out. The functions of getting mould is limited within manual mode to prevent accident occurs; in the semi-auto/ auto mode, the accident is caused by the influence of bad products, which comes from the sudden varying of the set parameters in the menu.
- (4). How to delete: Move cursor to box of mould number, key in the mould number that will be deleted, and than move the cursor the box of deleting, press the [enter] to delete. The current mould number can not be deleted.
- (5). How to check mould: Move cursor to the box of mould browsing, read it through the rolling menu by using [↑ ↓] key.

18. Set production information

Press  key, enter the menu for setting production information, now the menu is as following:

2003.1.2 【 Product Manager 】 15:32:15

Set Mode	999999	Molds	Good	Bad
Modl Qua	20	900	1780	20
Warn Stop	Nuse	ZERO		

DATE	Mold	Tnum	Good	Bad
03.01.01	13	999999	999999	9999
03.01.02	03	999999	999999	9999
03.01.03	23	999999	999999	9999
03.01.04	05	999999	999999	9999
03.01.05	01	999999	999999	9999

Description on setting parameters

- (1) The quality products equal to the number of the opened mould times the amount of one mould minus rejects. The rejects are controlled through ejecting testing function. When ejecting testing function is on, just like in stroke. When too much or too less stuff occurs, the rejects will increase amount value of one mould, and [rejects found] alarms.
- (2). Set mould numbers: In the mould numbers setting of pre-production, the system starts alarming when the number of mould opening arrives at the first 5 moulds till it reaches the mould number.
- (3). Stop after alarming: [On] or [Off] can be selected. It will continue producing even arrives at the set mould number if [Off] has been selected till an operator stops it.
- (4). How to check production records: Move cursor to the box of production records, read it through the rolling menu by using [↑ ↓] key.

19. SPC Tracing record with production management

Press



key 3 times to enter the SPC Tracing record with production management, and the

panel is as follows:

2003.1.2 【SPC TracRecd】 15:32:15						
Page 01		Prin OFF		PrintNum 05		
MoldNo	Cycl	Inje	lend	Mend	Fend	Oilt
pcs	sec	sec	mm	mm	mm	℃
- 01	999.9	999.9	999.9	999.9	999.9	035
- 02	999.9	999.9	999.9	999.9	999.9	035
- 03	999.9	999.9	999.9	999.9	999.9	035
- 04	999.9	999.9	999.9	999.9	999.9	035
- 05	999.9	999.9	999.9	999.9	999.9	035
- 06	999.9	999.9	999.9	999.9	999.9	035
- 07	999.9	999.9	999.9	999.9	999.9	035
- 08	999.9	999.9	999.9	999.9	999.9	035

Description on setting parameters

- (1). Pages: the panel has up to 10 pages, containing the consecutive information of the 80 modules. The SPC Tracing record system can provide up to 6 important parameters of the latest 80 modules. The operator can scroll up and down between page 1 and page 10 to manage the production of the modules. By using the system, the operator will be able to have more insight of the actual variation of the important parameters and take specific and proper actions to adjust the system's operation and improve the quality of the product as a result.
- (2). Print the page: the function would let the operator to make use of the printing service of the system.
- (3). Print the number of the modules: the system would record one set of SPC parameters every specific number of modules.

20. Log of Modified records

Press the  Key 4 times to enter the panel and it should be like as follows:


2003.1.2 【修改经过记录】 15:32:15				
页数 01		列印 OFF		
日期	时间	修改项目	原来值	修改值
12.31	10:01	开模慢速压力	25 bar	28 bar
12.31	10:01	开模慢速流量	20 %	26 %
12.31	10:01	开模慢速位置	75 mm	105 mm
12.31	10:01	机械手功能	不用	使用
12.31	10:01	射咀温度	205	210
12.31	10:01	开模快速压力	75 bar	68 bar
12.31	10:01	锁模低压力	25 bar	15 bar
12.31	10:01	锁模高压力	125 bar	135 bar
12.31	10:01	射胶一段流量	25 bar	28 bar

Description on setting parameters

- (1). Pages: the panel has up to 10 pages, containing 90 set of information. The operator can scroll up and down between page 1 and page 10 to manage the production of the modules to double check the already modified records.
- (2). Print the page: the function would let the operator to make use of the printing service of the system.

21. Pressure / Speed curve

press the  key 5 times to enter the panel and it should be as follows:




Description on setting parameters

- (1). Curve of Feedback value: the system can show you the selected curve, such as curve of injection, curve of pressure for injection, pressure for pressure retention, pressure for locking the modules. All the curves can be selected by the input key.
- (2). Color of the Curve of Feedback value: the operator can choose a favorite color for the curve. The available colors are: yellow, red blue, green and white. All the colors can be selected by the input key.
- (3). Curve of set value: the system can show you the set value curve, such as curve of injection, curve of pressure for injection, pressure for pressure retention, pressure for locking the modules. All the curves can be selected by the input key.
- (4). Color of the Curve of set value: the operator can choose a favorite color for the curve. The available colors are: yellow, red blue, green and white. All the colors can be selected by the input key.

22. Adjust/set special parameters

Press  key in the home menu, enter the menu for adjusting/setting special parameters, now the menu is as following:




Description on setting parameters

- (1) Adjust the brightness of LCD: Move cursor to this place, press  key, the display will darken gradually. Press  key, the display will lighten gradually. The adjustment scope: "1-16" grade.
- (2). Set the color of LCD: The system provides two modes[normal, reverse color]. Move cursor to this place, press  key, they can be converted to each other.
- (3). The time of LCD backlight: The system has the function of screen saver. The time of the background light can be set. The setting scope is 1-5minutes. The background light will turn automatically to OFF if the keyboard is not operated within the set time.
- (4) Set English and Chinese: The system provides two languages of [English and Chinese]. Move cursor to this place, press  key, they can be converted to each other.
- (5) Saving power by changed frequency: can be [ON] or [Not used]. If the function is chosen, it would have saving power output point.
- (6). The function of sensor: [On] or [Off] can be selected. The finished products will be tested by sensor if [On] is selected. In auto mode, the mould closing movement will not start after the mould opening and thimble completed. The next cycle movement will not start until the sensor has tested the finished products.
- (7). Start moderate pump: The output point of Y62 moderate pumps outputs when the set values of the moving flux overpass the set output values of the flux of the moderate pump.
- (8). Start large pump: The output point of Y61 large pumps outputs when the set values of the moving flux overpasses the set output values of the flux of the large pump.

Chapter 4 Instructions for the System Commissioning Settings

1. Engineer Setting Page

Press  Key on the Main Page to enter the Engineer Setting Page, and the following will be displayed:



Enter the password * * * *. If correct, will be displayed. If incorrect, will be displayed. If the password entered is correct, you can enter the system parameter setting page. It is not necessary for the equipment end-user to adjust the system parameters. Please consult the equipment manufacturer for any query. Any parameter adjustment disorder may result in damage to equipment capability, unstable performance or failure to operate.

After the correct password is entered, the cursor jumps automatically to the first item from the right. The cursor can be moved to different items and then Key   is pressed to enter the corresponding pages. Alternatively, you can press the following keys  to enter directly the corresponding pages:

Key	Entering Page	Key	Entering Page
	<Delay Setting>		<Special Function Options>
	<Pressure/Flow Setting I> <Pressure/Flow Setting II>		<Standby Function Setting> <Programmable Standby Points>
	<Pressure Pre-Adjustment> <Flow Pre-Adjustment> <Back Pressure Adjustment>		<Temperature Parameter/ Time Setting>
	<Electronic Ruler Setting>		<Machine No./Ex-Factory Value Setting>

2. Delay Setting Page

After entering the correct password, press



Key to enter the Delay Setting Page. The


following is displayed:

RET<<
【Set Delay】

Begi	Act	End	Begi	Act	End
0.0	M.CI	0.0	0.0	RET	0.0
0.0	ADV	0.0	0.0	THIN	0.0
0.0	INJE	0.0	0.0	THIC	0.0
0.0	FEED	0.0	0.0	A_IN	0.0
0.0	DECO	0.0	0.0	AOUT	0.0
0.0	RET	0.0	0.0	B_IN	0.0
0.0	OPEN	0.0	0.0	BOUT	0.0
0.0	ADV	0.0	***	DIFF	0.0

NOTE Set scope 0.0-0.5 second

Description on setting parameters



- (1) The meaning of Start Delay: the corresponding action valve ON → } delay time T1 → pressure output ON
} flow output ON
- (2) The meaning of End Delay: the corresponding action valve → } pressure output OFF
} flow output OFF → delay time T2 → action valve OFF
- (3) The setting ranges for the Start [T1] and the End [T2] are 0.0-0.5 seconds.

3. Pressure/Flow Slope Setting Page

After entering the correct password, press



Key once to enter Pressure/Flow Slope

Page I. The following is displayed:

Next>>
【Set Pres/Flux Slope1】

Act	P	F	Act	P	F
SlowClos	16	16	SlowOpen	16	16
FastClos	16	16	FastOpen	16	16
MediClos	16	16	MediOpen	16	16
LowClos	16	16	LowOpen	16	16
HPreClos	16	16	CoreA In	16	16
ADV.Quic	16	16	CoreAout	16	16
ADV.Slow	16	16	CoreA In	16	16
Ejec RET	16	16	CoreAout	16	16

NOTE GotoPressFlusSet2

After entering the correct password, press



Key twice to enter Pressure/Flow Slope

Page II. The following is displayed:

RET<<
【Set Pres/Flux Slope2】

ACT	P	F	ACT	P	F
1LevInjc	16	16	1LevFeed	16	16
2LevInjc	16	16	2LevFeed	16	16
3LevInjc	16	16	BackDeco	16	16
4LevInjc	16	16	NozzIADV	16	16
1LevPres	16	16	NozzIRET	16	16
2LevPres	16	16	MoldThin	16	16
3LevPres	16	16	MoldThic	16	16
FronDecp	16	16	Other	16	16

NOTE Return to Engineer Set

Description on setting parameters

The Pressure/Flow Slope refers to the steep degree of rise or fall when the pressure/flow changes from one value to the next value. “1” stands for the slowest change and “16” stands for the fastest change. The setting range is [1-16].

4. Pressure Pre-Adjustment Page

After entering the correct password, press  Key once to enter the Pressure Pre-Adjustment Page. The following is displayed:

Next>>		【 PressPreadj 】		
Coil RES	Prea Nuse	70	120	OFF
20 Ω	1 10 OFF	80	160	OFF
CurrMax	10 20 OFF	90	180	OFF
10 mA	20 40 OFF	100	200	OFF
CurrMin	30 60 OFF	110	210	OFF
800 mA	40 80 OFF	120	220	OFF
PreAdjp	50 100 OFF	130	230	OFF
90 %	60 110 OFF	140	255	OFF
NOTE GotoFluxpreAdj				

Description on setting parameters

The pressure pre-adjustment is the linear adjustment of pressure output. In general, the standard pressure is 0-800mA and the standard output impedance is 10-20 Ω ,unless the manufacturer has specific requirements since different manufactures' overall oil piping designs and the capabilities of the pressure proportional valve being used are different.

Pressure Adjustment Method:

The parameters on this page have been set before ex-factory. If the capability of the proportional valves being used by the user is different, and the normal proportion and linear proportion cannot be achieved, the parameters on this page can be adjusted. First set the pre-adjustment to be [Activated], and then set the pre-adjustment item to be [ON]. For example, for the 50 bar pressure position of Item 50, if the reading on the pressure meter is 45 bar, the parameter of this item should be increased until the pressuremeter reading reaches 50 bar. Make adjustments on all parameters which need adjusting and make the0-140 bar pressures being set correspond to the pressures being shown on the oil pressure meter respectively.After the adjustments are completed, the computer executes automatically linear processing and takes theprocessing results as the subsequent normal D/A proportional output values.

5. Flow Pre-Adjustment Page

After entering the correct password, press Key



twice to enter the Flow Pre-Adjustment Page. The following is displayed:

Next>> **【FluxPreadj】**

Coil RES	20 Ω	Prea	Nuse	50	160	OFF	
CurrMax	10 mA	1	40	OFF	60	180	OFF
CurrMin	800 mA	10	60	OFF	70	200	OFF
PreAdj	90 bar	20	80	OFF	80	210	OFF
		30	110	OFF	90	230	OFF
		40	140	OFF	99	255	OFF

NOTE GotoBPressPreadj

Description on setting parameters

The flow pre-adjustment is the linear adjustment of flow output. In general, the standard value is 0-800mA and the output impedance is 40 Ω ,unless the manufacturer has specific requirements since different manufactures' overall oil piping designs and the capabilities of the pressure proportional valve being used are different.

Flow Adjustment Method:

The parameters on this page have been set before ex-factory. If the capability of the proportional valves being used by the user is different, and the normal proportion and linear proportion cannot be achieved, the parameters on this page can be adjusted. As for the speed adjustment, different manufacturers have different measuring methods. Some manufacturers use the melt tachometer to measure the rotation speed. First heat the barrel until the barrel temperature reaches normal melt temperature. Set the melt speed to be 1, 10, 20, 30, and more until 99 and check the actual values. Make adjustments on all parameters which need adjusting and make the 0-99% speeds being set correspond to the proportional coefficients being shown on the tachometer respectively. After the adjustments are completed, the computer executes automatically linear processing and takes the processing results as the subsequent normal D/A proportional output values.

6. Back Pressure Pre-Adjustment Page

After entering the correct password, press  Key three time to enter the Back Pressure Pre-Adjustment Page. The following is displayed:

RET<<
【 BPPreadj 】

Coil RES	Prea	Nuse	70	120	OFF
20 Ω	1	10	OFF	80	160
CurrMax	10	20	OFF	90	180
10 mA	20	40	OFF	100	200
CurrMin	30	60	OFF	110	210
800 mA	40	80	OFF	120	220
	50	100	OFF	130	230
	60	110	OFF	140	255
					OFF

NOTE Return to Engineer Set

Description on setting parameters

The back pressure pre-adjustment is the linear adjustment of back pressure output. In general, the standard pressure is 0-800mA and the standard output impedance is 10-20 Ω ,unless the manufacturer has specific requirements since different manufactures' overall oil piping designs and the capabilities of the pressure proportional valve being used are different.

Back Pressure Adjustment Method:

The parameters on this page have been set before ex-factory. If the capability of the proportional valves being used by the user is different, and the normal proportion and linear proportion cannot be achieved, the parameters on this page can be adjusted. First heat the barrel until the barrel temperature reaches normal melt temperature. Set the melt back pressure to be 1, 10, 20, 30, and more until 140 and check the actual values. Make adjustments on all parameters which need adjusting and make the 0-140 bar back pressures being set correspond to the back pressures being shown on the back pressure meter respectively. After the adjustments are completed, the computer executes automatically linear processing and takes the processing results as the subsequent normal D/A proportional output values.

7. Electronic Ruler Setting Page

After entering the correct password, press  Key _ three times to enter the Electronic Ruler Setting Page. The following is displayed:

Ret<<		【 E.Ruler Set 】			
E.Rule		Mete.V	Leng	Limi	G.Orig
LMIdRu	Rset	250.0	400.0	375.0	Conf
InjeRU	Rset	68.8	150.0	235.0	Conf
ThimRU	Use	188.8	250.0	125.0	Conf

NOTE Scope:0.0---999.9

Description on setting parameters

- (1) Electronic Ruler Function: If the equipment needs to use the electronic ruler, choose [Activated]. If the equipment adopts stroke switch control, choose [Deactivated].
- (2) Measurement Values: indicating the actual dynamic positions of the electronic rulers for the clamping unit, the injection unit and the ejector.
- (3) Total Length: referring to the actual lengths of the electronic rulers for the clamping unit, the injection unit and the ejector.
- (4) Limit Position: It refers to the maximum value set for the position. This parameter is subject to the maximum position setting. For example, if the parameter set is bigger than the limit position value, the system will not accept the parameter set and will retain the original setting.
- (5) Zeroing: When the equipment choose [Activated] for the Electronic Ruler Function and uses the electronic ruler, it may appear that the mechanic movement stroke is in place and yet the actual positions of the electronic rulers for the clamping unit, the injection unit and the ejector do not indicate "0" . In such case, the corresponding ruler should be zeroed. Move the cursor to the zeroing button

for [clamping unit ruler], [injection unit ruler] and [ejector ruler], and then press Key  to make zero clearing for the corresponding electronic ruler.

8. Special Function Options Page

After entering the correct password, press



Key to enter the Special Function Options Page.

The following is displayed:

Ret <<		【ChosesSpecFunc】	
MotorStpSelf	Use	EjeEndMd	Way
MotorLTimeFr	50	MldAdjUs	Lpre
MotoY- Δ	Use	CoreOutU	Way
Y- Δ Time	3.0	FeedSpd	Nuse
ManSeaInLim	Use	LibLimt	Use
FeedMldopns	Use	B/SRange	699.9
FeedKeyLock	Use		
NOTE Scope: 0.0 --- 999.9			


Descriptions on setting parameters function mode

- (1) Motor Idle Running & Automatic Stop: When [Activated] is chosen, time setting is effective and the setting range is 0-999 minutes. If the equipment has no operation within the set time period after the motor starts up, the motor is turned off automatically to protect the motor life and to save electricity charge.
- (2) Motor Y- Δ Conversion: If [Activated] is chosen, the system converts from star output to delta output when the motor starts up. The conversion time period can be set and the setting range is 0-999.9 seconds.
- (3) Manual Base Advance Limit: If deactivated, the injection base advance is not subject to stroke control. If activated, the injection base advance position is subject to the control of the limit switch X400.
- (4) Mould Opening with Melt: If activated, the mould opening can be done as soon as the cooling time expires, even if the melt has not finished taking out.
- (5) Melt Key Locking: If activated, press the melt key once and then the melting continues and will stop when the melt position is reached or the time expires. Or press the melt key once more to stop the melting.
- (6) Ejector Stop Type: [Stroke] or [Time] can be chosen. If [Stroke] is chosen, the stop is subject to the stroke. If [Time] is chosen, the stop is subject to the set time.
- (7) Mould Adjustment Activation: [Hydraulic] or [Electric] can be chosen. When [Hydraulic] is chosen, mould adjustment pressure and speed do not participate in the mould adjustment job.
- (8) Core-out Starting: can be [Position] and [processor]. When processor is chosen, then it would be up to the processor, otherwise it would be decided by position.
- (9) Lubrication alarming: can be [on] and not [Not Used]. When it is not used, if the lubrication fails to work properly, the system would not stop and continues working. Otherwise, it would change to work in manual mode and stop the engine after the cycle of the warning is elapsed.

9. Standby Function Setting Page

After entering the correct password, press  Key to enter the Standby Function Setting

Page. The following is displayed:



Descriptions on setting parameters function mode

- (1) Output Point Transfer Function: This function can be activated or deactivated. If activated, the output point executes immediately transfer operation. In case that mal-function or damage occurs to a certain point, the control can be transferred to another point by activating this function. For example, in case that failure occurs to the mould opening output point and the knockout core function is deactivated, the Y46 mould opening point can be transferred to Y66 and then the output wires should be exchanged. The system is equipped with the function of simultaneously transferring two output points. Once this function is activated, the system makes judgment on the two selected items. If the item is [ON], the transfer of the pre-set conditions of the item will be executed.
- (2) Input Point Transfer Function: This function can be activated or deactivated. If activated, the input point executes immediately transfer operation. In case that mal-function or damage occurs to a certain point, the control can be transferred to another point by activating this function. For example, in case that failure occurs to the front safety door input point and the knockout core function is deactivated, the X00 front safety door input point can be transferred to X25 and then the input wires should be exchanged. The system is equipped with the function of simultaneously transferring two input points. Once this function is activated, the system makes judgment on the two selected items. If the item is [ON], the transfer of the pre-set conditions of the item will be executed.

10. Programmable Standby Function Page

After entering the correct password, press Key  twice to enter the Programmable Page.

The following is displayed:

Ret<<		【PragBckPoint】			
NUSE	Y	73	AT	ACFL	SegOut
NUSE	Y	72	AT	ABCDEFGHIJKLMNOP	SegOut
NUSE	Y	71	AT	FL	SegOut
NUSE	Y	70	AT	C	SegOut
NUSE	Y	67	AT	CD	SegOut
NOTE		Set Scope:40---73			

Descriptions on setting parameters function mode

In order to meet diversified application needs and provide an innovative product, we take the initiative to offer the programmable standby function page so that the users can define and revise by themselves the functions and the action sequence.

Example 1: For a certain mould injection machine, due to the different design of the oil piping, it is required that a point is output while clamping at high pressure and the power will not be interrupted until the melt finishes taking out. To achieve such a special function, choose an item and have it activated, and then specify an output point (i.e. this function is output through Y xx), and then set the action sequence [CD].

Notes: Regarding the output scope of Sequence D Clamping Stop, in automatic mode, the clamping switch is contacted during the process of mould close at high pressure, and this sequence output starts until the melting finishes; in manual mode, the clamping switch is contacted during the process of mould close at high pressure, and this sequence output starts until the mould opening key or the reset key is pressed.

Example 2: For a certain mould injection machine, due to the different design of the oil piping, it is required that a point is output while injecting and melting. To achieve such a special function, choose an item and have it activated, and then specify an output point (i.e. this function is output through Y xx), and then set the action sequence [FH].

11. Temperature Parameter/Time Setting Page

After entering the correct password, press Key

温度
TEMP.

to enter the Temperature Parameter/Time

Setting Page. The following is displayed:

Ret<<		【 Set temp./Time Prams 】					
		P	D		P	D	
Ejec	Use	50	50	3Seg	Use	50	50
1Seg	Use	50	50	4Seg	Use	50	50
2Seg	Use	50	50	5Seg	Use	50	50
OiITAlrm		Use		Max	80		
03	Y	01	M	01	D	18	H
						08	M
							58
							S
							Wed.
NOTE		Return to Engineer Set					


Descriptions on setting parameters function mode

- (1) Nozzle Function: [Activated] or [Deactivated] can be chosen. If deactivated, the system will not execute inspection and control on this sequence.
- (2) Sequence I Function: [Activated] or [Deactivated] can be chosen. If deactivated, the system will not execute inspection and control on this sequence.
- (3) Sequence II Function: [Activated] or [Deactivated] can be chosen. If deactivated, the system will not execute inspection and control on this sequence.
- (4) Sequence III Function: [Activated] or [Deactivated] can be chosen. If deactivated, the system will not execute inspection and control on this sequence.
- (5) Sequence IV Function: [Activated] or [Deactivated] can be chosen. If deactivated, the system will not execute inspection and control on this sequence.
- (6) Sequence V Function: [Activated] or [Deactivated] can be chosen. If deactivated, the system will not execute inspection and control on this sequence.
- (7) Oil Temperature Selected: [Activated] or [Deactivated] can be chosen. If deactivated, once it is detected that the oil temperature is equal to or over the set upper limit, the alarm will be neglected. If activated, the alarm will be output, and the system will turn to manual mode and the motor will be turned off when the alarm cycle ends.
- (8) Pd Setting: Pd has been set before ex-factory. It is recommended that the user should not revise this parameter under normal circumstance.

12. Machine No./Ex-Factory Value Setting Page

After entering the correct password, press Key  to enter the Machine No./Ex-Factory

Value Setting Page. The following is displayed:



Ret<< 【 MachinCode/SetFacVal 】

Machine Code

PS-999999999

Revert Fac.Value

Confirm

NOTE Return to Engineer Set


Descriptions on setting parameters function mode

- (1) Mould Injection Machine No.: The system is equipped with the function of setting NO. for the mould injection machine so that the manufacturer can set the No. for easy sales management and after-sales service record.
- (2) Ex-Factory Value Restoration: During the modifying process of password pages, if normal operation cannot be achieved due to too much deviations of the modified parameters, press Key Enter and choose Confirm, and then all the contents and all the parameters will be restored to the standards values set before ex-factory.


Chapter 5 Input/Output Mode Inspection

1. Input Inspection Page


(1) Press Key  on the Main Page to enter Input Inspection Page I and the following will be displayed:




(2) Press Key  on the Main Page to enter Input Inspection Page II and the following will be displayed:




(3) Press Key  on the Main Page to enter Key Inspection Page I and the following will be displayed:



(4) Press Key  on the Main Page to enter Key Inspection Page II and the following will be displayed:




(5) Press Key  on the Main Page to enter A/D Inspection Page V and the following will be displayed:




(6) The above input inspection pages are used for signal inspection and cannot accept information modified. The solid box on the display indicates that the signals are being input.

2. Output Inspection Page


(1) Press Key  on the Main Page to enter Output Inspection Page I and the following will be displayed:



(2) Press Key  on the Main Page to enter Output Inspection Page II and the following will be displayed:




- (3) Press Key  on the Main Page to enter Output Inspection Page III and the following will be displayed:



- (4) The above output inspection pages are used for signal inspection and cannot accept information modification. The solid box on the display indicates that the signals are being output.

★ Notes:

All the input and output point pages in this instruction manual are subject to changes without notice. The inspection pages displayed on the computer should be correct and final.



Bk108 Keyboard Installation Size Diagram




Figure of Dimensions & Installation Hole Positions for Power Supply Case






Figure of Dimensions & Installation Hole Positions for Master Machine



PS 800AM Control System Power Supply Wiring Diagram



Motor Electric-Heating Wiring Diagram (for reference only)