

BESA -12PM

Battery Electrical System Analyser



User's Manual

Version PM1504

Table of Contents

1.0 Introduction	
1.1 BESA 12PM (Battery Electrical System Analyser)	3
1.2 Specifications	4
2.0 Safety Measures	
2.1 Safety Precautions	5
2.2 Other Precautions	6
3.0 Working with Batteries	7
4.0 The Battery Electrical System Analyser	
4.1 BESA 12PM	9
4.2 Key Functions	10
4.3 Functions of Individual Key	10
5.0 Initial Setup	
5.1 Paper Installation	11
5.2 Setup Menu	11
5.3 LCD Brightness	12
5.4 Printer	12
5.5 Set Date & Time	13
5.5 PC Link	13
5.7 Erase Memory	14
6.0 Battery Test	
6.1 Begin Battery Test (Automotive)	17
6.2 Battery Test for Motorcycle, Commercial Vehicle, etc.	23
7.0 Other System Test	
7.1 Starter Test	32
7.2 Alternator Test	35
Starts with No Load testing at 3,000 RPM	35
Testing with electrical load at 2,000 RPM	32
7.3 Grounding Test	41
8.0 Stored Results	
8.1 Recalling and viewing previous Test Results	45
9.0 Printing the previous Test Result from memory	48
10.0 PC Link	
10.1 Installing driver	48
10.2 Printing Results from PC Printer	53
10.3 Saving Results to PC	54
11.0 Warranty Information	
11.1 Limited Warranty	55
11.2 Limitations of Warranty	56



1.0 Introduction

1.1 BESA-12PM (Battery Electrical System Analyser):

The utilization of the latest advanced technologies in battery testing had enabled this Analyser to test batteries in any conditions. Testing procedures are made simple with quick, easy and repeatable results. Test Results can be printed directly on its' built in printer. It can store up to 300 test Results in its memory for future references and they can also be transferred and saved in the PC for records management via an USB port link.

The programs consist of:

1. Battery Test:

- Analyses the battery condition using microprocessor controlled testing methods without the need of fully charging it before test.
- The unit consumes very little current during testing hence the test can be repeated numerous times without worry of draining the battery and its results are highly accurate.
- Extremely safe as it does not create any sparks during clamp on and it takes less than 8 seconds to obtain the full analysed results of the battery being tested.

2. Starter Test:

- Checks the cranking effectiveness of the battery to predict when the battery will fail to crank a vehicle basing on voltage profiles with results and recommendations display.

3. Charging Test:

- This test checks the alternator charging condition during electrical loading at 2,000 RPM and without load at 3,000 RPM with results and recommendations displayed after each test.

4. Grounding Test:

- Analyses the condition of the electrical return circuit contacts resistance which was connected to the engine or chassis body from the battery terminal with results and recommendations displayed after testing.

1.2 Specifications:

Operating Voltage: 9V ~ 15V DC (max)

Safety: Built-in reverse polarity protection.

Analysing Capacity (Amps):

Automotive, Commercial vehicle, Marine / Watercraft:	CCA:	100A ~ 1700A	EN:	100A ~ 1000A
	IEC:	100A ~ 1700A	DIN:	100A ~ 1000A
	JIS#:	100A ~ 1700A	SAE:	100A ~ 1700A
	CA:	100A ~ 1700A		

Motorcycle, Motor Scooter, Lawn Mover, Golf cart, Snowmobile:	CCA:	40A ~ 600A	EN:	40A ~ 600A
	IEC:	40A ~ 600A	DIN:	40A ~ 600A
	JIS#:	40A ~ 600A	SAE:	40A ~ 600A
	CA:	40A ~ 600A		

DC Volts Accuracy: $\pm 1\%$ Reading

Battery analysing time: Less than 8 seconds.

Language: English only.

Memory: Stored up to 300 Test results.

PC connection: Through USB port.

Printer head: Thermo print head.

Paper width: 57.5mm \pm 0.5mm

Paper roll diameter: 45.0 mm O.D.

Printing speed: 50 mm per second.

Working temperature: 0°C ~ 50°C

Working Humidity: 10 % ~ 80 %



2.0 Safety Measures:



For safety reasons, read this manual thoroughly before operating the Tool.

Always refer to and follow the safety instructions and testing procedures provided by the car or equipment manufacturer. The safety messages presented below and throughout this user's manual are reminders to the operator to exercise extreme care when using this test instrument.

2.1 Safety Precautions:



⚠ DANGER

When the engine is running, it produces carbon monoxide, a toxic and poisonous gas. Always operate the vehicle in a well ventilated area. Do not breathe exhaust gases – they are hazardous that can lead to death.



⚠ CAUTION

To protect your eyes from propellant object such as caustic liquids, always wear safety eye protection.



⚠ DANGER

Fuel and battery vapors are highly flammable.
DO NOT SMOKE NEAR THE VEHICLE DURING TESTING.




⚠ CAUTION

When engine is running, many parts (such as pulleys, coolant fan, belts, etc) turn at high speed. To avoid serious injury, always be alert and keep a safe distance from these parts.




⚠ WARNING

Before starting the engine for testing or trouble shooting, always make sure the parking brakes is firmly engaged. Put the transmission in Park (automatic transmission) and Neutral (manual transmission).



⚠ WARNING

Always block the drive wheels.
Never leave vehicle unattended while testing.

**⚠ CAUTION**

Never lay tools on vehicle battery. You may short the terminals together causing harm to yourself, the tools or the battery.

**⚠ CAUTION**

Engine parts become very hot when engine is running. To prevent severe burns, avoid contact with hot engine parts.

**⚠ WARNING**

Do not wear loose clothing or jewelry while working on engine. Loose clothing can get caught in fan, pulleys, belts, etc. Jewelry can conduct current and can cause severe burns if comes in contact between power source and ground.

**⚠ CAUTION**

When the engine is running, be cautious when working around the ignition coil, distributor cap, ignition wires and spark plugs. They are HIGH VOLTAGE components that can cause electrical Shock.

**IMPORTANT**

Always keep a fire extinguisher readily available and easily accessible in the workshop.

2.2 Other Precautions:



- This Battery Analyser is meant for testing of 12 Volts batteries only.
- Its operating voltage is from 9V ~ 15V DC and should not be tested on 24V directly. It will cause damage the unit. For 12V x 2 batteries (in series or parallel), disconnect the connections and test them individually.
- Battery that has just been charged by the charger contains surface charge and it should be discharged by turning ON the Head lights for 3~5 minutes before testing.
- Always attached the analyser clips on the lead side of the battery terminal posts during testing so that it has a good contact. This will provide better and accurate results.

- Do not attach the analyser clips directly onto the steel bolt that tightened to the battery terminal posts; this may give inaccurate readings or inconsistent results. (Note: This also applies to all other battery testing methods.)
- If the battery terminal posts were oxidised or badly corroded and the connections were bad, the analyser will prompt you to check the connections. In this case, clean the terminal posts and performs testing directly on the terminal posts it-self.
- During testing on the battery whilst it is still in the car, make sure the engine is OFF.
- Do not store the analyser near high humidity or temperature area. Exposing to extreme temperatures will cause damage to the unit.

3.0 Working with Batteries



Lead-acid batteries contain a sulfuric acid electrolyte, which is a highly corrosive poison and will produce gasses when recharged and explode if ignited. It can hurt you badly.

When working with batteries, make sure you have plenty of ventilation, remove your hand jewelry, watch and wear protective eyewear (safety glasses), clothing, and exercise caution.

Do not allow battery electrolyte to mix with salt water. Even small quantities of this combination will produce chlorine gas that can KILL people!

Whenever possible, please follow the manufacturer's instructions for testing, jumping, installing, charging and equalising batteries.



- Never disconnect a battery cable from a vehicle with the engine running because the battery acts like a filter for the electrical system.

Unfiltered [pulsating DC] electricity can damage expensive electronic components, e.g., emissions computer, radio, charging system, etc.

Turn off all electrical switches and components; turn off the ignition before disconnecting the battery.

- For non-sealed batteries, check the electrolyte level. Make sure it is covering the plates, and it is not frozen before starting to recharge (especially during winters).
- Do not add distilled water if the electrolyte is covering the top of the plates because during the recharging process, it will get warm and expand. After recharging has been completed, recheck the level.
- Reinstall the vent caps BEFORE recharging, recharge ONLY in well-ventilated areas, and wear protective goggle.

Do NOT smoke or cause sparks or flames while the battery is being recharged because batteries give off explosive gasses.

- If your battery is an AGM or a sealed flooded type, do NOT recharge with current ABOVE 12% of the battery's RC rating (or 20% of the ampere-hour rating).

Gel cells should be charged over a 20-hour period and never over the manufacturer's recommended level or over 14.1 Volts DC.


- Follow the battery and charger manufacturer's procedures for connecting and disconnecting cables and other steps to minimize the possibility of an explosion or incorrectly charging the battery.

You should turn the charger OFF before connecting or disconnecting cables to a battery.

Do not wiggle the cable clamps while the battery is recharging, because a spark might occur, and this could cause an explosion. Good ventilation or a fan is recommended to disperse the gasses created by the recharging process.

- If a battery becomes hot, over 43.3 °C (110 °F), or violent gassing or spewing of electrolyte occurs, turn the charger off temporarily or reduce the charging rate.
- When charging the battery in the car with an external MANUAL charger, make sure that it will not damage the vehicle's electrical system or components with high voltages.

Even if this is a remote possibility, it is best to disconnect the vehicle's battery cables from the battery BEFORE connecting the charger.



4.0 The Battery Electrical System Analyser

4.1 BESA-12PM









Fig. 1

4.2 Keypad Functions:



Fig. 2

4.3 Functions of Individual key:

1.  Use this key to scroll up to the next item OR when it is in the Battery Rating mode, pressing this key once will increase the value by 5.
2.  Use this key to shift the selection tab to the right OR when it is in the Battery Rating mode, pressing this key once will increase the value by 100.
3.  Use this key to scroll down to the next item OR when it is in the Battery Rating mode, pressing this key once will decrease the value by 5.
4.  Use this key to shift the selection tab to the left item OR when it is in the Battery Rating mode, pressing this key once will decrease the value by 100.
5.  Press this ENTER key to select the function or proceed to the next step.
6.  To EXIT the function, press this key once and return to the previous screen.

7.



Press this key to print test results on the built-in Printer after a test or in View Last Test mode.

5.0 Initial Setup

5.1 Paper installation

Open the printer cover by pushing it upwards from the middle. Place the thermo paper roll into the slot with the paper edge facing up (Fig. 3a). Make sure the paper is about 20mm out when the printer cover is closed (Fig. 3b).


Fig. 3a



Fig. 3b



5.2 Setup Menu

To access into this function go to the main screen (Fig.4) as shown below, select Setup Menu (Fig. 5) and press  key.




Fig.4






Fig.5

5.3 LCD Brightness

While you are in the [Setup Menu] display, select [LCD Brightness] from the menu (Fig. 6). Once entered, the display will show as in (Fig. 7).

To increase the contrast press  key and the bar graph will move forward. Likewise to decrease, press  key while in this screen.




Fig. 6





Fig.7

Once the LCD brightness has been confirmed, press  key to save and it will return back to the [Setup Menu] screen above.




5.4 Printer

Selecting this [Printer] mode (Fig. 8) will initiate printing of the results of the last tested vehicle that has been stored in the memory.



Fig. 8

5.5 Set Date and Time

The date and time on the Analysers were set in the Factory during production. Due to the differences of the Time zone in your Country, you may need to set according to your local date & time and this can be done by selecting [Set date & time] with  or  key and the press  and the display shows as in Fig.10 below.




Fig. 9










Fig. 10

Press  or  key to change the date and then press  to skip to the next. Do this for the rest like month, year and the time. When the setting is done, press  key to save.

5.6 PC Link

This PC Link mode is used when you wish to connect BESA-12PM to PC to print or store the results of the last tested vehicle. Once the tester is connected to the PC with the USB cable provided, select [PC Link] as in Fig. 11 with  key and press  key will show as in Fig. 12.





Fig. 11



Fig. 12

5.7 Erase Memory

This Analyser is able to save up to 300 test results in its memory. In event that you need to clear all the results in the memory to make for new ones after they had been backed up into the PC, then select this item [Erase Memory] and press  key to enter into it. Once entered, the display will show as in Fig.13 below:




Fig. 13





Fig. 14

To erase the memory, now press  key and it will proceed with the erasure as shown in Fig. 14 above. After completion, it will return to the setup menu (Fig.11)

6.0 **Battery Test**

Performing Battery Test while it is still on the car (Automotive Only)

Vehicle that was running has to have its engine OFF first and then switch ON the headlights for 30 seconds to remove the surface charge. After the headlights had switched OFF, let the battery rest for at least 1 minute to recover before testing commences.


The car engine and all other accessory loads must be **OFF** during test in order to have accurate results. When attaching the analyser clips, make sure that the battery posts were not oxidized or badly corroded. Clean them first before clamping to it. Do not clamp onto the steel bolts directly which may give inaccurate and inconsistent results.

Testing on stand-alone batteries (Motorcycle & Others)

Clean the battery posts with a wire brush prior testing. For side post batteries, install stud adaptors. Do not use steel bolts for better results.


1. Attach the Analyser clips onto the battery terminal posts [Red to (+) and Black to (-)] the unit will power up and lights up the LCD display screen as shown (Fig.15).

Fig.15



2. It will run through a self-test and when completed it displays the Main Menu as shown: (Fig. 16)

Fig.16



Here, it will let you select your choice from the Menu:

New Test

This function will allow you to key in the particulars (e.g. license plate numbers, names, etc) that you need before commencing the test. The particulars will be included in the test results when printed out from its printer. It also allows the test Results to be saved in its memory which can be called up for later viewing and printout.

Note: If you do not key in any particulars (e.g. license plate number, etc.) the results obtained will not be saved in the memory.

Other System Test



This selection consists of three individual tests namely: **Starter Test**, **Charging Test** and **Grounding Test**.

Selecting anyone of these Tests will require to key in the particulars (e.g. licenses plate numbers, names, etc) before commencing the test and it will be included in the test results when printed out. It will also be saved as well in the memory which can be called up for later viewing and printout.

Note: If you do not key in any particulars (e.g. license plate number, etc.) the results obtained will not be saved in the memory.

Stored Results

The Analyser allows saving up to 300 tested Results in its memory. Access into this function will permit you to view the tests done previously and also able to print out a hardcopy of it whenever needed.

Use  or  keys to scroll for the pages during viewing.

Examples of the results:




Fig.17





Fig. 18

6.1 Begin Battery Test (Automotive)

1. After you have made your choice, selecting "New Test" will proceed to the display below: (Fig. 19)

Fig.19





3. Here it lets you to key in the particulars (e.g. license plate number, etc.) that you need to be included into the test report when printed out after the test and it also serves as the name for the record to be saved in its memory for easy search.
4. To key in the alphabets or numbers, keep pressing or key to scroll from X,Y,Z,-,.,/,0,1,2,3,... in a loop sequence and stop it when found. Press key to move to the next or key to move backwards to continue the key in.

Note: If you do not input any particulars and straight away press key to continue, then the test results will not save in its memory.



5. After completion of the input, press key will proceed to the next display as shown in Fig. 20 below.

Fig.20



Here it will let you select the type of battery construction that you are testing. Once it has been selected, press  key to proceed.

- The next display (Fig. 21) below will ask the type of application that the battery being used.



- On the [Application] menu above, if “Automotive” is selected, then the display will change to as shown Fig.22 above. Here it offers a selection of:

In vehicle

This test can be performed on cars only with the battery fixed on. The Analyser will test the Battery, the Starter and the Alternator charging conditions of the car in an automatic, one after another sequence manner. It will prompt you all the way until completion of the full test.

Outside vehicle

Selecting this item will only test the Battery only whether the battery is inside the car or outside.



- After you had made your choice, pressing  key will proceed to do the battery testing and if it has detected any surface charge on the battery, it will start to remove it and a message is shown (Fig. 23) below.

Fig. 23



9. If the surface charge is too great for the analyser to handle, it will prompt you with the instructions as shown: (Fig. 24) below and the beeper will sound continuously.

Fig. 24

Battery surface
charge is present!

Turn the ignition key
to ON position.

Switch ON the
headlights to remove
surface charge.


10. Wait until the surface charge removal had completed, the analyser will advise as follows: (Fig.25) and then press  key.

Fig. 25

Battery surface
charge has been
removed.

Turn ignition key to
OFF position.

Switch OFF the
headlights and then
press [Enter].

11. If there is no surface charge present, then it will straight away enter into "Select Rating" menu screen as shown in Fig. 26

Fig. 26

Select Rating ▼▲

CCA

SAE

DIN

JIS

IEC

EN

CA

Unknown

12. Before selecting the ratings 'CCA, SAE, EN, IEC, DIN, CA and JIS #' from the menu, check the battery specification value. This value can be checked on the battery labels as some of the examples shown below:



If it is selected under JIS # (Japanese Industrial Standard) then the display will prompt you as shown (Fig.27) below.

Figure 27

Please refer to the charts provided for converting JIS# to CCA ratings before keying in the values.

Press [Enter] to continue...

Refer to the battery model (example: 80D26L or NX110-5L) on the Cold Cranking Amps (CCA) Table list which is supplied separately. (See example Fig.28 below.)

Battery Model (JIS#)		CCA			Battery Model (JIS#)		CCA		
NEW	OLD	WET	MF	CMF SMF	NEW	OLD	WET	MF	CMF SMF
50D20R		310	380	480	80D26L	NX110-5L	580	580	630
50D20L		310	380	480	85B60K				500
50D23R	85BR60K	500			85BR60K				500
50D23L	85B60K	500			95D31R	NX120-7	620	660	850
50D24R	NT80-S6	390			95D31L	NX120-7L	620	660	850
50B24L	NT80-S6L	390			95E41R	N100	515	640	770
50D26R	50D20R		370		95E41L	N100L	515	640	770

Figure 28

Press  key and the display will show: (Fig.29) below:

Figure 29

Input Battery Rating

Increase/decrease:

▲ Single digit ▼

◀ By hundredth ▶


100 CCA

Press [Enter] to proceed.

13. Referring to the Table list (Fig.28) basing on 80D26L, check the battery type: WET, MF, Sealed MF or Closed MF (CMF) as each category has different CCA ratings. For instance, if the battery is a Sealed MF (CMF) then it is rated at 630 CCA.

Note:

- WET - Wet Cell Type
- MF - Maintenance Free Type
- SMF - Closed or Sealed Maintenance Free






14. To enter the value 630, press  key will increase the original value of 100 (Fig.29) by step of 100 units to 600. Likewise use  key to increase the last two digits (00) to 30 by step of 5 units for each pressing. (See Fig. 30)

Fig. 30





Once the CCA rating of the battery is confirmed, press  key will start the testing process. Refer to the display below (Fig. 31).

Fig. 31



15. For less than 8 seconds, the results of the testing will be displayed on the LCD screen. (Fig. 32)





Fig.32

16. This Analyser will also takes the temperature of the battery into consideration when it has detected that the battery condition is marginal (below 75%) and it will prompt you with the display as shown (Fig. 33) below:

Fig.33





17. Here it let you to select the surrounding temperature that you are working with the battery. If the surrounding temperature is for example 15°C, then select [Above 0°C] by pressing  key and then press  key. Then the results will show on the LCD display.

Fig.34

To print out the results, just press  key on the Analyser, the printer will start printing.




6.2 Battery Test for Motorcycle, Commercial vehicle, etc.

To test motorcycle batteries or others, it is better to test with the battery taken out from the vehicle battery compartment for better results. This is mainly due to the obstruction of the wires that were attached to the battery terminals and the tester clamps may not clip properly due to lack of space at its terminals thereby may cause false test results.


1. While it is on the Main Menu as shown: (Fig. 35)





Fig.35





2. Select "New Test" will proceed to the display below: (Fig. 36)

Fig.36



3. To key in the alphabets or numbers, keep pressing  or  key to scroll from X,Y,Z,-,.,/,0,1,2,3,... in a loop sequence and stop it when found. Press  key to move to the next or  key to move backwards to continue the key in.

Note: If you do not input any particulars and straight away press  key to continue, then the test results will not save in its memory.

- After completion of the input, press  key will proceed to the next display as shown in Fig. 20 below.






Fig.37

Here it will let you select the type of battery construction that you are testing. Always refer to the table provide if you are not sure. Once it has been selected, press  key to proceed.

- The next display (Fig. 38) below will ask the type of application that the battery being used. Select [Motorcycle] if you are testing motorcycle battery and then press  key. Once entered, it will proceed to display Fig.39 as shown below:




Fig.38




Fig.39

- Before selecting the ratings 'CCA, SAE, EN, IEC, DIN, CA and JIS from the menu, check the battery model. This can be checked on the battery labels as some of the examples shown below:



With the battery model in hand, refer to the Battery rating chart (as seen in this example Fig.38 below) provided in separate copies with the Tester when purchased, to get values to be keyed in.

Battery Model	AH	CCA		Battery Model	AH	CCA	
		WET	AGM			WET	AGM
YT4L-4	3		50	YTZ12S-BS	11		210
YT7B-4	6.5		110	YTZ14S	11.2		230
YT7B-BS	6.5		110	YTZ14S-BS	11.2		230
YT9B-4	8		120				

Fig.38

3. If the rating CCA is confirmed, pressing  key will show: (Fig.39) below:

Fig. 39

Input Battery Rating

Increase/decrease:

▲ Single digit ▼

◀ By hundredth ▶

40 CCA

Press [Enter] to proceed.

4. For Example:

If the motorcycle battery is model YT9B4 (Type: AGM, 120CCA) as refer to the above table (Fig.38).



To enter the value 120, press  key will increase the original value of 40 (Fig.39) by step of 100 units to 140. Likewise use  key to decrease the last two digits (40) to 20 by step of 5 units for each pressing. (See Fig. 40)

Fig. 40

Input Battery Rating


Increase/decrease:

▲ Single digit ▼

◀ By hundredths ▶

120 CCA

Press [Enter] to proceed.

Once the CCA rating of the battery is confirmed, press  key will start the testing process. Refer to the display below (Fig. 41).




Fig. 41

5. For less than 8 seconds, the results of the testing will be displayed on the LCD screen. (Fig. 42)




Fig.42

6. This Analyser will also takes the temperature of the battery into consideration when it has detected that the battery condition is marginal (below 75%) and it will prompt you with the display as shown (Fig. 43) below:




Fig.43

7. Here it let you to select the surrounding temperature that you are working with the battery. If the surrounding temperature is for example 15°C, then select [Above 0°C] by pressing ▼ key and then press ↩ key. Then the results will show on the LCD display.




Fig.44

Interpretations of the above (Fig.44) results:

1. **Battery: Good**

A very straight forward display of the final results basing on the evaluation of the tested condition. [Good] indicates the battery in top condition. [OK Recharge] indicates that the battery is in good condition but need to recharge to give its maximum performance. [Replace] indicates that the battery needs to be replaced. If not, the battery will fail anytime without any warning.

2. **Rating: 120 CCA**

The battery capacity rated output is normally stated on the label for car batteries. For other batteries, please refer the chart provided or check on information provided on the label.

3. **Measured: 95 CCA**

It means that the battery tested has a capacity of 95 CCA power available. CCA ratings has been used here, therefore the tested result is in CCA and if other rating (DIN, SAE, JIS, IEC, CA, or EN) were selected, it will base on the respective rating to calculate and show the results in that selected rating.

4. **Volts : 12.60V**

The volts here indicated the State of Charge (SOC) of the tested battery which is 12.60V during open circuit condition. [75% SOC for AGM batteries by referring to the table below.]

SOC	WET	GEL	AGM
100 %	12.60V or higher	12.85V or higher	12.80V or higher
90 %	12.58 V	12.77 V	12.72 V
80 %	12.44 V	12.69 V	12.64 V
75 %	12.40 V	12.65 V	12.60 V
50 %	12.20 V	12.35 V	12.30 V

Please take Note:

This output value (95 CCA) is related to the actual power available in the battery in relation to that battery's rating (120 CCA). On average, a new battery's CCA as measured by this tester will read 10-15 % higher than its stated rating.

As the battery ages, the CCA number measured by this tester will decrease so it reads near its rating. While this value is not the same as a CCA test, it is the best available measurement for showing a battery's current condition in relation to its rating.

From the above example, a 120 CCA rated battery measuring 95 CCA available power does not mean that the battery would pass a CCA test at 95 CCA. The available power reading shows that the battery is not able to perform up to its rated ability (120 CCA).

In comparison to another battery when fully charged, the 120 CCA battery measuring 95 CCA is no stronger than a 90 CCA battery showing 90 CCA available power when fully charged.

The available power number is meant for comparison to its own rating. In fact, in this example the 120 CCA battery is failing to perform to its rating, while the 90 CCA battery is still working.

Basing on SAE, CCA test is a manufacturing process control test applicable only on new, fully charged batteries. It does not produce an actual value, but is a PASS / FAIL test.

It measures the discharge load, in amps, that a battery can supply for 30 seconds at 0°F/-18°C while maintaining a voltage of 1.2 volts per cell (7.2 volts per battery) or higher.

Thus, the CCA test shows the minimum power requirement for the battery as rated, which means a battery rated at 90 CCA must measure 7.2 volts or above for 30 seconds when a load of 90 amps is applied at 0°F / -18°C.

The above methods also hold for DIN, IEC, JIS, EN basing on its individual ratings.

5. Int. R (Internal Resistance): 28.42 mΩ

In normal condition, the internal resistance for motorcycle batteries should fall between 4.5 mΩ ~ 65.0 mΩ. As for cars, the internal resistance will be from 2.0 mΩ to 15.0 mΩ. As a matter of fact, the higher the battery CCA readings obtained the lower the internal resistance should be.

6. LIFE: 69 % (Health)

This is an indication of the battery life (State of Health) in percentage. If the LIFE falls below 60%, the RESULT will display "Replace" and it is time to change to a new battery.

Explanation of the following terms used as shown on the LCD display:

- **CCA (Cold Cranking Amps) – most commonly used Standard.**
CCA is a rating used in the battery industry to rate a battery's ability to start an engine in cold temperatures. This rating is the number of amperes that a new fully charged battery can delivery at 0°F (-18°C) for 30 seconds, while maintaining a voltage level of 7.2 Volts for a 12V battery during cranking.
- **SAE (The Society of Automotive Engineers) Standard.**
SAE has established Cold Cranking Amperes (CCA) rating for batteries as their standard. Therefore this rating is the same as CCA rating as mentioned above.
- **IEC (International Electro technical Commission) Standard.**
IEC rating require that at 0°F (-18°C), the number of amperes that the 12V battery can deliver while maintaining a voltage level of 7.5V for 10 seconds and 7.2V for 30 seconds during cranking.
- **EN (European Norm) Standard.**
EN 1 rating require that at 0°F (-18°C), the number of amperes that the 12V battery can deliver while maintaining a voltage level of 7.5V for 10 seconds, stop for 10 seconds and continue with 60% load with maintaining voltage level of 7.2V for 70 seconds during cranking (Total time: 90 seconds).
- **JIS# (Japanese Industrial Standard)**
JIS # amperes' rating is based on Ampere Hours and is calculated using 20 hours rating. In this manual, it is using CCA ratings reference table list provided basing on the JIS model number (See page 29 & 30).
- **DIN (Deutsches Industrie Normen) Standard.**
Basing on DIN , the rating requires that at 0°F (-18°C), the 12V battery is able to deliver the number of amperes while maintaining a voltage level of 9.0 Volts for 30 seconds and 8.0 Volts for 150 seconds during cranking.
- **CA (Cranking Amperes) Rating.**
This rating is the number of amperes that a new fully charged battery can delivery at 32°F (0°C) for 30 seconds, while maintaining a voltage level of 7.2 Volts for a 12V battery during cranking.
- **Unknown**
If you are not sure which ratings (CCA, EN, IEC, JIS or DIN) that the battery is based on, then choose this setting. It will show the battery's Voltage (State of Charge), CCA and the Internal Resistance (m Ohm) only. This selection can also be used to test 12V - Deep Cycle Batteries.

An example of the results display is shown below: (Fig.45)







Fig.45

To determine the condition of the tested Deep Cycle Batteries, refer the **Volts** reading – State of Charge (*should not fall below 12.60V when fully charged for Lead Acid Batteries, 12.85V for Gel Batteries and 12.80V for AGM Batteries*) and the Internal Resistance [**Int. R**] of the tested battery *should not be more 15 mOhm* readings.


Batteries that had been left idle for long periods can still be tested with this analyser. To perform the test, just clamp the analyser clips onto the battery terminals and it will display the screen (Fig.46) as shown if its voltage falls below the normal 12.0 volts.

Fig.46



Press  key to continue and the display will show: (Fig.47)

Fig.47



Check the battery ratings and enter it as described in steps 13 to 15 (page 20~21) and the results will show as an example below: (Fig. 48 and Fig.49)






Fig.48 - Results shown [OK-Recharge], it indicated that the battery has to be fully charged first before repeating the test.

For Fig.49, the Results shown [To replace], this meant that the battery need to be replaced as its internal plate resistance [**Int. R**] is higher than 15.0 mOhm.

- Pressing the  key at any moment will exit and return back to the main menu screen (Fig.35).

7.0 Other System Test

When this item is selected, it will allow you to select one of the three Tests namely: Starter Test, Charging Test and Grounding Test:

7.1 Starter Test

- With engine OFF, place the vehicle transmission in NEUTRAL for Manual and PARK for Automatic then apply the parking brake.
- Connect the analyser to the battery terminals and the display will light up as shown (Fig 50) below:




Fig.50




Fig.51

3. Selecting [Starter Test] (Fig. 51) will proceed to the display below: (Fig. 52)

Fig.52

4. Here it let you key in the particulars (e.g. license plate number, etc.). To key in the alphabets or numbers, keep pressing or key to scroll from X,Y,Z,-,.,/,0,1,2,3,... in a loop sequence and stop it when found. Press key to move to the next or key to move backwards to continue the key in.


Note: If you do not input any particulars and straight away press key to continue, then the test results will not save in its memory.

5. After completion of the input, press key will proceed to the next display as shown in Fig. 53 below.

Fig.53

6. Switch the ignition key to ON and start cranking the engine until it starts. Immediately after that press key and the results will show as follows (Figure 54):

Fig.54




```
Result: OK
Battery:    12.45V
Min. Volts: 10.56V
Volt Drop: Normal

[Exit] to Menu.
```

7. If the voltage drop is too great during the cranking, the tested results will display as follows (Fig.55) and will prompt you to check the starter system.

Fig.55




```
Result: High Drop
Battery:    12.45V
Min. Volts: 8.56V
Volt Drop: High

Check starter relay,
battery terminals or
battery has aged.

[Exit] to Menu.
```

8. During cranking when it detects that there is no drop in voltage, it will display the following screen (Fig.56).


Fig.56



```
Result: Not detected
Battery:    12.45V
Starter test fail!

No change in volt
drop. Check clamping
at battery side and
test again.


[Exit] to Menu.
```

6. Pressing the  key at any moment will exit and return back to the main menu screen. (Fig.50)

7.2 Alternator Test

This test is to check the MAX and MIN charging voltages output of the alternator at 3000 RPM without load and 2000 RPM with all loads ON. With this test you can determine the alternator's condition when in reference with the vehicle's Service Manual.

Starts with No load testing at 3,000 RPM

1. With engine OFF, place the vehicle transmission in NEUTRAL for Manual and PARK for Automatic and apply the parking brake.
2. Attach the Analyser clips onto the battery terminal posts and it will power up and lights up the LCD display screen as shown (Fig.57). Press  key and the display will show as Fig. 58 below.




Fig.57




Fig.58

3. Select [Alternator Test] and it will proceed to the display below: (Fig. 59)









Fig.59

4. Here it let you key in the particulars (e.g. license plate number, etc.). To key in the alphabets or numbers, keep pressing  or  key to scroll from X,Y,Z,-,.,/,0,1,2,3,... in a loop sequence and stop it when found. Press  key to move to the next or  key to move backwards to continue the key in.

Note: If you do not input any particulars and straight away press  key to continue, then the test results will not save in its memory.




After completion of the input, press  key will proceed to the next display as shown in Fig. 60 below.


Fig.60





Start the engine and then press  key again and the screen will prompt you as shown below (Fig. 61).

Fig. 61



Follow the instructions, make sure that all loads (lights, air-condition, etc) are OFF. Rev the engine up to **2,500 ~ 3,000 RPM** by referring to the dashboard meter, then press  key and maintain the engine speed for about 10 seconds and release the pedal. The maximum and minimum voltages values will be captured.

After that press  key again and it show as below (Fig. 62)



With the captured readings, analysis can be done by Fig.62 to the limits as indicated that **MAX voltage should not exceed 15.0V** (max. voltage at 3,000 RPM) and **MIN voltage should be more than 13.3V** (min voltage during idling speed).



5. Press  key will show the results of the test (Fig.63):

Fig.63



6. If either minimum or maximum charging volts are not within the voltage range limits then it will display one of the screen as below (Fig.64 & 65) and it will prompt you to check the charging system for the fault.




Fig.64




Fig.65

Testing with electrical load at 2,000 RPM

As more electrical accessories, such as lights, rear demister, heater, car stereos, etc. were used; the electro-motive force decreases and this will allow more amperage from the alternator to flow into the battery to compensate for the added load. This test is to check the alternator's behavior during loading.


- 7. Continue from the previous test (either Fig. 63, 64 or 65); proceed to the next step by pressing  key will enter to the display as follows. (Fig.66)


Fig.66

Loading Test

Switch ON all electrical loads.
Rev engine up to 2,000 rpm. Press [Enter].Hold on to this 2,000 rpm for 10 seconds and release the pedal.

Follow the instructions; switch ON all electrical loads (Head Lights, Radio, Rear Demister, Heater, etc).

Note: Air-Condition (mostly mechanical load) should be OFF as it sometimes slowdown the idling speed of certain cars while it is ON thereby affecting the idling speed charging results.

Rev the engine up to **1,500 ~ 2,000 RPM** by referring to the dashboard meter, then press  key and maintain the engine speed for about 10 seconds and release the pedal. The maximum and minimum voltages values will be captured. (Fig.67)

Loading Test

At 2,000 rpm:
Av. Volts: 13.3V
Max. >13.5V: 13.8V
Min. >12.5V: 12.8V

Press [Enter] for results.


Normal Charging range limit.

Average Charging volts.

Captured Volts readings

Fig. 67

With the captured readings, analysis can be done by referring to the limits as indicated that **MAX voltage should exceed 13.5V** (max. voltage at 2,000 RPM) and **MIN voltage should be more than 12.5V** (min voltage during idling speed).

After that press  key again and the results will be shown as below (Fig 68.)




Fig.68

8. If either minimum or maximum charging volts are not within the voltage range limits then it will display one of the screen as below (Fig.69 & 70) and it will prompt you to check the alternator system for the fault.




Fig.69






Fig. 70

11. Just press  key if you need to print out the results.

12. Continue from the previous test (either Fig. 68, 69 or 70); the display will automatically switch to Diode Ripple Test (Fig.17) as below:


Fig. 71



13. Make sure the electrical loads (Headlights, High beams, heaters, etc) are switched ON. **[Important Note: Do not switch ON the Air Conditioner as it may affect the results].** Let the engine runs at idling speed. Do not Rev.

14. Then press  key to continue. The display will show: (Fig. 72)

Fig. 72



15. After analysing, the analyser will display the results Fig.73 or Fig.74 depending on the outcome.




Fig. 73




Fig. 74


16. Just press  key if you need to printout the results.
17. To exit the program, pressing the  key at any moment will exit and return back to the main menu screen (Fig.57).

7.3 Grounding Test

The engine body and the vehicle chassis are always connected to the battery negative terminal to provide the electrical return path (grounding) for all the electrical components. Due to the surrounding environmental effect, the surface contacts of these joints or connections of these circuits will subject to oxidation and corrosion in a matter of time rendering them to have high resistance in it. One typical example is the connection at the battery terminals where oxidation and corrosion takes place very often. If these contacts were no good then it will pose a lot of electrical problems to the vehicle.

To check the grounding condition, this Analyser will measure the resistance from the engine body contact to the battery terminal then it will display the results and the recommendations.

Start Testing

1. With engine OFF, place the vehicle transmission in NEUTRAL for Manual and PARK for Automatic and apply the parking brake.
2. Attach the Analyser clips onto the battery terminal posts and it will power up and lights up the LCD display screen as shown (Fig.75). Press  key and the display will show as Fig. 76 below.




Fig.75




Fig.76

3. Select[Grounding Test] and it will proceed to the display below: (Fig. 77)





Fig.77

4. Here it let you key in the particulars (e.g. license plate number, etc.). To key in the alphabets or numbers, keep pressing or key to scroll from X,Y,Z,-,.,/,0,1,2,3,... in a loop sequence and stop it when found. Press key to move to the next or key to move backwards to continue the key in.

Note: If you do not input any particulars and straight away press key to continue, then the test results will not save in its memory.


After completion of the input, press key will proceed to the next display as shown in Fig. 78 below.

Fig.78




5. Now transfer the BLACK tester clip from the battery [-] terminal to a suitable position on the engine or chassis body leaving the RED clip still attached to the battery [+] terminal.
6. Press key again and it will starts analyzing (Fig. 79)
- 7.

Fig.79




8. Once it has finished analysing, it will prompt you with an instruction (Fig. 80) stating that you should unclamp the Black tester clip from the engine or chassis body and transfer to the battery negative [-] terminal within 20 seconds time limit if not the testing procedure has to be repeated again as the gathered data will be lost.


Fig.80



9. Once the Black clip is clamped onto the battery [-] terminal, the Analyser display will light up as shown. (Fig. 81)

Fig.81



10. Now you need to press  key to proceed and the display will show as follows (Fig. 82).
- 11.






Fig.82





12. If the measured resistance reading is within limits, then it will display as follows (Fig. 83)

Fig.83



13. If the measured resistance reading has gone beyond the limits, then it will display the screen as follows (Fig. 84).

Fig.84



Note:

The above indicates that the ground contact from the engine body to the battery is bad. Check for rusted or corroded point of contacts. If found, dismantle it for cleaning or replace before fixing back. Repeat the test again after fixing.

Another thing is that if you suspect that the result is in question, you may conduct the test with the Black clip clamp at different location.


14. If you did not follow the right procedures during the testing, it will display the results as follows (Fig. 85) below:

Fig.85

Results: Not detected
Grounding test
Failed!

Try again and follow
the step by step
instructions given.

[Exit] to Menu.

15. Just press  key if you need to printout the results.

16. To exit the program, pressing the  key at any moment will exit and return back to the main menu screen (Fig.75).

8.0 – Stored Results


8.1 Recalling and viewing previous Test Results

To view the results of the last test, BESA-12PM has to be connected to an external power source by either clamping its clips directly to a 12Volt car battery or connected to a PC via the USB port.

Fig.86


1. Once power up, the wakeup screen will display as follows:

Fig.87



2. It will run through a self-test and when completed it displays the Main Menu as shown: (Fig. 88)

Fig.88





3. Pressing  key to scroll down to the [Stored Results] as shown in Fig. 89 below.

Fig.89





4. Press  key will proceed to the display on a list of the recorded names (particulars that was keyed in earlier) for you to select as an example shown below (Fig.90).

Fig.90








5. Select it by pressing  or  key. If you do not find the name then press  or  key to continue to the next page in event that it is full.
6. Once selected, the display will show the date with time and particulars that you have selected and keyed in during the test done. (Fig. 91).

Fig.91



Press  key will proceed to show the test results.

Some examples of the Results are shown below are: (Figs. 92 & 93)

Fig.92






Fig.93



9.0 Printing the previous Test Results from Memory

To print out the previous results from its memory, select [Stored Results] from the menu. Access to the recorded names (example: Fig.90), select and press  key will display the results.


To print just press  key on the Analyser, the printer will start printing

Important:

The Analyser has to be connected to a 12V battery in order to work with the mobile printer. This is because the printer needs higher Amps to operate which the PC USB output is unable to provide.

Note:

To printout on PC printer, it has to be connected to the PC with BESA-12PM software installed. (See Print Results from PC Printer – Page 52).

To exit the program, pressing the  key at any moment will exit and return back to the main menu screen (Fig.89).

10.0 PC Link

BESA-12PM is also designed to link with PC for data storage and printout through PC printer. To do so, the PC has to install the driver and the software provided in order to operate.

10.1 Installing Driver.


Important Note:

Before you start to install the driver, please do not plug BESA-12PM into the computer's USB port or else the installation will fail and the computer cannot detect the proper driver for BESA-12PM when connected.


If you have made the above error and wish to install the driver the second time, you need to uninstall the previously installed driver first before starting to reinstall again. This time make sure that BESA-12PM is not plugged in.


Step 1. You can install the driver from the CD provided or download it from our website:
<http://www.aetool.com/productshow.asp?id=1055&sortsid=0&categoryid=219>


First click to open the folder:




You will find the following files:




Step 2. Double click on the icon . The installation will start automatically. Typical example below is for Windows 7 operating system.



As instructed, click [Next>] tab the program will continue to install the driver on the computer. Once it had finished, it will prompt you as shown below. Click [Finish] tab to complete the installation.



Step 3. Next open this folder again:



Look for the program icon (see below).



Then double click it. The software will start to install and will prompt with the display below:

Then double click it. The software will start to install and will prompt. See example below:



Click “OK” tab to continue the installation and the software will start to install.

A few seconds later, the display will show as below that the installation has been completed and click “Finish” tab to exit.




Once the software has been installed, the icon



will appear on the desktop.

Step 4. Now plug the Analyzer into any one of the PC USB port.

Step 5. On the PC, go to desktop display and look for  icon. Left click on the icon to open the program and the display page will show as below:

Step 6. Now link up BESA-12PM with PC by the following procedures:



1. On the Main Menu page (Fig. 94) below, select [Stored Results] by pressing  key to highlight it and then press  key.

Fig.94




2. The display (Fig. 95) will show a list of the particulars that you had keyed in prior to the test. Select by scrolling  or  key and then press  key. The display will change to as shown in Fig.91.

Fig. 95


Fig.96

Particulars:	
15/04/2014	10:55
ADC8899L	
Automotive	
Regular Wet (Pb/Pb)	
Outside Vehicle	

3. While on this display (Fig.96) click on [Get Data from Analyser] tab on the PC and the Test Result will appear. See example below.

You can type in the particulars here and then click [Add to Test Report] tab to be included in the test report which will be stored and printed out if you wish.

4. If you need to view another test result, press key to go back to the display as shown in Fig.95.
5. Select the next test Result and press key, and as usual the display will go to the particulars screen (Fig.96). Now press key again will display the results.
6. ON the PC, click "Get Data from Analyser" tab and the results will be transferred to the PC.



If there is no communication, a message text box will appear (see below)




In this case, unplug the Analyzer from the PC and repeat Step 4 to Step 6. If problem persists, then select an alternate COMPORT individually from the dropdown list and click [Get Data From Analyser] tab to see whether the Last Test Result will appear (as displayed in Step 6 No.4).

If the above fails again, then try plugging the Analyzer to the PC's another USB port and repeating Step 4 to Step 6 again.

10.2 Printing Results from PC Printer:


While on this page, if you wish to print out the results, make sure that your printer is connected to the computer. Click on [PRINT] tab and a text box will appear. Select the right printer and click [Print] tab to print.



Select the printer which is connected to your computer here.



10.3 Saving Results to PC:

If you wish to save the results from this page, then click on [SAVE AS] tab. A message box will appear. Type in the file name and click [Save] tab.



After you had completed saving the first result and wish to save the next one, you should press  key on the Analyser to the display as shown in Fig.90. Select the one on the list shown on the screen that you want and then press  key to proceed to the 'particulars' screen (Fig.91).

Again, you have to click "Get Data from Analyser" tab on the PC to transfer the results data to be saved.

Disclaimer

All information, illustrations, and specifications contained in this user manual are based on the latest information available at the time of printing. The right is reserved to make any changes at any time without obligation to notify any person or organization of such revisions or changes.

Furthermore, the manufacturer or its sales agents are not liable for errors contained herein or for incidental or consequential damages (including lost profits) in connection with the furnishing, performance or use of this material.

This user manual tells how to use and perform the required procedures on vehicles. Safe and effective use of this Analyser is very much dependant on the user following the normal practices and procedures outline in this manual.

11.0 Warranty Information

11.1 Limited Warranty

This limited warranty cover defects in materials and workmanship for a period of twelve (12) months which begins from the date the product is purchased by the end user and is subjected to the following terms and conditions:

1. Within the warranty period, the manufacturer will repair or replace, at their options, any defective parts and return to the owner in good working condition.
2. Any repaired or replaced parts will be warranted for the balance of the original warranty or three months (3) months from the date of repair, whichever is longer.
3. This warranty only extends to the first owner and not assignable or transferable to any subsequent owner.
4. Cost of delivery charges incurred for the repair of the product to and from the manufacturer will be borne by the owner.
5. This limited warranty covers only those defects that occur as a result of normal use and do not cover those that resulted from:
 - Unauthorized modifications and repair.
 - Improper operation or misuse.
 - Accident or neglect such as dropping the unit onto hard surfaces.
 - Contact with water, rain or extreme humidity.
 - Contact with extreme heat.
 - Broken cables, bent contact pins or subject to extreme stress or wear.
 - Physical damage to the product surface including scratches, cracks or other damage to the display screen or other externally exposed parts.



11.2 Limitations of Warranty

Other than the foregoing limited warranty, the manufacturer does not make any other warranty or condition of any kind, whether express or implied.

Any implied warranty of merchantability, or fitness for use shall be limited to the duration of the foregoing limited warranty.

Otherwise, the foregoing limited warranty is the owner's sole and exclusive remedy and is in lieu of all other warranties whether express or implied.

The manufacturer or any of its exclusive sales agents shall not be liable for any consequential or incidental damages or losses arising from the loss of the product.

All warranty information, product features and specifications are subjected to change without prior notice.

