

User Manual

PON OLT Series

PON 8510



Headquarters:
No. 25, Alley 15, Lane 120,
Sec. 1. Nei-Hu Rd,
Taipei 114, Taiwan
TEL: 886-2-26583000
FAX: 886-2-26583232

Beijing Branch:
3F, A Building,
113 Zhi Chun Lu,
HaiDian District,
Beijing, China
Zip Code: 100086
TEL: 86-10-62522081~87
FAX: 86-10-62522077

Version: 1.0
Date: 2007/11/16
P/N: 07008-00105

Copyright © 2007 TAINET COMMUNICATION SYSTEM CORP.

All right reserved

Notice

This document is protected by the international copyright law. No part of this publication may be reproduced by any means without the permission of Tainet Communication System Corporation.

TAINET is a registered trademark, and PON 8510 is trademarks of Tainet Communication System Corporation.

Other product names mentioned in this manual are used for identification purposes only and may be trademarks or trademarks of their respective companies.

The information provided from Tainet Communication System Corporation is believed to be accurate. Any changes and enhancements to the product and to the information thereof will be documented and issued as a new release to this guide.

Trademark

All products and services mentioned herein are the trademarks, service marks, registered trademarks or registered service marks of their respective owners.



About This Manual

This section guides users on how to use the manual effectively. The manual contains information needed to install, configure, and operate TAINET's PON OLT Series. The summary of this manual is as follows:

Chapter 1: Overview

Chapter 2: Specification

Chapter 3: Basic Operation

Chapter 4: More Advanced Configuration

Chapter 5: Maintenance

Chapter 6: Monitor

Appendix A: Console PIN Assignment

Appendix B: Command Line Mode



Symbols Used in This Manual

3 types of symbols may be used throughout this manual. These symbols are used to advise the users when a special condition arises, such as a safety or operational hazard, or to present extra information to the users. These symbols are explained below:

**Warning:**

This symbol and associated text are used when death or injury to the user may result if operating instructions are not followed properly.

**Caution:**

This symbol and associated text are used when damages to the equipment or impact to the operation may result if operating instructions are not followed properly.

**Note:**

This symbol and associated text are used to provide the users with extra information that may be helpful when following the main instructions in this manual.



LIMITED WARRANTY

TAINET's DISTRIBUTOR shall be responsible to its customers for any and all warranties, which it makes relating to Products, and for ensuring that replacements and other adjustments required in connection with the said warranties are satisfactory. TAINET warrants to DISTRIBUTOR that the Products to be delivered hereunder will be free of defects in material and workmanship under normal use and service for a period of twenty-four (24) months [twelve (12) months in Taiwan] following the date of shipment to DISTRIBUTOR.

If during the warranty period, any component part of the equipment becomes defective by reason of material or workmanship, and DISTRIBUTOR notifies TAINET of such defect within seven days after knowing of such defect, TAINET shall, for any Product that TAINET agrees is defective, at its option, supply a replacement part, request return of equipment to its plant for repair, or perform necessary repair at the equipment's location. At TAINET's option, DISTRIBUTOR shall destroy any Product that TAINET agrees is defective and shall provide satisfactory proof of such destruction to TAINET. TAINET is not responsible for Products damaged by misuse, neglect, accident or improper installation, or if repairs or modifications were made by persons other than TAINET's own authorized service personnel, unless such repairs by others were made with the written consent of TAINET.

THE ABOVE WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED. THERE ARE NO WARRANTIES THAT EXTEND BEYOND THE FACE HEREOF, INCLUDING, BUT NOT LIMITED TO, WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, AND IN NO EVENT SHALL TAINET BE LIABLE FOR CONSEQUENTIAL DAMAGES. If DISTRIBUTOR extends to its customers any additional warranty with respect to Products that is broader in scope than the warranty provided by TAINET, DISTRIBUTOR shall be solely responsible for any and all liabilities, obligations and damages resulting from the extension of such warranty.

TAINET shall not be liable to any person for any special or indirect damages, including, but not limited to, lost profits, from any cause whatsoever arising from or in any way connected with the manufacture, sale, handling, repair, maintenance or use of the Products, and in no event shall TAINET's liability exceed the purchase price of the Products.

Software Products are provided "as is" and without warranty of any kind. TAINET disclaims all warranties including the implied warranties of merchantability and fitness for a particular purpose. TAINET shall not be liable for any loss of use, interruption of business or indirect, special, incidental or consequential damages of any kind. TAINET shall do its best to provide end users with Software updates during the warranty period under this Agreement.

TAINET has not been notified of any intellectual property rights or others which may be infringed by the Products or the promotion, marketing, sale (or resale), or servicing thereof in the Territory, but TAINET makes NO WARRANTY, EXPRESS OR IMPLIED, WITH RESPECT THERETO.



CONTENT

CHAPTER 1. OVERVIEW	1
1.1 OVERVIEW	1
CHAPTER 2. SPECIFICATION	5
2.1 PON INTERFACE	5
2.2 NNI INTERFACE	6
2.3 MANAGEMENT INTERFACE	7
2.4 CRAFT INTERFACE	8
2.5 FEATURE AND SPECIFICATION	9
2.6 OPERATION ENVIRONMENT	10
2.6.1 Power requirement	10
2.6.2 Temperature	10
2.6.3 Humidity	10
CHAPTER 3. BASIC OPERATION	11
3.1 CONFIGURATION	12
3.1.1 System	12
CHAPTER 4. MORE ADVANCED CONFIGURATIONS	15
4.1 CONFIGURATION	15
4.1.1 OLT	15
CHAPTER 5. MAINTENANCE	21
5.1 SYSTEM	21
5.1.1 Firmware Upgrade	21
5.1.2 Device Maintenance	22
5.1.3 Log	22
5.1.4 Save Configuration	22
5.2 OLT	24
5.2.1 Testing	24
CHAPTER 6. MONITOR	27
APPENDIX A CONSOLE PIN ASSIGNMENT	29
APPENDIX B COMMAND LINE MODE	31



FIGURE

FIGURE 1-1 PON NETWORK STRUCTURE	1
FIGURE 1-2 FRONT PANEL OF OLT DEVICE.....	2
FIGURE 1-3 REAR PANEL OF OLT DEVICE	3
FIGURE 3-1 LOGIN INTERFACE	11
FIGURE 3-2 GENERAL INFORMATION OF SYSTEM.....	12
FIGURE 3-3 CLOCK OF SYSTEM	13
FIGURE 3-4 IP ADDRESS OF SYSTEM.....	13
FIGURE 3-5 USERS INFORMATION OF SYSTEM	14
FIGURE 4-1 GENERAL INFORMATION OF OLT.....	15
FIGURE 4-2 BRIDGE TABLE	16
FIGURE 4-3 MULTICASTING MANAGEMENT.....	16
FIGURE 4-4 PORT STATUS OF OLT MODULE.....	17
FIGURE 4-5 PVID INFORMATION	17
FIGURE 4-6 QoS CONFIGURATION OF OLT	19
FIGURE 4-7 TRAFFIC CONFIGURATION OF OLT.....	20
FIGURE 4-8 VLAN CONFIGURATION OF OLT.....	20
FIGURE 5-1 FIRMWARE UPGRADE.....	21
FIGURE 5-2 DEVICE MAINTENANCE	22
FIGURE 5-3 SYSTEM LOG FUNCTION	22
FIGURE 5-4 SAVE CONFIGURATION.....	23
FIGURE 5-5 TESTING.....	24
FIGURE 5-6 ONU SELECTING.....	24
FIGURE 5-7 MESSAGE OF TESTING RESULT	25



TABLE

TABLE 1-1 LEDS STATUS INDICATION	2
TABLE 2-1 PON INTERFACE.....	5
TABLE 2-2 NNI INTERFACE.....	6
TABLE 2-3 MANAGEMENT INTERFACE	7
TABLE 2-4 CRAFT PORT.....	8
TABLE A- 1 RJ-45 TO DB-9 PIN ASSIGNMENT	29

Chapter 1. Overview

1.1 Overview

“Ethernet Passive Optical Network” (hereafter called “EPON Network”) comprises an Optical Line Terminal (OLT) system using its individual OLT to interconnect with one or more specific groups of Optical Network Units (ONUs) via a corresponding number of Passive Optical Distribution Networks (ODNs) to construct a broadband point-to-multipoint access network between central office and customer premises. A Server Provider can provide the broadband triple play services by way of the EPON Network, such as high-speed Internet access, VoIP and IPTV services. The PON network diagram is as shown as Figure 1-1.




Figure 1-1 PON network structure

There are two modules can be inserted into the OLT device, each module has four PON interfaces and four NNI (Gigabit Ethernet) interfaces. The maximum capacity of OLT device is up to eight NNI interfaces and eight PON interfaces.

The NNI interface of OLT is used to uplink to core network through physical GE (Gigabit Ethernet) link. One PON interface connects OLT to splitter through an optical fiber and each splitter can be divided into 16 or 32 optical links each connected with one ONU. Subscriber's network can be connected to the UNI interface of ONU device by physical FE (Fast Ethernet) medium.

On the right side of front panel, there is a MPU module with two management ports and craft port for OLT as well as ONU devices configuring. Through the management ports (MGMT 1 or MGMT 2) on the MPU, administrator is able to configure the device by web interface mode. The pin assignment of craft port is as Appendix A .

The LEDs of front panel indicate the status as following:

Table 1-1 LEDs status indication

LED	Function
PWR (green LED)	When OLT power is on , light PWR LED
ALM (red LED)	When power or fan fail , light ALM LED
NNI (GE) interface *4	GE port for NNI link (1~4 ports)(w/LNK & ACT LED)
Management interface*2	LAN port for management (w/LNK & ACT LED)
PON Link (green LED)*4	Indicating OLT PON port link (1~4 ports)

There is an RST button on each module to reset its configurations to default values.




Figure 1-2 Front panel of OLT device




Figure 1-3 Rear panel of OLT device

The power requirement of OLT device is ether AC or DC.



Chapter 2. Specification

2.1 PON Interface

Table 2-1 PON interface

Item	Parameter
Transmitter Center wavelength	1490nm(1480 to 1500 nm)
Transmitter Spectrum width	Compliant with IEEE 802.3ah
Transmitter Average Launched Power	+2~+7 dBm
Receiver Center wavelength	1310nm(1260 to 1360 nm)
Receiver Minimum Sensitivity	-28dBm
Receiver Input Saturation Power (Overload)	-6.5dBm
Connector type	SC
Data rate	1.25Gbps
Transmission distance	20Km
Transmission method	Single fiber, bi-direction transmission (2-wavelength WDM)



2.2 NNI Interface

Table 2-2 NNI interface

Item	Parameter
Supported standards	Support auto-negotiation, 1000Base-T Full duplex only
Number of ports	4
Connector	RJ45
Type of cable	Cat.5e , auto MDI/MDI-X

2.3 Management Interface

Table 2-3 Management interface

Item	Parameter
Supported standards	Support auto-negotiation, 10/100 Base-T
Number of ports	2
Connector	RJ45
Type of cable	Cat.5 , auto MDI/MDI-X



2.4 Craft Interface

Table 2-4 Craft port

Item	Parameter
Supported standards	RS232C
Number of ports	1
Baud rate	38400
Connector	RJ45
Type of cable	Need RJ45 to DUB9 adapter



2.5 Feature and Specification

- Full compliance to IEEE 802.3ah (Clause 64 and Clause65)
- Complete processing and generation of MPCP control messages
- Point-to-point emulation between each ONU and OLT using LLID (logical link identifier)
- IEEE 802.1D compliance bridging
- Support of up to 8K MAC address learning table
- Configurable two QoS mode of operation : 802.1p and DSCP
- Traffic profile derived from the service level agreement (SLA) with two configurable parameters per ONU
 - Committed Information Rate (CIR)
 - Peak Information Rate (PIR)
- Support of eight priority classes
 - Strict priority (SP) or weighted round-robin (WRR) or SP+ WRR scheduling
- Intelligent Dynamic Bandwidth Allocation (DBA) algorithms
- Per-ONU based upstream traffic policing and downstream traffic shaping and policing
- Support multicast shaping feature to shape specified multicast group stream
- Support ONU remote upgrade
- Support IGMP v1/v2 protocol
- Support of up to 512 multicast group addresses
- In-band management based on Ethernet OAM frames and Ethernet frames
- Full compliance with IEEE 802.3ah OAM function
- Support per-ONU based OAM loopback
- Security management including 802.1x authentication (future)
- Support downstream traffic AES or Churning encryption (future)



2.6 Operation Environment

2.6.1 Power requirement

AC: 90~264VAC, 50/60Hz, Input (90W)

DC: -36~-72VDC, Input (92W)

2.6.2 Temperature

Operating +0°C ~ +50°C

Storage -25°C ~ 75°C

2.6.3 Humidity

Operating 5% ~ 95% non-condensing

Storage 0% ~ 75% non-condensing

Chapter 3. Basic Operation

Administrator can configure the device through web browser by connecting PC to the Management ports (MGMT1 or MGMT2) of device. The default IP address of device is 192.168.0.1. Administrator can modify the IP address through command line mode or web configuring mode. Please refer to Appendix B for configuring IP address through command line mode.

On web configuring mode, the default login user name and password for administrator are: **admin** and **admin**, respectively.

The connection between OLT and ONU device is shown as Figure 1-1.

NOTE: All the OLT and ONU devices must only be configured through the management port.




Figure 3-1 Login interface

There are three main menu pages on the web interface: **Configuration**, **Maintenance** and **Monitor**.



3.1 Configuration

3.1.1 System

3.1.1.1 General

For viewing the general information such as: software, hardware and firmware information, administrator can go to the **General** submenu.

The screenshot shows the TAINET GEPON-OLT web interface. The top navigation bar includes 'Configuration', 'Maintenance', and 'Monitor'. The left sidebar has 'System', 'OLT', and 'ONU' options. The main content area is titled 'Configuration > System > General'. It contains a form with the following fields and values:

System Name	test1
Location	Taipei
Contact	nickclaus@yahoo.com
System Up Time	2007-11-06 09:57:52
Hardware Version	1.0
Firmware Version	1.02b
Kernel Version	1.00
Number of OLTs Online	2
Number of ONUs	2 / 0 (Online/Offline)

Below the form is a 'Dual Power Disable' checkbox. An 'Apply' button is located to the right of the Contact field.

Figure 3-2 General information of system

3.1.1.2 Clock

To configure or modify the correct time and date of device, administrator can go to the **Clock** submenu. Administrator can Key in the correct information and press **Apply** button to activate it.



Figure 3-3 Clock of system

3.1.1.3 Host IP

To configure or modify the network IP of device, administrator can go to the **Host IP** submenu.



Figure 3-4 IP address of system

3.1.1.4 Users

To change the default user name and password, administrator can go to the **Users** submenu. Three roles for different logging levels can be selected. **Admin** has not only the highest authority to configure the device but also change other users' name as well as password. **Operator** has the permission as **Admin** but not include changing other users' name and password. **User** only has the permission of reading.




Figure 3-5 Users information of system



Chapter 4. More Advanced Configurations

4.1 Configuration

4.1.1 OLT

4.1.1.1 General

This submenu shows the general information of OLT module as Figure 4-1 shown:

Status	OLT - 1	OLT - 2
Startup Time	2007-11-06 14:23:22	2007-11-06 14:23:21
Status	On Line	On Line
Version		
Chip version	2.0	2.0
Image version	02.00.03-1192179790	02.00.03-1192179790

Figure 4-1 General information of OLT

4.1.1.2 Bridge

Administrator can select either OLT1 or OLT2 to configure static or dynamic FDB table. The dynamic FDB learning mode is active after enabling **Learning Enable** field and pressing **Apply** button. Administrator can manual adding one static **destination MAC** address, **VLAN ID** and **Egress Port** to the FDB table, It is active after press **Add** button.

NOTE: the range of **Agging Time** is 0~1048 seconds. The maximum entry of Static FDB is 32.



Figure 4-2 Bridge table

4.1.1.3 Multicasting

Administrator can select either OLT1 or OLT2 to configure static or dynamic Multicast mode (default is dynamic mode). Administrator also can specify one or more NNI port(s) to enable Multicast traffic on the port(s). The system supports either IGMPv1 or IGMPv2 (default is IGMPv2).

Administrator can enable the function of multicast traffic shaping by enabling **Action** and specifying any desire limit rate. It is active after pressing **Apply** button.




Figure 4-3 Multicasting management



4.1.1.4 Port

Administrator can force either NNI or PON port of OLT to be activated or not.

The screenshot shows the configuration page for OLT ports. On the left is a navigation menu with 'Port' selected. The main content area is titled 'Configuration > OLT > Port' and has two tabs: 'OLT - 1' and 'OLT - 2', with 'OLT - 2' being active. Under the 'NNI Port' section, there are four rows for NNI - 1 to NNI - 4. Each row has an 'Admin Status' dropdown menu set to 'Up' and an 'Oper Status' field showing 'Up'. An 'Apply' button is at the bottom right of this section. Under the 'PON Port' section, there are four rows for PON - 1 to PON - 4. Each row has an 'Admin Status' dropdown menu set to 'Up' and an 'Oper Status' field. PON - 1 shows 'Up', while PON - 2, PON - 3, and PON - 4 show 'Down'. An 'Apply' button is at the bottom right of this section.

Figure 4-4 Port status of OLT module

4.1.1.5 PVID

To prevent any untagged packet from dropping by OLT, administrator can manually add VLAN ID to one or more specified NNI port(s). Any VLAN ID can not be added if it was not specified in the VLAN submenu, in advance. Please refer to the section 4.1.1.8.

NOTE: The VLAN ID administrator aim to insert must be added to VLAN submenu in advance and the range of VLAN ID is 1~4094.

The screenshot shows the configuration page for OLT PVID. On the left is a navigation menu with 'PVID' selected. The main content area is titled 'Configuration > OLT > PVID' and has two tabs: 'OLT - 1' and 'OLT - 2', with 'OLT - 2' being active. Under the 'Port VLAN ID' section, there is a label 'Each NNI PVID' followed by four input fields numbered 1, 2, 3, and 4. Each field contains the number '1'. An 'Apply' button is at the bottom right of the section.

Figure 4-5 PVID information



4.1.1.6 QoS

On this submenu, administrator can select the QoS criteria mode, queue mapping, default CoS queue, default 802.1p value and the scheduling mode of frame in egress.

Administrator can select one active module to configure it by alternating OLT-1 or OLT-2. Administrator determines the QoS mode by selecting either **DSCP** or **802.1p** mode, and then press the **Apply** button.

For the QoS Mapping item, administrator can set the **DSCP** or **802.1p** to output queue mapping table. The three most significant bits of the packet's DSCP [0:2] value is used for the mapping (IP precedence) and the allowed range is 0~7. The greater number it is, the higher priority it has. Administrator can assign each priority (0 ~ 7) to the same or different queue.

Administrator can set the default **802.1p** value to a VLAN tagging packet. The default value is 0. The default **CoS** value is used for mapping a packet to an output queue when QoS mode is **802.1p** and the packet is untagged. The value of **CoS** can not be set when QoS mode was set to **DSCP** and the packet was not recognized as the IP packet. In this scenario, therefore, the value is referred to the default 802.1p value and its queue mapping.

For selecting the frame egress scheduling mode, there are three modes can be selected:

- **Strict Priority:** All top priority frames are egress a port until that priority queue is empty, and then the next lower priority queue frames are sent out.
- **WRR (Weighted Round Robin):** Weights from 1 to 255 can be selected for each of the 8 queues. The utilization of each queue is scaled to its own weight value.
- **Hierarchical mode:** queue 7 and 6 are in strict priority and remaining queues are in WRR mode.

Figure 4-6 QoS configuration of OLT

4.1.1.7 Traffic

Select one OLT entity, **enable** or **disable** the Flow Control then press **Apply** button to activate or inactivate the Flow Control function. It will generate 802.3x PAUSE frame on the NNI port after enabling **Flow Control**.

In DBA mode, there are three items can be selected:

- **WorkConserv**: As long as sufficient bandwidth is available in a cycle and there are no other contending ONUs , an ONU may get as much bandwidth as its demand. In other word, the bandwidth allocated to an ONU is not upper-bounded by its PIR value.
- **NonWorkConserv**: an ONU never get more bandwidth than PIR value even if there is spare bandwidth available.
- **CBR**: the CIR value is allocated on the each registered ONU even if its demand for this cycle is less than this value.




Figure 4-7 Traffic configuration of OLT

4.1.1.8 VLAN

Administrator can add one VLAN ID to the specified NNI and/or PON port(s). The packet with a VLAN ID will be forwarded to the designated port assigned with the same VLAN ID or it will be drop if OLT didn't find any matching entries in the VLAN Table. For example: administrator aim to tag one **VLAN ID: 3000** to any packets through **NNI-3** and **PON-3** ports. Therefore administrator keys in **3000** on the **VLAN ID** field and check **NNI-3** and **PON-3**. Finally, press the **Add** button to make it available.

NOTE: The maximum entry of VLAN table is 512.




Figure 4-8 VLAN configuration of OLT


Chapter 5. Maintenance

The main purpose of this menu is to do system maintenance such as firmware upgrading, configuration saving, system reboot...etc.

5.1 System

5.1.1 Firmware Upgrade

Please connect the TFTP server to the management port through Ethernet link, first. To upgrade the firmware of system, administrator has to specify the correct IP address of TFTP server and the file name of firmware, then, press **Apply** button.



The screenshot shows a web interface for configuring the firmware upgrade. At the top, there are three tabs: Configuration, Maintenance, and Monitor. The Maintenance tab is selected. Below the tabs, there is a breadcrumb trail: Maintenance > System > Firmware Upgrade. On the left side, there is a vertical menu with the following items: System, OLT, ONU, Firmware Upgrade (highlighted), Device Maintenances, Save Configuration, and Log. The main content area contains two input fields: 'TFTP Server IP Address' with the value '192.168.0.200' and 'Ramdisk File Name' with the value 'firmware201'. An 'Apply' button is located to the right of the second input field, with a mouse cursor pointing to it.

Figure 5-1 Firmware upgrade

5.1.2 Device Maintenance

Press the **Apply** button to reboot the system or restore the system to default value.




Figure 5-2 Device maintenance

5.1.3 Log

This submenu provides system log and download the log to one's PC. The system log is recorded when the **Log Enable** is set to **Enable** after pressing **Apply** button. Press the **Download** button to download the log information to administrator's PC.




Figure 5-3 System log function

5.1.4 Save Configuration

Go to this submenu to save configuration of OLT or ONU if any value was modified.




Figure 5-4 Save configuration

5.2 OLT

5.2.1 Testing

Go to the OLT >>Testing submenu to test any ONU unit connected to the OLT entity.



Figure 5-5 Testing

Press << **Select ONU** >> button to select one ONU entity, which will be tested. On the list of ONU units, click one ONU you aim to test (it's MAC or Name will be displayed on bold) and return to the **OLT Testing** submenu. Press **Apply** button to see the testing result. Administrator can specify the size and count number for the testing.




Figure 5-6 ONU selecting

The testing result will be shown as following if OLT got response from ONU unit:




Figure 5-7 Message of testing result

Chapter 6. Monitor

Administrator can view major event logs through the **Event Log** submenu.

Monitor > Event Log

Page 1 ▾

No.	Entity	Type	Time
1	ONU-00:90:bb:14:52:f4	On Line	2007-09-29:13:37:01
2	ONU-00:90:bb:14:53:14	On Line	2007-09-29:13:37:01
3	OLT-1-PON-1	PON port up	2007-09-29:13:36:59
4	OLT-2-PON-1	PON port down	2007-09-29:13:36:56
5	ONU-00:90:bb:14:53:14	Off Line	2007-09-29:13:36:56
6	ONU-00:90:bb:14:52:f4	Off Line	2007-09-29:13:36:56
7	ONU-00:90:bb:14:52:f4	On Line	2007-09-29:13:36:48
8	ONU-00:90:bb:14:53:14	On Line	2007-09-29:13:36:48
9	OLT-2-PON-1	PON port up	2007-09-29:13:36:46
10	OLT-2-PON-1	PON port down	2007-09-29:13:36:41
11	ONU-00:90:bb:14:53:14	Off Line	2007-09-29:13:36:41
12	ONU-00:90:bb:14:52:f4	Off Line	2007-09-29:13:36:40
13	ONU-00:90:bb:14:53:14	On Line	2007-09-29:13:36:25
14	ONU-00:90:bb:14:52:f4	On Line	2007-09-29:13:36:25
15	OLT-1	On Line	2007-09-29:13:36:23
16	OLT-2	On Line	2007-09-29:13:36:22
17	SYS-PWR-2	Power failure	2007-09-29:13:36:13

Appendix A Console Pin Assignment

RJ-45 to DB-9 pin assignment is as following:

Pin Number	Description	Note
1	NC	
2	NC	
3	RXD	DUB9 pin2 (Output)
4	GND	DUB9 pin5
5	TXD	DUB9 pin3 (Input)
6	NC	
7	NC	
8	NC	

Table A- 1 RJ-45 to DB-9 pin assignment



Appendix B Command Line Mode

Administrator can login to PON 8510 through craft port(Speed:38400, Data bit: 8, Parity: No, Stop bit: 1, Flow control: No) on the front panel to configure the device. The default user name is: **root** and password is: **admin**.

There are two items can be specified on the command line mode. The first one is to specify the network configuration. Administrator can specify the network configuration of the device before entering the mode of web setting interface.

➤ For example:

EPON login: root

Password: *****

=====

GEPON

=====

login[54]: root login on `tty'

1) Modify Network Configuration

2) Show Event Log

3) Restore to default

>1

IP Address (172.16.5.191):**192.168.0.118**

Netmask (255.255.255.0): **255.255.255.0**



Default Gateway (172.16.5.254): **192.168.0.1**

New system configuration

IP Address: 192.168.0.118

Netmask: 255.255.255.0

Default Gateway: 192.168.0.1

Apply these settings? (Y/N): **y**

Apply system configuration succeed

Save settings? (Y/N): **y**

Saving system settings ok.

Bye!

➤ The second item is to show event logs of the device.

1) Modify Network Configuration

2) Show Event Log

>2

n: last n records from now

n=10

Event log total 10 entries: timestamp entity type

2007-09-28:13:40:04 OLT-2-NNI-3 NNI port up

2007-09-28:13:40:04 OLT-2-NNI-4 NNI port up

2007-09-28:13:40:04 OLT-2-PON-1 PON port up



```
2007-09-28:13:40:04 OLT-1-NNI-1 NNI port up
2007-09-28:13:40:04 OLT-1-NNI-2 NNI port up
2007-09-28:13:40:04 OLT-1-NNI-3 NNI port up
2007-09-28:13:40:05 OLT-1-NNI-4 NNI port up
2007-09-28:13:40:06 ONU-00:90:bb:14:53:14 On Line
2007-09-28:14:26:15 SYS-FAN-1 Fan fail
2007-09-28:14:26:39 SYS-FAN-1 Fan normal

Bye!
```

➤ The third item is to restore configuration to default.

1) Modify Network Configuration

2) Show Event Log

3) Restore to default

>3