

MCU *Scribe*[™]

**XL36
Programming
Adapter Board
User's Manual**

How to Reach Us:

Home Page:

www.freescale.com

E-mail:

support@freescale.com

USA/Europe or Locations Not Listed:

Freescale Semiconductor
Technical Information Center, CH370
1300 N. Alma School Road
Chandler, Arizona 85224
+1-800-521-6274 or +1-480-768-2130
support@freescale.com

Europe, Middle East, and Africa:

Freescale Halbleiter Deutschland GmbH
Technical Information Center
Schatzbogen 7
81829 Muenchen, Germany
+44 1296 380 456 (English)
+46 8 52200080 (English)
+49 89 92103 559 (German)
+33 1 69 35 48 48 (French)
support@freescale.com

Japan:

Freescale Semiconductor Japan Ltd.
Headquarters
ARCO Tower 15F
1-8-1, Shimo-Meguro, Meguro-ku,
Tokyo 153-0064
Japan
0120 191014 or +81 3 5437 9125
support.japan@freescale.com

Asia/Pacific:

Freescale Semiconductor Hong Kong Ltd.
Technical Information Center
2 Dai King Street
Tai Po Industrial Estate
Tai Po, N.T., Hong Kong
+800 2666 8080
support.asia@freescale.com

For Literature Requests Only:

Freescale Semiconductor Literature Distribution Center
P.O. Box 5405
Denver, Colorado 80217
1-800-441-2447 or 303-675-2140
Fax: 303-675-2150
LDCForFreescaleSemiconductor@hibbertgroup.com

Information in this document is provided solely to enable system and software implementers to use Freescale Semiconductor products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits or integrated circuits based on the information in this document. Freescale Semiconductor reserves the right to make changes without further notice to any products herein. Freescale Semiconductor makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does Freescale Semiconductor assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters which may be provided in Freescale Semiconductor data sheets and/or specifications can and do vary in different applications and actual performance may vary over time. All operating parameters, including "Typicals" must be validated for each customer application by customer's technical experts. Freescale Semiconductor does not convey any license under its patent rights nor the rights of others. Freescale Semiconductor products are not designed, intended, or authorized for use as components in systems intended for surgical implant into the body, or other applications intended to support or sustain life, or for any other application in which the failure of the Freescale Semiconductor product could create a situation where personal injury or death may occur. Should Buyer purchase or use Freescale Semiconductor products for any such unintended or unauthorized application, Buyer shall indemnify and hold Freescale Semiconductor and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that Freescale Semiconductor was negligent regarding the design or manufacture of the part.





Contents



1 Getting Started

- Installing the MCUscribe application and personality files 6
 - Installed files 6
 - Installing Acrobat Reader 7
- Inserting XL36 programming adapter boards 7
- Inserting XL36 MCUs 8
 - Disconnecting power before inserting an MCU 8
 - Inserting a QFP MCU 9
 - Inserting an SDIP MCU 10

2 Using the XL36 Programming Adapter Board

- XL36 devices and mask sets 12
- MCU memory configuration 13
 - 908XL36 MCU memory 13
 - 708XL36-secured MCU memory 14
- Adjusting the device supply voltage 14
- Restrictions and limitations 16

3 Support

Opening additional online documentation 18

Contacting customer support 19

1

Getting Started

Who needs to read the XL36 Programming Adapter Board User's Manual?

Refer to the XL36 Programming Adapter Board User's Manual if you have purchased an XL36 programming adapter board (PAB), and want information about:

- Installing software and setting up the XL36 PAB for use
- XL36-specific operation instructions
- Getting additional support

This chapter explains how to install the software that comes with your XL36 PAB, and how to plug in the XL36 PAB and the MCUs it supports.

Installing the MCUscribe application and personality files

The XL36 PAB comes with the latest version of the MCUscribe application (for Windows[®] NT and Windows 95). First, install the software:

Insert the first MCUscribe diskette in your floppy drive, and enter **a:\setup.exe** in the Windows **Run** dialog box. The installation setup program opens.

Follow the instructions to install the software in a folder of your choice. The installation program places all the MCUscribe files in one folder. Using a single folder expedites selection of the MCU and S-record files, so that you can start programming more quickly.

Installed files

These files are installed on your host system:

- **MCUscribe.exe** — Windows executable file for the MCUscribe application—the interface you use to communicate with the SPGMR08, and to program MCU memory.
- **.mmp** files — The personality files that supply the SPGMR08 with MCU configuration and memory map information. *908XL36.mmp* and *708XL36.mmp* are the personality files for XL36-supported MCUs.
- **MCUscribe.hlp** and **MCUscribe.cnt** — Online help for using the MCUscribe application.
- **MCUscribe.pdf** — *Serial Programmer for HC08 User's Manual*. Instructions for using the MCUscribe application (help information in an Acrobat-format user's manual).
- **QStart08.pdf** — *SPGMR08 QuickStart Guide*. A streamlined guide (in Acrobat format) to setting up SPGMR08 hardware and software.
- **PABXL36.pdf** — *XL36 Programming Adapter Board User's Manual*. A short manual (in Acrobat format) that contains specific instructions for setting up and using the XL36 PAB. The software may also include user manuals for other PABs.
- **readme.txt** — Release notes in ASCII format (text from *QStart08.pdf*)

For tips about opening online support documents, see [page 18](#).


Installing Acrobat Reader

You must have Acrobat Reader™ installed on your host system in order to view and print the *Serial Programmer for HC08 User's Manual* and other Acrobat-format support documents. The Reader is supplied on a separate set of diskettes. To install the Reader:

Insert the first Reader diskette in your floppy drive, and enter **a:\setup.exe** in the Windows **Run** dialog box. The installation setup program opens. Follow the instructions to install the software in a folder of your choice.

Inserting XL36 programming adapter boards

To use the XL36 programming adapter board, plug the PAB onto the SPGMR08 base unit (as shown in the illustration below). The PAB works when installed in either direction on the SPGMR08 base unit. That is, the connector on the base unit labeled **Pin 1** can accept either connector of the adapter board.



Inserting XL36 MCUs

Disconnecting power before inserting an MCU

If power is disconnected, you can insert or remove MCUs freely. However, if you are in an MCUscribe session, make sure the yellow Socket Power light is off before you handle the MCU. MCUs can be damaged by power surges during installation.

If the Socket Power light is on, click the **Power Off** button in the MCUscribe Control Panel. Socket power is disconnected, and the yellow Socket Power light goes off.


Inserting a QFP MCU

The illustration below shows a QFP MCU ready to be inserted in the PAB:

- 1 Open the socket case by lifting the latch on the left.
- 2 Insert the MCU, matching the MCU's pin 1 with the socket's pin 1. The marked corner of the MCU identifies the location of pin 1. If you turn the PAB so that the Motorola logo is at the bottom, pin 1 is in the socket's upper left corner. (The printed number **1** on the back side of the programming adapter board corresponds to the location of the socket's pin 1.)

Note: Motorola recommends that you use a vacuum pen or other appropriate tool to handle MCUs. Be careful to avoid bending the pins.

- 3 Push the socket lid down gently until it snaps shut.



Inserting an SDIP MCU


The illustration below shows an SDIP MCU ready to be inserted in the PAB:

Insert the MCU, matching the MCU's pin 1 with the socket's pin 1. The marked corner of the MCU identifies the location of pin 1. The printed number **1** shows the location of the socket's pin 1.

Note: Motorola recommends that you use a vacuum pen or other appropriate tool to handle MCUs. Be careful to avoid bending the pins.

The MCU's pin 1 is left of the half-moon depression. The pin 1 corner is also marked with a recessed dot on some devices.

The socket's pin 1 is identified by a **1** printed on the board.



2

Using the XL36 Programming Adapter Board

This chapter has specific information about using the M68PAL908XL36 (XL36) programming adapter board. The XL36 PAB enables the SPGMR08 to program:

- Flash EEPROM memory ranges of MC68HC908XL36 (908XL36) microcontroller units (MCUs) in 64-pin Quad Flat Pack (QFP) or 56-pin Shrink DIP (SDIP) package configurations.
- EPROM memory ranges of MC68HC708XL36 (708XL36) MCUs in 64-pin Quad Flat Pack (QFP) or 56-pin Shrink DIP (SDIP) package configurations.


Note: If you need information about support for other XL36 MCU masks, contact Motorola customer support (see "[Contacting customer support](#)" on page 18).

XL36 Devices and Mask Sets

Device	Mask set	Device supply voltage (VDD)	Personality file	Selected MCU / Mask choice
MC68HC908XL36	2H68R	5V (± 10%)	908XL36.mmp	908XL36 H68R
MC68HC708XL36	2H17F	3V (± 10%)	708XL36.mmp	708XL36 H17F
	3H17F	5V (± 10%)		

The table above lists XL36-supported devices and mask sets, with these types of corresponding information:


- **Device supply voltage (VDD)** — The voltage you can use for a particular device and mask set. For information about testing or changing this voltage, see "[Adjusting the device supply voltage](#)" on page 14.
- **Personality file** — The files that supply configuration and memory map data for programming the various XL36-supported MCUs and mask sets. To program a particular mask set, the corresponding personality file for that mask set must be installed on the host system.
- **Selected MCU/Mask choice** — The entry you select during an MCUscribe session, from the Control Panel's *Selected MCU* list (shown in the illustration below).



MCU memory configuration


908XL36 MCU memory

The 908XL36 MCU has 36 KB of programmable Flash EEPROM memory and 34 bytes of vector memory. MCUscribe's Memory Map status box (shown below) displays the location of the Flash EEPROM memory arrays.



708XL36-secured MCU memory

The 708XL36 MCU has 36 KB of programmable EPROM memory and 34 bytes of vector memory. MCUscribe's Memory Map status box (shown below) displays the location of the EPROM memory array.



Adjusting the device supply voltage

You can adjust the device supply voltage (VDD) of the XL36 programming adapter board to match the voltage in your target application. The XL36 programming adapter board can program MCUs at a range of voltages.

To measure the current device supply voltage, use the test point (labelled **E1**):


- 1 Begin an MCUscribe session, and select the MCU.

Note: To measure device supply voltage, you must first establish communications between the software and the MCU. When the base unit's yellow Socket Power light is on, communications are established.

- 2 Connect a voltmeter to pin **1** (VMCU) and pin **3** (GND—ground). Read the device supply voltage on the meter.

To change the device supply voltage, turn the screw on top of the voltmeter with a screwdriver.

The variable resistor is in a blue case, with the words **VOLTAGE ADJUST** printed next to it. The test point is marked **TEST PT.**, and printed numbers identify pin 1 and pin 3.



Note: For more information about voltage ranges appropriate for your device, see its *General Release Specification*.

Restrictions and limitations

This restriction applies to the XL36 programming adapter board:

908XL36 PAB programming voltage: The 908XL36 PAB supports 3 to 5 volt programming; however, the currently available 908XL36 device functions only at 5 volts.

3

Support

This chapter explains how to open information resources online, and how to contact customer support.

Opening additional online documentation

Acrobat-format documents

The MCUscribe application comes with a user's manual in Acrobat PDF format, along with the latest version of the Acrobat Reader. There are a number of online resources (described on [page 6](#)) that you can open from Windows Explorer by double-clicking the file name:

- *Serial Programmer for HC08 User's Manual* — **MCUscribe.pdf**
(You can also double-click the manual icon in the MCUscribe program group.)
- *XL36 Programming Adapter Board User's Manual* (online version) — **PABXL36.pdf**
- *SPGMR08 QuickStart Guide* — **QStart08.pdf**

Online help

Open MCUscribe help directly from the desktop, or from within the application. (Make sure you have installed the **MCUscribe.hlp** file and the **MCUscribe.cnt** files in the same folder.) You can use any of these methods to open MCUscribe help:

- Double-click the help icon in the MCUscribe program group.
- Double-click the **MCUscribe.hlp** file in Windows Explorer, if *.hlp* files are associated with *Winhlp32.exe*.
- Click the **Help** button in the MCUscribe application, or press **F1**.

Contacting customer support

Contact the Motorola software support team by telephone, FAX, regular postal mail, or through the Worldwide Web.

Telephone: 1-800-521-6274 (Customer Focus Center)

Telephone support hours are Monday through Friday,
9:00 a.m. to 5:00 p.m. (CST).

FAX: (602) 302-8157 (Customer Focus Center)

Website: <http://www.design-net.com/csic>

(68HC05 and 68HC08 8-bit Microcontroller Home Page)

For software upgrades, choose **Development Tools**,
then **Free Software Upgrades/Assemblers**.

For more MCU products, see: **<http://www.mcu.motsp.com>**
(Embedded Microcontroller Products page)

Mailing address: MCTG Software Support
Motorola, Inc. MD OE45
6501 William Cannon Drive West
Austin, Texas 78735