



# PowerFlex<sup>®</sup> 700S Adjustable Frequency AC Drive - Phase I (Frames 1 - 6)



## Introduction

This document is designed to guide you through the basic steps needed to install, start-up, and program the PowerFlex<sup>®</sup> 700S Adjustable Frequency AC - Phase I drive for Frames 1 - 6. **The information provided in this document does not replace the user manual and is intended for qualified personnel only.** For detailed PowerFlex 700S information refer to the appropriate publications listed below.

## Reference Materials

Allen-Bradley publications are available on the internet at:

[www.rockwellautomation.com/literature](http://www.rockwellautomation.com/literature).

Title	Publication
PowerFlex 700S Drives with Phase I Control User Manual	20D-UM001
PowerFlex 700S Drives with Phase I Control Reference Manual	PFLEX-RM002
PowerFlex 700S and DriveLogix <sup>™</sup> Firmware Release Notes	20D-RN007
PowerFlex 700S / 700H High Power Installation Instructions (Frames 9 - 12)	PFLEX-IN006
Wiring and Grounding Guidelines for Pulse Width Modulated (PWM) AC Drives	DRIVES-IN001



---

## Table of Contents

### Six Basic Steps to a Successful Start-Up

<b>Step 1 — <a href="#">Read General Information</a></b> .....	<b>4</b>
<a href="#">General Precautions</a> .....	4
<a href="#">EMC Instructions — CE Conformity</a> .....	5
<a href="#">General Notes</a> .....	6
<b>Step 2 — <a href="#">Mount the Drive</a></b> .....	<b>7</b>
<a href="#">Minimum Mounting Clearances</a> .....	7
<a href="#">Operating Temperatures</a> .....	7
<a href="#">Dimensions</a> .....	8
<b>Step 3 — <a href="#">Power Wiring</a></b> .....	<b>14</b>
<a href="#">Wire Recommendations</a> .....	14
<a href="#">Power &amp; Ground Wiring</a> .....	19
<a href="#">Power Terminal Block Designations</a> .....	19
<a href="#">Using PowerFlex 700S Drives with Regen Power Units</a> ...	20
<b>Step 4 — <a href="#">Control Wiring</a></b> .....	<b>20</b>
<a href="#">Wiring Recommendations</a> .....	20
<a href="#">DIP Switch Settings</a> .....	22
<a href="#">I/O Terminal Blocks</a> .....	23
<a href="#">I/O Wiring Examples</a> .....	25
<b>Step 5 — <a href="#">Start-Up Check List</a></b> .....	<b>29</b>
<a href="#">Before Applying Power to the Drive</a> .....	29
<a href="#">Applying Power to the Drive</a> .....	30
<b>Step 6 — <a href="#">Program the Drive – Start-Up</a></b> .....	<b>32</b>
<a href="#">Assisted Start</a> .....	32
<a href="#">Parameter Files &amp; Groups</a> .....	34
<a href="#">Frequently Used Parameters</a> .....	34

### Additional Information

<b><a href="#">DriveLogix™ Recommended Programming Techniques</a></b> .....	<b>37</b>
<b><a href="#">Troubleshooting</a></b> .....	<b>38</b>
<a href="#">Abbreviated Fault &amp; Alarm Clearing</a> .....	38
<a href="#">HIM Indication</a> .....	38
<a href="#">Manually Clearing Faults</a> .....	38
<b><a href="#">Technical Support</a></b> .....	<b>39</b>
<a href="#">Online</a> .....	39
<a href="#">Telephone</a> .....	39

---

**Step 1** Read General Information**General Precautions****Class 1 LED Product**

---



**ATTENTION:** Hazard of permanent eye damage exists when using optical transmission equipment. This product emits intense light and invisible radiation. Do not look into module ports or fiber optic cable connectors.

---



**ATTENTION:** This drive contains **ESD** (Electrostatic Discharge) sensitive parts and assemblies. Static control precautions are required when installing, testing, servicing or repairing this assembly. Component damage may result if ESD control procedures are not followed. If you are not familiar with static control procedures, reference Allen-Bradley publication 8000-4.5.2, “Guarding Against Electrostatic Damage” or any other applicable ESD protection handbook.



**ATTENTION:** An incorrectly applied or installed drive can result in component damage or a reduction in product life. Wiring or application errors such as under sizing the motor, incorrect or inadequate AC supply, or excessive surrounding air temperatures may result in malfunction of the system.



**ATTENTION:** Only **qualified personnel** familiar with the PowerFlex 700S Drive and associated machinery should plan or implement the installation, start-up and subsequent maintenance of the system. Failure to comply may result in personal injury and/or equipment damage.



**ATTENTION:** To avoid an electric shock hazard, verify that the voltage on the bus capacitors has discharged before performing any work on the drive. Measure the DC bus voltage at the +DC & – DC terminals of the Power Terminal Block (refer to Chapter 1 in the *PowerFlex 700S User Manual*, publication 20D-UM001, for location). The voltage must be zero.



**ATTENTION:** Risk of injury or equipment damage exists. DPI or SCANport host products must not be directly connected together via 1202 cables. Unpredictable behavior can result if two or more devices are connected in this manner.



**ATTENTION:** Risk of injury or equipment damage exists. Parameters 365 [Encdr0 Loss Cnfg] - 394 [VoltFdbkLossCnfg] let you determine the action of the drive in response to operating anomalies. Precautions should be taken to ensure that the settings of these parameters do not create hazards of injury or equipment damage



**ATTENTION:** Risk of injury or equipment damage exists. Parameters 383 [SL CommLoss Data] - 392 [NetLoss DPI Cnfg] let you determine the action of the drive if communications are disrupted. You can set these parameters so the drive continues to run. Precautions should be taken to ensure the settings of these parameters do not create hazards of injury or equipment damage.

---

## EMC Instructions — CE Conformity

Conformity with the Low Voltage (LV) Directive and Electromagnetic Compatibility (EMC) Directive has been demonstrated using harmonized European Norm (EN) standards published in the Official Journal of the European Communities. PowerFlex Drives comply with the EN standards listed below when installed according to the User and Reference Manual.

Declarations of Conformity are available online at:  
<http://www.rockwellautomation.com/products/certification/>.

### Low Voltage Directive (73/23/EEC)

- EN50178 Electronic equipment for use in power installations.

### EMC Directive (89/336/EEC)

- EN61800-3 Adjustable speed electrical power drive systems Part 3: EMC product standard including specific test methods.

### Essential Requirements for CE Compliance

Conditions 1-6 listed below **must be** satisfied for PowerFlex drives to meet the requirements of **EN61800-3**.

1. Standard PowerFlex 700S CE compatible Drive.
2. Review important precautions/attentions statements throughout this document before installing drive.
3. Grounding as described in the *PowerFlex 700S Drive with Phase I Control User Manual*, publication 20D-UM001.
4. Output power, control (I/O) and signal wiring must be braided, shield cable with a coverage of 75% or better, metal conduit or equivalent attenuation.
5. All shielded cables should terminate with proper shielded connector.
6. Conditions in Table A.

**Table A PowerFlex 700S EN61800-3 EMC Compatibility<sup>(1)</sup>**

Frame(s)	Second Environment	First Environment Restricted Distribution	
	<i>Restrict Motor Cable to 30 m (98 ft.)</i>	<i>Restrict Motor Cable to 150 m (492 ft.)</i>	
	<i>Any Drive and Option</i>	<i>Any Drive and Option</i>	<i>External Filter Required</i>
1 - 6	✓	✓	✓

(1) External filters for First Environment installations and increasing motor cable lengths in Second Environment installations are available. Roxburgh models KMFA (RF3 for UL installations) and MIF or Schaffner FN3258 and FN258 models are recommended. Refer to <http://www.deltron-emcon.com> and <http://www.mtecorp.com> (USA) or <http://www.schaffner.com>, respectively.


**General Notes**

- If the adhesive label is removed from the top of the drive, the drive must be installed in an enclosure with side openings less than 12.5 mm (0.5 in.) and top openings less than 1.0 mm (0.04 in.) to maintain compliance with the LV Directive.
- The motor cable should be kept as short as possible in order to avoid electromagnetic emission as well as capacitive currents.
- Use of line filters in ungrounded systems is not recommended.
- PowerFlex drives may cause radio frequency interference if used in a residential or domestic environment. The installer is required to take measures to prevent interference, in addition to the essential requirements for CE compliance provided in this section, if necessary.
- Conformity of the drive with CE EMC requirements does not guarantee an entire machine or installation complies with CE EMC requirements. Many factors can influence total machine/installation compliance.
- PowerFlex drives can generate conducted low frequency disturbances (harmonic emissions) on the AC supply system.
- More information regarding harmonic emissions can be found in the *PowerFlex 700S Drives with Phase I Control Reference Manual*, publication PFLEX-RM001.
- When operated on a public supply system, it is the responsibility of the installer or user to ensure, by consultation with the distribution network operator and Rockwell Automation, if necessary, that applicable requirements have been met.

## Step 2 Mount the Drive

### Minimum Mounting Clearances

Figure 1 Minimum Mounting Clearance Requirements



### Operating Temperatures

PowerFlex 700S drives are designed to operate in a surrounding air temperature range of 0° to 40° C. To operate the drive in installations with surrounding air temperature between 41° and 50° C, remove the adhesive label affixed to the top of the drive enclosure.


**Important:** Removing the adhesive label from the drive changes the NEMA enclosure rating from Type 1 to Open type.

## Dimensions

Table B PowerFlex 700S Frames

Frame	AC Input												DC Input			
	208		240		380 ... 400V		480V		600V		690V		540V		650V	
	ND HP	HD HP	ND HP	HD HP	ND kW	HD kW	ND HP	HD HP	ND HP	HD HP	ND HP	HD HP	ND HP	HD HP	ND HP	HD HP
1	0.75	0.37	1.0	0.75	0.75	0.55	1	0.75	1	0.5	–	–	–	–	–	–
	1.5	0.75	2.0	1.5	1.5	0.75	2	1.5	2	1	–	–	–	–	–	–
	2.2	1.5	3.0	2.0	2.2	1.5	3	2	3	2	–	–	–	–	–	–
	4.0	2.2	5.0	3.0	4.0	2.2	5	3	5	3	–	–	–	–	–	–
	5.5	4.0	7.5	5.0	5.5	4.0	7.5	5	7.5	5	–	–	–	–	–	–
	–	–	–	–	7.5	5.5	10	7.5	10	7.5	–	–	–	–	–	–
	–	–	–	–	11	7.5	15	10	15	10	–	–	–	–	–	–
2	7.5	5.5	10	7.5	15	11	20	15	20	15	–	–	–	–	–	–
	–	–	–	–	18.5	15	25	20	25	20	–	–	–	–	–	–
3	11	7.5	15	10	22	18.5	30	25	30	25	–	–	–	–	–	–
	15	11	20	15	30	22	40	30	40	30	–	–	–	–	–	–
	–	–	–	–	37	30	50	40	50	40	–	–	–	–	–	–
4	18.5	15	25	20	45	37	60	50	60	50	–	–	–	–	–	–
	22	18.5	30	25	–	–	–	–	–	–	–	–	–	–	–	–
5	30	22	40	30	55	45	75	60	75	60	75	55	55	45	75	60
	30	30	50	40	55	45	100	75	100	75	90	75	55	45	75	60
	–	–	–	–	–	–	–	–	–	–	–	–	55	45	100	75
	–	–	–	–	–	–	–	–	–	–	–	–	55	45	100	75
6	45	37	60	50	90	75	125	100	125	100	110	90	90	75	125	100
	55	45	75	60	110	90	150	125	150	125	132	110	90	75	125	100
	66	55	100	75	132	110	200	150	–	–	–	–	110	90	150	125
	–	–	–	–	–	–	–	–	–	–	–	–	110	90	150	125
	–	–	–	–	–	–	–	–	–	–	–	–	132	110	200	150
	–	–	–	–	–	–	–	–	–	–	–	–	132	110	200	150

**Figure 2 PowerFlex 700S Frame 1-3 (Frame 1 Shown)**




Dimensions are in

Frame	A	B	C	D	E	Weight • kg (lbs.)
						Drive
1	200.0 (7.87)	389.0 (15.31)	202.8 (7.98)	175.0 (6.89)	375.0 (14.76)	11.3 (24.92)
2	285.0 (11.22)	389.0 (15.31)	202.7 (7.98)	250.0 (9.84)	375.0 (14.76)	18.4 (40.57)
3	285.0 (11.22)	564.0 (22.20)	202.7 (7.98)	250.0 (9.84)	550.0 (21.65)	26.6 (58.65)


• Weights include HIM, DriveLogix™ controller with ControlNet daughtercard, Hi-Resolution Encoder Option, and 20-COMM-C ControlNet adapter

**Figure 3 PowerFlex 700S Bottom View Dimensions, Frame1 & 2**




**Frame 3 - All Drives, except 50 HP, 480 V (37 kW, 400V)**

**Frame 3 - 50 HP, 480V (37 kW, 400V) Normal Duty Drive**



*Dimensions are in millimeters and (inches)*

**Figure 4 PowerFlex 700S Frame 4 Dimensions**




Dimensions are in millimeters and (inches)


Frame	A (Max.)	B	C (Max.)	D	E	Approx. Weight $\bullet$ kg (lbs.)	
						Drive	Drive & Packaging
4	220.8 (8.69)	758.8 (29.9)	201.8 (7.94)	192.0 (7.56)	741.7 (29.2)	28.4 (62.5)	29.03 (63.9)

$\bullet$  Weights include HIM and Standard I/O.


**Figure 5 PowerFlex 700S Frame 5 Dimensions**



**Frame 5 - 75 HP, 480 V (55kW, 400V)**



**Frame 5 - 100 HP, 480 V (55kW, 400V)**




Dimensions are in millimeters and (inches)

Frame	A	B	C	D	E	Approx Weight $\bullet$ kg (lbs.)
5	308.9(12.16)	644.5(25.37)	275.4(10.84)	225.0(8.86)	625.0(24.61)	37.19 (82)

$\bullet$  Weights include HIM and Standard I/O.

**Figure 6 PowerFlex 700S Frame 6 Dimensions**



Frame	A (Max.)	B	C (Max.)	D	E	Approx. Weight $\bullet$ kg (lbs.)	
						Drive	Drive and Packaging
6	403.90 (15.90)	850.00 (33.46)	275.50 (10.85)	300.00 (11.81)	825.00 (32.48)	11.3 (24.92)	92.85 (202.50)

$\bullet$  Weights include HIM and Standard I/O.

## Step 3 Power Wiring

### Wire Recommendations

Since most start-up difficulties are the result of incorrect wiring, take every precaution to assure the wiring is correct. Read and understand all items in this section before beginning installation.



**ATTENTION:** The following information is merely a guide for proper installation. The Allen-Bradley Company cannot assume responsibility for the compliance or the noncompliance to any code, national, local or otherwise for the proper installation of this drive or associated equipment. A hazard of personal injury and/or equipment damage exists if codes are ignored during installation.

### Power Cable Types Acceptable for 200-600 Volt Installations



**ATTENTION:** National Codes and standards (NEC, VDE, BSI etc.) and local codes outline provisions for safely installing electrical equipment. Installation must comply with specifications regarding wire types, conductor sizes, branch circuit protection and disconnect devices. Failure to do so may result in personal injury and/or equipment damage.

#### General

A variety of cable types are acceptable for drive installations. For many installations, unshielded cable is adequate, provided it can be separated from sensitive circuits. As an approximate guide, allow a spacing of 0.3 meters (1 foot) for every 10 meters (32.8 feet) of length. In all cases, long parallel runs must be avoided. Do not use cable with an insulation thickness less than or equal to 15 mils (0.4mm/0.015 in.). Use tinned copper wire only. Wire gauge requirements and recommendations are based on 75° C. Do not reduce wire gauge when using higher temperature wire.

#### Unshielded

THHN, THWN or similar wire is acceptable for drive installation in dry environments provided adequate free air space and/or conduit fill rates limits are provided. **Do not use THHN or similarly coated wire in wet areas.** Any wire chosen must have a minimum insulation thickness of 15 Mils and should not have large variations in insulation concentricity.

#### Shielded/Armored Cable

Shielded cable contains all of the general benefits of multi-conductor cable with the added benefit of a copper braided shield that can contain much of the noise generated by a typical AC Drive. Strong consideration for shielded cable should be given in installations with sensitive equipment such as weigh scales, capacitive proximity switches and other devices that may be affected by electrical noise in the distribution system. Applications with large numbers of drives in a similar location, imposed EMC regulations or a high degree of communications/networking are also good candidates for shielded cable.

Shielded cable may also help reduce shaft voltage and induced bearing currents for some applications. In addition, the increased impedance of shielded cable may help extend the distance the motor can be located from the drive without the addition of motor protective devices such as terminator networks. Refer to Reflected Wave in *Wiring and Grounding Guidelines for PWM AC Drives*, publication DRIVES-IN001.

Consideration should be given to all of the general specifications dictated by the environment of the installation, including temperature, flexibility, moisture characteristics and chemical resistance. In addition, a braided shield should be included and specified by the cable manufacturer as having coverage of at least 75%. An additional foil shield can greatly improve noise containment.

A good example of recommended cable is Belden<sup>®</sup> 295xx (xx indicates gauge). This cable has 4 XLPE insulated conductors with a 100% coverage foil and an 85% coverage copper braided shield (with drain wire) surrounded by a PVC jacket.

Other types of shielded cable are available, but the selection of these types may limit the allowable cable length. Particularly, some of the newer cables twist 4 conductors of THHN wire and wrap them tightly with a foil shield. This construction can greatly increase the cable charging current required and reduce the overall drive performance. Unless specified in the individual distance tables as tested with the drive, these cables are not recommended and their performance against the lead length limits supplied is not known.

**Table C Recommended Shielded Wire for Power Wiring**

Location	Rating/Type	Description
Standard (Option 1)	600V, 90° C (194° F) XHHW2/RHW-2 Anixter B209500-B209507, Belden <sup>®</sup> 29501-29507, or equivalent	Four tinned copper conductors with XLPE insulation. Copper braid/aluminum foil combination shield and tinned copper drain wire. PVC jacket.
Standard (Option 2)	Tray rated 600V, 90° C (194° F) RHH/RHW-2 Anixter OLF-7xxxx or equivalent	Three tinned copper conductors with XLPE insulation. 5 mil single helical copper tape (25% overlap min.) with three bare copper grounds in contact with shield. PVC jacket.
Class I & II; Division I & II	Tray rated 600V, 90° C (194° F) RHH/RHW-2 Anixter 7V-7xxx-3G or equivalent	Three bare copper conductors with XLPE insulation and impervious corrugated continuously welded aluminum armor. Black sunlight resistant PVC jacket overall. Three copper grounds on #10 AWG and smaller.

Figure 7 Power Terminal Block Location





Figure 8 Power Terminal Block Location, Cont'd



**Fan VA Rating - Common Bus Only**

Frame	Fan Voltage (120V or 240V)
5	100 VA
6	138 VA

<sup>1</sup> Frame 5 & 6 utilize a transformer to match the input line voltage to the internal fan voltage. If your line voltage is different then the voltage class specified on the drive nameplate, it may be necessary to change the transformer taps. The taps are shown in the inserts of frames 5 & 6.

Common Bus drives require user supplied 120V or 240V to power the cooling fans. Power source is connected between "0V AC" and the terminal corresponding to your source voltage.

Table D Power Terminal Block Specifications

No.	Name	Frame	Description	Wire Size Range <sup>(1)</sup>		Torque		Terminal Bolt Size <sup>(2)</sup>		
				Maximum	Minimum	Maximum	Recommended			
❶	Power Terminal Block	1	Input power and motor connections	4.0 mm <sup>2</sup> (10 AWG)	0.5 mm <sup>2</sup> (22 AWG)	1.7 N-m (15 lb.-in.)	0.8 N-m (7 lb.-in.)	—		
		2	Input power and motor connections	10.0 mm <sup>2</sup> (6 AWG)	0.8 mm <sup>2</sup> (18 AWG)	1.7 N-m (15 lb.-in.)	1.4 N-m (12 lb.-in.)	—		
		3	Input power and motor connections	25.0 mm <sup>2</sup> (3 AWG)	2.5 mm <sup>2</sup> (14 AWG)	3.6 N-m (32 lb.-in.)	1.8 N-m (16 lb.-in.)	—		
			BR1, BR2	10.0 mm <sup>2</sup> (6 AWG)	0.8 mm <sup>2</sup> (18 AWG)	1.7 N-m (15 lb.-in.)	1.4 N-m (12 lb.-in.)	—		
		4	Input power and motor connections	35.0 mm <sup>2</sup> (1/0 AWG)	10 mm <sup>2</sup> (8 AWG)	4.0 N-m (24 lb.-in.)	4.0 N-m (24 lb.-in.)	—		
		5 (75 HP) <sup>(3)</sup>	R, S, T, BR1, BR2, DC+, DC-, U, V and W	50.0 mm <sup>2</sup> (1/0 AWG)	2.5 mm <sup>2</sup> (14 AWG)	See Note (4)	See Note (4)	—		
			PE	50.0 mm <sup>2</sup> (1/0 AWG)	4.0 mm <sup>2</sup> (12 AWG)			—		
		5 (100 HP) <sup>(3)</sup>	R, S, T, DC+, DC-, U, V and W	70.0 mm <sup>2</sup> (2/0 AWG)	16.0 mm <sup>2</sup> (6 AWG)			—		
			BR1, BR2	50.0 mm <sup>2</sup> (1/0 AWG)	2.5 mm <sup>2</sup> (14 AWG)			—		
			PE	50.0 mm <sup>2</sup> (1/0 AWG)	4.0 mm <sup>2</sup> (12 AWG)			—		
6	Input power and motor connections	120.0 mm <sup>2</sup> (4/0 AWG)	2.5 mm <sup>2</sup> (14 AWG)	6 N-m (52 lb.-in.)	6 N-m (52 lb.-in.)			—		
❷	SHLD Terminal	1-6	Terminating point for wiring shields	—	—			1.6 N-m (14 lb.-in.)	1.6 N-m (14 lb.-in.)	—
❸	AUX Terminal Block	1-4	Auxiliary Control Voltage <sup>(5)</sup> PS+, PS-	1.5 mm <sup>2</sup> (16 AWG)	0.2 mm <sup>2</sup> (24 AWG)			—	—	—
		5-6		4.0 mm <sup>2</sup> (10 AWG)	0.5 mm <sup>2</sup> (22 AWG)			0.6 N-m (5.3 lb.-in.)	0.6 N-m (5.3 lb.-in.)	—
❹	Fan Terminal Block (Common Bus Only)	5-6	User Supplied Fan Voltage 0V AC, 120V AC, 240V AC	4.0 mm <sup>2</sup> (10 AWG)	0.5 mm <sup>2</sup> (22 AWG)			0.6 N-m (5.3 lb.-in.)	0.6 N-m (5.3 lb.-in.)	—

(1) Maximum/minimum sizes that the terminal block will accept - these are not recommendations.

(2) Apply counter torque to the nut on the other side of terminations when tightening or loosening the terminal bolt in order to avoid damage to the terminal.


(3) Not all terminals present on all drives.

(4) Refer to the terminal block label inside the drive.

(5) External control power: UL Installation - 300V DC, ±10%, Non UL Installation - 270-600V DC, ±10%. Frame 1-6, 100 W

## Power &amp; Ground Wiring

Figure 9 Power and Ground Wiring



## Important Common Bus (DC Input) Application Notes

1. If drives without internal precharge are used (Frames 5 & 6 only), then:
  - a) precharge capability must be provided in the system to guard against possible damage, and
  - b) disconnect switches **Must Not** be used between the input of the drive and a common DC bus without the use of an external precharge device.
2. If drives with internal precharge (Frames 1-6) are used with a disconnect switch to the common bus, then:
  - a) an auxiliary contact on the disconnect must be connected to a digital input of the drive. The corresponding input (parameter 361-366) must be set to option 30, "Precharge Enable." This provides the proper precharge interlock, guarding against possible damage to the drive when connected to a common DC bus. The drive must have firmware version 2.002 or above (Standard & Vector Control).

## Power Terminal Block Designations

Terminal	Description	Notes
BR1	DC Brake (+)	Dynamic Brake Resistor Connection (+)
BR2	DC Brake (-)	Dynamic Brake Resistor Connection (-)
DC+	DC Bus (+)	DC Input Power or Dynamic Brake Chopper
DC-	DC Bus (-)	DC Input Power or Dynamic Brake Chopper
PE	PE Ground	Refer to <a href="#">Figure 9 on page 19</a> for location on Frame 3 drives
$\perp$	Motor Ground	Refer to <a href="#">Figure 7 on page 16</a> for location on Frame 3 drives
U	U (T1)	To motor
V	V (T2)	To motor
W	W (T3)	To motor
R	R (L1)	AC Line Input Power
S	S (L2)	AC Line Input Power
T	T (L3)	AC Line Input Power

## Using PowerFlex 700S Drives with Regen Power Units

If a Regenerative unit (i.e., 1336 REGEN) is used as a bus supply or a brake, the common mode capacitors should be disconnected. Refer to the *PowerFlex 700S Drives with Phase I Control User Manual*, publication 20D-UM001, for information on removing common mode capacitors.

### Regenerative Unit to Drive Connections

#### Regenerative Brake Mode

Frame(s)	Terminals	
	1336 Regen	PowerFlex 700S
1 - 4	DC+ & DC-	BR1 & DC-
5 & 6	DC+ & DC-	DC+ & DC-

#### Regenerative Bus Supply Mode

Frame(s)	Terminals	
	1336 Regen	PowerFlex 700S
1 - 4	DC+ & DC-	DC+ & DC-
5 & 6	DC+ & DC-	DC+ & DC- of the Common Bus Drives

Refer to *1336 REGEN Line Regeneration Package User Manual*, publication 1336-REGEN-5.0, for more information.

## Step 4 Control Wiring

### Wiring Recommendations

Important points to remember about I/O wiring:

- Always use copper wire.
- Wire with an insulation rating of 600V or greater is recommended.
- Control and signal wires should be separated from power wires by at least 0.3 meters (1 foot).
- 4100CCF3 Flex I/O cable for use with DriveLogix is 3 ft. maximum length.

**Important:** I/O terminals labeled “(-)” or “Common” are not referenced to earth ground and are designed to greatly reduce common mode interference. Grounding these terminals can cause signal noise.



**ATTENTION:** Hazard of personal injury or equipment damage exists when using bipolar input sources. Noise and drift in sensitive input circuits can cause unpredictable changes in motor speed and direction. Use speed command parameters to help reduce input source sensitivity.

**Table E Recommended Control Wire**

Type		Wire Type(s)	Description	Insulation Rating
Digital I/O	Un-shielded	Per US NEC or applicable national or local code	—	300V, 60° C (140° F), Minimum
	Shielded	Multi-conductor shielded cable such as Belden 8770 (or equiv.)	0.750 mm <sup>2</sup> (18 AWG), 3 conductor, shielded.	
Standard Analog I/O		Belden 8760/9460 (or equiv.)	0.750 mm <sup>2</sup> (18 AWG), twisted pair, 100% shield with drain <sup>(5)</sup> .	300V, 75-90 °C (167-194 °F)
Remote Pot		Belden 8770 (or equiv.)	0.750 mm <sup>2</sup> (18 AWG), 3 cond., shielded	
Encoder/Pulse I/O Less 30.5 m (100 ft.)	Combined:	Belden 9730 (or equivalent) <sup>(1)</sup>	0.196 mm <sup>2</sup> (24 AWG), individually shielded.	
Encoder/Pulse I/O 30.5 m (100 ft.) to 152.4 m (500 ft.)	Signal:	Belden 9730/9728 (or equivalent) <sup>(1)</sup>	0.196 mm <sup>2</sup> (24 AWG), individually shielded.	
	Power:	Belden 8790 <sup>(2)</sup>	0.750 mm <sup>2</sup> (18 AWG)	
	Combined:	Belden 9892 <sup>(3)</sup>	0.330 mm <sup>2</sup> or 0.500 mm <sup>2</sup> <sup>(3)</sup>	
Encoder/Pulse I/O 152.4 m (500 ft.) to 259.1 m (850 ft.)	Signal:	Belden 9730/9728 (or equivalent) <sup>(1)</sup>	0.196 mm <sup>2</sup> (24 AWG), individually shielded.	
	Power:	Belden 8790 <sup>(2)</sup>	0.750 mm <sup>2</sup> (18 AWG)	
	Combined:	Belden 9773/9774 (or equivalent) <sup>(4)</sup>	0.750 mm <sup>2</sup> (18 AWG), individually shielded pair.	
<b>EMC Compliance</b>	Refer to <a href="#">EMC Instructions — CE Conformity on page Quick Start-5</a> for details.			

(1) Belden 9730 is 3 individually shielded pairs (2 channel plus power). If 3 channel is required, use Belden 9728 (or equivalent).

(2) Belden 8790 is 1 shielded pair.


(3) Belden 9892 is 3 individually shielded pairs (3 channel), 0.33 mm<sup>2</sup> (22 AWG) plus 1 shielded pair 0.5 mm<sup>2</sup> (20 AWG) for power.

(4) Belden 9773 is 3 individually shielded pairs (2 channel plus power). If 3 channel is required, use Belden 9774 (or equivalent).

(5) If the wires are short and contained within a cabinet which has no sensitive circuits, the use of shielded wire may not be necessary, but is always recommended.

DIP Switch Settings

Figure 10 Main Control Board Dip Switches



<b>Analog Input #1 Scaling</b>	+/-10.0V DC	+/-1.0V DC
<b>SW1-1</b>	Open	Closed

<b>Analog Input #2 Scaling</b>	+/-10.0V DC	+/-1.0V DC
<b>SW1-2</b>	Open	Closed

<b>Encoder Power Supply Voltage</b>	<b>Jumper Position</b>
5V DC	2-3
12V DC	1-2

<b>Primary Encoder</b>	<b>SW2-2</b>	<b>SW2-4</b>	<b>SW2-6</b>
5V DC Operation	Closed	Closed	Closed
12V DC Operation	Open	Open	Open

<b>Secondary Encoder</b>	<b>SW2-1</b>	<b>SW2-3</b>	<b>SW2-5</b>
5V DC Operation	Closed	Closed	Closed
12V DC Operation	Open	Open	Open

Analog Input Settings

Switch SW1-1 configures the scaling of Analog Input #1. Switch SW1-2 configures the scaling of Analog Input #2. Open the switch for +/-10.0V DC operation. Close the switch for +/-1.0V DC operation.

Encoder Input Settings

Dip switch SW2 on the main control board configures the encoder inputs for 5V DC or 12V DC operation. Switches SW2-2, 2-4, and 2-6 are for the primary encoder. Set these switches to match the encoder output specifications. Open these switches for 12V DC operation, close them for 5V DC operation.

Switches SW2-1, 2-3, and 2-5 are for the secondary encoder. Set these switches to match the encoder output specifications. Open these switches for 12V DC operation, close them for 5V DC operation.

## I/O Terminal Blocks

### Wiring the Main Control Board I/O Terminals

Terminal blocks TB1 and TB2 contain connection points for all inputs, outputs and standard encoder connections. When installed, both terminal blocks reside on the Main Control Board. These components are provided with the drive but are not factory installed.

Make the terminal block wire connections.



**TIP:** Remember to route wires through the sliding access panel at the bottom Control Assembly.

When wiring is complete, install the plug. The terminal blocks have keys, which make it difficult to insert a terminal plug into the wrong socket.


**Table F Control & Encoder Terminal Block Specifications**

Name	Frame	Description	Wires Size Range <sup>(1)</sup>		Torque	
			Maximum	Minimum	Maximum	Recommended
I/O & Encoder Blocks	1, 2, 3, 5	Signal & Encoder power connections	1.5 mm <sup>2</sup> (16 AWG)	.14 mm <sup>2</sup> (28 AWG)	.25 N-m (2.2 lb.-in.)	.22 N-m (1.9 lb.-in.)

(1) Maximum/minimum sizes the terminal block will accept - these are not recommendations.

**Table G TB1 - Row T (Top) Terminals**


Terminal	Signal	Description	Related Parameter
T11	Power Supply 24V DC Return (-)	Power and common for pre charge and enable inputs. <sup>(1)</sup> Inputs may sink or source. <sup>(2)</sup> Rating: 100 mA maximum.	
T10	Power Supply 24V DC (+)		
T9	Logic Common		
T8	Digital Input #1 Default = Precharge	For common DC bus drives. Must be high, for drive to complete the pre charge cycle. Load: 20 mA at 24V DC.	824, 838, 829, 826, 827, 828
T7	Enable Input	Must be high for drive to run. Load: 20 mA at 24V DC.	824, 825
T6	Digital Output #1	24V DC open collector (sinking logic) output. Rating: 25 mA maximum.	843, 844, 824
T5	Digital Output #2	24V DC open collector (sinking logic) output. Rating: 25 mA maximum.	845, 846, 824
T4	Digital Output Return	Return for Digital outputs 1 and 2.	
T3	Thermistor Input	Used only in FOC2 mode with approved motor for temperature adaptation.	485
T2	Thermistor Input Return		
T1	Thermistor Shield		



(1) The drive's 24V DC power supply supports only on-board digital inputs. Do not use it to power circuits outside of the drive.

(2) Refer to wiring examples of sinking and sourcing outputs.

Table H TB1 - Row B (Bottom) Terminals




Terminal	Signal	Description	Related Parameter
B11	Analog Input #1 (-)	+/-10.0V DC or +/-1.0V DC bipolar, differential input. <sup>(1)</sup> , 13 bit + sign, 20k ohm input impedance	800, 801, 802, 803, 804, 805
B10	Analog Input #1 (+)		
B9	Analog Input Shield	Optional connection point for analog input shield. <sup>(2)</sup>	
B8	Analog Input #2 (-)	+/-10.0V DC or +/-1.0V DC bipolar, differential input. <sup>(1)</sup> , 13 bit + sign, 20k ohm input impedance	806, 807, 808, 809, 810, 811
B7	Analog Input #2 (+)		
B6	Analog Output #1 (+)	+/-10.0V DC bipolar, differential output, 11 bit + sign, 2k ohm minimum load	814, 815, 816, 817, 812, 818
B5	Analog Output #1 Return (-)		
B4	Analog Output Shield	Optional connection point for analog output shield. <sup>(2)</sup>	
B3	Analog Output #2 (+)	+/-10.0V DC bipolar, differential output, 11 bit + sign, 2k ohm minimum load	819, 820, 821, 822, 813, 823
B2	Analog Output #2 Return (-)		
B1	Analog Output Shield	Optional connection point for analog shields.	

(1) Refer to Analog Input Settings in the *PowerFlex 700S User Manual*, publication 20D-UM001, for necessary dip switch settings.

(2) Analog shields should connect to common at the signal source, if possible. Shields for signals from ungrounded devices, such as analog tachometers, should connect to an analog shield terminal point at the drive.

Table I TB2 - Row T (Top) Terminals




Terminal	Signal	Description	Related Parameter
T13	Encoder Signal A	Primary encoder interface. 5 or 12V DC switch selectable <sup>(1)</sup> , Nominal current draw per channel @ 12V DC 45 mA, @5V DC 32 mA	222, 232, 233, 234, 231, 230, 236, 237, 238, 235
T12	Encoder Signal Not A		
T11	Encoder Signal B		
T10	Encoder Signal Not B		
T9	Encoder Signal Z		
T8	Encoder Signal Not Z		
T7	Shield	Connection point for encoder shield.	
T6	Digital Input #2	High speed 12-24V DC sinking digital input.	824, 839, 833, 830, 831, 832
T5	Digital Input #2 Return		
T4	Digital Input #3	High speed 12-24V DC sinking digital input.	824, 840, 837, 834, 835, 836
T3	Digital Input #3 Return		
T2	Power Supply +12V DC (A) (+)	12V DC power supply for primary encoder interface and high speed inputs. Rating 300 mA <sup>(2)</sup>	
T1	Power Supply +12V DC Return (A) (-)		

(1) Refer to Encoder Input Settings in the *PowerFlex 700S User Manual*, publication 20D-UM001, for necessary dip switch settings.

(2) This power supply supports only the primary encoder interface and digital inputs. Do not use it to power circuits outside of the drive.

Table J TB2 - Row B (Bottom) Terminals



Terminal	Signal	Description	Related Parameter
B13	Encoder Signal A	Secondary encoder interface. 5 or 12V DC switch selectable <sup>(1)</sup> , Nominal current draw per channel @ 12V DC 45 mA, @5V DC 32 mA	222, 243, 244, 242, 241, 240, 246, 247, 248, 245
B12	Encoder Signal Not A		
B11	Encoder Signal B		
B10	Encoder Signal Not B		
B9	Encoder Signal Z		
B8	Encoder Signal Not Z		
B7	Shield	Connection point for encoder shield.	
B6	Unused		
B5	Relay Output	Relay contact output.	824, 841, 842
B4	Relay Output Return	Rating: 5A @ 24V DC Resistive, 2A 24V DC Inductive	
B3	Unused		
B2	Power Supply +12V DCDC (B) (+)	12V DC power supply for secondary encoder interface. Rating 300 mA <sup>(2)</sup>	
B1	Power Supply +12V DC Return (B) (-)		

(1) Refer to Encoder Input Setting in the *PowerFlex 700S User Manual*, publication 20D-UM001, for necessary dip switch settings.

(2) This power supply supports only the secondary encoder interface. Do not use it to power circuits outside of the drive

## I/O Wiring Examples

This section provides basic information to wire the PowerFlex 700S Drive.

### Table K Digital Wiring Examples





The following definitions are used throughout this section:



#### Source

- Apply positive voltage through the device to the input or output.
- Connect the input or output common (return) directly to the power supply common.

#### Sink


- Apply the positive voltage directly to the input or output common (return).
- Connect the input or output to the power supply common through the device


Input/Output	Connection Example	
<p>Digital Inputs used for enable and precharge control.</p> <p><i>Note:</i> <b>24V DC Supply</b> - supports only on-board digital inputs. Do not use for circuits outside the drive.</p>	<p>Sourcing Input - using internal power supply</p> <p style="text-align: center;"><b>TB1 - Row T (Top)</b></p> 	<p><b>Required Parameter Changes</b></p> <p><b>Enable</b> - In sinking configuration, this circuit must connect to 24V DC power for drive to run.</p> <p><b>Precharge</b> Precharge control is used in common bus configurations and is not required for AC fed drives.</p> <p>If precharge control is not required, reprogram Par 838 [DigIn1 Sel] to a value of zero (0) or replace the contact shown with a jumper from Terminal 8 to Terminal 10.</p> <p>If precharge is needed, in sinking configuration, this circuit must connect to 24V DC power for drive to complete the precharge cycle.</p>
	<p>Sourcing Input - using external power supply</p> <p style="text-align: center;"><b>TB1 - Row T (Top)</b></p> 	<p><b>Enable</b> - In sourcing configuration, must connect to 24V DC common for drive to run.</p> <p><b>Precharge</b> Precharge control is used in common bus configurations and is not required for AC fed drives.</p> <p>If precharge control is not required, reprogram Par 838 [DigIn1 Sel] to a value of zero (0)</p> <p>If precharge is needed, in sourcing configuration, must connect to 24V DC common for drive to enter pre charge cycle.</p>
<p><b>Auxiliary Outputs</b> - 24V DC outputs 25 mA maximum per output</p>	<p>Digital Output 1 Indicating Alarm and Digital Output 2 Indicating Fault - in sourcing configuration</p> <p style="text-align: center;"><b>TB1 - Row T (Top)</b></p> 	<p><b>Using DigOut 1 to annunciate an alarm:</b></p> <ul style="list-style-type: none"> <li>Link the status word to the output control Par 843 [DigOut 1 Data] (the destination) linked to Par 155 [Logic Status] (the source)</li> <li>Select which bit activated the output Par 844 [DigOut 1 Bit] = 8 "Alarm"</li> </ul>
<p><b>Auxiliary Output</b> - Relay contact output</p>	<p>Auxiliary Output - sourcing configuration</p> <p style="text-align: center;"><b>TB2 - Row B (Bottom)</b></p> 	<p><b>Using Relay Out to annunciate "drive running:"</b></p> <ul style="list-style-type: none"> <li>Link the status word to the relay control Par 841 [Relay Out Data] (the destination) linked to Par 155 [Logic Status] (the source)</li> <li>Set Par 842 [Relay Out Bit] to a value of 1, so that Par 155 [Logic Status], bit 1 [Running] will control the output.</li> </ul>

Input/Output	Connection Example	
<p>12 - 24V DC Inputs</p> <p>Digital Inputs used for Start/Stop 3-Wire Control</p>	<p>3-Wire Control, Non-Reversing - using internal power supply</p> 	<ul style="list-style-type: none"> <li>• Set the value of Parameter 839 [DigIn2 Sel] to a value of 1 - "Normal Stop"</li> <li>• Set the value of Parameter 840 [DigIn3 Sel] to a value of 2 - "Start"</li> <li>• Set Parameter 153 [Control Options], bit 8 [3WireControl]</li> </ul>
<p>Digital Inputs used for Run/Stop 2-Wire Control</p> <p><b>Note:</b> +12V and +24V are also available from TB1 Top 10 &amp; 11.</p>	<p>2-Wire Control, Non-Reversing - using external power supply <sup>(1)</sup></p> 	<ul style="list-style-type: none"> <li>• Set the value of Par 839 [DigIn2 Sel] = 3 "Run"</li> <li>• Set Par 153 [Control Options], bit 8 [3WireControl] = 0 (2-wire control)</li> </ul> <p style="text-align: center;"><b>AND</b></p> <ul style="list-style-type: none"> <li>• Set Par 153 [Control Options], bit 9 [2W CoastStop] = 0 (ramp stop)</li> </ul> <p style="text-align: center;"><b>or</b></p> <ul style="list-style-type: none"> <li>• Par 153 [Control Options], bit 9 [2W CoastStop] = 1 (coast stop)</li> </ul> <p style="text-align: center;">Use Digital Input 2 for 2-wire Run/Stop Control</p>


(1) See "Important" statement about the HIM on [page 32](#).

**Table L Analog Wiring Examples**

Analog I/O	Connection Example	
<p><b>Analog Inputs -</b> +/-10V DC or +/-1.0V DC (DIP switch setable) Terminate shields at the analog source if analog common is available</p> <p>Used for Speed Reference and Speed Trim</p>	<p>Analog Inputs - shield terminated at source</p> 	<p><b>Required Parameter Changes</b></p> <p><b>Using Analog In1 as 0 - 10 V speed reference:</b></p> <ul style="list-style-type: none"> <li>• Scale the Input to 1 V, Par 802 [Anlg In1 Scale] = 0.1</li> <li>• Send the data to the Speed Reference parameter Par 10 [Speed Ref 1] (the destination) linked to Par 800 [Anlg In1 Data] (the source)</li> <li>• Select Ref 1 as the active speed reference Par 16 [Speed Ref Sel] = 1 "Spd Ref 1"</li> <li>• Par 153 [Control Option], bit 0 = 0 (Unipolar Speed Reference)</li> </ul> <p><b>Using Analog In2 as -10 to +10V speed trim @ 10%:</b></p> <ul style="list-style-type: none"> <li>• Scale the input to 0.1V - 10% Par 808 [Anlg In2 Scale] = 0.01</li> <li>• Send the data to the Speed Reference parameter Par 12 [Speed Ref 2] (the destination) linked to Par 806 [Anlg In2 Data] (the source)</li> <li>• Select Ref 1 as the active speed reference and Ref 2 as trim, Par 16 [Speed Ref Sel] = 3 "Spd Ref 3"</li> </ul>

Analog I/O	Connection Example	
<p><b>Analog Outputs - +/-10V DC</b></p> <p>Used to drive analog meters displaying speed and current</p>		<p><b>Using Analog Out 1, -10V to + 10V to meter Motor RPM and direction:</b></p> <ul style="list-style-type: none"> <li>Send the data to the Analog Output Par 815 [Anlg Out1 Real] (the destination) linked to Par 300 [Motor Spd Fdbk] (the source)</li> <li>Scale the Output to the source parameter Par 817 [Anlg Out1 Scale] = 175 (Par 4 [Motor NP RPM] = 1750 / 10V)</li> </ul> <p><b>Using Analog Out 2, -10V to + 10V to meter Motor Current:</b></p> <ul style="list-style-type: none"> <li>Send the data to the Analog Output Par 820 [Anlg Out2 Real] (the destination) linked to Par 308 [Output Current] (the source)</li> <li>Scale the Output to the source parameter Par 822 [Anlg Out2 Scale] = xx (Par 2 [Motor NP FLA] / 10 V Output)</li> </ul>

**Table M Encoder Wiring Example**

Input/Output	Connection Example	
<p><b>Primary Encoder Interface -</b> Supports 12V DC differential encoders with internal power supply.</p> <p>5V DC differential encoders require external power supply and special jumper settings.</p> <p>Used as primary closed loop speed feedback</p>	<p>Primary Encoder - using internal power supply</p> 	<p><b>Required Parameter Changes</b></p> <p><b>Using Encoder 0 as speed feedback:</b></p> <ul style="list-style-type: none"> <li>Par 222 [Motor Fdkbk Sel] = 0 "Encoder 0" (default)</li> <li>Par 232 [Encoder0 PPR] = Pulses/Rev for installed encoder</li> </ul>

## Step 5 Start-Up Check List

This section describes how you start-up the PowerFlex 700S drive.




**ATTENTION:** Power must be applied to the drive to perform the following start-up procedure. Some of the voltages present are at incoming line potential. To avoid electric shock hazard or damage to equipment, only qualified service personnel should perform the following procedure. Thoroughly read and understand the procedure before beginning. If an event does not occur while performing this procedure, **Do Not Proceed**.

**Remove Power** including user supplied control voltages. User supplied voltages may exist even when main AC power is not applied to then drive. Correct the malfunction before continuing.


**Important:** If you have a DriveLogix™ application, you must first connect the battery before starting this section.

### Before Applying Power to the Drive


- 1. Confirm that motor wires are connected to the correct terminals and are secure.



- 2. Confirm that encoder wires are connected to the correct terminals and are secure.
- 3. Confirm that all control inputs are connected to the correct terminals and are secure.
- 4. Verify that AC line power at the disconnect device is within the rated value of the drive.
- 5. Verify that supply voltage is correct.



The remainder of this procedure requires that a Human Interface Module (HIM) be installed. If an operator interface is not available, remote devices should be used to start-up the drive.



**Applying Power to the Drive**

- ❑ 6. Apply AC power and control voltages to the drive. Examine the *Power (PWR)* LED.

**Table N Drive Status Indicator Descriptions**

#	Name	Color	State	Description		
1	PWR (Power)	Green	Steady	Illuminates when power is applied to the drive.		
		2	STS (Status)	Green	Flashing	Drive ready, but not running & no faults are present.
				Green	Steady	Drive running, no faults are present.
		3	STS (Status)	Yellow	Flashing	When running, a type 2 (non-configurable) alarm condition exists, drive continues to run. When stopped, a start inhibit exists and the drive cannot be started.
				Yellow	Steady	A type 1 (user configurable) alarm condition exists, but drive continues to run.
		4	STS (Status)	Red	Flashing	A fault has occurred.
				Red	Steady	A non-resettable fault has occurred.
5	STS (Status)	Red / Yellow	Flashing Alternately	The drive is in flash recovery mode. The only operation permitted is flash upgrade.		
		3	PORT MOD NET A NET B	Refer to the <i>Communication Adapter User Manual</i>	Status of DPI port internal communications (if present).	
Status of communications module (when installed).						
Status of network (if connected).						
Status of secondary network (if connected).						
4	SYNCHLINK	Green	Steady	<ul style="list-style-type: none"> <li>• The module is configured as the time keeper.</li> <li>or</li> <li>• The module is configured as a follower and synchronization is complete.</li> </ul>		
		Green	Flashing	The follower(s) are not synchronized with the time keeper.		
		Red	Flashing	The module is configured as a time master on SynchLink and has received time information from another time master on SynchLink.		
		ENABLE	Green	On	The drive's enable input is high.	
			Green	Off	The drive's enable input is low.	

- ❑ 7. Examine the *Status (STS)* LED. Verify that it is flashing green. If it is not in this state, check the following possible causes and take the necessary corrective action.

**Table O Common Causes of a Pre-Start Alarm**

Examine Par 156 - Run Inhibit Status			
bit	Description	Action	
1	No power is present at the Enable Terminal TB1 - T7	Apply the enable	
2, 3, 4	A stop command is being issued	Close all stop inputs	
5	Power loss event is in progress, indicating a loss of the AC input voltage	Restore AC power	
6	Data supplied by the power structure EEPROM is invalid or corrupt	Cycle power (wait five (5) minutes before re-applying power to the drive). If problem persists, replace the power structure	
7	Flash Update in Progress	Complete Flash Procedures	
8	Drive is expecting a Start Edge and is receiving a continuous signal	Open all start buttons and remove all start commands	
9	Drive is expecting a Jog Edge and is receiving a continuous signal	Open all jog buttons and remove all jog commands	
10	A conflict exists between the Encoder PPR programming (Par 232 or 242) and the encoder configuration for edge counts (Par 233 or 243, bits 4 & 5)	Verify encoder data and reprogram	
11	The drive cannot precharge because a precharge input is programmed and no signal is present	Reprogram the input or close the precharge control contact	
12	Digital Configuration	Start input configured but stop not configured	Program Par 838-840 to include a stop button, rewire the drive
		Run input configured but control options do not match	Program Par 153, Bit 8 to "0" (2 wire control)
		Start input configured but control options do not match	Program Par 153, Bit 8 to "1" (3 wire control)
		Multiple inputs configured as Start or Run	Reprogram Par 838-840 so multiple starts, multiple runs or any combination do not exist
		Multiple inputs configured as Jog1	Reprogram Par 838-840 so only (1) is set to Jog1
		Multiple inputs configured as Jog2	Reprogram Par 838-840 so only (1) is set to Jog2
14	Invalid Feedback Device for Permanent Magnet Motor Control	Multiple inputs configured as Fwd/Rev	Reprogram Par 838-840 so only (1) is set to Fwd/Rev
			Set Par 222 [Mtr Fdbk Sel] to 5 "FB Opt Port0"

**Table P Common Start-Up Faults**

Fault	Description	Action
Encoder Loss	One of the following has occurred on an encoder: <ul style="list-style-type: none"> <li>missing encoder (broken wire)</li> <li>quadrature error</li> <li>phase loss</li> </ul>	Reconnect encoder or replace encoder.
Motor Overload	A motor overload is pending.	Enter correct motor nameplate full load amps. Par 2 [Motor NP FLA] or reduce excess load.
Motor Poles Fault	The poles of the motor do not match its rating.	Enter correct motor nameplate RPM. Par 4 [Motor NP RPM]

If any digital input is configured to Stop - CF (CF=Clear Faults) verify that the signal is present or that the drive will not start. Refer to Chapter 4 in the *PowerFlex 700S Drives with Phase I Control User Manual*, publication 20D-UM001, for a list of potential digital input conflicts.

If a fault code appears, refer to Chapter 4 in the *PowerFlex 700S Drives with Phase I Control User Manual*, publication 20D-UM001.

The STS LED should be flashing green at this point.

- ❑ 8. Proceed to Step 6 Program the Drive - Start-Up.


**Step 6 Program the Drive – Start-Up**

**Assisted Start**


This routine prompts you for information that is needed to start-up a drive for most applications, such as line and motor data, commonly adjusted parameters and I/O.

- ▶ **Important:** This start-up routine requires a HIM. If the drive is configured for 2-wire control, the HIM installed on the drive will also act as a 2-wire device. In 2-wire mode, the drive will start when the HIM “Start” is pressed and stop when the HIM “Start” is released. The recommended mode of use for a Start-Up Routine is 3-wire control, Parameter 153 [Control Options], Bit 8 set to “1”.

The assisted start-up routine asks simple yes or no questions and prompts you to input required information. Access Assisted Start-Up by selecting “Start-Up” from the Main Menu.


<p>1. To exit the User Display screen Press Esc.</p>		
<p>1. In the Main Menu, use the Down Arrow to scroll to “Start Up”. 2. Press Enter.</p> <p>▶ <b>TIP:</b> Throughout the Start-Up Routine many screens have more selections than shown. Use the arrow keys to scroll through all the menu options.</p>		
<p>1. Follow the instructions on the screen to complete the Start-Up.</p>		

- ▶ **TIP:** If using a HIM the following functions are not available.
  - Alt-Man
  - Alt-Lang
  - Alt-SMART



**Note:** In 2-wire mode, the drive will start when the HIM “Start” is pressed and stop when the HIM “Start” is released. The recommended mode of use for the Start-Up Routine is 3-wire control, Parameter 153 [Control Options], Bit 8 set to “1”.

Parameter Files & Groups



Frequently Used Parameters

Footnote definitions are found on page 36.

No. <sup>(1)</sup>	Name Description <sup>(2)</sup>	Values <sup>(3)</sup>	Linkable	Read-Write	Data Type
1	<b>Motor NP Volts</b> Set to the motor nameplate rated volts.	Units: Volt Default: Calculated Min/Max: 75/705		RW	16-bit Integer
2	<b>Motor NP FLA</b> Set to the motor nameplate rated full load amps. Range limited by three-second inverter rating.	Units: Amps Default: Calculated Min/Max: Calculated/Calculated		RW	Real
3	<b>Motor NP Hertz</b> Set to the motor nameplate rated frequency.	Units: Hz Default: Calculated Min/Max: 2.0000/500.0000		RW	Real
4	<b>Motor NP RPM</b> Set to the motor nameplate rated RPM.	Units: RPM Default: Calculated Min/Max: 1/30000		RW	16-bit Integer
5	<b>Motor NP Power</b> Set to the motor nameplate rated power.	Units: Hp Default: Calculated Min/Max: 0.2500/3500.0000		RW	Real
6	<b>Mtr NP Pwr Units</b> The power units shown on the motor nameplate.	Default: 0 Hp Options: 0 Hp, 1 W			
10	<b>Speed Ref 1</b> Sets the speed reference that the drive should use when selected by Parameter 16 [Speed Ref Sel]. A value of 1.0 represents base speed of the motor.	Default: 0.0000 Min/Max: -/+2200000000.0000	✓	RW	Real
16	<b>Speed Ref Sel</b> Selects the source of the speed reference to the drive.	Default: 1 "Spd Ref DPI" Options: 0 "Zero Speed", 1 "Spd Ref 1", 2 "Spd Ref 2", 3 "Spd Ref 3", 4 "Spd Ref 4", 5 "Spd Ref 5", 6 "Spd Ref DPI"			
30	<b>Rev Speed Limit</b> Sets a limit on the speed reference in the negative direction. This value can be entered as a negative value or zero.	Units: RPM Default: -2205.0000 Min/Max: -14112.0000/0.0000 Comm Scale: Parameter 4 [Motor NP RPM] = 1.0		RW	Real

No.(1)	Name Description (2)	Values (3)	Linkable	Read-Write	Data Type																																																																																																		
31	<b>Fwd Speed Limit</b> Sets a limit on the speed reference in the positive direction. This value can be entered as a positive value or zero.	Units: RPM Default: 2205.0000 Min/Max: 0.0000/14112.0000 Comm Scale: Parameter 4 [Motor NP RPM] = 1.0		RW	Real																																																																																																		
32	<b>Accel Time</b> Sets the rate of acceleration for all speed increases, with time in seconds to base speed. Accel Rate = Parameter 4 [Motor NP RPM] / Parameter 32 [Accel Time]	Units: Sec Default: 10.0000 Min/Max: 0.0100/6553.5000	✓	RW	Real																																																																																																		
33	<b>Decel Time</b> Sets the rate of deceleration for all speed decreases, with time in seconds to base speed. Decel Rate = Parameter 4 [Motor NP RPM] / Parameter 33 [Decel Time]	Units: Sec Default: 10.0000 Min/Max: 0.0100/6553.5000	✓	RW	Real																																																																																																		
34	<b>S Curve Time</b> Sets the S time (Round In and Round Out) in seconds. Half of the time specified is added to the beginning and half to the end of the applied ramp. The S time is independent of speed and results in a trapezoidal torque profile.	Units: Sec Default: 0.5000 Min/Max: 0.0000/4.0000	✓	RW	Real																																																																																																		
90	<b>Spd Reg BW</b> Sets the bandwidth of the speed regulator in rad/sec. Bandwidth is also referred to as the crossover frequency. Small signal time response is approximately 1/BW and is the time to reach 63% of set point. A change to this parameter will cause an automatic update of Parameters 81 [Spd Reg P Gain] and 82 [Spd Reg I Gain]. To disable the automatic gain calculation, set this parameter to a value of zero.  Adjustments to Parameters 474 [Freq Reg We BW] and 475 Freq Reg Wr BW] may be necessary when using sensorless feedback.	Units: R/S Default: 10.0000 Min/Max: 0.0000/500.0000	✓	RW	Real																																																																																																		
153	<b>Control Options</b> Set bits to configure the options for operating the drive.	<table border="1"> <thead> <tr> <th>Options</th> <th>Reserved</th> <th>Reserved</th> <th>Reserved</th> <th>Reserved</th> <th>Reserved</th> <th>Tq Trim En</th> <th>Reserved</th> <th>Reserved</th> <th>Reserved</th> <th>Reserved</th> <th>Reserved</th> <th>Reserved</th> <th>Reserved</th> <th>Reserved</th> <th>Aux Pwr Sply</th> <th>Auto Tach Sw</th> <th>Reserved</th> <th>Reserved</th> <th>OL ClsLpDshl</th> <th>Jog -NoInteg</th> <th>Iq Delay</th> <th>Motor Dir</th> <th>2W CoastStop</th> <th>3WireControl</th> <th>Stop Cndt Tq</th> <th>Stop in Torq</th> <th>Jog - NoRamp</th> <th>Jog in Torq</th> <th>2WCurLimStp</th> <th>Sreg LPF 1</th> <th>SRef Flt En</th> <th>Bipolar SRef</th> </tr> </thead> <tbody> <tr> <td>Default</td> <td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>1</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>1</td> </tr> <tr> <td>Bit</td> <td>31</td><td>30</td><td>29</td><td>28</td><td>27</td><td>26</td><td>25</td><td>24</td><td>23</td><td>22</td><td>21</td><td>20</td><td>19</td><td>18</td><td>17</td><td>16</td><td>15</td><td>14</td><td>13</td><td>12</td><td>11</td><td>10</td><td>9</td><td>8</td><td>7</td><td>6</td><td>5</td><td>4</td><td>3</td><td>2</td><td>1</td><td>0</td> </tr> </tbody> </table> <p>0 = False 1 = True</p>	Options	Reserved	Reserved	Reserved	Reserved	Reserved	Tq Trim En	Reserved	Reserved	Reserved	Reserved	Reserved	Reserved	Reserved	Reserved	Aux Pwr Sply	Auto Tach Sw	Reserved	Reserved	OL ClsLpDshl	Jog -NoInteg	Iq Delay	Motor Dir	2W CoastStop	3WireControl	Stop Cndt Tq	Stop in Torq	Jog - NoRamp	Jog in Torq	2WCurLimStp	Sreg LPF 1	SRef Flt En	Bipolar SRef	Default	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0	1	Bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0			
Options	Reserved	Reserved	Reserved	Reserved	Reserved	Tq Trim En	Reserved	Reserved	Reserved	Reserved	Reserved	Reserved	Reserved	Reserved	Aux Pwr Sply	Auto Tach Sw	Reserved	Reserved	OL ClsLpDshl	Jog -NoInteg	Iq Delay	Motor Dir	2W CoastStop	3WireControl	Stop Cndt Tq	Stop in Torq	Jog - NoRamp	Jog in Torq	2WCurLimStp	Sreg LPF 1	SRef Flt En	Bipolar SRef																																																																							
Default	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0	1																																																																								
Bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0																																																																							
222	<b>Motor Fdbk Sel</b> Enter or write a value to select the primary motor speed feedback device.	Default: 0 "Encoder 0" Options: 0 "Encoder 0" 4 "Motor Sim" 1 "Encoder 1" 5 "FB Opt Port0" 2 "Sensorless" 6 "FB Opt Port1" 3 "Reserved"																																																																																																					
800	<b>Anlg In1 Data</b> Displays the value of Analog Input 1. This is the final value (after conversion, offsetting, scaling and filtering).	Default: 0.0000 Min/Max: -/+2200000000.0000			Real																																																																																																		
802	<b>Anlg In1 Scale</b> Scales the range of Analog Input 1 to the range of Parameter 800 [Anlg In1 Data]. Parameter 801 [Anlg In1 Volts] is multiplied by this number to produce the input to the lead lag filter function. Par 802 = 1, Par 800 = 10 when 10V is applied.	Units: /1v Default: 0.0000 Min/Max: -/+2200000000.0000	✓	RW	Real																																																																																																		
803	<b>Anlg In1 Offset</b> Applies an offset to Analog Input 1. The output of the analog to digital conversion is summed with this number to produce Parameter 801 [Anlg In1 Volts]. This is used to zero out the analog input.	Units: Volt Default: 0.0000 Min/Max: -/+20.0000	✓	RW	Real																																																																																																		
806	<b>Anlg In2 Data</b> Displays the value of Analog Input 2. This is the final value (after conversion, offsetting, scaling and filtering).	Units: 0.0000 Default: 0.0000 Min/Max: -/+2200000000.0000			Real																																																																																																		
808	<b>Anlg In2 Scale</b> Scales the range of Analog Input 1 to the range of Parameter 806 [Anlg In2 Data]. Parameter 807 [Anlg In2 Volts] is multiplied by this number to produce the input to the lead lag filter function.	Units: /1v Default: 0.0000 Min/Max: -/+2200000000.0000	✓	RW	Real																																																																																																		
809	<b>Anlg In2 Offset</b> Applies an offset to Analog Input 1. The output of the analog to digital conversion is summed with this number to produce Parameter 807 [Anlg In2 Volts].	Units: Volt Default: 0.0000 Min/Max: -/+20.0000	✓	RW	Real																																																																																																		
838	<b>DigIn1 Sel</b> Enter or write a value to select the function of digital input 1.	Default: 0 "Not Used" Options: 0 "Not Used" 8 "Fwd/Reverse" 1 "Normal Stop" 9 "CurLim Stop" 2 "Start" 10 "Coast Stop" 3 "Run" 11 "Aux Fault" 4 "Clear Faults" 12 "AuxFault Inv" 5 "Stop - CF" 13 "User Select" 6 "Jog 1" 14 "PreChrg/Disc" 7 "Jog 2"																																																																																																					

No. (1)	Name Description (2)	Values (3)	Linkable	Read-Write	Data Type
839	<b>DigIn2 Sel</b> Enter or write a value to select the function of digital input 2.	Default: 4 "Norm Stop-CF" Options: 0 "Not Used" 13 1 "Normal Stop" 14 2 "Start" 15 3 "Run" 16 4 "Clear Faults" 17 5 "Stop-CF" 18 6 "Jog 1" 19 7 "Jog 2" 21 8 "Fwd/Reverse" 22 9 "CurLim Stop" 23 10 "Coast Stop" 24 11 "Aux Fault" 25 12 "AuxFault Inv"	13	"User Select"	
840	<b>DigIn3 Sel</b> Enter or write a value to select the function of digital input 3.	Default: 0 "Not Used" Options: 0 "Not Used" 13 1 "Normal Stop" 14 2 "Start" 15 3 "Run" 16 4 "Clear Faults" 17 5 "Stop-CF" 18 6 "Jog 1" 19 7 "Jog 2" 21 8 "Fwd/Reverse" 22 9 "CurLim Stop" 23 10 "Coast Stop" 24 11 "Aux Fault" 25 12 "AuxFault Inv"	13	"User Select"	

(1) No. - Parameter Number

 - Parameter value cannot be changed until the drive is stopped.

(2) Name - Parameter name as it appears in DriveExecutive software.

Description - Brief description of parameter function.

(3) Values - Define the various operating characteristics of the parameter. There are 3 types of Values: ENUM, Bit and Numeric.

## DriveLogix™ Recommended Programming Techniques

1. Tag naming:
  - a) Use a convention when naming tags and consistently follow the convention set.
  - b) Add descriptions for each tag when creating the tag.
  - c) Example convention (used at Allen-Bradley):
    - i. <prefix>\_<function>\_<suffix>
    - ii. **prefix** - use to identify the machine section in multi-section programs.
      - 1) Sct1 = Section 1, or Fan2 = Fan 2, or RewA = Rewind A
    - iii. **function** - use to describe the function or signal of the tag.
    - iv. **suffix** - use to identify the units of the signal or control status.
      - 1) Rpm = Rotations per Minute, or Ok = status OK, or Off = contact Off
    - v. Example: Sct2\_SpdRef\_Fpm, Fan5\_FaultState\_OK
2. Use Aliasing for all Static Assembly connections with DriveLogix and the PowerFlex® 700S.
  - a) Improves program portability over processors and through upgrades to DriveLogix, PowerFlex 700S, and RSLogix™ 5000 firmware.
  - b) Allows real names to be applied to the User Defined tags of the static assembly.
  - c) Allows new functions of DriveLogix and the PowerFlex 700S to be clearly named in the program even if RSLogix 5000 has not been updated.
  - d) Allows long tag names in RSLogix 5000 to be shortened for easier program viewing.
  - e) Allows tags to be named using the above naming convention to identify machine section association.
  - f) Apply aliases to all external connections including the PowerFlex 700S static assembly and I/O. All defined bits should be included.
3. Use "Periodic Tasks" to optimize processor utilization.
  - a) Name periodic tasks to identify the update time.
    - i. Ex. Periodic\_020ms\_P9 = 20ms task with priority 9
  - b) Set the periodic task time appropriate programming requirements.  
**Note:** the faster the task time (function execution) the more processor bandwidth used.
  - c) Set the priority of each task to coincide with the task speed. Set faster tasks to higher priority (lower number = higher priority, i.e, 9 is a higher priority than 10)
  - d) Do not set the priority number lower than 8 (recommended priority range is 8-15). This will provide I/O scanning with optimal updating. Flex I/O is coded as priority 7 for DriveLogix.

## Troubleshooting

### Abbreviated Fault & Alarm Clearing

For a complete listing of Faults and Alarms, refer to the *PowerFlex® 700S Drives with Phase I Control User Manual*, publication 20D-UM001.

A fault is a condition that stops the drive. There are two fault types.

Type	Fault Description
①	<p>Non-Resettable</p> <p>This type of fault normally requires drive or motor repair. The cause of the fault must be corrected before the fault can be cleared. The fault will be reset on power up after repair.</p>
②	<p>User Configurable</p> <p>Programming and commissioning personnel can configure the drive's response to these exception events. Responses include:</p> <ul style="list-style-type: none"> <li>• Ignore</li> <li>• Alarm</li> <li>• Fault Coast Stop</li> <li>• Fault Ramp Stop</li> <li>• Fault Current Limit Stop</li> </ul>

### HIM Indication

The HIM also provides visual notification of a fault or alarm condition.

Condition	Display
<p><b>Drive is indicating a fault.</b></p> <p>The LCD HIM immediately reports the fault condition by displaying the following:</p> <ul style="list-style-type: none"> <li>• "Faulted" appears in the status line</li> <li>• Fault number</li> <li>• Fault name</li> <li>• Time that has passed since fault occurred</li> </ul> <p>Press <b>Esc</b> to regain HIM control.</p>	

### Manually Clearing Faults

This section illustrates a table showing the HIM keystrokes necessary to clear faults.

Step	Key(s)
1. Press <b>Esc</b> to acknowledge the fault. The fault information will be removed so that you can use the HIM.	
2. Address the condition that caused the fault. The cause must be corrected before the fault can be cleared.	
3. After corrective action has been taken, clear the fault by one of these methods. <ul style="list-style-type: none"> <li>• Press <b>Stop</b></li> <li>• Cycle drive power (wait five (5) minutes before re-applying power to the drive)</li> <li>• Select <b>Clear Faults</b> from "Diagnostic - Faults" menu</li> </ul>	

## Technical Support

### Online

You can access the complete *PowerFlex 700S User Manual*, publication 20D-UM001, online at:

<http://www.rockwellautomation.com/literature>

PowerFlex 700S and DriveLogix™ Technical Support is available online

**Important:** You are encouraged to navigate our **free** website as part of your installation and start-up process.

You will have complete access to the following information:

- Firmware Updates
- Tech Tips
- Application Guides
- Knowledgebase Documents
- Product Specifications
- Technical Publications

You will find the information on the website to be useful, as well as important in the application, installation and troubleshooting of a PowerFlex® 700S and DriveLogix™ System.

These simple steps will guide you to our website so you can obtain the information needed to help solve your most difficult problems.

Here's how...

1. Open your Internet Browser, this may be: Microsoft® Internet Explorer, Netscape®, or Opera®.
2. With your browser open, type in the following URL address in your path bar.

<http://www.ab.com/support/abdrives/powerflex700s/>

3. Press the **Enter** key or click the **Go** button. This will take you to our website.

### Drives Technical Forum

Remember that we currently offer a *Drives Technical Forum* for all Allen-Bradley® drive products. The forum can also help you solve issues in areas such as *Applications*, *Communications*, *Hardware* and *Software*. You can visit us at the following URL address...

<http://www.ab.com/support/abdrives/registered.html>

### Telephone

Drives Technical Support Hotline:

Monday through Friday, 7:00a.m. to 6:00p.m. Central time

Call **1-262-512-8176**

## Notes:

PowerFlex, DriveLogix, Logix, FlexLogix, NetLinx, DriveExecutive, DriveObserver, DriveExpert, FORCE Technology, Zero Stacking, Flex I/O, FlexLogix, DriveTools, RSLogix 5000, SynchLink and SCANPort are trademarks of Rockwell Automation. ControlNet is a trademark of ControlNet International, Ltd. DeviceNet is a trademark of the Open DeviceNet Vendor Association.



[www.rockwellautomation.com](http://www.rockwellautomation.com)

---

### Power, Control and Information Solutions Headquarters

Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444

Europe/Middle East/Africa: Rockwell Automation, Vorstlaan/Boulevard du Souverain 36, 1170 Brussels, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640

Asia Pacific: Rockwell Automation, Level 14, Core F, Cyberport 3, 100 Cyberport Road, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846