

# MM300 Series



## MODELS:

**MM301U**

**MM311U**

**U  
s  
e  
r  
'  
s  
  
M  
a  
n  
u  
a  
l**

Isolated Input, Dual Voltage, Variable Speed SCR  
Drives for Brush Motors


Copyright © 2005 by  
Minarik Corporation

All rights reserved. No part of this manual may be reproduced or transmitted in any form without written permission from Minarik Corporation. The information and technical data in this manual are subject to change without notice. Minarik Corporation and its Divisions make no warranty of any kind with respect to this material, including, but not limited to, the implied warranties of its merchantability and fitness for a given purpose. Minarik Corporation and its Divisions assume no responsibility for any errors that may appear in this manual and make no commitment to update or to keep current the information in this manual.

Printed in the United States of America.

---

# Safety Warnings

This symbol  denotes an important safety tip or warning. Please read these sections carefully prior to performing any of the instructions contained in that section.

- Have a qualified electrical maintenance technician install, adjust and service this equipment. Follow the National Electrical Code and all other applicable electrical and safety codes, including the provisions of the Occupational Safety and Health Act (OSHA), when installing equipment.
- Reduce the chance of an electrical fire, shock, or explosion by proper grounding, over-current protection, thermal protection, and enclosure. Follow sound maintenance procedures.
- **It is possible for a drive to run at full speed as a result of a component failure.** Please ensure that a master switch has been placed in the AC line to stop the drive in an emergency.
- **This drive is isolated from earth ground.** Circuit potentials are at 115 VAC or 230 VAC above earth ground. Avoid direct contact with the printed circuit board or with circuit elements to prevent the risk of serious injury or fatality. Use a non-metallic screwdriver for adjusting the calibration trim pots.

---

# Contents

<b>Safety Warnings</b> .....	<b>i</b>
<b>Specifications</b> .....	<b>1</b>
<b>Dimensions</b> .....	<b>3</b>
<b>Installation</b> .....	<b>5</b>
Wiring .....	5
Shielding Guidelines .....	6
Chassis Drives (MM301U, MM311U) .....	7
Mounting .....	7
Heatsinking .....	8
Line Fusing .....	8
Speed adjust potentiometer .....	10
Cage-clamp terminals .....	11
Connections .....	12
Motor .....	12
Power Input .....	14
Field Output .....	14
START/STOP pushbuttons .....	15
Tachometer feedback .....	15
Voltage or current follower .....	16
Slide switches .....	17

---

<b>Operation</b> .....	<b>19</b>
Before applying power (all models) .....	19
Chassis Drives (MM301U, MM311U) .....	19
Diagnostic LEDs .....	21
Line starting and line stopping .....	22
Decelerating to minimum speed .....	22
Dynamic braking .....	23
Dynamic brake resistor value .....	23
<b>Calibration</b> .....	<b>26</b>
Drive Calibration Procedure .....	28
MINIMUM SPEED (MIN SPD) .....	29
MAXIMUM SPEED (MAX SPD) .....	29
CURRENT LIMIT .....	30
IR COMPENSATION (IR COMP) .....	31
ACCELERATION (ACCEL) .....	33
DECELERATION (DECEL) .....	33
TACH VOLTS .....	34
<b>Application Notes</b> .....	<b>36</b>
Multiple fixed speeds .....	36
Adjustable speeds using potentiometers in series .....	36
Independent adjustable speeds .....	37
Reversing .....	38
RUN/JOG switch .....	40
Reversing with a DIGI=LOK Controller, Model DLC600 .....	41

<b>Troubleshooting</b> .....	<b>.42</b>
<b>Certificate of Compliance</b> .....	<b>.48</b>
<b>Unconditional Warranty</b> .....	<b>.51</b>

---

# Illustrations

Fig.	Description	Page
1.	MM301U and MM311U Dimensions .....	3
2.	MM300 Series Layout .....	4
3.	Speed Adjust Potentiometer .....	10
4.	Cage-Clamp Terminal .....	11
5.	MM301U and MM311U AC Line, Motor and Field Connections .....	13
6.	Signal Follower Connection .....	16
7.	Slide Switches .....	18
8.	Current Limit and Power LEDs .....	21
9.	Run/Decelerate to Minimum Speed Switch .....	23
10.	Dynamic Brake Connection .....	24
11.	Calibration Trimpot Layout .....	27
12.	Typical CURRENT LIMIT, and IR COMP Settings for MM311U and MM301U (actual settings may vary with each application) .....	32
13.	Multiple Fixed Speeds .....	36
14.	Adjustable Fixed Speeds Using Potentiometers in Series .....	37
15.	Independent Adjustable Speeds .....	38
16.	Reversing Circuit Connection .....	39
17.	RUN/JOG Switch Connection to Speed Adjust Potentiometer .....	40
18.	Reversing with a DLC600 .....	41
19.	MM301U and MM311U Block Diagram .....	46

---

# Tables

Fig.	Description	Page
1.	Recommended Line Fuse Sizes .....	9
2.	Field Output Connections for Chassis Drives .....	14
3.	Replacement Parts .....	47
4.	Corcom® Filters .....	49
5.	Minarik Filters .....	49



# Specifications

<b>Model</b>	<b>Max. Armature Current (Amps DC)</b>	<b>HP Range with 115 VAC Applied</b>	<b>HP Range with 230 VAC Applied</b>
MM301U	10.0	1/4–1	1/2–2
MM311U	3.0	1/20–1/8	1/10–1/4

<b>AC Line Voltage</b>	115 VAC or 230 V AC, 50 or 60 Hz, 1 Phase
<b>Armature Voltage (115 VAC Input)</b>	0–90 VDC
<b>Armature Voltage (230 VAC Input)</b>	0–180 VDC
<b>Form Factor</b>	1.37 at base speed
<b>Field Voltage (115 VAC)</b>	50 VDC (F1 to L1); 100 VDC (F1 to F2)
<b>Field Voltage (230 VAC)</b>	100 VDC (F1 to L1); 200 VDC (F1 to F2)
<b>Maximum Field Current</b>	1 ADC
<b>Acceleration Time Range (with no load)</b>	1-11 seconds
<b>Deceleration Time Range (with no load)</b>	1-11 seconds
<b>Analog Input Voltage Range (S1 to S2)</b>	0-10 VDC or 4-20 mADC
<b>Input Impedance (S1 to S2)</b>	>100K ohms
<b>Load Regulation (% of base speed)</b>	
<b>with Armature Feedback</b>	1% or better
<b>with Tachogenerator Feedback</b>	0.1%
<b>Vibration</b>	0.5G max. (0-50 Hz); 0.1G max. (>50 Hz)

## 2 Specifications

---

### **Ambient Temperature Range**

---

Open Chassis	10°C-55°C
--------------	-----------

---

### **Weight**

---


Open Chassis	2.1 lbs (953 grams)
--------------	---------------------

---

<b>Tachogenerator Feedback Voltage Range</b>	7-50 VDC per 1000RPM
--	----------------------

---

# Dimensions



SIX (6) MOUNTING SLOTS  
0.18 [5] WIDE x 0.30 [8] DEEP

ALL DIMENSIONS IN INCHES [MILLIMETERS]

Figure 1. MM301U and MM311U Dimensions




Figure 2. MM300 Series Layout

---

# Installation

## Wiring

Use 12 AWG wire for the AC line voltage (L1 and L2), motor armature (A1 and A2), and dynamic brake resistor (if used). Use 18 AWG wire for logic (field output, speed adjust potentiometer, tachogenerator, etc.)

Twist logic wires to avoid picking up unwanted electrical noise. Use shielded cable if wires are longer than 12 inches (30 cm).

Do not bundle logic wires with power carrying wires. This can cause erratic operation. Keep logic wires in a conduit separated by at least 2 inches from power carrying wires. Do not allow logic wires to travel in parallel to power carrying wires for more than 1 inch.

It may be necessary to earth ground the shielded cable. If noise is produced by devices other than the drive, ground the shield at the drive end. If noise is generated by a device on the drive, ground the shield at the end away from the drive. Do not ground both ends of the shield.

## Shielding guidelines



### Warning

Under no circumstances should power and logic leads be bundled together. Induced voltage can cause unpredictable behavior any electronic device, including motor controls.

As a general rule, Minarik recommends shielding of all conductors. If it is not practical to shield power conductors, Minarik recommends shielding all logic-level leads. If shielding logic level leads is not practical, the user should twist all logic leads with themselves to minimize induced noise.

It may be necessary to earth ground the shielded cable. If noise is produced by devices other than the drive, ground the shield at the drive end. If noise is generated by a device on the drive, ground the shield at the end away from the drive. Do not ground both ends of the shield.

If the drive continues to pick up noise after grounding the shield, it may be necessary to add AC line filtering devices, or to mount the drive in a less noisy environment.

Logic wires from other input devices, such as motion controllers and PLL velocity controllers, must be separated from power lines in the same manner as the logic I/O on this drive.

---

## Chassis Drives (MM301U, MM311U)

### Mounting

Mount the drive with its board in either a horizontal or vertical plane. Four 0.188 inch (4.8 mm) wide slots in the chassis accept #8 pan head screws.

The chassis units do not have to be earth grounded. If you choose to ground the chassis, use a star washer beneath the head of at least one of the mounting screws to penetrate the anodized chassis surface and to reach bare metal.

Drive components are sensitive to electrostatic fields. Avoid contact with the circuit board directly. Hold the drive by the chassis only.

Protect the drive from dirt, moisture, and accidental contact. Provide sufficient room for access to the terminal block and calibration trim pots.

Mount the drive away from other heat sources. Operate the drive within the specified ambient operating temperature range.

Prevent loose connections by avoiding excessive vibration of the drive.

Observe the following guidelines when installing an isolation transformer:

- A power disconnecting device must be installed between the power line and primary of the transformer.
- If the power disconnecting device is a circuit breaker, the circuit breaker trip rating must be coordinated with the in-rush current (10-12 times full load current) of the transformer.

## Heatsinking

The MM301U and MM311U contain sufficient heat sinking in its original configuration. No additional heat sinking is necessary when installed in accordance with the guidelines specified in this instruction manual. The chassis plate acts as the thermal heatsink.

## Line fusing

MM300 Series drives have line fuses mounted on fuse holders 501 and 502 (FU501 and FU502). See the Replacement Parts section for preinstalled line fuse size. When replacing the line fuses, use fast acting fuses rated for 250 VAC or higher, and at least 200% of the armature current. See Figure 2, page 4, for fuse holder location, and Table 1 for recommended line fuse sizes.



**Table 1. Recommended Line Fuse Sizes**

90 VDC Motor Horsepower	180 VDC Motor Horsepower	Max. DC Armature Current (amps)	AC Line Fuse Size (amps)
1/20	1/10	0.5	3
1/15	1/8	0.8	3
1/8	1/4	1.5	5
1/6	1/3	1.7	5
1/4	1/2	2.6	8
1/3	3/4	3.5	8
1/2	1	5.0	10
3/4	1 1/2	7.6	15

Minarik Corporation offers a 63 mA pico fuse (part number 050-0081) which protects the the transformer and logic.

## Speed adjust potentiometer

Install the circular insulating disk between the mounting panel and the 10K ohm speed adjust potentiometer (see Figure 3). Mount the speed adjust potentiometer through a 0.38 inch (10 mm) hole with the hardware provided. Twist the speed adjust potentiometer wire to avoid picking up unwanted electrical noise. If potentiometer leads are longer than 18 inches (46 cm), use shielded cable.

Alternate speed adjust potentiometer connections may be found in the Application Notes section of this user guide.

**Note:** The user may choose to install a 5K ohm speed adjust potentiometer; however, the MIN SPD and MAX SPD trim pots must be recalibrated if the 5K ohm potentiometer is used.





Figure 3. Speed Adjust Potentiometer

## Cage-clamp terminals

Logic connections are made to a cage-clamp terminals. To insert a wire into the cage-clamp terminal:




**Figure 4. Cage-Clamp Terminal**

## Connections

### Motor

Connect a motor to terminals A1 and A2 as shown in Figure 5. Ensure that the motor voltage rating is consistent with the drive's output voltage.

Minarik drives supply motor voltage from A1 and A2 terminals (TB501). It is assumed throughout this manual that when A1 is positive with respect to A2, the motor will rotate clockwise (CW) while looking at the output shaft protruding from the front of the motor. If this is opposite of the desired rotation, simply reverse the wiring of A1 and A2 with each other.



**Figure 5. MM301U and MM311U AC Line, Motor and Field Connections**

## Power Input

Connect the AC line power leads to terminals L1 and L2 and install a master power switch in the voltage input line as shown in Figure 5. The switch contacts should be rated at a minimum of 250 volts and 200% of maximum drive current.

## Field output

The field output is for shunt wound motors only. **Do not make any connections to F1 and F2 (TB501) when using a permanent magnet motor.** See Table 2 for field output connections.

**Table 2. Field Output Connections for Chassis Drives**

<b>Line Voltage (VAC)</b>	<b>Approximate Field Voltage (VDC)</b>	<b>Connect Motor Field To</b>
115	50	F1 and L1
115	100	F1 and F2
230	100	F1 and L1
230	200	F1 and F2

---

## **START/STOP pushbuttons**

Pushbutton operation of the MM301U requires a momentary normally open STOP pushbutton be wired to terminals B2 and B3 and a momentary normally closed START pushbutton wired to terminals B1 and B2. These switches must be used together and are not included with the drive. The B1, B2 and B3 terminals are on terminal block TB502.

If the START/STOP pushbuttons are not used, wire a jumper between terminals B1 and B3 to bypass the latching circuit. The drive will then operate in a power-up start mode. See Figure 5 (page 13) for these switch connections.

## **Tachometer feedback**

Using tachometer feedback improves speed regulation from approximately 1% of motor base speed to approximately 0.1% of motor base speed. Use tachometers rated from 7 VDC per 1000 RPM to 50 VDC per 1000 RPM. Connect the tachometer to terminals T1 and T2 of terminal block 502 (TB502). Place SW504 in the TACH position. See Figure 5 (page 13) for tachometer connections. The TACH trimpot trim-pot must be adjusted prior to operating with tachometer feedback. Refer to the Calibration section for instructions on calibrating the TACH trimpot.

## Voltage or current follower

Instead of using a speed adjust potentiometer, MM300 Series drives may be wired to follow an analog input signal (see Figure 6 for connections). This input signal can be in the form of voltage (0-10 VDC) or current (4-20 mA). Because these drives have built in isolation the input signal can be either grounded or ungrounded. The signal slide switch must also be set for current or voltage input (see Slide switches section).




Figure 6. Signal Follower Connection



## Slide switches

### **Warning**

Change slide switch settings only when the drive is disconnected from the AC line voltage. Make sure both line voltage and motor switches are set to their correct position. If the switches are improperly set to a lower voltage position, the motor will not run at full voltage and may cause transformer damage. If the switches are improperly set to a higher voltage position, the motor will over-speed, which may cause motor damage.

### **LINE VOLTAGE (SW501 and SW502)**

Select the appropriate line voltage: 115 for 115 VAC line voltage, or 230 for 230 VAC line voltage.

### **MOTOR (SW503)**

Select the maximum armature voltage: 90V for 90 VDC motors, or 180V for 180 VDC motors.


### **SIGNAL (SW504)**

Select the input signal being used: CURR for current input signal, or VOLT for voltage input signal or speed adjust potentiometer input.

**FEEDBACK (SW505)**

Select the appropriate feedback option: ARMATURE for armature feedback, or TACH for tachometer feedback.

See Figure 7 for all slide switch locations.



**Figure 7. Slide Switches**

---

# Operation

## Before applying power

1. Set LINE VOLTAGE SELECT switches SW501 and SW502 to either 115V or 230V to match the AC line voltage.
2. Set ARMATURE VOLTAGE SELECT switch SW503 to either 90V or 180V to match the maximum armature voltage.
3. Set SIGNAL SELECT switch SW504 to CURR if using a 4-20 mADC current signal; set it to VOLT if using a 0-10VDC voltage signal or the speed adjust potentiometer.
4. Verify that no conductive material is present on the printed circuit board.
5. If using a 90 VDC or 130 VDC motor with 230 VAC line voltage, derate the nameplate motor torque by at least 30%. The form factor will increase beyond the typical value, causing increased motor heating. Contact the factory for details.

## Chassis Drives (MM301U, MM311U)

### **Speed adjust potentiometer input, no START/STOP pushbutton:**

It is necessary to wire a jumper between B1 and B3 if no START/STOP switches are to be used.

1. Turn the speed adjust potentiometer full counterclockwise (CCW).

2. Apply AC line voltage.
3. Slowly advance the speed adjust potentiometer clockwise (CW). The motor slowly accelerates as the potentiometer is turned CW. Continue until the desired speed is reached.
4. Remove AC line voltage to coast the motor to a stop.

**Speed adjust potentiometer input with START/STOP pushbuttons:**

1. Turn the speed adjust potentiometer full counterclockwise (CCW).
2. Apply AC line voltage.
3. Press the START pushbutton.
4. Slowly advance the speed adjust potentiometer clockwise (CW). The motor accelerates as the potentiometer is turned clockwise. Continue until desired speed is reached.
5. Press STOP pushbutton to coast motor to a stop.

**Analog signal input, no START/STOP pushbuttons:**

It is necessary to wire a jumper between B1 and B3 if no START/STOP switches are to be used.


1. Set the analog signal so that it is at its lowest level (0V or 4mA).
2. Apply AC line voltage.
3. Slowly increase the analog signal. The motor accelerates as the signal is increased. Continue increasing signal until desired speed is reached.
4. Remove AC line voltage to coast the motor to a stop.

**Analog signal input with START/STOP pushbuttons:**

1. Set the analog signal so that it is at its lowest level (0V or 4mA).
2. Apply AC line voltage.
3. Press the START pushbutton.
4. Slowly increase the analog signal and press the start pushbutton. The motor accelerates as the signal is increased. Continue increasing signal until desired speed is reached.
5. Press STOP pushbutton to coast motor to a stop.

**Diagnostic LEDs**

MM300 Series drives are equipped with two diagnostic LEDs (see Figure 8 for LED location). The red current limit LED turns on whenever the drive reaches current limit and stays off whenever the drive is not in current limit (normal operation). The green power LED turns on whenever AC line voltage is applied to the drive and stays off whenever there is no AC line voltage applied to the drive.

**Figure 8. Current Limit and Power LEDs**

## Line starting and line stopping

Line starting and line stopping (applying and removing AC line voltage) is recommended for infrequent starting and stopping of a drive only. When AC line voltage is applied to the drive and a START is commanded, the motor accelerates to the speed set by the speed adjust potentiometer or analog input signal. When AC line voltage is removed, the motor coasts to a stop.

## Decelerating to minimum speed

The circuit shown in Figure 9 may be used to decelerate a motor to a minimum speed. Closing the switch between S1 and S2 decelerates the motor from set speed to a minimum speed determined by the MIN SPD trimpot setting. If the MIN SPD trimpot is set full CCW, the motor decelerates to zero speed when the switch between S1 and S2 is closed. The DECEL trimpot setting determines the rate at which the drive decelerates. By opening the switch the motor accelerates to set speed at a rate determined by the ACCEL trimpot setting.




Figure 9. Run/Decelerate to Minimum Speed Switch

## Dynamic Braking


Dynamic braking may be used to rapidly stop a motor (Figure 10). For the RUN/BRAKE switch, use a three pole, double throw switch rated for at least the maximum DC armature voltage, 15 amps. For the dynamic brake resistor, use a 40 Watt minimum, high power, wirewound resistor.

### Dynamic Brake Resistor Value

Sizing the dynamic brake resistor depends on load inertia, motor voltage and braking time. Use a lower-value, higher wattage dynamic brake resistor to stop a motor more rapidly. A good starting point is a 40 Ohm, 40 Watt.

**⚠ Warning**

Wait for the motor to completely stop before switching it back to RUN. This will prevent high armature currents from damaging the motor.



**Figure 10. Dynamic Brake Connection**





## Warning

For frequent starts and stops, use coasting to a stop with a STOP push-button, decelerating to minimum speed (shorting S2 and S1 to each other), or dynamic braking. Do not use any of these methods for emergency stopping. They may not stop a drive that is malfunctioning. Removing AC line power (both L1 and L2) is the only acceptable method for emergency stopping.

Frequent starts and stops, coasting to a stop, decelerating to minimum speed, and dynamic braking produce high current. This may cause damage to motors, especially gearmotors that are not properly sized for the application.

# Calibration



## Warning

Dangerous voltages exist on the drive when it is powered. When possible disconnect the voltage input from the drive before adjusting the trim-pots. If the trim-pots must be adjusted with power applied, use insulated tools and the appropriate personal protection equipment. BE ALERT. High voltages can cause serious or fatal injury.

The control circuit is at line potential when the drive is energized. Exercise extreme caution as hazardous voltages exist.

MM300 Series drives have seven user adjustable trim-pots. Each drive is factory calibrated to its maximum current rating. Readjust the calibration trim-pot settings to accommodate lower current rated motors.

All adjustments increase with CW rotation, and decrease with CCW rotation. Use a non-metallic screwdriver for calibration. Each trim-pot is identified on the printed circuit board. Refer to Figure 11 for trim-pot layouts.




Figure 11. Calibration Trimpot Layout

## Drive Calibration Procedure

Prepare the MM300 series drive for calibration as follows. This procedure applies to both chassis and enclosed drives.

1. Ensure that no power is applied to the drive.
2. If you use an enclosed drive, you must open the drive cover to gain access to the trimpots. Turn the slotted screw on the front cover counterclockwise until it is free from the enclosure. The right side of the cover is hinged to the enclosure. Pull the slotted screw to open the enclosure.
3. Set all trimpots except CURRENT LIMIT and TACH VOLTS full counterclockwise (CCW).
4. Set the CURRENT LIMIT trimpot full clockwise (CW).
5. Make no adjustment to the TACH VOLTS trimpot unless tachometer feedback is used. If you use tachometer feedback, set the TACH VOLTS trimpot to the center of travel (12 o'clock position).
6. Adjust the trimpots in the following order:
  - a. MINIMUM SPEED (MIN SPD)
  - b. MAXIMUM SPEED (MAX SPD)
  - c. CURRENT LIMIT
  - d. IR COMPENSATION (IR COMP)
  - e. ACCELERATION (ACCEL)
  - f. DECELERATION (DECEL)
  - g. TACH VOLTS (if used)

---

## MINIMUM SPEED (MIN SPD)

The MIN SPD setting determines the motor speed when the speed adjust potentiometer or input signal is set for minimum speed. It is factory set to zero speed.

To calibrate MIN SPD:

1. Turn the speed adjust potentiometer full CCW or set the input signal for minimum voltage or current.
2. Adjust the MIN SPD trimpot until the motor has stopped, or is running at the desired minimum speed.

## MAXIMUM SPEED (MAX SPD)

The MAX SPD setting determines the motor speed when the speed adjust potentiometer or input signal is set for maximum speed. It is factory set for maximum rated motor speed.

To calibrate MAX SPD:

1. Set the MAX SPD trimpot full CCW.
2. Turn the speed adjust potentiometer full CW or set the input signal for maximum speed.
3. Adjust the MAX SPD trimpot until the desired maximum motor speed is reached.

*Note:* Check the MIN SPD and MAX SPD settings after recalibrating to verify that the motor runs at the desired minimum and maximum speeds.

## CURRENT LIMIT

The CURRENT LIMIT setting determines the maximum armature current output of the drive. It is factory set at 120% of rated motor current.

To calibrate CURRENT LIMIT, refer to Figure 12 (page 32), or use the following procedure:

1. With the power disconnected from the drive, connect a DC ammeter in series with the armature.
2. Set the CURRENT LIMIT trimpot to minimum (full CCW).
3. Lock the motor armature. Be sure that the motor is firmly mounted.
4. Connect power to the drive. The motor should remain stopped.
5. Set the speed adjust potentiometer or input signal for maximum speed.
6. Adjust the CURRENT LIMIT trimpot slowly CW until the armature current is 120% of motor rated current.
7. Set the speed adjust potentiometer or input signal for zero speed.
8. Remove power from the drive.
9. Remove the stall from the motor.

---

## IR COMPENSATION (IR COMP)

The IR COMP setting determines the degree to which motor speed is held constant as the motor load changes. It is factory set at optimum motor regulation for the highest motor horsepower.

To calibrate IR COMP, refer to Figure 12 (page 32), or use the following procedure:

1. Turn the IR COMP trimpot full CCW.
2. Set the speed adjust potentiometer or input signal until the motor runs at midspeed without load (for example, 900 RPM for an 1800 RPM motor). A hand held tachometer may be used to measure motor speed.
3. Load the motor armature to its full load armature current rating. The motor should slow down.
4. While keeping the load on the motor, rotate the IR COMP trimpot until the motor runs at the speed measured in step 2.

### *Approximate calibration:*

If the motor does not maintain set speed as the load changes, gradually rotate the IR COMP trimpot CW. If the motor oscillates (overcompensation), the IR COMP trimpot may be set too high (CW). Turn the IR COMP trimpot CCW to stabilize the motor speed.

## MM311U

CURRENT  
LIMITIR  
COMP1/8 HP  
90 VDC  
1750 RPM  
1.3 ADCCURRENT  
LIMITIR  
COMP1/4 HP  
180 VDC  
1750 RPM  
1.4 ADCCURRENT  
LIMITIR  
COMP1/10 HP  
90 VDC  
1750 RPM  
5 ADCCURRENT  
LIMITIR  
COMP1/8 HP  
180 VDC  
1750 RPM  
0.8 ADCCURRENT  
LIMITIR  
COMP1/15 HP  
90 VDC  
1750 RPM  
0.75 ADC

## MM301U

CURRENT  
LIMITIR  
COMP1 HP  
90 VDC  
1750 RPM  
10 ADCCURRENT  
LIMITIR  
COMP1 HP  
180 VDC  
1750 RPM  
5 ADCCURRENT  
LIMITIR  
COMP1/2 HP  
90 VDC  
1750 RPM  
5 ADCCURRENT  
LIMITIR  
COMP1/2 HP  
180 VDC  
1750 RPM  
2.5 ADCCURRENT  
LIMITIR  
COMP1/4 HP  
90 VDC  
1750 RPM  
1.4 ADCCURRENT  
LIMITIR  
COMP1/4 HP  
90 VDC  
1750 RPM  
1.2 ADC

**Figure 12. Typical CURRENT LIMIT, and IR COMP Settings for MM311U and MM301U (actual settings may vary with each application)**



---

## ACCELERATION (ACCEL)

The ACCEL setting determines the time the motor takes to ramp to a higher speed, within the limits of available torque. The ACCEL setting is factory set for its fastest acceleration time (full CCW).

To calibrate ACCEL:

1. Set the speed adjust potentiometer or input signal for minimum speed. The motor should run at minimum speed.
2. Set the speed adjust potentiometer or input signal to maximum speed, and measure the time it takes the motor to go from minimum to maximum speed.
3. If the time measured in step 2 is not the desired acceleration time, turn the ACCEL trimpot CW for a slower acceleration time, or CCW for a faster acceleration time.

Repeat steps 1 through 3 until the acceleration time is correct.

## DECELERATION (DECEL)

The DECEL setting determines the time the motor takes to ramp to lower speed, within the limits of available torque. The DECEL setting is factory set for its fastest deceleration time (full CCW).

To calibrate DECEL:

1. Set the speed adjust potentiometer or input signal for maximum speed. The motor should run at maximum speed.
2. Set the speed adjust potentiometer or input signal for minimum speed and measure the time it takes the motor to go from maximum to minimum speed.
3. If the time measured in step 2 is not the desired deceleration time, turn the DECEL trimpot CW for a slower deceleration time, or CCW for a faster deceleration time. Repeat steps 1 through 3 until the deceleration time is correct.

## TACH VOLTS

**Calibrate the TACH VOLTS setting only when a tachometer is used.** The TACH VOLTS setting, like the IR COMP setting, determines the degree to which the motor speed is held constant as the motor load changes.

To calibrate the TACH VOLTS trimpot:

1. Connect the tachometer to T1 and T2. The polarity is (+) for T1 and (-) for T2 when the motor is running in forward direction.
2. Set switch SW505 to ARM for armature feedback.
3. Set the speed adjust potentiometer or input signal to maximum speed.
4. Measure the armature voltage across A1 and A2 using a voltmeter.

5. Set the speed adjust potentiometer or input signal to minimum speed.
6. Remove power from the drive.
7. Set SW505 to TACH for tachometer feedback.
8. Connect power to the drive.
9. Set the IR COMP trimpot full CCW.
10. Set the TACH VOLTS trimpot full CW.
11. Set the speed adjust potentiometer or input signal to maximum speed.
12. Adjust the TACH VOLTS trimpot until the armature voltage is the same value as the voltage measured in step 3.

Check that the TACH VOLTS trimpot is properly calibrated. The motor should run at the same set speed when SW503 is set to either armature or tachometer feedback.

# Application Notes

## Multiple fixed speeds

Replace the speed adjust potentiometer with series resistors with a total series resistance of 10K ohms (Figure 13). Add a single pole, multi-position switch with the correct number of positions for the desired number of fixed speeds.




Figure 13. Multiple Fixed Speeds

## Adjustable speeds using potentiometers in series

Replace the speed adjust potentiometer with a single pole, multi-position switch, and two or more potentiometers in series, with a total series resistance of 10K ohms.

Figure 14 shows a connection for fixed high and low speed adjust potentiometers.




Figure 14. Adjustable Fixed Speeds Using Potentiometers in Series

## Independent adjustable speeds

Replace the speed adjust potentiometer with a single pole, multi-position switch, and two or more potentiometers in parallel, with a total parallel resistance of 10K ohms.

Figure 15 shows the connection of two independent speed adjust potentiometers that can be mounted at two separate operating stations.




Figure 15. Independent Adjustable Speeds

## Reversing

A dynamic brake may be used when reversing the motor direction (Figure 16). Use a two pole, three position switch rated for at least the maximum DC armature voltage and maximum braking current. Wait for the motor to stop completely before switching it to either the forward or reverse direction. See the Dynamic braking section, page 23, for sizing the dynamic brake resistor.




Figure 16. Reversing Circuit Connection

## RUN/JOG switch

Using a RUN/JOG switch is recommended in applications where quick stopping is not needed and frequent jogging is required. Use a single pole, two position switch for the RUN/JOG switch, and a single pole, normally closed, momentary operated pushbutton for the JOG pushbutton.

Connect the RUN/JOG switch and the JOG pushbutton as shown in Figure 17. When the RUN/JOG switch is set to JOG, the motor decelerates to minimum speed (minimum speed is determined by the MIN SPD trimpot setting). Press the JOG pushbutton to jog the motor. Return the RUN/JOG switch to RUN for normal operation.




Figure 17. RUN/JOG Switch Connection to Speed Adjust Potentiometer



## Reversing with a DIGI-LOK Controller, Model DLC600

A DIGI-LOK controller, model DLC600 can be used in a reversing application. The DIGI-LOK must be inhibited while braking. Without the inhibit feature, the DIGI-LOK will continue to regulate. This will cause overshoot when the DIGI-LOK is switched back to the drive. Figure 18 shows the connection of the reversing circuit to a MM300 series drive and to a DLC600. **Note:** Only one DLC option (Optical Encoder or Magnetic Pickup) may be used at a time.




Figure 18. Reversing with a DLC600

# Troubleshooting



## Warning

Dangerous voltages exist on the drive when it is powered. When possible, disconnect the drive while troubleshooting. High voltages can cause serious or fatal injury.

Check the following steps before proceeding:

1. The AC line voltage must be balanced, and match the voltage on the drive name-plate.
2. On dual voltage drives, check that the slide switches are set to the correct position.
3. The motor must be rated for the drive's rated armature (all motors) and field outputs (shunt wound motors only).
4. Do not make any connections to F1 and F2 when a permanent magnet motor is used.
5. Terminal block connections should be consistent with the connections shown in this manual.
6. Check that line fuses FU501 and F502 are properly sized and not blown.

For additional assistance, contact your local Minarik distributor, or the factory direct:

PHONE: (800) MINARIK or (800) 646-2745

FAX: (800) 624-6960

<b>Problem</b>	<b>Possible Causes</b>	<b>Suggested Solutions</b>
Line fuse blows	<ol style="list-style-type: none"><li>1. Line fuses are the wrong size.</li><li>2. Motor cable or armature is shorted to ground.</li><li>3. Nuisance tripping caused by a combination of ambient conditions and high-current spikes (i.e. reversing).</li><li>4. Field circuit is open.</li></ol>	<ol style="list-style-type: none"><li>1. Check that line fuses are correct for motor size (page 9).</li><li>2. Check motor cable and armature for shorts.</li><li>3. Add a blower to cool the drive components, or decrease the duty cycle of the system.</li><li>4. Send drive to Minarik repair department.</li></ol>
Motor runs too fast at maximum speed setting	<ol style="list-style-type: none"><li>1. MIN SPD and MAX SPD settings are too high.</li><li>2. Motor field connections are loose (shunt wound motors only).</li><li>3. Motor is demagnetized.</li><li>4. Tachometer leads are reversed.</li></ol>	<ol style="list-style-type: none"><li>1. Recalibrate MIN SPD and MAX SPD.</li><li>2. Check motor field connections.</li><li>3. Check for proper braking technique and method by which power is cycled.</li><li>4. Check tachometer connections.</li></ol>

Problem	Possible Causes	Suggested Solutions
Line fuse does not blow, but the motor does not run	<ol style="list-style-type: none"><li data-bbox="350 219 627 286">1. Speed adjust pot, voltage input signal, or current input signal set to zero speed.</li><li data-bbox="350 338 627 451">2. Speed adjust pot, voltage input signal, or current input signal not connected to drive input properly; connections are open.</li><li data-bbox="350 504 550 521">3. S2 is shorted to S1.</li><li data-bbox="350 574 578 592">4. Drive is in current limit.</li><li data-bbox="350 744 594 786">5. Drive is not receiving AC line voltage.</li><li data-bbox="350 839 584 856">6. Motor is not connected.</li><li data-bbox="350 936 627 1002">7. B1 not connected to B3 (if START/STOP push-buttons are not used).</li></ol>	<ol style="list-style-type: none"><li data-bbox="653 219 923 286">1. Increase the speed adjust pot, voltage, or current setting.</li><li data-bbox="653 341 923 408">2. Check connections to input. Verify that connections are not open.</li><li data-bbox="653 509 806 526">3. Remove short.</li><li data-bbox="653 582 907 669">4. Verify that motor is not jammed. Increase CURRENT LIMIT setting if it is set too low.</li><li data-bbox="653 749 917 791">5. Apply AC line voltage to L1 and L2.</li><li data-bbox="653 846 902 888">6. Connect motor to A1 and A2.</li><li data-bbox="653 943 847 961">7. Connect B1 to B3.</li></ol>

Problem	Possible Causes	Suggested Solutions
Line fuse blows	<ol style="list-style-type: none"><li>1. Line fuses are the wrong size.</li><li>2. Motor cable or armature is shorted to ground.</li><li>3. Nuisance tripping caused by a combination of ambient conditions and high-current spikes (i.e. reversing).</li><li>4. Field circuit is open.</li></ol>	<ol style="list-style-type: none"><li>1. Check that line fuses are correct for motor size (page 9).</li><li>2. Check motor cable and armature for shorts.</li><li>3. Add a blower to cool the drive components, or decrease the duty cycle of the system.</li><li>4. Send drive to Minarik repair department.</li></ol>
Motor runs too fast at maximum speed setting	<ol style="list-style-type: none"><li>1. MIN SPD and MAX SPD settings are too high.</li><li>2. Motor field connections are loose (shunt wound motors only).</li><li>3. Motor is demagnetized.</li><li>4. Tachometer leads are reversed.</li></ol>	<ol style="list-style-type: none"><li>1. Recalibrate MIN SPD and MAX SPD.</li><li>2. Check motor field connections.</li><li>3. Check for proper braking technique and method by which power is cycled.</li><li>4. Check tachometer connections.</li></ol>

## Block Diagram




Figure 19. MM301U and MM311U Block Diagram

## Replacement Parts

Replacement parts are available from Minarik Corporation and its distributors for this drive series.

**Table 3. Replacement Parts**

<b>Model No.</b>	<b>Symbol</b>	<b>Description</b>	<b>Minarik P/N</b>
<b>MM301U</b>	D501,502, 503	20 A, 800 V Diode, D8020L	071-0039
	IC503	IS0122P IC	060-0106
	R501	.01 Ohm, 5 W Resistor	032-0129
	SCR501-502	800 V, 20 SCR, S8020L	072-0043
	T501	DST-436 Transformer	230-0072
	FU501, 502	15 A Fuse, Normal Blow	050-0018
		Heat Sink	223-0252
	10K Ohm Potentiometer Kit	202-0003	
		63mA Pico fuse	050-0081
<b>MM311U</b>	Same as MM301U except:		
	R501	.1W, 5 W Resistor	032-0100
	FU501, 502	5 A , Fast Acting Fuse	050-0022

# Certificate of Compliance

Minarik Corporation hereby certifies that its MM300 series drives have been approved to bear the "CE" mark provided the conditions of approval (listed in Exhibit "A") have been met by the end user.

The MM300 series has been tested to the following test specifications:

**EN55011:1991 (emissions),**  
**EN50082-1:1992 (immunity)**

Compliance allows Minarik's MM300 series to bear the CE mark.

The end user, as described herein, falls into one of two categories:

1. The Consumer will deploy a stand-alone unit as an integral, yet external, portion of the machine he/she is operating.
2. The Original Equipment Manufacturer (OEM) will implement the product as a component of the machine being manufactured.

## Exhibit "A"

In addition to EMI/RFI safeguards inherent in the MM300 series' design, external filtering is required.

Minarik requires the Corcom<sup>®</sup> filters listed in Table 6. If the exact filter is not available, the specifications are as follows:

L = (1.73 + 0.03) milliHenries.

C = (0.27 + 0.54) microFarads (X); 0.0055 microFarads (Y).

R = 330Kohms.

Rated current: 1.4 times maximum DC motor current.

Filter type: Balanced 2-section.




**Table 4. Corcom® Filters**

Nameplate Current of Motor Wired to the Drive	Corcom® Filter Part Number
0 to 4 amps	6VV1
4.1 to 13 amps	20VV1

The filters in Table 6 must be wired to the AC output of the drive, as close to the drive as possible. The ground connection from the filter must be wired to solid earth ground (resistance less than 500 ohms); not machine ground. This is very important!

If the end-user is using a CE-approved motor, the correct filter from Table 6 is all that is necessary to meet the EMC directives listed herein.

If the end-user is not using a CE-approved motor, a Minarik CEXXMM filter must be deployed on the output. XX is the rated current on the filter



The CE20MM is a Real-Pole Balanced-Pi 3-pole filter. If the exact filter is not available, the specifications are as follows:

$L \text{ \& } L1 = 2 * (0.8) \text{ milliHenries.}$

$C \text{ \& } C1 = 2 * (0.1) \text{ microFarads @ 400W VDC.}$


$R_{in} = 0.1 \text{ ohm; } R_{out} = 1.2 \text{ ohm.}$

**Table 5. Minarik Filters**

Nameplate Current of Motor Wired to the Drive	Minarik Filter Part Number
0 to 4 amps	CE04MM
4.1 to 13 amps	CE20MM

The filters in Table 5 must be wired to the DC output of the drive, as close to the drive as possible. The ground connection from the filter must be wired to solid earth ground (resistance less than 500 ohms); not machine ground. This is very important!

The end user must use the filtration listed in Exhibit A to comply with CE. The OEM may choose to provide alternative filtering that encompasses the Minarik drive and other electronics within the same panel.



The OEM has this liberty because CE is a machinery directive. Whether or not every component in the OEM's machinery meets CE, the OEM must still submit his machine for CE approval. Thus, no component must necessarily meet CE within the machine, as long as the OEM takes the necessary steps to guarantee the machine does meet CE. By the same token, even if every component in the OEM's machine does meet CE, the machine will not necessarily meet CE as a machine.

Use of CE-approved wiring practices, such as proper shielding, and the filters listed in Exhibit A guarantee the drive will meet EN55011 (1991 emissions standard) and EN50082-1 (1992 immunity standard).

---

# Unconditional Warranty

**A. Warranty** - Minarik Corporation (referred to as "the Corporation") warrants that its products will be free from defects in workmanship and material for twelve (12) months or 3,000 hours, whichever comes first, from date of manufacture thereof. Within this warranty period, the Corporation will repair or replace, at its sole discretion, such products that are returned to Minarik Drives, 14300 De La Tour Drive, South Beloit, IL 61080 USA.

This warranty applies only to standard catalog products, and does not apply to specials. Any returns for special controls will be evaluated on a case-by-case basis. The Corporation is not responsible for removal, installation, or any other incidental expenses incurred in shipping the product to and from the repair point.

**B. Disclaimer** - The provisions of Paragraph A are the Corporation's sole obligation and exclude all other warranties of merchantability for use, express or implied. The Corporation further disclaims any responsibility whatsoever to the customer or to any other person for injury to the person or damage or loss of property of value caused by any product that has been subject to misuse, negligence, or accident, or misapplied or modified by unauthorized persons or improperly installed.

**C. Limitations of Liability** - In the event of any claim for breach of any of the Corporation's obligations, whether express or implied, and particularly of any other claim or breach of warranty contained in Paragraph A, or of any other warranties, express or implied, or claim of liability that might, despite Paragraph B, be decided against the Corporation by lawful authority, the Corporation shall under no circumstances be liable for any consequential damages, losses, or expense arising in connection with the use of, or inability to use, the Corporation's product for any purpose whatsoever.

An adjustment made under warranty does not void the warranty, nor does it imply an extension of the original 12-month warranty period. Products serviced and/or parts replaced on a no-charge basis during the warranty period carry the unexpired portion of the original warranty only.

If for any reason any of the foregoing provisions shall be ineffective, the Corporation's liability for damages arising out of its manufacture or sale of equipment, or use thereof, whether such liability is based on warranty, contract, negligence, strict liability in tort, or otherwise, shall not in any event exceed the full purchase price of such equipment.

Any action against the Corporation based upon any liability or obligation arising hereunder or under any law applicable to the sale of equipment or the use thereof, must be commenced within one year after the cause of such action arises.

# Notes

## OTHER PRODUCTS BY MINARIK DRIVES



**PCM4**



**C4XL3200A**



**DLC600**



**MINARIK DRIVES**  
[www.minarikdrives.com](http://www.minarikdrives.com)

14300 De La Tour Drive, South Beloit, IL 61080

Phone: (800) 646-2745

Fax: (800) 624-6960

Document number 250-0175, Revision 8

Printed in the U.S.A - 10/05